Shenzhen Xtooltech Co., Ltd

INFINITI Function List V11.90

Tips and Instructions:

* This feature is new.

√ This feature is supported.

This feature is not supported.

※ This feature is partially supported.

Country	Model	Vehicle Type	Year	System Name	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Actuation Test	Special Functions
Abu dhabi	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Abu dhabi	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Abu dhabi	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Abu dhabi	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Abu dhabi	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Abu dhabi	INFINITI EX35	I50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Abu dhabi	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Abu dhabi	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI EX35	I50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Abu dhabi	INFINITI EX35	I50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Abu dhabi	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Abu dhabi	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Abu dhabi	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Abu dhabi	INFINITI EX35/EX37	I50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Abu dhabi	INFINITI EX35/EX37	I50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI EX35/EX37	I50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Abu dhabi	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Abu dhabi	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Abu dhabi	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Abu dhabi	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349

XTOOL

Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Abu dhabi	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Abu dhabi	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Abu dhabi	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Abu dhabi	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Abu dhabi	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Abu dhabi	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Abu dhabi	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Abu dhabi	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Abu dhabi	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Abu dhabi	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Abu dhabi	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Abu dhabi	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		

Abu dhabi	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957	
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Abu dhabi	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Abu dhabi	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Abu dhabi	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Abu dhabi	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Abu dhabi	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Abu dhabi	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Abu dhabi	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Abu dhabi	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276,SP0278,SP0279
Abu dhabi	INFINITI JX35	L50	2012.5-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Abu dhabi	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Abu dhabi	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0487
Abu dhabi	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Abu dhabi	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Abu dhabi	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Abu dhabi	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Abu dhabi	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Abu dhabi	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Abu dhabi	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Abu dhabi	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Abu dhabi	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Abu dhabi	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831,AC0856	
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347,SP0348,SP0349
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653,AC0698	SP0391,SP0393
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561,SP0562
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0922,AC0923,AC0924,AC0925,AC0926,AC0928	SP0511,SP0512,SP0518,SP0520,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0529,SP0530,SP0531,SP0532,SP0534,SP0535,SP0536,SP0537
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570,SP0571
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Abu dhabi	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546,AC0547,AC0548,AC0549	SP0342,SP0343,SP0344

Abu dhabi	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Abu dhabi	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Abu dhabi	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Abu dhabi	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Abu dhabi	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Abu dhabi	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Abu dhabi	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Abu dhabi	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Abu dhabi	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Abu dhabi	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Abu dhabi	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Abu dhabi	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Abu dhabi	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Abu dhabi	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Abu dhabi	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Abu dhabi	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Abu dhabi	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Abu dhabi	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Abu dhabi	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Abu dhabi	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Abu dhabi	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Abu dhabi	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Abu dhabi	INFINITI Q45	F50	2001.8-	Motor control						

Abu dhabi	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Abu dhabi	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Abu dhabi	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Abu dhabi	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Abu dhabi	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Abu dhabi	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Abu dhabi	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Abu dhabi	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Abu dhabi	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Abu dhabi	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Abu dhabi	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Abu dhabi	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Abu dhabi	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Abu dhabi	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Abu dhabi	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Abu dhabi	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Abu dhabi	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Abu dhabi	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Abu dhabi	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Abu dhabi	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Abu dhabi	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Abu dhabi	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Abu dhabi	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Abu dhabi	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Abu dhabi	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Abu dhabi	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Abu dhabi	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Abu dhabi	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Abu dhabi	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Abu dhabi	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Abu dhabi	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Abu dhabi	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Abu dhabi	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Abu dhabi	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Abu dhabi	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Abu dhabi	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Abu dhabi	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Abu dhabi	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Abu dhabi	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Abu dhabi	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Abu dhabi	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Abu dhabi	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Abu dhabi	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Abu dhabi	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Abu dhabi	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Abu dhabi	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Abu dhabi	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Abu dhabi	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Abu dhabi	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Abu dhabi	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Abu dhabi	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Abu dhabi	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Abu dhabi	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Abu dhabi	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Abu dhabi	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Abu dhabi	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Abu dhabi	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Abu dhabi	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Abu dhabi	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Abu dhabi	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Abu dhabi	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Abu dhabi	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247,SP0265,SP0274,SP0276
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Abu dhabi	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0009,SP0016,SP0032,SP0033,SP0038,SP0039,SP0053,SP0063,SP0064,SP0074,SP0079,SP0082,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Abu dhabi	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Abu dhabi	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Abu dhabi	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Abu dhabi	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Abu dhabi	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Abu dhabi	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Abu dhabi	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Abu dhabi	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Abu dhabi	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Abu dhabi	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Abu dhabi	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Abu dhabi	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Abu dhabi	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Abu dhabi	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Abu dhabi	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Abu dhabi	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Abu dhabi	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Abu dhabi	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Abu dhabi	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Abu dhabi	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Abu dhabi	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Abu dhabi	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Abu dhabi	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Abu dhabi	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Abu dhabi	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Abu dhabi	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Abu dhabi	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Abu dhabi	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		

Abu dhabi	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Abu dhabi	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Abu dhabi	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Abu dhabi	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Abu dhabi	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Abu dhabi	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Abu dhabi	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Abu dhabi	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Abu dhabi	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Abu dhabi	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Abu dhabi	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Abu dhabi	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Abu dhabi	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Abu dhabi	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Abu dhabi	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Abu dhabi	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Abu dhabi	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Abu dhabi	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Abu dhabi	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0247,SP0265,SP0270,SP0274,SP0276
Abu dhabi	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Abu dhabi	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Abu dhabi	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Abu dhabi	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Abu dhabi	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Abu dhabi	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Abu dhabi	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Abu dhabi	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Abu dhabi	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Abu dhabi	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584

Abu dhabi	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Abu dhabi	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Abu dhabi	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Abu dhabi	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Abu dhabi	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Abu dhabi	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Abu dhabi	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Abu dhabi	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Abu dhabi	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Abu dhabi	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Abu dhabi	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Abu dhabi	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Abu dhabi	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Abu dhabi	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Abu dhabi	INFINITI Q70	Y51	2013.9-	PSCM	√	√	√	√	AC1109	
Abu dhabi	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Abu dhabi	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Abu dhabi	INFINITI QX50	I50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Abu dhabi	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Abu dhabi	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Abu dhabi	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Abu dhabi	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Abu dhabi	INFINITI QX50	I50	2013.6-	Transmission	√	√	√	√		SP0274
Abu dhabi	INFINITI QX50	I50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Abu dhabi	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Abu dhabi	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI QX50	I50	2013.6-	Occupant detection			√	√		SP0584
Abu dhabi	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Abu dhabi	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Abu dhabi	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Abu dhabi	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Abu dhabi	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Abu dhabi	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Abu dhabi	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Abu dhabi	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Abu dhabi	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Abu dhabi	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Abu dhabi	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Abu dhabi	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Abu dhabi	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Abu dhabi	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Abu dhabi	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Abu dhabi	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Abu dhabi	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Abu dhabi	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Abu dhabi	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Abu dhabi	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Abu dhabi	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Abu dhabi	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Abu dhabi	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Abu dhabi	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Abu dhabi	INFINITI QX50	J55	2018.5-	Shift						
Abu dhabi	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Abu dhabi	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Abu dhabi	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Abu dhabi	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Abu dhabi	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Abu dhabi	INFINITI QX50	I55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI QX50	I55	2018.5-	CAN gateway	√	√	√	√		
Abu dhabi	INFINITI QX50	I55	2018.5-	Lane camera	√	√	√	√		
Abu dhabi	INFINITI QX50	I55	2018.5-	DAST 1	√	√	√	√		
Abu dhabi	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Abu dhabi	INFINITI QX50	J55	2018.5-	ANC						
Abu dhabi	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Abu dhabi	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Abu dhabi	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Abu dhabi	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Abu dhabi	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Abu dhabi	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Abu dhabi	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Abu dhabi	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Abu dhabi	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Abu dhabi	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Abu dhabi	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Abu dhabi	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Abu dhabi	INFINITI QX56	JA60	2004.10-	Motor control						
Abu dhabi	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Abu dhabi	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471

Abu dhabi	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Abu dhabi	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Abu dhabi	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Abu dhabi	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Abu dhabi	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Abu dhabi	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Abu dhabi	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962. AC0963. AC0964. AC0966. AC0967. AC0968. AC0969. AC0970	SP0553. SP0554. SP0555. SP0556. SP0557. SP0558. SP0559
Abu dhabi	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Abu dhabi	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Abu dhabi	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Abu dhabi	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Abu dhabi	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Abu dhabi	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Abu dhabi	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Abu dhabi	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Abu dhabi	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Abu dhabi	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Abu dhabi	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572. SP0573
Abu dhabi	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Abu dhabi	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Abu dhabi	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Abu dhabi	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Abu dhabi	INFINITI QX56	Z62	2010.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Abu dhabi	INFINITI QX56	Z62	2010.3-	Laser/radar	√	√	√	√		
Abu dhabi	INFINITI QX56	Z62	2010.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI QX56	Z62	2010.3-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Abu dhabi	INFINITI QX56	Z62	2010.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI QX56	Z62	2010.3-	Air bag	√	√	√	√		
Abu dhabi	INFINITI QX56	Z62	2010.3-	Meter/M&A	√	√	√	√		SP0347. SP0348. SP0349. SP0350. SP0351
Abu dhabi	INFINITI QX56	Z62	2010.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI QX56	Z62	2010.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Abu dhabi	INFINITI QX56	Z62	2010.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Abu dhabi	INFINITI QX56	Z62	2010.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Abu dhabi	INFINITI QX56	Z62	2010.3-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI QX56	Z62	2010.3-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Abu dhabi	INFINITI QX56	Z62	2010.3-	E-SUS	√	√	√	√	AC1031. AC1032. AC1033	SP0585. SP0586. SP0587
Abu dhabi	INFINITI QX56	Z62	2010.3-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI QX56	Z62	2010.3-	Auto back door	√	√	√	√		
Abu dhabi	INFINITI QX56	Z62	2010.3-	Occupant detection			√	√		SP0584
Abu dhabi	INFINITI QX56	Z62	2010.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Abu dhabi	INFINITI QX56	Z62	2010.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Abu dhabi	INFINITI QX56	Z62	2010.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Abu dhabi	INFINITI QX56	Z62	2010.3-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Abu dhabi	INFINITI QX56	Z62	2010.3-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI QX56	Z62	2010.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI QX56	Z62	2010.3-	CAN gateway	√	√	√			
Abu dhabi	INFINITI QX56	Z62	2010.3-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Abu dhabi	INFINITI QX56	Z62	2010.3-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI QX56	Z62	2010.3-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Abu dhabi	INFINITI QX56	Z62	2010.3-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI QX56	Z62	2010.3-	Rearview camera	√			√		SP0570, SP0571
Abu dhabi	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Abu dhabi	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Abu dhabi	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Abu dhabi	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Abu dhabi	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Abu dhabi	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Abu dhabi	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Abu dhabi	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Abu dhabi	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Abu dhabi	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Abu dhabi	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Abu dhabi	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Abu dhabi	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Abu dhabi	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Abu dhabi	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Abu dhabi	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Abu dhabi	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553. SP0554. SP0555. SP0556. SP0557. SP0558. SP0559
Abu dhabi	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Abu dhabi	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983. AC0984. AC0985. AC0986. AC0987. AC0988. AC0989. AC0990	SP0563. SP0564. SP0565. SP0566. SP0567
Abu dhabi	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Abu dhabi	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Abu dhabi	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Abu dhabi	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Abu dhabi	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Abu dhabi	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Abu dhabi	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Abu dhabi	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Abu dhabi	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Abu dhabi	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Abu dhabi	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		

Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Abu dhabi	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Abu dhabi	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Abu dhabi	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Abu dhabi	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Abu dhabi	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Abu dhabi	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Abu dhabi	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Abu dhabi	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Abu dhabi	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Abu dhabi	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Abu dhabi	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Abu dhabi	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Abu dhabi	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Abu dhabi	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Abu dhabi	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Abu dhabi	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Abu dhabi	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Abu dhabi	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Abu dhabi	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Abu dhabi	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Abu dhabi	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Abu dhabi	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Abu dhabi	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Abu dhabi	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Abu dhabi	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Abu dhabi	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Abu dhabi	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Abu dhabi	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Abu dhabi	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Abu dhabi	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Abu dhabi	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Abu dhabi	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Abu dhabi	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Abu dhabi	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Abu dhabi	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Abu dhabi	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Abu dhabi	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Abu dhabi	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Abu dhabi	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Abu dhabi	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Abu dhabi	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Abu dhabi	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Abu dhabi	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Abu dhabi	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Abu dhabi	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Abu dhabi	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Abu dhabi	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Abu dhabi	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Abu dhabi	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Abu dhabi	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Abu dhabi	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Abu dhabi	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Abu dhabi	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Abu dhabi	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Abu dhabi	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Abu dhabi	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Abu dhabi	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Abu dhabi	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Abu dhabi	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Abu dhabi	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Abu dhabi	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Abu dhabi	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Abu dhabi	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Abu dhabi	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		

Abu dhabi	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Afghanistan	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Afghanistan	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Afghanistan	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Afghanistan	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Afghanistan	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Afghanistan	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Afghanistan	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Afghanistan	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Afghanistan	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Afghanistan	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		

Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Afghanistan	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		

Afghanistan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Afghanistan	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	

Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Afghanistan	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Afghanistan	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Afghanistan	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Afghanistan	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Afghanistan	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Afghanistan	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Afghanistan	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Afghanistan	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Afghanistan	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Afghanistan	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Afghanistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503

Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Afghanistan	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Afghanistan	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Afghanistan	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Afghanistan	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Afghanistan	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Afghanistan	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Afghanistan	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Afghanistan	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Afghanistan	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Afghanistan	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Afghanistan	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Afghanistan	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Afghanistan	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Afghanistan	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Afghanistan	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Afghanistan	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Afghanistan	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Afghanistan	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Afghanistan	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Afghanistan	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Afghanistan	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Afghanistan	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Afghanistan	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Afghanistan	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Afghanistan	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Afghanistan	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Afghanistan	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	

Afghanistan	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Afghanistan	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Afghanistan	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Afghanistan	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Afghanistan	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Afghanistan	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Afghanistan	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Afghanistan	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Afghanistan	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Afghanistan	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Afghanistan	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Afghanistan	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Afghanistan	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Afghanistan	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Afghanistan	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Afghanistan	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Afghanistan	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Afghanistan	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Afghanistan	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Afghanistan	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Afghanistan	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Afghanistan	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Afghanistan	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Afghanistan	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Afghanistan	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Afghanistan	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Afghanistan	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		

Afghanistan	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Afghanistan	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Afghanistan	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Afghanistan	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Afghanistan	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Afghanistan	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Afghanistan	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Afghanistan	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510

XTOOL

Afghanistan	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Afghanistan	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Afghanistan	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Afghanistan	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Afghanistan	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Afghanistan	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Afghanistan	INFINITI Q45	F50	2001.8-	Motor control						
Afghanistan	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Afghanistan	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Afghanistan	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Afghanistan	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Afghanistan	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Afghanistan	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Afghanistan	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Afghanistan	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Afghanistan	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Afghanistan	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Afghanistan	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Afghanistan	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Afghanistan	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Afghanistan	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Afghanistan	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Afghanistan	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Afghanistan	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Afghanistan	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Afghanistan	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Afghanistan	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Afghanistan	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Afghanistan	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Afghanistan	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Afghanistan	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Afghanistan	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Afghanistan	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Afghanistan	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Afghanistan	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Afghanistan	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Afghanistan	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Afghanistan	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Afghanistan	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Afghanistan	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Afghanistan	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Afghanistan	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Afghanistan	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562

XTOOL

Afghanistan	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Afghanistan	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Afghanistan	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Afghanistan	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Afghanistan	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Afghanistan	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Afghanistan	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Afghanistan	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Afghanistan	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Afghanistan	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Afghanistan	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Afghanistan	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Afghanistan	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Afghanistan	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Afghanistan	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Afghanistan	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Afghanistan	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Afghanistan	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Afghanistan	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Afghanistan	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Afghanistan	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582

Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Afghanistan	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0009,SP0016,SP0032,SP0033,SP0038,SP0039,SP0053,SP0063,SP0064,SP0074,SP0079,SP0082,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Afghanistan	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Afghanistan	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Afghanistan	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Afghanistan	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Afghanistan	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Afghanistan	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Afghanistan	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Afghanistan	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Afghanistan	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Afghanistan	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274

Afghanistan	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Afghanistan	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Afghanistan	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Afghanistan	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Afghanistan	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Afghanistan	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Afghanistan	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Afghanistan	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Afghanistan	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Afghanistan	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Afghanistan	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Afghanistan	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Afghanistan	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Afghanistan	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Afghanistan	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Afghanistan	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Afghanistan	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Afghanistan	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Afghanistan	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Afghanistan	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Afghanistan	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Afghanistan	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Afghanistan	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Afghanistan	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Afghanistan	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Afghanistan	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Afghanistan	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Afghanistan	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Afghanistan	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Afghanistan	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Afghanistan	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Afghanistan	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Afghanistan	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Afghanistan	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Afghanistan	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Afghanistan	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Afghanistan	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Afghanistan	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Afghanistan	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Afghanistan	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Afghanistan	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Afghanistan	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Afghanistan	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Afghanistan	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Afghanistan	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Afghanistan	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Afghanistan	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Afghanistan	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Afghanistan	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Afghanistan	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Afghanistan	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Afghanistan	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Afghanistan	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Afghanistan	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Afghanistan	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Afghanistan	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Afghanistan	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Afghanistan	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Afghanistan	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Afghanistan	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Afghanistan	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Afghanistan	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Afghanistan	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Afghanistan	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Afghanistan	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Afghanistan	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Afghanistan	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Afghanistan	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Afghanistan	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Afghanistan	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Afghanistan	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Afghanistan	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Afghanistan	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI QX50	J55	2018.5-	Shift						
Afghanistan	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Afghanistan	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	ANC						
Afghanistan	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Afghanistan	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583

Afghanistan	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Afghanistan	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Afghanistan	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Afghanistan	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Afghanistan	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Afghanistan	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Afghanistan	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Afghanistan	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Afghanistan	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Afghanistan	INFINITI QX56	JA60	2004.10-	Motor control						
Afghanistan	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Afghanistan	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Afghanistan	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Afghanistan	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Afghanistan	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Afghanistan	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Afghanistan	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Afghanistan	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Afghanistan	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Afghanistan	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Afghanistan	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Afghanistan	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Afghanistan	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Afghanistan	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Afghanistan	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Afghanistan	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Afghanistan	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Afghanistan	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Afghanistan	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Afghanistan	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Afghanistan	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Afghanistan	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Afghanistan	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Afghanistan	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Afghanistan	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Afghanistan	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Afghanistan	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Afghanistan	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Afghanistan	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270, SP0274
Afghanistan	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Afghanistan	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Afghanistan	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Afghanistan	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Afghanistan	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Afghanistan	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Afghanistan	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Afghanistan	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Afghanistan	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Afghanistan	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Afghanistan	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Afghanistan	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Afghanistan	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Afghanistan	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Afghanistan	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Afghanistan	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Afghanistan	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Afghanistan	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Afghanistan	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Afghanistan	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Afghanistan	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Afghanistan	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Afghanistan	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Afghanistan	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Afghanistan	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Afghanistan	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Afghanistan	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Afghanistan	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Afghanistan	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Afghanistan	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Afghanistan	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Afghanistan	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Afghanistan	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Afghanistan	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Afghanistan	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Afghanistan	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315

Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Afghanistan	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Afghanistan	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Afghanistan	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Afghanistan	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Afghanistan	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Afghanistan	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Afghanistan	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Afghanistan	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Afghanistan	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Afghanistan	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Afghanistan	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Afghanistan	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Afghanistan	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Afghanistan	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Afghanistan	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Afghanistan	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Afghanistan	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Afghanistan	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Afghanistan	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Afghanistan	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Afghanistan	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Afghanistan	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Afghanistan	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Afghanistan	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Afghanistan	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Afghanistan	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Afghanistan	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Afghanistan	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Afghanistan	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Afghanistan	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Afghanistan	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Afghanistan	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Afghanistan	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Afghanistan	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Afghanistan	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Afghanistan	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Afghanistan	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Afghanistan	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Afghanistan	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Afghanistan	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Afghanistan	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Afghanistan	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Afghanistan	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Afghanistan	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Afghanistan	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Afghanistan	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Afghanistan	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Afghanistan	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Afghanistan	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Afghanistan	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Afghanistan	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Afghanistan	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Afghanistan	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Afghanistan	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Afghanistan	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Afghanistan	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Afghanistan	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Afghanistan	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Afghanistan	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Afghanistan	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Afghanistan	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Afghanistan	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Africa common	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Africa common	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Africa common	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Africa common	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Africa common	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Africa common	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Africa common	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Africa common	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Africa common	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Africa common	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Africa common	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Africa common	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Africa common	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Africa common	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Africa common	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Africa common	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Africa common	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Africa common	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Africa common	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Africa common	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Africa common	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

XTOOL

Africa common	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Africa common	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Africa common	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Africa common	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Africa common	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Africa common	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Africa common	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Africa common	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Africa common	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Africa common	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Africa common	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Africa common	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Africa common	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Africa common	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Africa common	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Africa common	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Africa common	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Africa common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Africa common	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Africa common	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Africa common	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Africa common	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Africa common	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Africa common	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Africa common	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Africa common	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Africa common	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Africa common	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Africa common	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Africa common	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Africa common	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Africa common	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Africa common	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Africa common	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Africa common	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Africa common	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Africa common	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Africa common	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Africa common	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Africa common	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Africa common	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Africa common	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Africa common	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Africa common	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Africa common	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Africa common	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Africa common	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Africa common	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Africa common	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Africa common	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Africa common	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Africa common	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Africa common	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Africa common	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Africa common	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Africa common	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Africa common	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Africa common	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Africa common	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Africa common	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Africa common	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Africa common	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Africa common	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Africa common	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Africa common	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		

Africa common	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Africa common	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Africa common	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Africa common	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Africa common	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Africa common	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Africa common	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Africa common	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Africa common	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Africa common	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Africa common	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Africa common	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Africa common	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Africa common	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Africa common	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Africa common	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Africa common	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Africa common	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Africa common	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Africa common	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Africa common	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Africa common	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Africa common	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Africa common	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Africa common	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Africa common	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Africa common	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Africa common	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Africa common	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Africa common	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Africa common	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Africa common	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Africa common	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Africa common	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Africa common	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Africa common	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Africa common	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Africa common	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Africa common	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Africa common	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Africa common	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Africa common	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Africa common	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Africa common	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Africa common	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Africa common	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Africa common	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582

Africa common	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Africa common	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Africa common	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Africa common	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Africa common	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0330,AC0331,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247,SP0274,SP0276
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979,AC0981,AC0982	SP0562
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
Africa common	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Africa common	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Africa common	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Africa common	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Africa common	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Africa common	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Africa common	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Africa common	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Africa common	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Africa common	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Africa common	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Africa common	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Africa common	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		

Africa common	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Africa common	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Africa common	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Africa common	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Africa common	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Africa common	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Africa common	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Africa common	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Africa common	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Africa common	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Africa common	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Africa common	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Africa common	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Africa common	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Africa common	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Africa common	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Africa common	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Africa common	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Africa common	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Africa common	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Africa common	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Africa common	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Africa common	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Africa common	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Africa common	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		

Africa common	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Africa common	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Africa common	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Africa common	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Africa common	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Africa common	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Africa common	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Africa common	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Africa common	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Africa common	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Africa common	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Africa common	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Africa common	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Africa common	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Africa common	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Africa common	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Africa common	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Africa common	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Africa common	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Africa common	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Africa common	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Africa common	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Africa common	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Africa common	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Africa common	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Africa common	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Africa common	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Africa common	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Africa common	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Africa common	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Africa common	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Africa common	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Africa common	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Africa common	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Africa common	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Africa common	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Africa common	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Africa common	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Africa common	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Africa common	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Africa common	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Africa common	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Africa common	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Africa common	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Africa common	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	

Africa common	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Africa common	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Africa common	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Africa common	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Africa common	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Africa common	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Africa common	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Africa common	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Africa common	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Africa common	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Africa common	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Africa common	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Africa common	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Africa common	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Africa common	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Africa common	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Africa common	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Africa common	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Africa common	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Africa common	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Africa common	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Africa common	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Africa common	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Africa common	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Africa common	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Africa common	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Africa common	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Africa common	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Africa common	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Africa common	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Africa common	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Africa common	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Africa common	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Africa common	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Africa common	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Africa common	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Africa common	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Africa common	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Africa common	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Africa common	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Africa common	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Africa common	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Africa common	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Africa common	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Africa common	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Africa common	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Africa common	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Africa common	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Africa common	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Africa common	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Africa common	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Africa common	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Africa common	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Africa common	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Africa common	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Africa common	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Africa common	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Africa common	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562

Africa common	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Africa common	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Africa common	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Africa common	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Africa common	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Africa common	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Africa common	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Africa common	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Africa common	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Africa common	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Africa common	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Africa common	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Africa common	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Africa common	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Africa common	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Albania	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Albania	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Albania	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Albania	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Albania	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Albania	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Albania	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Albania	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Albania	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Albania	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Albania	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Albania	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Albania	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Albania	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Albania	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Albania	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Albania	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Albania	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Albania	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Albania	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Albania	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Albania	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Albania	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Albania	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Albania	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Albania	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Albania	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Albania	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	

Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Albania	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Albania	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Albania	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Albania	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Albania	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Albania	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Albania	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Albania	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Albania	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Albania	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Albania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Albania	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Albania	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Albania	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Albania	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Albania	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Albania	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Albania	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Albania	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Albania	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Albania	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Albania	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Albania	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Albania	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Albania	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Albania	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Albania	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Albania	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Albania	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Albania	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Albania	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Albania	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Albania	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Albania	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Albania	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Albania	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Albania	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Albania	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Albania	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Albania	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Albania	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Albania	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Albania	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Albania	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Albania	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Albania	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Albania	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Albania	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Albania	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Albania	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Albania	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Albania	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Albania	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Albania	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Albania	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Albania	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Albania	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Albania	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Albania	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Albania	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Albania	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Albania	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Albania	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Albania	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Albania	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Albania	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Albania	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Albania	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Albania	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Albania	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Albania	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Albania	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Albania	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Albania	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Albania	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Albania	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Albania	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Albania	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Albania	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	

Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Albania	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Albania	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Albania	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Albania	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Albania	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Albania	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Albania	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Albania	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Albania	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Albania	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Albania	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Albania	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Albania	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Albania	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Albania	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Albania	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Albania	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Albania	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Albania	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Albania	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Albania	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Albania	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Albania	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Albania	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Albania	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Albania	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Albania	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Albania	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Albania	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Albania	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Albania	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Albania	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Albania	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Albania	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Albania	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Albania	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Albania	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Albania	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Albania	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Albania	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

XTOOL

Albania	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Albania	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Albania	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Albania	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Albania	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Albania	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Albania	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Albania	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Albania	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Albania	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Albania	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Albania	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Albania	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Albania	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Albania	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Albania	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Albania	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Albania	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Albania	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Albania	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Albania	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Albania	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Albania	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Albania	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Albania	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Albania	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Albania	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Albania	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Albania	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Albania	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Albania	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Albania	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Albania	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Albania	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Albania	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Albania	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Albania	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Albania	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Albania	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Albania	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Albania	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Albania	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Albania	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Albania	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Albania	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		

Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Albania	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Albania	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Albania	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Albania	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Albania	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Albania	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Albania	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Albania	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Albania	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Albania	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Albania	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Albania	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Albania	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Albania	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Albania	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Albania	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Albania	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Albania	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Albania	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Albania	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Albania	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Albania	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Albania	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Albania	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Albania	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Albania	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Albania	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Albania	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Albania	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Albania	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Albania	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Albania	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Albania	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Albania	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Albania	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Albania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Albania	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Albania	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Albania	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Albania	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Albania	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Albania	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Albania	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Albania	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Albania	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Albania	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Albania	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Albania	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Albania	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Albania	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Albania	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Albania	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Albania	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Albania	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Albania	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Albania	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Albania	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Albania	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Albania	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Albania	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Albania	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Albania	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Albania	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Albania	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Albania	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Albania	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Albania	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Albania	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Albania	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Albania	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Albania	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Albania	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Albania	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Albania	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Albania	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Albania	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Albania	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Albania	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Albania	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Albania	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Albania	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Albania	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Albania	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559

Xtool

Albania	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Albania	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Albania	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Albania	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Albania	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Albania	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Albania	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Albania	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Albania	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Albania	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Albania	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Albania	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Albania	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Albania	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Albania	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Albania	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Albania	INFINITI QX50	I50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Albania	INFINITI QX50	I50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Albania	INFINITI QX50	I50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Albania	INFINITI QX50	I50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Albania	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Albania	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Albania	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Albania	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Albania	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Albania	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Albania	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Albania	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Albania	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Albania	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Albania	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Albania	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Albania	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Albania	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Albania	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Albania	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Albania	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Albania	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Albania	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Albania	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Albania	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Albania	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Albania	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Albania	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Albania	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Albania	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Albania	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Albania	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Albania	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Albania	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Albania	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Albania	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Albania	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Albania	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Albania	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Albania	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Albania	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Albania	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Albania	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Albania	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Albania	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Albania	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Albania	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Albania	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Albania	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Albania	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Albania	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Albania	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Albania	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Albania	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Albania	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Albania	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Algeria	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Algeria	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Algeria	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Algeria	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Algeria	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Algeria	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Algeria	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Algeria	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Algeria	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Algeria	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Algeria	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Algeria	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Algeria	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Algeria	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Algeria	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Algeria	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Algeria	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Algeria	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Algeria	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Algeria	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Algeria	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Algeria	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Algeria	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Algeria	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Algeria	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Algeria	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Algeria	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Algeria	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Algeria	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Algeria	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Algeria	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Algeria	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Algeria	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Algeria	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Algeria	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Algeria	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0238, SP0239
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

XTOOL

Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Algeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Algeria	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Algeria	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Algeria	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Algeria	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Algeria	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Algeria	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Algeria	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Algeria	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Algeria	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Algeria	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Algeria	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Algeria	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Algeria	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Algeria	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Algeria	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Algeria	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Algeria	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Algeria	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Algeria	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Algeria	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Algeria	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Algeria	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Algeria	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Algeria	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Algeria	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Algeria	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Algeria	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Algeria	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Algeria	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Algeria	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Algeria	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Algeria	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Algeria	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Algeria	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Algeria	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Algeria	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Algeria	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Algeria	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Algeria	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Algeria	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Algeria	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Algeria	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Algeria	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Algeria	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Algeria	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Algeria	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Algeria	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Algeria	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Algeria	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Algeria	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Algeria	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Algeria	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Algeria	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Algeria	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Algeria	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Algeria	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Algeria	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Algeria	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Algeria	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		

Algeria	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Algeria	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Algeria	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Algeria	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Algeria	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Algeria	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Algeria	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Algeria	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Algeria	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Algeria	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Algeria	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Algeria	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Algeria	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Algeria	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Algeria	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Algeria	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Algeria	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Algeria	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Algeria	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Algeria	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Algeria	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Algeria	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Algeria	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Algeria	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Algeria	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Algeria	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Algeria	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Algeria	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Algeria	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Algeria	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Algeria	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Algeria	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Algeria	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Algeria	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Algeria	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Algeria	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Algeria	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Algeria	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Algeria	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Algeria	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Algeria	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Algeria	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Algeria	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Algeria	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Algeria	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Algeria	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274

Algeria	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Algeria	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Algeria	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Algeria	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Algeria	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Algeria	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Algeria	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Algeria	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Algeria	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Algeria	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Algeria	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Algeria	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Algeria	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Algeria	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Algeria	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Algeria	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Algeria	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Algeria	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Algeria	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Algeria	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Algeria	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Algeria	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Algeria	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Algeria	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Algeria	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Algeria	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Algeria	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Algeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Algeria	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Algeria	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Algeria	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Algeria	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Algeria	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Algeria	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Algeria	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Xtool

Algeria	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Algeria	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Algeria	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Algeria	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Algeria	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Algeria	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Algeria	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Algeria	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Algeria	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Algeria	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Algeria	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Algeria	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Algeria	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Algeria	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Algeria	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Algeria	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Algeria	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Algeria	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Algeria	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Algeria	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Algeria	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Algeria	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Algeria	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Algeria	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Algeria	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Algeria	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Algeria	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Algeria	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Algeria	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Algeria	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Algeria	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Algeria	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Algeria	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Algeria	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Algeria	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Algeria	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Algeria	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Algeria	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Algeria	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Algeria	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Algeria	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Algeria	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Algeria	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Algeria	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Algeria	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Algeria	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Algeria	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Algeria	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Algeria	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Algeria	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Algeria	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Algeria	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Algeria	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Algeria	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Algeria	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Algeria	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Algeria	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Algeria	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Algeria	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Algeria	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Algeria	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Algeria	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Algeria	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Algeria	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Algeria	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Algeria	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Algeria	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Algeria	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Algeria	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Algeria	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Algeria	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Algeria	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Algeria	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Algeria	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Algeria	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Algeria	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Algeria	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Algeria	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Algeria	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Algeria	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Algeria	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Algeria	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Algeria	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Algeria	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Algeria	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Algeria	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Algeria	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Algeria	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Algeria	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Algeria	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Algeria	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Algeria	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Algeria	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Algeria	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Algeria	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Algeria	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Algeria	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Algeria	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Algeria	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Algeria	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Algeria	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Algeria	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Algeria	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Algeria	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Algeria	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Algeria	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Algeria	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
American samoa	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Air bag	√	√	√	√		
American samoa	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	
American samoa	INFINITI EX35	J50	2008.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI EX35	J50	2008.NULL-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI EX35	J50	2008.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI EX35	J50	2008.NULL-	Air bag	√	√	√	√		
American samoa	INFINITI EX35	J50	2008.NULL-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
American samoa	INFINITI EX35	J50	2008.NULL-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
American samoa	INFINITI EX35	J50	2008.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
American samoa	INFINITI EX35	J50	2008.NULL-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
American samoa	INFINITI EX35	J50	2008.NULL-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI EX35	J50	2008.NULL-	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI EX35	J50	2008.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI EX35	J50	2008.NULL-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
American samoa	INFINITI EX35	J50	2008.NULL-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI EX35	J50	2008.NULL-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
American samoa	INFINITI EX35	J50	2008.NULL-	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI EX35	J50	2008.NULL-	CAN gateway	√	√	√			
American samoa	INFINITI EX35	J50	2008.NULL-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
American samoa	INFINITI EX35	J50	2008.NULL-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
American samoa	INFINITI EX35	J50	2008.NULL-	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI EX35	J50	2008.NULL-	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI EX35	J50	2008.NULL-	Rearview camera	√			√		SP0570, SP0571
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	Air bag	√	√	√	√		
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	Motor control						
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	HVAC	√	√	√	√		
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	Difference lock	√	√	√	√		
American samoa	INFINITI FX35/FX45	S50	2003.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

American samoa	INFINITI FX35/FX45	S50	2003.NULL –	Auto slide door	√	√	√	√	AC0941	
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	DIU		√	√	√		
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	Adaptive light	√	√	√	√		
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	IVMS	√	√		√		
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	Distance control	√	√		√		
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	Active suspense system	√	√	√	√		
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	Motor assist		√	√	√		SP0574
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	ASCD	√	√	√	√		
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	Active engine mount	√	√	√	√		
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	TCS	√	√	√	√		
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	S/blind camera	√			√		SP0572,SP0573
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	Nats immu	√	√	√			
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	Rearview camera	√			√		SP0570,SP0571
American samoa	INFINITI FX35/FX45	S50	2003.NULL –	Smart entrance						SP0568
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0045,SP0051,SP0053,SP0063,SP0064,SP0074,SP0079,SP0083,SP0085,SP0086,SP0087,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0225,SP0239
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Auto back door	√	√	√	√		SP0611
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Occupant detection			√	√		SP0584
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	CAN gateway	√	√	√			
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI FX35/FX50	S51	2009.NULL –	Rearview camera	√			√		SP0570,SP0571
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0350
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Transmission	√	√	√	√		SP0274
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Auto back door	√	√	√	√		SP0611
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Occupant detection			√	√		SP0584
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Accele pedal ACT	√	√	√	√	AC1029,AC1030	

American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	CAN gateway	√	√	√			
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
American samoa	INFINITI FX37/FX50	S51	2013.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI G20	CA33	2002.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
American samoa	INFINITI G20	CA33	2002.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
American samoa	INFINITI G20	CA33	2002.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI G20	CA33	2002.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
American samoa	INFINITI G20	CA33	2002.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI G20	CA33	2002.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
American samoa	INFINITI G20	CA33	2002.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
American samoa	INFINITI G20	CA33	2002.NULL –	Motor control						
American samoa	INFINITI G20	CA33	2002.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI G20	CA33	2002.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
American samoa	INFINITI G20	CA33	2002.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
American samoa	INFINITI G20	CA33	2002.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI G20	CA33	2002.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI G20	CA33	2002.NULL –	HVAC	√	√	√	√		
American samoa	INFINITI G20	CA33	2002.NULL –	Difference lock	√	√	√	√		
American samoa	INFINITI G20	CA33	2002.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI G20	CA33	2002.NULL –	Auto slide door	√	√	√	√	AC0941	
American samoa	INFINITI G20	CA33	2002.NULL –	DIU		√	√	√		
American samoa	INFINITI G20	CA33	2002.NULL –	Adaptive light	√	√	√	√		
American samoa	INFINITI G20	CA33	2002.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI G20	CA33	2002.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
American samoa	INFINITI G20	CA33	2002.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI G20	CA33	2002.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
American samoa	INFINITI G20	CA33	2002.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
American samoa	INFINITI G20	CA33	2002.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI G20	CA33	2002.NULL –	IVMS	√	√		√		
American samoa	INFINITI G20	CA33	2002.NULL –	Distance control	√	√		√		
American samoa	INFINITI G20	CA33	2002.NULL –	Active suspense system	√	√	√	√		
American samoa	INFINITI G20	CA33	2002.NULL –	Motor assist		√	√	√		SP0574
American samoa	INFINITI G20	CA33	2002.NULL –	ASCD	√	√	√	√		
American samoa	INFINITI G20	CA33	2002.NULL –	Active engine mount	√	√	√	√		
American samoa	INFINITI G20	CA33	2002.NULL –	TCS	√	√	√	√		
American samoa	INFINITI G20	CA33	2002.NULL –	S/blind camera	√			√		SP0572, SP0573
American samoa	INFINITI G20	CA33	2002.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
American samoa	INFINITI G20	CA33	2002.NULL –	Nats immu	√	√	√			
American samoa	INFINITI G20	CA33	2002.NULL –	Rearview camera	√			√		SP0570, SP0571
American samoa	INFINITI G20	CA33	2002.NULL –	Smart entrance						SP0568
American samoa	INFINITI G20	P11	1999.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
American samoa	INFINITI G20	P11	1999.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
American samoa	INFINITI G20	P11	1999.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI G20	P11	1999.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
American samoa	INFINITI G20	P11	1999.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI G20	P11	1999.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
American samoa	INFINITI G20	P11	1999.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
American samoa	INFINITI G20	P11	1999.NULL –	Motor control						
American samoa	INFINITI G20	P11	1999.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI G20	P11	1999.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
American samoa	INFINITI G20	P11	1999.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471

American samoa	INFINITI G20	P11	1999.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI G20	P11	1999.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI G20	P11	1999.NULL –	HVAC	√	√	√	√		
American samoa	INFINITI G20	P11	1999.NULL –	Difference lock	√	√	√	√		
American samoa	INFINITI G20	P11	1999.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI G20	P11	1999.NULL –	Auto slide door	√	√	√	√	AC0941	
American samoa	INFINITI G20	P11	1999.NULL –	DIU		√	√	√		
American samoa	INFINITI G20	P11	1999.NULL –	Adaptive light	√	√	√	√		
American samoa	INFINITI G20	P11	1999.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI G20	P11	1999.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
American samoa	INFINITI G20	P11	1999.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI G20	P11	1999.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
American samoa	INFINITI G20	P11	1999.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
American samoa	INFINITI G20	P11	1999.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI G20	P11	1999.NULL –	IVMS	√	√		√		
American samoa	INFINITI G20	P11	1999.NULL –	Distance control	√	√		√		
American samoa	INFINITI G20	P11	1999.NULL –	Active suspense system	√	√	√	√		
American samoa	INFINITI G20	P11	1999.NULL –	Motor assist		√	√	√		SP0574
American samoa	INFINITI G20	P11	1999.NULL –	ASCD	√	√	√	√		
American samoa	INFINITI G20	P11	1999.NULL –	Active engine mount	√	√	√	√		
American samoa	INFINITI G20	P11	1999.NULL –	TCS	√	√	√	√		
American samoa	INFINITI G20	P11	1999.NULL –	S/blind camera	√			√		SP0572, SP0573
American samoa	INFINITI G20	P11	1999.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
American samoa	INFINITI G20	P11	1999.NULL –	Nats immu	√	√	√			
American samoa	INFINITI G20	P11	1999.NULL –	Rearview camera	√			√		SP0570, SP0571
American samoa	INFINITI G20	P11	1999.NULL –	Smart entrance						SP0568
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Transmission	√	√	√	√		SP0274
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Pop up hood	√	√	√	√		
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Precrash seatbelt	√	√	√	√		
American samoa	INFINITI G25/G37 SEDAN	V36	2011.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Motor control						
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	HVAC	√	√	√	√		

American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Difference lock	√	√	√	√		
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Auto slide door	√	√	√	√	AC0941	
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	DIU		√	√	√		
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Adaptive light	√	√	√	√		
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	IVMS	√	√		√		
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Distance control	√	√		√		
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Active suspense system	√	√	√	√		
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Motor assist		√	√	√		SP0574
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	ASCD	√	√	√	√		
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Active engine mount	√	√	√	√		
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	TCS	√	√	√	√		
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	S/blind camera	√			√		SP0572, SP0573
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Nats immu	√	√	√			
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Rearview camera	√			√		SP0570, SP0571
American samoa	INFINITI G35 COUPE	CV35	2003.NULL –	Smart entrance						SP0568
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Motor control						
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	HVAC	√	√	√	√		
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Difference lock	√	√	√	√		
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Auto slide door	√	√	√	√	AC0941	
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	DIU		√	√	√		
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Adaptive light	√	√	√	√		
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	IVMS	√	√		√		
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Distance control	√	√		√		
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Active suspense system	√	√	√	√		
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Motor assist		√	√	√		SP0574
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	ASCD	√	√	√	√		
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Active engine mount	√	√	√	√		
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	TCS	√	√	√	√		
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	S/blind camera	√			√		SP0572, SP0573
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Nats immu	√	√	√			
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Rearview camera	√			√		SP0570, SP0571
American samoa	INFINITI G35 SEDAN	V35	2003.NULL –	Smart entrance						SP0568
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494

American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	Multi AV	√	√	√	√		
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	Precrash seatbelt	√	√	√	√		
American samoa	INFINITI G35 SEDAN	V36	2007.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Pop up hood	√	√	√	√		
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Precrash seatbelt	√	√	√	√		
American samoa	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	Pop up hood	√	√	√	√		
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	Precrash seatbelt	√	√	√	√		
American samoa	INFINITI G37 COUPE	CV36	2008.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	Precrash seatbelt	√	√	√	√		
American samoa	INFINITI G37 SEDAN	V36	2009.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI I30	CA32	1996.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
American samoa	INFINITI I30	CA32	1996.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
American samoa	INFINITI I30	CA32	1996.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI I30	CA32	1996.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
American samoa	INFINITI I30	CA32	1996.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI I30	CA32	1996.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
American samoa	INFINITI I30	CA32	1996.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
American samoa	INFINITI I30	CA32	1996.NULL –	Motor control						
American samoa	INFINITI I30	CA32	1996.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI I30	CA32	1996.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
American samoa	INFINITI I30	CA32	1996.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
American samoa	INFINITI I30	CA32	1996.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI I30	CA32	1996.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI I30	CA32	1996.NULL –	HVAC	√	√	√	√		
American samoa	INFINITI I30	CA32	1996.NULL –	Difference lock	√	√	√	√		
American samoa	INFINITI I30	CA32	1996.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI I30	CA32	1996.NULL –	Auto slide door	√	√	√	√	AC0941	
American samoa	INFINITI I30	CA32	1996.NULL –	DIU		√	√	√		
American samoa	INFINITI I30	CA32	1996.NULL –	Adaptive light	√	√	√	√		
American samoa	INFINITI I30	CA32	1996.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI I30	CA32	1996.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
American samoa	INFINITI I30	CA32	1996.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI I30	CA32	1996.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
American samoa	INFINITI I30	CA32	1996.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
American samoa	INFINITI I30	CA32	1996.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI I30	CA32	1996.NULL –	IVMS	√	√		√		
American samoa	INFINITI I30	CA32	1996.NULL –	Distance control	√	√		√		
American samoa	INFINITI I30	CA32	1996.NULL –	Active suspense system	√	√	√	√		
American samoa	INFINITI I30	CA32	1996.NULL –	Motor assist		√	√	√		SP0574
American samoa	INFINITI I30	CA32	1996.NULL –	ASCD	√	√	√	√		
American samoa	INFINITI I30	CA32	1996.NULL –	Active engine mount	√	√	√	√		
American samoa	INFINITI I30	CA32	1996.NULL –	TCS	√	√	√	√		
American samoa	INFINITI I30	CA32	1996.NULL	S/blind camera	√			√		SP0572, SP0573
American samoa	INFINITI I30	CA32	1996.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
American samoa	INFINITI I30	CA32	1996.NULL –	Nats immu	√	√	√			
American samoa	INFINITI I30	CA32	1996.NULL –	Rearview camera	√			√		SP0570, SP0571
American samoa	INFINITI I30	CA32	1996.NULL –	Smart entrance						SP0568
American samoa	INFINITI I35	CA33	2002.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
American samoa	INFINITI I35	CA33	2002.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
American samoa	INFINITI I35	CA33	2002.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI I35	CA33	2002.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
American samoa	INFINITI I35	CA33	2002.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI I35	CA33	2002.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
American samoa	INFINITI I35	CA33	2002.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
American samoa	INFINITI I35	CA33	2002.NULL –	Motor control						
American samoa	INFINITI I35	CA33	2002.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI I35	CA33	2002.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288

American samoa	INFINITI I35	CA33	2002.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
American samoa	INFINITI I35	CA33	2002.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI I35	CA33	2002.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI I35	CA33	2002.NULL –	HVAC	√	√	√	√		
American samoa	INFINITI I35	CA33	2002.NULL –	Difference lock	√	√	√	√		
American samoa	INFINITI I35	CA33	2002.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI I35	CA33	2002.NULL –	Auto slide door	√	√	√	√	AC0941	
American samoa	INFINITI I35	CA33	2002.NULL –	DIU		√	√	√		
American samoa	INFINITI I35	CA33	2002.NULL –	Adaptive light	√	√	√	√		
American samoa	INFINITI I35	CA33	2002.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI I35	CA33	2002.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
American samoa	INFINITI I35	CA33	2002.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI I35	CA33	2002.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
American samoa	INFINITI I35	CA33	2002.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
American samoa	INFINITI I35	CA33	2002.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI I35	CA33	2002.NULL –	IVMS	√	√		√		
American samoa	INFINITI I35	CA33	2002.NULL –	Distance control	√	√		√		
American samoa	INFINITI I35	CA33	2002.NULL –	Active suspense system	√	√	√	√		
American samoa	INFINITI I35	CA33	2002.NULL –	Motor assist		√	√	√		SP0574
American samoa	INFINITI I35	CA33	2002.NULL –	ASCD	√	√	√	√		
American samoa	INFINITI I35	CA33	2002.NULL –	Active engine mount	√	√	√	√		
American samoa	INFINITI I35	CA33	2002.NULL –	TCS	√	√	√	√		
American samoa	INFINITI I35	CA33	2002.NULL –	S/blind camera	√			√		SP0572, SP0573
American samoa	INFINITI I35	CA33	2002.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
American samoa	INFINITI I35	CA33	2002.NULL –	Nats immu	√	√	√			
American samoa	INFINITI I35	CA33	2002.NULL –	Rearview camera	√			√		SP0570, SP0571
American samoa	INFINITI I35	CA33	2002.NULL –	Smart entrance						SP0568
American samoa	INFINITI JX35	L50	2013.NULL –	Laser/radar	√	√	√	√		
American samoa	INFINITI JX35	L50	2013.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI JX35	L50	2013.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
American samoa	INFINITI JX35	L50	2013.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI JX35	L50	2013.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI JX35	L50	2013.NULL –	EPS/DAST 3	√	√	√	√		
American samoa	INFINITI JX35	L50	2013.NULL –	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
American samoa	INFINITI JX35	L50	2013.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI JX35	L50	2013.NULL –	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
American samoa	INFINITI JX35	L50	2013.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
American samoa	INFINITI JX35	L50	2013.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
American samoa	INFINITI JX35	L50	2013.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI JX35	L50	2013.NULL –	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
American samoa	INFINITI JX35	L50	2013.NULL –	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI JX35	L50	2013.NULL –	Auto back door	√	√	√	√		SP0611
American samoa	INFINITI JX35	L50	2013.NULL –	Occupant detection			√	√		SP0584
American samoa	INFINITI JX35	L50	2013.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI JX35	L50	2013.NULL –	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
American samoa	INFINITI JX35	L50	2013.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI JX35	L50	2013.NULL –	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI JX35	L50	2013.NULL –	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI JX35	L50	2013.NULL –	CAN gateway	√	√	√			
American samoa	INFINITI JX35	L50	2013.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
American samoa	INFINITI JX35	L50	2013.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI JX35	L50	2013.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
American samoa	INFINITI JX35	L50	2013.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI M35/M45	Y50	2006.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
American samoa	INFINITI M35/M45	Y50	2006.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
American samoa	INFINITI M35/M45	Y50	2006.NULL –	IPDM E/R	√	√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
American samoa	INFINITI M35/M45	Y50	2006.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI M35/M45	Y50	2006.NULL –	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
American samoa	INFINITI M35/M45	Y50	2006.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
American samoa	INFINITI M35/M45	Y50	2006.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
American samoa	INFINITI M35/M45	Y50	2006.NULL –	BCM					AC0653, AC0698	SP0391, SP0393
American samoa	INFINITI M35/M45	Y50	2006.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319

American samoa	INFINITI M35/M45	Y50	2006.NULL–	Multi AV	√	√	√	√		
American samoa	INFINITI M35/M45	Y50	2006.NULL–	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI M35/M45	Y50	2006.NULL–	Adaptive light	√	√	√	√		SP0561, SP0562
American samoa	INFINITI M35/M45	Y50	2006.NULL–	All mode AWD/4WD	√	√	√	√	AC0957	
American samoa	INFINITI M35/M45	Y50	2006.NULL–	Precrash seatbelt	√	√	√	√		
American samoa	INFINITI M35/M45	Y50	2006.NULL–	Intelligent key	√	√	√	√	AC0911, AC0913, AC0915, AC0916, AC0917, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
American samoa	INFINITI M35/M45	Y50	2006.NULL–	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976	SP0560
American samoa	INFINITI M35/M45	Y50	2006.NULL–	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI M35H	HY51	2012.NULL–	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
American samoa	INFINITI M35H	HY51	2012.NULL–	Laser/radar	√	√	√	√		
American samoa	INFINITI M35H	HY51	2012.NULL–	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI M35H	HY51	2012.NULL–	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
American samoa	INFINITI M35H	HY51	2012.NULL–	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI M35H	HY51	2012.NULL–	Air bag	√	√	√	√		
American samoa	INFINITI M35H	HY51	2012.NULL–	EPS/DAST 3	√	√	√	√		
American samoa	INFINITI M35H	HY51	2012.NULL–	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
American samoa	INFINITI M35H	HY51	2012.NULL–	Motor control	√	√	√	√		
American samoa	INFINITI M35H	HY51	2012.NULL–	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
American samoa	INFINITI M35H	HY51	2012.NULL–	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
American samoa	INFINITI M35H	HY51	2012.NULL–	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
American samoa	INFINITI M35H	HY51	2012.NULL–	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
American samoa	INFINITI M35H	HY51	2012.NULL–	Diag data recorder	√					
American samoa	INFINITI M35H	HY51	2012.NULL–	Pop up hood	√	√	√	√		
American samoa	INFINITI M35H	HY51	2012.NULL–	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI M35H	HY51	2012.NULL–	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
American samoa	INFINITI M35H	HY51	2012.NULL–	HV battery	√	√	√	√	AC1121	
American samoa	INFINITI M35H	HY51	2012.NULL–	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI M35H	HY51	2012.NULL–	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
American samoa	INFINITI M35H	HY51	2012.NULL–	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
American samoa	INFINITI M35H	HY51	2012.NULL–	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI M35H	HY51	2012.NULL–	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
American samoa	INFINITI M35H	HY51	2012.NULL–	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI M35H	HY51	2012.NULL–	CAN gateway	√	√	√			
American samoa	INFINITI M35H	HY51	2012.NULL–	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
American samoa	INFINITI M35H	HY51	2012.NULL–	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI M35H	HY51	2012.NULL–	Telematics	√	√	√	√		SP0590, SP0591, SP0592
American samoa	INFINITI M35H	HY51	2012.NULL–	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI M35H	HY51	2012.NULL–	Brake	√	√	√	√	AC1127	
American samoa	INFINITI M35H	HY51	2012.NULL–	VSP	√	√	√	√	AC1124, AC1125, AC1126	
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Laser/radar	√	√	√	√		
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
American samoa	INFINITI M37/M56	Y51	2011.NULL–	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
American samoa	INFINITI M37/M56	Y51	2011.NULL–	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Air bag	√	√	√	√		
American samoa	INFINITI M37/M56	Y51	2011.NULL–	EPS/DAST 3	√	√	√	√		
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Motor control	√	√	√	√		
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
American samoa	INFINITI M37/M56	Y51	2011.NULL–	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
American samoa	INFINITI M37/M56	Y51	2011.NULL–	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Pop up hood	√	√	√	√		
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI M37/M56	Y51	2011.NULL–	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
American samoa	INFINITI M37/M56	Y51	2011.NULL–	HV battery	√	√	√	√	AC1121	
American samoa	INFINITI M37/M56	Y51	2011.NULL–	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
American samoa	INFINITI M37/M56	Y51	2011.NULL–	4WAS(front)	√	√	√	√	AC1027, AC1028	
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI M37/M56	Y51	2011.NULL–	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
American samoa	INFINITI M37/M56	Y51	2011.NULL–	Accele pedal ACT	√	√	√	√	AC1029, AC1030	

American samoa	INFINITI M37/M56	Y51	2011.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
American samoa	INFINITI M37/M56	Y51	2011.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI M37/M56	Y51	2011.NULL –	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI M37/M56	Y51	2011.NULL –	CAN gateway	√	√	√			
American samoa	INFINITI M37/M56	Y51	2011.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
American samoa	INFINITI M37/M56	Y51	2011.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI M37/M56	Y51	2011.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI M37/M56	Y51	2011.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
American samoa	INFINITI M37/M56	Y51	2011.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI M37/M56	Y51	2011.NULL –	VSP	√	√	√	√	AC1124, AC1125, AC1126	
American samoa	INFINITI M45	Y34	2003.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
American samoa	INFINITI M45	Y34	2003.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
American samoa	INFINITI M45	Y34	2003.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI M45	Y34	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
American samoa	INFINITI M45	Y34	2003.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI M45	Y34	2003.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
American samoa	INFINITI M45	Y34	2003.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
American samoa	INFINITI M45	Y34	2003.NULL –	Motor control						
American samoa	INFINITI M45	Y34	2003.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI M45	Y34	2003.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
American samoa	INFINITI M45	Y34	2003.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
American samoa	INFINITI M45	Y34	2003.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI M45	Y34	2003.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI M45	Y34	2003.NULL –	HVAC	√	√	√	√		
American samoa	INFINITI M45	Y34	2003.NULL –	Difference lock	√	√	√	√		
American samoa	INFINITI M45	Y34	2003.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI M45	Y34	2003.NULL –	Auto slide door	√	√	√	√	AC0941	
American samoa	INFINITI M45	Y34	2003.NULL –	DIU		√	√	√		
American samoa	INFINITI M45	Y34	2003.NULL –	Adaptive light	√	√	√	√		
American samoa	INFINITI M45	Y34	2003.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI M45	Y34	2003.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
American samoa	INFINITI M45	Y34	2003.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI M45	Y34	2003.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
American samoa	INFINITI M45	Y34	2003.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
American samoa	INFINITI M45	Y34	2003.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI M45	Y34	2003.NULL –	IVMS	√	√		√		
American samoa	INFINITI M45	Y34	2003.NULL –	Distance control	√	√		√		
American samoa	INFINITI M45	Y34	2003.NULL –	Active suspense system	√	√	√	√		
American samoa	INFINITI M45	Y34	2003.NULL –	Motor assist		√	√	√		SP0574
American samoa	INFINITI M45	Y34	2003.NULL –	ASCD	√	√	√	√		
American samoa	INFINITI M45	Y34	2003.NULL –	Active engine mount	√	√	√	√		
American samoa	INFINITI M45	Y34	2003.NULL –	TCS	√	√	√	√		
American samoa	INFINITI M45	Y34	2003.NULL –	S/blind camera	√			√		SP0572, SP0573
American samoa	INFINITI M45	Y34	2003.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
American samoa	INFINITI M45	Y34	2003.NULL –	Nats immu	√	√	√			
American samoa	INFINITI M45	Y34	2003.NULL –	Rearview camera	√			√		SP0570, SP0571
American samoa	INFINITI M45	Y34	2003.NULL –	Smart entrance						SP0568
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0038, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	Transmission	√	√	√	√		SP0274
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	Pop up hood	√	√	√	√		
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

XTOOL

American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI Q40 SEDAN	V36	2015.NULL –	Precrash seatbelt	√	√	√	√		
American samoa	INFINITI Q45	F50	2002.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
American samoa	INFINITI Q45	F50	2002.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
American samoa	INFINITI Q45	F50	2002.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI Q45	F50	2002.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
American samoa	INFINITI Q45	F50	2002.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI Q45	F50	2002.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
American samoa	INFINITI Q45	F50	2002.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
American samoa	INFINITI Q45	F50	2002.NULL –	Motor control						
American samoa	INFINITI Q45	F50	2002.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI Q45	F50	2002.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
American samoa	INFINITI Q45	F50	2002.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
American samoa	INFINITI Q45	F50	2002.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI Q45	F50	2002.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI Q45	F50	2002.NULL –	HVAC	√	√	√	√		
American samoa	INFINITI Q45	F50	2002.NULL –	Difference lock	√	√	√	√		
American samoa	INFINITI Q45	F50	2002.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI Q45	F50	2002.NULL –	Auto slide door	√	√	√	√	AC0941	
American samoa	INFINITI Q45	F50	2002.NULL –	DIU		√	√	√		
American samoa	INFINITI Q45	F50	2002.NULL –	Adaptive light	√	√	√	√		
American samoa	INFINITI Q45	F50	2002.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI Q45	F50	2002.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
American samoa	INFINITI Q45	F50	2002.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI Q45	F50	2002.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
American samoa	INFINITI Q45	F50	2002.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
American samoa	INFINITI Q45	F50	2002.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI Q45	F50	2002.NULL –	IVMS	√	√		√		
American samoa	INFINITI Q45	F50	2002.NULL –	Distance control	√	√		√		
American samoa	INFINITI Q45	F50	2002.NULL –	Active suspense system	√	√	√	√		
American samoa	INFINITI Q45	F50	2002.NULL	Motor assist		√	√	√		SP0574
American samoa	INFINITI Q45	F50	2002.NULL –	ASCD	√	√	√	√		
American samoa	INFINITI Q45	F50	2002.NULL –	Active engine mount	√	√	√	√		
American samoa	INFINITI Q45	F50	2002.NULL –	TCS	√	√	√	√		
American samoa	INFINITI Q45	F50	2002.NULL –	S/blind camera	√			√		SP0572, SP0573
American samoa	INFINITI Q45	F50	2002.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
American samoa	INFINITI Q45	F50	2002.NULL –	Nats immu	√	√	√			
American samoa	INFINITI Q45	F50	2002.NULL –	Rearview camera	√			√		SP0570, SP0571
American samoa	INFINITI Q45	F50	2002.NULL –	Smart entrance						SP0568
American samoa	INFINITI Q45	FY33	1995.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
American samoa	INFINITI Q45	FY33	1995.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
American samoa	INFINITI Q45	FY33	1995.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI Q45	FY33	1995.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
American samoa	INFINITI Q45	FY33	1995.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI Q45	FY33	1995.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
American samoa	INFINITI Q45	FY33	1995.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
American samoa	INFINITI Q45	FY33	1995.NULL –	Motor control						
American samoa	INFINITI Q45	FY33	1995.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI Q45	FY33	1995.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
American samoa	INFINITI Q45	FY33	1995.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
American samoa	INFINITI Q45	FY33	1995.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI Q45	FY33	1995.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI Q45	FY33	1995.NULL –	HVAC	√	√	√	√		
American samoa	INFINITI Q45	FY33	1995.NULL –	Difference lock	√	√	√	√		
American samoa	INFINITI Q45	FY33	1995.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

American samoa	INFINITI Q45	FY33	1995.NULL –	Auto slide door	√	√	√	√	AC0941	
American samoa	INFINITI Q45	FY33	1995.NULL –	DIU		√	√	√		
American samoa	INFINITI Q45	FY33	1995.NULL –	Adaptive light	√	√	√	√		
American samoa	INFINITI Q45	FY33	1995.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI Q45	FY33	1995.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
American samoa	INFINITI Q45	FY33	1995.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI Q45	FY33	1995.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
American samoa	INFINITI Q45	FY33	1995.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
American samoa	INFINITI Q45	FY33	1995.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI Q45	FY33	1995.NULL –	IVMS	√	√		√		
American samoa	INFINITI Q45	FY33	1995.NULL –	Distance control	√	√		√		
American samoa	INFINITI Q45	FY33	1995.NULL –	Active suspense system	√	√	√	√		
American samoa	INFINITI Q45	FY33	1995.NULL –	Motor assist		√	√	√		SP0574
American samoa	INFINITI Q45	FY33	1995.NULL –	ASCD	√	√	√	√		
American samoa	INFINITI Q45	FY33	1995.NULL –	Active engine mount	√	√	√	√		
American samoa	INFINITI Q45	FY33	1995.NULL –	TCS	√	√	√	√		
American samoa	INFINITI Q45	FY33	1995.NULL –	S/blind camera	√			√		SP0572, SP0573
American samoa	INFINITI Q45	FY33	1995.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
American samoa	INFINITI Q45	FY33	1995.NULL –	Nats immu	√	√	√			
American samoa	INFINITI Q45	FY33	1995.NULL –	Rearview camera	√			√		SP0570, SP0571
American samoa	INFINITI Q45	FY33	1995.NULL –	Smart entrance						SP0568
American samoa	INFINITI Q50	V37	2018.1-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
American samoa	INFINITI Q50	V37	2018.1-	Laser/radar	√	√	√	√	AC0994	
American samoa	INFINITI Q50	V37	2018.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI Q50	V37	2018.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
American samoa	INFINITI Q50	V37	2018.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI Q50	V37	2018.1-	Air bag	√	√	√	√		
American samoa	INFINITI Q50	V37	2018.1-	EPS/DAST 3	√	√	√	√		SP0507
American samoa	INFINITI Q50	V37	2018.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
American samoa	INFINITI Q50	V37	2018.1-	Motor control	√	√	√	√		
American samoa	INFINITI Q50	V37	2018.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI Q50	V37	2018.1-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
American samoa	INFINITI Q50	V37	2018.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
American samoa	INFINITI Q50	V37	2018.1-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
American samoa	INFINITI Q50	V37	2018.1-	Pop up hood	√	√	√	√		
American samoa	INFINITI Q50	V37	2018.1-	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI Q50	V37	2018.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
American samoa	INFINITI Q50	V37	2018.1-	HV battery	√	√	√	√	AC1121	
American samoa	INFINITI Q50	V37	2018.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
American samoa	INFINITI Q50	V37	2018.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
American samoa	INFINITI Q50	V37	2018.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI Q50	V37	2018.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
American samoa	INFINITI Q50	V37	2018.1-	Occupant detection			√	√		SP0584
American samoa	INFINITI Q50	V37	2018.1-	Shift	√	√	√	√		SP0613
American samoa	INFINITI Q50	V37	2018.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
American samoa	INFINITI Q50	V37	2018.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI Q50	V37	2018.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI Q50	V37	2018.1-	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI Q50	V37	2018.1-	DAST 2	√	√	√	√		
American samoa	INFINITI Q50	V37	2018.1-	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI Q50	V37	2018.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI Q50	V37	2018.1-	CAN gateway	√	√	√			
American samoa	INFINITI Q50	V37	2018.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
American samoa	INFINITI Q50	V37	2018.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI Q50	V37	2018.1-	DAST 1	√	√	√	√		
American samoa	INFINITI Q50	V37	2018.1-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
American samoa	INFINITI Q50	V37	2018.1-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
American samoa	INFINITI Q50	V37	2018.1-	ANC	√	√	√	√	AC1024	
American samoa	INFINITI Q50	V37	2018.1-	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI Q50	V37	2018.1-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
American samoa	INFINITI Q50	V37	2018.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
American samoa	INFINITI Q50	V37	2018.1-	HIGH BEAM ASSIST	√	√	√	√		
American samoa	INFINITI Q50	V37	2018.1-	Side radar right	√	√	√	√	AC1026	SP0583

American samoa	INFINITI Q50	V37	2018.1-	Brake	√	√	√	√	AC1127	
American samoa	INFINITI Q50	V37	2018.1-	6ch CAN GATEWAY	√	√	√	√		
American samoa	INFINITI Q50	V37	2018.1-	3ch CAN GATEWAY	√	√	√	√		
American samoa	INFINITI Q50	V37	2018.1-	ICC/ADAS 2	√	√	√	√		
American samoa	INFINITI Q50	V37	2018.1-	FSCM	√	√	√	√	AC1109	
American samoa	INFINITI Q50	V37	2018.1-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Laser/radar	√	√	√	√		
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Air bag	√	√	√	√		
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	EPS/DAST 3	√	√	√	√		SP0507
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Motor control	√	√	√	√		
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Transmission	√	√	√	√		SP0274, SP0276
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Pop up hood	√	√	√	√		
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	HV battery	√	√	√	√	AC1121	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	4WAS(front)	√	√	√	√	AC1027, AC1028	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Occupant detection			√	√		SP0584
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Shift	√	√	√	√		SP0613
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	DAST 2	√	√	√	√		
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	CAN gateway	√	√	√			
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	DAST 1	√	√	√	√		
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	ANC	√	√	√	√	AC1024	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	HIGH BEAM ASSIST	√	√	√	√		
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	Brake	√	√	√	√	AC1127	
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	6ch CAN GATEWAY	√	√	√	√		
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	3ch CAN GATEWAY	√	√	√	√		
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	ICC/ADAS 2	√	√	√	√		
American samoa	INFINITI Q50 HYBRID	HV37	2014.NULL-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Laser/radar	√	√	√	√		
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Air bag	√	√	√	√		
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	EPS/DAST 3	√	√	√	√		
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Motor control	√	√	√	√		
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Transmission	√	√	√	√		SP0276

American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Pop up hood	√	√	√	√		
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	HV battery	√	√	√	√	AC1121	
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Occupant detection			√	√		SP0584
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 2	√	√	√	√		
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Lane camera	√	√	√	√		
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 1	√	√	√	√		
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	ANC	√	√	√	√	AC1024	
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	HIGH BEAM ASSIST	√	√	√	√		
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√		
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	Brake	√	√	√	√	AC1127	
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	6ch CAN GATEWAY	√	√	√	√		
American samoa	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
American samoa	INFINITI Q60	CV37	2019.NULL-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
American samoa	INFINITI Q60	CV37	2019.NULL-	Laser/radar	√	√	√	√	AC0994	
American samoa	INFINITI Q60	CV37	2019.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI Q60	CV37	2019.NULL-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
American samoa	INFINITI Q60	CV37	2019.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI Q60	CV37	2019.NULL-	Air bag	√	√	√	√		
American samoa	INFINITI Q60	CV37	2019.NULL-	EPS/DAST 3	√	√	√	√		
American samoa	INFINITI Q60	CV37	2019.NULL-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
American samoa	INFINITI Q60	CV37	2019.NULL-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI Q60	CV37	2019.NULL-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
American samoa	INFINITI Q60	CV37	2019.NULL-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
American samoa	INFINITI Q60	CV37	2019.NULL-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
American samoa	INFINITI Q60	CV37	2019.NULL-	Pop up hood	√	√	√	√		
American samoa	INFINITI Q60	CV37	2019.NULL-	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI Q60	CV37	2019.NULL-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
American samoa	INFINITI Q60	CV37	2019.NULL-	4WAS(front)	√	√	√	√	AC1027, AC1028	
American samoa	INFINITI Q60	CV37	2019.NULL-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI Q60	CV37	2019.NULL-	Occupant detection			√	√		SP0584
American samoa	INFINITI Q60	CV37	2019.NULL-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
American samoa	INFINITI Q60	CV37	2019.NULL-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI Q60	CV37	2019.NULL-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
American samoa	INFINITI Q60	CV37	2019.NULL-	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI Q60	CV37	2019.NULL-	DAST 2	√	√	√	√		
American samoa	INFINITI Q60	CV37	2019.NULL-	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI Q60	CV37	2019.NULL-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI Q60	CV37	2019.NULL-	CAN gateway	√	√	√			
American samoa	INFINITI Q60	CV37	2019.NULL-	Lane camera	√	√	√	√		
American samoa	INFINITI Q60	CV37	2019.NULL-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI Q60	CV37	2019.NULL-	DAST 1	√	√	√	√		
American samoa	INFINITI Q60	CV37	2019.NULL-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
American samoa	INFINITI Q60	CV37	2019.NULL-	ANC	√	√	√	√	AC1024	
American samoa	INFINITI Q60	CV37	2019.NULL-	Side radar left	√	√	√	√	AC1025	SP0582

American samoa	INFINITI Q60	CV37	2019.NULL –	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
American samoa	INFINITI Q60	CV37	2019.NULL –	Telematics	√	√	√	√		SP0590,SP0591,SP0592
American samoa	INFINITI Q60	CV37	2019.NULL –	HIGH BEAM ASSIST	√	√	√	√		
American samoa	INFINITI Q60	CV37	2019.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI Q60	CV37	2019.NULL –	Lane camera 2	√	√	√	√		
American samoa	INFINITI Q60	CV37	2019.NULL –	6ch CAN GATEWAY	√	√	√	√		
American samoa	INFINITI Q60	CV37	2019.NULL –	3ch CAN GATEWAY	√	√	√	√		
American samoa	INFINITI Q60	CV37	2019.NULL –	ICC/ADAS 2	√	√	√	√		
American samoa	INFINITI Q60	CV37	2019.NULL –	FSCM	√	√	√	√	AC1109	
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Transmission	√	√	√	√		SP0274
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Pop up hood	√	√	√	√		
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
American samoa	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Precrash seatbelt	√	√	√	√		
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	Transmission	√	√	√	√		SP0274
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	Pop up hood	√	√	√	√		
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI Q60 COUPE	CV36	2014.NULL –	Precrash seatbelt	√	√	√	√		
American samoa	INFINITI Q70	Y51	2019.NULL –	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
American samoa	INFINITI Q70	Y51	2019.NULL –	Laser/radar	√	√	√	√	AC0994	
American samoa	INFINITI Q70	Y51	2019.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI Q70	Y51	2019.NULL –	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
American samoa	INFINITI Q70	Y51	2019.NULL –	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
American samoa	INFINITI Q70	Y51	2019.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI Q70	Y51	2019.NULL –	EPS/DAST 3	√	√	√	√		SP0507
American samoa	INFINITI Q70	Y51	2019.NULL –	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
American samoa	INFINITI Q70	Y51	2019.NULL –	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
American samoa	INFINITI Q70	Y51	2019.NULL –	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0247,SP0265,SP0270,SP0274
American samoa	INFINITI Q70	Y51	2019.NULL –	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471

American samoa	INFINITI Q70	Y51	2019.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI Q70	Y51	2019.NULL –	Pop up hood	√	√	√	√		
American samoa	INFINITI Q70	Y51	2019.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI Q70	Y51	2019.NULL –	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
American samoa	INFINITI Q70	Y51	2019.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
American samoa	INFINITI Q70	Y51	2019.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
American samoa	INFINITI Q70	Y51	2019.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI Q70	Y51	2019.NULL –	Occupant detection			√	√		SP0584
American samoa	INFINITI Q70	Y51	2019.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
American samoa	INFINITI Q70	Y51	2019.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI Q70	Y51	2019.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI Q70	Y51	2019.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI Q70	Y51	2019.NULL –	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI Q70	Y51	2019.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI Q70	Y51	2019.NULL –	CAN gateway	√	√	√			
American samoa	INFINITI Q70	Y51	2019.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
American samoa	INFINITI Q70	Y51	2019.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI Q70	Y51	2019.NULL –	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
American samoa	INFINITI Q70	Y51	2019.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI Q70	Y51	2019.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
American samoa	INFINITI Q70	Y51	2019.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI Q70	Y51	2019.NULL –	6ch CAN GATEWAY	√	√	√	√		
American samoa	INFINITI Q70	Y51	2019.NULL –	ICC/ADAS 2	√	√	√	√		
American samoa	INFINITI Q70	Y51	2019.NULL –	FSCM	√	√	√	√	AC1109	
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Laser/radar	√	√	√	√	AC0994	
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	EPS/DAST 3	√	√	√	√		
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Motor control	√	√	√	√		
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	BCM				√	AC0613, AC0618, AC0653, AC0663, AC0690, AC0692, AC0698, AC0702	SP0372, SP0429, SP0471
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Pop up hood	√	√	√	√		
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	HV battery	√	√	√	√	AC1121	
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Occupant detection			√	√		SP0584
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	CAN gateway	√	√	√			
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	Brake	√	√	√	√	AC1127	
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	6ch CAN GATEWAY	√	√	√	√		
American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	ICC/ADAS 2	√	√	√	√		

American samoa	INFINITI Q70 HYBRID	HY51	2014.NULL –	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
American samoa	INFINITI QX30	H15	2019.NULL –	Air pressure monitor	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	EPS/DAST 3	√	√	√			
American samoa	INFINITI QX30	H15	2019.NULL –	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
American samoa	INFINITI QX30	H15	2019.NULL –	Engine	√	√	√	√	AC0002, AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0103, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
American samoa	INFINITI QX30	H15	2019.NULL –	EHS/PKB	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	Transmission	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
American samoa	INFINITI QX30	H15	2019.NULL –	ABS	√	√	√	√		SP0308
American samoa	INFINITI QX30	H15	2019.NULL –	Multi AV	√	√	√	√		SP0501
American samoa	INFINITI QX30	H15	2019.NULL –	HVAC	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	Auto drive position	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	Shift	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	All mode AWD/4WD	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	AVM	√	√		√		
American samoa	INFINITI QX30	H15	2019.NULL –	Intelligent key	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	CAN gateway	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	ANC	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	Telematics	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	FSCM	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	Siren control unit	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
American samoa	INFINITI QX30	H15	2019.NULL –	Overhead Control Panel Unit	√			√		
American samoa	INFINITI QX30	H15	2019.NULL –	Universal Garage Door Opener	√			√		
American samoa	INFINITI QX30	H15	2019.NULL –	Upper control panel cont unit	√					
American samoa	INFINITI QX30	H15	2019.NULL –	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
American samoa	INFINITI QX30	H15	2019.NULL –	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
American samoa	INFINITI QX30	H15	2019.NULL –	Light/Rain Sensor Module	√			√		
American samoa	INFINITI QX30	H15	2019.NULL –	EC Mirror Compass	√					
American samoa	INFINITI QX30	H15	2019.NULL –	Intelligent Battery Sensor	√					
American samoa	INFINITI QX30	H15	2019.NULL –	Alarm siren	√			√		
American samoa	INFINITI QX30	H15	2019.NULL –	Radar sensor	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	Steering column cont module	√	√	√			
American samoa	INFINITI QX30	H15	2019.NULL –	ICC sensor	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	Trailer recognition control unit	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	H/L control module LH	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	Powertrain cont module	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	Side radar LH	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	LED H/L control module LH	√			√		
American samoa	INFINITI QX30	H15	2019.NULL –	Steering Wheel Switch Pad	√			√		
American samoa	INFINITI QX30	H15	2019.NULL –	Parking assist	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	Occupant Classification Unit	√			√		
American samoa	INFINITI QX30	H15	2019.NULL –	Electronic Ignition Switch cont unit	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	H/L control module RH	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	Front camera unit	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	Side radar RH	√	√	√	√		
American samoa	INFINITI QX30	H15	2019.NULL –	LED H/L control module RH	√			√		
American samoa	INFINITI QX4	JR50	1997.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
American samoa	INFINITI QX4	JR50	1997.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
American samoa	INFINITI QX4	JR50	1997.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI QX4	JR50	1997.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
American samoa	INFINITI QX4	JR50	1997.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI QX4	JR50	1997.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
American samoa	INFINITI QX4	JR50	1997.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
American samoa	INFINITI QX4	JR50	1997.NULL –	Motor control						
American samoa	INFINITI QX4	JR50	1997.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI QX4	JR50	1997.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
American samoa	INFINITI QX4	JR50	1997.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471

XTOOL

American samoa	INFINITI QX4	JR50	1997.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI QX4	JR50	1997.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI QX4	JR50	1997.NULL –	HVAC	√	√	√	√		
American samoa	INFINITI QX4	JR50	1997.NULL –	Difference lock	√	√	√	√		
American samoa	INFINITI QX4	JR50	1997.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI QX4	JR50	1997.NULL –	Auto slide door	√	√	√	√	AC0941	
American samoa	INFINITI QX4	JR50	1997.NULL –	DIU		√	√	√		
American samoa	INFINITI QX4	JR50	1997.NULL –	Adaptive light	√	√	√	√		
American samoa	INFINITI QX4	JR50	1997.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI QX4	JR50	1997.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
American samoa	INFINITI QX4	JR50	1997.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI QX4	JR50	1997.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
American samoa	INFINITI QX4	JR50	1997.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
American samoa	INFINITI QX4	JR50	1997.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI QX4	JR50	1997.NULL –	IVMS	√	√		√		
American samoa	INFINITI QX4	JR50	1997.NULL –	Distance control	√	√		√		
American samoa	INFINITI QX4	JR50	1997.NULL –	Active suspense system	√	√	√	√		
American samoa	INFINITI QX4	JR50	1997.NULL –	Motor assist		√	√	√		SP0574
American samoa	INFINITI QX4	JR50	1997.NULL –	ASCD	√	√	√	√		
American samoa	INFINITI QX4	JR50	1997.NULL –	Active engine mount	√	√	√	√		
American samoa	INFINITI QX4	JR50	1997.NULL –	TCS	√	√	√	√		
American samoa	INFINITI QX4	JR50	1997.NULL –	S/blind camera	√			√		SP0572, SP0573
American samoa	INFINITI QX4	JR50	1997.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
American samoa	INFINITI QX4	JR50	1997.NULL –	Nats immu	√	√	√			
American samoa	INFINITI QX4	JR50	1997.NULL –	Rearview camera	√			√		SP0570, SP0571
American samoa	INFINITI QX4	JR50	1997.NULL –	Smart entrance						SP0568
American samoa	INFINITI QX50	J50	2014.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
American samoa	INFINITI QX50	J50	2014.NULL –	Laser/radar	√	√	√	√	AC0994	
American samoa	INFINITI QX50	J50	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI QX50	J50	2014.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI QX50	J50	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI QX50	J50	2014.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI QX50	J50	2014.NULL –	EPS/DAST 3	√	√	√	√		SP0507
American samoa	INFINITI QX50	J50	2014.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
American samoa	INFINITI QX50	J50	2014.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
American samoa	INFINITI QX50	J50	2014.NULL –	Transmission	√	√	√	√		SP0274
American samoa	INFINITI QX50	J50	2014.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
American samoa	INFINITI QX50	J50	2014.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
American samoa	INFINITI QX50	J50	2014.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI QX50	J50	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI QX50	J50	2014.NULL –	Occupant detection			√	√		SP0584
American samoa	INFINITI QX50	J50	2014.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
American samoa	INFINITI QX50	J50	2014.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI QX50	J50	2014.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
American samoa	INFINITI QX50	J50	2014.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI QX50	J50	2014.NULL –	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI QX50	J50	2014.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI QX50	J50	2014.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
American samoa	INFINITI QX50	J50	2014.NULL –	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
American samoa	INFINITI QX50	J50	2014.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI QX50	J50	2014.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
American samoa	INFINITI QX50	J50	2014.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI QX50	J55	2019.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
American samoa	INFINITI QX50	J55	2019.NULL –	Laser/radar	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
American samoa	INFINITI QX50	J55	2019.NULL –	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
American samoa	INFINITI QX50	J55	2019.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	EPS/DAST 3	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	Meter/M&A	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
American samoa	INFINITI QX50	J55	2019.NULL –	EHS/PKB	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292

American samoa	INFINITI QX50	J55	2019.NULL –	BCM					AC0618,AC0690,AC0692	SP0390,SP0438,SP0450,SP0458
American samoa	INFINITI QX50	J55	2019.NULL –	ABS	√	√	√	√		SP0313,SP0315
American samoa	INFINITI QX50	J55	2019.NULL –	Total illum C/U	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI QX50	J55	2019.NULL –	HVAC	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	Auto drive position	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	Auto back door	√	√	√	√		SP0611
American samoa	INFINITI QX50	J55	2019.NULL –	Occupant detection			√	√		SP0584
American samoa	INFINITI QX50	J55	2019.NULL –	Shift						
American samoa	INFINITI QX50	J55	2019.NULL –	Adaptive light	√	√	√	√		SP0562
American samoa	INFINITI QX50	J55	2019.NULL –	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
American samoa	INFINITI QX50	J55	2019.NULL –	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
American samoa	INFINITI QX50	J55	2019.NULL –	All mode AWD/4WD	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	DAST 2	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
American samoa	INFINITI QX50	J55	2019.NULL –	CAN gateway	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	Lane camera	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	DAST 1	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	Chassis control	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	ANC						
American samoa	INFINITI QX50	J55	2019.NULL –	E-HUD	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI QX50	J55	2019.NULL –	Telematics	√	√	√	√		SP0590,SP0591,SP0592
American samoa	INFINITI QX50	J55	2019.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI QX50	J55	2019.NULL –	6ch CAN GATEWAY	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	3ch CAN GATEWAY	√	√	√	√		
American samoa	INFINITI QX50	J55	2019.NULL –	ICC/ADAS 2	√	√	√	√		
American samoa	INFINITI QX56	JA60	2004.NULL –	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
American samoa	INFINITI QX56	JA60	2004.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
American samoa	INFINITI QX56	JA60	2004.NULL –	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
American samoa	INFINITI QX56	JA60	2004.NULL –	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
American samoa	INFINITI QX56	JA60	2004.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI QX56	JA60	2004.NULL –	EPS/DAST 3	√	√	√	√		SP0506,SP0507
American samoa	INFINITI QX56	JA60	2004.NULL –	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
American samoa	INFINITI QX56	JA60	2004.NULL –	Motor control						
American samoa	INFINITI QX56	JA60	2004.NULL –	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
American samoa	INFINITI QX56	JA60	2004.NULL –	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
American samoa	INFINITI QX56	JA60	2004.NULL –	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
American samoa	INFINITI QX56	JA60	2004.NULL –	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
American samoa	INFINITI QX56	JA60	2004.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI QX56	JA60	2004.NULL –	HVAC	√	√	√	√		
American samoa	INFINITI QX56	JA60	2004.NULL –	Difference lock	√	√	√	√		
American samoa	INFINITI QX56	JA60	2004.NULL –	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
American samoa	INFINITI QX56	JA60	2004.NULL –	Auto slide door	√	√	√	√	AC0941	
American samoa	INFINITI QX56	JA60	2004.NULL –	DIU		√	√	√		
American samoa	INFINITI QX56	JA60	2004.NULL –	Adaptive light	√	√	√	√		
American samoa	INFINITI QX56	JA60	2004.NULL –	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
American samoa	INFINITI QX56	JA60	2004.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
American samoa	INFINITI QX56	JA60	2004.NULL –	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
American samoa	INFINITI QX56	JA60	2004.NULL –	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
American samoa	INFINITI QX56	JA60	2004.NULL –	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
American samoa	INFINITI QX56	JA60	2004.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI QX56	JA60	2004.NULL –	IVMS	√	√		√		
American samoa	INFINITI QX56	JA60	2004.NULL –	Distance control	√	√		√		
American samoa	INFINITI QX56	JA60	2004.NULL –	Active suspense system	√	√	√	√		
American samoa	INFINITI QX56	JA60	2004.NULL –	Motor assist		√	√	√		SP0574
American samoa	INFINITI QX56	JA60	2004.NULL –	ASCD	√	√	√	√		
American samoa	INFINITI QX56	JA60	2004.NULL –	Active engine mount	√	√	√	√		
American samoa	INFINITI QX56	JA60	2004.NULL –	TCS	√	√	√	√		
American samoa	INFINITI QX56	JA60	2004.NULL –	S/blind camera	√			√		SP0572,SP0573
American samoa	INFINITI QX56	JA60	2004.NULL –	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
American samoa	INFINITI QX56	JA60	2004.NULL –	Nats immu	√	√	√			
American samoa	INFINITI QX56	JA60	2004.NULL –	Rearview camera	√			√		SP0570,SP0571

American samoa	INFINITI QX56	JA60	2004.NULL –	Smart entrance						SP0568
American samoa	INFINITI QX56	Z62	2011.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
American samoa	INFINITI QX56	Z62	2011.NULL –	Laser/radar	√	√	√	√		
American samoa	INFINITI QX56	Z62	2011.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI QX56	Z62	2011.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
American samoa	INFINITI QX56	Z62	2011.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI QX56	Z62	2011.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI QX56	Z62	2011.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
American samoa	INFINITI QX56	Z62	2011.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
American samoa	INFINITI QX56	Z62	2011.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
American samoa	INFINITI QX56	Z62	2011.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
American samoa	INFINITI QX56	Z62	2011.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
American samoa	INFINITI QX56	Z62	2011.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI QX56	Z62	2011.NULL –	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0476, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488, SP0489, SP0490
American samoa	INFINITI QX56	Z62	2011.NULL –	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
American samoa	INFINITI QX56	Z62	2011.NULL –	Difference lock	√	√	√	√		
American samoa	INFINITI QX56	Z62	2011.NULL –	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI QX56	Z62	2011.NULL –	Auto back door	√	√	√	√		
American samoa	INFINITI QX56	Z62	2011.NULL –	Occupant detection			√	√		SP0584
American samoa	INFINITI QX56	Z62	2011.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
American samoa	INFINITI QX56	Z62	2011.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI QX56	Z62	2011.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
American samoa	INFINITI QX56	Z62	2011.NULL –	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
American samoa	INFINITI QX56	Z62	2011.NULL –	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI QX56	Z62	2011.NULL –	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI QX56	Z62	2011.NULL –	CAN gateway	√	√	√			
American samoa	INFINITI QX56	Z62	2011.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
American samoa	INFINITI QX56	Z62	2011.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI QX56	Z62	2011.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
American samoa	INFINITI QX56	Z62	2011.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI QX56	Z62	2011.NULL –	Rearview camera	√			√		SP0570, SP0571
American samoa	INFINITI QX60	L50	2019.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
American samoa	INFINITI QX60	L50	2019.2-	Laser/radar	√	√	√	√	AC0994	
American samoa	INFINITI QX60	L50	2019.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI QX60	L50	2019.2-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
American samoa	INFINITI QX60	L50	2019.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI QX60	L50	2019.2-	Air bag	√	√	√	√		
American samoa	INFINITI QX60	L50	2019.2-	EPS/DAST 3	√	√	√	√		
American samoa	INFINITI QX60	L50	2019.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
American samoa	INFINITI QX60	L50	2019.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
American samoa	INFINITI QX60	L50	2019.2-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
American samoa	INFINITI QX60	L50	2019.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
American samoa	INFINITI QX60	L50	2019.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
American samoa	INFINITI QX60	L50	2019.2-	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI QX60	L50	2019.2-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
American samoa	INFINITI QX60	L50	2019.2-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI QX60	L50	2019.2-	Auto back door	√	√	√	√		SP0611
American samoa	INFINITI QX60	L50	2019.2-	Occupant detection			√	√		SP0584
American samoa	INFINITI QX60	L50	2019.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI QX60	L50	2019.2-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI QX60	L50	2019.2-	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI QX60	L50	2019.2-	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI QX60	L50	2019.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI QX60	L50	2019.2-	CAN gateway	√	√	√			
American samoa	INFINITI QX60	L50	2019.2-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
American samoa	INFINITI QX60	L50	2019.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
American samoa	INFINITI QX60	L50	2019.2-	ANC	√	√	√	√	AC1024	
American samoa	INFINITI QX60	L50	2019.2-	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI QX60	L50	2019.2-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
American samoa	INFINITI QX60	L50	2019.2-	HIGH BEAM ASSIST	√	√	√	√		
American samoa	INFINITI QX60	L50	2019.2-	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI QX60	L50	2019.2-	3ch CAN GATEWAY	√	√	√	√		
American samoa	INFINITI QX60	L50	2019.2-	ICC/ADAS 2	√	√	√	√		
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Laser/radar	√	√	√	√		
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	EPS/DAST 3	√	√	√	√		
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Motor control	√	√	√	√		
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0038, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	HV battery	√	√	√	√	AC1121	
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Auto back door	√	√	√	√		SP0611
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Occupant detection			√	√		SP0584
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	CAN gateway	√	√	√			
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	ANC	√	√	√	√		
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	HIGH BEAM ASSIST	√	√	√	√		
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	ICC/ADAS 2	√	√	√	√		
American samoa	INFINITI QX60 HYBRID	HL50	2014.NULL –	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
American samoa	INFINITI QX70	S51	2014.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
American samoa	INFINITI QX70	S51	2014.NULL –	Laser/radar	√	√	√	√	AC0994	
American samoa	INFINITI QX70	S51	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI QX70	S51	2014.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
American samoa	INFINITI QX70	S51	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI QX70	S51	2014.NULL –	Air bag	√	√	√	√		
American samoa	INFINITI QX70	S51	2014.NULL –	EPS/DAST 3	√	√	√	√		SP0507
American samoa	INFINITI QX70	S51	2014.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
American samoa	INFINITI QX70	S51	2014.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
American samoa	INFINITI QX70	S51	2014.NULL –	Transmission	√	√	√	√		SP0274
American samoa	INFINITI QX70	S51	2014.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
American samoa	INFINITI QX70	S51	2014.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
American samoa	INFINITI QX70	S51	2014.NULL –	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
American samoa	INFINITI QX70	S51	2014.NULL –	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI QX70	S51	2014.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
American samoa	INFINITI QX70	S51	2014.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
American samoa	INFINITI QX70	S51	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI QX70	S51	2014.NULL –	Auto back door	√	√	√	√		SP0611
American samoa	INFINITI QX70	S51	2014.NULL –	Occupant detection			√	√		SP0584
American samoa	INFINITI QX70	S51	2014.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
American samoa	INFINITI QX70	S51	2014.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI QX70	S51	2014.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
American samoa	INFINITI QX70	S51	2014.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
American samoa	INFINITI QX70	S51	2014.NULL –	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI QX70	S51	2014.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI QX70	S51	2014.NULL –	CAN gateway	√	√	√			
American samoa	INFINITI QX70	S51	2014.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
American samoa	INFINITI QX70	S51	2014.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
American samoa	INFINITI QX80	Z62	2019.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510

American samoa	INFINITI QX80	Z62	2019.NULL-	Laser/radar	√	√	√	√	AC0994	
American samoa	INFINITI QX80	Z62	2019.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
American samoa	INFINITI QX80	Z62	2019.NULL-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
American samoa	INFINITI QX80	Z62	2019.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
American samoa	INFINITI QX80	Z62	2019.NULL-	Air bag	√	√	√	√		
American samoa	INFINITI QX80	Z62	2019.NULL-	EPS/DAST 3	√	√	√	√		SP0507
American samoa	INFINITI QX80	Z62	2019.NULL-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
American samoa	INFINITI QX80	Z62	2019.NULL-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
American samoa	INFINITI QX80	Z62	2019.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
American samoa	INFINITI QX80	Z62	2019.NULL-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
American samoa	INFINITI QX80	Z62	2019.NULL-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
American samoa	INFINITI QX80	Z62	2019.NULL-	Multi AV	√	√	√	√		SP0503
American samoa	INFINITI QX80	Z62	2019.NULL-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
American samoa	INFINITI QX80	Z62	2019.NULL-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
American samoa	INFINITI QX80	Z62	2019.NULL-	Difference lock	√	√	√	√		
American samoa	INFINITI QX80	Z62	2019.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
American samoa	INFINITI QX80	Z62	2019.NULL-	Auto back door	√	√	√	√		
American samoa	INFINITI QX80	Z62	2019.NULL-	Occupant detection			√	√		SP0584
American samoa	INFINITI QX80	Z62	2019.NULL-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
American samoa	INFINITI QX80	Z62	2019.NULL-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
American samoa	INFINITI QX80	Z62	2019.NULL-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
American samoa	INFINITI QX80	Z62	2019.NULL-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
American samoa	INFINITI QX80	Z62	2019.NULL-	Precrash seatbelt	√	√	√	√		SP0612
American samoa	INFINITI QX80	Z62	2019.NULL-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
American samoa	INFINITI QX80	Z62	2019.NULL-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
American samoa	INFINITI QX80	Z62	2019.NULL-	CAN gateway	√	√	√			
American samoa	INFINITI QX80	Z62	2019.NULL-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
American samoa	INFINITI QX80	Z62	2019.NULL-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
American samoa	INFINITI QX80	Z62	2019.NULL-	Side radar left	√	√	√	√	AC1025	SP0582
American samoa	INFINITI QX80	Z62	2019.NULL-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
American samoa	INFINITI QX80	Z62	2019.NULL-	HIGH BEAM ASSIST	√	√	√	√		
American samoa	INFINITI QX80	Z62	2019.NULL-	Side radar right	√	√	√	√	AC1026	SP0583
American samoa	INFINITI QX80	Z62	2019.NULL-	6ch CAN GATEWAY	√	√	√	√		
American samoa	INFINITI QX80	Z62	2019.NULL-	ICC/ADAS 2	√	√	√	√		
American samoa	INFINITI QX80	Z62	2019.NULL-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Angola	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Angola	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI EX35/EX37	I50	2011.1-	Air bag	√	√	√	√		
Angola	INFINITI EX35/EX37	I50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Angola	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Angola	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Angola	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Angola	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Angola	INFINITI EX35/EX37	I50	2011.1-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Angola	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Angola	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Angola	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Angola	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Angola	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Angola	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Angola	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Angola	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Angola	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Angola	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Angola	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Angola	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Angola	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Angola	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Angola	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Angola	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Angola	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Angola	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611

Angola	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Angola	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Angola	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Angola	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Angola	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Angola	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Angola	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Angola	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Angola	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Angola	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Angola	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Angola	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Angola	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Angola	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Angola	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Angola	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Angola	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Angola	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Angola	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Angola	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Angola	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Angola	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Angola	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Angola	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Angola	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Angola	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Angola	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Angola	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Angola	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Angola	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Angola	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Angola	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Angola	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Angola	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Angola	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Angola	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Angola	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Angola	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Angola	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Angola	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Angola	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Angola	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Angola	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Angola	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Angola	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Angola	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Angola	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Angola	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Angola	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Angola	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Angola	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Angola	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Angola	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Angola	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Angola	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Angola	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Angola	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Angola	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Angola	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Angola	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Angola	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Angola	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Angola	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Angola	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Angola	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Angola	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Angola	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Angola	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Angola	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Angola	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Angola	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Angola	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Angola	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Angola	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Angola	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Angola	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Angola	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Angola	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Angola	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Angola	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Angola	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Angola	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Angola	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Angola	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Angola	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Angola	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Angola	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Angola	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Angola	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Angola	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Angola	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Angola	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Angola	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Angola	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	

Angola	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Angola	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Angola	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Angola	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Angola	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Angola	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Angola	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Angola	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Angola	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Angola	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Angola	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Angola	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Angola	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Angola	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Angola	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Angola	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Angola	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Angola	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Angola	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Angola	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Angola	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Angola	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Angola	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Angola	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Angola	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Angola	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Angola	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Angola	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Angola	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Angola	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Angola	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Angola	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Angola	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Angola	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Angola	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Angola	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Angola	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Angola	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Angola	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Angola	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Angola	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Angola	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Angola	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Angola	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Angola	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Angola	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Angola	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Angola	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		

Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Angola	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Angola	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Angola	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Angola	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Angola	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Angola	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Angola	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Angola	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Angola	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Angola	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Angola	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Angola	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Angola	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Angola	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Angola	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Angola	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Angola	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Angola	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Angola	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Angola	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Angola	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Angola	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Angola	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Angola	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Angola	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Angola	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Angola	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Angola	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Angola	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Angola	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Angola	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Angola	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Angola	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Angola	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Angola	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Angola	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Angola	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Angola	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Angola	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Angola	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Angola	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Angola	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Angola	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Angola	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Angola	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Angola	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Angola	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Angola	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Angola	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Angola	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Angola	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Angola	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Angola	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Angola	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Angola	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Angola	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Angola	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Angola	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Angola	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Angola	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Angola	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Angola	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Angola	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Angola	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Angola	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Angola	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Angola	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Angola	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Angola	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Angola	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Angola	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Angola	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Angola	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Angola	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Angola	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Angola	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Angola	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Angola	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Angola	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Angola	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Angola	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Angola	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Angola	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Angola	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Angola	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Angola	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Angola	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Angola	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Angola	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Angola	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Angola	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Angola	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Angola	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Angola	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Angola	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Angola	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Angola	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Angola	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Angola	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Angola	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Angola	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Angola	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Angola	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Angola	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Angola	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Angola	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Angola	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Angola	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Angola	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Angola	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Angola	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Angola	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Angola	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Angola	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Angola	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Angola	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Angola	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Angola	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Angola	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Angola	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Angola	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Angola	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Angola	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Angola	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Angola	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Angola	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Angola	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Angola	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Angola	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Angola	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Angola	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Angola	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Angola	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Antigua	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Antigua	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Antigua	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Antigua	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Antigua	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Antigua	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Antigua	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Antigua	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315

Antigua	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Antigua	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Antigua	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Antigua	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Antigua	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Antigua	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Antigua	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Antigua	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Antigua	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Antigua	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Antigua	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Antigua	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Antigua	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Antigua	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Antigua	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Antigua	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0155, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Antigua	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Antigua	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Antigua	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Antigua	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Antigua	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Antigua	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Antigua	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Antigua	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Antigua	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Antigua	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Antigua	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Antigua	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Antigua	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Antigua	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Antigua	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Antigua	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Antigua	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Antigua	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Antigua	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Antigua	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		

Antigua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Antigua	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Antigua	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Antigua	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Antigua	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Antigua	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Antigua	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Antigua	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Antigua	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Antigua	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Antigua	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Antigua	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Antigua	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Antigua	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Antigua	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Antigua	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Antigua	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Antigua	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Antigua	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Antigua	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Antigua	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Antigua	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Antigua	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Antigua	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Antigua	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Antigua	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Antigua	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Antigua	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Antigua	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Antigua	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Antigua	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Antigua	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Antigua	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Antigua	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Antigua	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Antigua	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Antigua	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Antigua	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Antigua	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Antigua	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Antigua	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Antigua	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Antigua	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Antigua	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Antigua	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Antigua	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Antigua	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Antigua	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Antigua	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Antigua	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Antigua	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Antigua	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Antigua	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Antigua	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Antigua	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Antigua	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Antigua	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Antigua	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Antigua	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Antigua	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Antigua	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Antigua	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Antigua	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Antigua	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Antigua	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Antigua	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Antigua	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Antigua	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Antigua	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Antigua	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Antigua	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Antigua	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Antigua	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Antigua	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Antigua	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Antigua	INFINITI Q45	F50	2001.8-	Motor control						
Antigua	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Antigua	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Antigua	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Antigua	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Antigua	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Antigua	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Antigua	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Antigua	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Antigua	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Antigua	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Antigua	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Antigua	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962. AC0963. AC0964. AC0966. AC0967. AC0968. AC0969. AC0970	SP0553. SP0554. SP0555. SP0556. SP0557. SP0558. SP0559
Antigua	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Antigua	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Antigua	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Antigua	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Antigua	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Antigua	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Antigua	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Antigua	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Antigua	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Antigua	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Antigua	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Antigua	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Antigua	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572. SP0573
Antigua	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Antigua	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Antigua	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Antigua	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Antigua	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Antigua	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Antigua	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Antigua	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Antigua	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Antigua	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Antigua	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Antigua	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Antigua	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Antigua	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Antigua	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Antigua	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Antigua	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031. AC1032. AC1033	SP0585. SP0586. SP0587
Antigua	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946. AC0947. AC0948. AC0950. AC0951. AC0952. AC0953. AC0954. AC0955	SP0541. SP0542. SP0543
Antigua	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Antigua	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Antigua	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Antigua	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Antigua	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Antigua	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Antigua	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Antigua	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Antigua	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Antigua	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Antigua	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Antigua	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Argentina	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Argentina	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Argentina	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Argentina	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Argentina	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375. AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Argentina	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Argentina	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Argentina	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Argentina	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Argentina	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Argentina	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Argentina	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Argentina	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Argentina	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Argentina	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Argentina	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Argentina	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Argentina	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Argentina	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Argentina	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Argentina	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Argentina	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Argentina	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Argentina	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Argentina	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Argentina	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Argentina	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Argentina	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Argentina	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Argentina	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034. AC1035. AC1036. AC1037. AC1038. AC1039	
Argentina	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Argentina	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Argentina	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Argentina	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Argentina	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Argentina	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Argentina	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Argentina	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Argentina	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Argentina	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Argentina	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Argentina	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Argentina	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570. SP0571
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Argentina	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Argentina	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Argentina	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Argentina	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Argentina	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Argentina	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Argentina	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Argentina	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Argentina	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Argentina	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Argentina	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Argentina	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Argentina	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Argentina	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Argentina	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Argentina	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Argentina	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Argentina	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Argentina	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Argentina	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Argentina	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Argentina	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Argentina	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Argentina	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Argentina	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Argentina	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Argentina	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Argentina	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Argentina	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Argentina	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Argentina	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Argentina	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Argentina	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Argentina	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Argentina	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Argentina	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Argentina	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Argentina	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Argentina	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Argentina	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582

Argentina	INFINITI FX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Argentina	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Argentina	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Argentina	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Argentina	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Argentina	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Argentina	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Argentina	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Argentina	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Argentina	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Argentina	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Argentina	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Argentina	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Argentina	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Argentina	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Argentina	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Argentina	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Argentina	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Argentina	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Argentina	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Argentina	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Argentina	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Argentina	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Argentina	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Argentina	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Argentina	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Argentina	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Argentina	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Argentina	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Argentina	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Argentina	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Argentina	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Argentina	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Argentina	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Argentina	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Argentina	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Argentina	INFINITI Q45	F50	2001.8-	Motor control						
Argentina	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Argentina	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Argentina	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Argentina	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Argentina	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Argentina	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Argentina	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Argentina	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Argentina	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Argentina	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Argentina	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Argentina	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Argentina	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Argentina	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Argentina	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Argentina	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Argentina	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Argentina	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Argentina	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Argentina	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Argentina	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Argentina	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Argentina	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Argentina	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Argentina	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Argentina	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Argentina	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Argentina	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Argentina	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Argentina	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Argentina	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Argentina	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Argentina	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Argentina	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Argentina	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Argentina	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Argentina	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Argentina	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Argentina	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Argentina	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Argentina	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Argentina	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Argentina	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Argentina	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Argentina	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Argentina	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Argentina	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Argentina	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Argentina	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Argentina	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Argentina	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Argentina	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Argentina	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582

Argentina	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590、SP0591、SP0592
Argentina	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Aruba	INFINITI EX35/EX37	I50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Aruba	INFINITI EX35/EX37	I50	2011.1-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0876、AC0877	SP0494
Aruba	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Aruba	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Aruba	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004、AC0035、AC0036、AC0037、AC0051、AC0052、AC0053、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0147、AC0148、AC0149、AC0150、AC0154、AC0155、AC0156、AC0157、AC0160、AC0162、AC0164、AC0166、AC0168、AC0171、AC0172、AC0173、AC0174、AC0178、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0282、AC0283、AC0307、AC0351、AC0352、AC0365、AC0366、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0016、SP0032、SP0033、SP0053、SP0063、SP0064、SP0074、SP0079、SP0085、SP0086、SP0087、SP0104、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0152、SP0153、SP0160、SP0172、SP0173、SP0191、SP0192、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0239
Aruba	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270、SP0274
Aruba	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613、AC0618、AC0663、AC0692、AC0702、AC0719	SP0372、SP0429
Aruba	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533	SP0301、SP0313、SP0315
Aruba	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Aruba	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Aruba	INFINITI EX35/EX37	I50	2011.1-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980	SP0561、SP0562
Aruba	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Aruba	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962、AC0963、AC0964	SP0553、SP0554、SP0555、SP0556
Aruba	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Aruba	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973、AC0974、AC0975、AC0976	SP0560
Aruba	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Aruba	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Aruba	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894、AC0895、AC0896	SP0510
Aruba	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Aruba	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0876、AC0877	SP0494
Aruba	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Aruba	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Aruba	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350
Aruba	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0282、AC0283、AC0307、AC0333、AC0334、AC0335、AC0336、AC0337、AC0338、AC0339、AC0351、AC0352、AC0365、AC0366、AC0367、AC0369、AC0371、AC0372、AC0373、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0016、SP0017、SP0018、SP0032、SP0033、SP0043、SP0045、SP0051、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0083、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0196、SP0197、SP0198、SP0199、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0225、SP0237、SP0238、SP0239
Aruba	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Aruba	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613、AC0618、AC0663、AC0692、AC0702、AC0719	SP0372、SP0429
Aruba	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533	SP0301、SP0313、SP0315
Aruba	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133、AC1134、AC1135、AC1136、AC1137、AC1138、AC1139、AC1140、AC1141、AC1142	SP0614、SP0615、SP0616、SP0617、SP0618、SP0619、SP0620、SP0621
Aruba	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Aruba	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034、AC1035、AC1036、AC1037、AC1038、AC1039	
Aruba	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Aruba	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Aruba	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Aruba	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980	SP0561、SP0562
Aruba	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Aruba	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962、AC0963、AC0964、AC0966、AC0967、AC0968	SP0553、SP0554、SP0556、SP0557
Aruba	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Aruba	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Aruba	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985、AC0986、AC0987、AC0988、AC0989	SP0563、SP0564、SP0565、SP0566、SP0567
Aruba	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Aruba	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973、AC0974、AC0975、AC0976	SP0560
Aruba	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Aruba	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570、SP0571
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006、AC1007、AC1008、AC1009、AC1010	SP0575、SP0576、SP0577、SP0578、SP0579、SP0580
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0876、AC0877、AC0884	SP0494
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0282、AC0283、AC0307、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0016、SP0017、SP0018、SP0032、SP0033、SP0043、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613、AC0618、AC0663、AC0692、AC0702、AC0719	SP0372、SP0429
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498、AC0507、AC0508、AC0509、AC0510、AC0511、AC0512、AC0513、AC0514、AC0515、AC0516、AC0517、AC0527、AC0528、AC0529、AC0530、AC0531、AC0532、AC0533、AC0534、AC0535	SP0315、SP0316、SP0317、SP0319
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027、AC1028	
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980	SP0561、SP0562
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962、AC0963、AC0964	SP0553、SP0554、SP0555、SP0556
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Aruba	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006、AC1007、AC1008、AC1009、AC1010	SP0575、SP0576、SP0577、SP0578、SP0579、SP0580
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867、AC0868、AC0884	SP0494
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0282、AC0283、AC0307、AC0333、AC0334、AC0335、AC0336、AC0337、AC0338、AC0339、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0009、SP0016、SP0017、SP0018、SP0032、SP0033、SP0043、SP0051、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0196、SP0197、SP0198、SP0200、SP0202、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270、SP0274
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613、AC0618、AC0663、AC0692、AC0702、AC0719	SP0372、SP0429
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498、AC0507、AC0508、AC0509、AC0510、AC0511、AC0512、AC0513、AC0514、AC0515、AC0516、AC0517、AC0527、AC0528、AC0529、AC0530、AC0531、AC0532、AC0533、AC0534、AC0535	SP0315、SP0316、SP0317、SP0319

Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Aruba	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Aruba	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Aruba	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Aruba	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Aruba	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Aruba	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Aruba	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Aruba	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Aruba	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Aruba	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Aruba	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Aruba	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Aruba	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Aruba	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Aruba	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Aruba	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Aruba	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Aruba	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Aruba	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Aruba	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Aruba	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Aruba	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Aruba	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Aruba	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Aruba	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Aruba	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Aruba	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Aruba	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Aruba	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Aruba	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Aruba	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Aruba	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Aruba	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Aruba	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Aruba	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Aruba	INFINITI IX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Aruba	INFINITI IX35	L50	2012.9-	CAN gateway	√	√	√			
Aruba	INFINITI IX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Aruba	INFINITI IX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Aruba	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Aruba	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Aruba	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Aruba	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Aruba	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Aruba	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Aruba	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Aruba	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Aruba	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Aruba	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Aruba	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Aruba	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Aruba	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Aruba	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Aruba	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Aruba	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Aruba	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Aruba	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Aruba	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Aruba	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Aruba	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Aruba	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Aruba	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Aruba	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Aruba	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Aruba	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Aruba	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Aruba	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Aruba	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Aruba	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Aruba	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Aruba	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Aruba	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Aruba	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Aruba	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Aruba	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Aruba	INFINITI Q45	F50	2001.8-	Motor control						

Aruba	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Aruba	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Aruba	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Aruba	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Aruba	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Aruba	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Aruba	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Aruba	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Aruba	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Aruba	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Aruba	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Aruba	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Aruba	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Aruba	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Aruba	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Aruba	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Aruba	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Aruba	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Aruba	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Aruba	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Aruba	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Aruba	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Aruba	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Aruba	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Aruba	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Aruba	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Aruba	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Aruba	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Aruba	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Aruba	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Aruba	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Aruba	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Aruba	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Aruba	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Aruba	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Aruba	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Aruba	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Aruba	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Aruba	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Aruba	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Aruba	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Aruba	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Aruba	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Aruba	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Aruba	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Aruba	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Aruba	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Aruba	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Aruba	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Aruba	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Aruba	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Aruba	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Aruba	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Aruba	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Aruba	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Asia common	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Air bag	√	√	√	√		
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350

Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Transmission	√	√	√	√		SP0274
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Auto back door	√	√	√	√		SP0611
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	CAN gateway	√	√	√			
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Australia	INFINITI FX37/FX50/FX30D	S51	2012.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	Air bag	√	√	√	√		
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	Transmission	√	√	√	√		SP0274
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	Pop up hood	√	√	√	√		
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Australia	INFINITI G37 CONVERTIBLE	HV36	2012.10-	Precrash seatbelt	√	√	√	√		
Australia	INFINITI G37 COUPE	CV36	2012.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI G37 COUPE	CV36	2012.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Australia	INFINITI G37 COUPE	CV36	2012.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI G37 COUPE	CV36	2012.10-	Air bag	√	√	√	√		
Australia	INFINITI G37 COUPE	CV36	2012.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Australia	INFINITI G37 COUPE	CV36	2012.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Australia	INFINITI G37 COUPE	CV36	2012.10-	Transmission	√	√	√	√		SP0274
Australia	INFINITI G37 COUPE	CV36	2012.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Australia	INFINITI G37 COUPE	CV36	2012.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Australia	INFINITI G37 COUPE	CV36	2012.10-	Pop up hood	√	√	√	√		
Australia	INFINITI G37 COUPE	CV36	2012.10-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI G37 COUPE	CV36	2012.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Australia	INFINITI G37 COUPE	CV36	2012.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI G37 COUPE	CV36	2012.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Australia	INFINITI G37 COUPE	CV36	2012.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Australia	INFINITI G37 COUPE	CV36	2012.10-	Precrash seatbelt	√	√	√	√		
Australia	INFINITI G37 COUPE	CV36	2012.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Australia	INFINITI M35H	HY51	2012.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Australia	INFINITI M35H	HY51	2012.6-	Laser/radar	√	√	√	√		
Australia	INFINITI M35H	HY51	2012.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI M35H	HY51	2012.6-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Australia	INFINITI M35H	HY51	2012.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI M35H	HY51	2012.6-	Air bag	√	√	√	√		
Australia	INFINITI M35H	HY51	2012.6-	EPS/DAST 3	√	√	√	√		
Australia	INFINITI M35H	HY51	2012.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Australia	INFINITI M35H	HY51	2012.6-	Motor control	√	√	√	√		
Australia	INFINITI M35H	HY51	2012.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Australia	INFINITI M35H	HY51	2012.6-	Transmission	√	√	√	√		SP0274, SP0276
Australia	INFINITI M35H	HY51	2012.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Australia	INFINITI M35H	HY51	2012.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Australia	INFINITI M35H	HY51	2012.6-	Pop up hood	√	√	√	√		
Australia	INFINITI M35H	HY51	2012.6-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI M35H	HY51	2012.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487

Australia	INFINITI M35H	HY51	2012.6-	HV battery	√	√	√	√	AC1121	
Australia	INFINITI M35H	HY51	2012.6-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI M35H	HY51	2012.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Australia	INFINITI M35H	HY51	2012.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Australia	INFINITI M35H	HY51	2012.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Australia	INFINITI M35H	HY51	2012.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Australia	INFINITI M35H	HY51	2012.6-	Precrash seatbelt	√	√	√	√		SP0612
Australia	INFINITI M35H	HY51	2012.6-	CAN gateway	√	√	√			
Australia	INFINITI M35H	HY51	2012.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Australia	INFINITI M35H	HY51	2012.6-	Side radar left	√	√	√	√	AC1025	SP0582
Australia	INFINITI M35H	HY51	2012.6-	Side radar right	√	√	√	√	AC1026	SP0583
Australia	INFINITI M35H	HY51	2012.6-	Brake	√	√	√	√	AC1127	
Australia	INFINITI M35H	HY51	2012.6-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Australia	INFINITI M37/M30D	Y51	2012.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Australia	INFINITI M37/M30D	Y51	2012.6-	Laser/radar	√	√	√	√		
Australia	INFINITI M37/M30D	Y51	2012.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI M37/M30D	Y51	2012.6-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Australia	INFINITI M37/M30D	Y51	2012.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI M37/M30D	Y51	2012.6-	Air bag	√	√	√	√		
Australia	INFINITI M37/M30D	Y51	2012.6-	EPS/DAST 3	√	√	√	√		
Australia	INFINITI M37/M30D	Y51	2012.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Australia	INFINITI M37/M30D	Y51	2012.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Australia	INFINITI M37/M30D	Y51	2012.6-	Transmission	√	√	√	√		SP0274
Australia	INFINITI M37/M30D	Y51	2012.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Australia	INFINITI M37/M30D	Y51	2012.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0313, SP0315, SP0316, SP0317, SP0319
Australia	INFINITI M37/M30D	Y51	2012.6-	Pop up hood	√	√	√	√		
Australia	INFINITI M37/M30D	Y51	2012.6-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI M37/M30D	Y51	2012.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Australia	INFINITI M37/M30D	Y51	2012.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Australia	INFINITI M37/M30D	Y51	2012.6-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI M37/M30D	Y51	2012.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Australia	INFINITI M37/M30D	Y51	2012.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Australia	INFINITI M37/M30D	Y51	2012.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Australia	INFINITI M37/M30D	Y51	2012.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Australia	INFINITI M37/M30D	Y51	2012.6-	Precrash seatbelt	√	√	√	√		SP0612
Australia	INFINITI M37/M30D	Y51	2012.6-	CAN gateway	√	√	√			
Australia	INFINITI M37/M30D	Y51	2012.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Australia	INFINITI M37/M30D	Y51	2012.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Australia	INFINITI M37/M30D	Y51	2012.6-	Side radar left	√	√	√	√	AC1025	SP0582
Australia	INFINITI M37/M30D	Y51	2012.6-	Side radar right	√	√	√	√	AC1026	SP0583
Australia	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Australia	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Australia	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Australia	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Australia	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Australia	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Australia	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Australia	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Australia	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Australia	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Australia	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Australia	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Australia	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Australia	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Australia	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Australia	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Australia	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Australia	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Australia	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Australia	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Australia	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Australia	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Australia	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Australia	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Australia	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Australia	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	

Xtool

Australia	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Australia	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Australia	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Australia	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Australia	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Australia	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Australia	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Australia	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Australia	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Australia	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Australia	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Australia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Australia	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Australia	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Australia	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Australia	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Australia	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Australia	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Australia	INFINITI Q50	V37	2013.9-	Motor control	√	√	√	√		
Australia	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Australia	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Australia	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Australia	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Australia	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Australia	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Australia	INFINITI Q50	V37	2013.9-	HV battery	√	√	√	√	AC1121	
Australia	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Australia	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Australia	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI Q50	V37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Australia	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Australia	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Australia	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Australia	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Australia	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Australia	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Australia	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Australia	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Australia	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Australia	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Australia	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Australia	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Australia	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Australia	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Australia	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Australia	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Australia	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Australia	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Australia	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Australia	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Australia	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Australia	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Australia	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Australia	INFINITI Q50	V37	2013.9-	Brake	√	√	√	√	AC1127	
Australia	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Australia	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Australia	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Australia	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Australia	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Australia	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Australia	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		

Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Australia	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Australia	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Australia	INFINITI Q60	CV37	2016.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Australia	INFINITI Q60	CV37	2016.8-	Laser/radar	√	√	√	√	AC0994	
Australia	INFINITI Q60	CV37	2016.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI Q60	CV37	2016.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Australia	INFINITI Q60	CV37	2016.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI Q60	CV37	2016.8-	Air bag	√	√	√	√		
Australia	INFINITI Q60	CV37	2016.8-	EPS/DAST 3	√	√	√	√		
Australia	INFINITI Q60	CV37	2016.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Australia	INFINITI Q60	CV37	2016.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Australia	INFINITI Q60	CV37	2016.8-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Australia	INFINITI Q60	CV37	2016.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Australia	INFINITI Q60	CV37	2016.8-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Australia	INFINITI Q60	CV37	2016.8-	Pop up hood	√	√	√	√		
Australia	INFINITI Q60	CV37	2016.8-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI Q60	CV37	2016.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Australia	INFINITI Q60	CV37	2016.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Australia	INFINITI Q60	CV37	2016.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI Q60	CV37	2016.8-	Occupant detection			√	√		SP0584
Australia	INFINITI Q60	CV37	2016.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Australia	INFINITI Q60	CV37	2016.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Australia	INFINITI Q60	CV37	2016.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Australia	INFINITI Q60	CV37	2016.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Australia	INFINITI Q60	CV37	2016.8-	DAST 2	√	√	√	√		
Australia	INFINITI Q60	CV37	2016.8-	Precrash seatbelt	√	√	√	√		SP0612
Australia	INFINITI Q60	CV37	2016.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Australia	INFINITI Q60	CV37	2016.8-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Australia	INFINITI Q60	CV37	2016.8-	CAN gateway	√	√	√			
Australia	INFINITI Q60	CV37	2016.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Australia	INFINITI Q60	CV37	2016.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Australia	INFINITI Q60	CV37	2016.8-	DAST 1	√	√	√	√		
Australia	INFINITI Q60	CV37	2016.8-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Australia	INFINITI Q60	CV37	2016.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Australia	INFINITI Q60	CV37	2016.8-	ANC	√	√	√	√	AC1024	
Australia	INFINITI Q60	CV37	2016.8-	Side radar left	√	√	√	√	AC1025	SP0582
Australia	INFINITI Q60	CV37	2016.8-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Australia	INFINITI Q60	CV37	2016.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Australia	INFINITI Q60	CV37	2016.8-	HIGH BEAM ASSIST	√	√	√	√		
Australia	INFINITI Q60	CV37	2016.8-	Side radar right	√	√	√	√	AC1026	SP0583
Australia	INFINITI Q60	CV37	2016.8-	Lane camera 2	√	√	√	√		
Australia	INFINITI Q60	CV37	2016.8-	6ch CAN GATEWAY	√	√	√	√		
Australia	INFINITI Q60	CV37	2016.8-	ICC/ADAS 2	√	√	√	√		
Australia	INFINITI Q60	CV37	2016.8-	FSCM	√	√	√	√	AC1109	
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Australia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Australia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Australia	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Australia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Australia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Australia	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Australia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Australia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Australia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Australia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Australia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Australia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Australia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Australia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Australia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Australia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Australia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Australia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Australia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Australia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Australia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Australia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Australia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Australia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Australia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Australia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Australia	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		

Australia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Australia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Australia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Australia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Australia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Australia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Australia	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Australia	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Australia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Australia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Australia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Australia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Australia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Australia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Australia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Australia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Australia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Australia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Australia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Australia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Australia	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Australia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Australia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Australia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Australia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Australia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Australia	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Australia	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Australia	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Australia	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Australia	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√	√		
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	ANC	√	√	√	√	AC1024	
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	FSCM	√	√	√	√	AC1109	
Australia	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Laser/radar	√	√	√	√		
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Air bag	√	√	√	√		
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	EPS/DAST 3	√	√	√	√		
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Motor control	√	√	√	√		
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Pop up hood	√	√	√	√		
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487

Australia	INFINITI Q70 Hybrid	HY51	2018.5-	HV battery	√	√	√	√	AC1121	
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Precrash seatbelt	√	√	√	√		SP0612
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	VSP	√	√	√	√		
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	Brake	√	√	√	√	AC1127	
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	ICC/ADAS 2	√	√	√	√		
Australia	INFINITI Q70 Hybrid	HY51	2018.5-	PSCM	√	√	√	√	AC1109	
Australia	INFINITI QX60	L50	2014.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Australia	INFINITI QX60	L50	2014.9-	Laser/radar	√	√	√	√		
Australia	INFINITI QX60	L50	2014.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI QX60	L50	2014.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Australia	INFINITI QX60	L50	2014.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI QX60	L50	2014.9-	Air bag	√	√	√	√		
Australia	INFINITI QX60	L50	2014.9-	EPS/DAST 3	√	√	√	√		
Australia	INFINITI QX60	L50	2014.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Australia	INFINITI QX60	L50	2014.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Australia	INFINITI QX60	L50	2014.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Australia	INFINITI QX60	L50	2014.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Australia	INFINITI QX60	L50	2014.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Australia	INFINITI QX60	L50	2014.9-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI QX60	L50	2014.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Australia	INFINITI QX60	L50	2014.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI QX60	L50	2014.9-	Auto back door	√	√	√	√		SP0611
Australia	INFINITI QX60	L50	2014.9-	Occupant detection			√	√		SP0584
Australia	INFINITI QX60	L50	2014.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Australia	INFINITI QX60	L50	2014.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Australia	INFINITI QX60	L50	2014.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Australia	INFINITI QX60	L50	2014.9-	Precrash seatbelt	√	√	√	√		SP0612
Australia	INFINITI QX60	L50	2014.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Australia	INFINITI QX60	L50	2014.9-	CAN gateway	√	√	√			
Australia	INFINITI QX60	L50	2014.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Australia	INFINITI QX60	L50	2014.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Australia	INFINITI QX60	L50	2014.9-	Side radar left	√	√	√	√	AC1025	SP0582
Australia	INFINITI QX60	L50	2014.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Australia	INFINITI QX60	L50	2014.9-	Side radar right	√	√	√	√	AC1026	SP0583
Australia	INFINITI QX60	L50	2014.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Australia	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Australia	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Australia	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Australia	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Australia	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Australia	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Australia	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Australia	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Australia	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Australia	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Australia	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Australia	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Australia	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Australia	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Australia	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Australia	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Australia	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Australia	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Australia	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Australia	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Australia	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Australia	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Australia	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Australia	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Australia	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Australia	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Australia	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Australia	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Australia	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Australia	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Australia	INFINITI QX80	Z62	2013.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Australia	INFINITI QX80	Z62	2013.8-	Laser/radar	√	√	√	√	AC0994	
Australia	INFINITI QX80	Z62	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Australia	INFINITI QX80	Z62	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Australia	INFINITI QX80	Z62	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Australia	INFINITI QX80	Z62	2013.8-	Air bag	√	√	√	√		
Australia	INFINITI QX80	Z62	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Australia	INFINITI QX80	Z62	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Australia	INFINITI QX80	Z62	2013.8-	Motor control	√	√	√	√		
Australia	INFINITI QX80	Z62	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Australia	INFINITI QX80	Z62	2013.8-	Transmission	√	√	√	√	AC0439, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0246, SP0270, SP0274, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Australia	INFINITI QX80	Z62	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Australia	INFINITI QX80	Z62	2013.8-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Australia	INFINITI QX80	Z62	2013.8-	Multi AV	√	√	√	√		SP0503
Australia	INFINITI QX80	Z62	2013.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Australia	INFINITI QX80	Z62	2013.8-	HV battery	√	√	√	√	AC1121	
Australia	INFINITI QX80	Z62	2013.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587

Australia	INFINITI QX80	Z62	2013.8-	Difference lock	√	√	√	√		
Australia	INFINITI QX80	Z62	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Australia	INFINITI QX80	Z62	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Australia	INFINITI QX80	Z62	2013.8-	Auto back door	√	√	√	√		SP0611
Australia	INFINITI QX80	Z62	2013.8-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Australia	INFINITI QX80	Z62	2013.8-	Occupant detection			√	√		SP0584
Australia	INFINITI QX80	Z62	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Australia	INFINITI QX80	Z62	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Australia	INFINITI QX80	Z62	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Australia	INFINITI QX80	Z62	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Australia	INFINITI QX80	Z62	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Australia	INFINITI QX80	Z62	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Australia	INFINITI QX80	Z62	2013.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Australia	INFINITI QX80	Z62	2013.8-	CAN gateway	√	√	√			
Australia	INFINITI QX80	Z62	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Australia	INFINITI QX80	Z62	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Australia	INFINITI QX80	Z62	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Australia	INFINITI QX80	Z62	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Australia	INFINITI QX80	Z62	2013.8-	HIGH BEAM ASSIST	√	√	√	√		
Australia	INFINITI QX80	Z62	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Australia	INFINITI QX80	Z62	2013.8-	Vehicle data transmitter	√	√	√	√		
Australia	INFINITI QX80	Z62	2013.8-	6ch CAN GATEWAY	√	√	√	√		
Australia	INFINITI QX80	Z62	2013.8-	ICC/ADAS 2	√	√	√	√		
Australia	INFINITI QX80	Z62	2013.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Australia	INFINITI QX80	Z62	2013.8-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Austria	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Austria	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Austria	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Austria	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Austria	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Austria	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Austria	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Austria	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Austria	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Austria	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Austria	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Austria	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Austria	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Austria	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Austria	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Austria	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Austria	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Austria	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Austria	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Austria	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Austria	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Austria	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Austria	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Austria	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Austria	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Austria	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Austria	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Austria	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Austria	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Austria	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Austria	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Austria	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Austria	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Austria	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Austria	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Austria	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Austria	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Austria	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Austria	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Austria	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Austria	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Austria	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Austria	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Austria	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Austria	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Austria	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Austria	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Austria	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Austria	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Austria	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Austria	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Austria	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Austria	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Austria	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Austria	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Austria	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Austria	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Austria	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Austria	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Austria	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Austria	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Austria	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Austria	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Austria	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Austria	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Austria	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Austria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Austria	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Austria	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Austria	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Austria	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Austria	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Austria	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Austria	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Austria	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Austria	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Austria	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Austria	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Austria	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Austria	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Austria	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Austria	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Austria	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Austria	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Austria	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Austria	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Austria	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Austria	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Austria	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Austria	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Austria	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Austria	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Austria	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Austria	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Austria	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Austria	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Austria	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Austria	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Austria	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Austria	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Austria	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Austria	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Austria	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Austria	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Austria	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Austria	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Austria	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Austria	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Austria	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Austria	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Austria	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Austria	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Austria	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Austria	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Austria	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Austria	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Austria	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Austria	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Austria	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Austria	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Austria	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Austria	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Austria	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Austria	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Austria	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Austria	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Austria	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Austria	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Austria	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Austria	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Austria	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Austria	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Austria	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Austria	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Austria	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580

Austria	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Austria	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Austria	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Austria	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Austria	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Austria	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Austria	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Austria	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Austria	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Austria	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Austria	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Austria	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Austria	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Austria	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Austria	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Austria	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Austria	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Austria	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Austria	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Austria	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Austria	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Austria	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Austria	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Austria	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Austria	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Austria	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Austria	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Austria	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		

Austria	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Austria	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Austria	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Austria	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Austria	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Austria	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Austria	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Austria	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Austria	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Austria	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Austria	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Austria	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Austria	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Austria	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Austria	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Austria	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Austria	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Austria	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Austria	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Austria	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Austria	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Austria	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Austria	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Austria	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Austria	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Austria	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Austria	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Austria	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Austria	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Austria	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Austria	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Austria	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Austria	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Austria	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Austria	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Austria	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Austria	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Austria	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Austria	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Austria	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Austria	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Austria	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Austria	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Austria	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Austria	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Austria	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Austria	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Austria	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Austria	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Austria	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Austria	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Austria	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Austria	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Austria	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Austria	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Austria	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Austria	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Austria	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		

Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Austria	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Austria	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Austria	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Austria	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Austria	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Austria	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Austria	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Austria	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Austria	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Austria	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Austria	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Austria	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Austria	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Austria	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Austria	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584

Austria	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Austria	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Austria	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Austria	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Austria	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Austria	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Austria	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Austria	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Austria	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Austria	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Austria	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Austria	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Austria	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Austria	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Austria	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Austria	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Austria	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Austria	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Austria	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Austria	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Austria	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Austria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Austria	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Austria	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Austria	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Austria	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Austria	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Austria	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Austria	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Austria	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Austria	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Austria	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Austria	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Austria	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Austria	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Austria	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Austria	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Austria	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Austria	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Austria	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Austria	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Austria	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Austria	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Austria	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Austria	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Austria	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Austria	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0247,SP0265,SP0270,SP0274
Austria	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Austria	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Austria	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Austria	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Austria	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Austria	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Austria	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Austria	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584

Austria	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Austria	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Austria	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Austria	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Austria	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Austria	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Austria	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Austria	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Austria	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Austria	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Austria	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Austria	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Austria	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Austria	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Austria	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Austria	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Austria	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Austria	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√	√		
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Austria	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Austria	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Austria	INFINITI QX50	I50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Austria	INFINITI QX50	I50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Austria	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Austria	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Austria	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Austria	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Austria	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Austria	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Austria	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Austria	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Austria	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Austria	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Austria	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Austria	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Austria	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Austria	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Austria	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Austria	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Austria	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Austria	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Austria	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Austria	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Austria	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Austria	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Austria	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Austria	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Austria	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Austria	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Austria	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Austria	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Austria	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Austria	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Austria	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544

Austria	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Austria	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Austria	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Austria	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Austria	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Austria	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Austria	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Austria	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Austria	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Austria	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Austria	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Austria	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Austria	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Austria	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Austria	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Austria	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Austria	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Austria	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Austria	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Austria	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Austria	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Austria	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Austria	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Austria	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Austria	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Austria	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Austria	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Austria	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Austria	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Austria	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Austria	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Austria	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Austria	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Austria	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Austria	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Austria	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Azerbaija	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaija	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Azerbaija	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Azerbaija	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Azerbaijan	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Azerbaijan	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Azerbaija	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Azerbaijan	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Azerbaija	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Azerbaija	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Azerbaija	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Azerbaija	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaija	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Azerbaijan	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Azerbaijan	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaija	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaija	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Azerbaija	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Azerbaija	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Azerbaija	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Azerbaija	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Azerbaija	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Azerbaija	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471

Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Azerbaijan	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaijan	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Azerbaijan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471

Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Azerbaijan	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Azerbaijan	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Azerbaijan	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaijan	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Azerbaijan	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Azerbaijan	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Azerbaijan	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Azerbaijan	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Azerbaijan	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Azerbaijan	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Azerbaijan	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaijan	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Azerbaijan	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Azerbaijan	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503

Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Azerbaijan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Azerbaijan	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Azerbaijan	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Azerbaijan	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Azerbaija	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaija	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaija	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Azerbaija	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Azerbaijan	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Azerbaijan	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Azerbaija	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Azerbaijan	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Azerbaija	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Azerbaija	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Azerbaijan	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Azerbaija	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Azerbaija	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Azerbaija	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Azerbaija	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaija	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Azerbaija	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Azerbaija	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Azerbaija	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Azerbaija	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Azerbaijan	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaija	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Azerbaija	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Azerbaija	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Azerbaija	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Azerbaija	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Azerbaija	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Azerbaija	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Azerbaija	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Azerbaija	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Azerbaija	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaija	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Azerbaija	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Azerbaija	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaija	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaija	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Azerbaija	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Azerbaijan	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Azerbaija	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Azerbaija	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Azerbaijan	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Azerbaijan	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Azerbaija	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Azerbaijan	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Azerbaija	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Azerbaijan	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Azerbaija	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Azerbaija	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Azerbaija	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Azerbaijan	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Azerbaija	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaija	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Azerbaija	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Azerbaija	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Azerbaija	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaija	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Azerbaija	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Azerbaija	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Azerbaijan	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaijan	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaijan	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Azerbaijan	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Azerbaijan	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Azerbaijan	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Azerbaijan	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Azerbaijan	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Azerbaijan	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Azerbaijan	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Azerbaijan	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Azerbaijan	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Azerbaijan	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Azerbaijan	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Azerbaijan	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Azerbaijan	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Azerbaijan	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Azerbaijan	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		

Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Azerbaijan	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Azerbaija	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Azerbaija	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Azerbaija	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Azerbaija	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Azerbaijan	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Azerbaija	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Azerbaija	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Azerbaija	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Azerbaija	INFINITI Q45	F50	2001.8-	Motor control						
Azerbaijan	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Azerbaijan	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Azerbaijan	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Azerbaija	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Azerbaija	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Azerbaija	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Azerbaijan	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Azerbaija	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Azerbaija	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Azerbaija	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaija	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Azerbaija	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaijan	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Azerbaija	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Azerbaija	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaija	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Azerbaija	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Azerbaija	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Azerbaija	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Azerbaija	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Azerbaija	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Azerbaija	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Azerbaija	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Azerbaija	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Azerbaija	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Azerbaija	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Azerbaija	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Azerbaija	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Azerbaija	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Azerbaija	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Azerbaija	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Azerbaija	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Azerbaija	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Azerbaijan	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaija	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Azerbaija	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Azerbaijan	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Azerbaija	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Azerbaija	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Azerbaija	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Azerbaija	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Azerbaijan	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Azerbaija	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Azerbaija	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaija	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Azerbaija	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Azerbaija	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaija	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaija	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Azerbaija	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Azerbaija	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Azerbaija	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaija	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Azerbaija	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606

Azerbaijan	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Azerbaija	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Azerbaija	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Azerbaija	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaija	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Azerbaija	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Azerbaija	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Azerbaija	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaija	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Azerbaija	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Azerbaija	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Azerbaija	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Azerbaija	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Azerbaija	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Azerbaija	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Azerbaija	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Azerbaijan	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Azerbaijan	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Azerbaijan	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Azerbaijan	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Azerbaija	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Azerbaijan	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Azerbaijan	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Azerbaijan	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Azerbaijan	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Azerbaija	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Azerbaija	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Azerbaija	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Azerbaija	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Azerbaija	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

Azerbaijan	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Azerbaijan	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Azerbaijan	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Azerbaijan	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Azerbaijan	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372,SP0429
Azerbaijan	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300,SP0313,SP0315
Azerbaijan	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Azerbaijan	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Azerbaijan	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Azerbaijan	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaijan	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Azerbaijan	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Azerbaijan	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaijan	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaijan	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Azerbaijan	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Azerbaijan	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaijan	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaijan	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Azerbaijan	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Azerbaijan	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Azerbaijan	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaijan	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Azerbaijan	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Azerbaijan	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Azerbaijan	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaijan	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Azerbaijan	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Azerbaijan	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Azerbaijan	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaijan	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Azerbaijan	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Azerbaijan	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Azerbaijan	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaijan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaijan	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaijan	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510

Azerbaija	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Azerbaija	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Azerbaija	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Azerbaija	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Azerbaija	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Azerbaija	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Azerbaijan	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Azerbaijan	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Azerbaija	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Azerbaijan	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Azerbaija	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Azerbaija	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Azerbaija	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Azerbaija	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Azerbaija	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Azerbaijan	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Azerbaija	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Azerbaija	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Azerbaija	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaija	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Azerbaija	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaija	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaija	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Azerbaija	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Azerbaija	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaija	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Azerbaija	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Azerbaija	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaija	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Azerbaija	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Azerbaija	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaija	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Azerbaija	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Azerbaija	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Azerbaija	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Azerbaija	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Azerbaija	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Azerbaija	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Azerbaija	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Azerbaija	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Azerbaija	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Azerbaija	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Azerbaijan	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Azerbaija	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Azerbaija	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Azerbaijan	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Azerbaija	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Azerbaija	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Azerbaija	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaija	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Azerbaija	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaija	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaija	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Azerbaija	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Azerbaija	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Azerbaija	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaija	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Azerbaija	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaija	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Azerbaija	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Azerbaijan	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Azerbaijan	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Azerbaija	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Azerbaija	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Azerbaija	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Azerbaijan	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaija	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Azerbaijan	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Azerbaija	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Azerbaija	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Azerbaija	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Azerbaija	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Azerbaija	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Azerbaija	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Azerbaija	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Azerbaija	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Azerbaija	INFINITI QX50	J55	2018.5-	Shift						
Azerbaija	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Azerbaija	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaija	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Azerbaija	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Azerbaija	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Azerbaija	INFINITI QX50	I55	2018.5-	CAN gateway	√	√	√	√		
Azerbaija	INFINITI QX50	I55	2018.5-	Lane camera	√	√	√	√		
Azerbaija	INFINITI QX50	I55	2018.5-	DAST 1	√	√	√	√		
Azerbaija	INFINITI QX50	I55	2018.5-	Chassis control	√	√	√	√		
Azerbaija	INFINITI QX50	J55	2018.5-	ANC						
Azerbaija	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Azerbaija	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaija	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Azerbaija	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaija	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Azerbaija	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Azerbaija	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Azerbaija	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Azerbaija	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Azerbaija	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Azerbaijan	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Azerbaija	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Azerbaija	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Azerbaija	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Azerbaija	INFINITI QX56	JA60	2004.10-	Motor control						
Azerbaijan	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Azerbaijan	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Azerbaijan	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Azerbaija	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Azerbaija	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Azerbaija	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Azerbaijan	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Azerbaija	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Azerbaija	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Azerbaija	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaija	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Azerbaija	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaijan	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Azerbaija	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Azerbaija	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaija	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Azerbaija	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Azerbaija	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Azerbaija	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Azerbaija	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Azerbaija	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Azerbaija	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Azerbaija	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Azerbaija	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Azerbaija	INFINITI QX56	IA60	2004.10-	Nats immu	√	√	√			
Azerbaija	INFINITI QX56	IA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Azerbaija	INFINITI QX56	IA60	2004.10-	Smart entrance						SP0568
Azerbaija	INFINITI QX56	Z62	2010.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Azerbaija	INFINITI QX56	Z62	2010.3-	Laser/radar	√	√	√	√		
Azerbaija	INFINITI QX56	Z62	2010.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI QX56	Z62	2010.3-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Azerbaija	INFINITI QX56	Z62	2010.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI QX56	Z62	2010.3-	Air bag	√	√	√	√		
Azerbaija	INFINITI QX56	Z62	2010.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Azerbaijan	INFINITI QX56	Z62	2010.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI QX56	Z62	2010.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Azerbaija	INFINITI QX56	Z62	2010.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Azerbaija	INFINITI QX56	Z62	2010.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Azerbaija	INFINITI QX56	Z62	2010.3-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI QX56	Z62	2010.3-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Azerbaija	INFINITI QX56	Z62	2010.3-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Azerbaija	INFINITI QX56	Z62	2010.3-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI QX56	Z62	2010.3-	Auto back door	√	√	√	√		
Azerbaija	INFINITI QX56	Z62	2010.3-	Occupant detection			√	√		SP0584
Azerbaija	INFINITI QX56	Z62	2010.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Azerbaija	INFINITI QX56	Z62	2010.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI QX56	Z62	2010.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaija	INFINITI QX56	Z62	2010.3-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Azerbaija	INFINITI QX56	Z62	2010.3-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaija	INFINITI QX56	Z62	2010.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaija	INFINITI QX56	Z62	2010.3-	CAN gateway	√	√	√			
Azerbaija	INFINITI QX56	Z62	2010.3-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Azerbaija	INFINITI QX56	Z62	2010.3-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaija	INFINITI QX56	Z62	2010.3-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Azerbaija	INFINITI QX56	Z62	2010.3-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaija	INFINITI QX56	Z62	2010.3-	Rearview camera	√			√		SP0570, SP0571
Azerbaija	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Azerbaija	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Azerbaija	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Azerbaija	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Azerbaija	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Azerbaija	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Azerbaija	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Azerbaijan	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Azerbaija	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Azerbaijan	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Azerbaija	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Azerbaija	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487

Azerbaija	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Azerbaija	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Azerbaija	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Azerbaija	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Azerbaija	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaija	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Azerbaija	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaija	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaija	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Azerbaija	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Azerbaija	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Azerbaija	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Azerbaija	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Azerbaija	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaija	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Azerbaija	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Azerbaija	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaija	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Azerbaija	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Azerbaija	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Azerbaija	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Azerbaijan	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Azerbaijan	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Azerbaijan	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Azerbaija	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Azerbaija	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Azerbaija	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Azerbaija	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Azerbaija	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Azerbaija	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Azerbaija	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Azerbaijan	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Azerbaijan	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Azerbaija	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Azerbaija	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Azerbaija	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Azerbaija	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Azerbaija	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Azerbaija	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Azerbaijan	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Azerbaija	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Azerbaija	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Azerbaija	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaija	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Azerbaija	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaija	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaija	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Azerbaija	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Azerbaija	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Azerbaija	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Azerbaija	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Azerbaija	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaija	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Azerbaija	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaija	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Azerbaija	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Azerbaija	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Azerbaija	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Azerbaijan	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Azerbaija	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Azerbaija	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Azerbaija	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Azerbaija	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Azerbaijan	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Azerbaijan	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Azerbaija	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Azerbaija	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Azerbaija	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Azerbaijan	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Azerbaija	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Azerbaija	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Azerbaija	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Azerbaijan	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Azerbaija	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Azerbaija	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Azerbaija	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Azerbaija	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Azerbaija	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Azerbaija	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Azerbaija	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Azerbaija	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Azerbaijan	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Azerbaija	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Azerbaija	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Azerbaija	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Azerbaija	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Azerbaija	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Azerbaija	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Azerbaija	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Azerbaija	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Azerbaija	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Azerbaija	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Azerbaija	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Bahamas	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahamas	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Bahamas	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahamas	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Bahamas	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bahamas	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Bahamas	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahamas	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bahamas	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Bahamas	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahamas	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahamas	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahamas	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahamas	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahamas	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Bahamas	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Bahamas	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahamas	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Bahamas	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Bahamas	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahamas	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Bahamas	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Bahamas	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Bahamas	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bahamas	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Bahamas	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahamas	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		

Bahamas	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Bahamas	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Bahamas	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahamas	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Bahamas	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bahamas	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahamas	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Bahamas	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bahamas	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bahamas	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Bahamas	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bahamas	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bahamas	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Bahamas	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Bahamas	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahamas	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Bahamas	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahamas	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Bahamas	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahamas	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bahamas	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Bahamas	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bahamas	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bahamas	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bahamas	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bahamas	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Bahamas	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahamas	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bahamas	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bahamas	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahamas	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Bahamas	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bahamas	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bahamas	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bahamas	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bahamas	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Bahamas	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Bahamas	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Bahamas	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bahamas	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bahamas	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Bahamas	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahamas	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahamas	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahamas	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahamas	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahamas	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Bahamas	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Bahamas	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bahamas	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahamas	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Bahamas	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Bahamas	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bahamas	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Bahamas	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bahamas	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bahamas	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Bahamas	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Bahamas	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Bahamas	INFINITI Q45	F50	2001.8-	Motor control						
Bahamas	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahamas	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Bahamas	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Bahamas	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bahamas	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Bahamas	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Bahamas	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Bahamas	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahamas	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Bahamas	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Bahamas	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Bahamas	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahamas	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Bahamas	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahamas	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Bahamas	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Bahamas	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahamas	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Bahamas	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Bahamas	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Bahamas	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Bahamas	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Bahamas	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Bahamas	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Bahamas	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Bahamas	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Bahamas	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Bahamas	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Bahamas	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Bahamas	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bahamas	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Bahamas	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bahamas	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bahamas	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Bahamas	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Bahamas	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahamas	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Bahamas	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bahamas	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Bahamas	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Bahamas	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Bahamas	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Bahamas	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahamas	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Bahamas	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Bahamas	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahamas	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahamas	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Bahamas	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Bahamas	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bahamas	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Bahamas	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bahamas	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Bahamas	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bahamas	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bahrain	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Bahrain	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bahrain	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bahrain	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bahrain	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahrain	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahrain	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahrain	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahrain	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Bahrain	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bahrain	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Bahrain	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Bahrain	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bahrain	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Bahrain	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahrain	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahrain	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahrain	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahrain	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Bahrain	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Bahrain	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bahrain	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Bahrain	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Bahrain	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Bahrain	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Bahrain	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Bahrain	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Bahrain	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Bahrain	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Bahrain	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Bahrain	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Bahrain	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bahrain	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Bahrain	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahrain	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Bahrain	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Bahrain	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Bahrain	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Bahrain	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		

Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Bahrain	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Bahrain	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Bahrain	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bahrain	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bahrain	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Bahrain	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahrain	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Bahrain	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Bahrain	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Bahrain	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahrain	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Bahrain	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Bahrain	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Bahrain	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bahrain	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Bahrain	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Bahrain	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Bahrain	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Bahrain	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bahrain	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bahrain	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Bahrain	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Bahrain	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Bahrain	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Bahrain	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahrain	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Bahrain	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bahrain	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bahrain	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Bahrain	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Bahrain	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Bahrain	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Bahrain	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bahrain	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bahrain	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Bahrain	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Bahrain	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Bahrain	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Bahrain	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Bahrain	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Bahrain	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Bahrain	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Bahrain	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bahrain	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Bahrain	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bahrain	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bahrain	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Bahrain	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bahrain	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bahrain	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bahrain	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Bahrain	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bahrain	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bahrain	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bahrain	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahrain	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahrain	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahrain	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Bahrain	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bahrain	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Bahrain	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Bahrain	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Bahrain	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Bahrain	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Bahrain	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Bahrain	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Bahrain	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Bahrain	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Bahrain	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Bahrain	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Bahrain	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Bahrain	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Bahrain	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Bahrain	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					

Bahrain	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Bahrain	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Bahrain	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Bahrain	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Bahrain	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Bahrain	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Bahrain	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Bahrain	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Bahrain	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Bahrain	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Bahrain	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Bahrain	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Bahrain	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Bahrain	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Bahrain	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bahrain	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Bahrain	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bahrain	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bahrain	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Bahrain	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Bahrain	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Bahrain	INFINITI Q45	F50	2001.8-	Motor control						
Bahrain	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Bahrain	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Bahrain	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Bahrain	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Bahrain	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Bahrain	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Bahrain	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Bahrain	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Bahrain	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537

Bahrain	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Bahrain	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Bahrain	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Bahrain	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Bahrain	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Bahrain	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Bahrain	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Bahrain	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Bahrain	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Bahrain	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Bahrain	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Bahrain	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Bahrain	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Bahrain	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bahrain	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Bahrain	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bahrain	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Bahrain	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Bahrain	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bahrain	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Bahrain	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bahrain	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bahrain	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Bahrain	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bahrain	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bahrain	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bahrain	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Bahrain	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bahrain	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Bahrain	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Bahrain	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Bahrain	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Bahrain	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bahrain	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Bahrain	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Bahrain	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Bahrain	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Bahrain	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Bahrain	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Bahrain	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bahrain	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Bahrain	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Bahrain	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Bahrain	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Bahrain	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Bahrain	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Bahrain	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Bahrain	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Bahrain	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	

Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Bahrain	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Bahrain	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Bahrain	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bahrain	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Bahrain	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bahrain	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Bahrain	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Bahrain	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bahrain	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Bahrain	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bahrain	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bahrain	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Bahrain	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bahrain	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bahrain	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Bahrain	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bahrain	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahrain	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Bahrain	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Bahrain	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Bahrain	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bahrain	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Bahrain	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Bahrain	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Bahrain	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Bahrain	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bahrain	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Bahrain	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Bahrain	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Bahrain	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Bahrain	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bahrain	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Bahrain	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bahrain	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Bahrain	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Bahrain	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bahrain	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Bahrain	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bahrain	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Bahrain	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bahrain	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Bahrain	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bahrain	INFINITI Q70	Y51	2013.9-	HV batterv	√	√	√	√	AC1121	
Bahrain	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bahrain	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bahrain	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bahrain	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Bahrain	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bahrain	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Bahrain	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Bahrain	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bahrain	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Bahrain	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bahrain	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Bahrain	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bahrain	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Bahrain	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Bahrain	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Bahrain	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Bahrain	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Bahrain	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bahrain	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Bahrain	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bahrain	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		

Bahrain	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Bahrain	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bahrain	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bahrain	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Bahrain	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahrain	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Bahrain	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahrain	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahrain	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Bahrain	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bahrain	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Bahrain	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bahrain	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Bahrain	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bahrain	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Bahrain	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Bahrain	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Bahrain	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Bahrain	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Bahrain	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Bahrain	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Bahrain	INFINITI QX50	J55	2018.5-	Shift						
Bahrain	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Bahrain	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	ANC						
Bahrain	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bahrain	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Bahrain	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Bahrain	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bahrain	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Bahrain	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bahrain	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bahrain	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Bahrain	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Bahrain	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Bahrain	INFINITI QX56	JA60	2004.10-	Motor control						
Bahrain	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Bahrain	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Bahrain	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bahrain	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Bahrain	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Bahrain	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Bahrain	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Bahrain	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Bahrain	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Bahrain	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Bahrain	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Bahrain	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Bahrain	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Bahrain	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Bahrain	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Bahrain	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Bahrain	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Bahrain	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Bahrain	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Bahrain	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Bahrain	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			

Bahrain	INFINITI QX56	IA60	2004.10-	Rearview camera	√			√		SP0570,SP0571
Bahrain	INFINITI QX56	IA60	2004.10-	Smart entrance						SP0568
Bahrain	INFINITI QX56	Z62	2010.3-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Bahrain	INFINITI QX56	Z62	2010.3-	Laser/radar	√	√	√	√		
Bahrain	INFINITI QX56	Z62	2010.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI QX56	Z62	2010.3-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bahrain	INFINITI QX56	Z62	2010.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI QX56	Z62	2010.3-	Air bag	√	√	√	√		
Bahrain	INFINITI QX56	Z62	2010.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Bahrain	INFINITI QX56	Z62	2010.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI QX56	Z62	2010.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bahrain	INFINITI QX56	Z62	2010.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bahrain	INFINITI QX56	Z62	2010.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bahrain	INFINITI QX56	Z62	2010.3-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI QX56	Z62	2010.3-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Bahrain	INFINITI QX56	Z62	2010.3-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Bahrain	INFINITI QX56	Z62	2010.3-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI QX56	Z62	2010.3-	Auto back door	√	√	√	√		
Bahrain	INFINITI QX56	Z62	2010.3-	Occupant detection			√	√		SP0584
Bahrain	INFINITI QX56	Z62	2010.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahrain	INFINITI QX56	Z62	2010.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI QX56	Z62	2010.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI QX56	Z62	2010.3-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Bahrain	INFINITI QX56	Z62	2010.3-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI QX56	Z62	2010.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI QX56	Z62	2010.3-	CAN gateway	√	√	√			
Bahrain	INFINITI QX56	Z62	2010.3-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bahrain	INFINITI QX56	Z62	2010.3-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI QX56	Z62	2010.3-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bahrain	INFINITI QX56	Z62	2010.3-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI QX56	Z62	2010.3-	Rearview camera	√			√		SP0570, SP0571
Bahrain	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bahrain	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Bahrain	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bahrain	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Bahrain	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Bahrain	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bahrain	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Bahrain	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Bahrain	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bahrain	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bahrain	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Bahrain	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Bahrain	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Bahrain	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Bahrain	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Bahrain	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahrain	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Bahrain	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Bahrain	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bahrain	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bahrain	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Bahrain	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bahrain	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Bahrain	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Bahrain	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Bahrain	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Bahrain	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583

Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Bahrain	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Bahrain	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bahrain	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Bahrain	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bahrain	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Bahrain	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Bahrain	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bahrain	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bahrain	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Bahrain	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bahrain	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bahrain	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Bahrain	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bahrain	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bahrain	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Bahrain	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Bahrain	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bahrain	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Bahrain	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Bahrain	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bahrain	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bahrain	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bahrain	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Bahrain	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bahrain	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Bahrain	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bahrain	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Bahrain	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bahrain	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bahrain	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bahrain	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Bahrain	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Bahrain	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Bahrain	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bahrain	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bahrain	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bahrain	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bahrain	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Bahrain	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Bahrain	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Bahrain	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Bahrain	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bahrain	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bahrain	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Bahrain	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Bahrain	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bahrain	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bahrain	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bahrain	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Bahrain	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Bahrain	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bahrain	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Bahrain	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Bahrain	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bahrain	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bahrain	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Bahrain	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bahrain	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Bahrain	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Bahrain	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Bahrain	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Bahrain	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Bahrain	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bangladesh	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bangladesh	INFINITI Q45	F50	ALL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bangladesh	INFINITI Q45	F50	ALL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Bangladesh	INFINITI Q45	F50	ALL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bangladesh	INFINITI Q45	F50	ALL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bangladesh	INFINITI Q45	F50	ALL	Air bag	√	√	√	√		
Bangladesh	INFINITI Q45	F50	ALL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Bangladesh	INFINITI Q45	F50	ALL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Bangladesh	INFINITI Q45	F50	ALL	Motor control						
Bangladesh	INFINITI Q45	F50	ALL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bangladesh	INFINITI Q45	F50	ALL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Bangladesh	INFINITI Q45	F50	ALL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Bangladesh	INFINITI Q45	F50	ALL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bangladesh	INFINITI Q45	F50	ALL	Multi AV	√	√	√	√		SP0503
Bangladesh	INFINITI Q45	F50	ALL	HVAC	√	√	√	√		
Bangladesh	INFINITI Q45	F50	ALL	Difference lock	√	√	√	√		
Bangladesh	INFINITI Q45	F50	ALL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bangladesh	INFINITI Q45	F50	ALL	Auto slide door	√	√	√	√	AC0941	
Bangladesh	INFINITI Q45	F50	ALL	DIU		√	√	√		
Bangladesh	INFINITI Q45	F50	ALL	Adaptive light	√	√	√	√		
Bangladesh	INFINITI Q45	F50	ALL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bangladesh	INFINITI Q45	F50	ALL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Bangladesh	INFINITI Q45	F50	ALL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bangladesh	INFINITI Q45	F50	ALL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Bangladesh	INFINITI Q45	F50	ALL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Bangladesh	INFINITI Q45	F50	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bangladesh	INFINITI Q45	F50	ALL	IVMS	√	√		√		
Bangladesh	INFINITI Q45	F50	ALL	Distance control	√	√		√		
Bangladesh	INFINITI Q45	F50	ALL	Active suspense system	√	√	√	√		
Bangladesh	INFINITI Q45	F50	ALL	Motor assist		√	√	√		SP0574
Bangladesh	INFINITI Q45	F50	ALL	ASCD	√	√	√	√		
Bangladesh	INFINITI Q45	F50	ALL	Active engine mount	√	√	√	√		
Bangladesh	INFINITI Q45	F50	ALL	TCS	√	√	√	√		
Bangladesh	INFINITI Q45	F50	ALL	S/blind camera	√			√		SP0572, SP0573
Bangladesh	INFINITI Q45	F50	ALL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Bangladesh	INFINITI Q45	F50	ALL	Nats immu	√	√	√			
Bangladesh	INFINITI Q45	F50	ALL	Rearview camera	√			√		SP0570, SP0571
Bangladesh	INFINITI Q45	F50	ALL	Smart entrance						SP0568
Barbados	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Barbados	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Barbados	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Barbados	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Barbados	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Barbados	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Barbados	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Barbados	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Barbados	INFINITI EX35/EX37	I50	2011.1-	Multi AV	√	√	√	√		SP0503
Barbados	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Barbados	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Barbados	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Barbados	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Barbados	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Barbados	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Barbados	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Barbados	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Barbados	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Barbados	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Barbados	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Barbados	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Barbados	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Barbados	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Barbados	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Barbados	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Barbados	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Barbados	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Barbados	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Barbados	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Barbados	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Barbados	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Barbados	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Barbados	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Barbados	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Barbados	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Barbados	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Barbados	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Barbados	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Barbados	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Barbados	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Barbados	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Barbados	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Barbados	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Barbados	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Barbados	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Barbados	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Barbados	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Barbados	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Barbados	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Barbados	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Barbados	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Barbados	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Barbados	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Barbados	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Barbados	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Barbados	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Barbados	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Barbados	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Barbados	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Barbados	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Barbados	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Barbados	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Barbados	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Barbados	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Barbados	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Barbados	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Barbados	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Barbados	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Barbados	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0202, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Barbados	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Barbados	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Barbados	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Barbados	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Barbados	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Barbados	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Barbados	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Barbados	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Barbados	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Barbados	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Barbados	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Barbados	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Barbados	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Barbados	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582

Barbados	INFINITI FX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Barbados	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Barbados	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Barbados	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Barbados	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Barbados	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Barbados	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Barbados	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Barbados	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Barbados	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Barbados	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Barbados	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Barbados	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Barbados	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Barbados	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Barbados	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Barbados	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Barbados	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Barbados	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Barbados	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Barbados	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Barbados	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Barbados	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Barbados	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Barbados	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Barbados	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Barbados	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Barbados	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Barbados	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Barbados	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Barbados	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Barbados	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Barbados	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Barbados	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Barbados	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Barbados	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Barbados	INFINITI Q45	F50	2001.8-	Motor control						
Barbados	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Barbados	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Barbados	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Barbados	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Barbados	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Barbados	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Barbados	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Barbados	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Barbados	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Barbados	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Barbados	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Barbados	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Barbados	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Barbados	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Barbados	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Barbados	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Barbados	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Barbados	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Barbados	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Barbados	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Barbados	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Barbados	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Barbados	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Barbados	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Barbados	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Barbados	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Barbados	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Barbados	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Barbados	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Barbados	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Barbados	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Barbados	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Barbados	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Barbados	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Barbados	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Barbados	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Barbados	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Barbados	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Barbados	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Barbados	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Barbados	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Barbados	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Barbados	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Barbados	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Barbados	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Barbados	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Barbados	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Barbados	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Barbados	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Barbados	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Barbados	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Barbados	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Barbados	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582

Barbados	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590、SP0591、SP0592
Barbados	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Belgium	INFINITI EX35/EX30D	I50	2009.7-	Air pressure monitor	√	√	√	√	AC0894、AC0895、AC0896	SP0510
Belgium	INFINITI EX35/EX30D	I50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0876、AC0877、AC0884	SP0494
Belgium	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Belgium	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Belgium	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350
Belgium	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0282、AC0283、AC0307、AC0333、AC0334、AC0335、AC0336、AC0337、AC0338、AC0339、AC0351、AC0352、AC0365、AC0366、AC0367、AC0369、AC0371、AC0372、AC0373、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0016、SP0017、SP0018、SP0032、SP0033、SP0043、SP0045、SP0051、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0083、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0196、SP0197、SP0198、SP0199、SP0200、SP0202、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0225、SP0236、SP0237、SP0238、SP0239
Belgium	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460、AC0461、AC0462、AC0463、AC0464、AC0465、AC0466、AC0467、AC0468、AC0469、AC0470、AC0471、AC0472、AC0473、AC0474	SP0270、SP0274
Belgium	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613、AC0618、AC0663、AC0692、AC0702、AC0719	SP0372、SP0429
Belgium	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498、AC0507、AC0508、AC0509、AC0510、AC0511、AC0512、AC0513、AC0514、AC0515、AC0516、AC0517、AC0527、AC0528、AC0529、AC0530、AC0531、AC0532、AC0533、AC0534、AC0535	SP0301、SP0313、SP0315、SP0316、SP0317、SP0319
Belgium	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Belgium	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980	SP0561、SP0562
Belgium	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Belgium	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962、AC0963、AC0964	SP0553、SP0554、SP0555、SP0556
Belgium	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Belgium	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Belgium	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973、AC0974、AC0975、AC0976	SP0560
Belgium	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022、AC1023	
Belgium	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Belgium	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Belgium	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894、AC0895、AC0896	SP0510
Belgium	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0876、AC0877、AC0884	SP0494
Belgium	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Belgium	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Belgium	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350
Belgium	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004、AC0035、AC0036、AC0037、AC0051、AC0052、AC0053、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0147、AC0148、AC0149、AC0150、AC0154、AC0155、AC0156、AC0157、AC0160、AC0162、AC0164、AC0166、AC0168、AC0171、AC0172、AC0173、AC0174、AC0178、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0282、AC0283、AC0307、AC0351、AC0352、AC0365、AC0366、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0016、SP0032、SP0033、SP0053、SP0063、SP0064、SP0074、SP0079、SP0085、SP0086、SP0087、SP0104、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0152、SP0153、SP0160、SP0172、SP0173、SP0191、SP0192、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0239
Belgium	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460、AC0461、AC0462、AC0463、AC0464、AC0465、AC0466、AC0467、AC0468、AC0469、AC0470、AC0471、AC0472、AC0473、AC0474	SP0270、SP0274
Belgium	INFINITI EX37	J50	2008.6-	BCM				√	AC0613、AC0618、AC0663、AC0692、AC0702、AC0719	SP0372、SP0429
Belgium	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533	SP0301、SP0313、SP0315
Belgium	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Belgium	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Belgium	INFINITI EX37	I50	2008.6-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980	SP0561、SP0562
Belgium	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962、AC0963、AC0964	SP0553、SP0554、SP0555、SP0556
Belgium	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Belgium	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812、AC0814、AC0815、AC0816、AC0817、AC0818、AC0820、AC0821、AC0822、AC0823、AC0825、AC0831	
Belgium	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Belgium	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347、SP0348、SP0349
Belgium	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004、AC0035、AC0036、AC0037、AC0051、AC0052、AC0053、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0147、AC0148、AC0149、AC0150、AC0154、AC0155、AC0156、AC0157、AC0160、AC0162、AC0164、AC0166、AC0168、AC0171、AC0172、AC0173、AC0174、AC0178、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0282、AC0283、AC0307、AC0351、AC0352、AC0365、AC0366、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0016、SP0032、SP0033、SP0053、SP0063、SP0064、SP0074、SP0079、SP0085、SP0086、SP0087、SP0104、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0152、SP0153、SP0160、SP0172、SP0173、SP0191、SP0192、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0239
Belgium	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460、AC0461、AC0462、AC0463、AC0464、AC0465、AC0466、AC0467、AC0468、AC0469、AC0470、AC0471、AC0472、AC0473、AC0474	SP0270
Belgium	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653、AC0695	SP0372、SP0429
Belgium	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498、AC0507、AC0508、AC0509、AC0510、AC0511、AC0512、AC0513、AC0514、AC0515、AC0516、AC0517、AC0527、AC0528、AC0529、AC0530、AC0531、AC0532、AC0533、AC0534、AC0535	SP0315、SP0316、SP0317、SP0319
Belgium	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Belgium	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962、AC0963、AC0964	SP0553、SP0554、SP0556
Belgium	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Belgium	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903、AC0904、AC0905、AC0906、AC0907、AC0908、AC0909、AC0910、AC0911、AC0912、AC0913、AC0914、AC0915、AC0916、AC0917、AC0918、AC0919、AC0920、AC0921、AC0922、AC0923、AC0924、AC0925、AC0926、AC0927、AC0928、AC0929、AC0930、AC0931、AC0932	SP0511、SP0512、SP0517、SP0518、SP0519、SP0520、SP0522、SP0523、SP0524、SP0525、SP0526、SP0527、SP0528、SP0529、SP0530、SP0531、SP0532、SP0533、SP0534、SP0535、SP0536、SP0537
Belgium	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570、SP0571
Belgium	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894、AC0895、AC0896	SP0510
Belgium	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0876、AC0877	SP0494
Belgium	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Belgium	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Belgium	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350
Belgium	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004、AC0035、AC0036、AC0037、AC0052、AC0053、AC0062、AC0066、AC0067、AC0068、AC0148、AC0149、AC0150、AC0156、AC0164、AC0166、AC0168、AC0173、AC0174、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0200、AC0282、AC0283、AC0307、AC0351、AC0352、AC0365、AC0366、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0016、SP0032、SP0033、SP0053、SP0063、SP0064、SP0074、SP0079、SP0085、SP0086、SP0087、SP0104、SP0109、SP0110、SP0111、SP0113、SP0114、SP0115、SP0116、SP0152、SP0153、SP0160、SP0172、SP0173、SP0191、SP0192、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0239
Belgium	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460、AC0461、AC0462、AC0463、AC0464、AC0465、AC0466、AC0467、AC0468、AC0469、AC0470、AC0471、AC0472、AC0473、AC0474	SP0274
Belgium	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613、AC0618、AC0663、AC0692、AC0702、AC0719	SP0372、SP0429
Belgium	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533	SP0301、SP0313、SP0315
Belgium	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133、AC1134、AC1135、AC1136、AC1137、AC1138、AC1139、AC1140、AC1141、AC1142	SP0614、SP0615、SP0616、SP0617、SP0618、SP0619、SP0620、SP0621
Belgium	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Belgium	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034、AC1035、AC1036、AC1037、AC1038、AC1039	
Belgium	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Belgium	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980	SP0561、SP0562
Belgium	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962、AC0963、AC0964	SP0553、SP0554、SP0555、SP0556
Belgium	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Belgium	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Belgium	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894、AC0895、AC0896	SP0510
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0876、AC0877、AC0884	SP0494
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0282、AC0283、AC0307、AC0333、AC0334、AC0335、AC0336、AC0337、AC0338、AC0339、AC0351、AC0352、AC0365、AC0366、AC0367、AC0369、AC0371、AC0372、AC0373、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0016、SP0017、SP0018、SP0032、SP0033、SP0043、SP0045、SP0051、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0083、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0196、SP0197、SP0198、SP0199、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0225、SP0237、SP0238、SP0239
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460、AC0461、AC0462、AC0463、AC0464、AC0465、AC0466、AC0467、AC0468、AC0469、AC0470、AC0471、AC0472、AC0473、AC0474	SP0274
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613、AC0618、AC0663、AC0692、AC0702、AC0719	SP0372、SP0429
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533	SP0301、SP0313、SP0315
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133、AC1134、AC1135、AC1136、AC1137、AC1138、AC1139、AC1140、AC1141、AC1142	SP0614、SP0615、SP0616、SP0617、SP0618、SP0619、SP0620、SP0621

Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Belgium	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belgium	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Belgium	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Belgium	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Belgium	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Belgium	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Belgium	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Belgium	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Belgium	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Belgium	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Belgium	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Belgium	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Belgium	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Belgium	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Belgium	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Belgium	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Belgium	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Belgium	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Belgium	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Belgium	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Belgium	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Belgium	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belgium	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belgium	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Belgium	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Belgium	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Belgium	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Belgium	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belgium	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Belgium	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Belgium	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Belgium	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Belgium	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Belgium	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Belgium	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Belgium	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Belgium	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belgium	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belgium	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Belgium	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Belgium	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Belgium	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Belgium	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Belgium	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Belgium	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Belgium	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Belgium	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Belgium	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Belgium	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Belgium	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Belgium	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Belgium	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Belgium	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Belgium	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Belgium	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Belgium	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Belgium	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Belgium	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Belgium	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belgium	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Belgium	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Belgium	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Belgium	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Belgium	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Belgium	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Belgium	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Belgium	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Belgium	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Belgium	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Belgium	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Belgium	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Belgium	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Belgium	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belgium	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belgium	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belgium	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Belgium	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Belgium	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Belgium	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Belgium	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Belgium	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Belgium	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503

Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Belgium	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Belgium	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Belgium	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Belgium	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Belgium	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Belgium	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Belgium	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Belgium	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Belgium	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Belgium	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Belgium	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Belgium	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Belgium	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Belgium	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Belgium	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Belgium	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Belgium	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Belgium	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Belgium	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Belgium	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Belgium	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Belgium	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Belgium	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Belgium	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Belgium	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Belgium	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Belgium	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Belgium	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Belgium	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Belgium	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Belgium	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Belgium	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Belgium	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Belgium	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Belgium	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Belgium	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		

Belgium	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Belgium	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Belgium	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Belgium	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509
Belgium	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Belgium	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0869、AC0870、AC0871、AC0872、AC0873、AC0874、AC0875、AC0876、AC0877、AC0878、AC0879、AC0880、AC0881、AC0882、AC0883、AC0884、AC0885	SP0494、SP0495、SP0496、SP0497
Belgium	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Belgium	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Belgium	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Belgium	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348、SP0349、SP0350、SP0351
Belgium	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Belgium	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0225、AC0226、AC0229、AC0256、AC0266、AC0270、AC0272、AC0277、AC0282、AC0283、AC0284、AC0307、AC0308、AC0309、AC0311、AC0312、AC0313、AC0314、AC0315、AC0316、AC0317、AC0318、AC0319、AC0320、AC0321、AC0322、AC0323、AC0324、AC0325、AC0326、AC0327、AC0330、AC0331、AC0332、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0009、SP0016、SP0017、SP0018、SP0032、SP0033、SP0034、SP0038、SP0039、SP0043、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0082、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0128、SP0140、SP0143、SP0150、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0193、SP0194、SP0195、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Belgium	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247、SP0265、SP0274、SP0276
Belgium	INFINITI Q50	V37	2013.6-	BCM				√	AC0613、AC0618、AC0663、AC0690、AC0692、AC0702	SP0372、SP0429
Belgium	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498、AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533、AC0536	SP0300、SP0313、SP0315
Belgium	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Belgium	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472、SP0473、SP0474、SP0475、SP0477、SP0479、SP0480、SP0481、SP0482、SP0486、SP0487
Belgium	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Belgium	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034、AC1035、AC1036、AC1037、AC1038、AC1039	
Belgium	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027、AC1028	
Belgium	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Belgium	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084、AC1085、AC1086、AC1087、AC1088、AC1089、AC1106	
Belgium	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Belgium	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980、AC0981、AC0982	SP0561、SP0562
Belgium	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Belgium	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962、AC0963、AC0964、AC0966、AC0967、AC0968、AC0969、AC0970	SP0553、SP0554、SP0555、SP0556、SP0557、SP0558、SP0559
Belgium	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956、AC0958、AC0959、AC0960	SP0544、SP0545、SP0546、SP0547、SP0548、SP0549、SP0550、SP0551
Belgium	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Belgium	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Belgium	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983、AC0984、AC0985、AC0986、AC0987、AC0988、AC0989、AC0990	SP0563、SP0564、SP0565、SP0566、SP0567
Belgium	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511、SP0515、SP0516、SP0538、SP0539、SP0540
Belgium	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Belgium	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973、AC0974、AC0976、AC0977	
Belgium	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Belgium	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604、SP0605、SP0606
Belgium	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043、AC1044、AC1045、AC1046、AC1047、AC1048、AC1049、AC1050、AC1051、AC1052、AC1053、AC1054、AC1055、AC1056、AC1057、AC1058、AC1059、AC1060、AC1061、AC1062、AC1063、AC1064、AC1065、AC1066、AC1067、AC1068、AC1069、AC1070、AC1071、AC1072、AC1073、AC1074、AC1075、AC1076、AC1077	
Belgium	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014、AC1015、AC1016、AC1017、AC1018、AC1019、AC1020、AC1021、AC1022、AC1023	
Belgium	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Belgium	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Belgium	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111、AC1112	SP0608、SP0609、SP0610
Belgium	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590、SP0591、SP0592
Belgium	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Belgium	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Belgium	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Belgium	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Belgium	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Belgium	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Belgium	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Belgium	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Belgium	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122、AC1123、AC1124、AC1125、AC1126	
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0869、AC0870、AC0871、AC0872、AC0873、AC0874、AC0875、AC0876、AC0877、AC0878、AC0879、AC0880、AC0881、AC0882、AC0883、AC0884、AC0885	SP0494、SP0495、SP0496、SP0497
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348、SP0349、SP0350、SP0351
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0225、AC0226、AC0229、AC0256、AC0282、AC0283、AC0284、AC0307、AC0311、AC0314、AC0315、AC0320、AC0325、AC0327、AC0330、AC0331、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0009、SP0016、SP0017、SP0018、SP0032、SP0033、SP0034、SP0038、SP0039、SP0043、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0082、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0140、SP0143、SP0150、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0193、SP0194、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247、SP0265、SP0274、SP0276
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613、AC0618、AC0663、AC0690、AC0692、AC0702	SP0372、SP0429
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498、AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533、AC0536	SP0300、SP0313、SP0315
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472、SP0473、SP0474、SP0475、SP0477、SP0479、SP0480、SP0481、SP0482、SP0486、SP0487
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084、AC1085、AC1086、AC1087、AC1088、AC1089、AC1106	
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980、AC0981、AC0982	SP0561、SP0562
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966、AC0967、AC0968	SP0557
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985、AC0986、AC0987、AC0988、AC0989	SP0563、SP0564、SP0565、SP0566、SP0567
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973、AC0974、AC0976、AC0977	
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043、AC1044、AC1045、AC1046、AC1047、AC1048、AC1049、AC1050、AC1051、AC1052、AC1053、AC1054、AC1055、AC1056、AC1057、AC1058、AC1059、AC1060、AC1061、AC1062、AC1063、AC1064、AC1065、AC1066、AC1067、AC1068、AC1069、AC1070、AC1071、AC1072、AC1073、AC1074、AC1075、AC1076、AC1077	
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014、AC1015、AC1016、AC1017、AC1018、AC1019、AC1020、AC1021	
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	

Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Belgium	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Belgium	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Belgium	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Belgium	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Belgium	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Belgium	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belgium	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Belgium	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Belgium	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Belgium	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Belgium	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Belgium	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Belgium	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Belgium	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Belgium	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Belgium	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Belgium	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Belgium	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belgium	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Belgium	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Belgium	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Belgium	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Belgium	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Belgium	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Belgium	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Belgium	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Belgium	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Belgium	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Belgium	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Belgium	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Belgium	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Belgium	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Belgium	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Belgium	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Belgium	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Belgium	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Belgium	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Belgium	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Belgium	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Belgium	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Belgium	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Belgium	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belgium	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Belgium	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Belgium	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Belgium	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Belgium	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Belgium	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Belgium	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Belgium	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Belgium	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Belgium	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Belgium	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Belgium	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Belgium	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Belgium	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belgium	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Belgium	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Belgium	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Belgium	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Belgium	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Belgium	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Belgium	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Belgium	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Belgium	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Belgium	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Belgium	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Belgium	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Belgium	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Belgium	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Belgium	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Belgium	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		

Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Belgium	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Belgium	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Belgium	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Belgium	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Belgium	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belgium	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Belgium	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Belgium	INFINITI QX50	I50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Belgium	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Belgium	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Belgium	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Belgium	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Belgium	INFINITI QX50	I50	2013.9-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belgium	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belgium	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belgium	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Belgium	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Belgium	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Belgium	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Belgium	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Belgium	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Belgium	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Belgium	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Belgium	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Belgium	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Belgium	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Belgium	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Belgium	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Belgium	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Belgium	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Belgium	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Belgium	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Belgium	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Belgium	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Belgium	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belgium	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Belgium	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Belgium	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Belgium	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Belgium	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Belgium	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Belgium	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belgium	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Belgium	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belgium	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Belgium	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Belgium	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Belgium	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Belgium	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Belgium	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Belgium	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Belgium	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621

Belgium	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Belgium	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Belgium	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Belgium	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belgium	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Belgium	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Belgium	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belgium	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belgium	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Belgium	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Belgium	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Belgium	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Belgium	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Belgium	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Belgium	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belgium	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Belgium	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Belgium	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Belgium	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Belgium	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Belize	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belize	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Belize	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belize	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Belize	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Belize	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Belize	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Belize	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Belize	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Belize	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belize	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belize	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belize	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belize	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Belize	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Belize	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Belize	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Belize	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Belize	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belize	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Belize	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belize	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Belize	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Belize	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Belize	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Belize	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Belize	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Belize	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Belize	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Belize	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Belize	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belize	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Belize	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Belize	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belize	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belize	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Belize	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Belize	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Belize	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Belize	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Belize	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Belize	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belize	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Belize	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Belize	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belize	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belize	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867. AC0868. AC0884	SP0494
Belize	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belize	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Belize	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Belize	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Belize	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Belize	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Belize	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Belize	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Belize	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Belize	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Belize	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belize	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belize	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belize	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Belize	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Belize	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belize	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Belize	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Belize	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belize	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Belize	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Belize	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Belize	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Belize	INFINITI JX35	L50	2012.9-	BCM				√	AC0613. AC0618. AC0663. AC0690. AC0692. AC0702	SP0372. SP0429
Belize	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509. AC0510. AC0514. AC0515. AC0528. AC0529. AC0531. AC0532. AC0533. AC0536	SP0300. SP0313. SP0315
Belize	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Belize	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808. AC0809	SP0472. SP0473. SP0474. SP0475. SP0477. SP0478. SP0483. SP0487
Belize	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belize	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Belize	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belize	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966. AC0967. AC0968	SP0557
Belize	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Belize	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Belize	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Belize	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Belize	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Belize	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Belize	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Belize	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Belize	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Belize	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Belize	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Belize	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Belize	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Belize	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Belize	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Belize	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Belize	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Belize	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Belize	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Belize	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Belize	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Belize	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Belize	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Belize	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belize	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belize	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belize	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Belize	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Belize	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Belize	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Belize	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Belize	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belize	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Belize	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Belize	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Belize	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Belize	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494

Belize	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Belize	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Belize	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Belize	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Belize	INFINITI Q45	F50	2001.8-	Motor control						
Belize	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Belize	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Belize	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Belize	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Belize	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Belize	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Belize	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Belize	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belize	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Belize	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Belize	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Belize	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Belize	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Belize	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Belize	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Belize	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Belize	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Belize	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Belize	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Belize	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Belize	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Belize	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Belize	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Belize	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Belize	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Belize	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Belize	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Belize	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Belize	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Belize	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Belize	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Belize	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Belize	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Belize	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Belize	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Belize	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Belize	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Belize	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Belize	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Belize	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Belize	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Belize	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031. AC1032. AC1033	SP0585. SP0586. SP0587
Belize	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Belize	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Belize	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Belize	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Belize	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Belize	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Belize	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Belize	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Belize	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Belize	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Belize	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Belize	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Belize	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Benin	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Benin	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Benin	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Benin	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Benin	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Benin	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Benin	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Benin	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Benin	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Benin	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Benin	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Benin	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Benin	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Benin	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Benin	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Benin	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Benin	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Benin	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Benin	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Benin	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Benin	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Benin	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Benin	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Benin	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Benin	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Benin	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Benin	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Benin	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Benin	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Benin	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Benin	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Benin	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Benin	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Benin	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Benin	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Benin	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Benin	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Benin	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Benin	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Benin	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Benin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Benin	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Benin	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Benin	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Benin	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Benin	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Benin	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Benin	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Benin	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Benin	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Benin	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Benin	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Benin	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Benin	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Benin	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Benin	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Benin	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Benin	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Benin	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Benin	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Benin	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Benin	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Benin	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Benin	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Benin	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Benin	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Benin	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Benin	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Benin	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Benin	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Benin	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Benin	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Benin	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Benin	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Benin	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Benin	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Benin	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Benin	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Benin	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Benin	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Benin	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Benin	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Benin	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Benin	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546,AC0547,AC0548,AC0549	SP0342,SP0343,SP0344
Benin	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002,AC0103,AC0214,AC0264,AC0265,AC0266,AC0267,AC0268,AC0269,AC0270,AC0271,AC0272,AC0273,AC0274,AC0275,AC0276,AC0277,AC0308,AC0310,AC0311,AC0312,AC0314,AC0315,AC0317,AC0320,AC0325,AC0327,AC0328,AC0329,AC0330,AC0331,AC0332	SP0034,SP0035,SP0159,SP0193,SP0194
Benin	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580,AC0674,AC0739,AC0740,AC0741,AC0742,AC0743,AC0744,AC0745,AC0746,AC0747,AC0748,AC0749,AC0750,AC0751,AC0752,AC0753,AC0754,AC0755,AC0756,AC0757,AC0758,AC0759,AC0760,AC0761,AC0762,AC0763,AC0764,AC0765,AC0766,AC0767,AC0768,AC0769,AC0770	
Benin	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Benin	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Benin	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Benin	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143,AC1144,AC1145,AC1146,AC1147,AC1148,AC1149,AC1150,AC1151,AC1152,AC1153,AC1154,AC1155,AC1156	
Benin	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Benin	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Benin	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Benin	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171,AC1172,AC1173,AC1174,AC1175	
Benin	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157,AC1158,AC1159,AC1160,AC1161,AC1162,AC1163,AC1164,AC1165,AC1166,AC1167,AC1168,AC1169,AC1170	SP0622
Benin	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Benin	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Benin	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Benin	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Benin	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Benin	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Benin	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Benin	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Benin	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Benin	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Benin	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Benin	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Benin	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Benin	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Benin	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Benin	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Benin	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Benin	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Benin	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0274
Benin	INFINITI Q50	V37	2013.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Benin	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
Benin	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Benin	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503

Benin	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Benin	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Benin	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Benin	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Benin	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Benin	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Benin	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Benin	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Benin	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Benin	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Benin	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Benin	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Benin	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Benin	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Benin	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Benin	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Benin	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Benin	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Benin	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Benin	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Benin	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Benin	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Benin	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Benin	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Benin	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Benin	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Benin	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Benin	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Benin	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Benin	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Benin	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Benin	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Benin	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Benin	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Benin	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Benin	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Benin	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Benin	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Benin	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Benin	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Benin	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Benin	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Benin	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Benin	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Benin	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Benin	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Benin	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Benin	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Benin	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Benin	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Benin	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Benin	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Benin	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Benin	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Benin	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Benin	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Benin	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Benin	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Benin	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Benin	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Benin	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Benin	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Benin	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	

Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Benin	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Benin	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Benin	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Benin	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Benin	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Benin	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Benin	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Benin	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Benin	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Benin	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Benin	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Benin	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Benin	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Benin	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Benin	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Benin	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Benin	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Benin	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Benin	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Benin	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Benin	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Benin	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Benin	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Benin	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Benin	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Benin	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Benin	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Benin	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Benin	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Benin	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Benin	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Benin	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Benin	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Benin	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Benin	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Benin	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Benin	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Benin	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Benin	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Benin	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Benin	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Benin	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Benin	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Benin	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Benin	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Benin	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Benin	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Benin	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Benin	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Benin	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Benin	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Benin	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Benin	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Benin	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

Benin	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Benin	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Benin	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Benin	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Benin	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC039 2, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Benin	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Benin	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Benin	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Benin	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Benin	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Benin	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Benin	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Benin	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Benin	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Benin	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Benin	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Benin	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Benin	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Benin	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Benin	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Benin	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Benin	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Benin	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Benin	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Benin	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Benin	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Benin	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Benin	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Benin	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Benin	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Benin	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Benin	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Benin	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Benin	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Benin	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Benin	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Benin	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Benin	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Benin	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Benin	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Benin	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Benin	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Benin	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Benin	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Benin	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Benin	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Benin	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Benin	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Benin	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Benin	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Benin	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Benin	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Benin	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Benin	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Benin	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Benin	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Benin	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Benin	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Benin	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Benin	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Benin	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Benin	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Benin	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Benin	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Benin	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Benin	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Benin	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031,AC1032,AC1033	SP0585,SP0586,SP0587
Benin	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Benin	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Benin	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Benin	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Benin	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Benin	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Benin	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Benin	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Benin	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Benin	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Benin	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Benin	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Benin	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Benin	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Benin	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Benin	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Benin	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Benin	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Benin	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Benin	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Bermuda	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bermuda	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Bermuda	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bermuda	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		

Bermuda	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bermuda	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Bermuda	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bermuda	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bermuda	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Bermuda	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bermuda	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bermuda	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bermuda	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bermuda	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bermuda	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Bermuda	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Bermuda	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bermuda	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Bermuda	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Bermuda	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bermuda	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Bermuda	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Bermuda	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Bermuda	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bermuda	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Bermuda	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bermuda	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Bermuda	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Bermuda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Bermuda	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bermuda	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Bermuda	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bermuda	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bermuda	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Bermuda	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bermuda	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bermuda	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Bermuda	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bermuda	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bermuda	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Bermuda	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Bermuda	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bermuda	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Bermuda	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bermuda	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Bermuda	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Bermuda	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bermuda	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Bermuda	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bermuda	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bermuda	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bermuda	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bermuda	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Bermuda	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bermuda	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bermuda	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bermuda	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bermuda	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Bermuda	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bermuda	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bermuda	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bermuda	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bermuda	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Bermuda	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Bermuda	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Bermuda	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bermuda	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bermuda	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bermuda	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bermuda	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bermuda	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bermuda	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bermuda	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bermuda	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Bermuda	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Bermuda	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bermuda	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bermuda	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Bermuda	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Bermuda	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bermuda	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Bermuda	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bermuda	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bermuda	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Bermuda	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Bermuda	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Bermuda	INFINITI Q45	F50	2001.8-	Motor control						
Bermuda	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bermuda	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288

Bermuda	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Bermuda	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bermuda	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Bermuda	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Bermuda	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Bermuda	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bermuda	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Bermuda	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Bermuda	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Bermuda	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bermuda	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Bermuda	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bermuda	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Bermuda	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Bermuda	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bermuda	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Bermuda	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Bermuda	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Bermuda	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Bermuda	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Bermuda	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Bermuda	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Bermuda	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Bermuda	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Bermuda	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Bermuda	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Bermuda	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Bermuda	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bermuda	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Bermuda	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bermuda	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bermuda	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Bermuda	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Bermuda	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bermuda	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Bermuda	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bermuda	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Bermuda	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Bermuda	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Bermuda	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Bermuda	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bermuda	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Bermuda	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Bermuda	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bermuda	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bermuda	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Bermuda	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Bermuda	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bermuda	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Bermuda	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bermuda	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Bermuda	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bermuda	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bhutan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bolivia	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bolivia	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Bolivia	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bolivia	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Bolivia	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bolivia	INFINITI EX35/EX37	I50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Bolivia	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bolivia	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bolivia	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Bolivia	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bolivia	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bolivia	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bolivia	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bolivia	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bolivia	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Bolivia	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Bolivia	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bolivia	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Bolivia	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Bolivia	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Bolivia	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bolivia	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Bolivia	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Bolivia	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Bolivia	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bolivia	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Bolivia	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bolivia	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Bolivia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Bolivia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Bolivia	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Bolivia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bolivia	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Bolivia	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bolivia	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bolivia	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Bolivia	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bolivia	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bolivia	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Bolivia	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bolivia	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bolivia	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Bolivia	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Bolivia	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bolivia	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Bolivia	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bolivia	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Bolivia	INFINITI TX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Bolivia	INFINITI TX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bolivia	INFINITI TX35	L50	2012.9-	CAN gateway	√	√	√			
Bolivia	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bolivia	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bolivia	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bolivia	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bolivia	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Bolivia	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bolivia	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bolivia	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bolivia	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bolivia	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Bolivia	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bolivia	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bolivia	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bolivia	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bolivia	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Bolivia	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Bolivia	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Bolivia	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bolivia	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bolivia	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bolivia	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bolivia	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bolivia	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bolivia	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bolivia	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Bolivia	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Bolivia	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Bolivia	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bolivia	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bolivia	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Bolivia	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Bolivia	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bolivia	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Bolivia	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bolivia	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bolivia	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Bolivia	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Bolivia	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Bolivia	INFINITI Q45	F50	2001.8-	Motor control						
Bolivia	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bolivia	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Bolivia	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Bolivia	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bolivia	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Bolivia	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Bolivia	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Bolivia	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bolivia	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Bolivia	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Bolivia	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Bolivia	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bolivia	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Bolivia	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Bolivia	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Bolivia	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Bolivia	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bolivia	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Bolivia	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Bolivia	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Bolivia	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Bolivia	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Bolivia	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Bolivia	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Bolivia	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Bolivia	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Bolivia	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Bolivia	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Bolivia	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Bolivia	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894. AC0895. AC0896	SP0510
Bolivia	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Bolivia	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bolivia	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bolivia	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Bolivia	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347. SP0348. SP0349. SP0350. SP0351
Bolivia	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bolivia	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Bolivia	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bolivia	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Bolivia	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Bolivia	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Bolivia	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Bolivia	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bolivia	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Bolivia	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Bolivia	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bolivia	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bolivia	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553. SP0554. SP0556
Bolivia	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544. SP0545. SP0546. SP0547. SP0548. SP0549
Bolivia	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985. AC0986. AC0987. AC0988. AC0989	SP0563. SP0564. SP0565. SP0566. SP0567
Bolivia	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Bolivia	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bolivia	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Bolivia	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bolivia	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Bosnia	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Bosnia	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bosnia	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Bosnia	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Bosnia	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bosnia	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Bosnia	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Bosnia	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Bosnia	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Bosnia	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Bosnia	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274

Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Bosnia	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Bosnia	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bosnia	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bosnia	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Bosnia	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bosnia	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Bosnia	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Bosnia	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Bosnia	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Bosnia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Bosnia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494

Bosnia	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Bosnia	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bosnia	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Bosnia	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Bosnia	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Bosnia	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Bosnia	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bosnia	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bosnia	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Bosnia	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Bosnia	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Bosnia	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Bosnia	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Bosnia	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Bosnia	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Bosnia	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Bosnia	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bosnia	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Bosnia	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bosnia	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Bosnia	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Bosnia	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bosnia	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Bosnia	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bosnia	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Bosnia	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bosnia	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bosnia	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Bosnia	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Bosnia	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bosnia	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Bosnia	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bosnia	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bosnia	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bosnia	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bosnia	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Bosnia	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Bosnia	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bosnia	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Bosnia	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Bosnia	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Bosnia	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		

Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Bosnia	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Bosnia	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Bosnia	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Bosnia	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Bosnia	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Bosnia	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Bosnia	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Bosnia	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Bosnia	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Bosnia	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Bosnia	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Bosnia	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Bosnia	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Bosnia	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Bosnia	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Bosnia	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Bosnia	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Bosnia	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Bosnia	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Bosnia	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Bosnia	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Bosnia	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Bosnia	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Bosnia	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Bosnia	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Bosnia	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Bosnia	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Bosnia	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Bosnia	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					

XTOOL

Bosnia	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Bosnia	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Bosnia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Bosnia	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bosnia	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Bosnia	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bosnia	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Bosnia	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Bosnia	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bosnia	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Bosnia	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bosnia	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Bosnia	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bosnia	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bosnia	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Bosnia	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bosnia	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Bosnia	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bosnia	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bosnia	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bosnia	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Bosnia	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bosnia	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bosnia	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bosnia	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Bosnia	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Bosnia	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Bosnia	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bosnia	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Bosnia	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Bosnia	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bosnia	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Bosnia	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Bosnia	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Bosnia	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Bosnia	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Bosnia	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Bosnia	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Bosnia	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bosnia	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Bosnia	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Bosnia	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Bosnia	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Bosnia	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Bosnia	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Bosnia	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Bosnia	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Bosnia	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	

Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Bosnia	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Bosnia	INFINITI Q60 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bosnia	INFINITI Q60 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Bosnia	INFINITI Q60 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Bosnia	INFINITI Q60 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bosnia	INFINITI Q60 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Bosnia	INFINITI Q60 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Bosnia	INFINITI Q60 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Bosnia	INFINITI Q60 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Bosnia	INFINITI Q60 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Bosnia	INFINITI Q60 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Bosnia	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Bosnia	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bosnia	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Bosnia	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bosnia	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Bosnia	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Bosnia	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bosnia	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bosnia	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Bosnia	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bosnia	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bosnia	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Bosnia	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bosnia	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Bosnia	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bosnia	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bosnia	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bosnia	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Bosnia	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Bosnia	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Bosnia	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bosnia	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Bosnia	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bosnia	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Bosnia	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Bosnia	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Bosnia	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Bosnia	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Bosnia	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bosnia	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Bosnia	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Bosnia	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Bosnia	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Bosnia	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Bosnia	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bosnia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bosnia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bosnia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Bosnia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bosnia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Bosnia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Bosnia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bosnia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bosnia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Bosnia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bosnia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Bosnia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bosnia	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bosnia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bosnia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Bosnia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bosnia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bosnia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bosnia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Bosnia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Bosnia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bosnia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Bosnia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bosnia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Bosnia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bosnia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bosnia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Bosnia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bosnia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bosnia	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Bosnia	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Bosnia	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Bosnia	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		

Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Bosnia	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Bosnia	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bosnia	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Bosnia	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bosnia	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Bosnia	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Bosnia	INFINITI QX50	I50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bosnia	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bosnia	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Bosnia	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bosnia	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI QX50	I50	2013.9-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bosnia	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bosnia	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bosnia	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Bosnia	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Bosnia	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bosnia	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bosnia	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Bosnia	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bosnia	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bosnia	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bosnia	INFINITI QX56	IA60	2007.8-	ICC/ADAS						
Bosnia	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bosnia	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Bosnia	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Bosnia	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bosnia	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Bosnia	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Bosnia	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bosnia	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Bosnia	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Bosnia	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Bosnia	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bosnia	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Bosnia	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Bosnia	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Bosnia	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Bosnia	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bosnia	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Bosnia	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bosnia	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bosnia	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bosnia	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Bosnia	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Bosnia	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bosnia	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bosnia	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Bosnia	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bosnia	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bosnia	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621

Bosnia	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Bosnia	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bosnia	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bosnia	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bosnia	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Bosnia	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Bosnia	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bosnia	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bosnia	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Bosnia	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Bosnia	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Bosnia	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bosnia	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Bosnia	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bosnia	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bosnia	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bosnia	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bosnia	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bosnia	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bosnia	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Botswana	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Botswana	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Botswana	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Botswana	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Botswana	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Botswana	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Botswana	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Botswana	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Botswana	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Botswana	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Botswana	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Botswana	INFINITI EX35/EX37	I50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Botswana	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Botswana	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Botswana	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Botswana	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Botswana	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Botswana	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Botswana	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Botswana	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Botswana	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Botswana	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Botswana	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Botswana	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Botswana	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Botswana	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Botswana	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Botswana	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Botswana	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Botswana	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Botswana	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Botswana	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Botswana	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Botswana	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Botswana	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Botswana	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Botswana	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Botswana	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Botswana	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Botswana	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Botswana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Botswana	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Botswana	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Botswana	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Botswana	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Botswana	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Botswana	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Botswana	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Botswana	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Botswana	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Botswana	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Botswana	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Botswana	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Botswana	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Botswana	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Botswana	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Botswana	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Botswana	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Botswana	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Botswana	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Botswana	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Botswana	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Botswana	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Botswana	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Botswana	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Botswana	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Botswana	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Botswana	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Botswana	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Botswana	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Botswana	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Botswana	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Botswana	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Botswana	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Botswana	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Botswana	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Botswana	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Botswana	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Botswana	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Botswana	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Botswana	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Botswana	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Botswana	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Botswana	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Botswana	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Botswana	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Botswana	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Botswana	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Botswana	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Botswana	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Botswana	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Botswana	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		

Botswana	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Botswana	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Botswana	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Botswana	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Botswana	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Botswana	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Botswana	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Botswana	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Botswana	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Botswana	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Botswana	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Botswana	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Botswana	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Botswana	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Botswana	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Botswana	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Botswana	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Botswana	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Botswana	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Botswana	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Botswana	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Botswana	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Botswana	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Botswana	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Botswana	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Botswana	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Botswana	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Botswana	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Botswana	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Botswana	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Botswana	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Botswana	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Botswana	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Botswana	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Botswana	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Botswana	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Botswana	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Botswana	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Botswana	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Botswana	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Botswana	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Botswana	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Botswana	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Botswana	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Botswana	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Botswana	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Botswana	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Botswana	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Botswana	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Botswana	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	

Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
Botswana	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Botswana	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Botswana	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Botswana	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Botswana	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Botswana	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Botswana	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Botswana	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Botswana	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Botswana	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Botswana	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Botswana	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Botswana	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Botswana	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Botswana	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Botswana	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Botswana	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Botswana	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Botswana	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Botswana	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966.AC0967.AC0968	SP0557
Botswana	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Botswana	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Botswana	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Botswana	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Botswana	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Botswana	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Botswana	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Botswana	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Botswana	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Botswana	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Botswana	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Botswana	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Botswana	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Botswana	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Botswana	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Botswana	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Botswana	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Botswana	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Botswana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543

Xtool

Botswana	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Botswana	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Botswana	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Botswana	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Botswana	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Botswana	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Botswana	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Botswana	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Botswana	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Botswana	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Botswana	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Botswana	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Botswana	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Botswana	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Botswana	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Botswana	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Botswana	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Botswana	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Botswana	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Botswana	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Botswana	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0555,SP0556,SP0557
Botswana	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Botswana	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Botswana	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Botswana	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Botswana	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Botswana	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Botswana	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Botswana	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Botswana	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Botswana	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Botswana	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Botswana	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Botswana	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Botswana	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Botswana	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Botswana	INFINITI QX50	I50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Botswana	INFINITI QX50	I50	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Botswana	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Botswana	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Botswana	INFINITI QX50	J50	2013.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Botswana	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Botswana	INFINITI QX50	I50	2013.8-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Botswana	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Botswana	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Botswana	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Botswana	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Botswana	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Botswana	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Botswana	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Botswana	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Botswana	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Botswana	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Botswana	INFINITI QX50	I50	2013.8-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Botswana	INFINITI QX50	I50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Botswana	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Botswana	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Botswana	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Botswana	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Botswana	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Botswana	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Botswana	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Botswana	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Botswana	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Botswana	INFINITI QX70	S51	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Botswana	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Botswana	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Botswana	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Botswana	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Botswana	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Botswana	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Botswana	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Botswana	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Botswana	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Botswana	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Botswana	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Botswana	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Botswana	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Botswana	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Botswana	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Botswana	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Botswana	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Botswana	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Botswana	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Botswana	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Botswana	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583

Botswana	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Botswana	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Botswana	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Botswana	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Botswana	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Botswana	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Botswana	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Botswana	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Botswana	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Botswana	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Botswana	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Botswana	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Botswana	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Botswana	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Botswana	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Botswana	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Botswana	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Botswana	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Botswana	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Botswana	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Botswana	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Botswana	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Botswana	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Botswana	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Botswana	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Botswana	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Botswana	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Botswana	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Botswana	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Botswana	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Botswana	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Botswana	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Botswana	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Botswana	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Botswana	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Brazil	INFINITI EX35/EX37	I50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Brazil	INFINITI EX35/EX37	I50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Brazil	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Brazil	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Brazil	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Brazil	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Brazil	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Brazil	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Brazil	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Brazil	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Brazil	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Brazil	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Brazil	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Brazil	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Brazil	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Brazil	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Brazil	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Brazil	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Brazil	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Brazil	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Brazil	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Brazil	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Brazil	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Brazil	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Brazil	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Brazil	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Brazil	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Brazil	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Brazil	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Brazil	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Brazil	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Brazil	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Brazil	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Brazil	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Brazil	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Brazil	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Brazil	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Brazil	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Brazil	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Brazil	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Brazil	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Brazil	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Brazil	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		

Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Brazil	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Brazil	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Brazil	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Brazil	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Brazil	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Brazil	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Brazil	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Brazil	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Brazil	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Brazil	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Brazil	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Brazil	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Brazil	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Brazil	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Brazil	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Brazil	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Brazil	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Brazil	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Brazil	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Brazil	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Brazil	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Brazil	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Brazil	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Brazil	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Brazil	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Brazil	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Brazil	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Brazil	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Brazil	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Brazil	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Brazil	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Brazil	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Brazil	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Brazil	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Brazil	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Brazil	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Brazil	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Brazil	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Brazil	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Brazil	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Brazil	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Brazil	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Brazil	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Brazil	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Brazil	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Brazil	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Brazil	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Brazil	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Brazil	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Brazil	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Brazil	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Brazil	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Brazil	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Brazil	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Brazil	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Brazil	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Brazil	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Brazil	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Brazil	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Brazil	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Brazil	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Brazil	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Brazil	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Brazil	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Brazil	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Brazil	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Brazil	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Brazil	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Brazil	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Brazil	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Brazil	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Brazil	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Brazil	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Brazil	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Brazil	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Brazil	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Brazil	INFINITI Q45	F50	2001.8-	Motor control						
Brazil	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Brazil	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Brazil	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Brazil	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Brazil	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Brazil	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Brazil	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Brazil	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Brazil	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Brazil	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Brazil	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Brazil	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Brazil	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Brazil	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Brazil	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Brazil	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Brazil	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Brazil	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Brazil	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Brazil	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Brazil	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Brazil	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Brazil	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Brazil	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Brazil	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Brazil	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Brazil	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Brazil	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Brazil	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Brazil	INFINITI Q50	V37	2015.3-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Brazil	INFINITI Q50	V37	2015.3-	Laser/radar	√	√	√	√	AC0994	
Brazil	INFINITI Q50	V37	2015.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Brazil	INFINITI Q50	V37	2015.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Brazil	INFINITI Q50	V37	2015.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Brazil	INFINITI Q50	V37	2015.3-	Air bag	√	√	√	√		
Brazil	INFINITI Q50	V37	2015.3-	EPS/DAST 3	√	√	√	√		
Brazil	INFINITI Q50	V37	2015.3-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Brazil	INFINITI Q50	V37	2015.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Brazil	INFINITI Q50	V37	2015.3-	Transmission	√	√	√	√		SP0247, SP0274
Brazil	INFINITI Q50	V37	2015.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Brazil	INFINITI Q50	V37	2015.3-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Brazil	INFINITI Q50	V37	2015.3-	Pop up hood	√	√	√	√		
Brazil	INFINITI Q50	V37	2015.3-	Multi AV	√	√	√	√		SP0503
Brazil	INFINITI Q50	V37	2015.3-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Brazil	INFINITI Q50	V37	2015.3-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Brazil	INFINITI Q50	V37	2015.3-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Brazil	INFINITI Q50	V37	2015.3-	Occupant detection			√	√		SP0584
Brazil	INFINITI Q50	V37	2015.3-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Brazil	INFINITI Q50	V37	2015.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Brazil	INFINITI Q50	V37	2015.3-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Brazil	INFINITI Q50	V37	2015.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Brazil	INFINITI Q50	V37	2015.3-	DAST 2	√	√	√	√		
Brazil	INFINITI Q50	V37	2015.3-	Precrash seatbelt	√	√	√	√		SP0612
Brazil	INFINITI Q50	V37	2015.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Brazil	INFINITI Q50	V37	2015.3-	CAN gateway	√	√	√			
Brazil	INFINITI Q50	V37	2015.3-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Brazil	INFINITI Q50	V37	2015.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Brazil	INFINITI Q50	V37	2015.3-	DAST 1	√	√	√	√		
Brazil	INFINITI Q50	V37	2015.3-	ADCM	√	√	√	√		SP0604, SP0605, SP0606

Brazil	INFINITI Q50	V37	2015.3-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Brazil	INFINITI Q50	V37	2015.3-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Brazil	INFINITI Q50	V37	2015.3-	ANC	√	√	√	√	AC1024	
Brazil	INFINITI Q50	V37	2015.3-	Side radar left	√	√	√	√	AC1025	SP0582
Brazil	INFINITI Q50	V37	2015.3-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Brazil	INFINITI Q50	V37	2015.3-	HIGH BEAM ASSIST	√	√	√	√		
Brazil	INFINITI Q50	V37	2015.3-	Side radar right	√	√	√	√	AC1026	SP0583
Brazil	INFINITI Q50	V37	2015.3-	FSCM	√	√	√	√	AC1109	
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Laser/radar	√	√	√	√		
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Air bag	√	√	√	√		
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	EPS/DAST 3	√	√	√	√		
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Motor control	√	√	√	√		
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Pop up hood	√	√	√	√		
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Multi AV	√	√	√	√		SP0503
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	HV battery	√	√	√	√	AC1121	
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Occupant detection			√	√		SP0584
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	All mode AWD/4WD	√	√	√	√	AC0956	
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	DAST 2	√	√	√	√		
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Precrash seatbelt	√	√	√	√		SP0612
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	CAN gateway	√	√	√			
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	DAST 1	√	√	√	√		
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	ANC	√	√	√	√	AC1024	
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Side radar left	√	√	√	√	AC1025	SP0582
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	HIGH BEAM ASSIST	√	√	√	√		
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Side radar right	√	√	√	√	AC1026	SP0583
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Brake	√	√	√	√	AC1127	
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Brazil	INFINITI Q50 HYBRID	HV37	.NULL-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Brazil	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Brazil	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Brazil	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Brazil	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Brazil	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Brazil	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Brazil	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Brazil	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Brazil	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Brazil	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Brazil	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Brazil	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Brazil	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Brazil	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Brazil	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Brazil	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Brazil	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Brazil	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Brazil	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Brazil	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Brazil	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Brazil	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Brazil	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Brazil	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Brazil	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Brazil	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556

Brunei	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Brunei	INFINITI Q45	F50	ALL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Brunei	INFINITI Q45	F50	ALL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Brunei	INFINITI Q45	F50	ALL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Brunei	INFINITI Q45	F50	ALL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Brunei	INFINITI Q45	F50	ALL	Air bag	√	√	√	√		
Brunei	INFINITI Q45	F50	ALL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Brunei	INFINITI Q45	F50	ALL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Brunei	INFINITI Q45	F50	ALL	Motor control						
Brunei	INFINITI Q45	F50	ALL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Brunei	INFINITI Q45	F50	ALL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Brunei	INFINITI Q45	F50	ALL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Brunei	INFINITI Q45	F50	ALL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Brunei	INFINITI Q45	F50	ALL	Multi AV	√	√	√	√		SP0503
Brunei	INFINITI Q45	F50	ALL	HVAC	√	√	√	√		
Brunei	INFINITI Q45	F50	ALL	Difference lock	√	√	√	√		
Brunei	INFINITI Q45	F50	ALL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Brunei	INFINITI Q45	F50	ALL	Auto slide door	√	√	√	√	AC0941	
Brunei	INFINITI Q45	F50	ALL	DIU		√	√	√		
Brunei	INFINITI Q45	F50	ALL	Adaptive light	√	√	√	√		
Brunei	INFINITI Q45	F50	ALL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Brunei	INFINITI Q45	F50	ALL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Brunei	INFINITI Q45	F50	ALL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Brunei	INFINITI Q45	F50	ALL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Brunei	INFINITI Q45	F50	ALL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Brunei	INFINITI Q45	F50	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Brunei	INFINITI Q45	F50	ALL	IVMS	√	√		√		
Brunei	INFINITI Q45	F50	ALL	Distance control	√	√		√		
Brunei	INFINITI Q45	F50	ALL	Active suspense system	√	√	√	√		
Brunei	INFINITI Q45	F50	ALL	Motor assist		√	√	√		SP0574
Brunei	INFINITI Q45	F50	ALL	ASCD	√	√	√	√		
Brunei	INFINITI Q45	F50	ALL	Active engine mount	√	√	√	√		
Brunei	INFINITI Q45	F50	ALL	TCS	√	√	√	√		
Brunei	INFINITI Q45	F50	ALL	S/blind camera	√			√		SP0572, SP0573
Brunei	INFINITI Q45	F50	ALL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Brunei	INFINITI Q45	F50	ALL	Nats immu	√	√	√			
Brunei	INFINITI Q45	F50	ALL	Rearview camera	√			√		SP0570, SP0571
Brunei	INFINITI Q45	F50	ALL	Smart entrance						SP0568
Bulgaria	INFINITI EX35/EX30D	I50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bulgaria	INFINITI EX35/EX30D	I50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI EX35/EX30D	I50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bulgaria	INFINITI EX35/EX30D	I50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bulgaria	INFINITI EX35/EX30D	I50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI EX35/EX30D	I50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bulgaria	INFINITI EX35/EX30D	I50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Bulgaria	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Bulgaria	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bulgaria	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bulgaria	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Bulgaria	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bulgaria	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bulgaria	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bulgaria	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bulgaria	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bulgaria	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Bulgaria	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI EX37	I50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bulgaria	INFINITI EX37	I50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bulgaria	INFINITI EX37	I50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Bulgaria	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bulgaria	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Bulgaria	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Bulgaria	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bulgaria	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Bulgaria	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Bulgaria	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Bulgaria	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	

Bulgaria	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Bulgaria	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Bulgaria	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Bulgaria	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Bulgaria	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bulgaria	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bulgaria	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Bulgaria	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bulgaria	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Bulgaria	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Bulgaria	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Bulgaria	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

XTOOL

Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Bulgaria	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Bulgaria	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Bulgaria	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bulgaria	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Bulgaria	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Bulgaria	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Bulgaria	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Bulgaria	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bulgaria	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bulgaria	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Bulgaria	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Bulgaria	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Bulgaria	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Bulgaria	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Bulgaria	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Bulgaria	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Bulgaria	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Bulgaria	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bulgaria	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Bulgaria	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bulgaria	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Bulgaria	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Bulgaria	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bulgaria	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Bulgaria	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bulgaria	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Bulgaria	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bulgaria	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315

Bulgaria	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Bulgaria	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Bulgaria	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bulgaria	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Bulgaria	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bulgaria	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bulgaria	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bulgaria	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bulgaria	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Bulgaria	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Bulgaria	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bulgaria	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Bulgaria	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Bulgaria	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Bulgaria	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124.AC1125.AC1126	
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Bulgaria	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Bulgaria	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Bulgaria	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Bulgaria	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Bulgaria	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Bulgaria	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Bulgaria	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Bulgaria	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Bulgaria	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Bulgaria	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Bulgaria	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Bulgaria	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Bulgaria	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Bulgaria	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Bulgaria	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Bulgaria	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Bulgaria	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Bulgaria	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Bulgaria	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Bulgaria	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		

Bulgaria	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Bulgaria	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Bulgaria	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Bulgaria	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Bulgaria	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Bulgaria	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Bulgaria	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bulgaria	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Bulgaria	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bulgaria	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Bulgaria	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Bulgaria	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bulgaria	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Bulgaria	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bulgaria	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Bulgaria	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bulgaria	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bulgaria	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Bulgaria	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bulgaria	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Bulgaria	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bulgaria	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bulgaria	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bulgaria	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Bulgaria	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bulgaria	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bulgaria	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bulgaria	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Bulgaria	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Bulgaria	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Bulgaria	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bulgaria	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Bulgaria	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Bulgaria	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bulgaria	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Bulgaria	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Bulgaria	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Bulgaria	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Bulgaria	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Bulgaria	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Bulgaria	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Bulgaria	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bulgaria	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Bulgaria	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Bulgaria	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	

XTOOL

Bulgaria	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Bulgaria	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Bulgaria	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Bulgaria	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Bulgaria	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Bulgaria	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084. AC1085. AC1086. AC1087. AC1088. AC1089. AC1106	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980. AC0981. AC0982	SP0561, SP0562
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Bulgaria	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966. AC0967. AC0968	SP0557
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Bulgaria	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Bulgaria	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bulgaria	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Bulgaria	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bulgaria	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Bulgaria	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Bulgaria	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Bulgaria	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bulgaria	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Bulgaria	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Bulgaria	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Bulgaria	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Bulgaria	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bulgaria	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Bulgaria	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bulgaria	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bulgaria	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bulgaria	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Bulgaria	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Bulgaria	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Bulgaria	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bulgaria	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Bulgaria	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bulgaria	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Bulgaria	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Bulgaria	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Bulgaria	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Bulgaria	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Bulgaria	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bulgaria	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Bulgaria	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Bulgaria	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Bulgaria	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Bulgaria	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Bulgaria	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bulgaria	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Bulgaria	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bulgaria	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Bulgaria	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Bulgaria	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Bulgaria	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bulgaria	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Bulgaria	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bulgaria	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Bulgaria	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bulgaria	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bulgaria	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bulgaria	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Bulgaria	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bulgaria	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bulgaria	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bulgaria	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Bulgaria	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Bulgaria	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bulgaria	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Bulgaria	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bulgaria	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Bulgaria	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bulgaria	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bulgaria	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Bulgaria	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bulgaria	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bulgaria	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Bulgaria	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Bulgaria	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Bulgaria	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Bulgaria	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Bulgaria	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Bulgaria	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Bulgaria	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bulgaria	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Bulgaria	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Bulgaria	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bulgaria	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bulgaria	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Bulgaria	INFINITI QX50	I50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bulgaria	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI QX50	I50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bulgaria	INFINITI QX50	I50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bulgaria	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bulgaria	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Bulgaria	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Bulgaria	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Bulgaria	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bulgaria	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	

Bulgaria	INFINITI QX50	I50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bulgaria	INFINITI QX50	I50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bulgaria	INFINITI QX50	I50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bulgaria	INFINITI QX56	IA60	2007.8-	ICC/ADAS						
Bulgaria	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Bulgaria	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Bulgaria	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Bulgaria	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Bulgaria	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Bulgaria	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Bulgaria	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Bulgaria	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Bulgaria	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Bulgaria	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Bulgaria	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Bulgaria	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Bulgaria	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Bulgaria	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Bulgaria	INFINITI QX56	IA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Bulgaria	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Bulgaria	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Bulgaria	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Bulgaria	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Bulgaria	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Bulgaria	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Bulgaria	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Bulgaria	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Bulgaria	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Bulgaria	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Bulgaria	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Bulgaria	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Bulgaria	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Bulgaria	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Bulgaria	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Bulgaria	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Bulgaria	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Bulgaria	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Bulgaria	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Bulgaria	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Bulgaria	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Bulgaria	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Bulgaria	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Bulgaria	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Bulgaria	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Bulgaria	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Bulgaria	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Bulgaria	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Bulgaria	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Bulgaria	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Bulgaria	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Bulgaria	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Bulgaria	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
BurmA(myanmer)	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274

Burukina faso	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Burukina faso	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burukina faso	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Burukina faso	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

XTOOL

Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Burukina faso	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Burukina faso	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Burukina faso	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Burukina faso	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Burukina faso	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Burukina faso	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Burukina faso	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Burukina faso	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burukina faso	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Burukina faso	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Burukina faso	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Burukina faso	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583

Burukina faso	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Burukina faso	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Burukina faso	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Burukina faso	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Burukina faso	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Burukina faso	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Burukina faso	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Burukina faso	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Burukina faso	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Burukina faso	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Burukina faso	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Burukina faso	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Burukina faso	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Burukina faso	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Burukina faso	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Burukina faso	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Burukina faso	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Burukina faso	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Burukina faso	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Burukina faso	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Burukina faso	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Burukina faso	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Burukina faso	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Burukina faso	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burukina faso	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Burukina faso	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Burukina faso	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Burukina faso	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Burukina faso	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Burukina faso	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burukina faso	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Burukina faso	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Burukina faso	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Burukina faso	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Burukina faso	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487

XTOOL

Burukina faso	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burukina faso	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Burukina faso	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Burukina faso	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burukina faso	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Burukina faso	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Burukina faso	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Burukina faso	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Burukina faso	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burukina faso	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Burukina faso	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Burukina faso	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burukina faso	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Burukina faso	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Burukina faso	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Burukina faso	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Burukina faso	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Burukina faso	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Burukina faso	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Burukina faso	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burukina faso	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Burukina faso	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Burukina faso	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	

Burukina faso	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Burukina faso	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burukina faso	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Burukina faso	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Burukina faso	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Burukina faso	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Burukina faso	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Burukina faso	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burukina faso	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Burukina faso	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Burukina faso	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Burukina faso	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Burukina faso	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Burukina faso	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burukina faso	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Burukina faso	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Burukina faso	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burukina faso	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Burukina faso	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Burukina faso	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Burukina faso	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Burukina faso	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Burukina faso	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Burukina faso	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Burukina faso	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burukina faso	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Burukina faso	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Burukina faso	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Burukina faso	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Burukina faso	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Burukina faso	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burukina faso	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Burukina faso	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Burukina faso	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Burukina faso	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Burukina faso	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556

XTOOL

Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burukina faso	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burukina faso	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burukina faso	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Burukina faso	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Burukina faso	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Burukina faso	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Burukina faso	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Burukina faso	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Burukina faso	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Burukina faso	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Burukina faso	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Burukina faso	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Burukina faso	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Burukina faso	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Burukina faso	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burukina faso	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Burukina faso	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Burukina faso	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burukina faso	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Burukina faso	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Burukina faso	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Burukina faso	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burukina faso	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Burukina faso	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Burukina faso	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burukina faso	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Burukina faso	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Burukina faso	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burukina faso	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Burukina faso	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burukina faso	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Burukina faso	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Burukina faso	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Burukina faso	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Burukina faso	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Burukina faso	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burukina faso	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Burukina faso	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Burukina faso	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burukina faso	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Burukina faso	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burukina faso	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burukina faso	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Burukina faso	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Burukina faso	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Burukina faso	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burukina faso	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Burukina faso	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Burukina faso	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Burukina faso	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Burukina faso	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burukina faso	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Burukina faso	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Burukina faso	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Burukina faso	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Burukina faso	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Burukina faso	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Burukina faso	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burukina faso	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Burukina faso	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Burukina faso	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burukina faso	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Burukina faso	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Burukina faso	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Burukina faso	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burukina faso	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Burukina faso	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Burukina faso	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burukina faso	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burukina faso	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Burukina faso	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Burukina faso	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Burukina faso	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burukina faso	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Burukina faso	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Burukina faso	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burukina faso	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Burukina faso	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Burukina faso	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Burukina faso	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burukina faso	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Burukina faso	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Burukina faso	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burukina faso	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		

Burukina faso	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burukina faso	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Burukina faso	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burukina faso	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Burukina faso	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Burukina faso	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burukina faso	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Burukina faso	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Burukina faso	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Burukina faso	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Burukina faso	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Burukina faso	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Burukina faso	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Burukina faso	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burukina faso	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Burukina faso	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Burukina faso	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Burukina faso	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burukina faso	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Burukina faso	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Burukina faso	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Burukina faso	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Burukina faso	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Burukina faso	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Burukina faso	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Burukina faso	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Burukina faso	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burukina faso	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Burukina faso	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Burukina faso	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Burukina faso	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Burukina faso	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Burundi	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burundi	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI EX35/EX37	I50	2011.1-	Air bag	√	√	√	√		
Burundi	INFINITI EX35/EX37	I50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burundi	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Burundi	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Burundi	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burundi	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Burundi	INFINITI EX35/EX37	I50	2011.1-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burundi	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burundi	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burundi	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Burundi	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Burundi	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Burundi	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Burundi	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Burundi	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Burundi	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burundi	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Burundi	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burundi	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Burundi	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Burundi	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burundi	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Burundi	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Burundi	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Burundi	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Burundi	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Burundi	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burundi	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burundi	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Burundi	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Burundi	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Burundi	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Burundi	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burundi	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571

Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Burundi	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0064, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Burundi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Burundi	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burundi	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Burundi	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burundi	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burundi	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Burundi	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burundi	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Burundi	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Burundi	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burundi	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burundi	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burundi	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Burundi	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burundi	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Burundi	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Burundi	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Burundi	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Burundi	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Burundi	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Burundi	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Burundi	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Burundi	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471

Burundi	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Burundi	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Burundi	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Burundi	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Burundi	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burundi	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burundi	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burundi	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burundi	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Burundi	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Burundi	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Burundi	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Burundi	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burundi	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Burundi	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Burundi	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Burundi	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Burundi	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Burundi	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Burundi	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Burundi	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Burundi	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Burundi	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Burundi	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Burundi	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Burundi	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Burundi	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Burundi	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Burundi	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Burundi	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Burundi	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Burundi	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Burundi	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Burundi	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Burundi	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Burundi	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Burundi	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Burundi	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Burundi	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burundi	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Burundi	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Burundi	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Burundi	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Burundi	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Burundi	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burundi	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Burundi	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Burundi	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Burundi	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Burundi	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Burundi	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burundi	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Burundi	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Burundi	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burundi	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Burundi	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Burundi	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Burundi	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Burundi	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burundi	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Burundi	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Burundi	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burundi	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Burundi	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Burundi	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Burundi	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Burundi	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Burundi	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Burundi	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Burundi	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burundi	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Burundi	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Burundi	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	

XTOOL

Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Burundi	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Burundi	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burundi	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Burundi	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Burundi	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Burundi	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Burundi	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Burundi	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burundi	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Burundi	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Burundi	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Burundi	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Burundi	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Burundi	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burundi	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Burundi	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Burundi	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burundi	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Burundi	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Burundi	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Burundi	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Burundi	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Burundi	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Burundi	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Burundi	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burundi	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Burundi	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Burundi	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Burundi	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Burundi	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Burundi	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burundi	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Burundi	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Burundi	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Burundi	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Burundi	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burundi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burundi	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burundi	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Burundi	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Burundi	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Burundi	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Burundi	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Burundi	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Burundi	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Burundi	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Burundi	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Burundi	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Burundi	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Burundi	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Burundi	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burundi	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Burundi	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Burundi	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burundi	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Burundi	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Burundi	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Burundi	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burundi	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Burundi	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Burundi	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burundi	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Burundi	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Burundi	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burundi	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Burundi	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burundi	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Burundi	INFINITI QX50	I50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Burundi	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Burundi	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Burundi	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burundi	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Burundi	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Burundi	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burundi	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Burundi	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI QX50	I50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burundi	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burundi	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Burundi	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Burundi	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612

Burundi	INFINITI QX50	I50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burundi	INFINITI QX50	I50	2013.8-	CAN gateway	√	√	√	√		
Burundi	INFINITI QX50	I50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Burundi	INFINITI QX50	I50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Burundi	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Burundi	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burundi	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Burundi	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Burundi	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Burundi	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Burundi	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Burundi	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Burundi	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Burundi	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Burundi	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Burundi	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Burundi	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Burundi	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Burundi	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Burundi	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Burundi	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Burundi	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Burundi	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Burundi	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burundi	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Burundi	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Burundi	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Burundi	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Burundi	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Burundi	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Burundi	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Burundi	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Burundi	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Burundi	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Burundi	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burundi	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Burundi	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Burundi	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Burundi	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Burundi	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Burundi	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Burundi	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Burundi	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Burundi	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Burundi	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Burundi	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Burundi	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Burundi	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Burundi	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Burundi	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Burundi	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Burundi	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Burundi	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Burundi	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Burundi	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Burundi	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Burundi	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Burundi	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Burundi	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Burundi	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Burundi	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Burundi	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Burundi	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Burundi	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Burundi	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Burundi	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Burundi	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Burundi	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Burundi	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Burundi	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Burundi	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Cabo	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cabo	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cabo	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Cabo	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cabo verde	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cabo	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Cabo	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cabo verde	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Cabo	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Cabo verde	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cabo	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cabo	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cabo	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cabo	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Cabo	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Cabo	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Cabo	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Cabo	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Cabo	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Cabo	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cabo	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cabo	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Cabo	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Cabo verde	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cabo	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Cabo	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cabo	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Cabo	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Cabo	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Cabo	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cabo verde	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cabo	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Cabo	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Cabo	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cabo	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cabo	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Cabo	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Cabo	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Cabo	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Cabo	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cabo	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Cabo verde	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Cabo verde	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Cabo	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cabo	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cabo	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Cabo	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cabo verde	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cabo	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Cabo	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cabo verde	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cabo	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Cabo	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Cabo	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cabo verde	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

XTOOL

Cabo	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Cabo	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Cabo	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Cabo	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cabo	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Cabo	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Cabo	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Cabo verde	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Cabo	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Cabo	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Cabo	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Cabo verde	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Cabo verde	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Cabo	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Cabo verde	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Cabo	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Cabo	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Cabo verde	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Cabo	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Cabo	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Cabo verde	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Cabo	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Cabo	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Cabo	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Cabo	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Cabo	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Cabo	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Cabo	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Cabo	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cabo	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Cabo	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Cabo	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Cabo	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546,AC0547,AC0548,AC0549	SP0342,SP0343,SP0344
Cabo verde	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002,AC0103,AC0214,AC0264,AC0265,AC0266,AC0267,AC0268,AC0269,AC0270,AC0271,AC0272,AC0273,AC0274,AC0275,AC0276,AC0277,AC0308,AC0310,AC0311,AC0312,AC0314,AC0315,AC0317,AC0320,AC0325,AC0327,AC0328,AC0329,AC0330,AC0331,AC0332	SP0034,SP0035,SP0159,SP0193,SP0194
Cabo	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Cabo verde	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580,AC0674,AC0739,AC0740,AC0741,AC0742,AC0743,AC0744,AC0745,AC0746,AC0747,AC0748,AC0749,AC0750,AC0751,AC0752,AC0753,AC0754,AC0755,AC0756,AC0757,AC0758,AC0759,AC0760,AC0761,AC0762,AC0763,AC0764,AC0765,AC0766,AC0767,AC0768,AC0769,AC0770	
Cabo	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Cabo	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Cabo	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Cabo	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Cabo verde	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143,AC1144,AC1145,AC1146,AC1147,AC1148,AC1149,AC1150,AC1151,AC1152,AC1153,AC1154,AC1155,AC1156	
Cabo verde	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Cabo verde	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Cabo verde	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Cabo verde	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171,AC1172,AC1173,AC1174,AC1175	
Cabo verde	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157,AC1158,AC1159,AC1160,AC1161,AC1162,AC1163,AC1164,AC1165,AC1166,AC1167,AC1168,AC1169,AC1170	SP0622
Cabo	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Cabo	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Cabo verde	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Cabo	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Cabo	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Cabo verde	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Cabo	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Cabo verde	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Cabo	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Cabo	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Cabo verde	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Cabo verde	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Cabo	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Cabo	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Cabo	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Cabo	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo verde	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Cabo	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Cabo	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Cabo	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Cabo	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Cabo verde	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Cabo	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0274
Cabo	INFINITI Q50	V37	2013.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Cabo	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
Cabo	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Cabo	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503

XTOOL

Cabo verde	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cabo	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cabo	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cabo	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Cabo	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Cabo	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cabo	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Cabo	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Cabo	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Cabo	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Cabo	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cabo	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Cabo	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Cabo	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cabo	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Cabo	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Cabo verde	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Cabo	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cabo	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Cabo	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Cabo	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Cabo	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cabo	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Cabo	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Cabo	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo verde	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Cabo verde	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Cabo verde	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Cabo verde	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Cabo	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Cabo	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cabo	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Cabo	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo verde	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Cabo	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cabo	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Cabo	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Cabo	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Cabo verde	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cabo	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Cabo	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Cabo verde	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Cabo	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Cabo	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Cabo verde	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cabo	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cabo verde	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cabo	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Cabo	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Cabo	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cabo	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Cabo	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Cabo	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Cabo	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Cabo	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Cabo	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Cabo	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Cabo	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cabo	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Cabo	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Cabo	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Cabo	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Cabo	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Cabo	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cabo	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Cabo	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Cabo	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Cabo	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Cabo	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	

Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cabo verde	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cabo verde	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cabo verde	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cabo verde	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cabo	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cabo	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Cabo	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Cabo	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo verde	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Cabo	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cabo	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Cabo	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Cabo	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Cabo verde	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cabo	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Cabo	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Cabo verde	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Cabo	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Cabo	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Cabo verde	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cabo	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cabo	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cabo	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Cabo	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Cabo	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cabo	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Cabo	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Cabo	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Cabo	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cabo	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Cabo	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Cabo	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cabo	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cabo	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Cabo	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cabo	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Cabo	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cabo	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Cabo	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo verde	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

Cabo	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Cabo	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Cabo	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Cabo	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Cabo verde	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cabo	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Cabo	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cabo verde	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Cabo	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Cabo verde	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cabo	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cabo	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cabo	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Cabo	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Cabo	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Cabo	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cabo	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Cabo	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Cabo	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Cabo	INFINITI QX50	I50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Cabo	INFINITI QX50	I50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cabo	INFINITI QX50	I50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Cabo	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Cabo	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Cabo	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo verde	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Cabo	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cabo	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Cabo	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Cabo	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cabo verde	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cabo verde	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Cabo	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cabo	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Cabo	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Cabo	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Cabo	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cabo	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cabo verde	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cabo	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Cabo	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Cabo	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cabo	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cabo	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Cabo	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Cabo	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Cabo	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cabo	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Cabo	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Cabo	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cabo	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cabo	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Cabo	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Cabo	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cabo	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Cabo	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Cabo	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cabo	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Cabo	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cabo verde	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Cabo	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cabo	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Cabo	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Cabo verde	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cabo verde	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Cabo	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Cabo	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Cabo	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Cabo verde	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Cabo	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031,AC1032,AC1033	SP0585,SP0586,SP0587
Cabo	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Cabo verde	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cabo	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Cabo	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Cabo	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Cabo	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cabo	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Cabo	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Cabo	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Cabo	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Cabo	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Cabo	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Cabo	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cabo	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Cabo	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cabo	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Cabo	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Cabo	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Cabo	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Cabo	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cambodia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Laser/radar	√	√	√	√		
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Air bag	√	√	√	√		
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	EPS/DAST 3	√	√	√	√		
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Motor control	√	√	√	√		
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Pop up hood	√	√	√	√		
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Multi AV	√	√	√	√		SP0503
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	HV battery	√	√	√	√	AC1121	
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Occupant detection			√	√		SP0584
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	DAST 2	√	√	√	√		
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Precrash seatbelt	√	√	√	√		SP0612
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	CAN gateway	√	√	√			
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	DAST 1	√	√	√	√		
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	ANC	√	√	√	√	AC1024	
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Side radar left	√	√	√	√	AC1025	SP0582
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	HIGH BEAM ASSIST	√	√	√	√		
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Side radar right	√	√	√	√	AC1026	SP0583
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Brake	√	√	√	√	AC1127	
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Cambodia	INFINITI Q50 HYBRID	HV37	2014.1-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Cameroon	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cameroon	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI EX35/EX37	I50	2011.1-	Air bag	√	√	√	√		
Cameroon	INFINITI EX35/EX37	I50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cameroon	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cameroon	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Cameroon	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cameroon	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Cameroon	INFINITI EX35/EX37	I50	2011.1-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cameroon	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cameroon	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cameroon	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Cameroon	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Cameroon	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Cameroon	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Cameroon	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cameroon	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Cameroon	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cameroon	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Cameroon	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cameroon	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Cameroon	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Cameroon	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cameroon	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Cameroon	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Cameroon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Cameroon	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cameroon	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Cameroon	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Cameroon	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Cameroon	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Cameroon	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Cameroon	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Cameroon	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cameroon	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Cameroon	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Cameroon	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Cameroon	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Cameroon	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cameroon	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cameroon	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cameroon	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cameroon	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cameroon	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cameroon	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Cameroon	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Cameroon	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Cameroon	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Cameroon	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cameroon	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Cameroon	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Cameroon	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Cameroon	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Cameroon	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Cameroon	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Cameroon	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Cameroon	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Cameroon	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Cameroon	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Cameroon	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Cameroon	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Cameroon	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Cameroon	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Cameroon	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Cameroon	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Cameroon	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Cameroon	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Cameroon	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Cameroon	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Cameroon	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Cameroon	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Cameroon	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Cameroon	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Cameroon	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Cameroon	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cameroon	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Cameroon	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Cameroon	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Cameroon	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Cameroon	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Cameroon	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cameroon	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Cameroon	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Cameroon	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Cameroon	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Cameroon	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cameroon	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cameroon	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Cameroon	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Cameroon	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cameroon	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Cameroon	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Cameroon	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Cameroon	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Cameroon	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cameroon	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Cameroon	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	

Xtool

Cameroon	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cameroon	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Cameroon	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Cameroon	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Cameroon	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cameroon	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Cameroon	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Cameroon	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Cameroon	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cameroon	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Cameroon	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Cameroon	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Cameroon	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Cameroon	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cameroon	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Cameroon	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Cameroon	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Cameroon	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Cameroon	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Cameroon	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cameroon	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Cameroon	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Cameroon	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Cameroon	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Cameroon	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cameroon	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cameroon	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Cameroon	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Cameroon	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cameroon	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Cameroon	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Cameroon	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Cameroon	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Cameroon	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Cameroon	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Cameroon	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Cameroon	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cameroon	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Cameroon	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Cameroon	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Cameroon	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Cameroon	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Cameroon	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cameroon	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Cameroon	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Cameroon	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Cameroon	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Cameroon	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		

Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cameroon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cameroon	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cameroon	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Cameroon	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Cameroon	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Cameroon	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Cameroon	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Cameroon	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Cameroon	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cameroon	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Cameroon	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Cameroon	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Cameroon	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Cameroon	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cameroon	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cameroon	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Cameroon	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Cameroon	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cameroon	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Cameroon	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Cameroon	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Cameroon	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cameroon	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Cameroon	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Cameroon	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cameroon	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cameroon	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Cameroon	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cameroon	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Cameroon	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cameroon	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Cameroon	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Cameroon	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Cameroon	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Cameroon	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Cameroon	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cameroon	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Cameroon	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cameroon	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Cameroon	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cameroon	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cameroon	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Cameroon	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Cameroon	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Cameroon	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cameroon	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Cameroon	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Cameroon	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Cameroon	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Cameroon	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cameroon	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Cameroon	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Cameroon	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Cameroon	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Cameroon	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Cameroon	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Cameroon	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cameroon	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cameroon	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Cameroon	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cameroon	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Cameroon	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Cameroon	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cameroon	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cameroon	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Cameroon	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Cameroon	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cameroon	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cameroon	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Cameroon	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Cameroon	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Cameroon	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cameroon	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Cameroon	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Cameroon	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cameroon	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cameroon	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Cameroon	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Cameroon	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cameroon	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Cameroon	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Cameroon	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cameroon	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Cameroon	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cameroon	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Cameroon	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cameroon	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Cameroon	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Cameroon	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cameroon	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Cameroon	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Cameroon	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Cameroon	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Cameroon	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Cameroon	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Cameroon	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Cameroon	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cameroon	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Cameroon	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Cameroon	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Cameroon	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cameroon	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Cameroon	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Cameroon	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Cameroon	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Cameroon	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Cameroon	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Cameroon	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cameroon	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Cameroon	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cameroon	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Cameroon	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Cameroon	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Cameroon	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Cameroon	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Canada	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Air bag	√	√	√	√		
Canada	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	
Canada	INFINITI EX35	J50	2008.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI EX35	J50	2008.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI EX35	J50	2008.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI EX35	J50	2008.NULL	Air bag	√	√	√	√		
Canada	INFINITI EX35	J50	2008.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Canada	INFINITI EX35	J50	2008.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Canada	INFINITI EX35	J50	2008.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Canada	INFINITI EX35	J50	2008.NULL_	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Canada	INFINITI EX35	J50	2008.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI EX35	J50	2008.NULL_	Multi AV	√	√	√	√		SP0503
Canada	INFINITI EX35	J50	2008.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI EX35	J50	2008.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Canada	INFINITI EX35	J50	2008.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI EX35	J50	2008.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Canada	INFINITI EX35	J50	2008.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI EX35	J50	2008.NULL	CAN gateway	√	√	√			
Canada	INFINITI EX35	J50	2008.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Canada	INFINITI EX35	J50	2008.NULL	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Canada	INFINITI EX35	J50	2008.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI EX35	J50	2008.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI EX35	J50	2008.NULL	Rearview camera	√			√		SP0570, SP0571
Canada	INFINITI FX35/FX45	S50	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Canada	INFINITI FX35/FX45	S50	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Canada	INFINITI FX35/FX45	S50	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI FX35/FX45	S50	2003.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Canada	INFINITI FX35/FX45	S50	2003.NULL	Air bag	√	√	√	√		
Canada	INFINITI FX35/FX45	S50	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Canada	INFINITI FX35/FX45	S50	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Canada	INFINITI FX35/FX45	S50	2003.NULL	Motor control						
Canada	INFINITI FX35/FX45	S50	2003.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI FX35/FX45	S50	2003.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Canada	INFINITI FX35/FX45	S50	2003.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Canada	INFINITI FX35/FX45	S50	2003.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI FX35/FX45	S50	2003.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI FX35/FX45	S50	2003.NULL	HVAC	√	√	√	√		
Canada	INFINITI FX35/FX45	S50	2003.NULL	Difference lock	√	√	√	√		
Canada	INFINITI FX35/FX45	S50	2003.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI FX35/FX45	S50	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Canada	INFINITI FX35/FX45	S50	2003.NULL	DIU		√	√	√		
Canada	INFINITI FX35/FX45	S50	2003.NULL	Adaptive light	√	√	√	√		
Canada	INFINITI FX35/FX45	S50	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI FX35/FX45	S50	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Canada	INFINITI FX35/FX45	S50	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI FX35/FX45	S50	2003.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Canada	INFINITI FX35/FX45	S50	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Canada	INFINITI FX35/FX45	S50	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI FX35/FX45	S50	2003.NULL	IVMS	√	√		√		
Canada	INFINITI FX35/FX45	S50	2003.NULL	Distance control	√	√		√		
Canada	INFINITI FX35/FX45	S50	2003.NULL	Active suspense system	√	√	√	√		
Canada	INFINITI FX35/FX45	S50	2003.NULL	Motor assist		√	√	√		SP0574
Canada	INFINITI FX35/FX45	S50	2003.NULL	ASCD	√	√	√	√		
Canada	INFINITI FX35/FX45	S50	2003.NULL	Active engine mount	√	√	√	√		
Canada	INFINITI FX35/FX45	S50	2003.NULL	TCS	√	√	√	√		
Canada	INFINITI FX35/FX45	S50	2003.NULL	S/blind camera	√			√		SP0572, SP0573
Canada	INFINITI FX35/FX45	S50	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Canada	INFINITI FX35/FX45	S50	2003.NULL	Nats immu	√	√	√			
Canada	INFINITI FX35/FX45	S50	2003.NULL	Rearview camera	√			√		SP0570, SP0571
Canada	INFINITI FX35/FX45	S50	2003.NULL	Smart entrance						SP0568
Canada	INFINITI FX35/FX50	S51	2009.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Canada	INFINITI FX35/FX50	S51	2009.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI FX35/FX50	S51	2009.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Canada	INFINITI FX35/FX50	S51	2009.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI FX35/FX50	S51	2009.NULL	Air bag	√	√	√	√		
Canada	INFINITI FX35/FX50	S51	2009.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Canada	INFINITI FX35/FX50	S51	2009.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0045, SP0051, SP0053, SP0063, SP0064, SP0074, SP0079, SP0083, SP0085, SP0086, SP0087, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0225, SP0239
Canada	INFINITI FX35/FX50	S51	2009.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Canada	INFINITI FX35/FX50	S51	2009.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Canada	INFINITI FX35/FX50	S51	2009.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Canada	INFINITI FX35/FX50	S51	2009.NULL	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Canada	INFINITI FX35/FX50	S51	2009.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI FX35/FX50	S51	2009.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Canada	INFINITI FX35/FX50	S51	2009.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI FX35/FX50	S51	2009.NULL	Auto back door	√	√	√	√		SP0611
Canada	INFINITI FX35/FX50	S51	2009.NULL	Occupant detection			√	√		SP0584
Canada	INFINITI FX35/FX50	S51	2009.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Canada	INFINITI FX35/FX50	S51	2009.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI FX35/FX50	S51	2009.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Canada	INFINITI FX35/FX50	S51	2009.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI FX35/FX50	S51	2009.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI FX35/FX50	S51	2009.NULL	CAN gateway	√	√	√			
Canada	INFINITI FX35/FX50	S51	2009.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Canada	INFINITI FX35/FX50	S51	2009.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI FX35/FX50	S51	2009.NULL	Rearview camera	√			√		SP0570, SP0571
Canada	INFINITI FX37/FX50	S51	2013.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Canada	INFINITI FX37/FX50	S51	2013.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Canada	INFINITI FX37/FX50	S51	2013.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI FX37/FX50	S51	2013.NULL	Air bag	√	√	√	√		
Canada	INFINITI FX37/FX50	S51	2013.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
Canada	INFINITI FX37/FX50	S51	2013.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Canada	INFINITI FX37/FX50	S51	2013.NULL	Transmission	√	√	√	√		SP0274
Canada	INFINITI FX37/FX50	S51	2013.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Canada	INFINITI FX37/FX50	S51	2013.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Canada	INFINITI FX37/FX50	S51	2013.NULL	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Canada	INFINITI FX37/FX50	S51	2013.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI FX37/FX50	S51	2013.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	

Canada	INFINITI FX37/FX50	S51	2013.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI FX37/FX50	S51	2013.NULL	Auto back door	√	√	√	√		SP0611
Canada	INFINITI FX37/FX50	S51	2013.NULL	Occupant detection			√	√		SP0584
Canada	INFINITI FX37/FX50	S51	2013.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Canada	INFINITI FX37/FX50	S51	2013.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI FX37/FX50	S51	2013.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Canada	INFINITI FX37/FX50	S51	2013.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI FX37/FX50	S51	2013.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI FX37/FX50	S51	2013.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI FX37/FX50	S51	2013.NULL	CAN gateway	√	√	√			
Canada	INFINITI FX37/FX50	S51	2013.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Canada	INFINITI FX37/FX50	S51	2013.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI G20	CA33	2002.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Canada	INFINITI G20	CA33	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Canada	INFINITI G20	CA33	2002.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI G20	CA33	2002.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Canada	INFINITI G20	CA33	2002.NULL	Air bag	√	√	√	√		
Canada	INFINITI G20	CA33	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Canada	INFINITI G20	CA33	2002.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Canada	INFINITI G20	CA33	2002.NULL	Motor control						
Canada	INFINITI G20	CA33	2002.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI G20	CA33	2002.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Canada	INFINITI G20	CA33	2002.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Canada	INFINITI G20	CA33	2002.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI G20	CA33	2002.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI G20	CA33	2002.NULL	HVAC	√	√	√	√		
Canada	INFINITI G20	CA33	2002.NULL	Difference lock	√	√	√	√		
Canada	INFINITI G20	CA33	2002.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI G20	CA33	2002.NULL	Auto slide door	√	√	√	√	AC0941	
Canada	INFINITI G20	CA33	2002.NULL	DIU		√	√	√		
Canada	INFINITI G20	CA33	2002.NULL	Adaptive light	√	√	√	√		
Canada	INFINITI G20	CA33	2002.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI G20	CA33	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Canada	INFINITI G20	CA33	2002.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI G20	CA33	2002.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Canada	INFINITI G20	CA33	2002.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Canada	INFINITI G20	CA33	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI G20	CA33	2002.NULL	IVMS	√	√		√		
Canada	INFINITI G20	CA33	2002.NULL	Distance control	√	√		√		
Canada	INFINITI G20	CA33	2002.NULL	Active suspense system	√	√	√	√		
Canada	INFINITI G20	CA33	2002.NULL	Motor assist		√	√	√		SP0574
Canada	INFINITI G20	CA33	2002.NULL	ASCD	√	√	√	√		
Canada	INFINITI G20	CA33	2002.NULL	Active engine mount	√	√	√	√		
Canada	INFINITI G20	CA33	2002.NULL	TCS	√	√	√	√		
Canada	INFINITI G20	CA33	2002.NULL	S/blind camera	√			√		SP0572, SP0573
Canada	INFINITI G20	CA33	2002.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Canada	INFINITI G20	CA33	2002.NULL	Nats immu	√	√	√			
Canada	INFINITI G20	CA33	2002.NULL	Rearview camera	√			√		SP0570, SP0571
Canada	INFINITI G20	CA33	2002.NULL	Smart entrance						SP0568
Canada	INFINITI G20	P11	1999.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Canada	INFINITI G20	P11	1999.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Canada	INFINITI G20	P11	1999.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI G20	P11	1999.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Canada	INFINITI G20	P11	1999.NULL	Air bag	√	√	√	√		
Canada	INFINITI G20	P11	1999.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Canada	INFINITI G20	P11	1999.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Canada	INFINITI G20	P11	1999.NULL	Motor control						
Canada	INFINITI G20	P11	1999.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI G20	P11	1999.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Canada	INFINITI G20	P11	1999.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Canada	INFINITI G20	P11	1999.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI G20	P11	1999.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI G20	P11	1999.NULL	HVAC	√	√	√	√		
Canada	INFINITI G20	P11	1999.NULL	Difference lock	√	√	√	√		
Canada	INFINITI G20	P11	1999.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI G20	P11	1999.NULL	Auto slide door	√	√	√	√	AC0941	
Canada	INFINITI G20	P11	1999.NULL	DIU		√	√	√		
Canada	INFINITI G20	P11	1999.NULL	Adaptive light	√	√	√	√		
Canada	INFINITI G20	P11	1999.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI G20	P11	1999.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Canada	INFINITI G20	P11	1999.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI G20	P11	1999.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Canada	INFINITI G20	P11	1999.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Canada	INFINITI G20	P11	1999.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI G20	P11	1999.NULL	IVMS	√	√		√		
Canada	INFINITI G20	P11	1999.NULL	Distance control	√	√		√		
Canada	INFINITI G20	P11	1999.NULL	Active suspense system	√	√	√	√		
Canada	INFINITI G20	P11	1999.NULL	Motor assist		√	√	√		SP0574
Canada	INFINITI G20	P11	1999.NULL	ASCD	√	√	√	√		
Canada	INFINITI G20	P11	1999.NULL	Active engine mount	√	√	√	√		
Canada	INFINITI G20	P11	1999.NULL	TCS	√	√	√	√		
Canada	INFINITI G20	P11	1999.NULL	S/blind camera	√			√		SP0572, SP0573
Canada	INFINITI G20	P11	1999.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Canada	INFINITI G20	P11	1999.NULL	Nats immu	√	√	√			
Canada	INFINITI G20	P11	1999.NULL	Rearview camera	√			√		SP0570, SP0571
Canada	INFINITI G20	P11	1999.NULL	Smart entrance						SP0568
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Air bag	√	√	√	√		

Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Transmission	√	√	√	√		SP0274
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Pop up hood	√	√	√	√		
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Multi AV	√	√	√	√		SP0503
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Precrash seatbelt	√	√	√	√		
Canada	INFINITI G25/G37 SEDAN	V36	2011.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Canada	INFINITI G35 COUPE	CV35	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI G35 COUPE	CV35	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Air bag	√	√	√	√		
Canada	INFINITI G35 COUPE	CV35	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Motor control						
Canada	INFINITI G35 COUPE	CV35	2003.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI G35 COUPE	CV35	2003.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Canada	INFINITI G35 COUPE	CV35	2003.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Canada	INFINITI G35 COUPE	CV35	2003.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI G35 COUPE	CV35	2003.NULL	HVAC	√	√	√	√		
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Difference lock	√	√	√	√		
Canada	INFINITI G35 COUPE	CV35	2003.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Canada	INFINITI G35 COUPE	CV35	2003.NULL	DIU		√	√	√		
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Adaptive light	√	√	√	√		
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI G35 COUPE	CV35	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Canada	INFINITI G35 COUPE	CV35	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI G35 COUPE	CV35	2003.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Canada	INFINITI G35 COUPE	CV35	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI G35 COUPE	CV35	2003.NULL	IVMS	√	√		√		
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Distance control	√	√		√		
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Active suspense system	√	√	√	√		
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Motor assist		√	√	√		SP0574
Canada	INFINITI G35 COUPE	CV35	2003.NULL	ASCD	√	√	√	√		
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Active engine mount	√	√	√	√		
Canada	INFINITI G35 COUPE	CV35	2003.NULL	TCS	√	√	√	√		
Canada	INFINITI G35 COUPE	CV35	2003.NULL	S/blind camera	√			√		SP0572, SP0573
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Nats immu	√	√	√			
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Rearview camera	√			√		SP0570, SP0571
Canada	INFINITI G35 COUPE	CV35	2003.NULL	Smart entrance						SP0568
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Canada	INFINITI G35 SEDAN	V35	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI G35 SEDAN	V35	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Air bag	√	√	√	√		
Canada	INFINITI G35 SEDAN	V35	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Motor control						
Canada	INFINITI G35 SEDAN	V35	2003.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI G35 SEDAN	V35	2003.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Canada	INFINITI G35 SEDAN	V35	2003.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Canada	INFINITI G35 SEDAN	V35	2003.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI G35 SEDAN	V35	2003.NULL	HVAC	√	√	√	√		
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Difference lock	√	√	√	√		
Canada	INFINITI G35 SEDAN	V35	2003.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Canada	INFINITI G35 SEDAN	V35	2003.NULL	DIU		√	√	√		
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Adaptive light	√	√	√	√		
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI G35 SEDAN	V35	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Canada	INFINITI G35 SEDAN	V35	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI G35 SEDAN	V35	2003.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Canada	INFINITI G35 SEDAN	V35	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

Canada	INFINITI G35 SEDAN	V35	2003.NULL	IVMS	√	√		√		
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Distance control	√	√		√		
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Active suspense system	√	√	√	√		
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Motor assist		√	√	√		SP0574
Canada	INFINITI G35 SEDAN	V35	2003.NULL	ASCD	√	√	√	√		
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Active engine mount	√	√	√	√		
Canada	INFINITI G35 SEDAN	V35	2003.NULL	TCS	√	√	√	√		
Canada	INFINITI G35 SEDAN	V35	2003.NULL	S/blind camera	√			√		SP0572, SP0573
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Nats immu	√	√	√			
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Rearview camera	√			√		SP0570, SP0571
Canada	INFINITI G35 SEDAN	V35	2003.NULL	Smart entrance						SP0568
Canada	INFINITI G35 SEDAN	V36	2007.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI G35 SEDAN	V36	2007.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Canada	INFINITI G35 SEDAN	V36	2007.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI G35 SEDAN	V36	2007.NULL	Air bag	√	√	√	√		
Canada	INFINITI G35 SEDAN	V36	2007.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Canada	INFINITI G35 SEDAN	V36	2007.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Canada	INFINITI G35 SEDAN	V36	2007.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Canada	INFINITI G35 SEDAN	V36	2007.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Canada	INFINITI G35 SEDAN	V36	2007.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Canada	INFINITI G35 SEDAN	V36	2007.NULL	Multi AV	√	√	√	√		
Canada	INFINITI G35 SEDAN	V36	2007.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Canada	INFINITI G35 SEDAN	V36	2007.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI G35 SEDAN	V36	2007.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Canada	INFINITI G35 SEDAN	V36	2007.NULL	All mode AWD/4WD	√	√	√	√	AC0957	
Canada	INFINITI G35 SEDAN	V36	2007.NULL	Precrash seatbelt	√	√	√	√		
Canada	INFINITI G35 SEDAN	V36	2007.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Air bag	√	√	√	√		
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Pop up hood	√	√	√	√		
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Multi AV	√	√	√	√		SP0503
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	4WAS(front)	√	√	√	√	AC1027, AC1028	
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Precrash seatbelt	√	√	√	√		
Canada	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI G37 COUPE	CV36	2008.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI G37 COUPE	CV36	2008.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Canada	INFINITI G37 COUPE	CV36	2008.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI G37 COUPE	CV36	2008.NULL	Air bag	√	√	√	√		
Canada	INFINITI G37 COUPE	CV36	2008.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Canada	INFINITI G37 COUPE	CV36	2008.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI G37 COUPE	CV36	2008.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Canada	INFINITI G37 COUPE	CV36	2008.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Canada	INFINITI G37 COUPE	CV36	2008.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Canada	INFINITI G37 COUPE	CV36	2008.NULL	Pop up hood	√	√	√	√		
Canada	INFINITI G37 COUPE	CV36	2008.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI G37 COUPE	CV36	2008.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Canada	INFINITI G37 COUPE	CV36	2008.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI G37 COUPE	CV36	2008.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Canada	INFINITI G37 COUPE	CV36	2008.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Canada	INFINITI G37 COUPE	CV36	2008.NULL	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Canada	INFINITI G37 COUPE	CV36	2008.NULL	Precrash seatbelt	√	√	√	√		
Canada	INFINITI G37 COUPE	CV36	2008.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI G37 SEDAN	V36	2009.NULL	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Canada	INFINITI G37 SEDAN	V36	2009.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Canada	INFINITI G37 SEDAN	V36	2009.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI G37 SEDAN	V36	2009.NULL	Air bag	√	√	√	√		
Canada	INFINITI G37 SEDAN	V36	2009.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Canada	INFINITI G37 SEDAN	V36	2009.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Canada	INFINITI G37 SEDAN	V36	2009.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Canada	INFINITI G37 SEDAN	V36	2009.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Canada	INFINITI G37 SEDAN	V36	2009.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Canada	INFINITI G37 SEDAN	V36	2009.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI G37 SEDAN	V36	2009.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Canada	INFINITI G37 SEDAN	V36	2009.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI G37 SEDAN	V36	2009.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Canada	INFINITI G37 SEDAN	V36	2009.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Canada	INFINITI G37 SEDAN	V36	2009.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI G37 SEDAN	V36	2009.NULL	Precrash seatbelt	√	√	√	√		
Canada	INFINITI G37 SEDAN	V36	2009.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI I30	CA32	1996.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Canada	INFINITI I30	CA32	1996.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Canada	INFINITI I30	CA32	1996.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI I30	CA32	1996.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	

Canada	INFINITI I30	CA32	1996.NULL	Air bag	√	√	√	√		
Canada	INFINITI I30	CA32	1996.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Canada	INFINITI I30	CA32	1996.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Canada	INFINITI I30	CA32	1996.NULL	Motor control						
Canada	INFINITI I30	CA32	1996.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Canada	INFINITI I30	CA32	1996.NULL_	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
Canada	INFINITI I30	CA32	1996.NULL_	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
Canada	INFINITI I30	CA32	1996.NULL_	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Canada	INFINITI I30	CA32	1996.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI I30	CA32	1996.NULL	HVAC	√	√	√	√		
Canada	INFINITI I30	CA32	1996.NULL	Difference lock	√	√	√	√		
Canada	INFINITI I30	CA32	1996.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Canada	INFINITI I30	CA32	1996.NULL	Auto slide door	√	√	√	√	AC0941	
Canada	INFINITI I30	CA32	1996.NULL	DIU		√	√	√		
Canada	INFINITI I30	CA32	1996.NULL	Adaptive light	√	√	√	√		
Canada	INFINITI I30	CA32	1996.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Canada	INFINITI I30	CA32	1996.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Canada	INFINITI I30	CA32	1996.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Canada	INFINITI I30	CA32	1996.NULL_	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Canada	INFINITI I30	CA32	1996.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Canada	INFINITI I30	CA32	1996.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI I30	CA32	1996.NULL	IVMS	√	√		√		
Canada	INFINITI I30	CA32	1996.NULL	Distance control	√	√		√		
Canada	INFINITI I30	CA32	1996.NULL	Active suspense system	√	√	√	√		
Canada	INFINITI I30	CA32	1996.NULL	Motor assist		√	√	√		SP0574
Canada	INFINITI I30	CA32	1996.NULL	ASCD	√	√	√	√		
Canada	INFINITI I30	CA32	1996.NULL	Active engine mount	√	√	√	√		
Canada	INFINITI I30	CA32	1996.NULL	TCS	√	√	√	√		
Canada	INFINITI I30	CA32	1996.NULL	S/blind camera	√			√		SP0572,SP0573
Canada	INFINITI I30	CA32	1996.NULL	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Canada	INFINITI I30	CA32	1996.NULL	Nats immu	√	√	√			
Canada	INFINITI I30	CA32	1996.NULL	Rearview camera	√			√		SP0570,SP0571
Canada	INFINITI I30	CA32	1996.NULL	Smart entrance						SP0568
Canada	INFINITI I35	CA33	2002.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Canada	INFINITI I35	CA33	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
Canada	INFINITI I35	CA33	2002.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Canada	INFINITI I35	CA33	2002.NULL_	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Canada	INFINITI I35	CA33	2002.NULL	Air bag	√	√	√	√		
Canada	INFINITI I35	CA33	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Canada	INFINITI I35	CA33	2002.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Canada	INFINITI I35	CA33	2002.NULL	Motor control						
Canada	INFINITI I35	CA33	2002.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Canada	INFINITI I35	CA33	2002.NULL_	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
Canada	INFINITI I35	CA33	2002.NULL_	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
Canada	INFINITI I35	CA33	2002.NULL_	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Canada	INFINITI I35	CA33	2002.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI I35	CA33	2002.NULL	HVAC	√	√	√	√		
Canada	INFINITI I35	CA33	2002.NULL	Difference lock	√	√	√	√		
Canada	INFINITI I35	CA33	2002.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Canada	INFINITI I35	CA33	2002.NULL	Auto slide door	√	√	√	√	AC0941	
Canada	INFINITI I35	CA33	2002.NULL	DIU		√	√	√		
Canada	INFINITI I35	CA33	2002.NULL	Adaptive light	√	√	√	√		
Canada	INFINITI I35	CA33	2002.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Canada	INFINITI I35	CA33	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Canada	INFINITI I35	CA33	2002.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Canada	INFINITI I35	CA33	2002.NULL_	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Canada	INFINITI I35	CA33	2002.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Canada	INFINITI I35	CA33	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI I35	CA33	2002.NULL	IVMS	√	√		√		
Canada	INFINITI I35	CA33	2002.NULL	Distance control	√	√		√		
Canada	INFINITI I35	CA33	2002.NULL	Active suspense system	√	√	√	√		
Canada	INFINITI I35	CA33	2002.NULL	Motor assist		√	√	√		SP0574
Canada	INFINITI I35	CA33	2002.NULL	ASCD	√	√	√	√		
Canada	INFINITI I35	CA33	2002.NULL	Active engine mount	√	√	√	√		
Canada	INFINITI I35	CA33	2002.NULL	TCS	√	√	√	√		
Canada	INFINITI I35	CA33	2002.NULL	S/blind camera	√			√		SP0572,SP0573
Canada	INFINITI I35	CA33	2002.NULL	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Canada	INFINITI I35	CA33	2002.NULL	Nats immu	√	√	√			
Canada	INFINITI I35	CA33	2002.NULL	Rearview camera	√			√		SP0570,SP0571
Canada	INFINITI I35	CA33	2002.NULL	Smart entrance						SP0568
Canada	INFINITI JX35	L50	2013.NULL	Laser/radar	√	√	√	√		
Canada	INFINITI JX35	L50	2013.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI JX35	L50	2013.NULL_	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Canada	INFINITI JX35	L50	2013.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Canada	INFINITI JX35	L50	2013.NULL	Air bag	√	√	√	√		
Canada	INFINITI JX35	L50	2013.NULL	EPS/DAST 3	√	√	√	√		
Canada	INFINITI JX35	L50	2013.NULL	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Canada	INFINITI JX35	L50	2013.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Canada	INFINITI JX35	L50	2013.NULL_	Transmission	√	√	√	√	AC0439	SP0246,SP0276,SP0278,SP0279,SP0281,SP0282,SP0283,SP0287,SP0289,SP0290,SP0292
Canada	INFINITI JX35	L50	2013.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Canada	INFINITI JX35	L50	2013.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Canada	INFINITI JX35	L50	2013.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI JX35	L50	2013.NULL	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0487
Canada	INFINITI JX35	L50	2013.NULL	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Canada	INFINITI JX35	L50	2013.NULL	Auto back door	√	√	√	√		SP0611
Canada	INFINITI JX35	L50	2013.NULL	Occupant detection			√	√		SP0584

Canada	INFINITI JX35	L50	2013.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Canada	INFINITI JX35	L50	2013.NULL	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Canada	INFINITI JX35	L50	2013.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI JX35	L50	2013.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI JX35	L50	2013.NULL	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Canada	INFINITI JX35	L50	2013.NULL	CAN gateway	√	√	√			
Canada	INFINITI JX35	L50	2013.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Canada	INFINITI JX35	L50	2013.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI JX35	L50	2013.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Canada	INFINITI JX35	L50	2013.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI M35/M45	Y50	2006.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Canada	INFINITI M35/M45	Y50	2006.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Canada	INFINITI M35/M45	Y50	2006.NULL_	IPDM E/R	√	√	√	√	AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831,AC0856	
Canada	INFINITI M35/M45	Y50	2006.NULL	Air bag	√	√	√	√		
Canada	INFINITI M35/M45	Y50	2006.NULL	Meter/M&A		√	√	√		SP0347,SP0348,SP0349
Canada	INFINITI M35/M45	Y50	2006.NULL_	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Canada	INFINITI M35/M45	Y50	2006.NULL_	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Canada	INFINITI M35/M45	Y50	2006.NULL	BCM					AC0653,AC0698	SP0391,SP0393
Canada	INFINITI M35/M45	Y50	2006.NULL_	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Canada	INFINITI M35/M45	Y50	2006.NULL	Multi AV	√	√	√	√		
Canada	INFINITI M35/M45	Y50	2006.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Canada	INFINITI M35/M45	Y50	2006.NULL	Adaptive light	√	√	√	√		SP0561,SP0562
Canada	INFINITI M35/M45	Y50	2006.NULL	All mode AWD/4WD	√	√	√	√	AC0957	
Canada	INFINITI M35/M45	Y50	2006.NULL	Precrash seatbelt	√	√	√	√		
Canada	INFINITI M35/M45	Y50	2006.NULL_	Intelligent key	√	√	√	√	AC0911,AC0913,AC0915,AC0916,AC0917,AC0920,AC0922,AC0923,AC0924,AC0925,AC0926,AC0928	SP0511,SP0512,SP0518,SP0520,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0529,SP0530,SP0531,SP0532,SP0534,SP0535,SP0536,SP0537
Canada	INFINITI M35/M45	Y50	2006.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976	SP0560
Canada	INFINITI M35/M45	Y50	2006.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI M35H	HY51	2012.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Canada	INFINITI M35H	HY51	2012.NULL	Laser/radar	√	√	√	√		
Canada	INFINITI M35H	HY51	2012.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI M35H	HY51	2012.NULL_	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Canada	INFINITI M35H	HY51	2012.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Canada	INFINITI M35H	HY51	2012.NULL	Air bag	√	√	√	√		
Canada	INFINITI M35H	HY51	2012.NULL	EPS/DAST 3	√	√	√	√		
Canada	INFINITI M35H	HY51	2012.NULL	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Canada	INFINITI M35H	HY51	2012.NULL	Motor control	√	√	√	√		
Canada	INFINITI M35H	HY51	2012.NULL_	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Canada	INFINITI M35H	HY51	2012.NULL_	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274,SP0276
Canada	INFINITI M35H	HY51	2012.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Canada	INFINITI M35H	HY51	2012.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Canada	INFINITI M35H	HY51	2012.NULL	Diag data recorder	√					
Canada	INFINITI M35H	HY51	2012.NULL	Pop up hood	√	√	√	√		
Canada	INFINITI M35H	HY51	2012.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI M35H	HY51	2012.NULL_	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Canada	INFINITI M35H	HY51	2012.NULL	HV battery	√	√	√	√	AC1121	
Canada	INFINITI M35H	HY51	2012.NULL	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Canada	INFINITI M35H	HY51	2012.NULL	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Canada	INFINITI M35H	HY51	2012.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Canada	INFINITI M35H	HY51	2012.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Canada	INFINITI M35H	HY51	2012.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Canada	INFINITI M35H	HY51	2012.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI M35H	HY51	2012.NULL	CAN gateway	√	√	√			
Canada	INFINITI M35H	HY51	2012.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Canada	INFINITI M35H	HY51	2012.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI M35H	HY51	2012.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Canada	INFINITI M35H	HY51	2012.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI M35H	HY51	2012.NULL	Brake	√	√	√	√	AC1127	
Canada	INFINITI M35H	HY51	2012.NULL	VSP	√	√	√	√	AC1124,AC1125,AC1126	
Canada	INFINITI M37/M56	Y51	2011.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Canada	INFINITI M37/M56	Y51	2011.NULL	Laser/radar	√	√	√	√		
Canada	INFINITI M37/M56	Y51	2011.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI M37/M56	Y51	2011.NULL	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Canada	INFINITI M37/M56	Y51	2011.NULL_	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Canada	INFINITI M37/M56	Y51	2011.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Canada	INFINITI M37/M56	Y51	2011.NULL	Air bag	√	√	√	√		
Canada	INFINITI M37/M56	Y51	2011.NULL	EPS/DAST 3	√	√	√	√		
Canada	INFINITI M37/M56	Y51	2011.NULL	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Canada	INFINITI M37/M56	Y51	2011.NULL	Motor control	√	√	√	√		
Canada	INFINITI M37/M56	Y51	2011.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Canada	INFINITI M37/M56	Y51	2011.NULL_	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Canada	INFINITI M37/M56	Y51	2011.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Canada	INFINITI M37/M56	Y51	2011.NULL_	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Canada	INFINITI M37/M56	Y51	2011.NULL	Pop up hood	√	√	√	√		
Canada	INFINITI M37/M56	Y51	2011.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI M37/M56	Y51	2011.NULL_	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Canada	INFINITI M37/M56	Y51	2011.NULL	HV battery	√	√	√	√	AC1121	
Canada	INFINITI M37/M56	Y51	2011.NULL	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Canada	INFINITI M37/M56	Y51	2011.NULL	4WAS(front)	√	√	√	√	AC1027,AC1028	
Canada	INFINITI M37/M56	Y51	2011.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Canada	INFINITI M37/M56	Y51	2011.NULL	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Canada	INFINITI M37/M56	Y51	2011.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Canada	INFINITI M37/M56	Y51	2011.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Canada	INFINITI M37/M56	Y51	2011.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Canada	INFINITI M37/M56	Y51	2011.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI M37/M56	Y51	2011.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI M37/M56	Y51	2011.NULL	CAN gateway	√	√	√			
Canada	INFINITI M37/M56	Y51	2011.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Canada	INFINITI M37/M56	Y51	2011.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI M37/M56	Y51	2011.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI M37/M56	Y51	2011.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Canada	INFINITI M37/M56	Y51	2011.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI M37/M56	Y51	2011.NULL	VSP	√	√	√	√	AC1124,AC1125,AC1126	
Canada	INFINITI M45	Y34	2003.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Canada	INFINITI M45	Y34	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
Canada	INFINITI M45	Y34	2003.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Canada	INFINITI M45	Y34	2003.NULL_	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Canada	INFINITI M45	Y34	2003.NULL	Air bag	√	√	√	√		
Canada	INFINITI M45	Y34	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Canada	INFINITI M45	Y34	2003.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Canada	INFINITI M45	Y34	2003.NULL	Motor control						

Canada	INFINITI M45	Y34	2003.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI M45	Y34	2003.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Canada	INFINITI M45	Y34	2003.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Canada	INFINITI M45	Y34	2003.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI M45	Y34	2003.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI M45	Y34	2003.NULL	HVAC	√	√	√	√		
Canada	INFINITI M45	Y34	2003.NULL	Difference lock	√	√	√	√		
Canada	INFINITI M45	Y34	2003.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI M45	Y34	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Canada	INFINITI M45	Y34	2003.NULL	DIU		√	√	√		
Canada	INFINITI M45	Y34	2003.NULL	Adaptive light	√	√	√	√		
Canada	INFINITI M45	Y34	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI M45	Y34	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Canada	INFINITI M45	Y34	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI M45	Y34	2003.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Canada	INFINITI M45	Y34	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Canada	INFINITI M45	Y34	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI M45	Y34	2003.NULL	IVMS	√	√		√		
Canada	INFINITI M45	Y34	2003.NULL	Distance control	√	√		√		
Canada	INFINITI M45	Y34	2003.NULL	Active suspense system	√	√	√	√		
Canada	INFINITI M45	Y34	2003.NULL	Motor assist		√	√	√		SP0574
Canada	INFINITI M45	Y34	2003.NULL	ASCD	√	√	√	√		
Canada	INFINITI M45	Y34	2003.NULL	Active engine mount	√	√	√	√		
Canada	INFINITI M45	Y34	2003.NULL	TCS	√	√	√	√		
Canada	INFINITI M45	Y34	2003.NULL	S/blind camera	√			√		SP0572, SP0573
Canada	INFINITI M45	Y34	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Canada	INFINITI M45	Y34	2003.NULL	Nats immu	√	√	√			
Canada	INFINITI M45	Y34	2003.NULL	Rearview camera	√			√		SP0570, SP0571
Canada	INFINITI M45	Y34	2003.NULL	Smart entrance						SP0568
Canada	INFINITI Q40 SEDAN	V36	2015.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI Q40 SEDAN	V36	2015.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Canada	INFINITI Q40 SEDAN	V36	2015.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI Q40 SEDAN	V36	2015.NULL	Air bag	√	√	√	√		
Canada	INFINITI Q40 SEDAN	V36	2015.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Canada	INFINITI Q40 SEDAN	V36	2015.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0038, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Canada	INFINITI Q40 SEDAN	V36	2015.NULL	Transmission	√	√	√	√		SP0274
Canada	INFINITI Q40 SEDAN	V36	2015.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Canada	INFINITI Q40 SEDAN	V36	2015.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Canada	INFINITI Q40 SEDAN	V36	2015.NULL	Pop up hood	√	√	√	√		
Canada	INFINITI Q40 SEDAN	V36	2015.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI Q40 SEDAN	V36	2015.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI Q40 SEDAN	V36	2015.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Canada	INFINITI Q40 SEDAN	V36	2015.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI Q40 SEDAN	V36	2015.NULL	Precrash seatbelt	√	√	√	√		
Canada	INFINITI Q45	F50	2002.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Canada	INFINITI Q45	F50	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Canada	INFINITI Q45	F50	2002.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI Q45	F50	2002.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Canada	INFINITI Q45	F50	2002.NULL	Air bag	√	√	√	√		
Canada	INFINITI Q45	F50	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Canada	INFINITI Q45	F50	2002.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Canada	INFINITI Q45	F50	2002.NULL	Motor control						
Canada	INFINITI Q45	F50	2002.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI Q45	F50	2002.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Canada	INFINITI Q45	F50	2002.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Canada	INFINITI Q45	F50	2002.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI Q45	F50	2002.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI Q45	F50	2002.NULL	HVAC	√	√	√	√		
Canada	INFINITI Q45	F50	2002.NULL	Difference lock	√	√	√	√		
Canada	INFINITI Q45	F50	2002.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI Q45	F50	2002.NULL	Auto slide door	√	√	√	√	AC0941	
Canada	INFINITI Q45	F50	2002.NULL	DIU		√	√	√		
Canada	INFINITI Q45	F50	2002.NULL	Adaptive light	√	√	√	√		
Canada	INFINITI Q45	F50	2002.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI Q45	F50	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Canada	INFINITI Q45	F50	2002.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI Q45	F50	2002.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Canada	INFINITI Q45	F50	2002.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Canada	INFINITI Q45	F50	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI Q45	F50	2002.NULL	IVMS	√	√		√		
Canada	INFINITI Q45	F50	2002.NULL	Distance control	√	√		√		
Canada	INFINITI Q45	F50	2002.NULL	Active suspense system	√	√	√	√		
Canada	INFINITI Q45	F50	2002.NULL	Motor assist		√	√	√		SP0574
Canada	INFINITI Q45	F50	2002.NULL	ASCD	√	√	√	√		
Canada	INFINITI Q45	F50	2002.NULL	Active engine mount	√	√	√	√		
Canada	INFINITI Q45	F50	2002.NULL	TCS	√	√	√	√		
Canada	INFINITI Q45	F50	2002.NULL	S/blind camera	√			√		SP0572, SP0573
Canada	INFINITI Q45	F50	2002.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Canada	INFINITI Q45	F50	2002.NULL	Nats immu	√	√	√			
Canada	INFINITI Q45	F50	2002.NULL	Rearview camera	√			√		SP0570, SP0571
Canada	INFINITI Q45	F50	2002.NULL	Smart entrance						SP0568
Canada	INFINITI Q45	FY33	1995.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Canada	INFINITI Q45	FY33	1995.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Canada	INFINITI Q45	FY33	1995.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI Q45	FY33	1995.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Canada	INFINITI Q45	FY33	1995.NULL	Air bag	√	√	√	√		
Canada	INFINITI Q45	FY33	1995.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Canada	INFINITI Q45	FY33	1995.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Canada	INFINITI Q45	FY33	1995.NULL	Motor control						

Canada	INFINITI Q45	FY33	1995.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI Q45	FY33	1995.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Canada	INFINITI Q45	FY33	1995.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Canada	INFINITI Q45	FY33	1995.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI Q45	FY33	1995.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI Q45	FY33	1995.NULL	HVAC	√	√	√	√		
Canada	INFINITI Q45	FY33	1995.NULL	Difference lock	√	√	√	√		
Canada	INFINITI Q45	FY33	1995.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI Q45	FY33	1995.NULL	Auto slide door	√	√	√	√	AC0941	
Canada	INFINITI Q45	FY33	1995.NULL	DIU		√	√	√		
Canada	INFINITI Q45	FY33	1995.NULL	Adaptive light	√	√	√	√		
Canada	INFINITI Q45	FY33	1995.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI Q45	FY33	1995.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Canada	INFINITI Q45	FY33	1995.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI Q45	FY33	1995.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Canada	INFINITI Q45	FY33	1995.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Canada	INFINITI Q45	FY33	1995.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI Q45	FY33	1995.NULL	IVMS	√	√		√		
Canada	INFINITI Q45	FY33	1995.NULL	Distance control	√	√		√		
Canada	INFINITI Q45	FY33	1995.NULL	Active suspense system	√	√	√	√		
Canada	INFINITI Q45	FY33	1995.NULL	Motor assist		√	√	√		SP0574
Canada	INFINITI Q45	FY33	1995.NULL	ASCD	√	√	√	√		
Canada	INFINITI Q45	FY33	1995.NULL	Active engine mount	√	√	√	√		
Canada	INFINITI Q45	FY33	1995.NULL	TCS	√	√	√	√		
Canada	INFINITI Q45	FY33	1995.NULL	S/blind camera	√			√		SP0572, SP0573
Canada	INFINITI Q45	FY33	1995.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Canada	INFINITI Q45	FY33	1995.NULL	Nats immu	√	√	√			
Canada	INFINITI Q45	FY33	1995.NULL	Rearview camera	√			√		SP0570, SP0571
Canada	INFINITI Q45	FY33	1995.NULL	Smart entrance						SP0568
Canada	INFINITI Q50	V37	2019.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Canada	INFINITI Q50	V37	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Canada	INFINITI Q50	V37	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI Q50	V37	2019.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Canada	INFINITI Q50	V37	2019.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI Q50	V37	2019.NULL	Air bag	√	√	√	√		
Canada	INFINITI Q50	V37	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
Canada	INFINITI Q50	V37	2019.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Canada	INFINITI Q50	V37	2019.NULL	Motor control	√	√	√	√		
Canada	INFINITI Q50	V37	2019.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI Q50	V37	2019.NULL	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Canada	INFINITI Q50	V37	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Canada	INFINITI Q50	V37	2019.NULL_	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Canada	INFINITI Q50	V37	2019.NULL	Pop up hood	√	√	√	√		
Canada	INFINITI Q50	V37	2019.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI Q50	V37	2019.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Canada	INFINITI Q50	V37	2019.NULL	HV battery	√	√	√	√	AC1121	
Canada	INFINITI Q50	V37	2019.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Canada	INFINITI Q50	V37	2019.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Canada	INFINITI Q50	V37	2019.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI Q50	V37	2019.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Canada	INFINITI Q50	V37	2019.NULL	Occupant detection			√	√		SP0584
Canada	INFINITI Q50	V37	2019.NULL	Shift	√	√	√	√		SP0613
Canada	INFINITI Q50	V37	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Canada	INFINITI Q50	V37	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI Q50	V37	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI Q50	V37	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI Q50	V37	2019.NULL	DAST 2	√	√	√	√		
Canada	INFINITI Q50	V37	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI Q50	V37	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI Q50	V37	2019.NULL	CAN gateway	√	√	√			
Canada	INFINITI Q50	V37	2019.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Canada	INFINITI Q50	V37	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI Q50	V37	2019.NULL	DAST 1	√	√	√	√		
Canada	INFINITI Q50	V37	2019.NULL_	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Canada	INFINITI Q50	V37	2019.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Canada	INFINITI Q50	V37	2019.NULL	ANC	√	√	√	√	AC1024	
Canada	INFINITI Q50	V37	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI Q50	V37	2019.NULL	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Canada	INFINITI Q50	V37	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Canada	INFINITI Q50	V37	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
Canada	INFINITI Q50	V37	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI Q50	V37	2019.NULL	Brake	√	√	√	√	AC1127	
Canada	INFINITI Q50	V37	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Canada	INFINITI Q50	V37	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
Canada	INFINITI Q50	V37	2019.NULL	ICC/ADAS 2	√	√	√	√		
Canada	INFINITI Q50	V37	2019.NULL	FSCM	√	√	√	√	AC1109	
Canada	INFINITI Q50	V37	2019.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Laser/radar	√	√	√	√		
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Air bag	√	√	√	√		
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Motor control	√	√	√	√		
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Transmission	√	√	√	√		SP0274, SP0276
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL_	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Pop up hood	√	√	√	√		
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Multi AV	√	√	√	√		SP0503

Canada	INFINITI Q50 HYBRID	HV37	2014.NULL
-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	HV battery	√	√	√	√	AC1121	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL
-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Occupant detection			√	√		SP0584
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Shift	√	√	√	√		SP0613
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	DAST 2	√	√	√	√		
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	CAN gateway	√	√	√			
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	DAST 1	√	√	√	√		
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL
-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	ANC	√	√	√	√	AC1024	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	HIGH BEAM ASSIST	√	√	√	√		
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	Brake	√	√	√	√	AC1127	
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	6ch CAN GATEWAY	√	√	√	√		
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	3ch CAN GATEWAY	√	√	√	√		
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	ICC/ADAS 2	√	√	√	√		
Canada	INFINITI Q50 HYBRID	HV37	2014.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Laser/radar	√	√	√	√		
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Air bag	√	√	√	√		
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	EPS/DAST 3	√	√	√	√		
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Motor control	√	√	√	√		
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Transmission	√	√	√	√		SP0276
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Pop up hood	√	√	√	√		
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Multi AV	√	√	√	√		SP0503
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	HV battery	√	√	√	√	AC1121	
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Occupant detection			√	√		SP0584
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 2	√	√	√	√		
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Lane camera	√	√	√	√		
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 1	√	√	√	√		
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	ANC	√	√	√	√	AC1024	
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	HIGH BEAM ASSIST	√	√	√	√		
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√		
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	Brake	√	√	√	√	AC1127	
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	6ch CAN GATEWAY	√	√	√	√		
Canada	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Canada	INFINITI Q60	CV37	2019.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Canada	INFINITI Q60	CV37	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Canada	INFINITI Q60	CV37	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI Q60	CV37	2019.NULL
-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Canada	INFINITI Q60	CV37	2019.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI Q60	CV37	2019.NULL	Air bag	√	√	√	√		
Canada	INFINITI Q60	CV37	2019.NULL	EPS/DAST 3	√	√	√	√		
Canada	INFINITI Q60	CV37	2019.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Canada	INFINITI Q60	CV37	2019.NULL
-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI Q60	CV37	2019.NULL	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Canada	INFINITI Q60	CV37	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Canada	INFINITI Q60	CV37	2019.NULL
-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Canada	INFINITI Q60	CV37	2019.NULL	Pop up hood	√	√	√	√		
Canada	INFINITI Q60	CV37	2019.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI Q60	CV37	2019.NULL
-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Canada	INFINITI Q60	CV37	2019.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Canada	INFINITI Q60	CV37	2019.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI Q60	CV37	2019.NULL	Occupant detection			√	√		SP0584
Canada	INFINITI Q60	CV37	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Canada	INFINITI Q60	CV37	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI Q60	CV37	2019.NULL	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Canada	INFINITI Q60	CV37	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI Q60	CV37	2019.NULL	DAST 2	√	√	√	√		
Canada	INFINITI Q60	CV37	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI Q60	CV37	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI Q60	CV37	2019.NULL	CAN gateway	√	√	√			
Canada	INFINITI Q60	CV37	2019.NULL	Lane camera	√	√	√	√		
Canada	INFINITI Q60	CV37	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI Q60	CV37	2019.NULL	DAST 1	√	√	√	√		
Canada	INFINITI Q60	CV37	2019.NULL
-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Canada	INFINITI Q60	CV37	2019.NULL	ANC	√	√	√	√	AC1024	

Canada	INFINITI Q60	CV37	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI Q60	CV37	2019.NULL	EMCM	√	√	√	√	AC1111.AC1112	SP0608.SP0609.SP0610
Canada	INFINITI Q60	CV37	2019.NULL	Telematics	√	√	√	√		SP0590.SP0591.SP0592
Canada	INFINITI Q60	CV37	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
Canada	INFINITI Q60	CV37	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI Q60	CV37	2019.NULL	Lane camera 2	√	√	√	√		
Canada	INFINITI Q60	CV37	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Canada	INFINITI Q60	CV37	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
Canada	INFINITI Q60	CV37	2019.NULL	ICC/ADAS 2	√	√	√	√		
Canada	INFINITI Q60	CV37	2019.NULL	FSCM	√	√	√	√	AC1109	
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Air bag	√	√	√	√		
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Transmission	√	√	√	√		SP0274
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Pop up hood	√	√	√	√		
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Multi AV	√	√	√	√		SP0503
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Canada	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Precrash seatbelt	√	√	√	√		
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	Air bag	√	√	√	√		
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	Meter/M&A	√	√	√	√		SP0347.SP0348.SP0349.SP0350
Canada	INFINITI Q60 COUPE	CV36	2014.NULL _	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	Transmission	√	√	√	√		SP0274
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Canada	INFINITI Q60 COUPE	CV36	2014.NULL _	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	Pop up hood	√	√	√	√		
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI Q60 COUPE	CV36	2014.NULL _	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI Q60 COUPE	CV36	2014.NULL	Precrash seatbelt	√	√	√	√		
Canada	INFINITI Q70	Y51	2019.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Canada	INFINITI Q70	Y51	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Canada	INFINITI Q70	Y51	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI Q70	Y51	2019.NULL _	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Canada	INFINITI Q70	Y51	2019.NULL	IPDM E/R	√	√	√	√	AC0811.AC0815.AC0816.AC0817.AC0818.AC0819.AC0821.AC0822.AC0825.AC0831	
Canada	INFINITI Q70	Y51	2019.NULL	Air bag	√	√	√	√		
Canada	INFINITI Q70	Y51	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
Canada	INFINITI Q70	Y51	2019.NULL	Meter/M&A	√	√	√	√		SP0348.SP0349.SP0350.SP0351
Canada	INFINITI Q70	Y51	2019.NULL _	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Canada	INFINITI Q70	Y51	2019.NULL _	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0247,SP0265,SP0270,SP0274
Canada	INFINITI Q70	Y51	2019.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Canada	INFINITI Q70	Y51	2019.NULL _	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Canada	INFINITI Q70	Y51	2019.NULL	Pop up hood	√	√	√	√		
Canada	INFINITI Q70	Y51	2019.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI Q70	Y51	2019.NULL _	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Canada	INFINITI Q70	Y51	2019.NULL	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Canada	INFINITI Q70	Y51	2019.NULL	4WAS(front)	√	√	√	√	AC1027,AC1028	
Canada	INFINITI Q70	Y51	2019.NULL _	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Canada	INFINITI Q70	Y51	2019.NULL	Occupant detection			√	√		SP0584
Canada	INFINITI Q70	Y51	2019.NULL	Adaptive light	√	√	√	√	AC0978.AC0979.AC0980.AC0981.AC0982	SP0561.SP0562
Canada	INFINITI Q70	Y51	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029.AC1030	
Canada	INFINITI Q70	Y51	2019.NULL	Sonar	√	√	√	√	AC0962.AC0963.AC0964.AC0966.AC0967.AC0968.AC0969.AC0970	SP0553.SP0554.SP0555.SP0556.SP0557.SP0558.SP0559
Canada	INFINITI Q70	Y51	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI Q70	Y51	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI Q70	Y51	2019.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Canada	INFINITI Q70	Y51	2019.NULL	CAN gateway	√	√	√			
Canada	INFINITI Q70	Y51	2019.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0976,AC0977	
Canada	INFINITI Q70	Y51	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI Q70	Y51	2019.NULL	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Canada	INFINITI Q70	Y51	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI Q70	Y51	2019.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Canada	INFINITI Q70	Y51	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI Q70	Y51	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Canada	INFINITI Q70	Y51	2019.NULL	ICC/ADAS 2	√	√	√	√		
Canada	INFINITI Q70	Y51	2019.NULL	FSCM	√	√	√	√	AC1109	
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Laser/radar	√	√	√	√	AC0994	
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Air bag	√	√	√	√		
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	EPS/DAST 3	√	√	√	√		
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Motor control	√	√	√	√		
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	BCM				√	AC0613, AC0618, AC0653, AC0663, AC0690, AC0692, AC0698, AC0702	SP0372, SP0429, SP0471
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Pop up hood	√	√	√	√		
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	HV battery	√	√	√	√	AC1121	
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	EV/HEV	√	√	√	√	AC1084. AC1085. AC1086. AC1087. AC1088. AC1089. AC1106	
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Occupant detection			√	√		SP0584
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	CAN gateway	√	√	√			
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	Brake	√	√	√	√	AC1127	
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	6ch CAN GATEWAY	√	√	√	√		
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	ICC/ADAS 2	√	√	√	√		
Canada	INFINITI Q70 HYBRID	HY51	2014.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Canada	INFINITI QX30	H15	2019.NULL	Air pressure monitor	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	Air bag	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	EPS/DAST 3	√	√	√			
Canada	INFINITI QX30	H15	2019.NULL	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Canada	INFINITI QX30	H15	2019.NULL	Engine	√	√	√	√	AC0002, AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0103, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Canada	INFINITI QX30	H15	2019.NULL	EHS/PKB	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	Transmission	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Canada	INFINITI QX30	H15	2019.NULL	ABS	√	√	√	√		SP0308
Canada	INFINITI QX30	H15	2019.NULL	Multi AV	√	√	√	√		SP0501
Canada	INFINITI QX30	H15	2019.NULL	HVAC	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	Auto drive position	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	Shift	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	All mode AWD/4WD	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	AVM	√	√		√		
Canada	INFINITI QX30	H15	2019.NULL	Intelligent key	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	CAN gateway	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	ANC	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	Telematics	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	FSCM	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	Siren control unit	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Canada	INFINITI QX30	H15	2019.NULL	Overhead Control Panel Unit	√			√		
Canada	INFINITI QX30	H15	2019.NULL	Universal Garage Door Opener	√			√		
Canada	INFINITI QX30	H15	2019.NULL	Upper control panel cont unit	√					
Canada	INFINITI QX30	H15	2019.NULL	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Canada	INFINITI QX30	H15	2019.NULL	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Canada	INFINITI QX30	H15	2019.NULL	Light/Rain Sensor Module	√			√		
Canada	INFINITI QX30	H15	2019.NULL	EC Mirror Compass	√					
Canada	INFINITI QX30	H15	2019.NULL	Intelligent Battery Sensor	√					
Canada	INFINITI QX30	H15	2019.NULL	Alarm siren	√			√		
Canada	INFINITI QX30	H15	2019.NULL	Radar sensor	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	Steering column cont module	√	√	√			
Canada	INFINITI QX30	H15	2019.NULL	ICC sensor	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	Trailer recognition control unit	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	H/L control module LH	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	Powertrain cont module	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	Side radar LH	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	LED H/L control module LH	√			√		
Canada	INFINITI QX30	H15	2019.NULL	Steering Wheel Switch Pad	√			√		
Canada	INFINITI QX30	H15	2019.NULL	Parking assist	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	Occupant Classification Unit	√			√		
Canada	INFINITI QX30	H15	2019.NULL	Electronic Ignition Switch cont unit	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	H/L control module RH	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	Front camera unit	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	Side radar RH	√	√	√	√		
Canada	INFINITI QX30	H15	2019.NULL	LED H/L control module RH	√			√		
Canada	INFINITI QX4	JR50	1997.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Canada	INFINITI QX4	JR50	1997.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Canada	INFINITI QX4	JR50	1997.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI QX4	JR50	1997.NULL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Canada	INFINITI QX4	JR50	1997.NULL	Air bag	√	√	√	√		
Canada	INFINITI QX4	JR50	1997.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Canada	INFINITI QX4	JR50	1997.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Canada	INFINITI QX4	JR50	1997.NULL	Motor control						

Canada	INFINITI QX4	JR50	1997.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI QX4	JR50	1997.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Canada	INFINITI QX4	JR50	1997.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Canada	INFINITI QX4	JR50	1997.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI QX4	JR50	1997.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI QX4	JR50	1997.NULL	HVAC	√	√	√	√		
Canada	INFINITI QX4	JR50	1997.NULL	Difference lock	√	√	√	√		
Canada	INFINITI QX4	JR50	1997.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI QX4	JR50	1997.NULL	Auto slide door	√	√	√	√	AC0941	
Canada	INFINITI QX4	JR50	1997.NULL	DIU		√	√	√		
Canada	INFINITI QX4	JR50	1997.NULL	Adaptive light	√	√	√	√		
Canada	INFINITI QX4	JR50	1997.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI QX4	JR50	1997.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Canada	INFINITI QX4	JR50	1997.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI QX4	JR50	1997.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Canada	INFINITI QX4	JR50	1997.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Canada	INFINITI QX4	JR50	1997.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI QX4	JR50	1997.NULL	IVMS	√	√		√		
Canada	INFINITI QX4	JR50	1997.NULL	Distance control	√	√		√		
Canada	INFINITI QX4	JR50	1997.NULL	Active suspense system	√	√	√	√		
Canada	INFINITI QX4	JR50	1997.NULL	Motor assist		√	√	√		SP0574
Canada	INFINITI QX4	JR50	1997.NULL	ASCD	√	√	√	√		
Canada	INFINITI QX4	JR50	1997.NULL	Active engine mount	√	√	√	√		
Canada	INFINITI QX4	JR50	1997.NULL	TCS	√	√	√	√		
Canada	INFINITI QX4	JR50	1997.NULL	S/blind camera	√			√		SP0572, SP0573
Canada	INFINITI QX4	JR50	1997.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Canada	INFINITI QX4	JR50	1997.NULL	Nats immu	√	√	√			
Canada	INFINITI QX4	JR50	1997.NULL	Rearview camera	√			√		SP0570, SP0571
Canada	INFINITI QX4	JR50	1997.NULL	Smart entrance						SP0568
Canada	INFINITI QX50	J50	2014.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Canada	INFINITI QX50	J50	2014.NULL	Laser/radar	√	√	√	√	AC0994	
Canada	INFINITI QX50	J50	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI QX50	I50	2014.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI QX50	I50	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI QX50	I50	2014.NULL	Air bag	√	√	√	√		
Canada	INFINITI QX50	I50	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
Canada	INFINITI QX50	J50	2014.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Canada	INFINITI QX50	J50	2014.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Canada	INFINITI QX50	J50	2014.NULL	Transmission	√	√	√	√		SP0274
Canada	INFINITI QX50	J50	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Canada	INFINITI QX50	J50	2014.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI QX50	J50	2014.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI QX50	J50	2014.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI QX50	J50	2014.NULL	Occupant detection			√	√		SP0584
Canada	INFINITI QX50	J50	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Canada	INFINITI QX50	J50	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI QX50	J50	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Canada	INFINITI QX50	J50	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI QX50	J50	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI QX50	J50	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI QX50	I50	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Canada	INFINITI QX50	I50	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Canada	INFINITI QX50	I50	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI QX50	I50	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Canada	INFINITI QX50	I50	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI QX50	J55	2019.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Canada	INFINITI QX50	J55	2019.NULL	Laser/radar	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Canada	INFINITI QX50	J55	2019.NULL_	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Canada	INFINITI QX50	I55	2019.NULL	Air bag	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL	EPS/DAST 3	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL	Meter/M&A	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Canada	INFINITI QX50	J55	2019.NULL	EHS/PKB	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL_	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Canada	INFINITI QX50	I55	2019.NULL	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Canada	INFINITI QX50	I55	2019.NULL	ABS	√	√	√	√		SP0313, SP0315
Canada	INFINITI QX50	I55	2019.NULL	Total illum C/U	√	√	√	√		
Canada	INFINITI QX50	I55	2019.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI QX50	J55	2019.NULL	HVAC	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL	Auto drive position	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL	Auto back door	√	√	√	√		SP0611
Canada	INFINITI QX50	J55	2019.NULL	Occupant detection			√	√		SP0584
Canada	INFINITI QX50	J55	2019.NULL	Shift						
Canada	INFINITI QX50	J55	2019.NULL	Adaptive light	√	√	√	√		SP0562
Canada	INFINITI QX50	J55	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI QX50	J55	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI QX50	J55	2019.NULL	All mode AWD/4WD	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL	DAST 2	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI QX50	J55	2019.NULL	CAN gateway	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL	Lane camera	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL	DAST 1	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL	Chassis control	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL	ANC						
Canada	INFINITI QX50	J55	2019.NULL	E-HUD	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI QX50	I55	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Canada	INFINITI QX50	I55	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI QX50	I55	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Canada	INFINITI QX50	I55	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
Canada	INFINITI QX50	J55	2019.NULL	ICC/ADAS 2	√	√	√	√		
Canada	INFINITI QX56	JA60	2004.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Canada	INFINITI QX56	JA60	2004.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Canada	INFINITI QX56	JA60	2004.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI QX56	JA60	2004.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Canada	INFINITI QX56	JA60	2004.NULL	Air bag	√	√	√	√		
Canada	INFINITI QX56	JA60	2004.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507

Canada	INFINITI QX56	JA60	2004.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Canada	INFINITI QX56	JA60	2004.NULL	Motor control						
Canada	INFINITI QX56	JA60	2004.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI QX56	JA60	2004.NULL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Canada	INFINITI QX56	JA60	2004.NULL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Canada	INFINITI QX56	JA60	2004.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Canada	INFINITI QX56	JA60	2004.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI QX56	JA60	2004.NULL	HVAC	√	√	√	√		
Canada	INFINITI QX56	JA60	2004.NULL	Difference lock	√	√	√	√		
Canada	INFINITI QX56	JA60	2004.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI QX56	JA60	2004.NULL	Auto slide door	√	√	√	√	AC0941	
Canada	INFINITI QX56	JA60	2004.NULL	DIU		√	√	√		
Canada	INFINITI QX56	JA60	2004.NULL	Adaptive light	√	√	√	√		
Canada	INFINITI QX56	JA60	2004.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI QX56	JA60	2004.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Canada	INFINITI QX56	JA60	2004.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI QX56	JA60	2004.NULL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Canada	INFINITI QX56	JA60	2004.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Canada	INFINITI QX56	JA60	2004.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI QX56	JA60	2004.NULL	IVMS	√	√		√		
Canada	INFINITI QX56	JA60	2004.NULL	Distance control	√	√		√		
Canada	INFINITI QX56	JA60	2004.NULL	Active suspense system	√	√	√	√		
Canada	INFINITI QX56	JA60	2004.NULL	Motor assist		√	√	√		SP0574
Canada	INFINITI QX56	JA60	2004.NULL	ASCD	√	√	√	√		
Canada	INFINITI QX56	JA60	2004.NULL	Active engine mount	√	√	√	√		
Canada	INFINITI QX56	JA60	2004.NULL	TCS	√	√	√	√		
Canada	INFINITI QX56	JA60	2004.NULL	S/blind camera	√			√		SP0572, SP0573
Canada	INFINITI QX56	JA60	2004.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Canada	INFINITI QX56	JA60	2004.NULL	Nats immu	√	√	√			
Canada	INFINITI QX56	JA60	2004.NULL	Rearview camera	√			√		SP0570, SP0571
Canada	INFINITI QX56	JA60	2004.NULL	Smart entrance						SP0568
Canada	INFINITI QX56	Z62	2011.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Canada	INFINITI QX56	Z62	2011.NULL	Laser/radar	√	√	√	√		
Canada	INFINITI QX56	Z62	2011.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI QX56	Z62	2011.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Canada	INFINITI QX56	Z62	2011.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI QX56	Z62	2011.NULL	Air bag	√	√	√	√		
Canada	INFINITI QX56	Z62	2011.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Canada	INFINITI QX56	Z62	2011.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Canada	INFINITI QX56	Z62	2011.NULL	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Canada	INFINITI QX56	Z62	2011.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Canada	INFINITI QX56	Z62	2011.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Canada	INFINITI QX56	Z62	2011.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI QX56	Z62	2011.NULL	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0476, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488, SP0489, SP0490
Canada	INFINITI QX56	Z62	2011.NULL	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Canada	INFINITI QX56	Z62	2011.NULL	Difference lock	√	√	√	√		
Canada	INFINITI QX56	Z62	2011.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI QX56	Z62	2011.NULL	Auto back door	√	√	√	√		
Canada	INFINITI QX56	Z62	2011.NULL	Occupant detection			√	√		SP0584
Canada	INFINITI QX56	Z62	2011.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Canada	INFINITI QX56	Z62	2011.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI QX56	Z62	2011.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Canada	INFINITI QX56	Z62	2011.NULL	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Canada	INFINITI QX56	Z62	2011.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI QX56	Z62	2011.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI QX56	Z62	2011.NULL	CAN gateway	√	√	√			
Canada	INFINITI QX56	Z62	2011.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Canada	INFINITI QX56	Z62	2011.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI QX56	Z62	2011.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Canada	INFINITI QX56	Z62	2011.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI QX56	Z62	2011.NULL	Rearview camera	√			√		SP0570, SP0571
Canada	INFINITI QX60	L50	2019.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Canada	INFINITI QX60	L50	2019.2-	Laser/radar	√	√	√	√	AC0994	
Canada	INFINITI QX60	L50	2019.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI QX60	L50	2019.2-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Canada	INFINITI QX60	L50	2019.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI QX60	L50	2019.2-	Air bag	√	√	√	√		
Canada	INFINITI QX60	L50	2019.2-	EPS/DAST 3	√	√	√	√		
Canada	INFINITI QX60	L50	2019.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Canada	INFINITI QX60	L50	2019.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Canada	INFINITI QX60	L50	2019.2-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Canada	INFINITI QX60	L50	2019.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Canada	INFINITI QX60	L50	2019.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Canada	INFINITI QX60	L50	2019.2-	Multi AV	√	√	√	√		SP0503
Canada	INFINITI QX60	L50	2019.2-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Canada	INFINITI QX60	L50	2019.2-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI QX60	L50	2019.2-	Auto back door	√	√	√	√		SP0611
Canada	INFINITI QX60	L50	2019.2-	Occupant detection			√	√		SP0584
Canada	INFINITI QX60	L50	2019.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI QX60	L50	2019.2-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI QX60	L50	2019.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI QX60	L50	2019.2-	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI QX60	L50	2019.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI QX60	L50	2019.2-	CAN gateway	√	√	√			
Canada	INFINITI QX60	L50	2019.2-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
Canada	INFINITI QX60	L50	2019.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Canada	INFINITI QX60	L50	2019.2-	ANC	√	√	√	√	AC1024	
Canada	INFINITI QX60	L50	2019.2-	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI QX60	L50	2019.2-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Canada	INFINITI QX60	L50	2019.2-	HIGH BEAM ASSIST	√	√	√	√		
Canada	INFINITI QX60	L50	2019.2-	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI QX60	L50	2019.2-	3ch CAN GATEWAY	√	√	√	√		
Canada	INFINITI QX60	L50	2019.2-	ICC/ADAS 2	√	√	√	√		
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Laser/radar	√	√	√	√		
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Air bag	√	√	√	√		
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	EPS/DAST 3	√	√	√	√		
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Motor control	√	√	√	√		
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0038, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL_	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	HV battery	√	√	√	√	AC1121	
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Auto back door	√	√	√	√		SP0611
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Occupant detection			√	√		SP0584
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	CAN gateway	√	√	√			
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	ANC	√	√	√	√		
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	HIGH BEAM ASSIST	√	√	√	√		
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	ICC/ADAS 2	√	√	√	√		
Canada	INFINITI QX60 HYBRID	HL50	2014.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Canada	INFINITI QX70	S51	2014.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Canada	INFINITI QX70	S51	2014.NULL	Laser/radar	√	√	√	√	AC0994	
Canada	INFINITI QX70	S51	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI QX70	S51	2014.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Canada	INFINITI QX70	S51	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI QX70	S51	2014.NULL	Air bag	√	√	√	√		
Canada	INFINITI QX70	S51	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
Canada	INFINITI QX70	S51	2014.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Canada	INFINITI QX70	S51	2014.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Canada	INFINITI QX70	S51	2014.NULL	Transmission	√	√	√	√		SP0274
Canada	INFINITI QX70	S51	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Canada	INFINITI QX70	S51	2014.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Canada	INFINITI QX70	S51	2014.NULL	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Canada	INFINITI QX70	S51	2014.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI QX70	S51	2014.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Canada	INFINITI QX70	S51	2014.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Canada	INFINITI QX70	S51	2014.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI QX70	S51	2014.NULL	Auto back door	√	√	√	√		SP0611
Canada	INFINITI QX70	S51	2014.NULL	Occupant detection			√	√		SP0584
Canada	INFINITI QX70	S51	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Canada	INFINITI QX70	S51	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI QX70	S51	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Canada	INFINITI QX70	S51	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Canada	INFINITI QX70	S51	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI QX70	S51	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI QX70	S51	2014.NULL	CAN gateway	√	√	√			
Canada	INFINITI QX70	S51	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Canada	INFINITI QX70	S51	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Canada	INFINITI QX80	Z62	2019.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Canada	INFINITI QX80	Z62	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Canada	INFINITI QX80	Z62	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Canada	INFINITI QX80	Z62	2019.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Canada	INFINITI QX80	Z62	2019.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Canada	INFINITI QX80	Z62	2019.NULL	Air bag	√	√	√	√		
Canada	INFINITI QX80	Z62	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
Canada	INFINITI QX80	Z62	2019.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Canada	INFINITI QX80	Z62	2019.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Canada	INFINITI QX80	Z62	2019.NULL	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Canada	INFINITI QX80	Z62	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Canada	INFINITI QX80	Z62	2019.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Canada	INFINITI QX80	Z62	2019.NULL	Multi AV	√	√	√	√		SP0503
Canada	INFINITI QX80	Z62	2019.NULL_	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Canada	INFINITI QX80	Z62	2019.NULL	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Canada	INFINITI QX80	Z62	2019.NULL	Difference lock	√	√	√	√		
Canada	INFINITI QX80	Z62	2019.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Canada	INFINITI QX80	Z62	2019.NULL	Auto back door	√	√	√	√		
Canada	INFINITI QX80	Z62	2019.NULL	Occupant detection			√	√		SP0584
Canada	INFINITI QX80	Z62	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Canada	INFINITI QX80	Z62	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Canada	INFINITI QX80	Z62	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Canada	INFINITI QX80	Z62	2019.NULL	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Canada	INFINITI QX80	Z62	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Canada	INFINITI QX80	Z62	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Canada	INFINITI QX80	Z62	2019.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Canada	INFINITI QX80	Z62	2019.NULL	CAN gateway	√	√	√			
Canada	INFINITI QX80	Z62	2019.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Canada	INFINITI QX80	Z62	2019.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Canada	INFINITI QX80	Z62	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Canada	INFINITI QX80	Z62	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Canada	INFINITI QX80	Z62	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
Canada	INFINITI QX80	Z62	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Canada	INFINITI QX80	Z62	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Canada	INFINITI QX80	Z62	2019.NULL	ICC/ADAS 2	√	√	√	√		
Canada	INFINITI QX80	Z62	2019.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Central africa	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Central africa	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Central africa	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Central africa	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Central africa	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Central africa	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Central africa	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Central africa	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Central africa	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Central africa	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Central africa	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Central africa	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Central africa	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Central africa	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Central africa	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Central africa	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Central africa	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Central africa	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Central africa	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Central africa	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Central africa	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Central africa	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Central africa	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Central africa	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Central africa	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Central africa	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Central africa	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Central africa	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Central africa	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Central africa	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Central africa	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Central africa	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Central africa	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Central africa	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Central africa	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Central africa	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Central africa	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Central africa	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Central africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Central africa	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Central africa	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Central africa	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Central africa	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Central africa	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Central africa	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Central africa	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Central africa	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Central africa	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Central africa	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Central africa	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Central africa	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Central africa	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Central africa	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Central africa	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Central africa	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Central africa	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Central africa	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Central africa	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Central africa	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Central africa	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Central africa	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Central africa	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Central africa	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Central africa	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Central africa	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Central africa	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Central africa	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Central africa	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Central africa	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Central africa	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Central africa	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Central africa	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	

Central africa	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Central africa	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Central africa	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Central africa	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Central africa	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Central africa	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Central africa	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Central africa	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Central africa	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Central africa	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Central africa	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Central africa	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Central africa	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Central africa	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Central africa	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Central africa	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Central africa	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Central africa	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Central africa	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Central africa	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Central africa	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Central africa	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Central africa	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Central africa	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Central africa	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Central africa	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Central africa	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Central africa	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Central africa	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Central africa	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Central africa	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Central africa	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Central africa	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Central africa	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Central africa	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Central africa	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Central africa	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Central africa	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Central africa	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Central africa	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Central africa	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Central africa	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Central africa	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Central africa	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Central africa	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Central africa	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Central africa	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Central africa	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Central africa	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Central africa	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Central africa	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Central africa	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Central africa	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Central africa	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Central africa	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Central africa	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Central africa	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Central africa	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Central africa	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Central africa	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Central africa	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Central africa	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Central africa	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Central africa	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Central africa	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582

Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
Central africa	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Central africa	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Central africa	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Central africa	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Central africa	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Central africa	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Central africa	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Central africa	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Central africa	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Central africa	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Central africa	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Central africa	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Central africa	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Central africa	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Central africa	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Central africa	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Central africa	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Central africa	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Central africa	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Central africa	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Central africa	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Central africa	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Central africa	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Central africa	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Central africa	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Central africa	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Central africa	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Central africa	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Central africa	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Central africa	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Central africa	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Central africa	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Central africa	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Central africa	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Central africa	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Central africa	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Central africa	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Central africa	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319

Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Central africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Central africa	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Central africa	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Central africa	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Central africa	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Central africa	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Central africa	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Central africa	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Central africa	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Central africa	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Central africa	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Central africa	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Central africa	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Central africa	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Central africa	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Central africa	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Central africa	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Central africa	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Central africa	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Central africa	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Central africa	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Central africa	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Central africa	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Central africa	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Central africa	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Central africa	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Central africa	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	

Central africa	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Central africa	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Central africa	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Central africa	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Central africa	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Central africa	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Central africa	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Central africa	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Central africa	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Central africa	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Central africa	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Central africa	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Central africa	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Central africa	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Central africa	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Central africa	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Central africa	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Central africa	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Central africa	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Central africa	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Central africa	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Central africa	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Central africa	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Central africa	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Central africa	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Central africa	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Central africa	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Central africa	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Central africa	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Central africa	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Central africa	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Central africa	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Central africa	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Central africa	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Central africa	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Central africa	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Central africa	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Central africa	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Central africa	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Central africa	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Central africa	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Central africa	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Central africa	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Central africa	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Central africa	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Central africa	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Central africa	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Central africa	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Central africa	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Central africa	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Central africa	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Central africa	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Central africa	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		

Central africa	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Central africa	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Central africa	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Central africa	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Central africa	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Central africa	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Central africa	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Central africa	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Central africa	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Central africa	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Central africa	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Central africa	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Central africa	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Central africa	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Central africa	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Central africa	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Central africa	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Central africa	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Central africa	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Central africa	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Central africa	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Central africa	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Central africa	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Central africa	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Central africa	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Central africa	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Central africa	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Central africa	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Central africa	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Central africa	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Central africa	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Central africa	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Central africa	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Central africa	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Central africa	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Central africa	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Central africa	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Central africa	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Chad	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Chad	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Chad	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chad	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Chad	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√	AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885, AC0886, AC0887, AC0888, AC0889, AC0890, AC0891, AC0892, AC0893, AC0894	SP0270, SP0274
Chad	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chad	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Chad	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chad	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chad	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chad	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Chad	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Chad	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Chad	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Chad	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Chad	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Chad	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Chad	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Chad	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chad	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Chad	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Chad	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chad	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Chad	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Chad	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	

Chad	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Chad	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Chad	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chad	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chad	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Chad	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Chad	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Chad	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Chad	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chad	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Chad	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Chad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Chad	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Chad	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Chad	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chad	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chad	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Chad	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chad	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Chad	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Chad	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chad	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chad	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chad	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Chad	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chad	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Chad	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Chad	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Chad	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Chad	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Chad	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Chad	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Chad	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Chad	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Chad	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Chad	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Chad	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Chad	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Chad	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chad	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chad	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chad	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chad	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Chad	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Chad	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Chad	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Chad	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chad	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Chad	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Chad	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Chad	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Chad	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Chad	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Chad	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Chad	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Chad	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Chad	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Chad	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Chad	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Chad	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Chad	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Chad	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Chad	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Chad	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Chad	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Chad	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Chad	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Chad	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Chad	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Chad	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Chad	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Chad	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Chad	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chad	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Chad	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Chad	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Chad	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Chad	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Chad	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chad	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Chad	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Chad	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Chad	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Chad	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Chad	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chad	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Chad	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Chad	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chad	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Chad	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Chad	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Chad	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Chad	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chad	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Chad	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	

Xtool

Chad	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chad	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Chad	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Chad	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Chad	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Chad	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Chad	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Chad	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Chad	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chad	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Chad	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Chad	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Chad	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Chad	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chad	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Chad	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Chad	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Chad	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Chad	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Chad	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chad	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Chad	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Chad	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Chad	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Chad	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Chad	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chad	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Chad	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Chad	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chad	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Chad	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Chad	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Chad	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Chad	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Chad	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Chad	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Chad	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chad	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Chad	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Chad	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Chad	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Chad	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Chad	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chad	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Chad	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Chad	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Chad	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Chad	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		

Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chad	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chad	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chad	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Chad	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Chad	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Chad	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Chad	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chad	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chad	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Chad	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chad	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Chad	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Chad	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Chad	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chad	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chad	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chad	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Chad	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Chad	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chad	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chad	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Chad	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Chad	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Chad	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Chad	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Chad	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Chad	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Chad	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Chad	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Chad	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Chad	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Chad	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Chad	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chad	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Chad	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Chad	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chad	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Chad	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Chad	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Chad	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chad	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Chad	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Chad	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chad	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Chad	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Chad	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chad	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Chad	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chad	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Chad	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Chad	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Chad	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Chad	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Chad	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Chad	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Chad	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chad	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Chad	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chad	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chad	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Chad	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Chad	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Chad	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chad	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Chad	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Chad	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Chad	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Chad	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chad	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Chad	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Chad	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Chad	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Chad	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Chad	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Chad	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chad	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Chad	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Chad	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chad	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Chad	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Chad	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Chad	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chad	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Chad	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Chad	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chad	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chad	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Chad	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Chad	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Chad	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chad	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Chad	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Chad	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chad	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Chad	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Chad	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Chad	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chad	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Chad	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Chad	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chad	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Chad	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chad	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Chad	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chad	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Chad	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Chad	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chad	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Chad	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Chad	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Chad	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Chad	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Chad	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Chad	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Chad	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chad	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Chad	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Chad	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Chad	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chad	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Chad	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Chad	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Chad	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Chad	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Chad	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Chad	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Chad	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Chad	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chad	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Chad	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Chad	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Chad	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Chad	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Chile	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Chile	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Chile	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Chile	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Chile	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chile	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315

Chile	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chile	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chile	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Chile	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI EX37	J50	2012.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI EX37	J50	2012.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI EX37	J50	2012.1-	Air bag	√	√	√	√		
Chile	INFINITI EX37	J50	2012.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
Chile	INFINITI EX37	J50	2012.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Chile	INFINITI EX37	J50	2012.1-	Transmission	√	√	√	√		SP0274
Chile	INFINITI EX37	J50	2012.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chile	INFINITI EX37	J50	2012.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Chile	INFINITI EX37	J50	2012.1-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI EX37	J50	2012.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI EX37	I50	2012.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chile	INFINITI EX37	I50	2012.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI EX37	I50	2012.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chile	INFINITI EX37	I50	2012.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI EX37	J50	2012.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Chile	INFINITI EX37	J50	2012.1-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI EX37	J50	2012.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chile	INFINITI EX37	J50	2012.1-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Chile	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Chile	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Chile	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chile	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Chile	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Chile	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chile	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Chile	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Chile	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Chile	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Chile	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Chile	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chile	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Chile	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Chile	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Chile	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Chile	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Chile	INFINITI FX37	S51	2012.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Chile	INFINITI FX37	S51	2012.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI FX37	S51	2012.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Chile	INFINITI FX37	S51	2012.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI FX37	S51	2012.1-	Air bag	√	√	√	√		
Chile	INFINITI FX37	S51	2012.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
Chile	INFINITI FX37	S51	2012.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Chile	INFINITI FX37	S51	2012.1-	Transmission	√	√	√	√		SP0274
Chile	INFINITI FX37	S51	2012.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chile	INFINITI FX37	S51	2012.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Chile	INFINITI FX37	S51	2012.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Chile	INFINITI FX37	S51	2012.1-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI FX37	S51	2012.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Chile	INFINITI FX37	S51	2012.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI FX37	S51	2012.1-	Auto back door	√	√	√	√		SP0611
Chile	INFINITI FX37	S51	2012.1-	Occupant detection			√	√		SP0584
Chile	INFINITI FX37	S51	2012.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chile	INFINITI FX37	S51	2012.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI FX37	S51	2012.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Chile	INFINITI FX37	S51	2012.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI FX37	S51	2012.1-	Precrash seatbelt	√	√	√	√		SP0612
Chile	INFINITI FX37	S51	2012.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI FX37	S51	2012.1-	CAN gateway	√	√	√			
Chile	INFINITI FX37	S51	2012.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Chile	INFINITI FX37	S51	2012.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Chile	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Chile	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Chile	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Chile	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chile	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chile	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Chile	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613. AC0618. AC0663. AC0692. AC0702. AC0719	SP0372. SP0429
Chile	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Chile	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Chile	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chile	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980	SP0561. SP0562
Chile	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chile	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Chile	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Chile	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Chile	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Chile	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Chile	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Chile	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Chile	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Chile	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Chile	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Chile	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Chile	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Chile	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985. AC0986. AC0987. AC0988. AC0989	SP0563. SP0564. SP0565. SP0566. SP0567
Chile	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Chile	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973. AC0974. AC0976. AC0977	
Chile	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI M37	Y51	2012.2-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Chile	INFINITI M37	Y51	2012.2-	Laser/radar	√	√	√	√		
Chile	INFINITI M37	Y51	2012.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI M37	Y51	2012.2-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Chile	INFINITI M37	Y51	2012.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI M37	Y51	2012.2-	Air bag	√	√	√	√		
Chile	INFINITI M37	Y51	2012.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Chile	INFINITI M37	Y51	2012.2-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Chile	INFINITI M37	Y51	2012.2-	Transmission	√	√	√	√		SP0274
Chile	INFINITI M37	Y51	2012.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Chile	INFINITI M37	Y51	2012.2-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Chile	INFINITI M37	Y51	2012.2-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI M37	Y51	2012.2-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Chile	INFINITI M37	Y51	2012.2-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI M37	Y51	2012.2-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chile	INFINITI M37	Y51	2012.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI M37	Y51	2012.2-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chile	INFINITI M37	Y51	2012.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI M37	Y51	2012.2-	CAN gateway	√	√	√			
Chile	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Chile	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Chile	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Chile	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Chile	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Chile	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Chile	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Chile	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Chile	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Chile	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Chile	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Chile	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Chile	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Chile	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chile	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chile	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chile	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Chile	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Chile	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Chile	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Chile	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Chile	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Chile	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Chile	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Chile	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Chile	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Chile	INFINITI Q45	F50	2001.8-	Motor control						
Chile	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chile	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Chile	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Chile	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Chile	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Chile	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Chile	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Chile	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Chile	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Chile	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Chile	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Chile	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Chile	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Chile	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Chile	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Chile	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Chile	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Chile	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Chile	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Chile	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Chile	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Chile	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Chile	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Chile	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Chile	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Chile	INFINITI Q50	V37	2013.12-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Chile	INFINITI Q50	V37	2013.12-	Laser/radar	√	√	√	√	AC0994	
Chile	INFINITI Q50	V37	2013.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI Q50	V37	2013.12-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Chile	INFINITI Q50	V37	2013.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI Q50	V37	2013.12-	Air bag	√	√	√	√		
Chile	INFINITI Q50	V37	2013.12-	EPS/DAST 3	√	√	√	√		SP0507
Chile	INFINITI Q50	V37	2013.12-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Chile	INFINITI Q50	V37	2013.12-	Motor control	√	√	√	√		

Chile	INFINITI Q50	V37	2013.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chile	INFINITI Q50	V37	2013.12-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Chile	INFINITI Q50	V37	2013.12-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Chile	INFINITI Q50	V37	2013.12-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Chile	INFINITI Q50	V37	2013.12-	Pop up hood	√	√	√	√		
Chile	INFINITI Q50	V37	2013.12-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI Q50	V37	2013.12-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Chile	INFINITI Q50	V37	2013.12-	HV battery	√	√	√	√	AC1121	
Chile	INFINITI Q50	V37	2013.12-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Chile	INFINITI Q50	V37	2013.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chile	INFINITI Q50	V37	2013.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI Q50	V37	2013.12-	EV/HEV	√	√	√	√	AC1084. AC1085. AC1086. AC1087. AC1088. AC1089. AC1106	
Chile	INFINITI Q50	V37	2013.12-	Occupant detection			√	√		SP0584
Chile	INFINITI Q50	V37	2013.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Chile	INFINITI Q50	V37	2013.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI Q50	V37	2013.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Chile	INFINITI Q50	V37	2013.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Chile	INFINITI Q50	V37	2013.12-	DAST 2	√	√	√	√		
Chile	INFINITI Q50	V37	2013.12-	Precrash seatbelt	√	√	√	√		SP0612
Chile	INFINITI Q50	V37	2013.12-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI Q50	V37	2013.12-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Chile	INFINITI Q50	V37	2013.12-	CAN gateway	√	√	√			
Chile	INFINITI Q50	V37	2013.12-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Chile	INFINITI Q50	V37	2013.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI Q50	V37	2013.12-	DAST 1	√	√	√	√		
Chile	INFINITI Q50	V37	2013.12-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Chile	INFINITI Q50	V37	2013.12-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Chile	INFINITI Q50	V37	2013.12-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Chile	INFINITI Q50	V37	2013.12-	ANC	√	√	√	√	AC1024	
Chile	INFINITI Q50	V37	2013.12-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI Q50	V37	2013.12-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Chile	INFINITI Q50	V37	2013.12-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chile	INFINITI Q50	V37	2013.12-	HIGH BEAM ASSIST	√	√	√	√		
Chile	INFINITI Q50	V37	2013.12-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI Q50	V37	2013.12-	CAN monitor unit	√	√	√	√		
Chile	INFINITI Q50	V37	2013.12-	Brake	√	√	√	√	AC1127	
Chile	INFINITI Q50	V37	2013.12-	HDmap	√	√	√	√		
Chile	INFINITI Q50	V37	2013.12-	6ch CAN GATEWAY	√	√	√	√		
Chile	INFINITI Q50	V37	2013.12-	3ch CAN GATEWAY	√	√	√	√		
Chile	INFINITI Q50	V37	2013.12-	ICC/ADAS 2	√	√	√	√		
Chile	INFINITI Q50	V37	2013.12-	PMAS	√	√	√	√		
Chile	INFINITI Q50	V37	2013.12-	FSCM	√	√	√	√	AC1109	
Chile	INFINITI Q50	V37	2013.12-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		SP0507
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348. SP0349. SP0350. SP0351
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129. AC1130. AC1131	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	6ch CAN GATEWAY	√	√	√	√		
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	FSCM	√	√	√	√	AC1109	
Chile	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122. AC1123. AC1124. AC1125. AC1126	
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		

Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Chile	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Chile	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chile	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Chile	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Chile	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Chile	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Chile	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Chile	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chile	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Chile	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Chile	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Chile	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Chile	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Chile	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chile	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Chile	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Chile	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Chile	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Chile	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Chile	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Chile	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Chile	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Chile	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Chile	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Chile	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Chile	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Chile	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chile	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Chile	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Chile	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Chile	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Chile	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Laser/radar	√	√	√	√	AC0994	
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Air bag	√	√	√	√		
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Transmission	√	√	√	√		SP0274
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Pop up hood	√	√	√	√		

Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Precrash seatbelt	√	√	√	√		
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI Q60 COUPE	CV36	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chile	INFINITI Q60 COUPE	CV36	2013.9-	Laser/radar	√	√	√	√	AC0994	
Chile	INFINITI Q60 COUPE	CV36	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI Q60 COUPE	CV36	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Chile	INFINITI Q60 COUPE	CV36	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI Q60 COUPE	CV36	2013.9-	Air bag	√	√	√	√		
Chile	INFINITI Q60 COUPE	CV36	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Chile	INFINITI Q60 COUPE	CV36	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chile	INFINITI Q60 COUPE	CV36	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chile	INFINITI Q60 COUPE	CV36	2013.9-	Transmission	√	√	√	√		SP0274
Chile	INFINITI Q60 COUPE	CV36	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chile	INFINITI Q60 COUPE	CV36	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Chile	INFINITI Q60 COUPE	CV36	2013.9-	Pop up hood	√	√	√	√		
Chile	INFINITI Q60 COUPE	CV36	2013.9-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI Q60 COUPE	CV36	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Chile	INFINITI Q60 COUPE	CV36	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chile	INFINITI Q60 COUPE	CV36	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI Q60 COUPE	CV36	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chile	INFINITI Q60 COUPE	CV36	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Chile	INFINITI Q60 COUPE	CV36	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Chile	INFINITI Q60 COUPE	CV36	2013.9-	Precrash seatbelt	√	√	√	√		
Chile	INFINITI Q60 COUPE	CV36	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI Q60 COUPE	CV36	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Chile	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Chile	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Chile	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Chile	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Chile	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Chile	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Chile	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Chile	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Chile	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Chile	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Chile	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Chile	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Chile	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Chile	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chile	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Chile	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Chile	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Chile	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Chile	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Chile	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Chile	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Chile	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Chile	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Chile	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Chile	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chile	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Chile	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Chile	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Chile	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Chile	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Chile	INFINITI QX30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	Air bag	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	EPS/DAST 3	√	√	√			
Chile	INFINITI QX30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Chile	INFINITI QX30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Chile	INFINITI QX30	H15	2016.4-	EHS/PKB	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	Transmission	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Chile	INFINITI QX30	H15	2016.4-	ABS	√	√	√	√		SP0308
Chile	INFINITI QX30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Chile	INFINITI QX30	H15	2016.4-	HVAC	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	Auto drive position	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	Shift	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	AVM	√	√		√		
Chile	INFINITI QX30	H15	2016.4-	Intelligent key	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	CAN gateway	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	ANC	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	Telematics	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	FSCM	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	Siren control unit	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Chile	INFINITI QX30	H15	2016.4-	Overhead Control Panel Unit	√			√		

Chile	INFINITI QX30	H15	2016.4-	Universal Garage Door Opener	√			√		
Chile	INFINITI QX30	H15	2016.4-	Upper control panel cont unit	√					
Chile	INFINITI QX30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Chile	INFINITI QX30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Chile	INFINITI QX30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Chile	INFINITI QX30	H15	2016.4-	EC Mirror Compass	√					
Chile	INFINITI QX30	H15	2016.4-	Intelligent Battery Sensor	√					
Chile	INFINITI QX30	H15	2016.4-	Alarm siren	√			√		
Chile	INFINITI QX30	H15	2016.4-	Radar sensor	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	Steering column cont module	√	√	√			
Chile	INFINITI QX30	H15	2016.4-	ICC sensor	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	H/L control module LH	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	Side radar LH	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	LED H/L control module LH	√			√		
Chile	INFINITI QX30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Chile	INFINITI QX30	H15	2016.4-	Parking assist	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	Occupant Classification Unit	√			√		
Chile	INFINITI QX30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	H/L control module RH	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	Front camera unit	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	Side radar RH	√	√	√	√		
Chile	INFINITI QX30	H15	2016.4-	LED H/L control module RH	√			√		
Chile	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chile	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Chile	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Chile	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI QX50	I50	2013.6-	Air bag	√	√	√	√		
Chile	INFINITI QX50	I50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Chile	INFINITI QX50	I50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chile	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Chile	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Chile	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chile	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Chile	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Chile	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chile	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Chile	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Chile	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Chile	INFINITI QX50	I50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Chile	INFINITI QX50	I50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Chile	INFINITI QX50	I50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI QX50	I50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chile	INFINITI QX50	I50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Chile	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Chile	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Chile	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Chile	INFINITI QX50	I55	2018.5-	Air bag	√	√	√	√		
Chile	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Chile	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Chile	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chile	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Chile	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Chile	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Chile	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Chile	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Chile	INFINITI QX50	I55	2018.5-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI QX50	I55	2018.5-	HVAC	√	√	√	√		
Chile	INFINITI QX50	I55	2018.5-	Auto drive position	√	√	√	√		
Chile	INFINITI QX50	I55	2018.5-	Auto back door	√	√	√	√		SP0611
Chile	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Chile	INFINITI QX50	J55	2018.5-	Shift						
Chile	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Chile	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Chile	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Chile	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Chile	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Chile	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Chile	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Chile	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Chile	INFINITI QX50	J55	2018.5-	ANC						
Chile	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Chile	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chile	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Chile	INFINITI QX50	I55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Chile	INFINITI QX50	I55	2018.5-	ICC/ADAS 2	√	√	√	√		
Chile	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Chile	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Chile	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Chile	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Chile	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Chile	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Chile	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chile	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Chile	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Chile	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Chile	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Chile	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Chile	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Chile	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Chile	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chile	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Chile	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Chile	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Chile	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Chile	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chile	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI QX60	L50	2014.12-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Chile	INFINITI QX60	L50	2014.12-	Laser/radar	√	√	√	√	AC0994	
Chile	INFINITI QX60	L50	2014.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI QX60	L50	2014.12-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Chile	INFINITI QX60	L50	2014.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI QX60	L50	2014.12-	Air bag	√	√	√	√		
Chile	INFINITI QX60	L50	2014.12-	EPS/DAST 3	√	√	√	√		
Chile	INFINITI QX60	L50	2014.12-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Chile	INFINITI QX60	L50	2014.12-	Motor control	√	√	√	√		
Chile	INFINITI QX60	L50	2014.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chile	INFINITI QX60	L50	2014.12-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Chile	INFINITI QX60	L50	2014.12-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Chile	INFINITI QX60	L50	2014.12-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Chile	INFINITI QX60	L50	2014.12-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI QX60	L50	2014.12-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Chile	INFINITI QX60	L50	2014.12-	HV battery	√	√	√	√	AC1121	
Chile	INFINITI QX60	L50	2014.12-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI QX60	L50	2014.12-	Auto back door	√	√	√	√		SP0611
Chile	INFINITI QX60	L50	2014.12-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Chile	INFINITI QX60	L50	2014.12-	Occupant detection			√	√		SP0584
Chile	INFINITI QX60	L50	2014.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI QX60	L50	2014.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Chile	INFINITI QX60	L50	2014.12-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI QX60	L50	2014.12-	Precrash seatbelt	√	√	√	√		SP0612
Chile	INFINITI QX60	L50	2014.12-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI QX60	L50	2014.12-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Chile	INFINITI QX60	L50	2014.12-	CAN gateway	√	√	√			
Chile	INFINITI QX60	L50	2014.12-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Chile	INFINITI QX60	L50	2014.12-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Chile	INFINITI QX60	L50	2014.12-	ANC	√	√	√	√	AC1024	
Chile	INFINITI QX60	L50	2014.12-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI QX60	L50	2014.12-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chile	INFINITI QX60	L50	2014.12-	HIGH BEAM ASSIST	√	√	√	√		
Chile	INFINITI QX60	L50	2014.12-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI QX60	L50	2014.12-	3ch CAN GATEWAY	√	√	√	√		
Chile	INFINITI QX60	L50	2014.12-	ICC/ADAS 2	√	√	√	√		
Chile	INFINITI QX60	L50	2014.12-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Chile	INFINITI QX60	L50	2014.12-	A-IVC(Renault common)	√	√	√	√		
Chile	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Chile	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Chile	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Chile	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Chile	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Chile	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Chile	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Chile	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Chile	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Chile	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Chile	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Chile	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Chile	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chile	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Chile	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Chile	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Chile	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Chile	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Chile	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Chile	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Chile	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Chile	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Chile	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Chile	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Chile	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chile	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Chile	INFINITI QX80	Z62	2015.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Chile	INFINITI QX80	Z62	2015.8-	Laser/radar	√	√	√	√	AC0994	
Chile	INFINITI QX80	Z62	2015.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Chile	INFINITI QX80	Z62	2015.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Chile	INFINITI QX80	Z62	2015.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Chile	INFINITI QX80	Z62	2015.8-	Air bag	√	√	√	√		
Chile	INFINITI QX80	Z62	2015.8-	EPS/DAST 3	√	√	√	√		SP0507
Chile	INFINITI QX80	Z62	2015.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Chile	INFINITI QX80	Z62	2015.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Chile	INFINITI QX80	Z62	2015.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Chile	INFINITI QX80	Z62	2015.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Chile	INFINITI QX80	Z62	2015.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Chile	INFINITI QX80	Z62	2015.8-	Multi AV	√	√	√	√		SP0503
Chile	INFINITI QX80	Z62	2015.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Chile	INFINITI QX80	Z62	2015.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Chile	INFINITI QX80	Z62	2015.8-	Difference lock	√	√	√	√		
Chile	INFINITI QX80	Z62	2015.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Chile	INFINITI QX80	Z62	2015.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Chile	INFINITI QX80	Z62	2015.8-	Auto back door	√	√	√	√		
Chile	INFINITI QX80	Z62	2015.8-	Occupant detection			√	√		SP0584
Chile	INFINITI QX80	Z62	2015.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Chile	INFINITI QX80	Z62	2015.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Chile	INFINITI QX80	Z62	2015.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Chile	INFINITI QX80	Z62	2015.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Chile	INFINITI QX80	Z62	2015.8-	Precrash seatbelt	√	√	√	√		SP0612
Chile	INFINITI QX80	Z62	2015.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Chile	INFINITI QX80	Z62	2015.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Chile	INFINITI QX80	Z62	2015.8-	CAN gateway	√	√	√			
Chile	INFINITI QX80	Z62	2015.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Chile	INFINITI QX80	Z62	2015.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Chile	INFINITI QX80	Z62	2015.8-	Side radar left	√	√	√	√	AC1025	SP0582
Chile	INFINITI QX80	Z62	2015.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Chile	INFINITI QX80	Z62	2015.8-	HIGH BEAM ASSIST	√	√	√	√		
Chile	INFINITI QX80	Z62	2015.8-	Side radar right	√	√	√	√	AC1026	SP0583
Chile	INFINITI QX80	Z62	2015.8-	Vehicle data transmitter	√	√	√	√		
Chile	INFINITI QX80	Z62	2015.8-	6ch CAN GATEWAY	√	√	√	√		
Chile	INFINITI QX80	Z62	2015.8-	ICC/ADAS 2	√	√	√	√		
Chile	INFINITI QX80	Z62	2015.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
China	INFINITI ESQ	F15	2014.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
China	INFINITI ESQ	F15	2014.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI ESQ	F15	2014.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
China	INFINITI ESQ	F15	2014.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI ESQ	F15	2014.7-	Air bag	√	√	√	√		
China	INFINITI ESQ	F15	2014.7-	EPS/DAST 3	√	√	√	√		SP0507
China	INFINITI ESQ	F15	2014.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI ESQ	F15	2014.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0016, AC0019, AC0020, AC0021, AC0023, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0043, AC0044, AC0045, AC0047, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0075, AC0085, AC0090, AC0091, AC0092, AC0114, AC0115, AC0122, AC0123, AC0131, AC0137, AC0139, AC0143, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0215, AC0217, AC0218, AC0219, AC0221, AC0222, AC0223, AC0224, AC0225, AC0226, AC0227, AC0229, AC0256, AC0278, AC0282, AC0283, AC0284, AC0287, AC0292, AC0295, AC0300, AC0301, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0341, AC0346, AC0348, AC0351, AC0352, AC0365, AC0366, AC0368, AC0369, AC0371, AC0372, AC0374, AC0375, AC0376, AC0377, AC0378, AC0379, AC0380, AC0381, AC0382, AC0383, AC0384, AC0385, AC0386, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0021, SP0022, SP0023, SP0024, SP0028, SP0029, SP0030, SP0032, SP0033, SP0038, SP0043, SP0047, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0070, SP0074, SP0078, SP0079, SP0080, SP0081, SP0084, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0107, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0125, SP0127, SP0131, SP0132, SP0133, SP0134, SP0135, SP0136, SP0137, SP0138, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0161, SP0164, SP0166, SP0172, SP0173, SP0176, SP0181, SP0183, SP0184, SP0185, SP0186, SP0187, SP0190, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0201, SP0202, SP0207, SP0208, SP0212, SP0213, SP0214, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0224, SP0226, SP0227, SP0229, SP0234, SP0237, SP0238, SP0239
China	INFINITI ESQ	F15	2014.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
China	INFINITI ESQ	F15	2014.7-	BCM				√	AC0613, AC0618, AC0653, AC0663, AC0690, AC0692, AC0698, AC0702	SP0372, SP0429, SP0471
China	INFINITI ESQ	F15	2014.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
China	INFINITI ESQ	F15	2014.7-	Multi AV	√	√	√	√		SP0503
China	INFINITI ESQ	F15	2014.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
China	INFINITI ESQ	F15	2014.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
China	INFINITI ESQ	F15	2014.7-	Occupant detection			√	√		SP0584
China	INFINITI ESQ	F15	2014.7-	All mode AWD/4WD	√	√	√	√	AC0959, AC0960	SP0550, SP0551
China	INFINITI ESQ	F15	2014.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI ESQ	F15	2014.7-	CAN gateway	√	√	√			
China	INFINITI ESQ	F15	2014.7-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI ESQ	F15	2014.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
China	INFINITI ESQ	F15	2014.7-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI ESQ	F15	2014.7-	Multi display		√	√	√	AC1110	
China	INFINITI ESQ	F15	2014.7-	PTC heater	√	√	√	√	AC1107, AC1108	
China	INFINITI EX25/EX35	J50	2009.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI EX25/EX35	J50	2009.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
China	INFINITI EX25/EX35	J50	2009.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI EX25/EX35	J50	2009.11-	Air bag	√	√	√	√		
China	INFINITI EX25/EX35	J50	2009.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
China	INFINITI EX25/EX35	J50	2009.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
China	INFINITI EX25/EX35	J50	2009.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
China	INFINITI EX25/EX35	J50	2009.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
China	INFINITI EX25/EX35	J50	2009.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
China	INFINITI EX25/EX35	J50	2009.11-	Multi AV	√	√	√	√		SP0503
China	INFINITI EX25/EX35	J50	2009.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI EX25/EX35	J50	2009.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI EX25/EX35	J50	2009.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI EX25/EX35	J50	2009.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
China	INFINITI EX25/EX35	J50	2009.11-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI EX25/EX35	J50	2009.11-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI EX25/EX35	J50	2009.11-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
China	INFINITI EX25/EX37	J50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI EX25/EX37	J50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
China	INFINITI EX25/EX37	J50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI EX25/EX37	J50	2012.5-	Air bag	√	√	√	√		
China	INFINITI EX25/EX37	J50	2012.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
China	INFINITI EX25/EX37	J50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
China	INFINITI EX25/EX37	J50	2012.5-	Transmission	√	√	√	√		SP0274
China	INFINITI EX25/EX37	J50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
China	INFINITI EX25/EX37	J50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
China	INFINITI EX25/EX37	J50	2012.5-	Multi AV	√	√	√	√		SP0503
China	INFINITI EX25/EX37	J50	2012.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI EX25/EX37	J50	2012.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

China	INFINITI EX25/EX37	J50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI EX25/EX37	J50	2012.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
China	INFINITI EX25/EX37	J50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI EX25/EX37	J50	2012.5-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI EX35	J50	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI EX35	J50	2008.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
China	INFINITI EX35	J50	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI EX35	J50	2008.7-	Air bag	√	√	√	√		
China	INFINITI EX35	J50	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
China	INFINITI EX35	J50	2008.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
China	INFINITI EX35	J50	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
China	INFINITI EX35	J50	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
China	INFINITI EX35	J50	2008.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
China	INFINITI EX35	J50	2008.7-	Multi AV	√	√	√	√		
China	INFINITI EX35	J50	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI EX35	J50	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI EX35	J50	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
China	INFINITI EX35	J50	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI FX35/FX45	S50	2007.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI FX35/FX45	S50	2007.4-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
China	INFINITI FX35/FX45	S50	2007.4-	Air bag	√	√	√	√		
China	INFINITI FX35/FX45	S50	2007.4-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
China	INFINITI FX35/FX45	S50	2007.4-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
China	INFINITI FX35/FX45	S50	2007.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
China	INFINITI FX35/FX45	S50	2007.4-	BCM					AC0653, AC0695	SP0372, SP0429
China	INFINITI FX35/FX45	S50	2007.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
China	INFINITI FX35/FX45	S50	2007.4-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI FX35/FX45	S50	2007.4-	All mode AWD/4WD	√	√	√	√	AC0957	
China	INFINITI FX35/FX45	S50	2007.4-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
China	INFINITI FX35/FX45	S50	2007.4-	Rearview camera	√			√		SP0570, SP0571
China	INFINITI FX35/FX50	S51	2008.11-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
China	INFINITI FX35/FX50	S51	2008.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI FX35/FX50	S51	2008.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
China	INFINITI FX35/FX50	S51	2008.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI FX35/FX50	S51	2008.11-	Air bag	√	√	√	√		
China	INFINITI FX35/FX50	S51	2008.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
China	INFINITI FX35/FX50	S51	2008.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
China	INFINITI FX35/FX50	S51	2008.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
China	INFINITI FX35/FX50	S51	2008.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
China	INFINITI FX35/FX50	S51	2008.11-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
China	INFINITI FX35/FX50	S51	2008.11-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
China	INFINITI FX35/FX50	S51	2008.11-	Multi AV	√	√	√	√		SP0503
China	INFINITI FX35/FX50	S51	2008.11-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
China	INFINITI FX35/FX50	S51	2008.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI FX35/FX50	S51	2008.11-	Auto back door	√	√	√	√		SP0611
China	INFINITI FX35/FX50	S51	2008.11-	Occupant detection			√	√		SP0584
China	INFINITI FX35/FX50	S51	2008.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI FX35/FX50	S51	2008.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI FX35/FX50	S51	2008.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
China	INFINITI FX35/FX50	S51	2008.11-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI FX35/FX50	S51	2008.11-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI FX35/FX50	S51	2008.11-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI FX35/FX50	S51	2008.11-	CAN gateway	√	√	√			
China	INFINITI FX35/FX50	S51	2008.11-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
China	INFINITI FX35/FX50	S51	2008.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI FX35/FX50	S51	2008.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI FX35/FX50	S51	2008.11-	Rearview camera	√			√		SP0570, SP0571
China	INFINITI G25/G37 SEDAN	V36	2009.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI G25/G37 SEDAN	V36	2009.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI G25/G37 SEDAN	V36	2009.11-	Air bag	√	√	√	√		
China	INFINITI G25/G37 SEDAN	V36	2009.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
China	INFINITI G25/G37 SEDAN	V36	2009.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI G25/G37 SEDAN	V36	2009.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
China	INFINITI G25/G37 SEDAN	V36	2009.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
China	INFINITI G25/G37 SEDAN	V36	2009.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
China	INFINITI G25/G37 SEDAN	V36	2009.11-	Multi AV	√	√	√	√		
China	INFINITI G25/G37 SEDAN	V36	2009.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
China	INFINITI G25/G37 SEDAN	V36	2009.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI G25/G37 SEDAN	V36	2009.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI G25/G37 SEDAN	V36	2009.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI G25/G37 SEDAN	V36	2009.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
China	INFINITI G25/G37 SEDAN	V36	2009.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
China	INFINITI G25/G37 SEDAN	V36	2009.11-	Precrash seatbelt	√	√	√	√		
China	INFINITI G25/G37 SEDAN	V36	2009.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI G35 SEDAN	V36	2007.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI G35 SEDAN	V36	2007.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI G35 SEDAN	V36	2007.5-	Air bag	√	√	√	√		
China	INFINITI G35 SEDAN	V36	2007.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

China	INFINITI G35 SEDAN	V36	2007.5-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
China	INFINITI G35 SEDAN	V36	2007.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
China	INFINITI G35 SEDAN	V36	2007.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
China	INFINITI G35 SEDAN	V36	2007.5-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
China	INFINITI G35 SEDAN	V36	2007.5-	Multi AV	√	√	√	√		
China	INFINITI G35 SEDAN	V36	2007.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI G35 SEDAN	V36	2007.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
China	INFINITI G35 SEDAN	V36	2007.5-	All mode AWD/4WD	√	√	√	√	AC0957	
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	Air bag	√	√	√	√		
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	Multi AV	√	√	√	√		SP0503
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
China	INFINITI G37 CONVERTIBLE	HV36	2009.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI G37 COUPE	CV36	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI G37 COUPE	CV36	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI G37 COUPE	CV36	2008.5-	Air bag	√	√	√	√		
China	INFINITI G37 COUPE	CV36	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
China	INFINITI G37 COUPE	CV36	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI G37 COUPE	CV36	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
China	INFINITI G37 COUPE	CV36	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
China	INFINITI G37 COUPE	CV36	2008.5-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
China	INFINITI G37 COUPE	CV36	2008.5-	Multi AV	√	√	√	√		SP0503
China	INFINITI G37 COUPE	CV36	2008.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
China	INFINITI G37 COUPE	CV36	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI G37 COUPE	CV36	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI G37 COUPE	CV36	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
China	INFINITI G37 COUPE	CV36	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
China	INFINITI G37 COUPE	CV36	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
China	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
China	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
China	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
China	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
China	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
China	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
China	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
China	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
China	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
China	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
China	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI JX35	L50	2012.8-	Laser/radar	√	√	√	√		
China	INFINITI JX35	L50	2012.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI JX35	L50	2012.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
China	INFINITI JX35	L50	2012.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI JX35	L50	2012.8-	Air bag	√	√	√	√		
China	INFINITI JX35	L50	2012.8-	EPS/DAST 3	√	√	√	√		
China	INFINITI JX35	L50	2012.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI JX35	L50	2012.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI JX35	L50	2012.8-	Transmission	√	√	√	√	AC0276, AC0278, AC0279	
China	INFINITI JX35	L50	2012.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
China	INFINITI JX35	L50	2012.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
China	INFINITI JX35	L50	2012.8-	Multi AV	√	√	√	√		SP0503
China	INFINITI JX35	L50	2012.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
China	INFINITI JX35	L50	2012.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI JX35	L50	2012.8-	Auto back door	√	√	√	√		SP0611
China	INFINITI JX35	L50	2012.8-	Occupant detection			√	√		SP0584
China	INFINITI JX35	L50	2012.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI JX35	L50	2012.8-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
China	INFINITI JX35	L50	2012.8-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI JX35	L50	2012.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI JX35	L50	2012.8-	CAN gateway	√	√	√			
China	INFINITI JX35	L50	2012.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
China	INFINITI JX35	L50	2012.8-	Side radar left	√	√	√	√	AC1025	SP0582

China	INFINITI IX35	L50	2012.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI IX35	L50	2012.8-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI M25/M37	Y51	2010.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
China	INFINITI M25/M37	Y51	2010.9-	Laser/radar	√	√	√	√		
China	INFINITI M25/M37	Y51	2010.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI M25/M37	Y51	2010.9-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
China	INFINITI M25/M37	Y51	2010.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
China	INFINITI M25/M37	Y51	2010.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI M25/M37	Y51	2010.9-	Air bag	√	√	√	√		
China	INFINITI M25/M37	Y51	2010.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI M25/M37	Y51	2010.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
China	INFINITI M25/M37	Y51	2010.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
China	INFINITI M25/M37	Y51	2010.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
China	INFINITI M25/M37	Y51	2010.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
China	INFINITI M25/M37	Y51	2010.9-	Pop up hood	√	√	√	√		
China	INFINITI M25/M37	Y51	2010.9-	Multi AV	√	√	√	√		SP0503
China	INFINITI M25/M37	Y51	2010.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
China	INFINITI M25/M37	Y51	2010.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
China	INFINITI M25/M37	Y51	2010.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
China	INFINITI M25/M37	Y51	2010.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI M25/M37	Y51	2010.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI M25/M37	Y51	2010.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI M25/M37	Y51	2010.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
China	INFINITI M25/M37	Y51	2010.9-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI M25/M37	Y51	2010.9-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI M25/M37	Y51	2010.9-	CAN gateway	√	√	√			
China	INFINITI M25/M37	Y51	2010.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
China	INFINITI M25/M37	Y51	2010.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI M25/M37	Y51	2010.9-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI M25/M37	Y51	2010.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI M25/M37	Y51	2010.9-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI M35/M45	Y50	2007.11-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
China	INFINITI M35/M45	Y50	2007.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
China	INFINITI M35/M45	Y50	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
China	INFINITI M35/M45	Y50	2007.11-	Air bag	√	√	√	√		
China	INFINITI M35/M45	Y50	2007.11-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
China	INFINITI M35/M45	Y50	2007.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
China	INFINITI M35/M45	Y50	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
China	INFINITI M35/M45	Y50	2007.11-	BCM					AC0653, AC0698	SP0391, SP0393
China	INFINITI M35/M45	Y50	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
China	INFINITI M35/M45	Y50	2007.11-	Multi AV	√	√	√	√		
China	INFINITI M35/M45	Y50	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI M35/M45	Y50	2007.11-	Adaptive light	√	√	√	√		SP0561, SP0562
China	INFINITI M35/M45	Y50	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
China	INFINITI M35/M45	Y50	2007.11-	All mode AWD/4WD	√	√	√	√	AC0957	
China	INFINITI M35/M45	Y50	2007.11-	Precrash seatbelt	√	√	√	√		
China	INFINITI M35/M45	Y50	2007.11-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
China	INFINITI M35/M45	Y50	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI M35/M45	Y50	2007.11-	Rearview camera	√			√		SP0570, SP0571
China	INFINITI M35H	HY51	2012.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
China	INFINITI M35H	HY51	2012.5-	Laser/radar	√	√	√	√		
China	INFINITI M35H	HY51	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI M35H	HY51	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
China	INFINITI M35H	HY51	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI M35H	HY51	2012.5-	Air bag	√	√	√	√		
China	INFINITI M35H	HY51	2012.5-	EPS/DAST 3	√	√	√	√		
China	INFINITI M35H	HY51	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI M35H	HY51	2012.5-	Motor control	√	√	√	√		
China	INFINITI M35H	HY51	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
China	INFINITI M35H	HY51	2012.5-	Transmission	√	√	√	√		SP0274, SP0276
China	INFINITI M35H	HY51	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
China	INFINITI M35H	HY51	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
China	INFINITI M35H	HY51	2012.5-	Pop up hood	√	√	√	√		
China	INFINITI M35H	HY51	2012.5-	Multi AV	√	√	√	√		SP0503
China	INFINITI M35H	HY51	2012.5-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
China	INFINITI M35H	HY51	2012.5-	HV battery	√	√	√	√	AC1121	
China	INFINITI M35H	HY51	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI M35H	HY51	2012.5-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
China	INFINITI M35H	HY51	2012.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI M35H	HY51	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI M35H	HY51	2012.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
China	INFINITI M35H	HY51	2012.5-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI M35H	HY51	2012.5-	CAN gateway	√	√	√			
China	INFINITI M35H	HY51	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
China	INFINITI M35H	HY51	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI M35H	HY51	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI M35H	HY51	2012.5-	Brake	√	√	√	√	AC1127	
China	INFINITI M35H	HY51	2012.5-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
China	INFINITI Q30	H15	2016.5-	Air pressure monitor	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	Air bag	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	EPS/DAST 3	√	√	√			
China	INFINITI Q30	H15	2016.5-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
China	INFINITI Q30	H15	2016.5-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
China	INFINITI Q30	H15	2016.5-	EHS/PKB	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	Transmission	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
China	INFINITI Q30	H15	2016.5-	ABS	√	√	√	√		SP0308
China	INFINITI Q30	H15	2016.5-	Multi AV	√	√	√	√		SP0501
China	INFINITI Q30	H15	2016.5-	HVAC	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	Auto drive position	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	Shift	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	All mode AWD/4WD	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	AVM	√	√		√		
China	INFINITI Q30	H15	2016.5-	Intelligent key	√	√	√	√		

China	INFINITI Q30	H15	2016.5-	CAN gateway	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	ANC	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	Telematics	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	FSCM	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	Siren control unit	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
China	INFINITI Q30	H15	2016.5-	Overhead Control Panel Unit	√			√		
China	INFINITI Q30	H15	2016.5-	Universal Garage Door Opener	√			√		
China	INFINITI Q30	H15	2016.5-	Upper control panel cont unit	√					
China	INFINITI Q30	H15	2016.5-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
China	INFINITI Q30	H15	2016.5-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
China	INFINITI Q30	H15	2016.5-	Light/Rain Sensor Module	√			√		
China	INFINITI Q30	H15	2016.5-	EC Mirror Compass	√					
China	INFINITI Q30	H15	2016.5-	Intelligent Battery Sensor	√					
China	INFINITI Q30	H15	2016.5-	Alarm siren	√			√		
China	INFINITI Q30	H15	2016.5-	Radar sensor	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	Steering column cont module	√	√	√			
China	INFINITI Q30	H15	2016.5-	ICC sensor	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	Trailer recognition control unit	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	H/L control module LH	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	Powertrain cont module	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	Side radar LH	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	LED H/L control module LH	√			√		
China	INFINITI Q30	H15	2016.5-	Steering Wheel Switch Pad	√			√		
China	INFINITI Q30	H15	2016.5-	Parking assist	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	Occupant Classification Unit	√			√		
China	INFINITI Q30	H15	2016.5-	Electronic Ignition Switch cont unit	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	H/L control module RH	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	Front camera unit	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	Side radar RH	√	√	√	√		
China	INFINITI Q30	H15	2016.5-	LED H/L control module RH	√			√		
China	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
China	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
China	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
China	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
China	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
China	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
China	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
China	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
China	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
China	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
China	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
China	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
China	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
China	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
China	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
China	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
China	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
China	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
China	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
China	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
China	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
China	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
China	INFINITI Q50	V37	2014.1-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
China	INFINITI Q50	V37	2014.1-	Laser/radar	√	√	√	√		
China	INFINITI Q50	V37	2014.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI Q50	V37	2014.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
China	INFINITI Q50	V37	2014.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI Q50	V37	2014.1-	Air bag	√	√	√	√		
China	INFINITI Q50	V37	2014.1-	EPS/DAST 3	√	√	√	√		
China	INFINITI Q50	V37	2014.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI Q50	V37	2014.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI Q50	V37	2014.1-	Transmission	√	√	√	√		SP0247, SP0274
China	INFINITI Q50	V37	2014.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
China	INFINITI Q50	V37	2014.1-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
China	INFINITI Q50	V37	2014.1-	Pop up hood	√	√	√	√		
China	INFINITI Q50	V37	2014.1-	Multi AV	√	√	√	√		SP0503

Xtool

China	INFINITI Q50	V37	2014.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
China	INFINITI Q50	V37	2014.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
China	INFINITI Q50	V37	2014.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
China	INFINITI Q50	V37	2014.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI Q50	V37	2014.1-	Occupant detection			√	√		SP0584
China	INFINITI Q50	V37	2014.1-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
China	INFINITI Q50	V37	2014.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI Q50	V37	2014.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
China	INFINITI Q50	V37	2014.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
China	INFINITI Q50	V37	2014.1-	DAST 2	√	√	√	√		
China	INFINITI Q50	V37	2014.1-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI Q50	V37	2014.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI Q50	V37	2014.1-	CAN gateway	√	√	√			
China	INFINITI Q50	V37	2014.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
China	INFINITI Q50	V37	2014.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI Q50	V37	2014.1-	DAST 1	√	√	√	√		
China	INFINITI Q50	V37	2014.1-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
China	INFINITI Q50	V37	2014.1-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
China	INFINITI Q50	V37	2014.1-	ANC	√	√	√	√	AC1024	
China	INFINITI Q50	V37	2014.1-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI Q50	V37	2014.1-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
China	INFINITI Q50	V37	2014.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI Q50	V37	2014.1-	HIGH BEAM ASSIST	√	√	√	√		
China	INFINITI Q50	V37	2014.1-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI Q50	V37	2014.1-	PMAS	√	√	√	√		
China	INFINITI Q50	V37	2014.1-	FSCM	√	√	√	√	AC1109	
China	INFINITI Q50	V37	2014.1-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
China	INFINITI Q50 HYBRID	HV37	2014.1-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
China	INFINITI Q50 HYBRID	HV37	2014.1-	Laser/radar	√	√	√	√		
China	INFINITI Q50 HYBRID	HV37	2014.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI Q50 HYBRID	HV37	2014.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
China	INFINITI Q50 HYBRID	HV37	2014.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI Q50 HYBRID	HV37	2014.1-	Air bag	√	√	√	√		
China	INFINITI Q50 HYBRID	HV37	2014.1-	EPS/DAST 3	√	√	√	√		
China	INFINITI Q50 HYBRID	HV37	2014.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI Q50 HYBRID	HV37	2014.1-	Motor control	√	√	√	√		
China	INFINITI Q50 HYBRID	HV37	2014.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI Q50 HYBRID	HV37	2014.1-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
China	INFINITI Q50 HYBRID	HV37	2014.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
China	INFINITI Q50 HYBRID	HV37	2014.1-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
China	INFINITI Q50 HYBRID	HV37	2014.1-	Pop up hood	√	√	√	√		
China	INFINITI Q50 HYBRID	HV37	2014.1-	Multi AV	√	√	√	√		SP0503
China	INFINITI Q50 HYBRID	HV37	2014.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
China	INFINITI Q50 HYBRID	HV37	2014.1-	HV battery	√	√	√	√	AC1121	
China	INFINITI Q50 HYBRID	HV37	2014.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI Q50 HYBRID	HV37	2014.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
China	INFINITI Q50 HYBRID	HV37	2014.1-	Occupant detection			√	√		SP0584
China	INFINITI Q50 HYBRID	HV37	2014.1-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
China	INFINITI Q50 HYBRID	HV37	2014.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI Q50 HYBRID	HV37	2014.1-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
China	INFINITI Q50 HYBRID	HV37	2014.1-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI Q50 HYBRID	HV37	2014.1-	DAST 2	√	√	√	√		
China	INFINITI Q50 HYBRID	HV37	2014.1-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI Q50 HYBRID	HV37	2014.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI Q50 HYBRID	HV37	2014.1-	CAN gateway	√	√	√			
China	INFINITI Q50 HYBRID	HV37	2014.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
China	INFINITI Q50 HYBRID	HV37	2014.1-	DAST 1	√	√	√	√		
China	INFINITI Q50 HYBRID	HV37	2014.1-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
China	INFINITI Q50 HYBRID	HV37	2014.1-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
China	INFINITI Q50 HYBRID	HV37	2014.1-	ANC	√	√	√	√	AC1024	
China	INFINITI Q50 HYBRID	HV37	2014.1-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI Q50 HYBRID	HV37	2014.1-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
China	INFINITI Q50 HYBRID	HV37	2014.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI Q50 HYBRID	HV37	2014.1-	HIGH BEAM ASSIST	√	√	√	√		
China	INFINITI Q50 HYBRID	HV37	2014.1-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI Q50 HYBRID	HV37	2014.1-	Brake	√	√	√	√	AC1127	
China	INFINITI Q50 HYBRID	HV37	2014.1-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
China	INFINITI Q50 HYBRID	HV37	2014.1-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
China	INFINITI Q50L	V37	2014.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
China	INFINITI Q50L	V37	2014.10-	Laser/radar	√	√	√	√		
China	INFINITI Q50L	V37	2014.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI Q50L	V37	2014.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
China	INFINITI Q50L	V37	2014.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI Q50L	V37	2014.10-	Air bag	√	√	√	√		
China	INFINITI Q50L	V37	2014.10-	EPS/DAST 3	√	√	√	√		
China	INFINITI Q50L	V37	2014.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI Q50L	V37	2014.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0307, AC0308, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI Q50L	V37	2014.10-	Transmission	√	√	√	√		SP0247, SP0274
China	INFINITI Q50L	V37	2014.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
China	INFINITI Q50L	V37	2014.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
China	INFINITI Q50L	V37	2014.10-	Pop up hood	√	√	√	√		
China	INFINITI Q50L	V37	2014.10-	Multi AV	√	√	√	√		SP0503
China	INFINITI Q50L	V37	2014.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
China	INFINITI Q50L	V37	2014.10-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
China	INFINITI Q50L	V37	2014.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI Q50L	V37	2014.10-	Occupant detection			√	√		SP0584
China	INFINITI Q50L	V37	2014.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
China	INFINITI Q50L	V37	2014.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI Q50L	V37	2014.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
China	INFINITI Q50L	V37	2014.10-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI Q50L	V37	2014.10-	DAST 2	√	√	√	√		
China	INFINITI Q50L	V37	2014.10-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI Q50L	V37	2014.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI Q50L	V37	2014.10-	CAN gateway	√	√	√			
China	INFINITI Q50L	V37	2014.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
China	INFINITI Q50L	V37	2014.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI Q50L	V37	2014.10-	DAST 1	√	√	√	√		
China	INFINITI Q50L	V37	2014.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
China	INFINITI Q50L	V37	2014.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
China	INFINITI Q50L	V37	2014.10-	ANC	√	√	√	√	AC1024	
China	INFINITI Q50L	V37	2014.10-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI Q50L	V37	2014.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
China	INFINITI Q50L	V37	2014.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI Q50L	V37	2014.10-	HIGH BEAM ASSIST	√	√	√	√		
China	INFINITI Q50L	V37	2014.10-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI Q50L	V37	2014.10-	FSCM	√	√	√	√	AC1109	
China	INFINITI Q50L	V37	2017.12-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
China	INFINITI Q50L	V37	2017.12-	Laser/radar	√	√	√	√	AC0994	

China	INFINITI Q50L	V37	2017.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI Q50L	V37	2017.12-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
China	INFINITI Q50L	V37	2017.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI Q50L	V37	2017.12-	Air bag	√	√	√	√		
China	INFINITI Q50L	V37	2017.12-	EPS/DAST 3	√	√	√	√		
China	INFINITI Q50L	V37	2017.12-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI Q50L	V37	2017.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI Q50L	V37	2017.12-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
China	INFINITI Q50L	V37	2017.12-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
China	INFINITI Q50L	V37	2017.12-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
China	INFINITI Q50L	V37	2017.12-	Pop up hood	√	√	√	√		
China	INFINITI Q50L	V37	2017.12-	Multi AV	√	√	√	√		SP0503
China	INFINITI Q50L	V37	2017.12-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
China	INFINITI Q50L	V37	2017.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI Q50L	V37	2017.12-	Occupant detection			√	√		SP0584
China	INFINITI Q50L	V37	2017.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
China	INFINITI Q50L	V37	2017.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI Q50L	V37	2017.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
China	INFINITI Q50L	V37	2017.12-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI Q50L	V37	2017.12-	DAST 2	√	√	√	√		
China	INFINITI Q50L	V37	2017.12-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI Q50L	V37	2017.12-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI Q50L	V37	2017.12-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
China	INFINITI Q50L	V37	2017.12-	DAST 1	√	√	√	√		
China	INFINITI Q50L	V37	2017.12-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
China	INFINITI Q50L	V37	2017.12-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
China	INFINITI Q50L	V37	2017.12-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
China	INFINITI Q50L	V37	2017.12-	ANC	√	√	√	√	AC1024	
China	INFINITI Q50L	V37	2017.12-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI Q50L	V37	2017.12-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
China	INFINITI Q50L	V37	2017.12-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI Q50L	V37	2017.12-	HIGH BEAM ASSIST	√	√	√	√		
China	INFINITI Q50L	V37	2017.12-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI Q50L	V37	2017.12-	6ch CAN GATEWAY	√	√	√	√		
China	INFINITI Q50L	V37	2017.12-	3ch CAN GATEWAY	√	√	√	√		
China	INFINITI Q50L	V37	2017.12-	FSCM	√	√	√	√	AC1109	
China	INFINITI Q60	CV37	2017.12-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
China	INFINITI Q60	CV37	2017.12-	Laser/radar	√	√	√	√	AC0994	
China	INFINITI Q60	CV37	2017.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI Q60	CV37	2017.12-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
China	INFINITI Q60	CV37	2017.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI Q60	CV37	2017.12-	Air bag	√	√	√	√		
China	INFINITI Q60	CV37	2017.12-	EPS/DAST 3	√	√	√	√		
China	INFINITI Q60	CV37	2017.12-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI Q60	CV37	2017.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI Q60	CV37	2017.12-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
China	INFINITI Q60	CV37	2017.12-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
China	INFINITI Q60	CV37	2017.12-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
China	INFINITI Q60	CV37	2017.12-	Pop up hood	√	√	√	√		
China	INFINITI Q60	CV37	2017.12-	Multi AV	√	√	√	√		SP0503
China	INFINITI Q60	CV37	2017.12-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
China	INFINITI Q60	CV37	2017.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
China	INFINITI Q60	CV37	2017.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI Q60	CV37	2017.12-	Occupant detection			√	√		SP0584
China	INFINITI Q60	CV37	2017.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
China	INFINITI Q60	CV37	2017.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI Q60	CV37	2017.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
China	INFINITI Q60	CV37	2017.12-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI Q60	CV37	2017.12-	DAST 2	√	√	√	√		
China	INFINITI Q60	CV37	2017.12-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI Q60	CV37	2017.12-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI Q60	CV37	2017.12-	CAN gateway	√	√	√			
China	INFINITI Q60	CV37	2017.12-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
China	INFINITI Q60	CV37	2017.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI Q60	CV37	2017.12-	DAST 1	√	√	√	√		
China	INFINITI Q60	CV37	2017.12-	Chassis control	√	√	√	√		
China	INFINITI Q60	CV37	2017.12-	ANC	√	√	√	√		
China	INFINITI Q60	CV37	2017.12-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI Q60	CV37	2017.12-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
China	INFINITI Q60	CV37	2017.12-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI Q60	CV37	2017.12-	HIGH BEAM ASSIST	√	√	√	√		
China	INFINITI Q60	CV37	2017.12-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI Q60	CV37	2017.12-	Lane camera 2	√	√	√	√		
China	INFINITI Q60	CV37	2017.12-	6ch CAN GATEWAY	√	√	√	√		
China	INFINITI Q60	CV37	2017.12-	ICC/ADAS 2	√	√	√	√		
China	INFINITI Q60	CV37	2017.12-	FSCM	√	√	√	√	AC1109	
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Laser/radar	√	√	√	√	AC0994	
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Air bag	√	√	√	√		
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Transmission	√	√	√	√		SP0274
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	BCM			√	√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Pop up hood	√	√	√	√		
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Multi AV	√	√	√	√		SP0503
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Precrash seatbelt	√	√	√	√		
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI Q60 COUPE	CV36	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
China	INFINITI Q60 COUPE	CV36	2013.9-	Laser/radar	√	√	√	√	AC0994	
China	INFINITI Q60 COUPE	CV36	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI Q60 COUPE	CV36	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
China	INFINITI Q60 COUPE	CV36	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI Q60 COUPE	CV36	2013.9-	Air bag	√	√	√	√		
China	INFINITI Q60 COUPE	CV36	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
China	INFINITI Q60 COUPE	CV36	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
China	INFINITI Q60 COUPE	CV36	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI Q60 COUPE	CV36	2013.9-	Transmission	√	√	√	√		SP0274
China	INFINITI Q60 COUPE	CV36	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
China	INFINITI Q60 COUPE	CV36	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
China	INFINITI Q60 COUPE	CV36	2013.9-	Pop up hood	√	√	√	√		
China	INFINITI Q60 COUPE	CV36	2013.9-	Multi AV	√	√	√	√		SP0503
China	INFINITI Q60 COUPE	CV36	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
China	INFINITI Q60 COUPE	CV36	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
China	INFINITI Q60 COUPE	CV36	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI Q60 COUPE	CV36	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI Q60 COUPE	CV36	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
China	INFINITI Q60 COUPE	CV36	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
China	INFINITI Q60 COUPE	CV36	2013.9-	Precrash seatbelt	√	√	√	√		
China	INFINITI Q60 COUPE	CV36	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI Q60 COUPE	CV36	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI Q70	Y51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
China	INFINITI Q70	Y51	2013.7-	Laser/radar	√	√	√	√	AC0994	
China	INFINITI Q70	Y51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI Q70	Y51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
China	INFINITI Q70	Y51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI Q70	Y51	2013.7-	Air bag	√	√	√	√		
China	INFINITI Q70	Y51	2013.7-	EPS/DAST 3	√	√	√	√		
China	INFINITI Q70	Y51	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI Q70	Y51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
China	INFINITI Q70	Y51	2013.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
China	INFINITI Q70	Y51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
China	INFINITI Q70	Y51	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
China	INFINITI Q70	Y51	2013.7-	Pop up hood	√	√	√	√		
China	INFINITI Q70	Y51	2013.7-	Multi AV	√	√	√	√		SP0503
China	INFINITI Q70	Y51	2013.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
China	INFINITI Q70	Y51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
China	INFINITI Q70	Y51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
China	INFINITI Q70	Y51	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI Q70	Y51	2013.7-	Occupant detection			√	√		SP0584
China	INFINITI Q70	Y51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
China	INFINITI Q70	Y51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI Q70	Y51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
China	INFINITI Q70	Y51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
China	INFINITI Q70	Y51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI Q70	Y51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI Q70	Y51	2013.7-	CAN gateway	√	√	√	√		
China	INFINITI Q70	Y51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
China	INFINITI Q70	Y51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI Q70	Y51	2013.7-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
China	INFINITI Q70	Y51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
China	INFINITI Q70	Y51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI Q70	Y51	2013.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
China	INFINITI Q70	Y51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI Q70	Y51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI Q70	Y51	2013.7-	6ch CAN GATEWAY	√	√	√	√		
China	INFINITI Q70	Y51	2013.7-	FSCM	√	√	√	√	AC1109	
China	INFINITI Q70 HYBRID	HY51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
China	INFINITI Q70 HYBRID	HY51	2013.7-	Laser/radar	√	√	√	√		
China	INFINITI Q70 HYBRID	HY51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI Q70 HYBRID	HY51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
China	INFINITI Q70 HYBRID	HY51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI Q70 HYBRID	HY51	2013.7-	Air bag	√	√	√	√		
China	INFINITI Q70 HYBRID	HY51	2013.7-	EPS/DAST 3	√	√	√	√		
China	INFINITI Q70 HYBRID	HY51	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI Q70 HYBRID	HY51	2013.7-	Motor control	√	√	√	√		
China	INFINITI Q70 HYBRID	HY51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
China	INFINITI Q70 HYBRID	HY51	2013.7-	Transmission	√	√	√	√		SP0274, SP0276
China	INFINITI Q70 HYBRID	HY51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
China	INFINITI Q70 HYBRID	HY51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
China	INFINITI Q70 HYBRID	HY51	2013.7-	Pop up hood	√	√	√	√		

China	INFINITI Q70 HYBRID	HY51	2013.7-	Multi AV	√	√	√	√		SP0503
China	INFINITI Q70 HYBRID	HY51	2013.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
China	INFINITI Q70 HYBRID	HY51	2013.7-	HV battery	√	√	√	√	AC1121	
China	INFINITI Q70 HYBRID	HY51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
China	INFINITI Q70 HYBRID	HY51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
China	INFINITI Q70 HYBRID	HY51	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI Q70 HYBRID	HY51	2013.7-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
China	INFINITI Q70 HYBRID	HY51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
China	INFINITI Q70 HYBRID	HY51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI Q70 HYBRID	HY51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
China	INFINITI Q70 HYBRID	HY51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
China	INFINITI Q70 HYBRID	HY51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI Q70 HYBRID	HY51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI Q70 HYBRID	HY51	2013.7-	CAN gateway	√	√	√	√		
China	INFINITI Q70 HYBRID	HY51	2013.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
China	INFINITI Q70 HYBRID	HY51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI Q70 HYBRID	HY51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
China	INFINITI Q70 HYBRID	HY51	2013.7-	ANC	√	√	√	√	AC1024	
China	INFINITI Q70 HYBRID	HY51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI Q70 HYBRID	HY51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI Q70 HYBRID	HY51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI Q70 HYBRID	HY51	2013.7-	Brake	√	√	√	√	AC1127	
China	INFINITI Q70 HYBRID	HY51	2013.7-	FSCM	√	√	√	√	AC1109	
China	INFINITI Q70 HYBRID	HY51	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
China	INFINITI Q70L HYBRID	HY51	2014.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
China	INFINITI Q70L HYBRID	HY51	2014.7-	Laser/radar	√	√	√	√	AC0994	
China	INFINITI Q70L HYBRID	HY51	2014.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI Q70L HYBRID	HY51	2014.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
China	INFINITI Q70L HYBRID	HY51	2014.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI Q70L HYBRID	HY51	2014.7-	Air bag	√	√	√	√		
China	INFINITI Q70L HYBRID	HY51	2014.7-	EPS/DAST 3	√	√	√	√		
China	INFINITI Q70L HYBRID	HY51	2014.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI Q70L HYBRID	HY51	2014.7-	Motor control	√	√	√	√		
China	INFINITI Q70L HYBRID	HY51	2014.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
China	INFINITI Q70L HYBRID	HY51	2014.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
China	INFINITI Q70L HYBRID	HY51	2014.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
China	INFINITI Q70L HYBRID	HY51	2014.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
China	INFINITI Q70L HYBRID	HY51	2014.7-	Pop up hood	√	√	√	√		
China	INFINITI Q70L HYBRID	HY51	2014.7-	Multi AV	√	√	√	√		SP0503
China	INFINITI Q70L HYBRID	HY51	2014.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
China	INFINITI Q70L HYBRID	HY51	2014.7-	HV battery	√	√	√	√	AC1121	
China	INFINITI Q70L HYBRID	HY51	2014.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
China	INFINITI Q70L HYBRID	HY51	2014.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
China	INFINITI Q70L HYBRID	HY51	2014.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI Q70L HYBRID	HY51	2014.7-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
China	INFINITI Q70L HYBRID	HY51	2014.7-	Occupant detection			√	√		SP0584
China	INFINITI Q70L HYBRID	HY51	2014.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
China	INFINITI Q70L HYBRID	HY51	2014.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI Q70L HYBRID	HY51	2014.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
China	INFINITI Q70L HYBRID	HY51	2014.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
China	INFINITI Q70L HYBRID	HY51	2014.7-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI Q70L HYBRID	HY51	2014.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI Q70L HYBRID	HY51	2014.7-	CAN gateway	√	√	√			
China	INFINITI Q70L HYBRID	HY51	2014.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
China	INFINITI Q70L HYBRID	HY51	2014.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI Q70L HYBRID	HY51	2014.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
China	INFINITI Q70L HYBRID	HY51	2014.7-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI Q70L HYBRID	HY51	2014.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
China	INFINITI Q70L HYBRID	HY51	2014.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI Q70L HYBRID	HY51	2014.7-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI Q70L HYBRID	HY51	2014.7-	Brake	√	√	√	√	AC1127	
China	INFINITI Q70L HYBRID	HY51	2014.7-	FSCM	√	√	√	√	AC1109	
China	INFINITI Q70L HYBRID	HY51	2014.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
China	INFINITI QX50	J50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
China	INFINITI QX50	J50	2013.7-	Laser/radar	√	√	√	√	AC0994	
China	INFINITI QX50	J50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI QX50	J50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
China	INFINITI QX50	J50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI QX50	J50	2013.7-	Air bag	√	√	√	√		
China	INFINITI QX50	I50	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
China	INFINITI QX50	I50	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
China	INFINITI QX50	J50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
China	INFINITI QX50	J50	2013.7-	Transmission	√	√	√	√		SP0274
China	INFINITI QX50	J50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
China	INFINITI QX50	J50	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
China	INFINITI QX50	I50	2013.7-	Multi AV	√	√	√	√		SP0503
China	INFINITI QX50	J50	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI QX50	J50	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI QX50	J50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI QX50	J50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
China	INFINITI QX50	J50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI QX50	J50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI QX50	J50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI QX50	J50	2013.7-	CAN gateway	√	√	√	√		
China	INFINITI QX50	J50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
China	INFINITI QX50	J50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
China	INFINITI QX50	I50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI QX50	I50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI QX50	I50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI QX50	I55	2018.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
China	INFINITI QX50	J55	2018.4-	Laser/radar	√	√	√	√		
China	INFINITI QX50	J55	2018.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
China	INFINITI QX50	J55	2018.4-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
China	INFINITI QX50	I55	2018.4-	Air bag	√	√	√	√		
China	INFINITI QX50	I55	2018.4-	EPS/DAST 3	√	√	√	√		
China	INFINITI QX50	I55	2018.4-	Meter/M&A	√	√	√	√		

China	INFINITI QX50	J55	2018.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI QX50	J55	2018.4-	EHS/PKB	√	√	√	√		SP0588
China	INFINITI QX50	J55	2018.4-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
China	INFINITI QX50	J55	2018.4-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
China	INFINITI QX50	J55	2018.4-	ABS	√	√	√	√		SP0313, SP0315
China	INFINITI QX50	J55	2018.4-	Total illum C/U	√	√	√	√		
China	INFINITI QX50	J55	2018.4-	Multi AV	√	√	√	√		SP0503
China	INFINITI QX50	J55	2018.4-	HVAC	√	√	√	√		
China	INFINITI QX50	J55	2018.4-	Auto drive position	√	√	√	√		
China	INFINITI QX50	J55	2018.4-	Auto back door	√	√	√	√		SP0611
China	INFINITI QX50	J55	2018.4-	Occupant detection			√	√		SP0584
China	INFINITI QX50	J55	2018.4-	Shift						
China	INFINITI QX50	J55	2018.4-	Adaptive light	√	√	√	√		SP0562
China	INFINITI QX50	I55	2018.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI QX50	I55	2018.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
China	INFINITI QX50	I55	2018.4-	All mode AWD/4WD	√	√	√	√		
China	INFINITI QX50	I55	2018.4-	DAST 2	√	√	√	√		
China	INFINITI QX50	J55	2018.4-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI QX50	J55	2018.4-	CAN gateway	√	√	√	√		
China	INFINITI QX50	J55	2018.4-	Lane camera	√	√	√	√		
China	INFINITI QX50	J55	2018.4-	DAST 1	√	√	√	√		
China	INFINITI QX50	J55	2018.4-	Chassis control	√	√	√	√		
China	INFINITI QX50	J55	2018.4-	ANC						
China	INFINITI QX50	J55	2018.4-	E-HUD	√	√	√	√		
China	INFINITI QX50	J55	2018.4-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI QX50	J55	2018.4-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI QX50	J55	2018.4-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI QX50	J55	2018.4-	6ch CAN GATEWAY	√	√	√	√		
China	INFINITI QX50	J55	2018.4-	3ch CAN GATEWAY	√	√	√	√		
China	INFINITI QX50	J55	2018.4-	ICC/ADAS 2	√	√	√	√		
China	INFINITI QX56	Z62	2010.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
China	INFINITI QX56	Z62	2010.6-	Laser/radar	√	√	√	√		
China	INFINITI QX56	Z62	2010.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI QX56	Z62	2010.6-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
China	INFINITI QX56	Z62	2010.6-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
China	INFINITI QX56	Z62	2010.6-	Air bag	√	√	√	√		
China	INFINITI QX56	Z62	2010.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
China	INFINITI QX56	Z62	2010.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI QX56	Z62	2010.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
China	INFINITI QX56	Z62	2010.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
China	INFINITI QX56	Z62	2010.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
China	INFINITI QX56	Z62	2010.6-	Multi AV	√	√	√	√		SP0503
China	INFINITI QX56	Z62	2010.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
China	INFINITI QX56	Z62	2010.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
China	INFINITI QX56	Z62	2010.6-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI QX56	Z62	2010.6-	Auto back door	√	√	√	√		
China	INFINITI QX56	Z62	2010.6-	Occupant detection			√	√		SP0584
China	INFINITI QX56	Z62	2010.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI QX56	Z62	2010.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI QX56	Z62	2010.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
China	INFINITI QX56	Z62	2010.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
China	INFINITI QX56	Z62	2010.6-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI QX56	Z62	2010.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI QX56	Z62	2010.6-	CAN gateway	√	√	√			
China	INFINITI QX56	Z62	2010.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
China	INFINITI QX56	Z62	2010.6-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI QX56	Z62	2010.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI QX56	Z62	2010.6-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI QX56	Z62	2010.6-	Rearview camera	√			√		SP0570, SP0571
China	INFINITI QX60	L50	2014.1-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
China	INFINITI QX60	L50	2014.1-	Laser/radar	√	√	√	√	AC0994	
China	INFINITI QX60	L50	2014.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI QX60	L50	2014.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
China	INFINITI QX60	L50	2014.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI QX60	L50	2014.1-	Air bag	√	√	√	√		
China	INFINITI QX60	L50	2014.1-	EPS/DAST 3	√	√	√	√		
China	INFINITI QX60	L50	2014.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI QX60	L50	2014.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI QX60	L50	2014.1-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
China	INFINITI QX60	L50	2014.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
China	INFINITI QX60	L50	2014.1-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
China	INFINITI QX60	L50	2014.1-	Multi AV	√	√	√	√		SP0503
China	INFINITI QX60	L50	2014.1-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
China	INFINITI QX60	L50	2014.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI QX60	L50	2014.1-	Auto back door	√	√	√	√		SP0611
China	INFINITI QX60	L50	2014.1-	Occupant detection			√	√		SP0584
China	INFINITI QX60	L50	2014.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI QX60	L50	2014.1-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
China	INFINITI QX60	L50	2014.1-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI QX60	L50	2014.1-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI QX60	L50	2014.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI QX60	L50	2014.1-	CAN gateway	√	√	√			
China	INFINITI QX60	L50	2014.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
China	INFINITI QX60	L50	2014.1-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
China	INFINITI QX60	L50	2014.1-	ANC	√	√	√	√	AC1024	
China	INFINITI QX60	L50	2014.1-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI QX60	L50	2014.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI QX60	L50	2014.1-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI QX60	L50	2014.1-	ICC/ADAS 2	√	√	√	√		
China	INFINITI QX60	L50	2014.1-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
China	INFINITI QX60 HYBRID	HL50	2014.4-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
China	INFINITI QX60 HYBRID	HL50	2014.4-	Laser/radar	√	√	√	√	AC0994	
China	INFINITI QX60 HYBRID	HL50	2014.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI QX60 HYBRID	HL50	2014.4-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
China	INFINITI QX60 HYBRID	HL50	2014.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI QX60 HYBRID	HL50	2014.4-	Air bag	√	√	√	√		
China	INFINITI QX60 HYBRID	HL50	2014.4-	EPS/DAST 3	√	√	√	√		
China	INFINITI QX60 HYBRID	HL50	2014.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
China	INFINITI QX60 HYBRID	HL50	2014.4-	Motor control	√	√	√	√		

China	INFINITI QX60 HYBRID	HL50	2014.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI QX60 HYBRID	HL50	2014.4-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
China	INFINITI QX60 HYBRID	HL50	2014.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
China	INFINITI QX60 HYBRID	HL50	2014.4-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
China	INFINITI QX60 HYBRID	HL50	2014.4-	Multi AV	√	√	√	√		SP0503
China	INFINITI QX60 HYBRID	HL50	2014.4-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
China	INFINITI QX60 HYBRID	HL50	2014.4-	HV battery	√	√	√	√	AC1121	
China	INFINITI QX60 HYBRID	HL50	2014.4-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI QX60 HYBRID	HL50	2014.4-	Auto back door	√	√	√	√		SP0611
China	INFINITI QX60 HYBRID	HL50	2014.4-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
China	INFINITI QX60 HYBRID	HL50	2014.4-	Occupant detection			√	√		SP0584
China	INFINITI QX60 HYBRID	HL50	2014.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI QX60 HYBRID	HL50	2014.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
China	INFINITI QX60 HYBRID	HL50	2014.4-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI QX60 HYBRID	HL50	2014.4-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI QX60 HYBRID	HL50	2014.4-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI QX60 HYBRID	HL50	2014.4-	CAN gateway	√	√	√			
China	INFINITI QX60 HYBRID	HL50	2014.4-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
China	INFINITI QX60 HYBRID	HL50	2014.4-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
China	INFINITI QX60 HYBRID	HL50	2014.4-	ANC	√	√	√	√		
China	INFINITI QX60 HYBRID	HL50	2014.4-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI QX60 HYBRID	HL50	2014.4-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI QX60 HYBRID	HL50	2014.4-	HIGH BEAM ASSIST	√	√	√	√		
China	INFINITI QX60 HYBRID	HL50	2014.4-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI QX60 HYBRID	HL50	2014.4-	ICC/ADAS 2	√	√	√	√		
China	INFINITI QX60 HYBRID	HL50	2014.4-	PMAS	√	√	√	√		
China	INFINITI QX60 HYBRID	HL50	2014.4-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
China	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
China	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
China	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
China	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
China	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
China	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
China	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
China	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
China	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
China	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
China	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
China	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
China	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
China	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
China	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
China	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
China	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
China	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
China	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
China	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
China	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
China	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
China	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
China	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
China	INFINITI QX80	Z62	2014.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
China	INFINITI QX80	Z62	2014.8-	Laser/radar	√	√	√	√		
China	INFINITI QX80	Z62	2014.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
China	INFINITI QX80	Z62	2014.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
China	INFINITI QX80	Z62	2014.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
China	INFINITI QX80	Z62	2014.8-	Air bag	√	√	√	√		
China	INFINITI QX80	Z62	2014.8-	EPS/DAST 3	√	√	√	√		SP0507
China	INFINITI QX80	Z62	2014.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
China	INFINITI QX80	Z62	2014.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
China	INFINITI QX80	Z62	2014.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
China	INFINITI QX80	Z62	2014.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
China	INFINITI QX80	Z62	2014.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
China	INFINITI QX80	Z62	2014.8-	Multi AV	√	√	√	√		SP0503
China	INFINITI QX80	Z62	2014.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
China	INFINITI QX80	Z62	2014.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
China	INFINITI QX80	Z62	2014.8-	Difference lock	√	√	√	√		
China	INFINITI QX80	Z62	2014.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
China	INFINITI QX80	Z62	2014.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
China	INFINITI QX80	Z62	2014.8-	Auto back door	√	√	√	√		
China	INFINITI QX80	Z62	2014.8-	Occupant detection			√	√		SP0584
China	INFINITI QX80	Z62	2014.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
China	INFINITI QX80	Z62	2014.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
China	INFINITI QX80	Z62	2014.8-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
China	INFINITI QX80	Z62	2014.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
China	INFINITI QX80	Z62	2014.8-	Precrash seatbelt	√	√	√	√		SP0612
China	INFINITI QX80	Z62	2014.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
China	INFINITI QX80	Z62	2014.8-	CAN gateway	√	√	√			
China	INFINITI QX80	Z62	2014.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
China	INFINITI QX80	Z62	2014.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
China	INFINITI QX80	Z62	2014.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
China	INFINITI QX80	Z62	2014.8-	Side radar left	√	√	√	√	AC1025	SP0582
China	INFINITI QX80	Z62	2014.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
China	INFINITI QX80	Z62	2014.8-	HIGH BEAM ASSIST	√	√	√	√		
China	INFINITI QX80	Z62	2014.8-	Side radar right	√	√	√	√	AC1026	SP0583
China	INFINITI QX80	Z62	2014.8-	ICC/ADAS 2	√	√	√	√		
China	INFINITI QX80	Z62	2014.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Colombia	INFINITI EX35/EX37	I50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Colombia	INFINITI EX35/EX37	I50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Colombia	INFINITI EX35/EX37	I50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Colombia	INFINITI EX35/EX37	I50	2011.1-	Air bag	√	√	√	√		

XTOOL

Colombia	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Colombia	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Colombia	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Colombia	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Colombia	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Colombia	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Colombia	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Colombia	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Colombia	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Colombia	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Colombia	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Colombia	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Colombia	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Colombia	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Colombia	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Colombia	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Colombia	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Colombia	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Colombia	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Colombia	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Colombia	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Colombia	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Colombia	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Colombia	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Colombia	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Colombia	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Colombia	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Colombia	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Colombia	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Colombia	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Colombia	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Colombia	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Colombia	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Colombia	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Colombia	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Colombia	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Colombia	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Colombia	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Colombia	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Colombia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Colombia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Colombia	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Colombia	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Colombia	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Colombia	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Colombia	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Colombia	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Colombia	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Colombia	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Colombia	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Colombia	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Colombia	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Colombia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Colombia	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Colombia	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Colombia	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Colombia	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Colombia	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Colombia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Colombia	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Colombia	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Colombia	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Colombia	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Colombia	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Colombia	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Colombia	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Colombia	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Colombia	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Colombia	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Colombia	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Colombia	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Colombia	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Colombia	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Colombia	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Colombia	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Colombia	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Colombia	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Colombia	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Colombia	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Colombia	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Colombia	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Colombia	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Colombia	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Colombia	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006. AC1007. AC1008. AC1009. AC1010	SP0575. SP0576. SP0577. SP0578. SP0579. SP0580
Colombia	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Colombia	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Colombia	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Colombia	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Colombia	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Colombia	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Colombia	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Colombia	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Colombia	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Colombia	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Colombia	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Colombia	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Colombia	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Colombia	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Colombia	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Colombia	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Colombia	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Colombia	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Colombia	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Colombia	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Colombia	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Colombia	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Colombia	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Colombia	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Colombia	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Colombia	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Colombia	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Colombia	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Colombia	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Colombia	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Colombia	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Colombia	INFINITI Q45	F50	2001.8-	Motor control						
Colombia	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Colombia	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288

Colombia	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Colombia	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Colombia	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Colombia	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Colombia	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Colombia	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Colombia	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Colombia	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Colombia	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Colombia	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Colombia	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Colombia	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Colombia	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Colombia	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Colombia	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Colombia	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Colombia	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Colombia	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Colombia	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Colombia	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Colombia	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Colombia	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Colombia	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Colombia	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Colombia	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Colombia	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Colombia	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Colombia	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Colombia	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Colombia	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Colombia	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Colombia	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Colombia	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Colombia	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Colombia	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Colombia	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Colombia	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Colombia	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Colombia	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Colombia	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Colombia	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Colombia	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Colombia	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Colombia	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Colombia	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Colombia	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Colombia	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Colombia	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Colombia	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Colombia	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Colombia	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Colombia	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Colombia	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Comores	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Comores	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Comores	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Comores	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Comores	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Comores	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Comores	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Comores	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Comores	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Comores	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Comores	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Comores	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Comores	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Comores	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Comores	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Comores	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Comores	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Comores	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Comores	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Comores	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Comores	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Comores	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Comores	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Comores	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Comores	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Comores	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Comores	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Comores	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Comores	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Comores	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Comores	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Comores	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Comores	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Comores	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Comores	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571

Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Comores	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0064, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Comores	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Comores	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Comores	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Comores	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Comores	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Comores	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Comores	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Comores	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Comores	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Comores	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Comores	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Comores	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Comores	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Comores	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Comores	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Comores	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Comores	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Comores	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Comores	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Comores	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Comores	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Comores	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Comores	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471

Comores	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Comores	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Comores	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Comores	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Comores	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Comores	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Comores	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Comores	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Comores	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Comores	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Comores	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Comores	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Comores	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Comores	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Comores	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Comores	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Comores	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Comores	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Comores	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Comores	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Comores	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Comores	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Comores	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Comores	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Comores	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Comores	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Comores	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Comores	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Comores	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Comores	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Comores	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Comores	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Comores	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Comores	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Comores	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Comores	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Comores	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Comores	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Comores	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Comores	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Comores	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Comores	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Comores	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Comores	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Comores	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Comores	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Comores	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Comores	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Comores	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Comores	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Comores	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Comores	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Comores	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Comores	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Comores	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Comores	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Comores	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Comores	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Comores	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Comores	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Comores	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Comores	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Comores	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Comores	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Comores	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Comores	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Comores	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Comores	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Comores	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Comores	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Comores	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Comores	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Comores	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	

XTOOL

Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Comores	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Comores	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Comores	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Comores	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Comores	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Comores	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Comores	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Comores	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Comores	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Comores	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Comores	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Comores	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Comores	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Comores	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Comores	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Comores	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Comores	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Comores	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Comores	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Comores	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Comores	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Comores	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Comores	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Comores	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Comores	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Comores	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Comores	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Comores	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Comores	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Comores	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Comores	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Comores	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Comores	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Comores	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Comores	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Comores	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Comores	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Comores	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Comores	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Comores	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Comores	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Comores	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Comores	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Comores	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Comores	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Comores	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Comores	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Comores	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Comores	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Comores	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Comores	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Comores	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Comores	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Comores	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Comores	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Comores	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Comores	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Comores	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Comores	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Comores	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Comores	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Comores	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Comores	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Comores	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Comores	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Comores	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Comores	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Comores	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Comores	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Comores	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Comores	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Comores	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Comores	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Comores	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Comores	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Comores	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Comores	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Comores	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Comores	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Comores	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Comores	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Comores	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Comores	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Comores	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Comores	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Comores	INFINITI QX50	I50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Comores	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Comores	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Comores	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Comores	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Comores	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Comores	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Comores	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Comores	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI QX50	I50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Comores	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Comores	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Comores	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Comores	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612

Comores	INFINITI QX50	I50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Comores	INFINITI QX50	I50	2013.8-	CAN gateway	√	√	√	√		
Comores	INFINITI QX50	I50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Comores	INFINITI QX50	I50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Comores	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Comores	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Comores	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Comores	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Comores	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Comores	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Comores	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Comores	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Comores	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Comores	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Comores	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Comores	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Comores	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Comores	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Comores	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Comores	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Comores	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Comores	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Comores	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Comores	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Comores	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Comores	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Comores	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Comores	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Comores	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Comores	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Comores	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Comores	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Comores	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Comores	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Comores	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Comores	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Comores	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Comores	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Comores	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Comores	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Comores	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Comores	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Comores	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Comores	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Comores	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Comores	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Comores	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Comores	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Comores	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Comores	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Comores	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Comores	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Comores	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Comores	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Comores	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Comores	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Comores	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Comores	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Comores	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Comores	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Comores	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Comores	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Comores	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Comores	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Comores	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Comores	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Comores	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Comores	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Comores	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Comores	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Comores	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Congo	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Congo	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Congo	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Congo	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Congo	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Congo	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Congo	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Congo	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Congo	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Congo	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Congo	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Congo	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Congo	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Congo	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Congo	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Congo	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Congo	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Congo	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Congo	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Congo	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Congo	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Congo	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Congo	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Congo	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Congo	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Congo	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Congo	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Congo	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Congo	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Congo	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Congo	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Congo	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Congo	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Congo	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Congo	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Congo	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Congo	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Congo	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Congo	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Congo	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Congo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Congo	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Congo	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Congo	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Congo	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Congo	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Congo	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Congo	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Congo	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Congo	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Congo	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Congo	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Congo	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Congo	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Congo	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Congo	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Congo	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Congo	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Congo	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Congo	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Congo	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Congo	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Congo	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Congo	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Congo	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Congo	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Congo	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Congo	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Congo	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Congo	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Congo	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Congo	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Congo	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Congo	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Congo	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Congo	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Congo	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Congo	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Congo	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Congo	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Congo	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Congo	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Congo	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Congo	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546,AC0547,AC0548,AC0549	SP0342,SP0343,SP0344
Congo	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002,AC0103,AC0214,AC0264,AC0265,AC0266,AC0267,AC0268,AC0269,AC0270,AC0271,AC0272,AC0273,AC0274,AC0275,AC0276,AC0277,AC0308,AC0310,AC0311,AC0312,AC0314,AC0315,AC0317,AC0320,AC0325,AC0327,AC0328,AC0329,AC0330,AC0331,AC0332	SP0034,SP0035,SP0159,SP0193,SP0194
Congo	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580,AC0674,AC0739,AC0740,AC0741,AC0742,AC0743,AC0744,AC0745,AC0746,AC0747,AC0748,AC0749,AC0750,AC0751,AC0752,AC0753,AC0754,AC0755,AC0756,AC0757,AC0758,AC0759,AC0760,AC0761,AC0762,AC0763,AC0764,AC0765,AC0766,AC0767,AC0768,AC0769,AC0770	
Congo	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Congo	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Congo	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Congo	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143,AC1144,AC1145,AC1146,AC1147,AC1148,AC1149,AC1150,AC1151,AC1152,AC1153,AC1154,AC1155,AC1156	
Congo	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Congo	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Congo	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Congo	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171,AC1172,AC1173,AC1174,AC1175	
Congo	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157,AC1158,AC1159,AC1160,AC1161,AC1162,AC1163,AC1164,AC1165,AC1166,AC1167,AC1168,AC1169,AC1170	SP0622
Congo	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Congo	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Congo	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Congo	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Congo	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Congo	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Congo	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Congo	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Congo	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Congo	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Congo	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Congo	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Congo	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Congo	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Congo	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Congo	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Congo	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Congo	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Congo	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0274
Congo	INFINITI Q50	V37	2013.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Congo	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
Congo	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Congo	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503

XTOOL

Congo	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Congo	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Congo	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Congo	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Congo	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Congo	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Congo	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Congo	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Congo	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Congo	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Congo	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Congo	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Congo	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Congo	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Congo	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Congo	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Congo	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Congo	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Congo	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Congo	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Congo	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Congo	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Congo	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Congo	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Congo	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Congo	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Congo	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Congo	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Congo	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Congo	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Congo	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Congo	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Congo	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Congo	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Congo	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Congo	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Congo	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Congo	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Congo	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Congo	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Congo	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Congo	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Congo	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Congo	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Congo	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Congo	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Congo	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Congo	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Congo	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Congo	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Congo	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Congo	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Congo	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Congo	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Congo	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Congo	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Congo	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Congo	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Congo	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Congo	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Congo	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Congo	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Congo	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	

Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Congo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Congo	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Congo	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Congo	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Congo	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Congo	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Congo	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Congo	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Congo	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Congo	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Congo	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Congo	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Congo	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Congo	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Congo	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Congo	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Congo	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Congo	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Congo	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Congo	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Congo	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Congo	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Congo	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Congo	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Congo	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Congo	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Congo	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Congo	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Congo	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Congo	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Congo	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Congo	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Congo	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Congo	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Congo	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Congo	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Congo	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Congo	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Congo	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Congo	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Congo	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Congo	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Congo	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Congo	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Congo	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Congo	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Congo	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Congo	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Congo	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Congo	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Congo	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Congo	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Congo	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Congo	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

Congo	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Congo	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Congo	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Congo	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Congo	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC039 2, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Congo	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Congo	INFINITI QX50	J50	2013.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Congo	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Congo	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Congo	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Congo	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Congo	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Congo	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Congo	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Congo	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Congo	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Congo	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Congo	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Congo	INFINITI QX50	I50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Congo	INFINITI QX50	I50	2013.8-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Congo	INFINITI QX50	I50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Congo	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Congo	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Congo	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Congo	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Congo	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Congo	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Congo	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Congo	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Congo	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Congo	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Congo	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Congo	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Congo	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Congo	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Congo	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Congo	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Congo	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Congo	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Congo	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Congo	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Congo	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Congo	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Congo	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Congo	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Congo	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Congo	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Congo	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Congo	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Congo	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Congo	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Congo	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Congo	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Congo	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Congo	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Congo	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Congo	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Congo	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Congo	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Congo	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Congo	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Congo	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Congo	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Congo	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Congo	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Congo	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Congo	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Congo	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Congo	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Congo	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Congo	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Congo	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Congo	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Congo	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Congo	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Congo	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Congo	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Congo	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Congo	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Congo	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Congo	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Congo	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Congo	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Congo	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Congo	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Congo	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Congo	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Costa	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Costa	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Costa	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Costa	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		

Costa rica	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Costa	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Costa	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Costa	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Costa	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Costa rica	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Costa	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Costa	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Costa	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Costa	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Costa	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Costa	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Costa	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Costa	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Costa	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Costa	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Costa	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Costa	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Costa	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Costa rica	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Costa	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Costa	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Costa	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Costa	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Costa	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Costa	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Costa rica	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Costa	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Costa	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Costa	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Costa	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Costa	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Costa	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Costa	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Costa	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Costa	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Costa	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Costa	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Costa	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Costa rica	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Costa rica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Costa	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Costa	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Costa	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Costa	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Costa	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Costa rica	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Costa	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Costa	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Costa rica	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Costa	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Costa	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Costa	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Costa rica	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Costa	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Costa	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Costa	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Costa	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Costa	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Costa	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Costa rica	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Costa	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Costa	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Costa	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Costa rica	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Costa rica	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Costa	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Costa	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Costa	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Costa	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Costa	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Costa	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Costa	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Costa	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Costa	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Costa	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Costa	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Costa	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Costa	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Costa	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Costa	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Costa	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Costa	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Costa	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006. AC1007. AC1008. AC1009. AC1010	SP0575. SP0576. SP0577. SP0578. SP0579. SP0580
Costa rica	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Costa	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Costa	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Costa	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Costa rica	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Costa rica	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Costa	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Costa rica	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Costa	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Costa	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Costa rica	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Costa	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Costa	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Costa rica	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Costa	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Costa	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Costa	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Costa	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Costa	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Costa	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Costa	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Costa	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Costa	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Costa	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Costa	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Costa	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Costa	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Costa rica	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Costa	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Costa	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Costa	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Costa	INFINITI Q45	F50	2001.8-	Motor control						
Costa rica	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Costa rica	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288

Costa rica	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Costa rica	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Costa	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Costa	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Costa	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Costa rica	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Costa	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Costa	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Costa	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Costa	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Costa	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Costa	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Costa rica	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Costa	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Costa	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Costa	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Costa	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Costa	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Costa	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Costa	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Costa	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Costa	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Costa	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Costa	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Costa	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Costa	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Costa	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Costa	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Costa	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Costa rica	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Costa rica	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Costa	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Costa	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Costa rica	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Costa	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Costa	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Costa	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Costa	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Costa rica	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Costa	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Costa	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Costa	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Costa	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Costa	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Costa	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Costa	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Costa	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Costa	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Costa	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Costa	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Costa	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Costa	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Costa	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Croatia	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Croatia	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Croatia	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Croatia	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Croatia	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Croatia	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Croatia	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Croatia	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Croatia	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Croatia	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Croatia	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Croatia	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Croatia	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Croatia	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Croatia	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Croatia	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Croatia	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Croatia	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Croatia	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Croatia	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Croatia	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Croatia	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Croatia	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Croatia	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Croatia	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Croatia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Croatia	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Croatia	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Croatia	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Croatia	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274

Croatia	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Croatia	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Croatia	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Croatia	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Croatia	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Croatia	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Croatia	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Croatia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Croatia	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Croatia	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Croatia	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Croatia	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Croatia	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Croatia	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Croatia	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Croatia	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Croatia	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Croatia	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Croatia	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Croatia	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Croatia	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Croatia	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Croatia	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Croatia	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Croatia	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Croatia	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Croatia	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Croatia	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Croatia	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Croatia	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Croatia	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Croatia	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Croatia	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Croatia	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Croatia	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Croatia	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Croatia	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Croatia	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Croatia	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Croatia	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Croatia	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Croatia	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Croatia	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Croatia	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Croatia	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Croatia	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Croatia	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Croatia	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Croatia	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Croatia	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Croatia	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Croatia	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Croatia	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Croatia	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Croatia	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Croatia	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Croatia	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Croatia	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Croatia	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Croatia	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		

Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Croatia	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Croatia	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Croatia	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Croatia	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Croatia	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Croatia	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Croatia	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Croatia	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Croatia	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Croatia	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Croatia	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Croatia	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Croatia	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Croatia	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Croatia	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Croatia	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Croatia	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Croatia	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Croatia	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Croatia	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Croatia	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Croatia	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Croatia	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Croatia	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Croatia	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Croatia	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Croatia	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Croatia	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Croatia	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Croatia	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		

Croatia	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Croatia	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Croatia	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Croatia	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Croatia	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Croatia	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Croatia	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Croatia	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Croatia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Croatia	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Croatia	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Croatia	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Croatia	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Croatia	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Croatia	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Croatia	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Croatia	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Croatia	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Croatia	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Croatia	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Croatia	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Croatia	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Croatia	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Croatia	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Croatia	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Croatia	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Croatia	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Croatia	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Croatia	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Croatia	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Croatia	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Croatia	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Croatia	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Croatia	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Croatia	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Croatia	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Croatia	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Croatia	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Croatia	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Croatia	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Croatia	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Croatia	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Croatia	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Croatia	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Croatia	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Croatia	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Croatia	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Croatia	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Croatia	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Croatia	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Croatia	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Croatia	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Croatia	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Croatia	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503

Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Croatia	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Croatia	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Croatia	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Croatia	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Croatia	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Croatia	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Croatia	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Croatia	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Croatia	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Croatia	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Croatia	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Croatia	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Croatia	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Croatia	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Croatia	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Croatia	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Croatia	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Croatia	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Croatia	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Croatia	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Croatia	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Croatia	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Croatia	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Croatia	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Croatia	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Croatia	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Croatia	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Croatia	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Croatia	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Croatia	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Croatia	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Croatia	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583

Croatia	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Croatia	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Croatia	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Croatia	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Croatia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Croatia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Croatia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Croatia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Croatia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Croatia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Croatia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Croatia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Croatia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Croatia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Croatia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Croatia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Croatia	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Croatia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Croatia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Croatia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Croatia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Croatia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Croatia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Croatia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Croatia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Croatia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Croatia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Croatia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Croatia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Croatia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Croatia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Croatia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Croatia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Croatia	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Croatia	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Croatia	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		

Croatia	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Croatia	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Croatia	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Croatia	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Croatia	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Croatia	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Croatia	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Croatia	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Croatia	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Croatia	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Croatia	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Croatia	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Croatia	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Croatia	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Croatia	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Croatia	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Croatia	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Croatia	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Croatia	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Croatia	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Croatia	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Croatia	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Croatia	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Croatia	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Croatia	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Croatia	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Croatia	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Croatia	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Croatia	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Croatia	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Croatia	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Croatia	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Croatia	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Croatia	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Croatia	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Croatia	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Croatia	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Croatia	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Croatia	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Croatia	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Croatia	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Croatia	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Croatia	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Croatia	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Croatia	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Croatia	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Croatia	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Croatia	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Croatia	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Croatia	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Croatia	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Croatia	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Croatia	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Croatia	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Croatia	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Croatia	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Croatia	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Croatia	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Croatia	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Croatia	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Croatia	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Croatia	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Croatia	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Croatia	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Croatia	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Croatia	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Croatia	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Croatia	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Croatia	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Croatia	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Croatia	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Curacao	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Curacao	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Curacao	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Curacao	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Curacao	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Curacao	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Curacao	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Curacao	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Curacao	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Curacao	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Curacao	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Curacao	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Curacao	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Curacao	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Curacao	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Curacao	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Curacao	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Curacao	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Curacao	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Curacao	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Curacao	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Curacao	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Curacao	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Curacao	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Curacao	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Curacao	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Curacao	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Curacao	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Curacao	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Curacao	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Curacao	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Curacao	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Curacao	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Curacao	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Curacao	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Curacao	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Curacao	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Curacao	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Curacao	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Curacao	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Curacao	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Curacao	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Curacao	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556

Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Curacao	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Curacao	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Curacao	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Curacao	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Curacao	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Curacao	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Curacao	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Curacao	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Curacao	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Curacao	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Curacao	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Curacao	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Curacao	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Curacao	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Curacao	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Curacao	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Curacao	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Curacao	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Curacao	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Curacao	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Curacao	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Curacao	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Curacao	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Curacao	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Curacao	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Curacao	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Curacao	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Curacao	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Curacao	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Curacao	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Curacao	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Curacao	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Curacao	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Curacao	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Curacao	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Curacao	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Curacao	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Curacao	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Curacao	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Curacao	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Curacao	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Curacao	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Curacao	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Curacao	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Curacao	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Curacao	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Curacao	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Curacao	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Curacao	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Curacao	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Curacao	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Curacao	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Curacao	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Curacao	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Curacao	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503

Curacao	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Curacao	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Curacao	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Curacao	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Curacao	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Curacao	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Curacao	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Curacao	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Curacao	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Curacao	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Curacao	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Curacao	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Curacao	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Curacao	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Curacao	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Curacao	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Curacao	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Curacao	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Curacao	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Curacao	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Curacao	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Curacao	INFINITI Q45	F50	2001.8-	Motor control						
Curacao	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Curacao	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Curacao	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Curacao	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Curacao	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Curacao	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Curacao	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Curacao	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Curacao	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Curacao	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Curacao	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Curacao	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Curacao	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Curacao	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Curacao	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Curacao	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Curacao	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Curacao	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Curacao	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Curacao	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Curacao	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Curacao	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Curacao	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Curacao	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Curacao	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Curacao	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Curacao	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Curacao	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Curacao	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Curacao	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Curacao	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Curacao	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Curacao	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Curacao	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Curacao	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Curacao	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Curacao	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Curacao	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Curacao	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Curacao	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Curacao	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Curacao	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Curacao	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Curacao	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Curacao	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Curacao	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Curacao	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Curacao	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Curacao	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Curacao	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Curacao	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Curacao	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Curacao	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Curacao	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Curacao	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Cyprus	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Cyprus	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Cyprus	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Cyprus	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Cyprus	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Cyprus	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Cyprus	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Cyprus	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Cyprus	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Cyprus	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Cyprus	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Cyprus	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Cyprus	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cyprus	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Cyprus	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Cyprus	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cyprus	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Cyprus	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Cyprus	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Cyprus	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274

XTOOL

Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Cyprus	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Cyprus	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Cyprus	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Cyprus	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Cyprus	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Cyprus	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Cyprus	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Cyprus	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Cyprus	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Cyprus	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Cyprus	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Cyprus	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Cyprus	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Cyprus	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Cyprus	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Cyprus	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Cyprus	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Cyprus	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Cyprus	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Cyprus	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Cyprus	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Cyprus	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Cyprus	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Cyprus	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Cyprus	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cyprus	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276

Cyprus	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Cyprus	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Cyprus	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Cyprus	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Cyprus	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cyprus	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Cyprus	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Cyprus	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cyprus	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cyprus	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cyprus	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Cyprus	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Cyprus	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Cyprus	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Cyprus	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Cyprus	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Cyprus	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Cyprus	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Cyprus	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Cyprus	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Cyprus	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Cyprus	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Cyprus	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Cyprus	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Cyprus	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Cyprus	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Cyprus	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Cyprus	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Cyprus	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Cyprus	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Cyprus	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Cyprus	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Cyprus	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Cyprus	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Cyprus	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Cyprus	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Cyprus	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		

Cyprus	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Cyprus	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Cyprus	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Cyprus	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Cyprus	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Cyprus	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Cyprus	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Cyprus	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Cyprus	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Cyprus	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Cyprus	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Cyprus	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Cyprus	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cyprus	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Cyprus	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Cyprus	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Cyprus	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Cyprus	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Cyprus	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Cyprus	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cyprus	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Cyprus	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Cyprus	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Cyprus	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Cyprus	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cyprus	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Cyprus	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cyprus	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cyprus	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Cyprus	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Cyprus	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Cyprus	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cyprus	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Cyprus	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Cyprus	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Cyprus	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Cyprus	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cyprus	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Cyprus	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Cyprus	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Cyprus	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Cyprus	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Cyprus	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Cyprus	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Cyprus	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Cyprus	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Cyprus	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Cyprus	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cyprus	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		

XTOOL

Cyprus	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Cyprus	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Cyprus	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Cyprus	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Cyprus	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Cyprus	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Cyprus	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Cyprus	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0311,AC0314,AC0315,AC0320,AC0325,AC0327,AC0330,AC0331,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247,SP0265,SP0274,SP0276
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Cyprus	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0009,SP0016,SP0032,SP0033,SP0038,SP0039,SP0053,SP0063,SP0064,SP0074,SP0079,SP0082,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Cyprus	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Cyprus	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Cyprus	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Cyprus	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Cyprus	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Cyprus	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Cyprus	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Cyprus	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351

Cyprus	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cyprus	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Cyprus	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Cyprus	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Cyprus	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Cyprus	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cyprus	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Cyprus	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Cyprus	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cyprus	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Cyprus	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Cyprus	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Cyprus	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Cyprus	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Cyprus	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Cyprus	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Cyprus	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Cyprus	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Cyprus	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Cyprus	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Cyprus	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Cyprus	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cyprus	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Cyprus	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Cyprus	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Cyprus	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Cyprus	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Cyprus	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cyprus	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cyprus	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Cyprus	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Cyprus	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Cyprus	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Cyprus	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Cyprus	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Cyprus	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cyprus	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Cyprus	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Cyprus	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Cyprus	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cyprus	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cyprus	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cyprus	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Cyprus	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Cyprus	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cyprus	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Cyprus	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Cyprus	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Cyprus	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cyprus	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Cyprus	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Cyprus	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Cyprus	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cyprus	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Cyprus	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Cyprus	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cyprus	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Cyprus	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Cyprus	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Cyprus	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Cyprus	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Cyprus	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Cyprus	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Cyprus	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Cyprus	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Cyprus	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Cyprus	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Cyprus	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cyprus	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cyprus	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Cyprus	INFINITI QX50	I50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cyprus	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI QX50	I50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cyprus	INFINITI QX50	I50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cyprus	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cyprus	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Cyprus	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Cyprus	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Cyprus	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Cyprus	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	

Cyprus	INFINITI QX50	I50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Cyprus	INFINITI QX50	I50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cyprus	INFINITI QX50	I50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Cyprus	INFINITI QX56	IA60	2007.8-	ICC/ADAS						
Cyprus	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Cyprus	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Cyprus	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Cyprus	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Cyprus	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Cyprus	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Cyprus	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Cyprus	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Cyprus	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Cyprus	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Cyprus	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Cyprus	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Cyprus	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Cyprus	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Cyprus	INFINITI QX56	IA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Cyprus	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Cyprus	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Cyprus	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Cyprus	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Cyprus	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Cyprus	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Cyprus	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Cyprus	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Cyprus	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Cyprus	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Cyprus	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Cyprus	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Cyprus	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Cyprus	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Cyprus	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Cyprus	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Cyprus	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Cyprus	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Cyprus	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Cyprus	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Cyprus	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Cyprus	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Cyprus	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Cyprus	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Cyprus	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Cyprus	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Cyprus	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Cyprus	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Cyprus	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Cyprus	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Cyprus	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Cyprus	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Cyprus	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Czech	INFINITI EX35/EX30D	I50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Czech	INFINITI EX35/EX30D	I50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI EX35/EX30D	I50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Czech	INFINITI EX35/EX30D	I50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI EX35/EX30D	I50	2009.7-	Air bag	√	√	√	√		
Czech	INFINITI EX35/EX30D	I50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Czech	INFINITI EX35/EX30D	I50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Czech	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Czech	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Czech	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Czech	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Czech	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Czech	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Czech	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Czech	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Czech	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Czech	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Czech	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Czech	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Czech	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Czech	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Czech	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Czech	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Czech	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Czech	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Czech	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Czech	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Czech	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Czech	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Czech	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Czech	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Czech	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	

Czech	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Czech	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Czech	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Czech	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Czech	INFINITI FX35/FX45	S50	2006.7-	BCM				√	AC0653, AC0695	SP0372, SP0429
Czech	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Czech	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Czech	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Czech	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Czech	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Czech	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Czech	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Czech	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Czech	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Czech	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Czech	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Czech	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Czech	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Czech	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Czech	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Czech	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Czech	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Czech	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Czech	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Czech	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Czech	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Czech	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Czech	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Czech	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Czech	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Czech	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Czech	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Czech	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Czech	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Czech	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Czech	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		

Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Czech	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Czech	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Czech	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Czech	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Czech	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Czech	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Czech	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Czech	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Czech	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Czech	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Czech	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Czech	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Czech	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Czech	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Czech	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Czech	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Czech	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Czech	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Czech	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Czech	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Czech	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Czech	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Czech	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Czech	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Czech	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Czech	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Czech	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Czech	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Czech	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Czech	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Czech	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Czech	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Czech	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Czech	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Czech	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Czech	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Czech	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Czech	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Czech	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Czech	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Czech	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Czech	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Czech	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Czech	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Czech	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Czech	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Czech	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Czech	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Czech	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Czech	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Czech	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Czech	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Czech	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Czech	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Czech	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Czech	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Czech	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Czech	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Czech	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Czech	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Czech	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Czech	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Czech	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Czech	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Czech	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Czech	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Czech	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Czech	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Czech	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Czech	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Czech	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Czech	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Czech	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Czech	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Czech	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Czech	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Czech	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Czech	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Czech	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		

Xtool

Czech	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Czech	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Czech	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Czech	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Czech	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Czech	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Czech	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Czech	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Czech	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Czech	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Czech	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Czech	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Czech	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Czech	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Czech	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Czech	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Czech	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Czech	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Czech	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Czech	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Czech	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Czech	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Czech	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Czech	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Czech	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Czech	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Czech	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Czech	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Czech	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Czech	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Czech	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Czech	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Czech	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Czech	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Czech	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Czech	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Czech	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Czech	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Czech	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Czech	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Czech	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Czech	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Czech	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Czech	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Czech	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Czech	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Czech	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Czech	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Czech	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Czech	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Czech	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Czech	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Czech	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612

Xtool

Czech	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Czech	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Czech	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Czech	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Czech	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Czech	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Czech	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Czech	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Czech	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Czech	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Czech	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Czech	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Czech	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Czech	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Czech	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Czech	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Czech	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Czech	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Czech	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Czech	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Czech	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Czech	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Czech	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		

Czech	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Czech	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Czech	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Czech	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Czech	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Czech	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Czech	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Czech	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Czech	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Czech	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Czech	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Czech	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Czech	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Czech	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Czech	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Czech	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Czech	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Czech	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Czech	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Czech	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Czech	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Czech	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Czech	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Czech	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Czech	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Czech	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Czech	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Czech	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Czech	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Czech	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Czech	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Czech	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Czech	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Czech	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Czech	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Czech	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Czech	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Czech	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Czech	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Czech	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Czech	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Czech	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Czech	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Czech	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Czech	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Czech	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Czech	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Czech	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Czech	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Czech	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Czech	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Czech	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Czech	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Czech	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Czech	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Czech	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Czech	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Czech	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Czech	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Czech	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Czech	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Czech	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Czech	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Czech	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Czech	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Czech	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Czech	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Czech	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Czech	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Czech	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Czech	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Czech	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Czech	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Czech	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Czech	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Czech	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Czech	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Czech	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Czech	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Czech	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Czech	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Czech	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Czech	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Czech	INFINITI Q70	Y51	2013.9-	PSCM	√	√	√	√	AC1109	
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Czech	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Czech	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Czech	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Czech	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Czech	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Czech	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Czech	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Czech	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Czech	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Czech	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Czech	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Czech	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Czech	INFINITI QX50	I50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Czech	INFINITI QX50	I50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Czech	INFINITI QX50	I50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Czech	INFINITI QX50	I50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Czech	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Czech	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Czech	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Czech	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Czech	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Czech	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Czech	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Czech	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Czech	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Czech	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Czech	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Czech	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Czech	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Czech	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Czech	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Czech	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Czech	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Czech	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Czech	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Czech	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Czech	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Czech	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Czech	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Czech	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Czech	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Czech	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Czech	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Czech	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Czech	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Czech	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Czech	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Czech	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Czech	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Czech	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Czech	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Czech	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Czech	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Czech	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Czech	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Czech	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Czech	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Czech	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Czech	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Czech	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Czech	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Czech	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Czech	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Czech	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Czech	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Czech	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Czech	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Czech	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Czech	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Czech	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Czech	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Denmark	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Denmark	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Denmark	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI EX35/EX30D	I50	2009.7-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Denmark	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Denmark	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Denmark	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Denmark	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Denmark	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Denmark	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Denmark	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Denmark	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Denmark	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Denmark	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Denmark	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
Denmark	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Denmark	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Denmark	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Denmark	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Denmark	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Denmark	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Denmark	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Denmark	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Denmark	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Denmark	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Denmark	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Denmark	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Denmark	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Denmark	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	

Denmark	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Denmark	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Denmark	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Denmark	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Denmark	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Denmark	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Denmark	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Denmark	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Denmark	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Denmark	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Denmark	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Denmark	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Denmark	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Denmark	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Denmark	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Denmark	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Denmark	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Denmark	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Denmark	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Denmark	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Denmark	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Denmark	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Denmark	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Denmark	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Denmark	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Denmark	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Denmark	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Denmark	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Denmark	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Denmark	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Denmark	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Denmark	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Denmark	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Denmark	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Denmark	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Denmark	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Denmark	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Denmark	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Denmark	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Denmark	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Denmark	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Denmark	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Denmark	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Denmark	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Denmark	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Denmark	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Denmark	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Denmark	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Denmark	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Denmark	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Denmark	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Denmark	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Denmark	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Denmark	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Denmark	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Denmark	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Denmark	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Denmark	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Denmark	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Denmark	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Denmark	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Denmark	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Denmark	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Denmark	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Denmark	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Denmark	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Denmark	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Denmark	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Denmark	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Denmark	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Denmark	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Denmark	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Denmark	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Denmark	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Denmark	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Denmark	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Denmark	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Denmark	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Denmark	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Denmark	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Denmark	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Denmark	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Denmark	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Denmark	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Denmark	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Denmark	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Denmark	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Denmark	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Denmark	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Denmark	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Denmark	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		

Denmark	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Denmark	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Denmark	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Denmark	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Denmark	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Denmark	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Denmark	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Denmark	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Denmark	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Denmark	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Denmark	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Denmark	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Denmark	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Denmark	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Denmark	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Denmark	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Denmark	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Denmark	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Denmark	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Denmark	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Denmark	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Denmark	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Denmark	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Denmark	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Denmark	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Denmark	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Denmark	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Denmark	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Denmark	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Denmark	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Denmark	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Denmark	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Denmark	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Denmark	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Denmark	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Denmark	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Denmark	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Denmark	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Denmark	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Denmark	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Denmark	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Denmark	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Denmark	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Denmark	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Denmark	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Denmark	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Denmark	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Denmark	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Denmark	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Denmark	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Denmark	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Denmark	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Denmark	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Denmark	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Denmark	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Denmark	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Denmark	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		

Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Denmark	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Denmark	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Denmark	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Denmark	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Denmark	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Denmark	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Denmark	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Denmark	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Denmark	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Denmark	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Denmark	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Denmark	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Denmark	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Denmark	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Denmark	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584

Denmark	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Denmark	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Denmark	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Denmark	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Denmark	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Denmark	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Denmark	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Denmark	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Denmark	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Denmark	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Denmark	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Denmark	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Denmark	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Denmark	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Denmark	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Denmark	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Denmark	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Denmark	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Denmark	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Denmark	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Denmark	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Denmark	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Denmark	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Denmark	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Denmark	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Denmark	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Denmark	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Denmark	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Denmark	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Denmark	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Denmark	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Denmark	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Denmark	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Denmark	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Denmark	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584

Denmark	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Denmark	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Denmark	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Denmark	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Denmark	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Denmark	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Denmark	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Denmark	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Denmark	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Denmark	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Denmark	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Denmark	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Denmark	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Denmark	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Denmark	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Denmark	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Denmark	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Denmark	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√	√		
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Denmark	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Denmark	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Denmark	INFINITI QX50	I50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Denmark	INFINITI QX50	I50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Denmark	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Denmark	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Denmark	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Denmark	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Denmark	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Denmark	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Denmark	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Denmark	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Denmark	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Denmark	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Denmark	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Denmark	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Denmark	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Denmark	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Denmark	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Denmark	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Denmark	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Denmark	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Denmark	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Denmark	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Denmark	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Denmark	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Denmark	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Denmark	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Denmark	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Denmark	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Denmark	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Denmark	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Denmark	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Denmark	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544

Denmark	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Denmark	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Denmark	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Denmark	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Denmark	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Denmark	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Denmark	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Denmark	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Denmark	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Denmark	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Denmark	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Denmark	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Denmark	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Denmark	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Denmark	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Denmark	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Denmark	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Denmark	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Denmark	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Denmark	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Denmark	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Denmark	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Denmark	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Denmark	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Denmark	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Denmark	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Denmark	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Denmark	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Denmark	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Denmark	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Denmark	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Denmark	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Denmark	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Denmark	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Denmark	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Denmark	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Djibouti	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Djibouti	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Djibouti	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Djibouti	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Djibouti	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Djibouti	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Djibouti	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Djibouti	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Djibouti	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Djibouti	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Djibouti	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Djibouti	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Djibouti	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Djibouti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Djibouti	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Djibouti	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Djibouti	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Djibouti	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Djibouti	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Djibouti	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Djibouti	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Djibouti	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Djibouti	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Djibouti	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Djibouti	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Djibouti	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Djibouti	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Djibouti	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Djibouti	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Djibouti	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Djibouti	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Djibouti	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Djibouti	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Djibouti	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Djibouti	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Djibouti	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Djibouti	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Djibouti	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Djibouti	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Djibouti	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			

Djibouti	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Djibouti	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Djibouti	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Djibouti	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Djibouti	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Djibouti	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Djibouti	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Djibouti	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Djibouti	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Djibouti	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Djibouti	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Djibouti	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Djibouti	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Djibouti	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Djibouti	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Djibouti	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Djibouti	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Djibouti	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Djibouti	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Djibouti	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Djibouti	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Djibouti	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Djibouti	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Djibouti	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Djibouti	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Djibouti	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Djibouti	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Djibouti	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Djibouti	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Djibouti	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Djibouti	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Djibouti	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Djibouti	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Djibouti	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Djibouti	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Djibouti	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Djibouti	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Djibouti	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Djibouti	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Djibouti	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Djibouti	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Djibouti	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Djibouti	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Djibouti	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Djibouti	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Djibouti	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Djibouti	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Djibouti	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Djibouti	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Djibouti	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Djibouti	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Djibouti	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Djibouti	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Djibouti	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Djibouti	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Djibouti	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Djibouti	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315

Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Djibouti	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Djibouti	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Djibouti	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Djibouti	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Djibouti	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Djibouti	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Djibouti	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Djibouti	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Djibouti	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Djibouti	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Djibouti	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Djibouti	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Djibouti	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Djibouti	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Djibouti	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Djibouti	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Djibouti	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Djibouti	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Djibouti	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Djibouti	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Djibouti	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Djibouti	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Djibouti	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Djibouti	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Djibouti	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Djibouti	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Djibouti	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Djibouti	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Djibouti	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Djibouti	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Djibouti	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Djibouti	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Djibouti	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Djibouti	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Djibouti	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Djibouti	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Djibouti	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Djibouti	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Djibouti	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Djibouti	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Djibouti	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Djibouti	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Djibouti	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Djibouti	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Djibouti	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Djibouti	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Djibouti	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Djibouti	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Djibouti	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Djibouti	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Djibouti	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Djibouti	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Djibouti	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Djibouti	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Djibouti	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Djibouti	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Djibouti	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Djibouti	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Djibouti	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Djibouti	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Djibouti	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Djibouti	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Djibouti	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Djibouti	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Djibouti	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Djibouti	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Djibouti	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Djibouti	INFINITI QX50	I50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Djibouti	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Djibouti	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Djibouti	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Djibouti	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Djibouti	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Djibouti	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Djibouti	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Djibouti	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Djibouti	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Djibouti	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Djibouti	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Djibouti	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Djibouti	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Djibouti	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Djibouti	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Djibouti	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Djibouti	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Djibouti	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Djibouti	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Djibouti	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Djibouti	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Djibouti	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Djibouti	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Djibouti	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Djibouti	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Djibouti	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Djibouti	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Djibouti	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Djibouti	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Djibouti	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Djibouti	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Djibouti	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Djibouti	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Djibouti	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Djibouti	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Djibouti	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Djibouti	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Djibouti	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Djibouti	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Djibouti	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Djibouti	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Djibouti	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Djibouti	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Djibouti	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Djibouti	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Djibouti	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Djibouti	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Djibouti	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Djibouti	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Djibouti	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Djibouti	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Djibouti	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Djibouti	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Djibouti	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Djibouti	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Djibouti	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Djibouti	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Djibouti	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Djibouti	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Djibouti	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Djibouti	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Djibouti	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Djibouti	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Djibouti	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Djibouti	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Djibouti	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Djibouti	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Djibouti	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Djibouti	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Djibouti	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Djibouti	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Djibouti	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Djibouti	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Djibouti	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Djibouti	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Djibouti	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Djibouti	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Djibouti	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Djibouti	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Djibouti	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Djibouti	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Djibouti	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Djibouti	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Dominica island	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominica island	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Dominica island	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominica island	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Dominica island	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Dominica island	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Dominica island	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dominica island	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Dominica island	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Dominica island	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominica island	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominica island	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominica island	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dominica island	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominica island	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Dominica island	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Dominica island	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominica island	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Dominica island	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Dominica island	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Dominica island	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dominica island	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Dominica island	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Dominica island	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Dominica island	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Dominica island	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Dominica island	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominica island	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Dominica island	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	

Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Dominica island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Dominica island	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominica island	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Dominica island	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Dominica island	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominica island	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Dominica island	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dominica island	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Dominica island	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Dominica island	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Dominica island	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dominica island	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Dominica island	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Dominica island	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominica island	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Dominica island	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominica island	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Dominica island	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominica island	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Dominica island	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Dominica island	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Dominica island	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Dominica island	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Dominica island	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Dominica island	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Dominica island	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominica island	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Dominica island	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Dominica island	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominica island	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Dominica island	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dominica island	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Dominica island	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Dominica island	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Dominica island	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Dominica island	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Dominica island	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Dominica island	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Dominica island	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Dominica island	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Dominica island	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominica island	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominica island	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominica island	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dominica island	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominica island	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Dominica island	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Dominica island	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Dominica island	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominica island	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Dominica island	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Dominica island	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Dominica island	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Dominica island	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dominica island	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Dominica island	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Dominica island	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Dominica island	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Dominica island	INFINITI Q45	F50	2001.8-	Motor control						
Dominica island	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominica island	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Dominica island	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Dominica island	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Dominica island	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Dominica island	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Dominica island	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Dominica island	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominica island	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Dominica island	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Dominica island	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Dominica island	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dominica island	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Dominica island	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dominica island	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Dominica island	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Dominica island	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominica island	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Dominica island	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Dominica island	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Dominica island	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Dominica island	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Dominica island	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Dominica island	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Dominica island	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Dominica island	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Dominica island	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Dominica island	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Dominica island	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Dominica island	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Dominica island	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Dominica island	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Dominica island	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Dominica island	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Dominica island	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Dominica island	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominica island	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Dominica island	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Dominica island	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315

Dominica island	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Dominica island	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Dominica island	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Dominica island	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominica island	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Dominica island	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Dominica island	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominica island	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominica island	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Dominica island	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Dominica island	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Dominica island	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Dominica island	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Dominica island	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Dominica island	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dominica island	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Dominican rep.	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominican rep.	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Dominican rep.	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Dominican rep.	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Dominican rep.	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominican rep.	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Dominican rep.	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Dominican rep.	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		

XTOOL

Dominican rep.	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dominican rep.	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Dominican rep.	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Dominican rep.	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Dominican rep.	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dominican rep.	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Dominican rep.	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Dominican rep.	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominican rep.	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Dominican rep.	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominican rep.	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Dominican rep.	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Dominican rep.	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Dominican rep.	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Dominican rep.	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Dominican rep.	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Dominican rep.	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Dominican rep.	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dominican rep.	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Dominican rep.	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Dominican rep.	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Dominican rep.	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Dominican rep.	INFINITI Q45	F50	2001.8-	Motor control						
Dominican rep.	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominican rep.	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Dominican rep.	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471

Dominican rep.	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Dominican rep.	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Dominican rep.	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Dominican rep.	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Dominican rep.	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Dominican rep.	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Dominican rep.	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dominican rep.	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Dominican rep.	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dominican rep.	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Dominican rep.	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Dominican rep.	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominican rep.	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Dominican rep.	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Dominican rep.	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Dominican rep.	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Dominican rep.	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Dominican rep.	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Dominican rep.	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Dominican rep.	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Dominican rep.	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Dominican rep.	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Dominican rep.	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Dominican rep.	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Dominican rep.	INFINITI Q50	V37	2013.12-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Dominican rep.	INFINITI Q50	V37	2013.12-	Laser/radar	√	√	√	√	AC0994	
Dominican rep.	INFINITI Q50	V37	2013.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI Q50	V37	2013.12-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Dominican rep.	INFINITI Q50	V37	2013.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI Q50	V37	2013.12-	Air bag	√	√	√	√		
Dominican rep.	INFINITI Q50	V37	2013.12-	EPS/DAST 3	√	√	√	√		SP0507
Dominican rep.	INFINITI Q50	V37	2013.12-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dominican rep.	INFINITI Q50	V37	2013.12-	Motor control	√	√	√	√		
Dominican rep.	INFINITI Q50	V37	2013.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominican rep.	INFINITI Q50	V37	2013.12-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Dominican rep.	INFINITI Q50	V37	2013.12-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Dominican rep.	INFINITI Q50	V37	2013.12-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dominican rep.	INFINITI Q50	V37	2013.12-	Pop up hood	√	√	√	√		
Dominican rep.	INFINITI Q50	V37	2013.12-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI Q50	V37	2013.12-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Dominican rep.	INFINITI Q50	V37	2013.12-	HV battery	√	√	√	√	AC1121	
Dominican rep.	INFINITI Q50	V37	2013.12-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Dominican rep.	INFINITI Q50	V37	2013.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dominican rep.	INFINITI Q50	V37	2013.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI Q50	V37	2013.12-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Dominican rep.	INFINITI Q50	V37	2013.12-	Occupant detection			√	√		SP0584
Dominican rep.	INFINITI Q50	V37	2013.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Dominican rep.	INFINITI Q50	V37	2013.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominican rep.	INFINITI Q50	V37	2013.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dominican rep.	INFINITI Q50	V37	2013.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Dominican rep.	INFINITI Q50	V37	2013.12-	DAST 2	√	√	√	√		
Dominican rep.	INFINITI Q50	V37	2013.12-	Precrash seatbelt	√	√	√	√		SP0612
Dominican rep.	INFINITI Q50	V37	2013.12-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dominican rep.	INFINITI Q50	V37	2013.12-	CAN gateway	√	√	√			
Dominican rep.	INFINITI Q50	V37	2013.12-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Dominican rep.	INFINITI Q50	V37	2013.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominican rep.	INFINITI Q50	V37	2013.12-	DAST 1	√	√	√	√		
Dominican rep.	INFINITI Q50	V37	2013.12-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Dominican rep.	INFINITI Q50	V37	2013.12-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Dominican rep.	INFINITI Q50	V37	2013.12-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	

XTOOL

Dominican rep.	INFINITI Q50	V37	2013.12-	ANC	√	√	√	√	AC1024	
Dominican rep.	INFINITI Q50	V37	2013.12-	Side radar left	√	√	√	√	AC1025	SP0582
Dominican rep.	INFINITI Q50	V37	2013.12-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Dominican rep.	INFINITI Q50	V37	2013.12-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dominican rep.	INFINITI Q50	V37	2013.12-	HIGH BEAM ASSIST	√	√	√	√		
Dominican rep.	INFINITI Q50	V37	2013.12-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI Q50	V37	2013.12-	Brake	√	√	√	√	AC1127	
Dominican rep.	INFINITI Q50	V37	2013.12-	6ch CAN GATEWAY	√	√	√	√		
Dominican rep.	INFINITI Q50	V37	2013.12-	3ch CAN GATEWAY	√	√	√	√		
Dominican rep.	INFINITI Q50	V37	2013.12-	ICC/ADAS 2	√	√	√	√		
Dominican rep.	INFINITI Q50	V37	2013.12-	PMAS	√	√	√	√		
Dominican rep.	INFINITI Q50	V37	2013.12-	FSCM	√	√	√	√	AC1109	
Dominican rep.	INFINITI Q50	V37	2013.12-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		SP0507
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	6ch CAN GATEWAY	√	√	√	√		
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	FSCM	√	√	√	√	AC1109	
Dominican rep.	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Laser/radar	√	√	√	√		
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Air bag	√	√	√	√		

XTOOL

Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	EPS/DAST 3	√	√	√	√		
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Motor control	√	√	√	√		
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Transmission	√	√	√	√		SP0276
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Pop up hood	√	√	√	√		
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	HV battery	√	√	√	√	AC1121	
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Occupant detection			√	√		SP0584
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	DAST 2	√	√	√	√		
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Precrash seatbelt	√	√	√	√		SP0612
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	DAST 1	√	√	√	√		
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	ANC	√	√	√	√	AC1024	
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Side radar left	√	√	√	√	AC1025	SP0582
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	HIGH BEAM ASSIST	√	√	√	√		
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	VSP	√	√	√	√		
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	Brake	√	√	√	√	AC1127	
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	6ch CAN GATEWAY	√	√	√	√		
Dominican rep.	INFINITI Q50 Hybrid	HV37	2018.6-	ICC/ADAS 2	√	√	√	√		
Dominican rep.	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Dominican rep.	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Dominican rep.	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Dominican rep.	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Dominican rep.	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Dominican rep.	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dominican rep.	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominican rep.	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Dominican rep.	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Dominican rep.	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dominican rep.	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Dominican rep.	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Dominican rep.	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dominican rep.	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Dominican rep.	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Dominican rep.	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominican rep.	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dominican rep.	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominican rep.	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Dominican rep.	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Dominican rep.	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dominican rep.	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Dominican rep.	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		

XTOOL

Dominican rep.	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominican rep.	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Dominican rep.	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Dominican rep.	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Dominican rep.	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Dominican rep.	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Dominican rep.	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dominican rep.	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Dominican rep.	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Dominican rep.	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Dominican rep.	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Dominican rep.	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	Laser/radar	√	√	√	√	AC0994	
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	Air bag	√	√	√	√		
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	Transmission	√	√	√	√		SP0274
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	Pop up hood	√	√	√	√		
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	Precrash seatbelt	√	√	√	√		
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dominican rep.	INFINITI Q60 COUPE	CV36	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominican rep.	INFINITI Q70	Y51	2013.11-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Dominican rep.	INFINITI Q70	Y51	2013.11-	Laser/radar	√	√	√	√		
Dominican rep.	INFINITI Q70	Y51	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI Q70	Y51	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Dominican rep.	INFINITI Q70	Y51	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI Q70	Y51	2013.11-	Air bag	√	√	√	√		
Dominican rep.	INFINITI Q70	Y51	2013.11-	EPS/DAST 3	√	√	√	√		
Dominican rep.	INFINITI Q70	Y51	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dominican rep.	INFINITI Q70	Y51	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Dominican rep.	INFINITI Q70	Y51	2013.11-	Transmission	√	√	√	√		SP0274
Dominican rep.	INFINITI Q70	Y51	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Dominican rep.	INFINITI Q70	Y51	2013.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Dominican rep.	INFINITI Q70	Y51	2013.11-	Pop up hood	√	√	√	√		
Dominican rep.	INFINITI Q70	Y51	2013.11-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI Q70	Y51	2013.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Dominican rep.	INFINITI Q70	Y51	2013.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dominican rep.	INFINITI Q70	Y51	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI Q70	Y51	2013.11-	Occupant detection			√	√		SP0584
Dominican rep.	INFINITI Q70	Y51	2013.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Dominican rep.	INFINITI Q70	Y51	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominican rep.	INFINITI Q70	Y51	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Dominican rep.	INFINITI Q70	Y51	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Dominican rep.	INFINITI Q70	Y51	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Dominican rep.	INFINITI Q70	Y51	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Dominican rep.	INFINITI Q70	Y51	2013.11-	CAN gateway	√	√	√	√		
Dominican rep.	INFINITI Q70	Y51	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Dominican rep.	INFINITI Q70	Y51	2013.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominican rep.	INFINITI Q70	Y51	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Dominican rep.	INFINITI Q70	Y51	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Dominican rep.	INFINITI Q70	Y51	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dominican rep.	INFINITI Q70	Y51	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI QX30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Air bag	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	EPS/DAST 3	√	√	√			
Dominican rep.	INFINITI QX30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Dominican rep.	INFINITI QX30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Dominican rep.	INFINITI QX30	H15	2016.4-	EHS/PKB	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Transmission	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Dominican rep.	INFINITI QX30	H15	2016.4-	ABS	√	√	√	√		SP0308
Dominican rep.	INFINITI QX30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Dominican rep.	INFINITI QX30	H15	2016.4-	HVAC	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Auto drive position	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Shift	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	AVM	√	√		√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Intelligent key	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	CAN gateway	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	ANC	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Telematics	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	FSCM	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Siren control unit	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Dominican rep.	INFINITI QX30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Universal Garage Door Opener	√			√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Upper control panel cont unit	√					
Dominican rep.	INFINITI QX30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Dominican rep.	INFINITI QX30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Dominican rep.	INFINITI QX30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Dominican rep.	INFINITI QX30	H15	2016.4-	EC Mirror Compass	√					
Dominican rep.	INFINITI QX30	H15	2016.4-	Intelligent Battery Sensor	√					
Dominican rep.	INFINITI QX30	H15	2016.4-	Alarm siren	√			√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Radar sensor	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Steering column cont module	√	√	√			
Dominican rep.	INFINITI QX30	H15	2016.4-	ICC sensor	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	H/L control module LH	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Side radar LH	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	LED H/L control module LH	√			√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Parking assist	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Occupant Classification Unit	√			√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	H/L control module RH	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Front camera unit	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	Side radar RH	√	√	√	√		
Dominican rep.	INFINITI QX30	H15	2016.4-	LED H/L control module RH	√			√		
Dominican rep.	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Dominican rep.	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Dominican rep.	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Dominican rep.	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominican rep.	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Dominican rep.	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292

Dominican rep.	INFINITI QX50	J55	2018.5-	BCM					AC0618,AC0690,AC0692	SP0390,SP0438,SP0450,SP0458
Dominican rep.	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313,SP0315
Dominican rep.	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Dominican rep.	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Dominican rep.	INFINITI QX50	J55	2018.5-	Shift						
Dominican rep.	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Dominican rep.	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Dominican rep.	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Dominican rep.	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Dominican rep.	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	ANC						
Dominican rep.	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Dominican rep.	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Dominican rep.	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Dominican rep.	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Dominican rep.	INFINITI QX56	Z62	2012.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Dominican rep.	INFINITI QX56	Z62	2012.1-	Laser/radar	√	√	√	√		
Dominican rep.	INFINITI QX56	Z62	2012.1-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Dominican rep.	INFINITI QX56	Z62	2012.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Dominican rep.	INFINITI QX56	Z62	2012.1-	Air bag	√	√	√	√		
Dominican rep.	INFINITI QX56	Z62	2012.1-	Meter/M&A		√	√	√		SP0347,SP0348,SP0349,SP0350,SP0351
Dominican rep.	INFINITI QX56	Z62	2012.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Dominican rep.	INFINITI QX56	Z62	2012.1-	Transmission	√	√	√	√		SP0270
Dominican rep.	INFINITI QX56	Z62	2012.1-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Dominican rep.	INFINITI QX56	Z62	2012.1-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0313,SP0315
Dominican rep.	INFINITI QX56	Z62	2012.1-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI QX56	Z62	2012.1-	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0484,SP0485,SP0486,SP0487,SP0488
Dominican rep.	INFINITI QX56	Z62	2012.1-	E-SUS	√	√	√	√	AC1031,AC1032,AC1033	SP0585,SP0586,SP0587
Dominican rep.	INFINITI QX56	Z62	2012.1-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Dominican rep.	INFINITI QX56	Z62	2012.1-	Auto back door	√	√	√	√		
Dominican rep.	INFINITI QX56	Z62	2012.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Dominican rep.	INFINITI QX56	Z62	2012.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Dominican rep.	INFINITI QX56	Z62	2012.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
Dominican rep.	INFINITI QX56	Z62	2012.1-	All mode AWD/4WD	√	√	√	√		SP0544,SP0545,SP0546,SP0547,SP0548,SP0549
Dominican rep.	INFINITI QX56	Z62	2012.1-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Dominican rep.	INFINITI QX56	Z62	2012.1-	CAN gateway	√	√	√			
Dominican rep.	INFINITI QX56	Z62	2012.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Dominican rep.	INFINITI QX56	Z62	2012.1-	Side radar left	√	√	√	√	AC1025	SP0582
Dominican rep.	INFINITI QX56	Z62	2012.1-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI QX60	L50	2014.12-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Dominican rep.	INFINITI QX60	L50	2014.12-	Laser/radar	√	√	√	√	AC0994	
Dominican rep.	INFINITI QX60	L50	2014.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI QX60	L50	2014.12-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Dominican rep.	INFINITI QX60	L50	2014.12-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Dominican rep.	INFINITI QX60	L50	2014.12-	Air bag	√	√	√	√		
Dominican rep.	INFINITI QX60	L50	2014.12-	EPS/DAST 3	√	√	√	√		
Dominican rep.	INFINITI QX60	L50	2014.12-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Dominican rep.	INFINITI QX60	L50	2014.12-	Motor control	√	√	√	√		
Dominican rep.	INFINITI QX60	L50	2014.12-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239

Dominican rep.	INFINITI QX60	L50	2014.12-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Dominican rep.	INFINITI QX60	L50	2014.12-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Dominican rep.	INFINITI QX60	L50	2014.12-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dominican rep.	INFINITI QX60	L50	2014.12-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI QX60	L50	2014.12-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Dominican rep.	INFINITI QX60	L50	2014.12-	HV battery	√	√	√	√	AC1121	
Dominican rep.	INFINITI QX60	L50	2014.12-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI QX60	L50	2014.12-	Auto back door	√	√	√	√		SP0611
Dominican rep.	INFINITI QX60	L50	2014.12-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Dominican rep.	INFINITI QX60	L50	2014.12-	Occupant detection			√	√		SP0584
Dominican rep.	INFINITI QX60	L50	2014.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominican rep.	INFINITI QX60	L50	2014.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dominican rep.	INFINITI QX60	L50	2014.12-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominican rep.	INFINITI QX60	L50	2014.12-	Precrash seatbelt	√	√	√	√		SP0612
Dominican rep.	INFINITI QX60	L50	2014.12-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dominican rep.	INFINITI QX60	L50	2014.12-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Dominican rep.	INFINITI QX60	L50	2014.12-	CAN gateway	√	√	√			
Dominican rep.	INFINITI QX60	L50	2014.12-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Dominican rep.	INFINITI QX60	L50	2014.12-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Dominican rep.	INFINITI QX60	L50	2014.12-	ANC	√	√	√	√	AC1024	
Dominican rep.	INFINITI QX60	L50	2014.12-	Side radar left	√	√	√	√	AC1025	SP0582
Dominican rep.	INFINITI QX60	L50	2014.12-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dominican rep.	INFINITI QX60	L50	2014.12-	HIGH BEAM ASSIST	√	√	√	√		
Dominican rep.	INFINITI QX60	L50	2014.12-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI QX60	L50	2014.12-	3ch CAN GATEWAY	√	√	√	√		
Dominican rep.	INFINITI QX60	L50	2014.12-	ICC/ADAS 2	√	√	√	√		
Dominican rep.	INFINITI QX60	L50	2014.12-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Dominican rep.	INFINITI QX60	L50	2014.12-	A-IVC(Renault common)	√	√	√	√		
Dominican rep.	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Dominican rep.	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Dominican rep.	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dominican rep.	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Dominican rep.	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Dominican rep.	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Dominican rep.	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dominican rep.	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Dominican rep.	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Dominican rep.	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dominican rep.	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Dominican rep.	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Dominican rep.	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Dominican rep.	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dominican rep.	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Dominican rep.	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Dominican rep.	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dominican rep.	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominican rep.	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dominican rep.	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Dominican rep.	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Dominican rep.	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dominican rep.	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Dominican rep.	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Dominican rep.	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dominican rep.	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Dominican rep.	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Dominican rep.	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Dominican rep.	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dominican rep.	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Dominican rep.	INFINITI QX80	Z62	2014.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Dominican rep.	INFINITI QX80	Z62	2014.1-	Laser/radar	√	√	√	√	AC0994	
Dominican rep.	INFINITI QX80	Z62	2014.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

XTOOL

Dominican rep.	INFINITI QX80	Z62	2014.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Dominican rep.	INFINITI QX80	Z62	2014.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dominican rep.	INFINITI QX80	Z62	2014.1-	Air bag	√	√	√	√		
Dominican rep.	INFINITI QX80	Z62	2014.1-	EPS/DAST 3	√	√	√	√		SP0507
Dominican rep.	INFINITI QX80	Z62	2014.1-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Dominican rep.	INFINITI QX80	Z62	2014.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dominican rep.	INFINITI QX80	Z62	2014.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Dominican rep.	INFINITI QX80	Z62	2014.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Dominican rep.	INFINITI QX80	Z62	2014.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dominican rep.	INFINITI QX80	Z62	2014.1-	Multi AV	√	√	√	√		SP0503
Dominican rep.	INFINITI QX80	Z62	2014.1-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Dominican rep.	INFINITI QX80	Z62	2014.1-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Dominican rep.	INFINITI QX80	Z62	2014.1-	Difference lock	√	√	√	√		
Dominican rep.	INFINITI QX80	Z62	2014.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dominican rep.	INFINITI QX80	Z62	2014.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dominican rep.	INFINITI QX80	Z62	2014.1-	Auto back door	√	√	√	√		
Dominican rep.	INFINITI QX80	Z62	2014.1-	Occupant detection			√	√		SP0584
Dominican rep.	INFINITI QX80	Z62	2014.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Dominican rep.	INFINITI QX80	Z62	2014.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dominican rep.	INFINITI QX80	Z62	2014.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dominican rep.	INFINITI QX80	Z62	2014.1-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Dominican rep.	INFINITI QX80	Z62	2014.1-	Precrash seatbelt	√	√	√	√		SP0612
Dominican rep.	INFINITI QX80	Z62	2014.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dominican rep.	INFINITI QX80	Z62	2014.1-	CAN gateway	√	√	√			
Dominican rep.	INFINITI QX80	Z62	2014.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Dominican rep.	INFINITI QX80	Z62	2014.1-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Dominican rep.	INFINITI QX80	Z62	2014.1-	Side radar left	√	√	√	√	AC1025	SP0582
Dominican rep.	INFINITI QX80	Z62	2014.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dominican rep.	INFINITI QX80	Z62	2014.1-	HIGH BEAM ASSIST	√	√	√	√		
Dominican rep.	INFINITI QX80	Z62	2014.1-	Side radar right	√	√	√	√	AC1026	SP0583
Dominican rep.	INFINITI QX80	Z62	2014.1-	Vehicle data transmitter	√	√	√	√		
Dominican rep.	INFINITI QX80	Z62	2014.1-	6ch CAN GATEWAY	√	√	√	√		
Dominican rep.	INFINITI QX80	Z62	2014.1-	ICC/ADAS 2	√	√	√	√		
Dominican rep.	INFINITI QX80	Z62	2014.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Dubai	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dubai	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Dubai	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dubai	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Dubai	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Dubai	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dubai	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI EX35	I50	2008.1-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dubai	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dubai	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dubai	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Dubai	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Dubai	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dubai	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Dubai	INFINITI EX35/EX37	I50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dubai	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Dubai	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Dubai	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dubai	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI EX35/EX37	I50	2011.1-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dubai	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dubai	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dubai	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Dubai	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Dubai	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Dubai	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Dubai	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494

XTOOL

Dubai	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Dubai	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Dubai	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Dubai	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Dubai	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Dubai	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Dubai	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Dubai	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Dubai	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Dubai	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Dubai	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Dubai	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Dubai	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dubai	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Dubai	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Dubai	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Dubai	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Dubai	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Dubai	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Dubai	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Dubai	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Dubai	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Dubai	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Dubai	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Dubai	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Dubai	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Dubai	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Dubai	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Dubai	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Dubai	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dubai	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Dubai	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dubai	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Dubai	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Dubai	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dubai	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Dubai	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Dubai	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Dubai	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Dubai	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Dubai	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dubai	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dubai	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Dubai	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Dubai	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Dubai	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Dubai	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Dubai	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894. AC0895. AC0896. AC0897. AC0898. AC0899. AC0900. AC0901. AC0902	SP0508. SP0509. SP0510
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Dubai	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dubai	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	

Dubai	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Dubai	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Dubai	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Dubai	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Dubai	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dubai	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Dubai	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Dubai	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Dubai	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Dubai	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Dubai	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Dubai	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Dubai	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dubai	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Dubai	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Dubai	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Dubai	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Dubai	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dubai	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Dubai	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Dubai	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Dubai	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Dubai	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Dubai	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Dubai	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Dubai	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Dubai	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dubai	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Dubai	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Dubai	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dubai	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Dubai	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Dubai	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Dubai	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dubai	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dubai	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Dubai	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dubai	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Dubai	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dubai	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Dubai	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dubai	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dubai	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dubai	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Dubai	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Dubai	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Dubai	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dubai	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Dubai	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Dubai	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dubai	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Dubai	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dubai	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dubai	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dubai	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Dubai	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Dubai	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Dubai	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Dubai	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Dubai	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Dubai	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dubai	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Dubai	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Dubai	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dubai	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Dubai	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Dubai	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Dubai	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dubai	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Dubai	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Dubai	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Dubai	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Dubai	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Dubai	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Dubai	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Dubai	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Dubai	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Dubai	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Dubai	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Dubai	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Dubai	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319

Dubai	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Dubai	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Dubai	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Dubai	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Dubai	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Dubai	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Dubai	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Dubai	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Dubai	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Dubai	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Dubai	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Dubai	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Dubai	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dubai	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Dubai	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Dubai	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Dubai	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Dubai	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Dubai	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dubai	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dubai	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dubai	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553. SP0554. SP0555. SP0556
Dubai	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Dubai	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Dubai	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Dubai	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Dubai	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Dubai	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Dubai	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Dubai	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Dubai	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Dubai	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Dubai	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Dubai	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Dubai	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Dubai	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Dubai	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Dubai	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Dubai	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Dubai	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Dubai	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Dubai	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Dubai	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Dubai	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Dubai	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Dubai	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Dubai	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Dubai	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Dubai	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Dubai	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		

Dubai	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Dubai	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Dubai	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Dubai	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Dubai	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Dubai	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Dubai	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Dubai	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Dubai	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Dubai	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Dubai	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Dubai	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Dubai	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Dubai	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Dubai	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dubai	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Dubai	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Dubai	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Dubai	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Dubai	INFINITI Q45	F50	2001.8-	Motor control						
Dubai	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Dubai	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Dubai	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Dubai	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Dubai	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Dubai	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Dubai	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Dubai	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dubai	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Dubai	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Dubai	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Dubai	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Dubai	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Dubai	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Dubai	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Dubai	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Dubai	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Dubai	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Dubai	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Dubai	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Dubai	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Dubai	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Dubai	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Dubai	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Dubai	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Dubai	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Dubai	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Dubai	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Dubai	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dubai	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Dubai	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Dubai	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dubai	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		

Dubai	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Dubai	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Dubai	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dubai	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Dubai	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Dubai	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dubai	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dubai	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Dubai	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Dubai	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Dubai	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Dubai	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Dubai	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Dubai	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Dubai	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Dubai	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Dubai	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Dubai	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Dubai	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dubai	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Dubai	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Dubai	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Dubai	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Dubai	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Dubai	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Dubai	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Dubai	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Dubai	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Dubai	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		

Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Dubai	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Dubai	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Dubai	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Dubai	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Dubai	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Dubai	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Dubai	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dubai	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Dubai	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Dubai	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dubai	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Dubai	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Dubai	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dubai	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Dubai	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Dubai	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dubai	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dubai	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Dubai	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Dubai	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Dubai	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Dubai	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Dubai	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Dubai	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Dubai	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Dubai	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Dubai	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dubai	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Dubai	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Dubai	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Dubai	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Dubai	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Dubai	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Dubai	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Dubai	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Dubai	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Dubai	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Dubai	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Dubai	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Dubai	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Dubai	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Dubai	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Dubai	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Dubai	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Dubai	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Dubai	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Dubai	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Dubai	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Dubai	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Dubai	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Dubai	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dubai	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dubai	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Dubai	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Dubai	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Dubai	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Dubai	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Dubai	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Dubai	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dubai	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Dubai	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Dubai	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Dubai	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Dubai	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Dubai	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Dubai	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Dubai	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Dubai	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Dubai	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Dubai	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Dubai	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Dubai	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Dubai	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Dubai	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI QX50	I50	2013.6-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Dubai	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dubai	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dubai	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dubai	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Dubai	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Dubai	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Dubai	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Dubai	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dubai	INFINITI QX50	I50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI QX50	I55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Dubai	INFINITI QX50	I55	2018.5-	Laser/radar	√	√	√	√		
Dubai	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Dubai	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Dubai	INFINITI QX50	I55	2018.5-	Air bag	√	√	√	√		
Dubai	INFINITI QX50	I55	2018.5-	EPS/DAST 3	√	√	√	√		
Dubai	INFINITI QX50	I55	2018.5-	Meter/M&A	√	√	√	√		

Dubai	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Dubai	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Dubai	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Dubai	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Dubai	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Dubai	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Dubai	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Dubai	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Dubai	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Dubai	INFINITI QX50	J55	2018.5-	Shift						
Dubai	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Dubai	INFINITI QX50	I55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dubai	INFINITI QX50	I55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dubai	INFINITI QX50	I55	2018.5-	All mode AWD/4WD	√	√	√	√		
Dubai	INFINITI QX50	I55	2018.5-	DAST 2	√	√	√	√		
Dubai	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Dubai	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Dubai	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Dubai	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Dubai	INFINITI QX50	J55	2018.5-	ANC						
Dubai	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Dubai	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dubai	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Dubai	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Dubai	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Dubai	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Dubai	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Dubai	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Dubai	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Dubai	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Dubai	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Dubai	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Dubai	INFINITI QX56	JA60	2004.10-	Motor control						
Dubai	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Dubai	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Dubai	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Dubai	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Dubai	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Dubai	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Dubai	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Dubai	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Dubai	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dubai	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Dubai	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Dubai	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Dubai	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Dubai	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Dubai	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Dubai	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Dubai	INFINITI QX56	IA60	2004.10-	ASCD	√	√	√	√		
Dubai	INFINITI QX56	IA60	2004.10-	Active engine mount	√	√	√	√		
Dubai	INFINITI QX56	IA60	2004.10-	TCS	√	√	√	√		
Dubai	INFINITI QX56	IA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Dubai	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Dubai	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Dubai	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Dubai	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Dubai	INFINITI QX56	Z62	2010.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Dubai	INFINITI QX56	Z62	2010.3-	Laser/radar	√	√	√	√		
Dubai	INFINITI QX56	Z62	2010.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI QX56	Z62	2010.3-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Dubai	INFINITI QX56	Z62	2010.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Dubai	INFINITI QX56	Z62	2010.3-	Air bag	√	√	√	√		
Dubai	INFINITI QX56	Z62	2010.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Dubai	INFINITI QX56	Z62	2010.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Dubai	INFINITI QX56	Z62	2010.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Dubai	INFINITI QX56	Z62	2010.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Dubai	INFINITI QX56	Z62	2010.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Dubai	INFINITI QX56	Z62	2010.3-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI QX56	Z62	2010.3-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Dubai	INFINITI QX56	Z62	2010.3-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Dubai	INFINITI QX56	Z62	2010.3-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Dubai	INFINITI QX56	Z62	2010.3-	Auto back door	√	√	√	√		
Dubai	INFINITI QX56	Z62	2010.3-	Occupant detection			√	√		SP0584
Dubai	INFINITI QX56	Z62	2010.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Dubai	INFINITI QX56	Z62	2010.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Dubai	INFINITI QX56	Z62	2010.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Dubai	INFINITI QX56	Z62	2010.3-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Dubai	INFINITI QX56	Z62	2010.3-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI QX56	Z62	2010.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Dubai	INFINITI QX56	Z62	2010.3-	CAN gateway	√	√	√			
Dubai	INFINITI QX56	Z62	2010.3-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Dubai	INFINITI QX56	Z62	2010.3-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI QX56	Z62	2010.3-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Dubai	INFINITI QX56	Z62	2010.3-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI QX56	Z62	2010.3-	Rearview camera	√			√		SP0570, SP0571

Dubai	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Dubai	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Dubai	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Dubai	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Dubai	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Dubai	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Dubai	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Dubai	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Dubai	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Dubai	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246,SP0274,SP0275,SP0276,SP0278,SP0279,SP0281,SP0282,SP0283,SP0287,SP0288,SP0289,SP0290,SP0292
Dubai	INFINITI QX60	L50	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Dubai	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Dubai	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0487
Dubai	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Dubai	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Dubai	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Dubai	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081,AC1084,AC1085,AC1086,AC1087,AC1088,AC1089	
Dubai	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Dubai	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Dubai	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Dubai	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Dubai	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Dubai	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Dubai	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Dubai	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Dubai	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Dubai	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Dubai	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Dubai	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Dubai	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Dubai	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Dubai	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Dubai	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246,SP0276,SP0279,SP0281,SP0282,SP0283,SP0287,SP0289,SP0290,SP0292
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0487
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081,AC1084,AC1085,AC1086,AC1087,AC1088,AC1089	
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Dubai	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Dubai	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Dubai	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Dubai	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Dubai	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Dubai	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Dubai	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Dubai	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Dubai	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Dubai	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Dubai	INFINITI QX70	S51	2013.5-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Dubai	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Dubai	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Dubai	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Dubai	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Dubai	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Dubai	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Dubai	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Dubai	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Dubai	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Dubai	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Dubai	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Dubai	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Dubai	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			

Dubai	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Dubai	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Dubai	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Dubai	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Dubai	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Dubai	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Dubai	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Dubai	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Dubai	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Dubai	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Dubai	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Dubai	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Dubai	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Dubai	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350,SP0351
Dubai	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Dubai	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Dubai	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Dubai	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Dubai	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Dubai	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0484,SP0485,SP0486,SP0487,SP0488
Dubai	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031,AC1032,AC1033	SP0585,SP0586,SP0587
Dubai	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Dubai	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Dubai	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Dubai	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Dubai	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Dubai	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Dubai	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Dubai	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Dubai	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544,SP0545,SP0546,SP0547,SP0548,SP0549
Dubai	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Dubai	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Dubai	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932,AC0933,AC0934,AC0935	SP0511,SP0512,SP0515,SP0516,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537,SP0538,SP0539,SP0540
Dubai	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Dubai	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Dubai	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Dubai	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Dubai	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Dubai	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Dubai	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Dubai	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Dubai	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Dubai	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Dubai	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Ecuador	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ecuador	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Ecuador	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Ecuador	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Ecuador	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Ecuador	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270,SP0274
Ecuador	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Ecuador	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Ecuador	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Ecuador	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Ecuador	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Ecuador	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Ecuador	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Ecuador	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ecuador	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Ecuador	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Ecuador	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ecuador	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Ecuador	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Ecuador	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Ecuador	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Ecuador	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0556,SP0557
Ecuador	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Ecuador	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Ecuador	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Ecuador	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ecuador	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570,SP0571
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350

Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Ecuador	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Ecuador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Ecuador	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ecuador	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Ecuador	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ecuador	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ecuador	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Ecuador	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ecuador	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ecuador	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Ecuador	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ecuador	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ecuador	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Ecuador	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Ecuador	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ecuador	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Ecuador	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ecuador	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ecuador	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Ecuador	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Ecuador	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Ecuador	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ecuador	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582

Ecuador	INFINITI FX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Ecuador	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ecuador	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Ecuador	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ecuador	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ecuador	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ecuador	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ecuador	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Ecuador	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ecuador	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ecuador	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ecuador	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ecuador	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Ecuador	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Ecuador	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Ecuador	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ecuador	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ecuador	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ecuador	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ecuador	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ecuador	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ecuador	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ecuador	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ecuador	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Ecuador	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Ecuador	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ecuador	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ecuador	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Ecuador	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Ecuador	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Ecuador	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Ecuador	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ecuador	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Ecuador	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Ecuador	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Ecuador	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Ecuador	INFINITI Q45	F50	2001.8-	Motor control						
Ecuador	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ecuador	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Ecuador	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Ecuador	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ecuador	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Ecuador	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Ecuador	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Ecuador	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ecuador	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Ecuador	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Ecuador	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Ecuador	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ecuador	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Ecuador	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ecuador	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Ecuador	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Ecuador	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ecuador	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Ecuador	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Ecuador	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Ecuador	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Ecuador	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Ecuador	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Ecuador	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Ecuador	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Ecuador	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Ecuador	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Ecuador	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Ecuador	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Ecuador	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ecuador	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Ecuador	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ecuador	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Ecuador	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Ecuador	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Ecuador	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ecuador	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Ecuador	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ecuador	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Ecuador	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Ecuador	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Ecuador	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Ecuador	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ecuador	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Ecuador	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Ecuador	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ecuador	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ecuador	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Ecuador	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Ecuador	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Ecuador	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Ecuador	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ecuador	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582

Ecuador	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Ecuador	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Eguat guinea	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eguat guinea	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503

Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Eguat guinea	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Eguat guinea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Eguat guinea	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	

Eguat guinea	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Eguat guinea	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Eguat guinea	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Eguat guinea	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Eguat guinea	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Eguat guinea	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Eguat guinea	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Eguat guinea	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Eguat guinea	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Eguat guinea	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Eguat guinea	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Eguat guinea	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Eguat guinea	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Eguat guinea	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Eguat guinea	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Eguat guinea	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Eguat guinea	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Eguat guinea	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Eguat guinea	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Eguat guinea	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Eguat guinea	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Eguat guinea	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Eguat guinea	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Eguat guinea	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Eguat guinea	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eguat guinea	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Eguat guinea	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Eguat guinea	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Eguat guinea	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Eguat guinea	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Eguat guinea	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eguat guinea	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Eguat guinea	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Eguat guinea	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eguat guinea	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Eguat guinea	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Eguat guinea	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Eguat guinea	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Eguat guinea	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eguat guinea	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Eguat guinea	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Eguat guinea	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eguat guinea	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Eguat guinea	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Eguat guinea	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Eguat guinea	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Eguat guinea	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Eguat guinea	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Eguat guinea	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Eguat guinea	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eguat guinea	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Eguat guinea	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Eguat guinea	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			

Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Eguat guinea	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Eguat guinea	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Eguat guinea	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Eguat guinea	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Eguat guinea	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Eguat guinea	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Eguat guinea	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Eguat guinea	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eguat guinea	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Eguat guinea	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Eguat guinea	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Eguat guinea	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Eguat guinea	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Eguat guinea	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eguat guinea	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Eguat guinea	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Eguat guinea	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eguat guinea	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Eguat guinea	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Eguat guinea	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Eguat guinea	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Eguat guinea	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Eguat guinea	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Eguat guinea	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Eguat guinea	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eguat guinea	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Eguat guinea	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Eguat guinea	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Eguat guinea	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Eguat guinea	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Eguat guinea	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eguat guinea	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Eguat guinea	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Eguat guinea	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Eguat guinea	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Eguat guinea	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

XTOOL

Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eguat guinea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eguat guinea	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eguat guinea	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Eguat guinea	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Eguat guinea	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Eguat guinea	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Eguat guinea	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Eguat guinea	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Eguat guinea	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Eguat guinea	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Eguat guinea	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Eguat guinea	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Eguat guinea	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Eguat guinea	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Eguat guinea	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eguat guinea	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Eguat guinea	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562

Eguat guinea	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eguat guinea	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Eguat guinea	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Eguat guinea	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Eguat guinea	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eguat guinea	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Eguat guinea	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Eguat guinea	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eguat guinea	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Eguat guinea	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Eguat guinea	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eguat guinea	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Eguat guinea	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Eguat guinea	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Eguat guinea	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Eguat guinea	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Eguat guinea	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Eguat guinea	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eguat guinea	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Eguat guinea	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Eguat guinea	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eguat guinea	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Eguat guinea	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eguat guinea	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eguat guinea	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Eguat guinea	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Eguat guinea	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Eguat guinea	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eguat guinea	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Eguat guinea	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Eguat guinea	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Eguat guinea	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Eguat guinea	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eguat guinea	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Eguat guinea	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Eguat guinea	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Eguat guinea	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Eguat guinea	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Eguat guinea	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Eguat guinea	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eguat guinea	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Eguat guinea	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Eguat guinea	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eguat guinea	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Eguat guinea	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Eguat guinea	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Eguat guinea	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eguat guinea	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Eguat guinea	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Eguat guinea	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eguat guinea	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	

Eguat guinea	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Eguat guinea	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Eguat guinea	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Eguat guinea	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eguat guinea	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Eguat guinea	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Eguat guinea	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eguat guinea	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Eguat guinea	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Eguat guinea	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Eguat guinea	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eguat guinea	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Eguat guinea	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Eguat guinea	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Eguat guinea	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Eguat guinea	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eguat guinea	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Eguat guinea	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eguat guinea	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Eguat guinea	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Eguat guinea	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eguat guinea	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Eguat guinea	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Eguat guinea	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Eguat guinea	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Eguat guinea	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Eguat guinea	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Eguat guinea	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Eguat guinea	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eguat guinea	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Eguat guinea	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Eguat guinea	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Eguat guinea	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eguat guinea	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Eguat guinea	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Eguat guinea	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Eguat guinea	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Eguat guinea	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Eguat guinea	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Eguat guinea	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Eguat guinea	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Eguat guinea	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eguat guinea	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Eguat guinea	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Eguat guinea	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Eguat guinea	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Eguat guinea	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Egypt	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Egypt	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Egypt	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Egypt	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Egypt	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Egypt	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Egypt	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Egypt	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Egypt	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Egypt	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Egypt	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Egypt	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Egypt	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Egypt	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Egypt	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Egypt	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Egypt	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Egypt	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Egypt	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Egypt	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Egypt	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Egypt	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Egypt	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Egypt	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Egypt	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Egypt	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Egypt	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Egypt	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Egypt	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Egypt	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Egypt	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Egypt	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Egypt	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Egypt	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Egypt	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Egypt	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Egypt	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Egypt	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Egypt	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Egypt	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Egypt	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Egypt	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Egypt	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Egypt	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Egypt	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Egypt	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Egypt	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Egypt	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Egypt	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Egypt	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Egypt	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Egypt	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Egypt	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Egypt	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Egypt	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Egypt	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Egypt	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Egypt	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Egypt	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Egypt	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Egypt	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Egypt	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Egypt	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Egypt	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Egypt	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Egypt	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Egypt	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Egypt	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Egypt	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Egypt	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Egypt	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Egypt	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Egypt	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Egypt	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Egypt	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Egypt	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Egypt	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Egypt	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Egypt	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Egypt	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Egypt	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Egypt	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Egypt	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Egypt	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Egypt	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Egypt	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Egypt	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Egypt	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Egypt	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		

Egypt	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Egypt	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Egypt	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Egypt	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572,SP0573
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570,SP0571
Egypt	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Egypt	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Egypt	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Egypt	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Egypt	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Egypt	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270
Egypt	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Egypt	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Egypt	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Egypt	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Egypt	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
Egypt	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Egypt	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570,SP0571
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0200,SP0202,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Egypt	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Egypt	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Egypt	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Egypt	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Egypt	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Egypt	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Egypt	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Egypt	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Egypt	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Egypt	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Egypt	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Egypt	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Egypt	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Egypt	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957	
Egypt	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Egypt	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Egypt	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Egypt	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Egypt	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Egypt	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Egypt	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Egypt	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Egypt	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Egypt	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Egypt	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Egypt	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Egypt	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Egypt	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957	
Egypt	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Egypt	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Egypt	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Egypt	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Egypt	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Egypt	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Egypt	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351

Egypt	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Egypt	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Egypt	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Egypt	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Egypt	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Egypt	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Egypt	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Egypt	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Egypt	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Egypt	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Egypt	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Egypt	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Egypt	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Egypt	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Egypt	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Egypt	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Egypt	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Egypt	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Egypt	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Egypt	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Egypt	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Egypt	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Egypt	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Egypt	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Egypt	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Egypt	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Egypt	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Egypt	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Egypt	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Egypt	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Egypt	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Egypt	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Egypt	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Egypt	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Egypt	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Egypt	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Egypt	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Egypt	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Egypt	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Egypt	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Egypt	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Egypt	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Egypt	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Egypt	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Egypt	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Egypt	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Egypt	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Egypt	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Egypt	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Egypt	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Egypt	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Egypt	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Egypt	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Egypt	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Egypt	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Egypt	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Egypt	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					

Egypt	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Egypt	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Egypt	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Egypt	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Egypt	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Egypt	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Egypt	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Egypt	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Egypt	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Egypt	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Egypt	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Egypt	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Egypt	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Egypt	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Egypt	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Egypt	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Egypt	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Egypt	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Egypt	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Egypt	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Egypt	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Egypt	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Egypt	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Egypt	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Egypt	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Egypt	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Egypt	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Egypt	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Egypt	INFINITI Q45	F50	2001.8-	Motor control						
Egypt	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Egypt	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Egypt	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Egypt	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Egypt	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Egypt	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Egypt	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Egypt	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Egypt	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537

Egypt	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Egypt	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Egypt	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Egypt	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Egypt	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Egypt	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Egypt	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Egypt	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Egypt	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Egypt	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Egypt	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Egypt	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Egypt	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Egypt	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Egypt	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Egypt	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Egypt	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Egypt	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Egypt	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Egypt	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Egypt	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Egypt	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Egypt	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Egypt	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Egypt	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Egypt	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Egypt	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Egypt	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Egypt	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Egypt	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Egypt	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Egypt	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Egypt	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Egypt	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Egypt	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Egypt	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Egypt	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Egypt	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Egypt	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Egypt	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Egypt	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Egypt	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Egypt	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Egypt	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Egypt	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Egypt	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Egypt	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Egypt	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Egypt	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	

Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Egypt	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Egypt	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Egypt	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Egypt	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Egypt	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Egypt	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Egypt	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Egypt	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Egypt	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Egypt	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Egypt	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Egypt	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Egypt	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Egypt	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Egypt	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Egypt	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Egypt	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Egypt	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Egypt	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Egypt	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Egypt	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Egypt	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Egypt	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Egypt	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Egypt	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Egypt	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Egypt	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Egypt	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Egypt	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Egypt	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Egypt	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Egypt	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Egypt	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Egypt	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Egypt	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Egypt	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Egypt	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Egypt	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Egypt	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Egypt	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Egypt	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Egypt	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Egypt	INFINITI Q70	Y51	2013.9-	HV batterv	√	√	√	√	AC1121	
Egypt	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Egypt	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Egypt	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Egypt	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Egypt	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Egypt	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Egypt	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Egypt	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Egypt	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Egypt	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Egypt	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Egypt	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Egypt	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Egypt	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Egypt	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Egypt	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Egypt	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Egypt	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Egypt	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Egypt	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Egypt	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		

Egypt	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Egypt	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Egypt	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Egypt	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Egypt	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Egypt	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Egypt	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Egypt	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Egypt	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Egypt	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Egypt	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Egypt	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Egypt	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Egypt	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Egypt	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Egypt	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Egypt	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Egypt	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Egypt	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Egypt	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Egypt	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Egypt	INFINITI QX50	J55	2018.5-	Shift						
Egypt	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Egypt	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	ANC						
Egypt	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Egypt	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Egypt	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Egypt	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Egypt	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Egypt	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Egypt	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Egypt	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Egypt	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Egypt	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Egypt	INFINITI QX56	JA60	2004.10-	Motor control						
Egypt	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Egypt	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Egypt	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Egypt	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Egypt	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Egypt	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Egypt	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Egypt	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Egypt	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Egypt	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Egypt	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Egypt	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Egypt	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Egypt	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Egypt	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Egypt	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Egypt	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Egypt	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Egypt	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Egypt	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Egypt	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			

Egypt	INFINITI QX56	IA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Egypt	INFINITI QX56	IA60	2004.10-	Smart entrance						SP0568
Egypt	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Egypt	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Egypt	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Egypt	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Egypt	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Egypt	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270, SP0274
Egypt	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Egypt	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Egypt	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Egypt	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Egypt	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Egypt	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Egypt	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Egypt	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Egypt	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Egypt	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Egypt	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Egypt	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Egypt	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Egypt	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Egypt	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Egypt	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Egypt	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Egypt	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Egypt	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Egypt	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Egypt	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Egypt	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Egypt	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Egypt	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Egypt	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Egypt	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Egypt	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Egypt	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Egypt	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Egypt	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Egypt	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Egypt	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Egypt	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Egypt	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Egypt	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Egypt	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Egypt	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Egypt	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		

Egypt	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Egypt	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Egypt	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Egypt	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Egypt	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Egypt	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Egypt	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Egypt	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Egypt	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Egypt	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Egypt	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Egypt	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Egypt	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Egypt	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Egypt	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Egypt	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Egypt	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Egypt	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Egypt	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Egypt	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Egypt	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Egypt	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Egypt	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Egypt	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Egypt	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Egypt	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Egypt	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Egypt	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Egypt	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Egypt	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Egypt	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Egypt	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Egypt	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Egypt	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Egypt	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Egypt	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Egypt	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Egypt	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Egypt	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Egypt	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Egypt	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Egypt	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Egypt	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Egypt	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Egypt	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Egypt	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Egypt	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Egypt	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Egypt	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Egypt	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Egypt	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Egypt	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Egypt	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Egypt	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Egypt	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Egypt	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Egypt	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Egypt	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Egypt	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Egypt	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Egypt	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Egypt	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Egypt	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
El salvador	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
El salvador	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
El salvador	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
El salvador	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
El salvador	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
El salvador	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
El salvador	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
El salvador	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
El salvador	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
El salvador	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
El salvador	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
El salvador	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
El salvador	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
El salvador	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
El salvador	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
El salvador	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582

El salvador	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
El salvador	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
El salvador	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
El salvador	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
El salvador	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
El salvador	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
El salvador	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
El salvador	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
El salvador	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
El salvador	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
El salvador	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
El salvador	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
El salvador	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
El salvador	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
El salvador	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
El salvador	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
El salvador	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
El salvador	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
El salvador	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
El salvador	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
El salvador	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
El salvador	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
El salvador	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
El salvador	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
El salvador	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
El salvador	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
El salvador	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
El salvador	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319

El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
El salvador	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
El salvador	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
El salvador	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
El salvador	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
El salvador	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
El salvador	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
El salvador	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
El salvador	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
El salvador	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
El salvador	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
El salvador	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
El salvador	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
El salvador	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
El salvador	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
El salvador	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
El salvador	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
El salvador	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
El salvador	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
El salvador	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
El salvador	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
El salvador	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
El salvador	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
El salvador	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
El salvador	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
El salvador	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
El salvador	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
El salvador	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
El salvador	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
El salvador	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
El salvador	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
El salvador	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
El salvador	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
El salvador	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
El salvador	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
El salvador	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
El salvador	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
El salvador	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
El salvador	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
El salvador	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
El salvador	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
El salvador	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
El salvador	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
El salvador	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
El salvador	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
El salvador	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
El salvador	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
El salvador	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
El salvador	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
El salvador	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
El salvador	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
El salvador	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471

El salvador	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
El salvador	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
El salvador	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
El salvador	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
El salvador	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
El salvador	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
El salvador	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
El salvador	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
El salvador	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
El salvador	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
El salvador	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
El salvador	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
El salvador	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
El salvador	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
El salvador	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
El salvador	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
El salvador	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
El salvador	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
El salvador	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
El salvador	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
El salvador	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
El salvador	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
El salvador	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
El salvador	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
El salvador	INFINITI Q45	F50	2001.8-	Motor control						
El salvador	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
El salvador	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
El salvador	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
El salvador	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
El salvador	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
El salvador	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
El salvador	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
El salvador	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
El salvador	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
El salvador	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
El salvador	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
El salvador	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
El salvador	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
El salvador	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
El salvador	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
El salvador	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
El salvador	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
El salvador	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
El salvador	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
El salvador	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
El salvador	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
El salvador	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
El salvador	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
El salvador	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
El salvador	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
El salvador	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
El salvador	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
El salvador	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
El salvador	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
El salvador	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
El salvador	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
El salvador	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
El salvador	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
El salvador	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
El salvador	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

El salvador	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
El salvador	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
El salvador	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
El salvador	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
El salvador	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
El salvador	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
El salvador	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
El salvador	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
El salvador	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
El salvador	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
El salvador	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
El salvador	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
El salvador	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
El salvador	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
El salvador	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
El salvador	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
El salvador	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
El salvador	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
El salvador	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
El salvador	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eritrea	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Eritrea	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eritrea	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eritrea	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Eritrea	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eritrea	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Eritrea	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eritrea	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eritrea	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Eritrea	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Eritrea	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eritrea	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Eritrea	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Eritrea	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Eritrea	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eritrea	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Eritrea	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Eritrea	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Eritrea	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Eritrea	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Eritrea	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Eritrea	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Eritrea	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Eritrea	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Eritrea	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Eritrea	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Eritrea	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Eritrea	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Eritrea	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eritrea	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eritrea	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eritrea	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eritrea	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Eritrea	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Eritrea	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Eritrea	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Eritrea	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eritrea	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Eritrea	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Eritrea	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Eritrea	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344

Eritrea	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Eritrea	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Eritrea	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Eritrea	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Eritrea	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Eritrea	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Eritrea	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Eritrea	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Eritrea	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Eritrea	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Eritrea	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Eritrea	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Eritrea	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Eritrea	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Eritrea	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Eritrea	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Eritrea	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Eritrea	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Eritrea	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Eritrea	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Eritrea	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Eritrea	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Eritrea	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Eritrea	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Eritrea	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Eritrea	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Eritrea	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Eritrea	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eritrea	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Eritrea	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Eritrea	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Eritrea	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Eritrea	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Eritrea	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eritrea	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Eritrea	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Eritrea	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eritrea	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Eritrea	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Eritrea	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Eritrea	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Eritrea	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eritrea	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Eritrea	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Eritrea	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eritrea	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Eritrea	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Eritrea	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Eritrea	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Eritrea	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Eritrea	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Eritrea	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Eritrea	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eritrea	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Eritrea	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Eritrea	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		

Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Eritrea	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Eritrea	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Eritrea	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Eritrea	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Eritrea	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Eritrea	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Eritrea	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Eritrea	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eritrea	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Eritrea	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Eritrea	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Eritrea	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Eritrea	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Eritrea	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eritrea	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Eritrea	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Eritrea	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eritrea	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Eritrea	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Eritrea	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Eritrea	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Eritrea	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Eritrea	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Eritrea	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Eritrea	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eritrea	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Eritrea	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Eritrea	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Eritrea	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Eritrea	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Eritrea	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eritrea	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Eritrea	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Eritrea	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Eritrea	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Eritrea	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eritrea	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eritrea	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eritrea	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Eritrea	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Eritrea	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Eritrea	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Eritrea	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Eritrea	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Eritrea	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Eritrea	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Eritrea	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Eritrea	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Eritrea	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Eritrea	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Eritrea	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eritrea	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Eritrea	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Eritrea	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eritrea	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Eritrea	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Eritrea	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Eritrea	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eritrea	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Eritrea	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Eritrea	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eritrea	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Eritrea	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Eritrea	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eritrea	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Eritrea	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Eritrea	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Eritrea	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Eritrea	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Eritrea	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Eritrea	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Eritrea	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Eritrea	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Eritrea	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eritrea	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Eritrea	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eritrea	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eritrea	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Eritrea	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Eritrea	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Eritrea	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eritrea	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Eritrea	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Eritrea	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Eritrea	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Eritrea	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eritrea	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Eritrea	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Eritrea	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Eritrea	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Eritrea	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Eritrea	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Eritrea	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Eritrea	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Eritrea	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Eritrea	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Eritrea	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Eritrea	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Eritrea	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Eritrea	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Eritrea	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Eritrea	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Eritrea	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Eritrea	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eritrea	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Eritrea	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Eritrea	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Eritrea	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Eritrea	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Eritrea	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Eritrea	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Eritrea	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Eritrea	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Eritrea	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Eritrea	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eritrea	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Eritrea	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Eritrea	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Eritrea	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Eritrea	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Eritrea	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Eritrea	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Eritrea	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Eritrea	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Eritrea	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Eritrea	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Eritrea	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Eritrea	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Eritrea	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Eritrea	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Eritrea	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Eritrea	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Eritrea	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Eritrea	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Eritrea	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Eritrea	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Eritrea	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Eritrea	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Eritrea	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Eritrea	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Eritrea	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Eritrea	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Eritrea	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Eritrea	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Eritrea	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Eritrea	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Eritrea	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Eritrea	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Eritrea	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Eritrea	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Eritrea	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Estonia	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Estonia	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Estonia	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Estonia	INFINITI EX35/EX30D	I50	2009.7-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Estonia	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Estonia	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Estonia	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Estonia	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Estonia	INFINITI EX37	I50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI EX37	I50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Estonia	INFINITI EX37	I50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI EX37	I50	2008.6-	Air bag	√	√	√	√		
Estonia	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Estonia	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Estonia	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Estonia	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Estonia	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Estonia	INFINITI EX37	I50	2008.6-	Multi AV	√	√	√	√		
Estonia	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Estonia	INFINITI EX37	I50	2008.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Estonia	INFINITI EX37	I50	2008.6-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Estonia	INFINITI EX37	I50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Estonia	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Estonia	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Estonia	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347,SP0348,SP0349
Estonia	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Estonia	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Estonia	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Estonia	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Estonia	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Estonia	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Estonia	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Estonia	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Estonia	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Estonia	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Estonia	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Estonia	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Estonia	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Estonia	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Estonia	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Estonia	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Estonia	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Estonia	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Estonia	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Estonia	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Estonia	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Estonia	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Estonia	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Estonia	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Estonia	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Estonia	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Estonia	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Estonia	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Estonia	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Estonia	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Estonia	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Estonia	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Estonia	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Estonia	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580

Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Estonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Estonia	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Estonia	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Estonia	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Estonia	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Estonia	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Estonia	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Estonia	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Estonia	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Estonia	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Estonia	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Estonia	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Estonia	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Estonia	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Estonia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Estonia	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Estonia	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Estonia	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Estonia	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Estonia	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Estonia	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Estonia	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Estonia	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Estonia	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Estonia	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Estonia	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Estonia	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Estonia	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Estonia	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Estonia	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Estonia	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Estonia	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Estonia	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Estonia	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Estonia	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Estonia	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Estonia	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Estonia	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Estonia	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Estonia	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Estonia	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Estonia	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Estonia	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Estonia	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Estonia	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Estonia	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Estonia	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Estonia	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Estonia	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Estonia	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Estonia	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Estonia	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Estonia	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Estonia	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Estonia	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Estonia	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Estonia	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Estonia	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Estonia	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Estonia	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Estonia	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Estonia	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Estonia	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Estonia	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Estonia	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Estonia	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Estonia	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Estonia	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Estonia	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Estonia	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Estonia	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Estonia	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Estonia	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Estonia	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Estonia	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Estonia	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Estonia	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Estonia	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Estonia	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		

Estonia	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Estonia	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Estonia	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Estonia	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Estonia	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Estonia	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Estonia	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Estonia	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Estonia	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Estonia	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Estonia	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Estonia	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Estonia	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Estonia	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Estonia	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Estonia	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Estonia	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Estonia	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Estonia	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Estonia	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Estonia	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Estonia	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Estonia	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Estonia	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Estonia	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Estonia	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Estonia	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Estonia	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Estonia	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Estonia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Estonia	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Estonia	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Estonia	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Estonia	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Estonia	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Estonia	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Estonia	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Estonia	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Estonia	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Estonia	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Estonia	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Estonia	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Estonia	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Estonia	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Estonia	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Estonia	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Estonia	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Estonia	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Estonia	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Estonia	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	

XTOOL

Estonia	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Estonia	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Estonia	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Estonia	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Estonia	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Estonia	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Estonia	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Estonia	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Estonia	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Estonia	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Estonia	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Estonia	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Estonia	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Estonia	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Estonia	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Estonia	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Estonia	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Estonia	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Estonia	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Estonia	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Estonia	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Estonia	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Estonia	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Estonia	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Estonia	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Estonia	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583

Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Estonia	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Estonia	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Estonia	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Estonia	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Estonia	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Estonia	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Estonia	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Estonia	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Estonia	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Estonia	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Estonia	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Estonia	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Estonia	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Estonia	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Estonia	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980. AC0981. AC0982	SP0561, SP0562
Estonia	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Estonia	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Estonia	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Estonia	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Estonia	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Estonia	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Estonia	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Estonia	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Estonia	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Estonia	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Estonia	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Estonia	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Estonia	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Estonia	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Estonia	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Estonia	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Estonia	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Estonia	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Estonia	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Estonia	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Estonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980	SP0561, SP0562
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553, SP0554, SP0555, SP0556
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Estonia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

Estonia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Estonia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Estonia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Estonia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Estonia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Estonia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Estonia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Estonia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Estonia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0247,SP0265,SP0270,SP0274
Estonia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Estonia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Estonia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Estonia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Estonia	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Estonia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Estonia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Estonia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Estonia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Estonia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Estonia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Estonia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Estonia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Estonia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Estonia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Estonia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Estonia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604,SP0605,SP0606
Estonia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Estonia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Estonia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Estonia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Estonia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Estonia	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107,AC1108	
Estonia	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Estonia	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Estonia	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274,SP0276
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Estonia	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Estonia	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Estonia	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Estonia	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Estonia	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Estonia	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Estonia	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Estonia	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Estonia	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Estonia	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Estonia	INFINITI QX50	J50	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Estonia	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Estonia	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503

Estonia	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Estonia	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Estonia	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Estonia	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Estonia	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Estonia	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Estonia	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Estonia	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Estonia	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Estonia	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Estonia	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Estonia	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Estonia	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Estonia	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Estonia	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Estonia	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Estonia	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Estonia	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Estonia	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Estonia	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Estonia	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Estonia	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Estonia	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Estonia	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Estonia	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Estonia	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Estonia	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Estonia	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Estonia	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Estonia	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Estonia	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Estonia	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Estonia	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Estonia	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Estonia	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Estonia	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Estonia	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Estonia	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Estonia	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Estonia	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Estonia	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Estonia	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Estonia	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Estonia	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Estonia	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Estonia	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Estonia	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Estonia	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Estonia	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Estonia	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Estonia	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Estonia	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Estonia	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Estonia	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Estonia	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Estonia	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Estonia	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Estonia	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Estonia	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Estonia	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ethiopia	INFINITI EX35/EX37	I50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI EX35/EX37	I50	2011.1-	Air bag	√	√	√	√		
Ethiopia	INFINITI EX35/EX37	I50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Ethiopia	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274

Ethiopia	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ethiopia	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Ethiopia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ethiopia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Ethiopia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ethiopia	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ethiopia	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Ethiopia	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ethiopia	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ethiopia	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ethiopia	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ethiopia	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ethiopia	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Ethiopia	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ethiopia	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Ethiopia	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Ethiopia	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Ethiopia	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Ethiopia	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Ethiopia	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Ethiopia	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Ethiopia	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Ethiopia	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Ethiopia	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Ethiopia	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Ethiopia	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Ethiopia	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Ethiopia	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Ethiopia	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Ethiopia	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Ethiopia	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Ethiopia	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Ethiopia	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Ethiopia	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Ethiopia	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Ethiopia	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Ethiopia	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Ethiopia	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Ethiopia	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Ethiopia	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ethiopia	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Ethiopia	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ethiopia	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Ethiopia	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Ethiopia	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ethiopia	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ethiopia	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Ethiopia	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ethiopia	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Ethiopia	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Ethiopia	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ethiopia	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ethiopia	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Ethiopia	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Ethiopia	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ethiopia	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ethiopia	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Ethiopia	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Ethiopia	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Ethiopia	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ethiopia	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Ethiopia	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	

Xtool

Ethiopia	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ethiopia	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Ethiopia	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Ethiopia	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Ethiopia	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ethiopia	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Ethiopia	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Ethiopia	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ethiopia	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ethiopia	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Ethiopia	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Ethiopia	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Ethiopia	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Ethiopia	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ethiopia	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Ethiopia	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ethiopia	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Ethiopia	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Ethiopia	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ethiopia	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ethiopia	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Ethiopia	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ethiopia	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ethiopia	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Ethiopia	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ethiopia	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ethiopia	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Ethiopia	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ethiopia	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ethiopia	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ethiopia	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Ethiopia	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Ethiopia	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Ethiopia	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Ethiopia	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Ethiopia	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Ethiopia	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ethiopia	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Ethiopia	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Ethiopia	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Ethiopia	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Ethiopia	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ethiopia	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ethiopia	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Ethiopia	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Ethiopia	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Ethiopia	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Ethiopia	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		

Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ethiopia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ethiopia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ethiopia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Ethiopia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Ethiopia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ethiopia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Ethiopia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Ethiopia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ethiopia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ethiopia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Ethiopia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ethiopia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Ethiopia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Ethiopia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ethiopia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ethiopia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Ethiopia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ethiopia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ethiopia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Ethiopia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Ethiopia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Ethiopia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ethiopia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Ethiopia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ethiopia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ethiopia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ethiopia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Ethiopia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ethiopia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Ethiopia	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ethiopia	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Ethiopia	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ethiopia	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Ethiopia	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Ethiopia	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Ethiopia	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ethiopia	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Ethiopia	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ethiopia	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ethiopia	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ethiopia	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ethiopia	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ethiopia	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Ethiopia	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Ethiopia	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ethiopia	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Ethiopia	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ethiopia	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Ethiopia	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Ethiopia	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ethiopia	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Ethiopia	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Ethiopia	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Ethiopia	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ethiopia	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Ethiopia	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Ethiopia	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ethiopia	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ethiopia	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Ethiopia	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ethiopia	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Ethiopia	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Ethiopia	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ethiopia	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ethiopia	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Ethiopia	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Ethiopia	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ethiopia	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ethiopia	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ethiopia	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Ethiopia	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Ethiopia	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ethiopia	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Ethiopia	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ethiopia	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ethiopia	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ethiopia	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Ethiopia	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Ethiopia	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ethiopia	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Ethiopia	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Ethiopia	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ethiopia	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Ethiopia	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ethiopia	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ethiopia	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ethiopia	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Ethiopia	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Ethiopia	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ethiopia	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ethiopia	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ethiopia	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ethiopia	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Ethiopia	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Ethiopia	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Ethiopia	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Ethiopia	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ethiopia	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Ethiopia	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Ethiopia	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ethiopia	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ethiopia	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ethiopia	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Ethiopia	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Ethiopia	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Ethiopia	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Ethiopia	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ethiopia	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ethiopia	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Ethiopia	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ethiopia	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Ethiopia	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Ethiopia	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Ethiopia	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Ethiopia	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Europe common	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Europe common	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Europe common	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Europe common	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Europe common	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Europe common	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Europe common	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Europe common	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Europe common	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Europe common	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Europe common	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Europe common	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Europe common	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Europe common	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Europe common	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Europe common	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Europe common	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Europe common	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Europe common	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Europe common	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Europe common	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Europe common	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Europe common	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Europe common	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Europe common	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Europe common	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Europe common	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Europe common	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Europe common	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Europe common	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Europe common	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Europe common	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Europe common	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Europe common	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Europe common	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Europe common	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Europe common	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Europe common	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Europe common	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Europe common	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		

Europe common	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Europe common	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Europe common	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Europe common	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Europe common	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Europe common	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Europe common	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Europe common	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Europe common	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Europe common	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Europe common	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Europe common	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Europe common	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Europe common	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Europe common	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Europe common	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Europe common	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Europe common	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Europe common	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Europe common	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Europe common	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Europe common	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Europe common	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Europe common	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Europe common	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Europe common	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Europe common	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Europe common	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Europe common	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Europe common	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Europe common	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Europe common	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Europe common	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Europe common	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Europe common	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Europe common	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Europe common	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Europe common	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Europe common	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Europe common	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Europe common	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Europe common	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Europe common	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Europe common	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349

Europe common	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Europe common	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Europe common	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Europe common	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Europe common	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Europe common	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Europe common	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Europe common	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Europe common	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Europe common	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Europe common	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Europe common	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Europe common	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Europe common	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Europe common	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Europe common	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Europe common	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Europe common	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Europe common	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Europe common	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Europe common	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Europe common	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Europe common	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Europe common	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Europe common	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Europe common	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Europe common	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Europe common	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Europe common	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Europe common	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Europe common	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Europe common	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Europe common	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Europe common	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Europe common	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Europe common	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Europe common	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Europe common	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Europe common	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Europe common	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Europe common	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Europe common	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Europe common	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503

Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Europe common	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Europe common	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Europe common	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Europe common	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Europe common	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Europe common	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Europe common	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Europe common	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Europe common	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Europe common	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Europe common	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Europe common	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Europe common	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Europe common	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Europe common	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Europe common	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Europe common	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Europe common	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Finland	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Finland	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Finland	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Finland	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Finland	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Finland	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Finland	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Finland	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Finland	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Finland	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Finland	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Finland	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Finland	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Finland	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Finland	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Finland	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Finland	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Finland	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Finland	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Finland	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Finland	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Finland	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Finland	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Finland	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Finland	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Finland	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Finland	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Finland	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Finland	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Finland	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Finland	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Finland	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Finland	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Finland	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270

Finland	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Finland	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Finland	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Finland	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Finland	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Finland	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Finland	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Finland	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Finland	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Finland	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Finland	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Finland	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Finland	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Finland	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Finland	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Finland	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Finland	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Finland	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Finland	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Finland	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Finland	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Finland	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Finland	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Finland	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Finland	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Finland	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Finland	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Finland	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Finland	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Finland	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Finland	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Finland	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Finland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Finland	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Finland	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Finland	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Finland	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Finland	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Finland	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Finland	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Finland	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Finland	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Finland	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Finland	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Finland	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Finland	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Finland	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Finland	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Finland	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Finland	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Finland	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Finland	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Finland	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Finland	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Finland	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Finland	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Finland	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Finland	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Finland	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Finland	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Finland	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Finland	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Finland	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Finland	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Finland	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Finland	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Finland	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Finland	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Finland	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Finland	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Finland	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Finland	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Finland	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Finland	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Finland	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Finland	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Finland	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Finland	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Finland	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Finland	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Finland	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Finland	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		

Finland	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Finland	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Finland	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Finland	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Finland	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Finland	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Finland	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Finland	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Finland	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Finland	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Finland	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Finland	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Finland	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Finland	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Finland	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Finland	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Finland	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Finland	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Finland	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Finland	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Finland	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Finland	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Finland	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Finland	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Finland	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Finland	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Finland	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Finland	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Finland	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Finland	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		

XTOOL

Finland	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Finland	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Finland	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Finland	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Finland	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Finland	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Finland	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Finland	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Finland	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Finland	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Finland	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Finland	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Finland	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Finland	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Finland	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Finland	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Finland	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Finland	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Finland	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Finland	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Finland	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Finland	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Finland	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Finland	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Finland	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Finland	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Finland	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Finland	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Finland	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Finland	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Finland	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Finland	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Finland	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Finland	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Finland	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Finland	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Finland	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Finland	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Finland	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Finland	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Finland	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Finland	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Finland	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Finland	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Finland	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Finland	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Finland	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Finland	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Finland	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Finland	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Finland	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Finland	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Finland	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Finland	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540

Finland	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Finland	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Finland	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Finland	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Finland	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Finland	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Finland	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Finland	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Finland	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Finland	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Finland	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Finland	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Finland	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Finland	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Finland	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Finland	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Finland	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Finland	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Finland	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Finland	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Finland	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Finland	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Finland	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Finland	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Finland	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Finland	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Finland	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Finland	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Finland	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Finland	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Finland	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Finland	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Finland	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Finland	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Finland	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Finland	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Finland	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Finland	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Finland	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Finland	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Finland	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985. AC0986. AC0987. AC0988. AC0989	SP0563. SP0564. SP0565. SP0566. SP0567
Finland	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Finland	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971. AC0972. AC0973. AC0974. AC0975. AC0976. AC0977	SP0560
Finland	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Finland	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Finland	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Finland	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Finland	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Finland	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Finland	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Finland	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Finland	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Finland	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Finland	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Finland	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Finland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Finland	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Finland	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Finland	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Finland	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Finland	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Finland	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Finland	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Finland	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Finland	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Finland	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Finland	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Finland	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Finland	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Finland	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983. AC0984. AC0985. AC0986. AC0987. AC0988. AC0989. AC0990	SP0563. SP0564. SP0565. SP0566. SP0567
Finland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894. AC0895. AC0896. AC0897. AC0898. AC0899. AC0900. AC0901. AC0902	SP0508. SP0509. SP0510
Finland	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Finland	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

Finland	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Finland	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Finland	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Finland	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Finland	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Finland	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Finland	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Finland	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Finland	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Finland	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Finland	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Finland	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Finland	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Finland	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Finland	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Finland	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Finland	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Finland	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Finland	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Finland	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Finland	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Finland	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Finland	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Finland	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Finland	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Finland	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Finland	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Finland	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Finland	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Finland	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Finland	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Finland	INFINITI QX50	I50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Finland	INFINITI QX50	I50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Finland	INFINITI QX50	I50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Finland	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Finland	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Finland	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Finland	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Finland	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Finland	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Finland	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Finland	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Finland	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Finland	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Finland	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	

Finland	INFINITI QX50	I50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Finland	INFINITI QX50	I50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Finland	INFINITI QX50	I50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Finland	INFINITI QX50	I50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Finland	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Finland	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Finland	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Finland	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Finland	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Finland	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Finland	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Finland	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Finland	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Finland	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Finland	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Finland	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Finland	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Finland	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Finland	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Finland	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Finland	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Finland	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Finland	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Finland	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Finland	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Finland	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Finland	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Finland	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Finland	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Finland	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Finland	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Finland	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Finland	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Finland	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Finland	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Finland	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Finland	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Finland	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Finland	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Finland	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Finland	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Finland	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Finland	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Finland	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Finland	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Finland	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Finland	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Finland	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Finland	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Finland	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Finland	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Finland	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Finland	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Finland	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Finland	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Finland	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
France	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
France	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
France	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
France	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
France	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
France	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
France	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
France	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
France	INFINITI EX35/EX30D	I50	2009.7-	Multi AV	√	√	√	√		SP0503
France	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
France	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
France	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
France	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
France	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
France	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
France	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
France	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
France	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
France	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
France	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
France	INFINITI EX37	I50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI EX37	I50	2008.6-	Air bag	√	√	√	√		
France	INFINITI EX37	I50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
France	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
France	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
France	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
France	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
France	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
France	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
France	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556

France	INFINITI EX37	I50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
France	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
France	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
France	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
France	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
France	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
France	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
France	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
France	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
France	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
France	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
France	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
France	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
France	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
France	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
France	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
France	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
France	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
France	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
France	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
France	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
France	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
France	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
France	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
France	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
France	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
France	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
France	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
France	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
France	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
France	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
France	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
France	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
France	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
France	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
France	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
France	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
France	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494

France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
France	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
France	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
France	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
France	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
France	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
France	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
France	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
France	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
France	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
France	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
France	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
France	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
France	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
France	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
France	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
France	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
France	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
France	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
France	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
France	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
France	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
France	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
France	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
France	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
France	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
France	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
France	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
France	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
France	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
France	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
France	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
France	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
France	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
France	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
France	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
France	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
France	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
France	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
France	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
France	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
France	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
France	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
France	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
France	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
France	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
France	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
France	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
France	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497

France	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
France	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
France	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
France	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
France	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
France	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
France	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
France	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
France	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
France	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
France	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
France	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
France	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
France	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
France	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
France	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
France	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
France	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
France	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
France	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
France	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
France	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
France	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
France	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
France	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
France	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
France	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
France	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
France	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
France	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
France	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
France	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
France	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
France	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
France	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
France	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
France	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
France	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
France	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
France	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
France	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
France	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
France	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
France	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
France	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
France	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
France	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
France	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
France	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
France	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
France	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
France	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
France	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
France	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
France	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
France	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
France	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
France	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
France	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
France	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	

France	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
France	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
France	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
France	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
France	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
France	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
France	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
France	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
France	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
France	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
France	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
France	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
France	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
France	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
France	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
France	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
France	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
France	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
France	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
France	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
France	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
France	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
France	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
France	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
France	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
France	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
France	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
France	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
France	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
France	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
France	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
France	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
France	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
France	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
France	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
France	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
France	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
France	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
France	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
France	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
France	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
France	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
France	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
France	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
France	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
France	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
France	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
France	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
France	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
France	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
France	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
France	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
France	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
France	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
France	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
France	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
France	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
France	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
France	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
France	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
France	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551

France	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
France	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
France	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
France	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
France	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
France	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
France	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
France	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
France	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
France	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
France	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
France	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
France	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
France	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
France	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
France	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
France	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
France	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
France	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
France	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
France	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
France	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
France	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
France	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
France	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
France	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
France	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
France	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
France	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
France	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
France	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
France	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
France	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
France	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
France	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
France	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
France	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
France	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
France	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
France	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
France	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
France	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
France	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
France	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
France	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
France	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
France	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
France	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
France	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
France	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
France	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
France	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
France	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
France	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
France	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
France	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
France	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
France	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
France	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
France	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
France	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
France	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
France	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
France	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
France	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
France	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
France	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
France	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
France	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
France	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
France	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
France	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
France	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
France	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
France	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
France	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
France	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
France	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
France	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
France	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
France	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
France	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
France	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
France	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
France	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
France	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
France	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
France	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
France	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
France	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
France	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
France	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
France	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
France	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
France	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
France	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
France	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
France	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
France	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	

France	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
France	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
France	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
France	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
France	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
France	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
France	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
France	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
France	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
France	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
France	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
France	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
France	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
France	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
France	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
France	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
France	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
France	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
France	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
France	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
France	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
France	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
France	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
France	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
France	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
France	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
France	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
France	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
France	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
France	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
France	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
France	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
France	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
France	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
France	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
France	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
France	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
France	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
France	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
France	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
France	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
France	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
France	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
France	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
France	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
France	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
France	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
France	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
France	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
France	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
France	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
France	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
France	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
France	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
France	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
France	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	

XTOOL

France	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
France	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
France	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
France	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
France	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
France	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
France	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
France	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
France	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
France	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
France	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
France	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
France	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
France	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
France	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
France	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
France	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
France	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
France	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
France	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
France	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
France	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
France	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
France	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
France	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
France	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
France	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
France	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
France	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
France	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
France	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
France	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
France	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
France	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
France	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
France	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
France	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
France	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
France	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
France	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
France	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
France	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
France	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
France	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
France	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
France	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
France	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
France	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
France	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
France	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
France	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
France	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
France	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
France	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
France	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
France	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
France	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
France	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
France	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
France	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
France	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
France	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
France	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
France	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
France	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
France	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
France	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
France	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
France	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
France	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
France	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
France	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
France	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
France	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
France	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
France	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
France	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
France	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

France	INFINITI QX50	I50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
France	INFINITI QX50	I50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
France	INFINITI QX50	I50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
France	INFINITI QX50	I50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
France	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
France	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
France	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
France	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
France	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
France	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
France	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
France	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
France	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
France	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
France	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
France	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
France	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
France	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
France	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
France	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
France	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
France	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
France	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
France	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
France	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
France	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
France	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
France	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
France	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
France	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
France	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
France	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
France	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
France	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
France	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
France	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
France	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
France	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
France	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
France	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
France	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
France	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
France	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
France	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
France	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
France	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
France	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
France	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
France	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
France	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
France	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
France	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
France	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
France	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
France	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
France	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
France	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
France	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
France	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
France	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
French guyana	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
French guyana	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
French guyana	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
French guyana	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
French guyana	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
French guyana	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583

French guyana	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
French guyana	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
French guyana	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
French guyana	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
French guyana	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
French guyana	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
French guyana	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
French guyana	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
French guyana	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
French guyana	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
French guyana	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
French guyana	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
French guyana	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
French guyana	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
French guyana	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
French guyana	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
French guyana	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
French guyana	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
French guyana	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
French guyana	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
French guyana	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
French guyana	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
French guyana	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
French guyana	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
French guyana	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
French guyana	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
French guyana	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
French guyana	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
French guyana	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
French guyana	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
French guyana	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
French guyana	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
French guyana	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
French guyana	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
French guyana	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
French guyana	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
French guyana	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
French guyana	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
French guyana	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
French guyana	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
French guyana	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
French guyana	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
French guyana	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
French guyana	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
French guyana	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
French guyana	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
French guyana	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
French guyana	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
French guyana	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349

French guyana	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
French guyana	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
French guyana	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
French guyana	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
French guyana	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
French guyana	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
French guyana	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
French guyana	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
French guyana	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
French guyana	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
French guyana	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
French guyana	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
French guyana	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
French guyana	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
French guyana	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
French guyana	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
French guyana	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
French guyana	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
French guyana	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
French guyana	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
French guyana	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
French guyana	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
French guyana	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
French guyana	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
French guyana	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
French guyana	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
French guyana	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
French guyana	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
French guyana	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
French guyana	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
French guyana	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
French guyana	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
French guyana	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
French guyana	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
French guyana	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
French guyana	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		

XTOOL

French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
French guyana	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
French guyana	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
French guyana	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
French guyana	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
French guyana	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
French guyana	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
French guyana	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
French guyana	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	AVM	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
French guyana	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
French guyana	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
French guyana	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
French guyana	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
French guyana	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
French guyana	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
French guyana	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
French guyana	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
French guyana	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
French guyana	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
French guyana	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
French guyana	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
French guyana	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
French guyana	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
French guyana	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
French guyana	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344

XTOOL

French guyana	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
French guyana	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
French guyana	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
French guyana	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
French guyana	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
French guyana	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
French guyana	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
French guyana	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
French guyana	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
French guyana	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
French guyana	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
French guyana	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
French guyana	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
French guyana	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
French guyana	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
French guyana	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
French guyana	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
French guyana	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
French guyana	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
French guyana	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
French guyana	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
French guyana	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
French guyana	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
French guyana	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
French guyana	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
French guyana	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
French guyana	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
French guyana	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
French guyana	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	

XTOOL

French guyana	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
French guyana	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
French guyana	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
French guyana	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
French guyana	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
French guyana	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
French guyana	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
French guyana	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
French guyana	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
French guyana	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
French guyana	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
French guyana	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
French guyana	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
French guyana	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
French guyana	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
French guyana	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
French guyana	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
French guyana	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
French guyana	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
French guyana	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
French guyana	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
French guyana	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
French guyana	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
French guyana	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
French guyana	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
French guyana	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
French guyana	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
French guyana	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
French guyana	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	

French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
French guyana	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
French guyana	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
French guyana	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
French guyana	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
French guyana	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
French guyana	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
French guyana	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
French guyana	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

XTOOL

French guyana	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
French guyana	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
French guyana	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
French guyana	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
French guyana	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
French guyana	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
French guyana	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
French guyana	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
French guyana	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
French guyana	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
French guyana	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
French guyana	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
French guyana	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
French guyana	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
French guyana	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
French guyana	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
French guyana	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
French guyana	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
French guyana	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
French guyana	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
French guyana	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
French guyana	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
French guyana	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
French guyana	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
French guyana	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
French guyana	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
French guyana	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
French guyana	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
French guyana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

XTOOL

French guyana	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
French guyana	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
French guyana	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
French guyana	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
French guyana	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
French guyana	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
French guyana	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
French guyana	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
French guyana	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
French guyana	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
French guyana	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
French guyana	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
French guyana	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
French guyana	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
French guyana	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
French guyana	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
French guyana	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
French guyana	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
French guyana	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
French guyana	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
French guyana	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
French guyana	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
French guyana	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
French guyana	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
French guyana	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
French guyana	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
French guyana	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
French guyana	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
French guyana	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
French guyana	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
French guyana	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
French guyana	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
French guyana	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		

French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
French guyana	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
French guyana	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
French guyana	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
French guyana	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
French guyana	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
French guyana	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
French guyana	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
French guyana	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
French guyana	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
French guyana	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
French guyana	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
French guyana	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
French guyana	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
French guyana	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
French guyana	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
French guyana	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
French guyana	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
French guyana	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
French guyana	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
French guyana	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
French guyana	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
French guyana	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
French guyana	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	

French guyana	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
French guyana	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
French guyana	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
French guyana	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
French guyana	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
French guyana	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
French guyana	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
French guyana	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
French guyana	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
French guyana	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
French guyana	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
French guyana	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
French guyana	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
French guyana	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
French guyana	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
French guyana	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
French guyana	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
French guyana	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
French guyana	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
French guyana	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
French guyana	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
French guyana	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
French guyana	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
French guyana	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
French guyana	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
French guyana	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
French guyana	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
French guyana	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
French guyana	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
French guyana	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
French guyana	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
French guyana	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
French guyana	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
French guyana	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
French guyana	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
French guyana	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
French guyana	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
French guyana	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
French guyana	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
French guyana	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
French guyana	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
French guyana	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
French guyana	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
French guyana	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
French guyana	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
French guyana	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
French guyana	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Gabon	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gabon	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gabon	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Gabon	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gabon	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gabon	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Gabon	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gabon	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gabon	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gabon	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gabon	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gabon	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556

Gabon	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Gabon	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Gabon	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Gabon	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Gabon	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Gabon	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Gabon	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gabon	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gabon	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Gabon	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gabon	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gabon	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Gabon	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gabon	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Gabon	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Gabon	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Gabon	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gabon	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Gabon	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Gabon	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gabon	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gabon	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Gabon	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Gabon	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Gabon	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Gabon	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gabon	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Gabon	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Gabon	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Gabon	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gabon	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gabon	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Gabon	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

XTOOL

Gabon	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gabon	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Gabon	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gabon	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Gabon	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Gabon	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gabon	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gabon	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gabon	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gabon	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Gabon	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gabon	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Gabon	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Gabon	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Gabon	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Gabon	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gabon	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Gabon	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Gabon	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gabon	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Gabon	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Gabon	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Gabon	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Gabon	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Gabon	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Gabon	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gabon	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gabon	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gabon	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gabon	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gabon	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Gabon	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Gabon	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Gabon	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Gabon	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gabon	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Gabon	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Gabon	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Gabon	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Gabon	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Gabon	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Gabon	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Gabon	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Gabon	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Gabon	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Gabon	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Gabon	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Gabon	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Gabon	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Gabon	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Gabon	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Gabon	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Gabon	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Gabon	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Gabon	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Gabon	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Gabon	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Gabon	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Gabon	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Gabon	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Gabon	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gabon	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Gabon	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gabon	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gabon	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Gabon	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		

Xtool

Gabon	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Gabon	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gabon	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Gabon	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Gabon	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Gabon	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Gabon	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Gabon	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gabon	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gabon	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Gabon	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Gabon	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gabon	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Gabon	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Gabon	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Gabon	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Gabon	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gabon	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Gabon	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Gabon	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gabon	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Gabon	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Gabon	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Gabon	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gabon	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Gabon	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Gabon	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Gabon	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gabon	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Gabon	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Gabon	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Gabon	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Gabon	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gabon	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Gabon	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gabon	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gabon	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Gabon	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Gabon	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Gabon	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gabon	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Gabon	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Gabon	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Gabon	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Gabon	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Gabon	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gabon	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gabon	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Gabon	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Gabon	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	

Gabon	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Gabon	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Gabon	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Gabon	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Gabon	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Gabon	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Gabon	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Gabon	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gabon	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Gabon	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Gabon	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Gabon	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Gabon	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Gabon	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Gabon	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Gabon	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Gabon	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Gabon	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Gabon	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Gabon	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Gabon	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gabon	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Gabon	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Gabon	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Gabon	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Gabon	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Gabon	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Gabon	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Gabon	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Gabon	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Gabon	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Gabon	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Gabon	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Gabon	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Gabon	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Gabon	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Gabon	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584

XTOOL

Gabon	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Gabon	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gabon	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Gabon	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Gabon	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Gabon	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gabon	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Gabon	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gabon	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gabon	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gabon	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Gabon	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gabon	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Gabon	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gabon	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Gabon	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gabon	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gabon	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Gabon	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Gabon	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gabon	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gabon	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Gabon	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gabon	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gabon	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gabon	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gabon	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gabon	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gabon	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Gabon	INFINITI QX50	I50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Gabon	INFINITI QX50	I50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gabon	INFINITI QX50	I50	2013.8-	CAN gateway	√	√	√	√		
Gabon	INFINITI QX50	I50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gabon	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Gabon	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Gabon	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gabon	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Gabon	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Gabon	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Gabon	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gabon	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gabon	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Gabon	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Gabon	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gabon	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gabon	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Gabon	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gabon	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Gabon	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Gabon	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Gabon	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gabon	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gabon	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Gabon	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Gabon	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gabon	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gabon	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gabon	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Gabon	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Gabon	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gabon	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Gabon	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gabon	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gabon	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gabon	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Gabon	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Gabon	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gabon	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Gabon	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Gabon	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gabon	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Gabon	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gabon	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Gabon	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gabon	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Gabon	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Gabon	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gabon	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Gabon	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Gabon	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Gabon	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Gabon	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Gabon	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Gabon	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Gabon	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gabon	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Gabon	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Gabon	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Gabon	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gabon	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Gabon	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Gabon	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Gabon	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Gabon	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			

Gabon	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gabon	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gabon	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Gabon	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gabon	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Gabon	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Gabon	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Gabon	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Gabon	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Gambia	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gambia	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gambia	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Gambia	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gambia	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gambia	INFINITI EX35/EX37	I50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Gambia	INFINITI EX35/EX37	I50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gambia	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gambia	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gambia	INFINITI EX35/EX37	I50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gambia	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gambia	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gambia	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Gambia	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Gambia	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Gambia	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Gambia	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Gambia	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Gambia	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gambia	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gambia	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Gambia	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gambia	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gambia	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Gambia	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gambia	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Gambia	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Gambia	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Gambia	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gambia	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Gambia	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Gambia	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gambia	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gambia	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Gambia	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Gambia	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Gambia	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Gambia	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gambia	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Gambia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Gambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Gambia	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gambia	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gambia	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Gambia	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gambia	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gambia	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Gambia	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gambia	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Gambia	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Gambia	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gambia	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gambia	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gambia	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gambia	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Gambia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gambia	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Gambia	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Gambia	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Gambia	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Gambia	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gambia	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Gambia	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Gambia	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gambia	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Gambia	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Gambia	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Gambia	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Gambia	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Gambia	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Gambia	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gambia	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gambia	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gambia	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gambia	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553. SP0554. SP0555. SP0556
Gambia	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Gambia	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Gambia	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Gambia	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Gambia	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gambia	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Gambia	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Gambia	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Gambia	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Gambia	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Gambia	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Gambia	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Gambia	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Gambia	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Gambia	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Gambia	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Gambia	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Gambia	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Gambia	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Gambia	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Gambia	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Gambia	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Gambia	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Gambia	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Gambia	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			

Gambia	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Gambia	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Gambia	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Gambia	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Gambia	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Gambia	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Gambia	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Gambia	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Gambia	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Gambia	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Gambia	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Gambia	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Gambia	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Gambia	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0274
Gambia	INFINITI Q50	V37	2013.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Gambia	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
Gambia	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Gambia	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Gambia	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Gambia	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Gambia	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Gambia	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979,AC0981,AC0982	SP0562
Gambia	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Gambia	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Gambia	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Gambia	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Gambia	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Gambia	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Gambia	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Gambia	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Gambia	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gambia	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Gambia	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604,SP0605,SP0606
Gambia	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Gambia	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Gambia	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Gambia	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Gambia	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Gambia	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Gambia	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Gambia	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Gambia	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811.AC0815.AC0816.AC0817.AC0818.AC0819.AC0821.AC0822.AC0825.AC0831	
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0330,AC0331,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247,SP0274,SP0276
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946.AC0947.AC0948.AC0950.AC0951.AC0952.AC0953.AC0954.AC0955	SP0541.SP0542.SP0543
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979,AC0981,AC0982	SP0562
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
Gambia	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122.AC1123.AC1124.AC1125.AC1126	
Gambia	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897.AC0898.AC0899.AC0900.AC0901.AC0902	SP0508.SP0509
Gambia	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Gambia	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Gambia	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Gambia	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Gambia	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Gambia	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351

Gambia	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gambia	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Gambia	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Gambia	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Gambia	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Gambia	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Gambia	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gambia	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gambia	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Gambia	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Gambia	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gambia	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Gambia	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Gambia	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Gambia	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Gambia	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Gambia	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Gambia	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Gambia	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gambia	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Gambia	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Gambia	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Gambia	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Gambia	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Gambia	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gambia	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Gambia	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Gambia	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Gambia	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Gambia	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gambia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gambia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Gambia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Gambia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

Gambia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Gambia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Gambia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Gambia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Gambia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gambia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Gambia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Gambia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Gambia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Gambia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Gambia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gambia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gambia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Gambia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Gambia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gambia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Gambia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Gambia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Gambia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gambia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Gambia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gambia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gambia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gambia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Gambia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gambia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Gambia	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gambia	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Gambia	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gambia	INFINITI QX50	I50	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Gambia	INFINITI QX50	I50	2013.8-	Air bag	√	√	√	√		
Gambia	INFINITI QX50	I50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Gambia	INFINITI QX50	I50	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Gambia	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gambia	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Gambia	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gambia	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gambia	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gambia	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gambia	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gambia	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gambia	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Gambia	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Gambia	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gambia	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Gambia	INFINITI QX50	I50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gambia	INFINITI QX50	I50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Gambia	INFINITI QX50	I50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Gambia	INFINITI QX50	I50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gambia	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Gambia	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Gambia	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Gambia	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gambia	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gambia	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Gambia	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Gambia	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gambia	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gambia	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Gambia	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gambia	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Gambia	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Gambia	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Gambia	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gambia	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gambia	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Gambia	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Gambia	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gambia	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gambia	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gambia	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Gambia	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Gambia	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gambia	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Gambia	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gambia	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gambia	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gambia	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Gambia	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Gambia	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gambia	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Gambia	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Gambia	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gambia	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Gambia	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gambia	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Gambia	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gambia	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Gambia	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Gambia	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gambia	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Gambia	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Gambia	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Gambia	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Gambia	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Gambia	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Gambia	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Gambia	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gambia	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Gambia	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Gambia	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Gambia	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gambia	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Gambia	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Gambia	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Gambia	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Gambia	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Gambia	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gambia	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gambia	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Gambia	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gambia	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Gambia	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Gambia	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Gambia	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Gambia	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Gaza	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gaza	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Gaza	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gaza strip	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Gaza strip	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Gaza	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gaza strip	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gaza	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gaza	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Gaza	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Gaza	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gaza	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Gaza	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gaza strip	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gaza	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Gaza	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gaza strip	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gaza	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gaza	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Gaza	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Gaza	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Gaza	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Gaza	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gaza strip	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Gaza	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Gaza	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Gaza	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Gaza	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Gaza strip	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza strip	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Gaza strip	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Gaza strip	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Gaza	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Gaza	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Gaza strip	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Gaza	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Gaza	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Gaza	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gaza	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Gaza	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Gaza strip	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Gaza	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Gaza	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Gaza	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Gaza	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Gaza	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Gaza	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Gaza	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Gaza	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Gaza	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Gaza	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Gaza	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Gaza	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Gaza	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Gaza	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894. AC0895. AC0896	SP0510
Gaza	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gaza	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Gaza	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gaza strip	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gaza strip	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Gaza	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gaza	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Gaza	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Gaza	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Gaza	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Gaza strip	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Gaza	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Gaza	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gaza	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Gaza	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962. AC0963. AC0964. AC0966. AC0967. AC0968	SP0553. SP0554. SP0555. SP0556. SP0557
Gaza	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Gaza	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Gaza	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Gaza	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Gaza strip	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Gaza	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gaza strip	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Gaza	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Gaza strip	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza strip	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Gaza strip	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Gaza strip	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Gaza	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Gaza strip	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Gaza	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962. AC0963. AC0964. AC0966. AC0967. AC0968. AC0969. AC0970	SP0553. SP0554. SP0555. SP0556. SP0557. SP0558. SP0559
Gaza	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Gaza	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Gaza strip	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Gaza	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Gaza	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Gaza	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Gaza	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Gaza	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894. AC0895. AC0896. AC0897. AC0898. AC0899. AC0900. AC0901. AC0902	SP0508, SP0509, SP0510
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Gaza	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gaza strip	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Gaza	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Gaza strip	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza strip	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Gaza strip	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Gaza strip	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Gaza	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Gaza strip	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Gaza	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gaza	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Gaza	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza strip	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971. AC0972. AC0973	
Gaza	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Gaza	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Gaza	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Gaza	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Gaza	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Gaza	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Gaza	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gaza strip	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Gaza strip	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Gaza	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gaza strip	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Gaza strip	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Gaza	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Gaza	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gaza strip	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865. AC0866. AC0867. AC0868. AC0876. AC0877. AC0884	SP0494
Gaza	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Gaza	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Gaza strip	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza strip	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Gaza	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gaza strip	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Gaza	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Gaza	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gaza strip	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gaza	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gaza	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Gaza	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Gaza	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Gaza	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gaza strip	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Gaza strip	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Gaza	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gaza strip	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Gaza	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gaza strip	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gaza	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gaza	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Gaza	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Gaza	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Gaza	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Gaza	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Gaza	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Gaza	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Gaza strip	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√	AC0276, AC0278, AC0279	SP0276, SP0278, SP0279
Gaza	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Gaza	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Gaza	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Gaza	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Gaza	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Gaza	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Gaza	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Gaza	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Gaza	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Gaza	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Gaza	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Gaza	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Gaza strip	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Gaza	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Gaza	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Gaza strip	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Gaza strip	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Gaza	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Gaza strip	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Gaza strip	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Gaza	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Gaza	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Gaza	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Gaza strip	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Gaza	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Gaza	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Gaza	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Gaza	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Gaza strip	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Gaza	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Gaza	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Gaza strip	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza strip	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Gaza	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471

Gaza strip	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Gaza	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Gaza	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Gaza	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gaza strip	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gaza	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Gaza	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Gaza	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Gaza	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Gaza	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Gaza	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Gaza strip	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Gaza	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Gaza strip	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Gaza	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Gaza	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Gaza	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Gaza	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Gaza strip	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Gaza strip	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Gaza strip	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Gaza strip	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Gaza strip	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Gaza strip	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Gaza	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Gaza	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Gaza strip	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Gaza	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Gaza	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Gaza strip	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Gaza	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Gaza strip	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Gaza	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Gaza	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Gaza strip	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Gaza strip	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Gaza	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Gaza	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Gaza strip	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Gaza strip	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Gaza	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Gaza	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Gaza	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Gaza strip	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Gaza strip	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Gaza strip	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Gaza strip	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Gaza strip	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Gaza strip	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Gaza	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Gaza strip	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Gaza	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Gaza strip	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Gaza	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		

XTOOL

Gaza strip	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Gaza strip	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Gaza strip	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Gaza	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Gaza	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Gaza	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Gaza	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gaza strip	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Gaza	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Gaza	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Gaza	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Gaza	INFINITI Q45	F50	2001.8-	Motor control						
Gaza strip	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza strip	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Gaza strip	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Gaza strip	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Gaza	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Gaza	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Gaza strip	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Gaza	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Gaza	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Gaza	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gaza	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Gaza	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza strip	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Gaza	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Gaza	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Gaza	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Gaza	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Gaza	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Gaza	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Gaza	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Gaza	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Gaza	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Gaza	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Gaza	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Gaza	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Gaza	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Gaza	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Gaza	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Gaza	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gaza	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Gaza	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Gaza	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Gaza strip	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Gaza	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Gaza strip	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Gaza	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Gaza	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Gaza	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Gaza	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gaza strip	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Gaza	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Gaza	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gaza	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Gaza	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Gaza	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Gaza	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Gaza	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gaza	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Gaza	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Gaza strip	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Gaza	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Gaza	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Gaza	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Gaza	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gaza	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Gaza	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Gaza	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Gaza	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Gaza	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Gaza	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Gaza	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		

Gaza	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Gaza	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Gaza strip	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Gaza strip	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Gaza strip	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962. AC0963. AC0964. AC0966. AC0967. AC0968. AC0969. AC0970	SP0553. SP0554. SP0555. SP0556. SP0557. SP0558. SP0559
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Gaza strip	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Gaza	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Gaza strip	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Gaza strip	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Gaza strip	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Gaza strip	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Gaza	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Gaza	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gaza	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Gaza	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gaza	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Gaza	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Gaza	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Gaza strip	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Gaza	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Gaza	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Gaza strip	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Gaza	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Gaza	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Gaza	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Gaza strip	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Gaza	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Gaza	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Gaza	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Gaza	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Gaza	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Gaza	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Gaza	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Gaza	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Gaza	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Gaza	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Gaza	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Gaza	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Gaza	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Gaza	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Gaza	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Gaza	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Gaza	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Gaza	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Gaza	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Gaza	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Gaza strip	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Gaza strip	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Gaza strip	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Gaza strip	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Gaza	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Gaza	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Gaza	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Gaza	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Gaza	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Gaza	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Gaza	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Gaza	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		

Gaza strip	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gaza strip	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Gaza	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Gaza strip	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Gaza	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Gaza	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Gaza	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Gaza	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gaza strip	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Gaza	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Gaza	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Gaza	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gaza	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Gaza	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Gaza	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Gaza	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Gaza	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gaza	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Gaza	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gaza	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Gaza	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Gaza	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Gaza	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Gaza	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Gaza	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gaza	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Gaza	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gaza	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Gaza	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Gaza	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gaza strip	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gaza	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Gaza	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gaza strip	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Gaza	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gaza	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gaza	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Gaza	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Gaza	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gaza	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Gaza	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gaza	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Gaza	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Gaza strip	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Gaza strip	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Gaza	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Gaza	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Gaza	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Gaza strip	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Gaza strip	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Gaza	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Gaza	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Gaza	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Gaza	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Gaza	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Gaza	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Gaza	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Gaza	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Gaza	INFINITI QX50	J55	2018.5-	Shift						
Gaza	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Gaza	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gaza	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Gaza	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Gaza	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Gaza	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Gaza	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Gaza	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Gaza	INFINITI QX50	J55	2018.5-	ANC						
Gaza	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Gaza	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gaza	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		

Gaza	INFINITI QX50	I55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Gaza	INFINITI QX50	I55	2018.5-	ICC/ADAS 2	√	√	√	√		
Gaza	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Gaza	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Gaza	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Gaza strip	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Gaza	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Gaza	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Gaza	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Gaza	INFINITI QX56	JA60	2004.10-	Motor control						
Gaza strip	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza strip	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Gaza strip	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Gaza strip	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Gaza	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Gaza	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Gaza	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Gaza strip	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Gaza	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Gaza	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Gaza	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gaza	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Gaza	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza strip	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Gaza	INFINITI QX56	IA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Gaza	INFINITI QX56	IA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI QX56	IA60	2004.10-	IVMS	√	√		√		
Gaza	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Gaza	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Gaza	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Gaza	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Gaza	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Gaza	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Gaza	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Gaza	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Gaza	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Gaza	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Gaza	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Gaza	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Gaza	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Gaza	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Gaza	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Gaza	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Gaza strip	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270, SP0274
Gaza	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Gaza	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Gaza	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Gaza	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Gaza	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Gaza	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Gaza	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gaza	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gaza	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Gaza	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Gaza	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Gaza	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gaza	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gaza	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Gaza	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gaza	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Gaza	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Gaza	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Gaza	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Gaza strip	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza strip	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Gaza	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Gaza strip	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Gaza	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Gaza	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Gaza	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Gaza	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Gaza	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Gaza	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Gaza	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gaza	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Gaza	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Gaza	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			

Gaza	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gaza	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gaza	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Gaza	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gaza	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Gaza	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Gaza	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Gaza	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Gaza	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Gaza strip	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza strip	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Gaza strip	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Gaza	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Gaza	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Gaza	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Gaza	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gaza	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Gaza	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Gaza	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Gaza strip	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Gaza strip	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Gaza	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Gaza	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Gaza	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Gaza	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Gaza	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Gaza	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gaza strip	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Gaza	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Gaza	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Gaza	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Gaza	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gaza	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Gaza	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Gaza	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gaza	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Gaza	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gaza	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Gaza	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gaza	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Gaza	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Gaza	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Gaza	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Gaza strip	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Gaza	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Gaza	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Gaza	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Gaza	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Gaza strip	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Gaza strip	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Gaza	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Gaza	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Gaza	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Gaza strip	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Gaza	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Gaza	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Gaza	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Gaza strip	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Gaza	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Gaza	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Gaza	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Gaza	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Gaza	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Gaza	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Gaza	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Gaza	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Gaza strip	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Gaza	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Gaza	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Gaza	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Gaza	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Gaza	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Gaza	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Gaza	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Gaza	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Gaza	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Gaza	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Gaza	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Georgia	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Georgia	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Georgia	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Georgia	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Georgia	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Georgia	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Georgia	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI EX35	I50	2008.1-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Georgia	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Georgia	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Georgia	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Georgia	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Georgia	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Georgia	INFINITI EX35/EX37	I50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Georgia	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Georgia	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Georgia	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Georgia	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI EX35/EX37	I50	2011.1-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Georgia	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Georgia	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Georgia	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Georgia	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Georgia	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Georgia	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Georgia	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Georgia	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Georgia	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Georgia	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Georgia	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Georgia	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Georgia	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Georgia	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Georgia	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Georgia	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Georgia	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Georgia	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Georgia	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Georgia	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Georgia	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Georgia	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Georgia	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Georgia	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Georgia	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Georgia	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Georgia	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Georgia	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Georgia	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Georgia	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Georgia	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Georgia	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Georgia	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568

Georgia	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Georgia	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Georgia	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Georgia	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Georgia	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Georgia	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Georgia	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Georgia	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Georgia	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Georgia	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Georgia	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Georgia	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Georgia	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Georgia	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Georgia	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Georgia	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Georgia	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0555,SP0556,SP0557
Georgia	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Georgia	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Georgia	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Georgia	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Georgia	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570,SP0571
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270,SP0274
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957	
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Georgia	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
Georgia	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Georgia	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Georgia	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
Georgia	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
Georgia	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Georgia	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Georgia	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Georgia	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Georgia	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Georgia	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Georgia	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Georgia	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572,SP0573
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570,SP0571
Georgia	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493

Georgia	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Georgia	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Georgia	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Georgia	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Georgia	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Georgia	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Georgia	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Georgia	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Georgia	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Georgia	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Georgia	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Georgia	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Georgia	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Georgia	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Georgia	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Georgia	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Georgia	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Georgia	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Georgia	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Georgia	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Georgia	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Georgia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Georgia	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Georgia	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Georgia	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Georgia	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Georgia	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Georgia	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Georgia	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Georgia	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Georgia	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Georgia	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Georgia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Georgia	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Georgia	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Georgia	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Georgia	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Georgia	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Georgia	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Georgia	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Georgia	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Georgia	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Georgia	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Georgia	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Georgia	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Georgia	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Georgia	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Georgia	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Georgia	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Georgia	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Georgia	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Georgia	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Georgia	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Georgia	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Georgia	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Georgia	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Georgia	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Georgia	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Georgia	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Georgia	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Georgia	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Georgia	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Georgia	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Georgia	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Georgia	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Georgia	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Georgia	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Georgia	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Georgia	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Georgia	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Georgia	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Georgia	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Georgia	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Georgia	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Georgia	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Georgia	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Georgia	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Georgia	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Georgia	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Georgia	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Georgia	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Georgia	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Georgia	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Georgia	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Georgia	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Georgia	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Georgia	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Georgia	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Georgia	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Georgia	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Georgia	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		

Georgia	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Georgia	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Georgia	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Georgia	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Georgia	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Georgia	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Georgia	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Georgia	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Georgia	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Georgia	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Georgia	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Georgia	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Georgia	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Georgia	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Georgia	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Georgia	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Georgia	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Georgia	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Georgia	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Georgia	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Georgia	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Georgia	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Georgia	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Georgia	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Georgia	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Georgia	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Georgia	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Georgia	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Georgia	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Georgia	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Georgia	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Georgia	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Georgia	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Georgia	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Georgia	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Georgia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Georgia	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Georgia	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Georgia	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Georgia	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Georgia	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		

Georgia	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Georgia	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Georgia	INFINITI Q45	F50	2001.8-	Motor control						
Georgia	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Georgia	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Georgia	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Georgia	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Georgia	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Georgia	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Georgia	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Georgia	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Georgia	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Georgia	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Georgia	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Georgia	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Georgia	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Georgia	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Georgia	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Georgia	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Georgia	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Georgia	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Georgia	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Georgia	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Georgia	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Georgia	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Georgia	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Georgia	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Georgia	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Georgia	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Georgia	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Georgia	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Georgia	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Georgia	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Georgia	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Georgia	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Georgia	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Georgia	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Georgia	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Georgia	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Georgia	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Georgia	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Georgia	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Georgia	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Georgia	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Georgia	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Georgia	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Georgia	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Georgia	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Georgia	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Georgia	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Georgia	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Georgia	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Georgia	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Georgia	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Georgia	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Georgia	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Georgia	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Georgia	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Georgia	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Georgia	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Georgia	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		

Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Georgia	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Georgia	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Georgia	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Georgia	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Georgia	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Georgia	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Georgia	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Georgia	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Georgia	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Georgia	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Georgia	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Georgia	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Georgia	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Georgia	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Georgia	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Georgia	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562

Georgia	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Georgia	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Georgia	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Georgia	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Georgia	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Georgia	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Georgia	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Georgia	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Georgia	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Georgia	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Georgia	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Georgia	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Georgia	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Georgia	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Georgia	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Georgia	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Georgia	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Georgia	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Georgia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Georgia	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Georgia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Georgia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Georgia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Georgia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Georgia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Georgia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Georgia	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Georgia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Georgia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0247,SP0265,SP0270,SP0274,SP0276
Georgia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471

XTOOL

Georgia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Georgia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Georgia	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Georgia	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Georgia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Georgia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Georgia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Georgia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Georgia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Georgia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Georgia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Georgia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Georgia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Georgia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Georgia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Georgia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Georgia	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Georgia	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Georgia	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Georgia	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Georgia	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Georgia	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Georgia	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Georgia	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Georgia	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Georgia	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Georgia	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Georgia	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Georgia	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Georgia	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Georgia	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Georgia	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Georgia	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Georgia	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Georgia	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Georgia	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Georgia	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Georgia	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Georgia	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Georgia	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Georgia	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Georgia	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Georgia	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Georgia	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Georgia	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Georgia	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Georgia	INFINITI QX50	J55	2018.5-	Shift						
Georgia	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Georgia	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	ANC						
Georgia	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Georgia	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Georgia	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Georgia	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Georgia	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Georgia	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Georgia	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Georgia	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Georgia	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Georgia	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Georgia	INFINITI QX56	JA60	2004.10-	Motor control						

Georgia	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Georgia	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Georgia	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Georgia	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Georgia	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Georgia	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Georgia	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Georgia	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Georgia	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Georgia	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Georgia	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Georgia	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Georgia	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Georgia	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Georgia	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Georgia	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Georgia	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Georgia	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Georgia	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Georgia	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Georgia	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Georgia	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Georgia	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Georgia	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Georgia	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Georgia	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Georgia	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Georgia	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Georgia	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270, SP0274
Georgia	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Georgia	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Georgia	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Georgia	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Georgia	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Georgia	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Georgia	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Georgia	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Georgia	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Georgia	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Georgia	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Georgia	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Georgia	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Georgia	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Georgia	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Georgia	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Georgia	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Georgia	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Georgia	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Georgia	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Georgia	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Georgia	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Georgia	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Georgia	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Georgia	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Georgia	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Georgia	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Georgia	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Georgia	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Georgia	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Georgia	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Georgia	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Georgia	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Georgia	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Georgia	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Georgia	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Georgia	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Georgia	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		

Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Georgia	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Georgia	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Georgia	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Georgia	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Georgia	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Georgia	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Georgia	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Georgia	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Georgia	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Georgia	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Georgia	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Georgia	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Georgia	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Georgia	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Georgia	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Georgia	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Georgia	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Georgia	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Georgia	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Georgia	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Georgia	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Georgia	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Georgia	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Georgia	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Georgia	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Georgia	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Georgia	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Georgia	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Georgia	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Georgia	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Georgia	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Georgia	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Georgia	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Georgia	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Georgia	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Georgia	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Georgia	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Georgia	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Georgia	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Georgia	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Georgia	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Georgia	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Georgia	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Georgia	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Georgia	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Georgia	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Georgia	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Georgia	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Georgia	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Georgia	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Georgia	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Georgia	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Georgia	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Georgia	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Georgia	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Georgia	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Georgia	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Georgia	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Georgia	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Georgia	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Georgia	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Georgia	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Georgia	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Georgia	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Germany	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Germany	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Germany	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Germany	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Germany	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Germany	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Germany	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Germany	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Germany	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Germany	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Germany	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Germany	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Germany	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Germany	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Germany	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Germany	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Germany	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Germany	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Germany	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Germany	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Germany	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Germany	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Germany	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Germany	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Germany	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Germany	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Germany	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Germany	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Germany	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Germany	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Germany	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Germany	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Germany	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Germany	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Germany	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Germany	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Germany	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Germany	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Germany	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Germany	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Germany	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Germany	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Germany	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Germany	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Germany	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Germany	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Germany	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Germany	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Germany	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Germany	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Germany	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Germany	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Germany	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Germany	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Germany	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Germany	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Germany	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Germany	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Germany	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Germany	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Germany	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Germany	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Germany	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Germany	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Germany	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Germany	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Germany	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Germany	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Germany	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Germany	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Germany	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Germany	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Germany	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Germany	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Germany	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Germany	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Germany	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Germany	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Germany	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Germany	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Germany	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Germany	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Germany	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Germany	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Germany	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Germany	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Germany	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Germany	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Germany	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Germany	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Germany	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Germany	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Germany	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Germany	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Germany	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Germany	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Germany	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Germany	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Germany	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Germany	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Germany	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Germany	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Germany	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Germany	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Germany	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Germany	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Germany	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Germany	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Germany	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Germany	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Germany	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Germany	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Germany	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Germany	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Germany	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Germany	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Germany	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Germany	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Germany	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Germany	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Germany	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Germany	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Germany	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Germany	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Germany	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Germany	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Germany	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Germany	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Germany	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Germany	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Germany	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Germany	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Germany	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Germany	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Germany	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		

Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Germany	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Germany	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Germany	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Germany	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Germany	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Germany	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Germany	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Germany	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Germany	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Germany	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Germany	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Germany	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Germany	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Germany	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Germany	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Germany	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Germany	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Germany	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Germany	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Germany	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Germany	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Germany	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Germany	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Germany	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Germany	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Germany	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Germany	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Germany	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Germany	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Germany	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		

Germany	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Germany	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Germany	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Germany	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Germany	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Germany	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Germany	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Germany	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Germany	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Germany	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Germany	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Germany	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Germany	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Germany	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Germany	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Germany	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Germany	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Germany	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Germany	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Germany	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Germany	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Germany	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Germany	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Germany	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Germany	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Germany	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Germany	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Germany	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Germany	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Germany	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Germany	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Germany	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Germany	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Germany	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Germany	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Germany	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Germany	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Germany	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Germany	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Germany	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Germany	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Germany	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Germany	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Germany	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Germany	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Germany	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Germany	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Germany	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Germany	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Germany	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Germany	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Germany	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Germany	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Germany	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Germany	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503

Germany	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Germany	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Germany	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Germany	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Germany	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Germany	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Germany	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Germany	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Germany	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Germany	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Germany	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Germany	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Germany	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Germany	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Germany	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Germany	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Germany	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Germany	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Germany	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Germany	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Germany	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Germany	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Germany	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Germany	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Germany	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Germany	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Germany	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Germany	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Germany	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Germany	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Germany	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Germany	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Germany	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583

Germany	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Germany	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Germany	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Germany	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Germany	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Germany	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Germany	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Germany	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Germany	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Germany	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Germany	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Germany	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Germany	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Germany	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Germany	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Germany	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Germany	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Germany	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Germany	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Germany	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Germany	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Germany	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Germany	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Germany	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Germany	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Germany	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Germany	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Germany	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Germany	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Germany	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Germany	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Germany	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Germany	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Germany	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Germany	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Germany	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Germany	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Germany	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Germany	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Germany	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Germany	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Germany	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Germany	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Germany	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Germany	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Germany	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Germany	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Germany	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Germany	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Germany	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Germany	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		

Germany	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Germany	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Germany	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Germany	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Germany	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Germany	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Germany	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Germany	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Germany	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Germany	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Germany	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Germany	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Germany	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Germany	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Germany	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Germany	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Germany	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Germany	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Germany	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Germany	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Germany	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Germany	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Germany	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Germany	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Germany	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Germany	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Germany	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Germany	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Germany	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Germany	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Germany	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Germany	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Germany	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Germany	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Germany	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Germany	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Germany	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Germany	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Germany	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Germany	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Germany	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Germany	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Germany	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Germany	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Germany	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Germany	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Germany	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Germany	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Germany	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Germany	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Germany	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Germany	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Germany	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Germany	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Germany	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Germany	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Germany	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Germany	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Germany	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Germany	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Germany	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Germany	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Germany	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Germany	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Germany	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Germany	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Germany	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Germany	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Germany	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Germany	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Germany	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Germany	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Ghana	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ghana	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Ghana	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ghana	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ghana	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Ghana	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ghana	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ghana	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ghana	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ghana	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ghana	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ghana	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Ghana	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Ghana	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Ghana	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Ghana	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ghana	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ghana	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Ghana	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ghana	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ghana	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Ghana	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ghana	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Ghana	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Ghana	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ghana	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Ghana	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Ghana	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ghana	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ghana	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ghana	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Ghana	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Ghana	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Ghana	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ghana	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Ghana	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ghana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Ghana	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ghana	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Ghana	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ghana	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ghana	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Ghana	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ghana	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ghana	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Ghana	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ghana	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ghana	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ghana	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Ghana	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ghana	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ghana	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Ghana	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ghana	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ghana	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Ghana	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ghana	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ghana	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ghana	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ghana	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Ghana	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Ghana	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ghana	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ghana	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ghana	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ghana	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ghana	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ghana	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ghana	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Ghana	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Ghana	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ghana	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ghana	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Ghana	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Ghana	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Ghana	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Ghana	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Ghana	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Ghana	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Ghana	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Ghana	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		

Ghana	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Ghana	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Ghana	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Ghana	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Ghana	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Ghana	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Ghana	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Ghana	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Ghana	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Ghana	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Ghana	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Ghana	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Ghana	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Ghana	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Ghana	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Ghana	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Ghana	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Ghana	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ghana	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Ghana	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ghana	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Ghana	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Ghana	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ghana	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ghana	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Ghana	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ghana	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Ghana	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Ghana	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ghana	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ghana	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Ghana	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Ghana	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ghana	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ghana	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Ghana	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Ghana	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Ghana	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ghana	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Ghana	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ghana	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ghana	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Ghana	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Ghana	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Ghana	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ghana	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Ghana	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Ghana	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ghana	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ghana	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Ghana	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Ghana	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Ghana	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Ghana	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ghana	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Ghana	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ghana	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Ghana	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Ghana	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ghana	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ghana	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Ghana	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ghana	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ghana	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Ghana	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ghana	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ghana	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Ghana	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ghana	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ghana	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ghana	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Ghana	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Ghana	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Ghana	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Ghana	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Ghana	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Ghana	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ghana	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Ghana	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Ghana	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Ghana	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Ghana	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ghana	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ghana	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Ghana	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Ghana	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Ghana	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Ghana	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ghana	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Ghana	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ghana	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ghana	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Ghana	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Ghana	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ghana	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Ghana	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Ghana	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ghana	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ghana	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Ghana	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ghana	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Ghana	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Ghana	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ghana	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ghana	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Ghana	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ghana	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ghana	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Ghana	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Ghana	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Ghana	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ghana	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Ghana	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ghana	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ghana	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ghana	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Ghana	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ghana	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Ghana	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ghana	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Ghana	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ghana	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Ghana	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Ghana	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ghana	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ghana	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Ghana	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ghana	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ghana	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ghana	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ghana	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ghana	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Ghana	INFINITI QX50	I50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Ghana	INFINITI QX50	I50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ghana	INFINITI QX50	I50	2013.8-	CAN gateway	√	√	√	√		
Ghana	INFINITI QX50	I50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ghana	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Ghana	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Ghana	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ghana	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Ghana	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Ghana	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Ghana	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ghana	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Ghana	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Ghana	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ghana	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ghana	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Ghana	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ghana	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315

Ghana	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Ghana	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ghana	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ghana	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Ghana	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Ghana	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ghana	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ghana	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ghana	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Ghana	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Ghana	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ghana	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Ghana	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ghana	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ghana	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ghana	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Ghana	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Ghana	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ghana	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Ghana	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Ghana	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ghana	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Ghana	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ghana	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ghana	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ghana	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Ghana	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Ghana	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ghana	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ghana	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ghana	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ghana	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Ghana	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Ghana	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Ghana	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Ghana	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ghana	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Ghana	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Ghana	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ghana	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ghana	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ghana	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Ghana	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Ghana	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Ghana	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Ghana	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ghana	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ghana	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Ghana	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ghana	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Ghana	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Ghana	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Ghana	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Ghana	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Grand cayman	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621

Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Grand cayman	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Grand cayman	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Grand cayman	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Grand cayman	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Grand cayman	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Grand cayman	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Grand cayman	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grand cayman	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Grand cayman	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Grand cayman	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Grand cayman	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Grand cayman	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Grand cayman	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Grand cayman	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Grand cayman	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Grand cayman	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grand cayman	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Grand cayman	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Grand cayman	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Grand cayman	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Grand cayman	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Grand cayman	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Grand cayman	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Grand cayman	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Grand cayman	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Grand cayman	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Grand cayman	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Grand cayman	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Grand cayman	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Grand cayman	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Grand cayman	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Grand cayman	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Grand cayman	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Grand cayman	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			

Grand cayman	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Grand cayman	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Grand cayman	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Grand cayman	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Grand cayman	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Grand cayman	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Grand cayman	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Grand cayman	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Grand cayman	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Grand cayman	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Grand cayman	INFINITI Q45	F50	2001.8-	Motor control						
Grand cayman	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Grand cayman	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Grand cayman	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Grand cayman	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Grand cayman	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Grand cayman	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Grand cayman	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Grand cayman	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grand cayman	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Grand cayman	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Grand cayman	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Grand cayman	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Grand cayman	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Grand cayman	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Grand cayman	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Grand cayman	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Grand cayman	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Grand cayman	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Grand cayman	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Grand cayman	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Grand cayman	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Grand cayman	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Grand cayman	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Grand cayman	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Grand cayman	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Grand cayman	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Grand cayman	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Grand cayman	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Grand cayman	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Grand cayman	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Grand cayman	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Grand cayman	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Grand cayman	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Grand cayman	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Grand cayman	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Grand cayman	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Grand cayman	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Grand cayman	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Grand cayman	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Grand cayman	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Grand cayman	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Grand cayman	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Grand cayman	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grand cayman	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Grand cayman	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Grand cayman	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Grand cayman	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Grand cayman	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Grand cayman	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Grand cayman	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Grand cayman	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Grand cayman	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Grand cayman	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Grand cayman	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Grand cayman	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Great britain	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Great britain	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Great britain	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Great britain	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Great britain	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Great britain	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Great britain	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Great britain	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Great britain	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Great britain	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Great britain	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Great britain	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Great britain	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Great britain	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Great britain	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Great britain	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Great britain	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Great britain	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Great britain	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Great britain	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Great britain	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Great britain	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Great britain	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Great britain	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Great britain	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Great britain	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Great britain	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Great britain	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Great britain	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510

Great britain	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Great britain	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Great britain	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Great britain	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Great britain	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Great britain	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Great britain	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Great britain	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Great britain	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Great britain	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Great britain	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Great britain	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Great britain	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Great britain	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Great britain	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Great britain	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Great britain	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Great britain	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Great britain	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Great britain	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Great britain	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Great britain	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Great britain	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Great britain	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		

Xtool

Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Great britain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Great britain	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Great britain	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Great britain	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Great britain	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Great britain	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Great britain	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Great britain	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Great britain	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Great britain	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Great britain	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Great britain	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Great britain	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Great britain	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Great britain	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Great britain	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Great britain	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Great britain	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Great britain	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Great britain	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Great britain	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Great britain	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Great britain	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Great britain	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Great britain	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Great britain	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Great britain	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Great britain	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Great britain	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Great britain	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349

Great britain	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Great britain	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Great britain	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Great britain	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Great britain	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Great britain	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Great britain	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Great britain	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Great britain	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Great britain	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Great britain	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Great britain	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Great britain	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Great britain	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Great britain	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Great britain	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Great britain	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Great britain	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Great britain	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Great britain	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Great britain	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Great britain	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Great britain	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Great britain	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Great britain	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Great britain	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Great britain	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Great britain	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Great britain	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Great britain	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Great britain	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Great britain	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Great britain	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Great britain	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Great britain	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Great britain	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		

Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Great britain	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Great britain	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Great britain	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Great britain	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Great britain	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Great britain	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Great britain	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Great britain	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	AVM	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Great britain	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Great britain	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Great britain	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Great britain	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Great britain	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Great britain	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Great britain	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Great britain	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Great britain	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Great britain	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Great britain	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Great britain	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Great britain	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Great britain	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Great britain	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Great britain	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344

XTOOL

Great britain	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Great britain	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Great britain	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Great britain	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Great britain	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Great britain	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Great britain	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Great britain	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Great britain	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Great britain	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Great britain	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Great britain	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Great britain	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Great britain	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Great britain	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Great britain	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Great britain	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Great britain	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Great britain	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Great britain	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Great britain	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Great britain	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Great britain	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Great britain	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Great britain	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Great britain	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Great britain	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Great britain	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Great britain	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	

XTOOL

Great britain	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Great britain	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Great britain	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Great britain	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Great britain	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Great britain	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Great britain	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Great britain	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Great britain	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Great britain	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Great britain	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Great britain	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Great britain	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Great britain	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Great britain	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Great britain	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Great britain	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Great britain	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Great britain	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Great britain	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Great britain	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Great britain	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Great britain	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Great britain	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Great britain	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Great britain	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Great britain	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Great britain	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Great britain	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	

Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Great britain	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Great britain	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Great britain	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Great britain	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Great britain	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Great britain	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Great britain	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Great britain	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

XTOOL

Great britain	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Great britain	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Great britain	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Great britain	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Great britain	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Great britain	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Great britain	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Great britain	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Great britain	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Great britain	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Great britain	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Great britain	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Great britain	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Great britain	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Great britain	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Great britain	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Great britain	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Great britain	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Great britain	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Great britain	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Great britain	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Great britain	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Great britain	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Great britain	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Great britain	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Great britain	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Great britain	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Great britain	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Great britain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

XTOOL

Great britain	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Great britain	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Great britain	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Great britain	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Great britain	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Great britain	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Great britain	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Great britain	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Great britain	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Great britain	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Great britain	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Great britain	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Great britain	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Great britain	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Great britain	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Great britain	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Great britain	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Great britain	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Great britain	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Great britain	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Great britain	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Great britain	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Great britain	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Great britain	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Great britain	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Great britain	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Great britain	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Great britain	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Great britain	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Great britain	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Great britain	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Great britain	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Great britain	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		

Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Great britain	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Great britain	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Great britain	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Great britain	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Great britain	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Great britain	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Great britain	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Great britain	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Great britain	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Great britain	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Great britain	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Great britain	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Great britain	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Great britain	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Great britain	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Great britain	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Great britain	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Great britain	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Great britain	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Great britain	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Great britain	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Great britain	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Great britain	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	

XTOOL

Great britain	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Great britain	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Great britain	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Great britain	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Great britain	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Great britain	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Great britain	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Great britain	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Great britain	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Great britain	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Great britain	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Great britain	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Great britain	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Great britain	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Great britain	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Great britain	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Great britain	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Great britain	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Great britain	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Great britain	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Great britain	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Great britain	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Great britain	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Great britain	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Great britain	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Great britain	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Great britain	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Great britain	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Great britain	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Great britain	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Great britain	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Great britain	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Great britain	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Great britain	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Great britain	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Great britain	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Great britain	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Great britain	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Great britain	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Great britain	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Great britain	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Great britain	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Great britain	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Great britain	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Great britain	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Great britain	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Great britain	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Greece	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Greece	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Greece	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Greece	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Greece	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Greece	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Greece	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Greece	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Greece	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Greece	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Greece	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Greece	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Greece	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Greece	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Greece	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022,AC1023	
Greece	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Greece	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Greece	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Greece	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Greece	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Greece	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Greece	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Greece	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Greece	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Greece	INFINITI EX37	J50	2008.6-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Greece	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Greece	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Greece	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Greece	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Greece	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Greece	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Greece	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Greece	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Greece	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347,SP0348,SP0349
Greece	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Greece	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270
Greece	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653,AC0695	SP0372,SP0429
Greece	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Greece	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Greece	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
Greece	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Greece	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Greece	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570,SP0571
Greece	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Greece	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Greece	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Greece	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Greece	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Greece	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Greece	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Greece	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Greece	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Greece	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Greece	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Greece	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Greece	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Greece	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Greece	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Greece	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Greece	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Greece	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0555,SP0556,SP0557
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570,SP0571

Greece	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Greece	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Greece	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Greece	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Greece	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Greece	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Greece	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Greece	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Greece	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Greece	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Greece	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Greece	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Greece	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Greece	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Greece	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Greece	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Greece	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Greece	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Greece	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Greece	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Greece	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Greece	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Greece	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Greece	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Greece	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Greece	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Greece	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Greece	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Greece	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Greece	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Greece	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Greece	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Greece	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Greece	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Greece	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Greece	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Greece	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Greece	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Greece	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Greece	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Greece	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Greece	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Greece	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349

Greece	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Greece	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Greece	INFINITI M35/M45	Y50	2006.7-	BCM				√	AC0653, AC0698	SP0391, SP0393
Greece	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Greece	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Greece	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Greece	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Greece	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Greece	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Greece	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Greece	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Greece	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Greece	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Greece	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Greece	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Greece	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Greece	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Greece	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Greece	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Greece	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Greece	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Greece	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Greece	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Greece	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Greece	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Greece	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Greece	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Greece	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Greece	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Greece	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Greece	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Greece	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Greece	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Greece	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Greece	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Greece	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Greece	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Greece	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583

XTOOL

Greece	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Greece	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Greece	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Greece	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Greece	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Greece	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Greece	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Greece	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Greece	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Greece	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Greece	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Greece	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Greece	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Greece	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Greece	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Greece	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Greece	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Greece	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Greece	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Greece	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Greece	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Greece	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Greece	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Greece	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Greece	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Greece	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Greece	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Greece	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Greece	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Greece	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Greece	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Greece	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Greece	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Greece	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Greece	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Greece	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Greece	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Greece	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Greece	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Greece	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Greece	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Greece	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Greece	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Greece	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Greece	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Greece	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		

Greece	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Greece	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Greece	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Greece	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Greece	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Greece	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Greece	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Greece	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Greece	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Greece	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084. AC1085. AC1086. AC1087. AC1088. AC1089. AC1106	
Greece	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Greece	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Greece	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Greece	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Greece	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Greece	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Greece	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Greece	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Greece	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Greece	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Greece	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Greece	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Greece	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Greece	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Greece	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Greece	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Greece	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Greece	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Greece	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Greece	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Greece	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Greece	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Greece	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Greece	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Greece	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Greece	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Greece	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Greece	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084. AC1085. AC1086. AC1087. AC1088. AC1089. AC1106	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980. AC0981. AC0982	SP0561. SP0562
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Greece	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897. AC0898. AC0899. AC0900. AC0901. AC0902	SP0508. SP0509
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429

Greece	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Greece	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Greece	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Greece	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Greece	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Greece	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Greece	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Greece	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Greece	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Greece	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Greece	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Greece	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Greece	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Greece	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Greece	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Greece	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Greece	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Greece	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Greece	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Greece	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Greece	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Greece	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Greece	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Greece	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Greece	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Greece	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Greece	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Greece	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Greece	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Greece	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Greece	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Greece	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Greece	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Greece	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Greece	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Greece	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Greece	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Greece	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Greece	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Greece	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Greece	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Greece	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Greece	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Greece	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Greece	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Greece	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Greece	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Greece	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Greece	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Greece	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Greece	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Greece	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Greece	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Greece	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Greece	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Greece	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Greece	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Greece	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Greece	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Greece	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Greece	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Greece	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Greece	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Greece	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Greece	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Greece	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Greece	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Greece	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Greece	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Greece	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Greece	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Greece	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Greece	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Greece	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Greece	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Greece	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Greece	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Greece	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Greece	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Greece	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Greece	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Greece	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Greece	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Greece	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Greece	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Greece	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583

Greece	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Greece	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122.AC1123.AC1124.AC1125.AC1126	
Greece	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897.AC0898.AC0899.AC0900.AC0901.AC0902	SP0508.SP0509
Greece	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Greece	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Greece	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Greece	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Greece	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Greece	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Greece	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Greece	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Greece	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Greece	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Greece	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Greece	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Greece	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Greece	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Greece	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Greece	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Greece	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Greece	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Greece	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Greece	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Greece	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Greece	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Greece	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Greece	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Greece	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Greece	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Greece	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Greece	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Greece	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Greece	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Greece	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Greece	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Greece	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Greece	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Greece	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Greece	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Greece	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Greece	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Greece	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Greece	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Greece	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Greece	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Greece	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Greece	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Greece	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Greece	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Greece	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Greece	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Greece	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Greece	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Greece	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Greece	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Greece	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Greece	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Greece	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Greece	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Greece	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Greece	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Greece	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Greece	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Greece	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Greece	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Greece	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Greece	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Greece	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Greece	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Greece	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Greece	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Greece	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Grenada	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Grenada	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Grenada	INFINITI EX35/EX37	I50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grenada	INFINITI EX35/EX37	I50	2011.1-	Air bag	√	√	√	√		
Grenada	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Grenada	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Grenada	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Grenada	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Grenada	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Grenada	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grenada	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Grenada	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Grenada	INFINITI EX35/EX37	I50	2011.1-	Sonar	√	√	√	√	AC0962.AC0963.AC0964	SP0553.SP0554.SP0555.SP0556
Grenada	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	

Grenada	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Grenada	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Grenada	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Grenada	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Grenada	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Grenada	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Grenada	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grenada	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Grenada	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Grenada	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Grenada	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Grenada	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Grenada	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Grenada	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Grenada	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Grenada	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Grenada	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grenada	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Grenada	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Grenada	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Grenada	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Grenada	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Grenada	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Grenada	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Grenada	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Grenada	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Grenada	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Grenada	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Grenada	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Grenada	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Grenada	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Grenada	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Grenada	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Grenada	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grenada	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Grenada	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Grenada	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Grenada	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√	AC0439	SP0274
Grenada	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Grenada	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Grenada	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Grenada	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Grenada	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Grenada	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grenada	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Grenada	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Grenada	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Grenada	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Grenada	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Grenada	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Grenada	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Grenada	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grenada	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Grenada	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Grenada	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0201, AC0202, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Grenada	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Grenada	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Grenada	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Grenada	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Grenada	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Grenada	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grenada	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Grenada	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Grenada	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Grenada	INFINITI TX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Grenada	INFINITI TX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Grenada	INFINITI TX35	L50	2012.9-	CAN gateway	√	√	√			
Grenada	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Grenada	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Grenada	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Grenada	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Grenada	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Grenada	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Grenada	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Grenada	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Grenada	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Grenada	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Grenada	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Grenada	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Grenada	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Grenada	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Grenada	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Grenada	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Grenada	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Grenada	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Grenada	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Grenada	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Grenada	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grenada	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Grenada	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Grenada	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Grenada	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Grenada	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Grenada	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Grenada	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Grenada	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Grenada	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Grenada	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Grenada	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Grenada	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Grenada	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Grenada	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Grenada	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Grenada	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Grenada	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Grenada	INFINITI Q45	F50	2001.8-	Motor control						
Grenada	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Grenada	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Grenada	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Grenada	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Grenada	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Grenada	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Grenada	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Grenada	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grenada	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Grenada	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Grenada	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Grenada	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Grenada	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Grenada	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Grenada	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Grenada	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Grenada	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Grenada	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Grenada	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Grenada	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Grenada	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Grenada	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Grenada	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Grenada	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Grenada	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Grenada	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Grenada	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Grenada	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Grenada	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Grenada	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894. AC0895. AC0896	SP0510
Grenada	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Grenada	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Grenada	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Grenada	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Grenada	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347. SP0348. SP0349. SP0350. SP0351
Grenada	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Grenada	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Grenada	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Grenada	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Grenada	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Grenada	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Grenada	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Grenada	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Grenada	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Grenada	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Grenada	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Grenada	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Grenada	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553. SP0554. SP0556
Grenada	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544. SP0545. SP0546. SP0547. SP0548. SP0549
Grenada	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985. AC0986. AC0987. AC0988. AC0989	SP0563. SP0564. SP0565. SP0566. SP0567
Grenada	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Grenada	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Grenada	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Grenada	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Grenada	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Guadeloupe	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guadeloupe	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloupe	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guadeloupe	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloupe	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Guadeloupe	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guadeloupe	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Guadeloupe	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guadeloupe	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guadeloupe	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guadeloupe	INFINITI EX35/EX30D	I50	2009.7-	Multi AV	√	√	√	√		SP0503
Guadeloupe	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guadeloup	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guadeloup	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guadeloup	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Guadeloup	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Guadeloup	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Guadeloup	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Guadeloup	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Guadeloup	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Guadeloup	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloupe	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guadeloup	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Guadeloup	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Guadeloupe	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guadeloupe	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Guadeloup	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Guadeloupe	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guadeloup	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Guadeloup	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Guadeloupe	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guadeloup	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274

Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloupe	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Guadeloup	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloup	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloup	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Guadeloup	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guadeloupe	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guadeloupe	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Guadeloup	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guadeloupe	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guadeloup	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Guadeloupe	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Guadeloup	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Guadeloup	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Guadeloupe	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloup	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloup	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guadeloupe	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guadeloup	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Guadeloup	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guadeloupe	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guadeloupe	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guadeloup	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guadeloupe	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guadeloup	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Guadeloup	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Guadeloup	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guadeloupe	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guadeloup	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guadeloup	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Guadeloup	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Guadeloup	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494

Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guadeloup e	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guadeloup e	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guadeloup e	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guadeloup e	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Guadeloup	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloup	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guadeloup	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Guadeloup e	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Guadeloup	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Guadeloup	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Guadeloup e	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guadeloup e	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guadeloup	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Guadeloup e	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guadeloup	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Guadeloup e	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Guadeloup	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Guadeloup	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Guadeloup	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Guadeloup e	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Guadeloup	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloup	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Guadeloup	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guadeloup	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Guadeloup	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloup e	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guadeloup	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloup	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Guadeloup	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Guadeloup	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guadeloup	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Guadeloup e	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guadeloup e	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Guadeloup	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guadeloup	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guadeloup	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Guadeloup	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Guadeloup	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Guadeloup e	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guadeloup	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Guadeloup	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Guadeloup	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guadeloup	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guadeloup	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guadeloup	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Guadeloup	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Guadeloup	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guadeloup	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Guadeloup	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Guadeloup	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Guadeloup	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Guadeloup e	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		

Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Guadeloupe	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Guadeloup	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Guadeloup	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Guadeloupe	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Guadeloup	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Guadeloupe	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Guadeloup	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Guadeloup	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Guadeloup	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Guadeloup	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Guadeloupe	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Guadeloupe	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Guadeloupe	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Guadeloupe	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Guadeloupe	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Guadeloupe	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Guadeloup	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Guadeloup	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Guadeloupe	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Guadeloup	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Guadeloup	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Guadeloupe	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Guadeloup	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Guadeloupe	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Guadeloup	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Guadeloup	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Guadeloupe	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Guadeloupe	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Guadeloup	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Guadeloupe	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Guadeloupe	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Guadeloupe	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Guadeloupe	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Guadeloupe	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Guadeloupe	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Guadeloupe	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Guadeloupe	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Guadeloupe	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					

Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Guadeloup e	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Guadeloup e	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Guadeloup e	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Guadeloup e	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Guadeloup	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Guadeloup	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guadeloup	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Guadeloup	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloup e	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guadeloup	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloup	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Guadeloup	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Guadeloup	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guadeloup	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Guadeloup e	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guadeloup	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Guadeloup	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guadeloup e	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guadeloup	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Guadeloup	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Guadeloup e	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guadeloup	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Guadeloup	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guadeloup	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guadeloup e	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Guadeloup	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Guadeloup	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guadeloup	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guadeloup	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guadeloup	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Guadeloup	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Guadeloup	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Guadeloup	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guadeloup	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Guadeloup	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Guadeloup	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guadeloup	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloup	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Guadeloup	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Guadeloup e	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Guadeloup	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Guadeloup	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Guadeloup	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Guadeloup	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Guadeloup	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guadeloup	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Guadeloup	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Guadeloup	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Guadeloup	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Guadeloup	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Guadeloup	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Guadeloup	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Guadeloup	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Guadeloup	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloup e	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Guadeloup e	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guadeloup e	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Guadeloup e	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Guadeloup e	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Guadeloup e	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	

Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Guadeloup	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloup e	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Guadeloup e	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0009,SP0016,SP0032,SP0033,SP0038,SP0039,SP0053,SP0063,SP0064,SP0074,SP0079,SP0082,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Guadeloup e	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Guadeloup e	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Guadeloup e	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Guadeloup	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Guadeloup e	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Guadeloup	INFINITI Q60	HV37	2016.7-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Guadeloup	INFINITI Q60	HV37	2016.7-	ANC	√	√	√	√	AC1024	
Guadeloup	INFINITI Q60	HV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Guadeloup	INFINITI Q60	HV37	2016.7-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Guadeloup	INFINITI Q60	HV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Guadeloup	INFINITI Q60	HV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Guadeloup	INFINITI Q60	HV37	2016.7-	VSP	√	√	√	√		
Guadeloup	INFINITI Q60	HV37	2016.7-	Brake	√	√	√	√	AC1127	
Guadeloup	INFINITI Q60	HV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Guadeloup	INFINITI Q60	HV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Guadeloup	INFINITI Q60	HV37	2016.7-	A-IVC(Renault common)	√	√	√	√		
Guadeloup	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Guadeloup	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Guadeloup	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloup e	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Guadeloup	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Guadeloup	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Guadeloup	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Guadeloup	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Guadeloup e	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Guadeloup	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Guadeloup	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Guadeloup e	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Guadeloup	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Guadeloup	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Guadeloup e	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Guadeloup e	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Guadeloup	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Guadeloup	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Guadeloup	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Guadeloup	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Guadeloup	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Guadeloup	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Guadeloup	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Guadeloup	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Guadeloup	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Guadeloup	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Guadeloup	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloup	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Guadeloup	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Guadeloup	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Guadeloup	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Guadeloup	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Guadeloup	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Guadeloup	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Guadeloup	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Guadeloup	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Guadeloup	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Guadeloup	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Guadeloup	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Guadeloup e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Guadeloup e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloup e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Guadeloup e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Guadeloup e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Guadeloup e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Guadeloup e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350

Guadeloupe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guadeloupe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Guadeloupe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guadeloupe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guadeloupe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Guadeloupe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Guadeloupe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloupe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guadeloupe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guadeloupe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Guadeloupe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guadeloupe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guadeloupe	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guadeloupe	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guadeloupe	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guadeloup	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloup	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guadeloup	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Guadeloup	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloupe	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guadeloup	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloup	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Guadeloup	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Guadeloup	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guadeloupe	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guadeloupe	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Guadeloup	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guadeloupe	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Guadeloup	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Guadeloup	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Guadeloupe	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guadeloup	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guadeloup	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guadeloupe	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Guadeloup	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guadeloup	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guadeloup	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guadeloup	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Guadeloup	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Guadeloup	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guadeloup	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Guadeloup	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guadeloup	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloup	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Guadeloup	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guadeloup	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Guadeloup	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Guadeloup	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guadeloup	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Guadeloup	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Guadeloup	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Guadeloup	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Guadeloup	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloupe	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		

Guadeloupe	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guadeloupe	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Guadeloupe	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guadeloupe	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Guadeloupe	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guadeloupe	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Guadeloup	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Guadeloup	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guadeloup	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Guadeloup	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloupe	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guadeloup	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloup	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Guadeloup	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Guadeloup	INFINITI QX50	I50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guadeloupe	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guadeloup	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Guadeloup	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guadeloupe	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guadeloup	INFINITI QX50	I50	2013.9-	Multi AV	√	√	√	√		SP0503
Guadeloupe	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guadeloup	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guadeloup	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guadeloup	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Guadeloup	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Guadeloup	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guadeloup	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Guadeloup	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Guadeloup	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Guadeloup	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guadeloup	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Guadeloup	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Guadeloupe	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guadeloup	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Guadeloup	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Guadeloupe	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guadeloupe	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Guadeloup	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Guadeloupe	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guadeloup	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Guadeloup	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Guadeloup	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Guadeloupe	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guadeloup	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Guadeloupe	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guadeloup	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guadeloup	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Guadeloup	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guadeloup	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Guadeloup	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guadeloupe	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guadeloup	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guadeloup	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Guadeloup	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Guadeloup	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guadeloupe	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guadeloupe	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Guadeloup	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guadeloup	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Guadeloup	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621

Guadeloup	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Guadeloup	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guadeloup	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guadeloup e	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guadeloup	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Guadeloup	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Guadeloup	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guadeloup	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guadeloup	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Guadeloup	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Guadeloup	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Guadeloup	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guadeloup	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Guadeloup	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Guadeloup	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guadeloup	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guadeloup	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Guadeloup	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guadeloup	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Guadeloup	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Guam	*INFINITI EX35 CAMP:P8202	J50	2008.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	*INFINITI EX35 CAMP:P8202	J50	2008.NULL	Air bag	√	√	√	√		
Guam	*INFINITI EX35 CAMP:P8202	J50	2008.NULL	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	
Guam	INFINITI EX35	J50	2008.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI EX35	J50	2008.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI EX35	J50	2008.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI EX35	J50	2008.NULL	Air bag	√	√	√	√		
Guam	INFINITI EX35	J50	2008.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guam	INFINITI EX35	J50	2008.NULL	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guam	INFINITI EX35	J50	2008.NULL	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guam	INFINITI EX35	J50	2008.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guam	INFINITI EX35	J50	2008.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI EX35	J50	2008.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI EX35	J50	2008.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI EX35	J50	2008.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guam	INFINITI EX35	J50	2008.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI EX35	J50	2008.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guam	INFINITI EX35	J50	2008.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI EX35	J50	2008.NULL	CAN gateway	√	√	√			
Guam	INFINITI EX35	J50	2008.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Guam	INFINITI EX35	J50	2008.NULL	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Guam	INFINITI EX35	J50	2008.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI EX35	J50	2008.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI EX35	J50	2008.NULL	Rearview camera	√			√		SP0570, SP0571
Guam	INFINITI FX35/FX45	S50	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guam	INFINITI FX35/FX45	S50	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Guam	INFINITI FX35/FX45	S50	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI FX35/FX45	S50	2003.NULL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guam	INFINITI FX35/FX45	S50	2003.NULL	Air bag	√	√	√	√		
Guam	INFINITI FX35/FX45	S50	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Guam	INFINITI FX35/FX45	S50	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Guam	INFINITI FX35/FX45	S50	2003.NULL	Motor control						
Guam	INFINITI FX35/FX45	S50	2003.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI FX35/FX45	S50	2003.NULL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Guam	INFINITI FX35/FX45	S50	2003.NULL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Guam	INFINITI FX35/FX45	S50	2003.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI FX35/FX45	S50	2003.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI FX35/FX45	S50	2003.NULL	HVAC	√	√	√	√		
Guam	INFINITI FX35/FX45	S50	2003.NULL	Difference lock	√	√	√	√		
Guam	INFINITI FX35/FX45	S50	2003.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI FX35/FX45	S50	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Guam	INFINITI FX35/FX45	S50	2003.NULL	DIU		√	√	√		
Guam	INFINITI FX35/FX45	S50	2003.NULL	Adaptive light	√	√	√	√		
Guam	INFINITI FX35/FX45	S50	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI FX35/FX45	S50	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guam	INFINITI FX35/FX45	S50	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI FX35/FX45	S50	2003.NULL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guam	INFINITI FX35/FX45	S50	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Guam	INFINITI FX35/FX45	S50	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI FX35/FX45	S50	2003.NULL	IVMS	√	√		√		
Guam	INFINITI FX35/FX45	S50	2003.NULL	Distance control	√	√		√		
Guam	INFINITI FX35/FX45	S50	2003.NULL	Active suspense system	√	√	√	√		
Guam	INFINITI FX35/FX45	S50	2003.NULL	Motor assist		√	√	√		SP0574
Guam	INFINITI FX35/FX45	S50	2003.NULL	ASCD	√	√	√	√		
Guam	INFINITI FX35/FX45	S50	2003.NULL	Active engine mount	√	√	√	√		
Guam	INFINITI FX35/FX45	S50	2003.NULL	TCS	√	√	√	√		
Guam	INFINITI FX35/FX45	S50	2003.NULL	S/blind camera	√			√		SP0572, SP0573
Guam	INFINITI FX35/FX45	S50	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guam	INFINITI FX35/FX45	S50	2003.NULL	Nats immu	√	√	√			
Guam	INFINITI FX35/FX45	S50	2003.NULL	Rearview camera	√			√		SP0570, SP0571
Guam	INFINITI FX35/FX45	S50	2003.NULL	Smart entrance						SP0568
Guam	INFINITI FX35/FX50	S51	2009.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guam	INFINITI FX35/FX50	S51	2009.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI FX35/FX50	S51	2009.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Guam	INFINITI FX35/FX50	S51	2009.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI FX35/FX50	S51	2009.NULL	Air bag	√	√	√	√		
Guam	INFINITI FX35/FX50	S51	2009.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guam	INFINITI FX35/FX50	S51	2009.NULL	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0045, SP0051, SP0053, SP0063, SP0064, SP0074, SP0079, SP0083, SP0085, SP0086, SP0087, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0225, SP0239
Guam	INFINITI FX35/FX50	S51	2009.NULL	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Guam	INFINITI FX35/FX50	S51	2009.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guam	INFINITI FX35/FX50	S51	2009.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Guam	INFINITI FX35/FX50	S51	2009.NULL	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Guam	INFINITI FX35/FX50	S51	2009.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI FX35/FX50	S51	2009.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guam	INFINITI FX35/FX50	S51	2009.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI FX35/FX50	S51	2009.NULL	Auto back door	√	√	√	√		SP0611
Guam	INFINITI FX35/FX50	S51	2009.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI FX35/FX50	S51	2009.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Guam	INFINITI FX35/FX50	S51	2009.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI FX35/FX50	S51	2009.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Guam	INFINITI FX35/FX50	S51	2009.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI FX35/FX50	S51	2009.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI FX35/FX50	S51	2009.NULL	CAN gateway	√	√	√			
Guam	INFINITI FX35/FX50	S51	2009.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Guam	INFINITI FX35/FX50	S51	2009.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI FX35/FX50	S51	2009.NULL	Rearview camera	√			√		SP0570, SP0571
Guam	INFINITI FX37/FX50	S51	2013.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guam	INFINITI FX37/FX50	S51	2013.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Guam	INFINITI FX37/FX50	S51	2013.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI FX37/FX50	S51	2013.NULL	Air bag	√	√	√	√		
Guam	INFINITI FX37/FX50	S51	2013.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
Guam	INFINITI FX37/FX50	S51	2013.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guam	INFINITI FX37/FX50	S51	2013.NULL	Transmission	√	√	√	√		SP0274
Guam	INFINITI FX37/FX50	S51	2013.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guam	INFINITI FX37/FX50	S51	2013.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Guam	INFINITI FX37/FX50	S51	2013.NULL	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Guam	INFINITI FX37/FX50	S51	2013.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI FX37/FX50	S51	2013.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guam	INFINITI FX37/FX50	S51	2013.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI FX37/FX50	S51	2013.NULL	Auto back door	√	√	√	√		SP0611
Guam	INFINITI FX37/FX50	S51	2013.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI FX37/FX50	S51	2013.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guam	INFINITI FX37/FX50	S51	2013.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI FX37/FX50	S51	2013.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Guam	INFINITI FX37/FX50	S51	2013.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI FX37/FX50	S51	2013.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI FX37/FX50	S51	2013.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI FX37/FX50	S51	2013.NULL	CAN gateway	√	√	√			
Guam	INFINITI FX37/FX50	S51	2013.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Guam	INFINITI FX37/FX50	S51	2013.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI G20	CA33	2002.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guam	INFINITI G20	CA33	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Guam	INFINITI G20	CA33	2002.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI G20	CA33	2002.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guam	INFINITI G20	CA33	2002.NULL	Air bag	√	√	√	√		
Guam	INFINITI G20	CA33	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Guam	INFINITI G20	CA33	2002.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Guam	INFINITI G20	CA33	2002.NULL	Motor control						
Guam	INFINITI G20	CA33	2002.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI G20	CA33	2002.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Guam	INFINITI G20	CA33	2002.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Guam	INFINITI G20	CA33	2002.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI G20	CA33	2002.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI G20	CA33	2002.NULL	HVAC	√	√	√	√		
Guam	INFINITI G20	CA33	2002.NULL	Difference lock	√	√	√	√		
Guam	INFINITI G20	CA33	2002.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI G20	CA33	2002.NULL	Auto slide door	√	√	√	√	AC0941	
Guam	INFINITI G20	CA33	2002.NULL	DIU		√	√	√		
Guam	INFINITI G20	CA33	2002.NULL	Adaptive light	√	√	√	√		
Guam	INFINITI G20	CA33	2002.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI G20	CA33	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guam	INFINITI G20	CA33	2002.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI G20	CA33	2002.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guam	INFINITI G20	CA33	2002.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Guam	INFINITI G20	CA33	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI G20	CA33	2002.NULL	IVMS	√	√		√		
Guam	INFINITI G20	CA33	2002.NULL	Distance control	√	√		√		
Guam	INFINITI G20	CA33	2002.NULL	Active suspense system	√	√	√	√		
Guam	INFINITI G20	CA33	2002.NULL	Motor assist		√	√	√		SP0574
Guam	INFINITI G20	CA33	2002.NULL	ASCD	√	√	√	√		
Guam	INFINITI G20	CA33	2002.NULL	Active engine mount	√	√	√	√		
Guam	INFINITI G20	CA33	2002.NULL	TCS	√	√	√	√		
Guam	INFINITI G20	CA33	2002.NULL	S/blind camera	√			√		SP0572, SP0573
Guam	INFINITI G20	CA33	2002.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guam	INFINITI G20	CA33	2002.NULL	Nats immu	√	√	√			
Guam	INFINITI G20	CA33	2002.NULL	Rearview camera	√			√		SP0570, SP0571
Guam	INFINITI G20	CA33	2002.NULL	Smart entrance						SP0568
Guam	INFINITI G20	P11	1999.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guam	INFINITI G20	P11	1999.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Guam	INFINITI G20	P11	1999.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI G20	P11	1999.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guam	INFINITI G20	P11	1999.NULL	Air bag	√	√	√	√		
Guam	INFINITI G20	P11	1999.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Guam	INFINITI G20	P11	1999.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Guam	INFINITI G20	P11	1999.NULL	Motor control						
Guam	INFINITI G20	P11	1999.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI G20	P11	1999.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Guam	INFINITI G20	P11	1999.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Guam	INFINITI G20	P11	1999.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI G20	P11	1999.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI G20	P11	1999.NULL	HVAC	√	√	√	√		
Guam	INFINITI G20	P11	1999.NULL	Difference lock	√	√	√	√		
Guam	INFINITI G20	P11	1999.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI G20	P11	1999.NULL	Auto slide door	√	√	√	√	AC0941	
Guam	INFINITI G20	P11	1999.NULL	DIU		√	√	√		

Guam	INFINITI G20	P11	1999.NULL	Adaptive light	√	√	√	√		
Guam	INFINITI G20	P11	1999.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI G20	P11	1999.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guam	INFINITI G20	P11	1999.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI G20	P11	1999.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guam	INFINITI G20	P11	1999.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Guam	INFINITI G20	P11	1999.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI G20	P11	1999.NULL	IVMS	√	√		√		
Guam	INFINITI G20	P11	1999.NULL	Distance control	√	√		√		
Guam	INFINITI G20	P11	1999.NULL	Active suspense system	√	√	√	√		
Guam	INFINITI G20	P11	1999.NULL	Motor assist		√	√	√		SP0574
Guam	INFINITI G20	P11	1999.NULL	ASCD	√	√	√	√		
Guam	INFINITI G20	P11	1999.NULL	Active engine mount	√	√	√	√		
Guam	INFINITI G20	P11	1999.NULL	TCS	√	√	√	√		
Guam	INFINITI G20	P11	1999.NULL	S/blind camera	√			√		SP0572, SP0573
Guam	INFINITI G20	P11	1999.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guam	INFINITI G20	P11	1999.NULL	Nats immu	√	√	√			
Guam	INFINITI G20	P11	1999.NULL	Rearview camera	√			√		SP0570, SP0571
Guam	INFINITI G20	P11	1999.NULL	Smart entrance						SP0568
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Air bag	√	√	√	√		
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Transmission	√	√	√	√		SP0274
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Pop up hood	√	√	√	√		
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Multi AV	√	√	√	√		SP0503
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Precrash seatbelt	√	√	√	√		
Guam	INFINITI G25/G37 SEDAN	V36	2011.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Guam	INFINITI G35 COUPE	CV35	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI G35 COUPE	CV35	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Air bag	√	√	√	√		
Guam	INFINITI G35 COUPE	CV35	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Motor control						
Guam	INFINITI G35 COUPE	CV35	2003.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI G35 COUPE	CV35	2003.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Guam	INFINITI G35 COUPE	CV35	2003.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Guam	INFINITI G35 COUPE	CV35	2003.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI G35 COUPE	CV35	2003.NULL	HVAC	√	√	√	√		
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Difference lock	√	√	√	√		
Guam	INFINITI G35 COUPE	CV35	2003.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Guam	INFINITI G35 COUPE	CV35	2003.NULL	DIU		√	√	√		
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Adaptive light	√	√	√	√		
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI G35 COUPE	CV35	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guam	INFINITI G35 COUPE	CV35	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI G35 COUPE	CV35	2003.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Guam	INFINITI G35 COUPE	CV35	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI G35 COUPE	CV35	2003.NULL	IVMS	√	√		√		
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Distance control	√	√		√		
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Active suspense system	√	√	√	√		
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Motor assist		√	√	√		SP0574
Guam	INFINITI G35 COUPE	CV35	2003.NULL	ASCD	√	√	√	√		
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Active engine mount	√	√	√	√		
Guam	INFINITI G35 COUPE	CV35	2003.NULL	TCS	√	√	√	√		
Guam	INFINITI G35 COUPE	CV35	2003.NULL	S/blind camera	√			√		SP0572, SP0573
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Nats immu	√	√	√			
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Rearview camera	√			√		SP0570, SP0571
Guam	INFINITI G35 COUPE	CV35	2003.NULL	Smart entrance						SP0568
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Guam	INFINITI G35 SEDAN	V35	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI G35 SEDAN	V35	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Air bag	√	√	√	√		
Guam	INFINITI G35 SEDAN	V35	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Motor control						

XTOOL

Guam	INFINITI G35 SEDAN	V35	2003.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI G35 SEDAN	V35	2003.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Guam	INFINITI G35 SEDAN	V35	2003.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Guam	INFINITI G35 SEDAN	V35	2003.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI G35 SEDAN	V35	2003.NULL	HVAC	√	√	√	√		
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Difference lock	√	√	√	√		
Guam	INFINITI G35 SEDAN	V35	2003.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Guam	INFINITI G35 SEDAN	V35	2003.NULL	DIU		√	√	√		
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Adaptive light	√	√	√	√		
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI G35 SEDAN	V35	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guam	INFINITI G35 SEDAN	V35	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI G35 SEDAN	V35	2003.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Guam	INFINITI G35 SEDAN	V35	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI G35 SEDAN	V35	2003.NULL	IVMS	√	√		√		
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Distance control	√	√		√		
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Active suspense system	√	√	√	√		
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Motor assist		√	√	√		SP0574
Guam	INFINITI G35 SEDAN	V35	2003.NULL	ASCD	√	√	√	√		
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Active engine mount	√	√	√	√		
Guam	INFINITI G35 SEDAN	V35	2003.NULL	TCS	√	√	√	√		
Guam	INFINITI G35 SEDAN	V35	2003.NULL	S/blind camera	√			√		SP0572, SP0573
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Nats immu	√	√	√			
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Rearview camera	√			√		SP0570, SP0571
Guam	INFINITI G35 SEDAN	V35	2003.NULL	Smart entrance						SP0568
Guam	INFINITI G35 SEDAN	V36	2007.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI G35 SEDAN	V36	2007.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Guam	INFINITI G35 SEDAN	V36	2007.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI G35 SEDAN	V36	2007.NULL	Air bag	√	√	√	√		
Guam	INFINITI G35 SEDAN	V36	2007.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guam	INFINITI G35 SEDAN	V36	2007.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guam	INFINITI G35 SEDAN	V36	2007.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Guam	INFINITI G35 SEDAN	V36	2007.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guam	INFINITI G35 SEDAN	V36	2007.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guam	INFINITI G35 SEDAN	V36	2007.NULL	Multi AV	√	√	√	√		
Guam	INFINITI G35 SEDAN	V36	2007.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guam	INFINITI G35 SEDAN	V36	2007.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI G35 SEDAN	V36	2007.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guam	INFINITI G35 SEDAN	V36	2007.NULL	All mode AWD/4WD	√	√	√	√	AC0957	
Guam	INFINITI G35 SEDAN	V36	2007.NULL	Precrash seatbelt	√	√	√	√		
Guam	INFINITI G35 SEDAN	V36	2007.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Air bag	√	√	√	√		
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Pop up hood	√	√	√	√		
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Multi AV	√	√	√	√		SP0503
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Precrash seatbelt	√	√	√	√		
Guam	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI G37 COUPE	CV36	2008.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI G37 COUPE	CV36	2008.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Guam	INFINITI G37 COUPE	CV36	2008.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI G37 COUPE	CV36	2008.NULL	Air bag	√	√	√	√		
Guam	INFINITI G37 COUPE	CV36	2008.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guam	INFINITI G37 COUPE	CV36	2008.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI G37 COUPE	CV36	2008.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guam	INFINITI G37 COUPE	CV36	2008.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guam	INFINITI G37 COUPE	CV36	2008.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guam	INFINITI G37 COUPE	CV36	2008.NULL	Pop up hood	√	√	√	√		
Guam	INFINITI G37 COUPE	CV36	2008.NULL	Multi AV	√	√	√	√		SP0503

Guam	INFINITI G37 COUPE	CV36	2008.NULL	4WAS(front)	√	√	√	√	AC1027,AC1028	
Guam	INFINITI G37 COUPE	CV36	2008.NULL	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Guam	INFINITI G37 COUPE	CV36	2008.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Guam	INFINITI G37 COUPE	CV36	2008.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Guam	INFINITI G37 COUPE	CV36	2008.NULL	All mode AWD/4WD	√	√	√	√	AC0956,AC0957	
Guam	INFINITI G37 COUPE	CV36	2008.NULL	Precrash seatbelt	√	√	√	√		
Guam	INFINITI G37 COUPE	CV36	2008.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI G37 SEDAN	V36	2009.NULL	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Guam	INFINITI G37 SEDAN	V36	2009.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Guam	INFINITI G37 SEDAN	V36	2009.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Guam	INFINITI G37 SEDAN	V36	2009.NULL	Air bag	√	√	√	√		
Guam	INFINITI G37 SEDAN	V36	2009.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Guam	INFINITI G37 SEDAN	V36	2009.NULL	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Guam	INFINITI G37 SEDAN	V36	2009.NULL	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Guam	INFINITI G37 SEDAN	V36	2009.NULL	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Guam	INFINITI G37 SEDAN	V36	2009.NULL	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Guam	INFINITI G37 SEDAN	V36	2009.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI G37 SEDAN	V36	2009.NULL	4WAS(front)	√	√	√	√	AC1027,AC1028	
Guam	INFINITI G37 SEDAN	V36	2009.NULL	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Guam	INFINITI G37 SEDAN	V36	2009.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Guam	INFINITI G37 SEDAN	V36	2009.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Guam	INFINITI G37 SEDAN	V36	2009.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI G37 SEDAN	V36	2009.NULL	Precrash seatbelt	√	√	√	√		
Guam	INFINITI G37 SEDAN	V36	2009.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI I30	CA32	1996.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Guam	INFINITI I30	CA32	1996.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
Guam	INFINITI I30	CA32	1996.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Guam	INFINITI I30	CA32	1996.NULL	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Guam	INFINITI I30	CA32	1996.NULL	Air bag	√	√	√	√		
Guam	INFINITI I30	CA32	1996.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Guam	INFINITI I30	CA32	1996.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Guam	INFINITI I30	CA32	1996.NULL	Motor control						
Guam	INFINITI I30	CA32	1996.NULL	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Guam	INFINITI I30	CA32	1996.NULL	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
Guam	INFINITI I30	CA32	1996.NULL	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
Guam	INFINITI I30	CA32	1996.NULL	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Guam	INFINITI I30	CA32	1996.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI I30	CA32	1996.NULL	HVAC	√	√	√	√		
Guam	INFINITI I30	CA32	1996.NULL	Difference lock	√	√	√	√		
Guam	INFINITI I30	CA32	1996.NULL	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Guam	INFINITI I30	CA32	1996.NULL	Auto slide door	√	√	√	√	AC0941	
Guam	INFINITI I30	CA32	1996.NULL	DIU		√	√	√		
Guam	INFINITI I30	CA32	1996.NULL	Adaptive light	√	√	√	√		
Guam	INFINITI I30	CA32	1996.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Guam	INFINITI I30	CA32	1996.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guam	INFINITI I30	CA32	1996.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Guam	INFINITI I30	CA32	1996.NULL	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Guam	INFINITI I30	CA32	1996.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Guam	INFINITI I30	CA32	1996.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI I30	CA32	1996.NULL	IVMS	√	√		√		
Guam	INFINITI I30	CA32	1996.NULL	Distance control	√	√		√		
Guam	INFINITI I30	CA32	1996.NULL	Active suspense system	√	√	√	√		
Guam	INFINITI I30	CA32	1996.NULL	Motor assist		√	√	√		SP0574
Guam	INFINITI I30	CA32	1996.NULL	ASCD	√	√	√	√		
Guam	INFINITI I30	CA32	1996.NULL	Active engine mount	√	√	√	√		
Guam	INFINITI I30	CA32	1996.NULL	TCS	√	√	√	√		
Guam	INFINITI I30	CA32	1996.NULL	S/blind camera	√			√		SP0572,SP0573
Guam	INFINITI I30	CA32	1996.NULL	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Guam	INFINITI I30	CA32	1996.NULL	Nats immu	√	√	√			
Guam	INFINITI I30	CA32	1996.NULL	Rearview camera	√			√		SP0570,SP0571
Guam	INFINITI I30	CA32	1996.NULL	Smart entrance						SP0568
Guam	INFINITI I35	CA33	2002.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Guam	INFINITI I35	CA33	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
Guam	INFINITI I35	CA33	2002.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Guam	INFINITI I35	CA33	2002.NULL	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Guam	INFINITI I35	CA33	2002.NULL	Air bag	√	√	√	√		
Guam	INFINITI I35	CA33	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Guam	INFINITI I35	CA33	2002.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Guam	INFINITI I35	CA33	2002.NULL	Motor control						
Guam	INFINITI I35	CA33	2002.NULL	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Guam	INFINITI I35	CA33	2002.NULL	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
Guam	INFINITI I35	CA33	2002.NULL	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
Guam	INFINITI I35	CA33	2002.NULL	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Guam	INFINITI I35	CA33	2002.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI I35	CA33	2002.NULL	HVAC	√	√	√	√		
Guam	INFINITI I35	CA33	2002.NULL	Difference lock	√	√	√	√		
Guam	INFINITI I35	CA33	2002.NULL	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Guam	INFINITI I35	CA33	2002.NULL	Auto slide door	√	√	√	√	AC0941	
Guam	INFINITI I35	CA33	2002.NULL	DIU		√	√	√		
Guam	INFINITI I35	CA33	2002.NULL	Adaptive light	√	√	√	√		
Guam	INFINITI I35	CA33	2002.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Guam	INFINITI I35	CA33	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guam	INFINITI I35	CA33	2002.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Guam	INFINITI I35	CA33	2002.NULL	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Guam	INFINITI I35	CA33	2002.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Guam	INFINITI I35	CA33	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI I35	CA33	2002.NULL	IVMS	√	√		√		

Guam	INFINITI I35	CA33	2002.NULL	Distance control	√	√		√		
Guam	INFINITI I35	CA33	2002.NULL	Active suspense system	√	√	√	√		
Guam	INFINITI I35	CA33	2002.NULL	Motor assist		√	√	√		SP0574
Guam	INFINITI I35	CA33	2002.NULL	ASCD	√	√	√	√		
Guam	INFINITI I35	CA33	2002.NULL	Active engine mount	√	√	√	√		
Guam	INFINITI I35	CA33	2002.NULL	TCS	√	√	√	√		
Guam	INFINITI I35	CA33	2002.NULL	S/blind camera	√			√		SP0572,SP0573
Guam	INFINITI I35	CA33	2002.NULL	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Guam	INFINITI I35	CA33	2002.NULL	Nats immu	√	√	√			
Guam	INFINITI I35	CA33	2002.NULL	Rearview camera	√			√		SP0570,SP0571
Guam	INFINITI I35	CA33	2002.NULL	Smart entrance						SP0568
Guam	INFINITI JX35	L50	2013.NULL	Laser/radar	√	√	√	√		
Guam	INFINITI JX35	L50	2013.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI JX35	L50	2013.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Guam	INFINITI JX35	L50	2013.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Guam	INFINITI JX35	L50	2013.NULL	Air bag	√	√	√	√		
Guam	INFINITI JX35	L50	2013.NULL	EPS/DAST 3	√	√	√	√		
Guam	INFINITI JX35	L50	2013.NULL	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Guam	INFINITI JX35	L50	2013.NULL	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Guam	INFINITI JX35	L50	2013.NULL	Transmission	√	√	√	√	AC0439	SP0246,SP0276,SP0278,SP0279,SP0281,SP0282,SP0283,SP0287,SP0289,SP0290,SP0292
Guam	INFINITI JX35	L50	2013.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Guam	INFINITI JX35	L50	2013.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Guam	INFINITI JX35	L50	2013.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI JX35	L50	2013.NULL	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0487
Guam	INFINITI JX35	L50	2013.NULL	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Guam	INFINITI JX35	L50	2013.NULL	Auto back door	√	√	√	√		SP0611
Guam	INFINITI JX35	L50	2013.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI JX35	L50	2013.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Guam	INFINITI JX35	L50	2013.NULL	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Guam	INFINITI JX35	L50	2013.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI JX35	L50	2013.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI JX35	L50	2013.NULL	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Guam	INFINITI JX35	L50	2013.NULL	CAN gateway	√	√	√			
Guam	INFINITI JX35	L50	2013.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Guam	INFINITI JX35	L50	2013.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI JX35	L50	2013.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Guam	INFINITI JX35	L50	2013.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI M35/M45	Y50	2006.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Guam	INFINITI M35/M45	Y50	2006.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Guam	INFINITI M35/M45	Y50	2006.NULL	IPDM E/R	√	√	√	√	AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831,AC0856	
Guam	INFINITI M35/M45	Y50	2006.NULL	Air bag	√	√	√	√		
Guam	INFINITI M35/M45	Y50	2006.NULL	Meter/M&A		√	√	√		SP0347,SP0348,SP0349
Guam	INFINITI M35/M45	Y50	2006.NULL	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Guam	INFINITI M35/M45	Y50	2006.NULL	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Guam	INFINITI M35/M45	Y50	2006.NULL	BCM					AC0653,AC0698	SP0391,SP0393
Guam	INFINITI M35/M45	Y50	2006.NULL	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Guam	INFINITI M35/M45	Y50	2006.NULL	Multi AV	√	√	√	√		
Guam	INFINITI M35/M45	Y50	2006.NULL	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Guam	INFINITI M35/M45	Y50	2006.NULL	Adaptive light	√	√	√	√		SP0561,SP0562
Guam	INFINITI M35/M45	Y50	2006.NULL	All mode AWD/4WD	√	√	√	√	AC0957	
Guam	INFINITI M35/M45	Y50	2006.NULL	Precrash seatbelt	√	√	√	√		
Guam	INFINITI M35/M45	Y50	2006.NULL	Intelligent key	√	√	√	√	AC0911,AC0913,AC0915,AC0916,AC0917,AC0920,AC0922,AC0923,AC0924,AC0925,AC0926,AC0928	SP0511,SP0512,SP0518,SP0520,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0529,SP0530,SP0531,SP0532,SP0534,SP0535,SP0536,SP0537
Guam	INFINITI M35/M45	Y50	2006.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976	SP0560
Guam	INFINITI M35/M45	Y50	2006.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI M35H	HY51	2012.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Guam	INFINITI M35H	HY51	2012.NULL	Laser/radar	√	√	√	√		
Guam	INFINITI M35H	HY51	2012.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI M35H	HY51	2012.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Guam	INFINITI M35H	HY51	2012.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Guam	INFINITI M35H	HY51	2012.NULL	Air bag	√	√	√	√		
Guam	INFINITI M35H	HY51	2012.NULL	EPS/DAST 3	√	√	√	√		
Guam	INFINITI M35H	HY51	2012.NULL	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Guam	INFINITI M35H	HY51	2012.NULL	Motor control	√	√	√	√		
Guam	INFINITI M35H	HY51	2012.NULL	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Guam	INFINITI M35H	HY51	2012.NULL	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274,SP0276
Guam	INFINITI M35H	HY51	2012.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Guam	INFINITI M35H	HY51	2012.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Guam	INFINITI M35H	HY51	2012.NULL	Diag data recorder	√					
Guam	INFINITI M35H	HY51	2012.NULL	Pop up hood	√	√	√	√		
Guam	INFINITI M35H	HY51	2012.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI M35H	HY51	2012.NULL	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Guam	INFINITI M35H	HY51	2012.NULL	HV battery	√	√	√	√	AC1121	
Guam	INFINITI M35H	HY51	2012.NULL	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Guam	INFINITI M35H	HY51	2012.NULL	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Guam	INFINITI M35H	HY51	2012.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Guam	INFINITI M35H	HY51	2012.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Guam	INFINITI M35H	HY51	2012.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Guam	INFINITI M35H	HY51	2012.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI M35H	HY51	2012.NULL	CAN gateway	√	√	√			
Guam	INFINITI M35H	HY51	2012.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Guam	INFINITI M35H	HY51	2012.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI M35H	HY51	2012.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Guam	INFINITI M35H	HY51	2012.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI M35H	HY51	2012.NULL	Brake	√	√	√	√	AC1127	
Guam	INFINITI M35H	HY51	2012.NULL	VSP	√	√	√	√	AC1124,AC1125,AC1126	
Guam	INFINITI M37/M56	Y51	2011.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Guam	INFINITI M37/M56	Y51	2011.NULL	Laser/radar	√	√	√	√		
Guam	INFINITI M37/M56	Y51	2011.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI M37/M56	Y51	2011.NULL	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Guam	INFINITI M37/M56	Y51	2011.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Guam	INFINITI M37/M56	Y51	2011.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Guam	INFINITI M37/M56	Y51	2011.NULL	Air bag	√	√	√	√		
Guam	INFINITI M37/M56	Y51	2011.NULL	EPS/DAST 3	√	√	√	√		
Guam	INFINITI M37/M56	Y51	2011.NULL	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Guam	INFINITI M37/M56	Y51	2011.NULL	Motor control	√	√	√	√		
Guam	INFINITI M37/M56	Y51	2011.NULL	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Guam	INFINITI M37/M56	Y51	2011.NULL	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274

Guam	INFINITI M37/M56	Y51	2011.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guam	INFINITI M37/M56	Y51	2011.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI M37/M56	Y51	2011.NULL	Pop up hood	√	√	√	√		
Guam	INFINITI M37/M56	Y51	2011.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI M37/M56	Y51	2011.NULL	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guam	INFINITI M37/M56	Y51	2011.NULL	HV battery	√	√	√	√	AC1121	
Guam	INFINITI M37/M56	Y51	2011.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guam	INFINITI M37/M56	Y51	2011.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guam	INFINITI M37/M56	Y51	2011.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI M37/M56	Y51	2011.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Guam	INFINITI M37/M56	Y51	2011.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guam	INFINITI M37/M56	Y51	2011.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI M37/M56	Y51	2011.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guam	INFINITI M37/M56	Y51	2011.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI M37/M56	Y51	2011.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI M37/M56	Y51	2011.NULL	CAN gateway	√	√	√			
Guam	INFINITI M37/M56	Y51	2011.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guam	INFINITI M37/M56	Y51	2011.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI M37/M56	Y51	2011.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI M37/M56	Y51	2011.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guam	INFINITI M37/M56	Y51	2011.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI M37/M56	Y51	2011.NULL	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Guam	INFINITI M45	Y34	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guam	INFINITI M45	Y34	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Guam	INFINITI M45	Y34	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI M45	Y34	2003.NULL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guam	INFINITI M45	Y34	2003.NULL	Air bag	√	√	√	√		
Guam	INFINITI M45	Y34	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Guam	INFINITI M45	Y34	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Guam	INFINITI M45	Y34	2003.NULL	Motor control						
Guam	INFINITI M45	Y34	2003.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI M45	Y34	2003.NULL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Guam	INFINITI M45	Y34	2003.NULL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Guam	INFINITI M45	Y34	2003.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI M45	Y34	2003.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI M45	Y34	2003.NULL	HVAC	√	√	√	√		
Guam	INFINITI M45	Y34	2003.NULL	Difference lock	√	√	√	√		
Guam	INFINITI M45	Y34	2003.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI M45	Y34	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Guam	INFINITI M45	Y34	2003.NULL	DIU		√	√	√		
Guam	INFINITI M45	Y34	2003.NULL	Adaptive light	√	√	√	√		
Guam	INFINITI M45	Y34	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI M45	Y34	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guam	INFINITI M45	Y34	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI M45	Y34	2003.NULL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guam	INFINITI M45	Y34	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Guam	INFINITI M45	Y34	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI M45	Y34	2003.NULL	IVMS	√	√		√		
Guam	INFINITI M45	Y34	2003.NULL	Distance control	√	√		√		
Guam	INFINITI M45	Y34	2003.NULL	Active suspense system	√	√	√	√		
Guam	INFINITI M45	Y34	2003.NULL	Motor assist		√	√	√		SP0574
Guam	INFINITI M45	Y34	2003.NULL	ASCD	√	√	√	√		
Guam	INFINITI M45	Y34	2003.NULL	Active engine mount	√	√	√	√		
Guam	INFINITI M45	Y34	2003.NULL	TCS	√	√	√	√		
Guam	INFINITI M45	Y34	2003.NULL	S/blind camera	√			√		SP0572, SP0573
Guam	INFINITI M45	Y34	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guam	INFINITI M45	Y34	2003.NULL	Nats immu	√	√	√			
Guam	INFINITI M45	Y34	2003.NULL	Rearview camera	√			√		SP0570, SP0571
Guam	INFINITI M45	Y34	2003.NULL	Smart entrance						SP0568
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	Air bag	√	√	√	√		
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0038, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	Transmission	√	√	√	√		SP0274
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	Pop up hood	√	√	√	√		
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI Q40 SEDAN	V36	2015.NULL	Precrash seatbelt	√	√	√	√		
Guam	INFINITI Q45	F50	2002.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guam	INFINITI Q45	F50	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Guam	INFINITI Q45	F50	2002.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI Q45	F50	2002.NULL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guam	INFINITI Q45	F50	2002.NULL	Air bag	√	√	√	√		
Guam	INFINITI Q45	F50	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Guam	INFINITI Q45	F50	2002.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Guam	INFINITI Q45	F50	2002.NULL	Motor control						
Guam	INFINITI Q45	F50	2002.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI Q45	F50	2002.NULL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Guam	INFINITI Q45	F50	2002.NULL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Guam	INFINITI Q45	F50	2002.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI Q45	F50	2002.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI Q45	F50	2002.NULL	HVAC	√	√	√	√		

Guam	INFINITI Q45	F50	2002.NULL	Difference lock	√	√	√	√		
Guam	INFINITI Q45	F50	2002.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI Q45	F50	2002.NULL	Auto slide door	√	√	√	√	AC0941	
Guam	INFINITI Q45	F50	2002.NULL	DIU		√	√	√		
Guam	INFINITI Q45	F50	2002.NULL	Adaptive light	√	√	√	√		
Guam	INFINITI Q45	F50	2002.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI Q45	F50	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guam	INFINITI Q45	F50	2002.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI Q45	F50	2002.NULL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guam	INFINITI Q45	F50	2002.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Guam	INFINITI Q45	F50	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI Q45	F50	2002.NULL	IVMS	√	√		√		
Guam	INFINITI Q45	F50	2002.NULL	Distance control	√	√		√		
Guam	INFINITI Q45	F50	2002.NULL	Active suspense system	√	√	√	√		
Guam	INFINITI Q45	F50	2002.NULL	Motor assist		√	√	√		SP0574
Guam	INFINITI Q45	F50	2002.NULL	ASCD	√	√	√	√		
Guam	INFINITI Q45	F50	2002.NULL	Active engine mount	√	√	√	√		
Guam	INFINITI Q45	F50	2002.NULL	TCS	√	√	√	√		
Guam	INFINITI Q45	F50	2002.NULL	S/blind camera	√			√		SP0572, SP0573
Guam	INFINITI Q45	F50	2002.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guam	INFINITI Q45	F50	2002.NULL	Nats immu	√	√	√			
Guam	INFINITI Q45	F50	2002.NULL	Rearview camera	√			√		SP0570, SP0571
Guam	INFINITI Q45	F50	2002.NULL	Smart entrance						SP0568
Guam	INFINITI Q45	FY33	1995.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guam	INFINITI Q45	FY33	1995.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Guam	INFINITI Q45	FY33	1995.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI Q45	FY33	1995.NULL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guam	INFINITI Q45	FY33	1995.NULL	Air bag	√	√	√	√		
Guam	INFINITI Q45	FY33	1995.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Guam	INFINITI Q45	FY33	1995.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Guam	INFINITI Q45	FY33	1995.NULL	Motor control						
Guam	INFINITI Q45	FY33	1995.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI Q45	FY33	1995.NULL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Guam	INFINITI Q45	FY33	1995.NULL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Guam	INFINITI Q45	FY33	1995.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI Q45	FY33	1995.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI Q45	FY33	1995.NULL	HVAC	√	√	√	√		
Guam	INFINITI Q45	FY33	1995.NULL	Difference lock	√	√	√	√		
Guam	INFINITI Q45	FY33	1995.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI Q45	FY33	1995.NULL	Auto slide door	√	√	√	√	AC0941	
Guam	INFINITI Q45	FY33	1995.NULL	DIU		√	√	√		
Guam	INFINITI Q45	FY33	1995.NULL	Adaptive light	√	√	√	√		
Guam	INFINITI Q45	FY33	1995.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI Q45	FY33	1995.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guam	INFINITI Q45	FY33	1995.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI Q45	FY33	1995.NULL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guam	INFINITI Q45	FY33	1995.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Guam	INFINITI Q45	FY33	1995.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI Q45	FY33	1995.NULL	IVMS	√	√		√		
Guam	INFINITI Q45	FY33	1995.NULL	Distance control	√	√		√		
Guam	INFINITI Q45	FY33	1995.NULL	Active suspense system	√	√	√	√		
Guam	INFINITI Q45	FY33	1995.NULL	Motor assist		√	√	√		SP0574
Guam	INFINITI Q45	FY33	1995.NULL	ASCD	√	√	√	√		
Guam	INFINITI Q45	FY33	1995.NULL	Active engine mount	√	√	√	√		
Guam	INFINITI Q45	FY33	1995.NULL	TCS	√	√	√	√		
Guam	INFINITI Q45	FY33	1995.NULL	S/blind camera	√			√		SP0572, SP0573
Guam	INFINITI Q45	FY33	1995.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guam	INFINITI Q45	FY33	1995.NULL	Nats immu	√	√	√			
Guam	INFINITI Q45	FY33	1995.NULL	Rearview camera	√			√		SP0570, SP0571
Guam	INFINITI Q45	FY33	1995.NULL	Smart entrance						SP0568
Guam	INFINITI Q50	V37	2019.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guam	INFINITI Q50	V37	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Guam	INFINITI Q50	V37	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI Q50	V37	2019.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guam	INFINITI Q50	V37	2019.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI Q50	V37	2019.NULL	Air bag	√	√	√	√		
Guam	INFINITI Q50	V37	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
Guam	INFINITI Q50	V37	2019.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guam	INFINITI Q50	V37	2019.NULL	Motor control	√	√	√	√		
Guam	INFINITI Q50	V37	2019.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI Q50	V37	2019.NULL	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Guam	INFINITI Q50	V37	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guam	INFINITI Q50	V37	2019.NULL	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guam	INFINITI Q50	V37	2019.NULL	Pop up hood	√	√	√	√		
Guam	INFINITI Q50	V37	2019.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI Q50	V37	2019.NULL	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guam	INFINITI Q50	V37	2019.NULL	HV battery	√	√	√	√	AC1121	
Guam	INFINITI Q50	V37	2019.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guam	INFINITI Q50	V37	2019.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guam	INFINITI Q50	V37	2019.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI Q50	V37	2019.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Guam	INFINITI Q50	V37	2019.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI Q50	V37	2019.NULL	Shift	√	√	√	√		SP0613
Guam	INFINITI Q50	V37	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guam	INFINITI Q50	V37	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI Q50	V37	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI Q50	V37	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI Q50	V37	2019.NULL	DAST 2	√	√	√	√		
Guam	INFINITI Q50	V37	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI Q50	V37	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI Q50	V37	2019.NULL	CAN gateway	√	√	√			
Guam	INFINITI Q50	V37	2019.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guam	INFINITI Q50	V37	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI Q50	V37	2019.NULL	DAST 1	√	√	√	√		
Guam	INFINITI Q50	V37	2019.NULL	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Guam	INFINITI Q50	V37	2019.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	

Guam	INFINITI Q50	V37	2019.NULL	ANC	√	√	√	√	AC1024	
Guam	INFINITI Q50	V37	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI Q50	V37	2019.NULL	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Guam	INFINITI Q50	V37	2019.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Guam	INFINITI Q50	V37	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
Guam	INFINITI Q50	V37	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI Q50	V37	2019.NULL	Brake	√	√	√	√	AC1127	
Guam	INFINITI Q50	V37	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Guam	INFINITI Q50	V37	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
Guam	INFINITI Q50	V37	2019.NULL	ICC/ADAS 2	√	√	√	√		
Guam	INFINITI Q50	V37	2019.NULL	FSCM	√	√	√	√	AC1109	
Guam	INFINITI Q50	V37	2019.NULL	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Laser/radar	√	√	√	√		
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL_	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Air bag	√	√	√	√		
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Motor control	√	√	√	√		
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL_	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0009,SP0016,SP0032,SP0033,SP0038,SP0039,SP0053,SP0063,SP0064,SP0074,SP0079,SP0082,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Transmission	√	√	√	√		SP0274,SP0276
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL_	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Pop up hood	√	√	√	√		
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL_	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	HV battery	√	√	√	√	AC1121	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	4WAS(front)	√	√	√	√	AC1027,AC1028	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	EV/HEV	√	√	√	√	AC1084.AC1085.AC1086.AC1087.AC1088.AC1089.AC1106	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Shift	√	√	√	√		SP0613
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	DAST 2	√	√	√	√		
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	CAN gateway	√	√	√			
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	DAST 1	√	√	√	√		
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL_	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	ANC	√	√	√	√	AC1024	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	HIGH BEAM ASSIST	√	√	√	√		
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	Brake	√	√	√	√	AC1127	
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	6ch CAN GATEWAY	√	√	√	√		
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	3ch CAN GATEWAY	√	√	√	√		
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	ICC/ADAS 2	√	√	√	√		
Guam	INFINITI Q50 HYBRID	HV37	2014.NULL	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Laser/radar	√	√	√	√		
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Air bag	√	√	√	√		
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	EPS/DAST 3	√	√	√	√		
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Motor control	√	√	√	√		
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0009,SP0016,SP0032,SP0033,SP0038,SP0039,SP0053,SP0063,SP0064,SP0074,SP0079,SP0082,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Transmission	√	√	√	√		SP0276
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Pop up hood	√	√	√	√		
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Multi AV	√	√	√	√		SP0503
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	HV battery	√	√	√	√	AC1121	
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	EV/HEV	√	√	√	√	AC1084.AC1085.AC1086.AC1087.AC1088.AC1089.AC1106	
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Occupant detection			√	√		SP0584
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Adaptive light	√	√	√	√	AC0978.AC0979.AC0980.AC0981.AC0982	SP0561,SP0562
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 2	√	√	√	√		
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Lane camera	√	√	√	√		
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 1	√	√	√	√		
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	ANC	√	√	√	√	AC1024	
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	HIGH BEAM ASSIST	√	√	√	√		
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√		
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	Brake	√	√	√	√	AC1127	
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	6ch CAN GATEWAY	√	√	√	√		
Guam	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Guam	INFINITI Q60	CV37	2019.NULL	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Guam	INFINITI Q60	CV37	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Guam	INFINITI Q60	CV37	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI Q60	CV37	2019.NULL_	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Guam	INFINITI Q60	CV37	2019.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Guam	INFINITI Q60	CV37	2019.NULL	Air bag	√	√	√	√		
Guam	INFINITI Q60	CV37	2019.NULL	EPS/DAST 3	√	√	√	√		
Guam	INFINITI Q60	CV37	2019.NULL	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351

Guam	INFINITI Q60	CV37	2019.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI Q60	CV37	2019.NULL_	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Guam	INFINITI Q60	CV37	2019.NULL_	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guam	INFINITI Q60	CV37	2019.NULL_	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guam	INFINITI Q60	CV37	2019.NULL_	Pop up hood	√	√	√	√		
Guam	INFINITI Q60	CV37	2019.NULL_	Multi AV	√	√	√	√		SP0503
Guam	INFINITI Q60	CV37	2019.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guam	INFINITI Q60	CV37	2019.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guam	INFINITI Q60	CV37	2019.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI Q60	CV37	2019.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI Q60	CV37	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guam	INFINITI Q60	CV37	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI Q60	CV37	2019.NULL	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Guam	INFINITI Q60	CV37	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI Q60	CV37	2019.NULL	DAST 2	√	√	√	√		
Guam	INFINITI Q60	CV37	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI Q60	CV37	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI Q60	CV37	2019.NULL	CAN gateway	√	√	√			
Guam	INFINITI Q60	CV37	2019.NULL	Lane camera	√	√	√	√		
Guam	INFINITI Q60	CV37	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI Q60	CV37	2019.NULL	DAST 1	√	√	√	√		
Guam	INFINITI Q60	CV37	2019.NULL_	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Guam	INFINITI Q60	CV37	2019.NULL	ANC	√	√	√	√	AC1024	
Guam	INFINITI Q60	CV37	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI Q60	CV37	2019.NULL	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Guam	INFINITI Q60	CV37	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guam	INFINITI Q60	CV37	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
Guam	INFINITI Q60	CV37	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI Q60	CV37	2019.NULL	Lane camera 2	√	√	√	√		
Guam	INFINITI Q60	CV37	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Guam	INFINITI Q60	CV37	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
Guam	INFINITI Q60	CV37	2019.NULL	ICC/ADAS 2	√	√	√	√		
Guam	INFINITI Q60	CV37	2019.NULL	FSCM	√	√	√	√	AC1109	
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Air bag	√	√	√	√		
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Transmission	√	√	√	√		SP0274
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Pop up hood	√	√	√	√		
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Multi AV	√	√	√	√		SP0503
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guam	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Precrash seatbelt	√	√	√	√		
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	Air bag	√	√	√	√		
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guam	INFINITI Q60 COUPE	CV36	2014.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	Transmission	√	√	√	√		SP0274
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guam	INFINITI Q60 COUPE	CV36	2014.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	Pop up hood	√	√	√	√		
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI Q60 COUPE	CV36	2014.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI Q60 COUPE	CV36	2014.NULL	Precrash seatbelt	√	√	√	√		
Guam	INFINITI Q70	Y51	2019.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guam	INFINITI Q70	Y51	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Guam	INFINITI Q70	Y51	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI Q70	Y51	2019.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guam	INFINITI Q70	Y51	2019.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI Q70	Y51	2019.NULL	Air bag	√	√	√	√		
Guam	INFINITI Q70	Y51	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
Guam	INFINITI Q70	Y51	2019.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Guam	INFINITI Q70	Y51	2019.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0155, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guam	INFINITI Q70	Y51	2019.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Guam	INFINITI Q70	Y51	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guam	INFINITI Q70	Y51	2019.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI Q70	Y51	2019.NULL	Pop up hood	√	√	√	√		
Guam	INFINITI Q70	Y51	2019.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI Q70	Y51	2019.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guam	INFINITI Q70	Y51	2019.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guam	INFINITI Q70	Y51	2019.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guam	INFINITI Q70	Y51	2019.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI Q70	Y51	2019.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI Q70	Y51	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guam	INFINITI Q70	Y51	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI Q70	Y51	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI Q70	Y51	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI Q70	Y51	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI Q70	Y51	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI Q70	Y51	2019.NULL	CAN gateway	√	√	√			
Guam	INFINITI Q70	Y51	2019.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
Guam	INFINITI Q70	Y51	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI Q70	Y51	2019.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guam	INFINITI Q70	Y51	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI Q70	Y51	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guam	INFINITI Q70	Y51	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI Q70	Y51	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Guam	INFINITI Q70	Y51	2019.NULL	ICC/ADAS 2	√	√	√	√		
Guam	INFINITI Q70	Y51	2019.NULL	FSCM	√	√	√	√	AC1109	
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Laser/radar	√	√	√	√	AC0994	
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Air bag	√	√	√	√		
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	EPS/DAST 3	√	√	√	√		
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Motor control	√	√	√	√		
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	BCM				√	AC0613, AC0618, AC0653, AC0663, AC0690, AC0692, AC0698, AC0702	SP0372, SP0429, SP0471
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Pop up hood	√	√	√	√		
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	HV battery	√	√	√	√	AC1121	
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	CAN gateway	√	√	√			
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL_	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	Brake	√	√	√	√	AC1127	
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	6ch CAN GATEWAY	√	√	√	√		
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	ICC/ADAS 2	√	√	√	√		
Guam	INFINITI Q70 HYBRID	HY51	2014.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Guam	INFINITI QX30	H15	2019.NULL	Air pressure monitor	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	Air bag	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	EPS/DAST 3	√	√	√			
Guam	INFINITI QX30	H15	2019.NULL	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Guam	INFINITI QX30	H15	2019.NULL_	Engine	√	√	√	√	AC0002, AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0103, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guam	INFINITI QX30	H15	2019.NULL	EHS/PKB	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	Transmission	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL_	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Guam	INFINITI QX30	H15	2019.NULL	ABS	√	√	√	√		SP0308
Guam	INFINITI QX30	H15	2019.NULL	Multi AV	√	√	√	√		SP0501
Guam	INFINITI QX30	H15	2019.NULL	HVAC	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	Auto drive position	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	Shift	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	All mode AWD/4WD	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	AVM	√	√		√		
Guam	INFINITI QX30	H15	2019.NULL	Intelligent key	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	CAN gateway	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	ANC	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	Telematics	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	FSCM	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	Siren control unit	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL_	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	

Guam	INFINITI QX30	H15	2019.NULL –	Overhead Control Panel Unit	√			√		
Guam	INFINITI QX30	H15	2019.NULL –	Universal Garage Door Opener	√			√		
Guam	INFINITI QX30	H15	2019.NULL –	Upper control panel cont unit	√					
Guam	INFINITI QX30	H15	2019.NULL –	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Guam	INFINITI QX30	H15	2019.NULL –	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Guam	INFINITI QX30	H15	2019.NULL	Light/Rain Sensor Module	√			√		
Guam	INFINITI QX30	H15	2019.NULL	EC Mirror Compass	√					
Guam	INFINITI QX30	H15	2019.NULL –	Intelligent Battery Sensor	√					
Guam	INFINITI QX30	H15	2019.NULL	Alarm siren	√			√		
Guam	INFINITI QX30	H15	2019.NULL	Radar sensor	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL –	Steering column cont module	√	√	√			
Guam	INFINITI QX30	H15	2019.NULL	ICC sensor	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL –	Trailer recognition control unit	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	H/L control module LH	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	Powertrain cont module	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	Side radar LH	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	LED H/L control module LH	√			√		
Guam	INFINITI QX30	H15	2019.NULL	Steering Wheel Switch Pad	√			√		
Guam	INFINITI QX30	H15	2019.NULL	Parking assist	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL –	Occupant Classification Unit	√			√		
Guam	INFINITI QX30	H15	2019.NULL –	Electronic Ignition Switch cont unit	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	H/L control module RH	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	Front camera unit	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	Side radar RH	√	√	√	√		
Guam	INFINITI QX30	H15	2019.NULL	LED H/L control module RH	√			√		
Guam	INFINITI QX4	JR50	1997.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guam	INFINITI QX4	JR50	1997.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Guam	INFINITI QX4	JR50	1997.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI QX4	JR50	1997.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guam	INFINITI QX4	JR50	1997.NULL	Air bag	√	√	√	√		
Guam	INFINITI QX4	JR50	1997.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Guam	INFINITI QX4	JR50	1997.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Guam	INFINITI QX4	JR50	1997.NULL	Motor control						
Guam	INFINITI QX4	JR50	1997.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI QX4	JR50	1997.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Guam	INFINITI QX4	JR50	1997.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Guam	INFINITI QX4	JR50	1997.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI QX4	JR50	1997.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI QX4	JR50	1997.NULL	HVAC	√	√	√	√		
Guam	INFINITI QX4	JR50	1997.NULL	Difference lock	√	√	√	√		
Guam	INFINITI QX4	JR50	1997.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI QX4	JR50	1997.NULL	Auto slide door	√	√	√	√	AC0941	
Guam	INFINITI QX4	JR50	1997.NULL	DIU		√	√	√		
Guam	INFINITI QX4	JR50	1997.NULL	Adaptive light	√	√	√	√		
Guam	INFINITI QX4	JR50	1997.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI QX4	JR50	1997.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guam	INFINITI QX4	JR50	1997.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI QX4	JR50	1997.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guam	INFINITI QX4	JR50	1997.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Guam	INFINITI QX4	JR50	1997.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI QX4	JR50	1997.NULL	IVMS	√	√		√		
Guam	INFINITI QX4	JR50	1997.NULL	Distance control	√	√		√		
Guam	INFINITI QX4	JR50	1997.NULL	Active suspense system	√	√	√	√		
Guam	INFINITI QX4	JR50	1997.NULL	Motor assist		√	√	√		SP0574
Guam	INFINITI QX4	IR50	1997.NULL	ASCD	√	√	√	√		
Guam	INFINITI QX4	IR50	1997.NULL	Active engine mount	√	√	√	√		
Guam	INFINITI QX4	IR50	1997.NULL	TCS	√	√	√	√		
Guam	INFINITI QX4	IR50	1997.NULL	S/blind camera	√			√		SP0572, SP0573
Guam	INFINITI QX4	JR50	1997.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guam	INFINITI QX4	JR50	1997.NULL	Nats immu	√	√	√			
Guam	INFINITI QX4	JR50	1997.NULL	Rearview camera	√			√		SP0570, SP0571
Guam	INFINITI QX4	JR50	1997.NULL	Smart entrance						SP0568
Guam	INFINITI QX50	J50	2014.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guam	INFINITI QX50	J50	2014.NULL	Laser/radar	√	√	√	√	AC0994	
Guam	INFINITI QX50	J50	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI QX50	J50	2014.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI QX50	J50	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI QX50	J50	2014.NULL	Air bag	√	√	√	√		
Guam	INFINITI QX50	J50	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
Guam	INFINITI QX50	J50	2014.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guam	INFINITI QX50	J50	2014.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guam	INFINITI QX50	J50	2014.NULL	Transmission	√	√	√	√		SP0274
Guam	INFINITI QX50	J50	2014.NULL	BCM				√		SP0372, SP0429
Guam	INFINITI QX50	J50	2014.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI QX50	J50	2014.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI QX50	J50	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI QX50	J50	2014.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI QX50	J50	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guam	INFINITI QX50	J50	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI QX50	J50	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Guam	INFINITI QX50	J50	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI QX50	J50	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI QX50	J50	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI QX50	J50	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guam	INFINITI QX50	J50	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Guam	INFINITI QX50	J50	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI QX50	J50	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guam	INFINITI QX50	J50	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI QX50	J55	2019.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Guam	INFINITI QX50	J55	2019.NULL	Laser/radar	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guam	INFINITI QX50	J55	2019.NULL –	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Guam	INFINITI QX50	J55	2019.NULL	Air bag	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	EPS/DAST 3	√	√	√	√		

Guam	INFINITI QX50	J55	2019.NULL	Meter/M&A	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guam	INFINITI QX50	J55	2019.NULL	EHS/PKB	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Guam	INFINITI QX50	J55	2019.NULL	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Guam	INFINITI QX50	J55	2019.NULL	ABS	√	√	√	√		SP0313, SP0315
Guam	INFINITI QX50	J55	2019.NULL	Total illum C/U	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI QX50	J55	2019.NULL	HVAC	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	Auto drive position	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	Auto back door	√	√	√	√		SP0611
Guam	INFINITI QX50	J55	2019.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI QX50	J55	2019.NULL	Shift						
Guam	INFINITI QX50	J55	2019.NULL	Adaptive light	√	√	√	√		SP0562
Guam	INFINITI QX50	J55	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI QX50	J55	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI QX50	J55	2019.NULL	All mode AWD/4WD	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	DAST 2	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI QX50	J55	2019.NULL	CAN gateway	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	Lane camera	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	DAST 1	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	Chassis control	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	ANC						
Guam	INFINITI QX50	J55	2019.NULL	E-HUD	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI QX50	J55	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guam	INFINITI QX50	J55	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI QX50	J55	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
Guam	INFINITI QX50	J55	2019.NULL	ICC/ADAS 2	√	√	√	√		
Guam	INFINITI QX56	JA60	2004.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guam	INFINITI QX56	JA60	2004.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Guam	INFINITI QX56	JA60	2004.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI QX56	JA60	2004.NULL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guam	INFINITI QX56	JA60	2004.NULL	Air bag	√	√	√	√		
Guam	INFINITI QX56	JA60	2004.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Guam	INFINITI QX56	JA60	2004.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Guam	INFINITI QX56	JA60	2004.NULL	Motor control						
Guam	INFINITI QX56	JA60	2004.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI QX56	JA60	2004.NULL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Guam	INFINITI QX56	JA60	2004.NULL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Guam	INFINITI QX56	JA60	2004.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guam	INFINITI QX56	JA60	2004.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI QX56	JA60	2004.NULL	HVAC	√	√	√	√		
Guam	INFINITI QX56	JA60	2004.NULL	Difference lock	√	√	√	√		
Guam	INFINITI QX56	JA60	2004.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI QX56	JA60	2004.NULL	Auto slide door	√	√	√	√	AC0941	
Guam	INFINITI QX56	JA60	2004.NULL	DIU		√	√	√		
Guam	INFINITI QX56	JA60	2004.NULL	Adaptive light	√	√	√	√		
Guam	INFINITI QX56	JA60	2004.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI QX56	JA60	2004.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guam	INFINITI QX56	JA60	2004.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI QX56	JA60	2004.NULL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guam	INFINITI QX56	JA60	2004.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Guam	INFINITI QX56	JA60	2004.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI QX56	JA60	2004.NULL	IVMS	√	√		√		
Guam	INFINITI QX56	JA60	2004.NULL	Distance control	√	√		√		
Guam	INFINITI QX56	JA60	2004.NULL	Active suspense system	√	√	√	√		
Guam	INFINITI QX56	JA60	2004.NULL	Motor assist		√	√	√		SP0574
Guam	INFINITI QX56	JA60	2004.NULL	ASCD	√	√	√	√		
Guam	INFINITI QX56	JA60	2004.NULL	Active engine mount	√	√	√	√		
Guam	INFINITI QX56	JA60	2004.NULL	TCS	√	√	√	√		
Guam	INFINITI QX56	JA60	2004.NULL	S/blind camera	√			√		SP0572, SP0573
Guam	INFINITI QX56	JA60	2004.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guam	INFINITI QX56	JA60	2004.NULL	Nats immu	√	√	√			
Guam	INFINITI QX56	JA60	2004.NULL	Rearview camera	√			√		SP0570, SP0571
Guam	INFINITI QX56	JA60	2004.NULL	Smart entrance						SP0568
Guam	INFINITI QX56	Z62	2011.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guam	INFINITI QX56	Z62	2011.NULL	Laser/radar	√	√	√	√		
Guam	INFINITI QX56	Z62	2011.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI QX56	Z62	2011.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guam	INFINITI QX56	Z62	2011.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI QX56	Z62	2011.NULL	Air bag	√	√	√	√		
Guam	INFINITI QX56	Z62	2011.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Guam	INFINITI QX56	Z62	2011.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guam	INFINITI QX56	Z62	2011.NULL	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guam	INFINITI QX56	Z62	2011.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guam	INFINITI QX56	Z62	2011.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Guam	INFINITI QX56	Z62	2011.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI QX56	Z62	2011.NULL	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0476, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488, SP0489, SP0490
Guam	INFINITI QX56	Z62	2011.NULL	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Guam	INFINITI QX56	Z62	2011.NULL	Difference lock	√	√	√	√		
Guam	INFINITI QX56	Z62	2011.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI QX56	Z62	2011.NULL	Auto back door	√	√	√	√		
Guam	INFINITI QX56	Z62	2011.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI QX56	Z62	2011.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guam	INFINITI QX56	Z62	2011.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI QX56	Z62	2011.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Guam	INFINITI QX56	Z62	2011.NULL	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Guam	INFINITI QX56	Z62	2011.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI QX56	Z62	2011.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI QX56	Z62	2011.NULL	CAN gateway	√	√	√			
Guam	INFINITI QX56	Z62	2011.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guam	INFINITI QX56	Z62	2011.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI QX56	Z62	2011.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guam	INFINITI QX56	Z62	2011.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI QX56	Z62	2011.NULL	Rearview camera	√			√		SP0570, SP0571
Guam	INFINITI QX60	L50	2019.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guam	INFINITI QX60	L50	2019.2-	Laser/radar	√	√	√	√	AC0994	
Guam	INFINITI QX60	L50	2019.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Guam	INFINITI QX60	L50	2019.2-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guam	INFINITI QX60	L50	2019.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI QX60	L50	2019.2-	Air bag	√	√	√	√		
Guam	INFINITI QX60	L50	2019.2-	EPS/DAST 3	√	√	√	√		
Guam	INFINITI QX60	L50	2019.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guam	INFINITI QX60	L50	2019.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guam	INFINITI QX60	L50	2019.2-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Guam	INFINITI QX60	L50	2019.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guam	INFINITI QX60	L50	2019.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guam	INFINITI QX60	L50	2019.2-	Multi AV	√	√	√	√		SP0503
Guam	INFINITI QX60	L50	2019.2-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Guam	INFINITI QX60	L50	2019.2-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI QX60	L50	2019.2-	Auto back door	√	√	√	√		SP0611
Guam	INFINITI QX60	L50	2019.2-	Occupant detection			√	√		SP0584
Guam	INFINITI QX60	L50	2019.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI QX60	L50	2019.2-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI QX60	L50	2019.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI QX60	L50	2019.2-	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI QX60	L50	2019.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI QX60	L50	2019.2-	CAN gateway	√	√	√			
Guam	INFINITI QX60	L50	2019.2-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
Guam	INFINITI QX60	L50	2019.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guam	INFINITI QX60	L50	2019.2-	ANC	√	√	√	√	AC1024	
Guam	INFINITI QX60	L50	2019.2-	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI QX60	L50	2019.2-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guam	INFINITI QX60	L50	2019.2-	HIGH BEAM ASSIST	√	√	√	√		
Guam	INFINITI QX60	L50	2019.2-	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI QX60	L50	2019.2-	3ch CAN GATEWAY	√	√	√	√		
Guam	INFINITI QX60	L50	2019.2-	ICC/ADAS 2	√	√	√	√		
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Laser/radar	√	√	√	√		
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Air bag	√	√	√	√		
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	EPS/DAST 3	√	√	√	√		
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Motor control	√	√	√	√		
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0038, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	HV battery	√	√	√	√	AC1121	
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Auto back door	√	√	√	√		SP0611
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	CAN gateway	√	√	√			
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	ANC	√	√	√	√		
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	HIGH BEAM ASSIST	√	√	√	√		
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	ICC/ADAS 2	√	√	√	√		
Guam	INFINITI QX60 HYBRID	HL50	2014.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Guam	INFINITI QX70	S51	2014.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guam	INFINITI QX70	S51	2014.NULL	Laser/radar	√	√	√	√	AC0994	
Guam	INFINITI QX70	S51	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI QX70	S51	2014.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guam	INFINITI QX70	S51	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI QX70	S51	2014.NULL	Air bag	√	√	√	√		
Guam	INFINITI QX70	S51	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
Guam	INFINITI QX70	S51	2014.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guam	INFINITI QX70	S51	2014.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guam	INFINITI QX70	S51	2014.NULL	Transmission	√	√	√	√		SP0274
Guam	INFINITI QX70	S51	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guam	INFINITI QX70	S51	2014.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Guam	INFINITI QX70	S51	2014.NULL	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Guam	INFINITI QX70	S51	2014.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI QX70	S51	2014.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guam	INFINITI QX70	S51	2014.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guam	INFINITI QX70	S51	2014.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI QX70	S51	2014.NULL	Auto back door	√	√	√	√		SP0611
Guam	INFINITI QX70	S51	2014.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI QX70	S51	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guam	INFINITI QX70	S51	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI QX70	S51	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Guam	INFINITI QX70	S51	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Guam	INFINITI QX70	S51	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI QX70	S51	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI QX70	S51	2014.NULL	CAN gateway	√	√	√			
Guam	INFINITI QX70	S51	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Guam	INFINITI QX70	S51	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guam	INFINITI QX80	Z62	2019.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guam	INFINITI QX80	Z62	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Guam	INFINITI QX80	Z62	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guam	INFINITI QX80	Z62	2019.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guam	INFINITI QX80	Z62	2019.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guam	INFINITI QX80	Z62	2019.NULL	Air bag	√	√	√	√		
Guam	INFINITI QX80	Z62	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
Guam	INFINITI QX80	Z62	2019.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Guam	INFINITI QX80	Z62	2019.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239

Guam	INFINITI QX80	Z62	2019.NULL -	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guam	INFINITI QX80	Z62	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guam	INFINITI QX80	Z62	2019.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guam	INFINITI QX80	Z62	2019.NULL	Multi AV	√	√	√	√		SP0503
Guam	INFINITI QX80	Z62	2019.NULL -	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Guam	INFINITI QX80	Z62	2019.NULL	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Guam	INFINITI QX80	Z62	2019.NULL	Difference lock	√	√	√	√		
Guam	INFINITI QX80	Z62	2019.NULL -	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guam	INFINITI QX80	Z62	2019.NULL	Auto back door	√	√	√	√		
Guam	INFINITI QX80	Z62	2019.NULL	Occupant detection			√	√		SP0584
Guam	INFINITI QX80	Z62	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guam	INFINITI QX80	Z62	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guam	INFINITI QX80	Z62	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guam	INFINITI QX80	Z62	2019.NULL	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Guam	INFINITI QX80	Z62	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Guam	INFINITI QX80	Z62	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guam	INFINITI QX80	Z62	2019.NULL -	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guam	INFINITI QX80	Z62	2019.NULL	CAN gateway	√	√	√			
Guam	INFINITI QX80	Z62	2019.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Guam	INFINITI QX80	Z62	2019.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guam	INFINITI QX80	Z62	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Guam	INFINITI QX80	Z62	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guam	INFINITI QX80	Z62	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
Guam	INFINITI QX80	Z62	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Guam	INFINITI QX80	Z62	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Guam	INFINITI QX80	Z62	2019.NULL	ICC/ADAS 2	√	√	√	√		
Guam	INFINITI QX80	Z62	2019.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guatemala	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guatemala	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Guatemala	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guatemala	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Guatemala	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guatemala	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Guatemala	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guatemala	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Guatemala	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Guatemala	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guatemala	INFINITI EX35/EX37	I50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guatemala	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guatemala	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guatemala	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guatemala	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Guatemala	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Guatemala	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guatemala	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Guatemala	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Guatemala	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guatemala	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Guatemala	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Guatemala	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Guatemala	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guatemala	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Guatemala	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guatemala	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Guatemala	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Guatemala	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Guatemala	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guatemala	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Guatemala	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guatemala	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guatemala	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Guatemala	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guatemala	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guatemala	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Guatemala	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guatemala	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guatemala	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Guatemala	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Guatemala	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guatemala	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Guatemala	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guatemala	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Guatemala	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Guatemala	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guatemala	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Guatemala	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guatemala	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Guatemala	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Guatemala	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guatemala	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Guatemala	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guatemala	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guatemala	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guatemala	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guatemala	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Guatemala	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guatemala	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guatemala	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guatemala	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guatemala	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Guatemala	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Guatemala	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Guatemala	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guatemala	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guatemala	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guatemala	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guatemala	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Guatemala	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guatemala	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guatemala	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guatemala	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Guatemala	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Guatemala	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guatemala	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guatemala	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Guatemala	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Guatemala	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guatemala	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Guatemala	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guatemala	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guatemala	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Guatemala	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Guatemala	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Guatemala	INFINITI Q45	F50	2001.8-	Motor control						
Guatemala	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guatemala	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Guatemala	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Guatemala	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guatemala	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Guatemala	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Guatemala	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Guatemala	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guatemala	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Guatemala	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Guatemala	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Guatemala	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guatemala	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guatemala	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guatemala	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guatemala	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Guatemala	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guatemala	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Guatemala	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Guatemala	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Guatemala	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Guatemala	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Guatemala	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Guatemala	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Guatemala	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Guatemala	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guatemala	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Guatemala	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Guatemala	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Guatemala	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guatemala	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Guatemala	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guatemala	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guatemala	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Guatemala	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Guatemala	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guatemala	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√	AC0270, AC0274	SP0270, SP0274
Guatemala	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guatemala	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Guatemala	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Guatemala	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Guatemala	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Guatemala	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guatemala	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Guatemala	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Guatemala	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guatemala	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guatemala	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Guatemala	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Guatemala	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guatemala	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Guatemala	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guatemala	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Guatemala	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guatemala	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Guinea bissau	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinea bissau	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Guinea bissau	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinea bissau	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Guinea bissau	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Guinea bissau	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Guinea bissau	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Guinea bissau	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Guinea bissau	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Guinea bissau	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		

Guinea bissau	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Guinea bissau	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Guinea bissau	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Guinea bissau	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Guinea bissau	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Guinea bissau	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Guinea bissau	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Guinea bissau	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Guinea bissau	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Guinea bissau	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Guinea bissau	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Guinea bissau	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Guinea bissau	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Guinea bissau	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinea bissau	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Guinea bissau	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guinea bissau	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Guinea bissau	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Guinea bissau	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guinea bissau	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinea bissau	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Guinea bissau	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guinea bissau	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Guinea bissau	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Guinea bissau	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guinea bissau	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinea bissau	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Guinea bissau	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Guinea bissau	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinea bissau	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Guinea bissau	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	

XTOOL

Guinea bissau	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Guinea bissau	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Guinea bissau	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinea bissau	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Guinea bissau	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guinea bissau	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinea bissau	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Guinea bissau	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Guinea bissau	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Guinea bissau	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guinea bissau	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Guinea bissau	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Guinea bissau	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Guinea bissau	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinea bissau	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Guinea bissau	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Guinea bissau	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Guinea bissau	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Guinea bissau	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinea bissau	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Guinea bissau	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guinea bissau	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		

Guinea bissau	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Guinea bissau	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guinea bissau	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinea bissau	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Guinea bissau	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guinea bissau	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guinea bissau	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Guinea bissau	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guinea bissau	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinea bissau	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Guinea bissau	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guinea bissau	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinea bissau	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Guinea bissau	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinea bissau	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Guinea bissau	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Guinea bissau	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guinea bissau	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Guinea bissau	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Guinea bissau	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinea bissau	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Guinea bissau	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Guinea bissau	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Guinea bissau	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Guinea bissau	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Guinea bissau	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinea bissau	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Guinea bissau	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Guinea bissau	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Guinea bissau	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Guinea bissau	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinea bissau	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

XTOOL

Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinea bissau	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinea bissau	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guinea bissau	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Guinea bissau	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guinea bissau	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Guinea bissau	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Guinea bissau	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guinea bissau	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guinea bissau	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Guinea bissau	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guinea bissau	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Guinea bissau	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Guinea bissau	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guinea bissau	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinea bissau	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Guinea bissau	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guinea bissau	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinea bissau	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Guinea bissau	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinea bissau	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Guinea bissau	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinea bissau	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Guinea bissau	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Guinea bissau	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinea bissau	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guinea bissau	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Guinea bissau	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinea bissau	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Guinea bissau	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinea bissau	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Guinea bissau	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guinea bissau	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Guinea bissau	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Guinea bissau	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Guinea bissau	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guinea bissau	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Guinea bissau	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinea bissau	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guinea bissau	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinea bissau	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinea bissau	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guinea bissau	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinea bissau	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Guinea bissau	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinea bissau	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Guinea bissau	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Guinea bissau	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Guinea bissau	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Guinea bissau	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinea bissau	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Guinea bissau	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guinea bissau	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Guinea bissau	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guinea bissau	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Guinea bissau	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Guinea bissau	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinea bissau	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guinea bissau	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Guinea bissau	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinea bissau	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Guinea bissau	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Guinea bissau	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guinea bissau	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinea bissau	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Guinea bissau	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Guinea bissau	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinea bissau	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinea bissau	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guinea bissau	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinea bissau	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Guinea bissau	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinea bissau	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Guinea bissau	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Guinea bissau	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinea bissau	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guinea bissau	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Guinea bissau	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Guinea bissau	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinea bissau	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Guinea bissau	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Guinea bissau	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinea bissau	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Guinea bissau	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinea bissau	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guinea bissau	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinea bissau	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Guinea bissau	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Guinea bissau	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinea bissau	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guinea bissau	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guinea bissau	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guinea bissau	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Guinea bissau	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Guinea bissau	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Guinea bissau	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Guinea bissau	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinea bissau	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Guinea bissau	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Guinea bissau	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guinea bissau	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinea bissau	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Guinea bissau	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Guinea bissau	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Guinea bissau	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guinea bissau	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Guinea bissau	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Guinea bissau	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guinea bissau	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Guinea bissau	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinea bissau	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Guinea bissau	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Guinea bissau	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Guinea bissau	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Guinea bissau	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guinee	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinee	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Guinee	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinee	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guinee	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Guinee	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinee	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guinee	INFINITI EX35/EX37	I50	2011.1-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinee	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinee	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinee	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinee	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Guinee	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Guinee	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Guinee	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Guinee	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guinee	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinee	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Guinee	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinee	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guinee	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Guinee	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinee	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Guinee	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Guinee	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guinee	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Guinee	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Guinee	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinee	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinee	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinee	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Guinee	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Guinee	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Guinee	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinee	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Guinee	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinee	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Guinee	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinee	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Guinee	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinee	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinee	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Guinee	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinee	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guinee	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Guinee	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinee	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinee	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinee	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Guinee	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinee	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guinee	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Guinee	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guinee	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guinee	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Guinee	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guinee	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guinee	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guinee	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guinee	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Guinee	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Guinee	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guinee	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guinee	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinee	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Guinee	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinee	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinee	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinee	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Guinee	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Guinee	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guinee	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinee	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Guinee	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Guinee	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Guinee	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Guinee	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Guinee	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Guinee	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Guinee	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Guinee	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Guinee	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Guinee	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Guinee	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Guinee	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Guinee	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Guinee	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Guinee	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Guinee	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Guinee	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Guinee	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Guinee	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Guinee	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Guinee	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Guinee	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Guinee	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Guinee	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Guinee	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinee	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Guinee	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guinee	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Guinee	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Guinee	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guinee	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinee	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Guinee	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guinee	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Guinee	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Guinee	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guinee	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinee	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Guinee	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Guinee	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinee	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Guinee	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinee	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Guinee	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Guinee	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinee	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Guinee	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guinee	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinee	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Guinee	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Guinee	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Guinee	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guinee	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Guinee	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Guinee	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Guinee	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinee	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Guinee	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Guinee	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		

Xtool

Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Guinee	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Guinee	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinee	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Guinee	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guinee	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Guinee	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Guinee	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guinee	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinee	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Guinee	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guinee	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guinee	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Guinee	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guinee	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinee	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Guinee	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guinee	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinee	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Guinee	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinee	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Guinee	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Guinee	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guinee	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Guinee	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Guinee	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinee	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Guinee	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Guinee	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Guinee	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Guinee	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Guinee	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinee	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Guinee	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Guinee	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Guinee	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Guinee	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503

Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinee	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinee	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinee	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guinee	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Guinee	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guinee	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Guinee	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Guinee	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guinee	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guinee	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Guinee	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guinee	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Guinee	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Guinee	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guinee	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinee	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Guinee	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guinee	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinee	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Guinee	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinee	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Guinee	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinee	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Guinee	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Guinee	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinee	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guinee	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Guinee	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinee	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Guinee	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinee	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Guinee	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guinee	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Guinee	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Guinee	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinee	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guinee	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Guinee	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinee	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guinee	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinee	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinee	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guinee	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinee	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Guinee	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinee	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Guinee	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Guinee	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Guinee	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Guinee	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinee	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Guinee	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guinee	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Guinee	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Guinee	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Guinee	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Guinee	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Guinee	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guinee	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guinee	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Guinee	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guinee	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Guinee	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Guinee	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guinee	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guinee	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Guinee	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Guinee	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guinee	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinee	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guinee	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Guinee	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Guinee	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guinee	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Guinee	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Guinee	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guinee	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guinee	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Guinee	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Guinee	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinee	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Guinee	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Guinee	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Guinee	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Guinee	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guinee	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guinee	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guinee	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Guinee	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Guinee	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guinee	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guinee	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guinee	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guinee	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Guinee	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Guinee	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Guinee	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Guinee	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guinee	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Guinee	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Guinee	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Guinee	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guinee	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Guinee	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Guinee	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Guinee	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guinee	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Guinee	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Guinee	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Guinee	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Guinee	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guinee	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Guinee	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Guinee	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Guinee	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Guinee	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guyana	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guyana	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Guyana	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guyana	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Guyana	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guyana	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Guyana	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guyana	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Guyana	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Guyana	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guyana	INFINITI EX35/EX37	I50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guyana	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guyana	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guyana	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guyana	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Guyana	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Guyana	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Guyana	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guyana	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guyana	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Guyana	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guyana	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Guyana	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guyana	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guyana	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Guyana	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guyana	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Guyana	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Guyana	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Guyana	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	

Guyana	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guyana	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Guyana	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Guyana	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guyana	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guyana	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Guyana	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guyana	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Guyana	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guyana	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Guyana	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Guyana	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guyana	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Guyana	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Guyana	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guyana	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guyana	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Guyana	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guyana	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Guyana	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Guyana	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guyana	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Guyana	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Guyana	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Guyana	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Guyana	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Guyana	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guyana	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guyana	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guyana	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guyana	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guyana	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Guyana	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guyana	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		

Guyana	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guyana	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guyana	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Guyana	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guyana	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Guyana	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Guyana	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Guyana	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Guyana	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Guyana	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Guyana	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guyana	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Guyana	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guyana	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Guyana	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Guyana	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guyana	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Guyana	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guyana	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Guyana	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Guyana	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guyana	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Guyana	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Guyana	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Guyana	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guyana	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Guyana	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Guyana	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Guyana	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Guyana	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Guyana	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guyana	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Guyana	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Guyana	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Guyana	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Guyana	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Guyana	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Guyana	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guyana	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guyana	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guyana	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Guyana	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Guyana	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Guyana	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Guyana	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guyana	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guyana	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Guyana	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Guyana	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Guyana	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Guyana	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Guyana	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guyana	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Guyana	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Guyana	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Guyana	INFINITI Q45	F50	2001.8-	Motor control						
Guyana	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guyana	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Guyana	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Guyana	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Guyana	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Guyana	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Guyana	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Guyana	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guyana	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Guyana	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Guyana	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Guyana	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Guyana	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Guyana	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Guyana	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Guyana	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Guyana	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Guyana	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Guyana	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Guyana	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Guyana	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Guyana	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Guyana	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Guyana	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Guyana	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Guyana	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Guyana	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Guyana	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Guyana	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Guyana	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Guyana	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Guyana	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Guyana	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Guyana	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Guyana	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Guyana	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Guyana	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Guyana	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Guyana	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Guyana	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Guyana	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Guyana	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Guyana	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Guyana	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Guyana	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Guyana	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Guyana	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Guyana	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Guyana	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Guyana	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Guyana	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Guyana	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Guyana	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Guyana	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Guyana	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Haiti	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Haiti	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Haiti	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Haiti	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Haiti	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Haiti	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Haiti	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Haiti	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Haiti	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Haiti	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Haiti	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Haiti	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Haiti	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Haiti	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Haiti	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Haiti	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Haiti	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Haiti	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Haiti	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Haiti	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Haiti	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Haiti	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Haiti	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Haiti	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Haiti	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Haiti	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Haiti	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Haiti	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Haiti	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Haiti	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Haiti	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Haiti	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Haiti	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Haiti	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Haiti	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Haiti	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Haiti	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Haiti	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Haiti	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Haiti	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Haiti	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Haiti	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Haiti	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Haiti	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Haiti	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Haiti	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Haiti	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Haiti	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Haiti	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Haiti	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Haiti	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Haiti	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Haiti	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Haiti	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Haiti	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Haiti	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Haiti	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Haiti	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Haiti	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Haiti	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Haiti	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Haiti	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Haiti	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Haiti	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Haiti	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Haiti	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Haiti	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Haiti	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Haiti	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Haiti	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Haiti	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Haiti	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Haiti	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Haiti	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Haiti	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Haiti	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Haiti	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Haiti	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Haiti	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Haiti	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Haiti	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Haiti	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Haiti	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Haiti	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Haiti	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Haiti	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Haiti	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Haiti	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Haiti	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Haiti	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Haiti	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Haiti	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Haiti	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Haiti	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Haiti	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Haiti	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Haiti	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Haiti	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Haiti	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Haiti	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Haiti	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Haiti	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Haiti	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Haiti	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Haiti	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556

Haiti	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Haiti	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Haiti	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Haiti	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Haiti	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Haiti	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Haiti	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Haiti	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Haiti	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Haiti	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Haiti	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Haiti	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Haiti	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Haiti	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Haiti	INFINITI Q45	F50	2001.8-	Motor control						
Haiti	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Haiti	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Haiti	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Haiti	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Haiti	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Haiti	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Haiti	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Haiti	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Haiti	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Haiti	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Haiti	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Haiti	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Haiti	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Haiti	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Haiti	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Haiti	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Haiti	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Haiti	INFINITI Q45	F50	2001.8-	TVMS	√	√		√		
Haiti	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Haiti	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Haiti	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Haiti	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Haiti	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Haiti	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Haiti	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Haiti	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Haiti	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Haiti	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Haiti	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Haiti	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Haiti	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Haiti	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Haiti	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Haiti	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Haiti	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Haiti	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Haiti	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Haiti	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Haiti	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Haiti	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Haiti	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Haiti	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Haiti	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Haiti	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Haiti	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Haiti	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Haiti	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Haiti	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Haiti	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Haiti	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Haiti	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Haiti	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Haiti	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Haiti	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Haiti	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Air bag	√	√	√	√		
Hawaii	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	
Hawaii	INFINITI EX35	J50	2008.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI EX35	J50	2008.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hawaii	INFINITI EX35	J50	2008.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI EX35	J50	2008.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI EX35	J50	2008.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hawaii	INFINITI EX35	J50	2008.NULL-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hawaii	INFINITI EX35	J50	2008.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Hawaii	INFINITI EX35	J50	2008.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hawaii	INFINITI EX35	J50	2008.NULL-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI EX35	J50	2008.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI EX35	J50	2008.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI EX35	J50	2008.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hawaii	INFINITI EX35	J50	2008.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hawaii	INFINITI EX35	J50	2008.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hawaii	INFINITI EX35	J50	2008.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI EX35	J50	2008.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI EX35	J50	2008.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Hawaii	INFINITI EX35	J50	2008.NULL	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Hawaii	INFINITI EX35	J50	2008.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI EX35	J50	2008.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI EX35	J50	2008.NULL	Rearview camera	√			√		SP0570, SP0571

Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Motor control						
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	DIU		√	√	√		
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Adaptive light	√	√	√	√		
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	IVMS	√	√		√		
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Distance control	√	√		√		
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Active suspense system	√	√	√	√		
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Motor assist		√	√	√		SP0574
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	ASCD	√	√	√	√		
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Active engine mount	√	√	√	√		
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	TCS	√	√	√	√		
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	S/blind camera	√			√		SP0572, SP0573
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Nats immu	√	√	√			
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI FX35/FX45	S50	2003.NULL	Smart entrance						SP0568
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0045, SP0051, SP0053, SP0063, SP0064, SP0074, SP0079, SP0083, SP0085, SP0086, SP0087, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0225, SP0239
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Auto back door	√	√	√	√		SP0611
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI FX35/FX50	S51	2009.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Transmission	√	√	√	√		SP0274
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Auto back door	√	√	√	√		SP0611
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Hawaii	INFINITI FX37/FX50	S51	2013.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI G20	CA33	2002.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hawaii	INFINITI G20	CA33	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Hawaii	INFINITI G20	CA33	2002.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hawaii	INFINITI G20	CA33	2002.NULL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hawaii	INFINITI G20	CA33	2002.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI G20	CA33	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Hawaii	INFINITI G20	CA33	2002.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Hawaii	INFINITI G20	CA33	2002.NULL	Motor control						

Hawaii	INFINITI G20	CA33	2002.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI G20	CA33	2002.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Hawaii	INFINITI G20	CA33	2002.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Hawaii	INFINITI G20	CA33	2002.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI G20	CA33	2002.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI G20	CA33	2002.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI G20	CA33	2002.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI G20	CA33	2002.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI G20	CA33	2002.NULL	Auto slide door	√	√	√	√	AC0941	
Hawaii	INFINITI G20	CA33	2002.NULL	DIU		√	√	√		
Hawaii	INFINITI G20	CA33	2002.NULL	Adaptive light	√	√	√	√		
Hawaii	INFINITI G20	CA33	2002.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI G20	CA33	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Hawaii	INFINITI G20	CA33	2002.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI G20	CA33	2002.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hawaii	INFINITI G20	CA33	2002.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Hawaii	INFINITI G20	CA33	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI G20	CA33	2002.NULL	IVMS	√	√		√		
Hawaii	INFINITI G20	CA33	2002.NULL	Distance control	√	√		√		
Hawaii	INFINITI G20	CA33	2002.NULL	Active suspense system	√	√	√	√		
Hawaii	INFINITI G20	CA33	2002.NULL	Motor assist		√	√	√		SP0574
Hawaii	INFINITI G20	CA33	2002.NULL	ASCD	√	√	√	√		
Hawaii	INFINITI G20	CA33	2002.NULL	Active engine mount	√	√	√	√		
Hawaii	INFINITI G20	CA33	2002.NULL	TCS	√	√	√	√		
Hawaii	INFINITI G20	CA33	2002.NULL	S/blind camera	√			√		SP0572, SP0573
Hawaii	INFINITI G20	CA33	2002.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hawaii	INFINITI G20	CA33	2002.NULL	Nats immu	√	√	√			
Hawaii	INFINITI G20	CA33	2002.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI G20	CA33	2002.NULL	Smart entrance						SP0568
Hawaii	INFINITI G20	P11	1999.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hawaii	INFINITI G20	P11	1999.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Hawaii	INFINITI G20	P11	1999.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hawaii	INFINITI G20	P11	1999.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hawaii	INFINITI G20	P11	1999.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI G20	P11	1999.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Hawaii	INFINITI G20	P11	1999.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Hawaii	INFINITI G20	P11	1999.NULL	Motor control						
Hawaii	INFINITI G20	P11	1999.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI G20	P11	1999.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Hawaii	INFINITI G20	P11	1999.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Hawaii	INFINITI G20	P11	1999.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI G20	P11	1999.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI G20	P11	1999.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI G20	P11	1999.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI G20	P11	1999.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI G20	P11	1999.NULL	Auto slide door	√	√	√	√	AC0941	
Hawaii	INFINITI G20	P11	1999.NULL	DIU		√	√	√		
Hawaii	INFINITI G20	P11	1999.NULL	Adaptive light	√	√	√	√		
Hawaii	INFINITI G20	P11	1999.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI G20	P11	1999.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Hawaii	INFINITI G20	P11	1999.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI G20	P11	1999.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hawaii	INFINITI G20	P11	1999.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Hawaii	INFINITI G20	P11	1999.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI G20	P11	1999.NULL	IVMS	√	√		√		
Hawaii	INFINITI G20	P11	1999.NULL	Distance control	√	√		√		
Hawaii	INFINITI G20	P11	1999.NULL	Active suspense system	√	√	√	√		
Hawaii	INFINITI G20	P11	1999.NULL	Motor assist		√	√	√		SP0574
Hawaii	INFINITI G20	P11	1999.NULL	ASCD	√	√	√	√		
Hawaii	INFINITI G20	P11	1999.NULL	Active engine mount	√	√	√	√		
Hawaii	INFINITI G20	P11	1999.NULL	TCS	√	√	√	√		
Hawaii	INFINITI G20	P11	1999.NULL	S/blind camera	√			√		SP0572, SP0573
Hawaii	INFINITI G20	P11	1999.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hawaii	INFINITI G20	P11	1999.NULL	Nats immu	√	√	√			
Hawaii	INFINITI G20	P11	1999.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI G20	P11	1999.NULL	Smart entrance						SP0568
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Air bag	√	√	√	√		
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Transmission	√	√	√	√		SP0274
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL_	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Pop up hood	√	√	√	√		
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Multi AV	√	√	√	√		SP0503

Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Precrash seatbelt	√	√	√	√		
Hawaii	INFINITI G25/G37 SEDAN	V36	2011.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Motor control						
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	DIU		√	√	√		
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Adaptive light	√	√	√	√		
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	IVMS	√	√		√		
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Distance control	√	√		√		
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Active suspense system	√	√	√	√		
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Motor assist		√	√	√		SP0574
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	ASCD	√	√	√	√		
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Active engine mount	√	√	√	√		
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	TCS	√	√	√	√		
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	S/blind camera	√			√		SP0572, SP0573
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Nats immu	√	√	√			
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI G35 COUPE	CV35	2003.NULL	Smart entrance						SP0568
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Motor control						
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	DIU		√	√	√		
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Adaptive light	√	√	√	√		
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	IVMS	√	√		√		
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Distance control	√	√		√		
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Active suspense system	√	√	√	√		
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Motor assist		√	√	√		SP0574
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	ASCD	√	√	√	√		
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Active engine mount	√	√	√	√		
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	TCS	√	√	√	√		
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	S/blind camera	√			√		SP0572, SP0573
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Nats immu	√	√	√			
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI G35 SEDAN	V35	2003.NULL	Smart entrance						SP0568
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL	ICC/ADAS	√	√	√	√	AC0867. AC0868. AC0884	SP0494
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL	IPDM E/R	√	√	√	√	AC0811. AC0815. AC0816. AC0817. AC0818. AC0819. AC0821. AC0822. AC0825. AC0831	
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Xtool

Hawaii	INFINITI G35 SEDAN	V36	2007.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL –	Multi AV	√	√	√	√		
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL –	Precrash seatbelt	√	√	√	√		
Hawaii	INFINITI G35 SEDAN	V36	2007.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Air bag	√	√	√	√		
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Pop up hood	√	√	√	√		
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Precrash seatbelt	√	√	√	√		
Hawaii	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	Air bag	√	√	√	√		
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	Pop up hood	√	√	√	√		
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	Precrash seatbelt	√	√	√	√		
Hawaii	INFINITI G37 COUPE	CV36	2008.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	Air bag	√	√	√	√		
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	Precrash seatbelt	√	√	√	√		
Hawaii	INFINITI G37 SEDAN	V36	2009.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI I30	CA32	1996.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hawaii	INFINITI I30	CA32	1996.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Hawaii	INFINITI I30	CA32	1996.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hawaii	INFINITI I30	CA32	1996.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hawaii	INFINITI I30	CA32	1996.NULL –	Air bag	√	√	√	√		
Hawaii	INFINITI I30	CA32	1996.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Hawaii	INFINITI I30	CA32	1996.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Hawaii	INFINITI I30	CA32	1996.NULL –	Motor control						

Hawaii	INFINITI I30	CA32	1996.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI I30	CA32	1996.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Hawaii	INFINITI I30	CA32	1996.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Hawaii	INFINITI I30	CA32	1996.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI I30	CA32	1996.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI I30	CA32	1996.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI I30	CA32	1996.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI I30	CA32	1996.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI I30	CA32	1996.NULL	Auto slide door	√	√	√	√	AC0941	
Hawaii	INFINITI I30	CA32	1996.NULL	DIU		√	√	√		
Hawaii	INFINITI I30	CA32	1996.NULL	Adaptive light	√	√	√	√		
Hawaii	INFINITI I30	CA32	1996.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI I30	CA32	1996.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Hawaii	INFINITI I30	CA32	1996.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI I30	CA32	1996.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hawaii	INFINITI I30	CA32	1996.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Hawaii	INFINITI I30	CA32	1996.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI I30	CA32	1996.NULL	IVMS	√	√		√		
Hawaii	INFINITI I30	CA32	1996.NULL	Distance control	√	√		√		
Hawaii	INFINITI I30	CA32	1996.NULL	Active suspense system	√	√	√	√		
Hawaii	INFINITI I30	CA32	1996.NULL	Motor assist		√	√	√		SP0574
Hawaii	INFINITI I30	CA32	1996.NULL	ASCD	√	√	√	√		
Hawaii	INFINITI I30	CA32	1996.NULL	Active engine mount	√	√	√	√		
Hawaii	INFINITI I30	CA32	1996.NULL	TCS	√	√	√	√		
Hawaii	INFINITI I30	CA32	1996.NULL	S/blind camera	√			√		SP0572, SP0573
Hawaii	INFINITI I30	CA32	1996.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hawaii	INFINITI I30	CA32	1996.NULL	Nats immu	√	√	√			
Hawaii	INFINITI I30	CA32	1996.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI I30	CA32	1996.NULL	Smart entrance						SP0568
Hawaii	INFINITI I35	CA33	2002.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hawaii	INFINITI I35	CA33	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Hawaii	INFINITI I35	CA33	2002.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hawaii	INFINITI I35	CA33	2002.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hawaii	INFINITI I35	CA33	2002.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI I35	CA33	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Hawaii	INFINITI I35	CA33	2002.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Hawaii	INFINITI I35	CA33	2002.NULL	Motor control						
Hawaii	INFINITI I35	CA33	2002.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI I35	CA33	2002.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Hawaii	INFINITI I35	CA33	2002.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Hawaii	INFINITI I35	CA33	2002.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI I35	CA33	2002.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI I35	CA33	2002.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI I35	CA33	2002.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI I35	CA33	2002.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI I35	CA33	2002.NULL	Auto slide door	√	√	√	√	AC0941	
Hawaii	INFINITI I35	CA33	2002.NULL	DIU		√	√	√		
Hawaii	INFINITI I35	CA33	2002.NULL	Adaptive light	√	√	√	√		
Hawaii	INFINITI I35	CA33	2002.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI I35	CA33	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Hawaii	INFINITI I35	CA33	2002.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI I35	CA33	2002.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hawaii	INFINITI I35	CA33	2002.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Hawaii	INFINITI I35	CA33	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI I35	CA33	2002.NULL	IVMS	√	√		√		
Hawaii	INFINITI I35	CA33	2002.NULL	Distance control	√	√		√		
Hawaii	INFINITI I35	CA33	2002.NULL	Active suspense system	√	√	√	√		
Hawaii	INFINITI I35	CA33	2002.NULL	Motor assist		√	√	√		SP0574
Hawaii	INFINITI I35	CA33	2002.NULL	ASCD	√	√	√	√		
Hawaii	INFINITI I35	CA33	2002.NULL	Active engine mount	√	√	√	√		
Hawaii	INFINITI I35	CA33	2002.NULL	TCS	√	√	√	√		
Hawaii	INFINITI I35	CA33	2002.NULL	S/blind camera	√			√		SP0572, SP0573
Hawaii	INFINITI I35	CA33	2002.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hawaii	INFINITI I35	CA33	2002.NULL	Nats immu	√	√	√			
Hawaii	INFINITI I35	CA33	2002.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI I35	CA33	2002.NULL	Smart entrance						SP0568
Hawaii	INFINITI JX35	L50	2013.NULL	Laser/radar	√	√	√	√		
Hawaii	INFINITI JX35	L50	2013.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI JX35	L50	2013.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Hawaii	INFINITI JX35	L50	2013.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI JX35	L50	2013.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI JX35	L50	2013.NULL	EPS/DAST 3	√	√	√	√		
Hawaii	INFINITI JX35	L50	2013.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hawaii	INFINITI JX35	L50	2013.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI JX35	L50	2013.NULL_	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Hawaii	INFINITI JX35	L50	2013.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Hawaii	INFINITI JX35	L50	2013.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hawaii	INFINITI JX35	L50	2013.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI JX35	L50	2013.NULL	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Hawaii	INFINITI JX35	L50	2013.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI JX35	L50	2013.NULL	Auto back door	√	√	√	√		SP0611
Hawaii	INFINITI JX35	L50	2013.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI JX35	L50	2013.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hawaii	INFINITI JX35	L50	2013.NULL	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Hawaii	INFINITI JX35	L50	2013.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI JX35	L50	2013.NULL	Precrash seatbelt	√	√	√	√		SP0612

Hawaii	INFINITI TX35	L50	2013.NULL	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Hawaii	INFINITI TX35	L50	2013.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI TX35	L50	2013.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Hawaii	INFINITI TX35	L50	2013.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI TX35	L50	2013.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Hawaii	INFINITI TX35	L50	2013.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI M35/M45	Y50	2006.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Hawaii	INFINITI M35/M45	Y50	2006.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Hawaii	INFINITI M35/M45	Y50	2006.NULL	IPDM E/R	√	√	√	√	AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831,AC0856	
Hawaii	INFINITI M35/M45	Y50	2006.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI M35/M45	Y50	2006.NULL	Meter/M&A		√	√	√		SP0347,SP0348,SP0349
Hawaii	INFINITI M35/M45	Y50	2006.NULL	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Hawaii	INFINITI M35/M45	Y50	2006.NULL	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Hawaii	INFINITI M35/M45	Y50	2006.NULL	BCM					AC0653,AC0698	SP0391,SP0393
Hawaii	INFINITI M35/M45	Y50	2006.NULL	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Hawaii	INFINITI M35/M45	Y50	2006.NULL	Multi AV	√	√	√	√		
Hawaii	INFINITI M35/M45	Y50	2006.NULL	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Hawaii	INFINITI M35/M45	Y50	2006.NULL	Adaptive light	√	√	√	√		SP0561,SP0562
Hawaii	INFINITI M35/M45	Y50	2006.NULL	All mode AWD/4WD	√	√	√	√	AC0957	
Hawaii	INFINITI M35/M45	Y50	2006.NULL	Precrash seatbelt	√	√	√	√		
Hawaii	INFINITI M35/M45	Y50	2006.NULL	Intelligent key	√	√	√	√	AC0911,AC0913,AC0915,AC0916,AC0917,AC0920,AC0922,AC0923,AC0924,AC0925,AC0926,AC0928	SP0511,SP0512,SP0518,SP0520,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0529,SP0530,SP0531,SP0532,SP0534,SP0535,SP0536,SP0537
Hawaii	INFINITI M35/M45	Y50	2006.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976	SP0560
Hawaii	INFINITI M35/M45	Y50	2006.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI M35H	HY51	2012.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Hawaii	INFINITI M35H	HY51	2012.NULL	Laser/radar	√	√	√	√		
Hawaii	INFINITI M35H	HY51	2012.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI M35H	HY51	2012.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Hawaii	INFINITI M35H	HY51	2012.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Hawaii	INFINITI M35H	HY51	2012.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI M35H	HY51	2012.NULL	EPS/DAST 3	√	√	√	√		
Hawaii	INFINITI M35H	HY51	2012.NULL	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Hawaii	INFINITI M35H	HY51	2012.NULL	Motor control	√	√	√	√		
Hawaii	INFINITI M35H	HY51	2012.NULL	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Hawaii	INFINITI M35H	HY51	2012.NULL	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274,SP0276
Hawaii	INFINITI M35H	HY51	2012.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Hawaii	INFINITI M35H	HY51	2012.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Hawaii	INFINITI M35H	HY51	2012.NULL	Diag data recorder	√					
Hawaii	INFINITI M35H	HY51	2012.NULL	Pop up hood	√	√	√	√		
Hawaii	INFINITI M35H	HY51	2012.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI M35H	HY51	2012.NULL	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Hawaii	INFINITI M35H	HY51	2012.NULL	HV battery	√	√	√	√	AC1121	
Hawaii	INFINITI M35H	HY51	2012.NULL	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Hawaii	INFINITI M35H	HY51	2012.NULL	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Hawaii	INFINITI M35H	HY51	2012.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Hawaii	INFINITI M35H	HY51	2012.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Hawaii	INFINITI M35H	HY51	2012.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Hawaii	INFINITI M35H	HY51	2012.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI M35H	HY51	2012.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI M35H	HY51	2012.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Hawaii	INFINITI M35H	HY51	2012.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI M35H	HY51	2012.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Hawaii	INFINITI M35H	HY51	2012.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI M35H	HY51	2012.NULL	Brake	√	√	√	√	AC1127	
Hawaii	INFINITI M35H	HY51	2012.NULL	VSP	√	√	√	√	AC1124,AC1125,AC1126	
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Laser/radar	√	√	√	√		
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Hawaii	INFINITI M37/M56	Y51	2011.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Hawaii	INFINITI M37/M56	Y51	2011.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI M37/M56	Y51	2011.NULL	EPS/DAST 3	√	√	√	√		
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Motor control	√	√	√	√		
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Hawaii	INFINITI M37/M56	Y51	2011.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Hawaii	INFINITI M37/M56	Y51	2011.NULL	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Pop up hood	√	√	√	√		
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI M37/M56	Y51	2011.NULL	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Hawaii	INFINITI M37/M56	Y51	2011.NULL	HV battery	√	√	√	√	AC1121	
Hawaii	INFINITI M37/M56	Y51	2011.NULL	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Hawaii	INFINITI M37/M56	Y51	2011.NULL	4WAS(front)	√	√	√	√	AC1027,AC1028	
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Hawaii	INFINITI M37/M56	Y51	2011.NULL	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Hawaii	INFINITI M37/M56	Y51	2011.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI M37/M56	Y51	2011.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Hawaii	INFINITI M37/M56	Y51	2011.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Hawaii	INFINITI M37/M56	Y51	2011.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI M37/M56	Y51	2011.NULL	VSP	√	√	√	√	AC1124,AC1125,AC1126	
Hawaii	INFINITI M45	Y34	2003.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Hawaii	INFINITI M45	Y34	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
Hawaii	INFINITI M45	Y34	2003.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Hawaii	INFINITI M45	Y34	2003.NULL	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Hawaii	INFINITI M45	Y34	2003.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI M45	Y34	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Hawaii	INFINITI M45	Y34	2003.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Hawaii	INFINITI M45	Y34	2003.NULL	Motor control						

Hawaii	INFINITI M45	Y34	2003.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI M45	Y34	2003.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Hawaii	INFINITI M45	Y34	2003.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Hawaii	INFINITI M45	Y34	2003.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI M45	Y34	2003.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI M45	Y34	2003.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI M45	Y34	2003.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI M45	Y34	2003.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI M45	Y34	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Hawaii	INFINITI M45	Y34	2003.NULL	DIU		√	√	√		
Hawaii	INFINITI M45	Y34	2003.NULL	Adaptive light	√	√	√	√		
Hawaii	INFINITI M45	Y34	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI M45	Y34	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Hawaii	INFINITI M45	Y34	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI M45	Y34	2003.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hawaii	INFINITI M45	Y34	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Hawaii	INFINITI M45	Y34	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI M45	Y34	2003.NULL	IVMS	√	√		√		
Hawaii	INFINITI M45	Y34	2003.NULL	Distance control	√	√		√		
Hawaii	INFINITI M45	Y34	2003.NULL	Active suspense system	√	√	√	√		
Hawaii	INFINITI M45	Y34	2003.NULL	Motor assist		√	√	√		SP0574
Hawaii	INFINITI M45	Y34	2003.NULL	ASCD	√	√	√	√		
Hawaii	INFINITI M45	Y34	2003.NULL	Active engine mount	√	√	√	√		
Hawaii	INFINITI M45	Y34	2003.NULL	TCS	√	√	√	√		
Hawaii	INFINITI M45	Y34	2003.NULL	S/blind camera	√			√		SP0572, SP0573
Hawaii	INFINITI M45	Y34	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hawaii	INFINITI M45	Y34	2003.NULL	Nats immu	√	√	√			
Hawaii	INFINITI M45	Y34	2003.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI M45	Y34	2003.NULL	Smart entrance						SP0568
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0038, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL	Transmission	√	√	√	√		SP0274
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL	Pop up hood	√	√	√	√		
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI Q40 SEDAN	V36	2015.NULL	Precrash seatbelt	√	√	√	√		
Hawaii	INFINITI Q45	F50	2002.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hawaii	INFINITI Q45	F50	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Hawaii	INFINITI Q45	F50	2002.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hawaii	INFINITI Q45	F50	2002.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hawaii	INFINITI Q45	F50	2002.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI Q45	F50	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Hawaii	INFINITI Q45	F50	2002.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Hawaii	INFINITI Q45	F50	2002.NULL	Motor control						
Hawaii	INFINITI Q45	F50	2002.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI Q45	F50	2002.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Hawaii	INFINITI Q45	F50	2002.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Hawaii	INFINITI Q45	F50	2002.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI Q45	F50	2002.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI Q45	F50	2002.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI Q45	F50	2002.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI Q45	F50	2002.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI Q45	F50	2002.NULL	Auto slide door	√	√	√	√	AC0941	
Hawaii	INFINITI Q45	F50	2002.NULL	DIU		√	√	√		
Hawaii	INFINITI Q45	F50	2002.NULL	Adaptive light	√	√	√	√		
Hawaii	INFINITI Q45	F50	2002.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI Q45	F50	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Hawaii	INFINITI Q45	F50	2002.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI Q45	F50	2002.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hawaii	INFINITI Q45	F50	2002.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Hawaii	INFINITI Q45	F50	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI Q45	F50	2002.NULL	IVMS	√	√		√		
Hawaii	INFINITI Q45	F50	2002.NULL	Distance control	√	√		√		
Hawaii	INFINITI Q45	F50	2002.NULL	Active suspense system	√	√	√	√		
Hawaii	INFINITI Q45	F50	2002.NULL	Motor assist		√	√	√		SP0574
Hawaii	INFINITI Q45	F50	2002.NULL	ASCD	√	√	√	√		
Hawaii	INFINITI Q45	F50	2002.NULL	Active engine mount	√	√	√	√		
Hawaii	INFINITI Q45	F50	2002.NULL	TCS	√	√	√	√		
Hawaii	INFINITI Q45	F50	2002.NULL	S/blind camera	√			√		SP0572, SP0573
Hawaii	INFINITI Q45	F50	2002.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hawaii	INFINITI Q45	F50	2002.NULL	Nats immu	√	√	√			
Hawaii	INFINITI Q45	F50	2002.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI Q45	F50	2002.NULL	Smart entrance						SP0568
Hawaii	INFINITI Q45	FY33	1995.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hawaii	INFINITI Q45	FY33	1995.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Hawaii	INFINITI Q45	FY33	1995.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hawaii	INFINITI Q45	FY33	1995.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hawaii	INFINITI Q45	FY33	1995.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI Q45	FY33	1995.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Hawaii	INFINITI Q45	FY33	1995.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Hawaii	INFINITI Q45	FY33	1995.NULL	Motor control						

Hawaii	INFINITI Q45	FY33	1995.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI Q45	FY33	1995.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Hawaii	INFINITI Q45	FY33	1995.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Hawaii	INFINITI Q45	FY33	1995.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI Q45	FY33	1995.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI Q45	FY33	1995.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI Q45	FY33	1995.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI Q45	FY33	1995.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI Q45	FY33	1995.NULL	Auto slide door	√	√	√	√	AC0941	
Hawaii	INFINITI Q45	FY33	1995.NULL	DIU		√	√	√		
Hawaii	INFINITI Q45	FY33	1995.NULL	Adaptive light	√	√	√	√		
Hawaii	INFINITI Q45	FY33	1995.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI Q45	FY33	1995.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Hawaii	INFINITI Q45	FY33	1995.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI Q45	FY33	1995.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hawaii	INFINITI Q45	FY33	1995.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Hawaii	INFINITI Q45	FY33	1995.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI Q45	FY33	1995.NULL	IVMS	√	√		√		
Hawaii	INFINITI Q45	FY33	1995.NULL	Distance control	√	√		√		
Hawaii	INFINITI Q45	FY33	1995.NULL	Active suspense system	√	√	√	√		
Hawaii	INFINITI Q45	FY33	1995.NULL	Motor assist		√	√	√		SP0574
Hawaii	INFINITI Q45	FY33	1995.NULL	ASCD	√	√	√	√		
Hawaii	INFINITI Q45	FY33	1995.NULL	Active engine mount	√	√	√	√		
Hawaii	INFINITI Q45	FY33	1995.NULL	TCS	√	√	√	√		
Hawaii	INFINITI Q45	FY33	1995.NULL	S/blind camera	√			√		SP0572, SP0573
Hawaii	INFINITI Q45	FY33	1995.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hawaii	INFINITI Q45	FY33	1995.NULL	Nats immu	√	√	√			
Hawaii	INFINITI Q45	FY33	1995.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI Q45	FY33	1995.NULL	Smart entrance						SP0568
Hawaii	INFINITI Q50	V37	2019.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hawaii	INFINITI Q50	V37	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Hawaii	INFINITI Q50	V37	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI Q50	V37	2019.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hawaii	INFINITI Q50	V37	2019.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI Q50	V37	2019.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI Q50	V37	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
Hawaii	INFINITI Q50	V37	2019.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hawaii	INFINITI Q50	V37	2019.NULL	Motor control	√	√	√	√		
Hawaii	INFINITI Q50	V37	2019.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI Q50	V37	2019.NULL	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Hawaii	INFINITI Q50	V37	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Hawaii	INFINITI Q50	V37	2019.NULL_	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hawaii	INFINITI Q50	V37	2019.NULL	Pop up hood	√	√	√	√		
Hawaii	INFINITI Q50	V37	2019.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI Q50	V37	2019.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hawaii	INFINITI Q50	V37	2019.NULL	HV battery	√	√	√	√	AC1121	
Hawaii	INFINITI Q50	V37	2019.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hawaii	INFINITI Q50	V37	2019.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hawaii	INFINITI Q50	V37	2019.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI Q50	V37	2019.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hawaii	INFINITI Q50	V37	2019.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI Q50	V37	2019.NULL	Shift	√	√	√	√		SP0613
Hawaii	INFINITI Q50	V37	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hawaii	INFINITI Q50	V37	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hawaii	INFINITI Q50	V37	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI Q50	V37	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI Q50	V37	2019.NULL	DAST 2	√	√	√	√		
Hawaii	INFINITI Q50	V37	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI Q50	V37	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI Q50	V37	2019.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI Q50	V37	2019.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Hawaii	INFINITI Q50	V37	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI Q50	V37	2019.NULL	DAST 1	√	√	√	√		
Hawaii	INFINITI Q50	V37	2019.NULL_	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Hawaii	INFINITI Q50	V37	2019.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hawaii	INFINITI Q50	V37	2019.NULL	ANC	√	√	√	√	AC1024	
Hawaii	INFINITI Q50	V37	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI Q50	V37	2019.NULL	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Hawaii	INFINITI Q50	V37	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hawaii	INFINITI Q50	V37	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
Hawaii	INFINITI Q50	V37	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI Q50	V37	2019.NULL	Brake	√	√	√	√	AC1127	
Hawaii	INFINITI Q50	V37	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Hawaii	INFINITI Q50	V37	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
Hawaii	INFINITI Q50	V37	2019.NULL	ICC/ADAS 2	√	√	√	√		
Hawaii	INFINITI Q50	V37	2019.NULL	FSCM	√	√	√	√	AC1109	
Hawaii	INFINITI Q50	V37	2019.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Laser/radar	√	√	√	√		
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Motor control	√	√	√	√		
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Transmission	√	√	√	√		SP0274, SP0276
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL_	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Pop up hood	√	√	√	√		
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Multi AV	√	√	√	√		SP0503

Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL
_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	HV battery	√	√	√	√	AC1121	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL
_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Shift	√	√	√	√		SP0613
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	DAST 2	√	√	√	√		
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	DAST 1	√	√	√	√		
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL
_	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	ANC	√	√	√	√	AC1024	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	HIGH BEAM ASSIST	√	√	√	√		
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	Brake	√	√	√	√	AC1127	
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	6ch CAN GATEWAY	√	√	√	√		
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	3ch CAN GATEWAY	√	√	√	√		
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	ICC/ADAS 2	√	√	√	√		
Hawaii	INFINITI Q50 HYBRID	HV37	2014.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Laser/radar	√	√	√	√		
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Air bag	√	√	√	√		
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	EPS/DAST 3	√	√	√	√		
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Motor control	√	√	√	√		
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Transmission	√	√	√	√		SP0276
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Pop up hood	√	√	√	√		
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	HV battery	√	√	√	√	AC1121	
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Occupant detection			√	√		SP0584
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 2	√	√	√	√		
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Lane camera	√	√	√	√		
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 1	√	√	√	√		
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	ANC	√	√	√	√	AC1024	
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	HIGH BEAM ASSIST	√	√	√	√		
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√		
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	Brake	√	√	√	√	AC1127	
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	6ch CAN GATEWAY	√	√	√	√		
Hawaii	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Hawaii	INFINITI Q60	CV37	2019.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hawaii	INFINITI Q60	CV37	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Hawaii	INFINITI Q60	CV37	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI Q60	CV37	2019.NULL
_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hawaii	INFINITI Q60	CV37	2019.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI Q60	CV37	2019.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI Q60	CV37	2019.NULL	EPS/DAST 3	√	√	√	√		
Hawaii	INFINITI Q60	CV37	2019.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hawaii	INFINITI Q60	CV37	2019.NULL
_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI Q60	CV37	2019.NULL	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Hawaii	INFINITI Q60	CV37	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Hawaii	INFINITI Q60	CV37	2019.NULL
_	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hawaii	INFINITI Q60	CV37	2019.NULL	Pop up hood	√	√	√	√		
Hawaii	INFINITI Q60	CV37	2019.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI Q60	CV37	2019.NULL
_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hawaii	INFINITI Q60	CV37	2019.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hawaii	INFINITI Q60	CV37	2019.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI Q60	CV37	2019.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI Q60	CV37	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hawaii	INFINITI Q60	CV37	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hawaii	INFINITI Q60	CV37	2019.NULL	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Hawaii	INFINITI Q60	CV37	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI Q60	CV37	2019.NULL	DAST 2	√	√	√	√		
Hawaii	INFINITI Q60	CV37	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI Q60	CV37	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI Q60	CV37	2019.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI Q60	CV37	2019.NULL	Lane camera	√	√	√	√		
Hawaii	INFINITI Q60	CV37	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI Q60	CV37	2019.NULL	DAST 1	√	√	√	√		
Hawaii	INFINITI Q60	CV37	2019.NULL
_	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Hawaii	INFINITI Q60	CV37	2019.NULL	ANC	√	√	√	√	AC1024	

Hawaii	INFINITI Q60	CV37	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI Q60	CV37	2019.NULL	EMCM	√	√	√	√	AC1111.AC1112	SP0608.SP0609.SP0610
Hawaii	INFINITI Q60	CV37	2019.NULL	Telematics	√	√	√	√		SP0590.SP0591.SP0592
Hawaii	INFINITI Q60	CV37	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
Hawaii	INFINITI Q60	CV37	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI Q60	CV37	2019.NULL	Lane camera 2	√	√	√	√		
Hawaii	INFINITI Q60	CV37	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Hawaii	INFINITI Q60	CV37	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
Hawaii	INFINITI Q60	CV37	2019.NULL	ICC/ADAS 2	√	√	√	√		
Hawaii	INFINITI Q60	CV37	2019.NULL	FSCM	√	√	√	√	AC1109	
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Air bag	√	√	√	√		
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Transmission	√	√	√	√		SP0274
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Pop up hood	√	√	√	√		
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Hawaii	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL _	Precrash seatbelt	√	√	√	√		
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	Meter/M&A	√	√	√	√		SP0347.SP0348.SP0349.SP0350
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL _	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	Transmission	√	√	√	√		SP0274
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL _	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	Pop up hood	√	√	√	√		
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL _	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI Q60 COUPE	CV36	2014.NULL	Precrash seatbelt	√	√	√	√		
Hawaii	INFINITI Q70	Y51	2019.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Hawaii	INFINITI Q70	Y51	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Hawaii	INFINITI Q70	Y51	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI Q70	Y51	2019.NULL _	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Hawaii	INFINITI Q70	Y51	2019.NULL	IPDM E/R	√	√	√	√	AC0811.AC0815.AC0816.AC0817.AC0818.AC0819.AC0821.AC0822.AC0825.AC0831	
Hawaii	INFINITI Q70	Y51	2019.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI Q70	Y51	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
Hawaii	INFINITI Q70	Y51	2019.NULL	Meter/M&A	√	√	√	√		SP0348.SP0349.SP0350.SP0351
Hawaii	INFINITI Q70	Y51	2019.NULL _	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Hawaii	INFINITI Q70	Y51	2019.NULL _	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0247,SP0265,SP0270,SP0274
Hawaii	INFINITI Q70	Y51	2019.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Hawaii	INFINITI Q70	Y51	2019.NULL _	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Hawaii	INFINITI Q70	Y51	2019.NULL	Pop up hood	√	√	√	√		
Hawaii	INFINITI Q70	Y51	2019.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI Q70	Y51	2019.NULL _	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Hawaii	INFINITI Q70	Y51	2019.NULL	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Hawaii	INFINITI Q70	Y51	2019.NULL	4WAS(front)	√	√	√	√	AC1027,AC1028	
Hawaii	INFINITI Q70	Y51	2019.NULL _	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Hawaii	INFINITI Q70	Y51	2019.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI Q70	Y51	2019.NULL	Adaptive light	√	√	√	√	AC0978.AC0979.AC0980.AC0981.AC0982	SP0561.SP0562
Hawaii	INFINITI Q70	Y51	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029.AC1030	
Hawaii	INFINITI Q70	Y51	2019.NULL	Sonar	√	√	√	√	AC0962.AC0963.AC0964.AC0966.AC0967.AC0968.AC0969.AC0970	SP0553.SP0554.SP0555.SP0556.SP0557.SP0558.SP0559
Hawaii	INFINITI Q70	Y51	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI Q70	Y51	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI Q70	Y51	2019.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Hawaii	INFINITI Q70	Y51	2019.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI Q70	Y51	2019.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0976,AC0977	
Hawaii	INFINITI Q70	Y51	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI Q70	Y51	2019.NULL	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Hawaii	INFINITI Q70	Y51	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI Q70	Y51	2019.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Hawaii	INFINITI Q70	Y51	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI Q70	Y51	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Hawaii	INFINITI Q70	Y51	2019.NULL	ICC/ADAS 2	√	√	√	√		
Hawaii	INFINITI Q70	Y51	2019.NULL	FSCM	√	√	√	√	AC1109	
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Laser/radar	√	√	√	√	AC0994	
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	EPS/DAST 3	√	√	√	√		
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Motor control	√	√	√	√		
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	BCM				√	AC0613, AC0618, AC0653, AC0663, AC0690, AC0692, AC0698, AC0702	SP0372, SP0429, SP0471
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Pop up hood	√	√	√	√		
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	HV battery	√	√	√	√	AC1121	
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	EV/HEV	√	√	√	√	AC1084. AC1085. AC1086. AC1087. AC1088. AC1089. AC1106	
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL_	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	Brake	√	√	√	√	AC1127	
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	6ch CAN GATEWAY	√	√	√	√		
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	ICC/ADAS 2	√	√	√	√		
Hawaii	INFINITI Q70 HYBRID	HY51	2014.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Hawaii	INFINITI QX30	H15	2019.NULL	Air pressure monitor	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	EPS/DAST 3	√	√	√			
Hawaii	INFINITI QX30	H15	2019.NULL	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Hawaii	INFINITI QX30	H15	2019.NULL_	Engine	√	√	√	√	AC0002, AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0103, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hawaii	INFINITI QX30	H15	2019.NULL	EHS/PKB	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	Transmission	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL_	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Hawaii	INFINITI QX30	H15	2019.NULL	ABS	√	√	√	√		SP0308
Hawaii	INFINITI QX30	H15	2019.NULL	Multi AV	√	√	√	√		SP0501
Hawaii	INFINITI QX30	H15	2019.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	Auto drive position	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	Shift	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	All mode AWD/4WD	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	AVM	√	√		√		
Hawaii	INFINITI QX30	H15	2019.NULL	Intelligent key	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	CAN gateway	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	ANC	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	Telematics	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	FSCM	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	Siren control unit	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL_	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Hawaii	INFINITI QX30	H15	2019.NULL_	Overhead Control Panel Unit	√			√		
Hawaii	INFINITI QX30	H15	2019.NULL_	Universal Garage Door Opener	√			√		
Hawaii	INFINITI QX30	H15	2019.NULL_	Upper control panel cont unit	√					
Hawaii	INFINITI QX30	H15	2019.NULL_	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Hawaii	INFINITI QX30	H15	2019.NULL_	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Hawaii	INFINITI QX30	H15	2019.NULL	Light/Rain Sensor Module	√			√		
Hawaii	INFINITI QX30	H15	2019.NULL	EC Mirror Compass	√					
Hawaii	INFINITI QX30	H15	2019.NULL_	Intelligent Battery Sensor	√					
Hawaii	INFINITI QX30	H15	2019.NULL	Alarm siren	√			√		
Hawaii	INFINITI QX30	H15	2019.NULL	Radar sensor	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL_	Steering column cont module	√	√	√			
Hawaii	INFINITI QX30	H15	2019.NULL	ICC sensor	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL_	Trailer recognition control unit	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	H/L control module LH	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	Powertrain cont module	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	Side radar LH	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	LED H/L control module LH	√			√		
Hawaii	INFINITI QX30	H15	2019.NULL	Steering Wheel Switch Pad	√			√		
Hawaii	INFINITI QX30	H15	2019.NULL	Parking assist	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL_	Occupant Classification Unit	√			√		
Hawaii	INFINITI QX30	H15	2019.NULL_	Electronic Ignition Switch cont unit	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	H/L control module RH	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	Front camera unit	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	Side radar RH	√	√	√	√		
Hawaii	INFINITI QX30	H15	2019.NULL	LED H/L control module RH	√			√		
Hawaii	INFINITI QX4	JR50	1997.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hawaii	INFINITI QX4	JR50	1997.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Hawaii	INFINITI QX4	JR50	1997.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hawaii	INFINITI QX4	JR50	1997.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hawaii	INFINITI QX4	JR50	1997.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI QX4	JR50	1997.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Hawaii	INFINITI QX4	JR50	1997.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Hawaii	INFINITI QX4	JR50	1997.NULL	Motor control						

Hawaii	INFINITI QX4	JR50	1997.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI QX4	JR50	1997.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Hawaii	INFINITI QX4	JR50	1997.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Hawaii	INFINITI QX4	JR50	1997.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI QX4	JR50	1997.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI QX4	JR50	1997.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI QX4	JR50	1997.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI QX4	JR50	1997.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI QX4	JR50	1997.NULL	Auto slide door	√	√	√	√	AC0941	
Hawaii	INFINITI QX4	JR50	1997.NULL	DIU		√	√	√		
Hawaii	INFINITI QX4	JR50	1997.NULL	Adaptive light	√	√	√	√		
Hawaii	INFINITI QX4	JR50	1997.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI QX4	JR50	1997.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Hawaii	INFINITI QX4	JR50	1997.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI QX4	JR50	1997.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hawaii	INFINITI QX4	JR50	1997.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Hawaii	INFINITI QX4	JR50	1997.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI QX4	JR50	1997.NULL	IVMS	√	√		√		
Hawaii	INFINITI QX4	JR50	1997.NULL	Distance control	√	√		√		
Hawaii	INFINITI QX4	JR50	1997.NULL	Active suspense system	√	√	√	√		
Hawaii	INFINITI QX4	JR50	1997.NULL	Motor assist		√	√	√		SP0574
Hawaii	INFINITI QX4	JR50	1997.NULL	ASCD	√	√	√	√		
Hawaii	INFINITI QX4	JR50	1997.NULL	Active engine mount	√	√	√	√		
Hawaii	INFINITI QX4	JR50	1997.NULL	TCS	√	√	√	√		
Hawaii	INFINITI QX4	JR50	1997.NULL	S/blind camera	√			√		SP0572, SP0573
Hawaii	INFINITI QX4	JR50	1997.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hawaii	INFINITI QX4	JR50	1997.NULL	Nats immu	√	√	√			
Hawaii	INFINITI QX4	JR50	1997.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI QX4	JR50	1997.NULL	Smart entrance						SP0568
Hawaii	INFINITI QX50	J50	2014.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hawaii	INFINITI QX50	J50	2014.NULL	Laser/radar	√	√	√	√	AC0994	
Hawaii	INFINITI QX50	J50	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI QX50	I50	2014.NULL	ICC/ADAS	√	√	√	√	AC0865. AC0866. AC0867. AC0868. AC0876. AC0877. AC0884	SP0494
Hawaii	INFINITI QX50	I50	2014.NULL	IPDM E/R	√	√	√	√	AC0811. AC0815. AC0816. AC0817. AC0818. AC0819. AC0821. AC0822. AC0825. AC0831	
Hawaii	INFINITI QX50	I50	2014.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI QX50	I50	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
Hawaii	INFINITI QX50	J50	2014.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hawaii	INFINITI QX50	J50	2014.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hawaii	INFINITI QX50	J50	2014.NULL	Transmission	√	√	√	√		SP0274
Hawaii	INFINITI QX50	J50	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hawaii	INFINITI QX50	J50	2014.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI QX50	J50	2014.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI QX50	J50	2014.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI QX50	J50	2014.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI QX50	J50	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hawaii	INFINITI QX50	J50	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hawaii	INFINITI QX50	J50	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Hawaii	INFINITI QX50	J50	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI QX50	J50	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI QX50	J50	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI QX50	I50	2014.NULL	Lane camera	√	√	√	√	AC0973. AC0974. AC0976. AC0977	
Hawaii	INFINITI QX50	I50	2014.NULL	BSW/buzzer	√	√	√	√	AC1014. AC1015. AC1016. AC1017. AC1018. AC1019. AC1020. AC1021. AC1022. AC1023	
Hawaii	INFINITI QX50	I50	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI QX50	I50	2014.NULL	Telematics	√	√	√	√		SP0590. SP0591. SP0592
Hawaii	INFINITI QX50	I50	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI QX50	J55	2019.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Hawaii	INFINITI QX50	J55	2019.NULL	Laser/radar	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Hawaii	INFINITI QX50	J55	2019.NULL_	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Hawaii	INFINITI QX50	I55	2019.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL	EPS/DAST 3	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL	Meter/M&A	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hawaii	INFINITI QX50	J55	2019.NULL	EHS/PKB	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL_	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Hawaii	INFINITI QX50	I55	2019.NULL	BCM					AC0618. AC0690. AC0692	SP0390. SP0438. SP0450. SP0458
Hawaii	INFINITI QX50	I55	2019.NULL	ABS	√	√	√	√		SP0313. SP0315
Hawaii	INFINITI QX50	I55	2019.NULL	Total illum C/U	√	√	√	√		
Hawaii	INFINITI QX50	I55	2019.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI QX50	J55	2019.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL	Auto drive position	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL	Auto back door	√	√	√	√		SP0611
Hawaii	INFINITI QX50	J55	2019.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI QX50	J55	2019.NULL	Shift						
Hawaii	INFINITI QX50	J55	2019.NULL	Adaptive light	√	√	√	√		SP0562
Hawaii	INFINITI QX50	J55	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hawaii	INFINITI QX50	J55	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI QX50	J55	2019.NULL	All mode AWD/4WD	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL	DAST 2	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI QX50	J55	2019.NULL	CAN gateway	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL	Lane camera	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL	DAST 1	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL	Chassis control	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL	ANC						
Hawaii	INFINITI QX50	J55	2019.NULL	E-HUD	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI QX50	I55	2019.NULL	Telematics	√	√	√	√		SP0590. SP0591. SP0592
Hawaii	INFINITI QX50	I55	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI QX50	I55	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Hawaii	INFINITI QX50	I55	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
Hawaii	INFINITI QX50	J55	2019.NULL	ICC/ADAS 2	√	√	√	√		
Hawaii	INFINITI QX56	JA60	2004.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hawaii	INFINITI QX56	JA60	2004.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Hawaii	INFINITI QX56	JA60	2004.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hawaii	INFINITI QX56	JA60	2004.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hawaii	INFINITI QX56	JA60	2004.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI QX56	JA60	2004.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507

Hawaii	INFINITI QX56	JA60	2004.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Hawaii	INFINITI QX56	JA60	2004.NULL	Motor control						
Hawaii	INFINITI QX56	JA60	2004.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI QX56	JA60	2004.NULL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Hawaii	INFINITI QX56	JA60	2004.NULL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Hawaii	INFINITI QX56	JA60	2004.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hawaii	INFINITI QX56	JA60	2004.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI QX56	JA60	2004.NULL	HVAC	√	√	√	√		
Hawaii	INFINITI QX56	JA60	2004.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI QX56	JA60	2004.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI QX56	JA60	2004.NULL	Auto slide door	√	√	√	√	AC0941	
Hawaii	INFINITI QX56	JA60	2004.NULL	DIU		√	√	√		
Hawaii	INFINITI QX56	JA60	2004.NULL	Adaptive light	√	√	√	√		
Hawaii	INFINITI QX56	JA60	2004.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI QX56	JA60	2004.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Hawaii	INFINITI QX56	JA60	2004.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI QX56	JA60	2004.NULL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hawaii	INFINITI QX56	JA60	2004.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Hawaii	INFINITI QX56	JA60	2004.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI QX56	JA60	2004.NULL	IVMS	√	√		√		
Hawaii	INFINITI QX56	JA60	2004.NULL	Distance control	√	√		√		
Hawaii	INFINITI QX56	JA60	2004.NULL	Active suspense system	√	√	√	√		
Hawaii	INFINITI QX56	JA60	2004.NULL	Motor assist		√	√	√		SP0574
Hawaii	INFINITI QX56	JA60	2004.NULL	ASCD	√	√	√	√		
Hawaii	INFINITI QX56	JA60	2004.NULL	Active engine mount	√	√	√	√		
Hawaii	INFINITI QX56	JA60	2004.NULL	TCS	√	√	√	√		
Hawaii	INFINITI QX56	JA60	2004.NULL	S/blind camera	√			√		SP0572, SP0573
Hawaii	INFINITI QX56	JA60	2004.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hawaii	INFINITI QX56	JA60	2004.NULL	Nats immu	√	√	√			
Hawaii	INFINITI QX56	JA60	2004.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI QX56	JA60	2004.NULL	Smart entrance						SP0568
Hawaii	INFINITI QX56	Z62	2011.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hawaii	INFINITI QX56	Z62	2011.NULL	Laser/radar	√	√	√	√		
Hawaii	INFINITI QX56	Z62	2011.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI QX56	Z62	2011.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Hawaii	INFINITI QX56	Z62	2011.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI QX56	Z62	2011.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI QX56	Z62	2011.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Hawaii	INFINITI QX56	Z62	2011.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hawaii	INFINITI QX56	Z62	2011.NULL	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Hawaii	INFINITI QX56	Z62	2011.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Hawaii	INFINITI QX56	Z62	2011.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Hawaii	INFINITI QX56	Z62	2011.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI QX56	Z62	2011.NULL	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0476, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488, SP0489, SP0490
Hawaii	INFINITI QX56	Z62	2011.NULL	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Hawaii	INFINITI QX56	Z62	2011.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI QX56	Z62	2011.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI QX56	Z62	2011.NULL	Auto back door	√	√	√	√		
Hawaii	INFINITI QX56	Z62	2011.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI QX56	Z62	2011.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hawaii	INFINITI QX56	Z62	2011.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hawaii	INFINITI QX56	Z62	2011.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Hawaii	INFINITI QX56	Z62	2011.NULL	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Hawaii	INFINITI QX56	Z62	2011.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI QX56	Z62	2011.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI QX56	Z62	2011.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI QX56	Z62	2011.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Hawaii	INFINITI QX56	Z62	2011.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI QX56	Z62	2011.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hawaii	INFINITI QX56	Z62	2011.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI QX56	Z62	2011.NULL	Rearview camera	√			√		SP0570, SP0571
Hawaii	INFINITI QX60	L50	2019.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hawaii	INFINITI QX60	L50	2019.2-	Laser/radar	√	√	√	√	AC0994	
Hawaii	INFINITI QX60	L50	2019.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI QX60	L50	2019.2-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hawaii	INFINITI QX60	L50	2019.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hawaii	INFINITI QX60	L50	2019.2-	Air bag	√	√	√	√		
Hawaii	INFINITI QX60	L50	2019.2-	EPS/DAST 3	√	√	√	√		
Hawaii	INFINITI QX60	L50	2019.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hawaii	INFINITI QX60	L50	2019.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hawaii	INFINITI QX60	L50	2019.2-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Hawaii	INFINITI QX60	L50	2019.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Hawaii	INFINITI QX60	L50	2019.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hawaii	INFINITI QX60	L50	2019.2-	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI QX60	L50	2019.2-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Hawaii	INFINITI QX60	L50	2019.2-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hawaii	INFINITI QX60	L50	2019.2-	Auto back door	√	√	√	√		SP0611
Hawaii	INFINITI QX60	L50	2019.2-	Occupant detection			√	√		SP0584
Hawaii	INFINITI QX60	L50	2019.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hawaii	INFINITI QX60	L50	2019.2-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hawaii	INFINITI QX60	L50	2019.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI QX60	L50	2019.2-	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI QX60	L50	2019.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hawaii	INFINITI QX60	L50	2019.2-	CAN gateway	√	√	√			
Hawaii	INFINITI QX60	L50	2019.2-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
Hawaii	INFINITI QX60	L50	2019.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hawaii	INFINITI QX60	L50	2019.2-	ANC	√	√	√	√	AC1024	
Hawaii	INFINITI QX60	L50	2019.2-	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI QX60	L50	2019.2-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hawaii	INFINITI QX60	L50	2019.2-	HIGH BEAM ASSIST	√	√	√	√		
Hawaii	INFINITI QX60	L50	2019.2-	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI QX60	L50	2019.2-	3ch CAN GATEWAY	√	√	√	√		
Hawaii	INFINITI QX60	L50	2019.2-	ICC/ADAS 2	√	√	√	√		
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Laser/radar	√	√	√	√		
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	IPDM E/R	√	√	√	√	AC0811.AC0815.AC0816.AC0817.AC0818.AC0819.AC0821.AC0822.AC0825.AC0831	
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	EPS/DAST 3	√	√	√	√		
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Meter/M&A	√	√	√	√		SP0348.SP0349.SP0350.SP0351
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Motor control	√	√	√	√		
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL_	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0038,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL_	Transmission	√	√	√	√	AC0439	SP0246,SP0276,SP0279,SP0281,SP0282,SP0283,SP0287,SP0289,SP0290,SP0292
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	HVAC	√	√	√	√	AC0808.AC0809	SP0472.SP0473.SP0474.SP0475.SP0477.SP0478.SP0483.SP0487
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	HV battery	√	√	√	√	AC1121	
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Auto drive position	√	√	√	√	AC0946.AC0947.AC0948.AC0950.AC0951.AC0952.AC0953.AC0954.AC0955	SP0541.SP0542.SP0543
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Auto back door	√	√	√	√		SP0611
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	EV/HEV	√	√	√	√	AC1081,AC1084,AC1085,AC1086,AC1087,AC1088,AC1089	
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0976,AC0977	
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	ANC	√	√	√	√		
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	HIGH BEAM ASSIST	√	√	√	√		
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	ICC/ADAS 2	√	√	√	√		
Hawaii	INFINITI QX60 HYBRID	HL50	2014.NULL	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Hawaii	INFINITI QX70	S51	2014.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Hawaii	INFINITI QX70	S51	2014.NULL	Laser/radar	√	√	√	√	AC0994	
Hawaii	INFINITI QX70	S51	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI QX70	S51	2014.NULL	ICC/ADAS	√	√	√	√	AC0865.AC0866.AC0867.AC0868.AC0876.AC0877.AC0884	SP0494
Hawaii	INFINITI QX70	S51	2014.NULL	IPDM E/R	√	√	√	√	AC0811.AC0815.AC0816.AC0817.AC0818.AC0819.AC0821.AC0822.AC0825.AC0831	
Hawaii	INFINITI QX70	S51	2014.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI QX70	S51	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
Hawaii	INFINITI QX70	S51	2014.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Hawaii	INFINITI QX70	S51	2014.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Hawaii	INFINITI QX70	S51	2014.NULL	Transmission	√	√	√	√		SP0274
Hawaii	INFINITI QX70	S51	2014.NULL	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Hawaii	INFINITI QX70	S51	2014.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Hawaii	INFINITI QX70	S51	2014.NULL	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Hawaii	INFINITI QX70	S51	2014.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI QX70	S51	2014.NULL	E-SUS	√	√	√	√	AC1034.AC1035.AC1036.AC1037.AC1038.AC1039	
Hawaii	INFINITI QX70	S51	2014.NULL	4WAS(front)	√	√	√	√	AC1027.AC1028	
Hawaii	INFINITI QX70	S51	2014.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Hawaii	INFINITI QX70	S51	2014.NULL	Auto back door	√	√	√	√		SP0611
Hawaii	INFINITI QX70	S51	2014.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI QX70	S51	2014.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Hawaii	INFINITI QX70	S51	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Hawaii	INFINITI QX70	S51	2014.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0555,SP0556,SP0557
Hawaii	INFINITI QX70	S51	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Hawaii	INFINITI QX70	S51	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI QX70	S51	2014.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Hawaii	INFINITI QX70	S51	2014.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI QX70	S51	2014.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Hawaii	INFINITI QX70	S51	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hawaii	INFINITI QX80	Z62	2019.NULL	Air pressure monitor	√	√	√	√	AC0894.AC0895.AC0896.AC0897.AC0898.AC0899.AC0900.AC0901.AC0902	SP0508.SP0509.SP0510
Hawaii	INFINITI QX80	Z62	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Hawaii	INFINITI QX80	Z62	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hawaii	INFINITI QX80	Z62	2019.NULL_	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Hawaii	INFINITI QX80	Z62	2019.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Hawaii	INFINITI QX80	Z62	2019.NULL	Air bag	√	√	√	√		
Hawaii	INFINITI QX80	Z62	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
Hawaii	INFINITI QX80	Z62	2019.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350,SP0351
Hawaii	INFINITI QX80	Z62	2019.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Hawaii	INFINITI QX80	Z62	2019.NULL_	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Hawaii	INFINITI QX80	Z62	2019.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Hawaii	INFINITI QX80	Z62	2019.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Hawaii	INFINITI QX80	Z62	2019.NULL	Multi AV	√	√	√	√		SP0503
Hawaii	INFINITI QX80	Z62	2019.NULL_	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0484,SP0485,SP0486,SP0487,SP0488
Hawaii	INFINITI QX80	Z62	2019.NULL	E-SUS	√	√	√	√	AC1031,AC1032,AC1033	SP0585,SP0586,SP0587
Hawaii	INFINITI QX80	Z62	2019.NULL	Difference lock	√	√	√	√		
Hawaii	INFINITI QX80	Z62	2019.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Hawaii	INFINITI QX80	Z62	2019.NULL	Auto back door	√	√	√	√		
Hawaii	INFINITI QX80	Z62	2019.NULL	Occupant detection			√	√		SP0584
Hawaii	INFINITI QX80	Z62	2019.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Hawaii	INFINITI QX80	Z62	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Hawaii	INFINITI QX80	Z62	2019.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Hawaii	INFINITI QX80	Z62	2019.NULL	All mode AWD/4WD	√	√	√	√		SP0544,SP0545,SP0546,SP0547,SP0548,SP0549
Hawaii	INFINITI QX80	Z62	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Hawaii	INFINITI QX80	Z62	2019.NULL	AVM	√	√	√	√	AC0983.AC0984.AC0985.AC0986.AC0987.AC0988.AC0989.AC0990	SP0563.SP0564.SP0565.SP0566.SP0567
Hawaii	INFINITI QX80	Z62	2019.NULL_	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932,AC0933,AC0934,AC0935	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Hawaii	INFINITI QX80	Z62	2019.NULL	CAN gateway	√	√	√			
Hawaii	INFINITI QX80	Z62	2019.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Hawaii	INFINITI QX80	Z62	2019.NULL	BSW/buzzer	√	√	√	√	AC1014.AC1015.AC1016.AC1017.AC1018.AC1019.AC1020.AC1021	
Hawaii	INFINITI QX80	Z62	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Hawaii	INFINITI QX80	Z62	2019.NULL	Telematics	√	√	√	√		SP0590.SP0591.SP0592
Hawaii	INFINITI QX80	Z62	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
Hawaii	INFINITI QX80	Z62	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Hawaii	INFINITI QX80	Z62	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Hawaii	INFINITI QX80	Z62	2019.NULL	ICC/ADAS 2	√	√	√	√		
Hawaii	INFINITI QX80	Z62	2019.NULL	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Holland	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Holland	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Holland	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Holland	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Holland	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350

Holland	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Holland	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Holland	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Holland	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Holland	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Holland	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Holland	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Holland	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Holland	INFINITI EX35/EX30D	I50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Holland	INFINITI EX35/EX30D	I50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Holland	INFINITI EX35/EX30D	I50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Holland	INFINITI EX35/EX30D	I50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Holland	INFINITI EX35/EX30D	I50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Holland	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Holland	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Holland	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Holland	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Holland	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Holland	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Holland	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Holland	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Holland	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Holland	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Holland	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Holland	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Holland	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Holland	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Holland	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Holland	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Holland	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Holland	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Holland	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Holland	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Holland	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Holland	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Holland	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Holland	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Holland	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Holland	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Holland	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Holland	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Holland	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Holland	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Holland	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Holland	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Holland	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Holland	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Holland	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Holland	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Holland	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Holland	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Holland	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611

Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Holland	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Holland	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Holland	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Holland	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Holland	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Holland	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Holland	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Holland	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Holland	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Holland	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Holland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Holland	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Holland	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Holland	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Holland	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Holland	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Holland	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Holland	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Holland	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Holland	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Holland	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Holland	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Holland	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Holland	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Holland	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Holland	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Holland	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Holland	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Holland	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Holland	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Holland	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Holland	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Holland	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Holland	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Holland	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Holland	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Holland	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Holland	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Holland	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Holland	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Holland	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Holland	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Holland	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Holland	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Holland	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Holland	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Holland	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Holland	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Holland	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Holland	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Holland	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Holland	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Holland	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Holland	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Holland	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Holland	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Holland	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Holland	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Holland	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Holland	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Holland	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Holland	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Holland	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Holland	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Holland	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Holland	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Holland	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Holland	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Holland	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Holland	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Holland	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Holland	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Holland	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Holland	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Holland	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Holland	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Holland	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Holland	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Holland	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	

Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Holland	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Holland	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Holland	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Holland	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Holland	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Holland	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Holland	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Holland	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Holland	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Holland	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Holland	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Holland	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Holland	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Holland	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Holland	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Holland	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Holland	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Holland	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Holland	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Holland	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Holland	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Holland	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Holland	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Holland	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Holland	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Holland	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Holland	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Holland	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Holland	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Holland	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Holland	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Holland	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Holland	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Holland	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Holland	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Holland	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Holland	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Holland	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		

XTOOL

Holland	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Holland	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Holland	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Holland	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Holland	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Holland	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Holland	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Holland	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Holland	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Holland	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Holland	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247,SP0265,SP0274,SP0276
Holland	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Holland	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Holland	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Holland	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Holland	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Holland	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Holland	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Holland	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Holland	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Holland	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561, SP0562
Holland	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Holland	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Holland	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Holland	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Holland	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Holland	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Holland	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Holland	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Holland	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Holland	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Holland	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Holland	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Holland	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Holland	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Holland	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Holland	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Holland	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Holland	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Holland	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Holland	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Holland	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Holland	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Holland	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Holland	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Holland	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Holland	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247,SP0265,SP0274,SP0276
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Holland	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Holland	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Holland	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Holland	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Holland	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Holland	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Holland	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Holland	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Holland	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Holland	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Holland	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Holland	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Holland	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Holland	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Holland	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Holland	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Holland	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Holland	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Holland	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Holland	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Holland	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Holland	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Holland	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Holland	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Holland	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Holland	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Holland	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Holland	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Holland	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Holland	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Holland	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Holland	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Holland	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Holland	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Holland	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Holland	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Holland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Holland	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Holland	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Holland	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Holland	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Holland	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Holland	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Holland	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Holland	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Holland	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Holland	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Holland	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Holland	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Holland	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Holland	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Holland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Holland	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Holland	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Holland	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Holland	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Holland	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Holland	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Holland	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Holland	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Holland	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Holland	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Holland	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Holland	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Holland	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Holland	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Holland	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Holland	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Holland	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Holland	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Holland	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Holland	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Holland	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Holland	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Holland	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Holland	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Holland	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Holland	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Holland	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Holland	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Holland	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Holland	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Holland	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Holland	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503

Holland	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Holland	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Holland	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Holland	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Holland	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Holland	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Holland	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Holland	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Holland	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Holland	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Holland	INFINITI QX50	I50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Holland	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Holland	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI QX50	I50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Holland	INFINITI QX50	I50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Holland	INFINITI QX50	I50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Holland	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Holland	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Holland	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Holland	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Holland	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Holland	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Holland	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Holland	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Holland	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Holland	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Holland	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Holland	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Holland	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Holland	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Holland	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Holland	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Holland	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Holland	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Holland	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Holland	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Holland	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Holland	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Holland	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Holland	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Holland	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Holland	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Holland	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Holland	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Holland	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Holland	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Holland	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Holland	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Holland	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Holland	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Holland	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Holland	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Holland	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Holland	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Holland	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Holland	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Holland	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Holland	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Holland	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Holland	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Holland	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Holland	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Holland	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Holland	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Holland	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Holland	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Holland	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Holland	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Holland	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Holland	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Holland	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Holland	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583

Holland	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Honduras	INFINITI EX35/EX37	I50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Honduras	INFINITI EX35/EX37	I50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Honduras	INFINITI EX35/EX37	I50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Honduras	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Honduras	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Honduras	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Honduras	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Honduras	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Honduras	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Honduras	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Honduras	INFINITI EX35/EX37	I50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Honduras	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Honduras	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Honduras	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Honduras	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Honduras	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Honduras	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Honduras	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Honduras	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Honduras	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Honduras	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Honduras	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Honduras	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Honduras	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Honduras	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Honduras	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Honduras	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Honduras	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Honduras	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Honduras	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Honduras	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Honduras	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Honduras	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Honduras	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Honduras	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Honduras	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Honduras	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Honduras	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Honduras	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Honduras	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Honduras	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Honduras	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Honduras	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Honduras	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		

Xtool

Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561, SP0562
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Honduras	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Honduras	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Honduras	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Honduras	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Honduras	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Honduras	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Honduras	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Honduras	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Honduras	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Honduras	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Honduras	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Honduras	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Honduras	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Honduras	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Honduras	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Honduras	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Honduras	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Honduras	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Honduras	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Honduras	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Honduras	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Honduras	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Honduras	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Honduras	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Honduras	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Honduras	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Honduras	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Honduras	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Honduras	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Honduras	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Honduras	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Honduras	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Honduras	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Honduras	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Honduras	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Honduras	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Honduras	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Honduras	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Honduras	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Honduras	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Honduras	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Honduras	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Honduras	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Honduras	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Honduras	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Honduras	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Honduras	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Honduras	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Honduras	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Honduras	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Honduras	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Honduras	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Honduras	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Honduras	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Honduras	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Honduras	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Honduras	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Honduras	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Honduras	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Honduras	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Honduras	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Honduras	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Honduras	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Honduras	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Honduras	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Honduras	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Honduras	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Honduras	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Honduras	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Honduras	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Honduras	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Honduras	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Honduras	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Honduras	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Honduras	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Honduras	INFINITI Q45	F50	2001.8-	Motor control						
Honduras	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Honduras	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Honduras	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Honduras	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Honduras	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Honduras	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Honduras	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Honduras	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Honduras	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Honduras	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Honduras	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Honduras	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Honduras	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Honduras	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Honduras	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Honduras	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Honduras	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Honduras	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Honduras	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Honduras	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Honduras	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Honduras	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Honduras	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Honduras	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Honduras	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Honduras	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Honduras	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Honduras	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Honduras	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Honduras	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Honduras	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Honduras	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Honduras	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Honduras	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Honduras	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Honduras	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Honduras	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Honduras	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Honduras	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Honduras	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Honduras	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Honduras	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Honduras	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Honduras	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Honduras	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Honduras	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Honduras	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Honduras	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Honduras	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Honduras	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Honduras	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Honduras	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Honduras	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Honduras	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Honduras	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hong kong	INFINITI FX35/FX50	S51	2012.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hong kong	INFINITI FX35/FX50	S51	2012.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Air bag	√	√	√	√		
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Transmission	√	√	√	√		SP0274
Hong kong	INFINITI FX35/FX50	S51	2012.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hong kong	INFINITI FX35/FX50	S51	2012.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI FX35/FX50	S51	2012.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Auto back door	√	√	√	√		SP0611
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Occupant detection			√	√		SP0584
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Hong kong	INFINITI FX35/FX50	S51	2012.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Precrash seatbelt	√	√	√	√		SP0612
Hong kong	INFINITI FX35/FX50	S51	2012.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Hong kong	INFINITI FX35/FX50	S51	2012.8-	CAN gateway	√	√	√			
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Hong kong	INFINITI FX35/FX50	S51	2012.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hong kong	INFINITI FX35/FX50	S51	2012.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hong kong	INFINITI FX37/FX50	S51	2012.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hong kong	INFINITI FX37/FX50	S51	2012.12-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Hong kong	INFINITI FX37/FX50	S51	2012.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hong kong	INFINITI FX37/FX50	S51	2012.12-	Air bag	√	√	√	√		
Hong kong	INFINITI FX37/FX50	S51	2012.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
Hong kong	INFINITI FX37/FX50	S51	2012.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hong kong	INFINITI FX37/FX50	S51	2012.12-	Transmission	√	√	√	√		SP0274
Hong kong	INFINITI FX37/FX50	S51	2012.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hong kong	INFINITI FX37/FX50	S51	2012.12-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Hong kong	INFINITI FX37/FX50	S51	2012.12-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Hong kong	INFINITI FX37/FX50	S51	2012.12-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI FX37/FX50	S51	2012.12-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hong kong	INFINITI FX37/FX50	S51	2012.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI FX37/FX50	S51	2012.12-	Auto back door	√	√	√	√		SP0611
Hong kong	INFINITI FX37/FX50	S51	2012.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hong kong	INFINITI FX37/FX50	S51	2012.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hong kong	INFINITI FX37/FX50	S51	2012.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hong kong	INFINITI FX37/FX50	S51	2012.12-	All mode AWD/4WD	√	√	√	√	AC0956	

Hong kong	INFINITI FX37/FX50	S51	2012.12-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Hong kong	INFINITI FX37/FX50	S51	2012.12-	CAN gateway	√	√	√			
Hong kong	INFINITI FX37/FX50	S51	2012.12-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Hong kong	INFINITI FX37/FX50	S51	2012.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hong kong	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hong kong	INFINITI M25/M37	Y51	2012.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hong kong	INFINITI M25/M37	Y51	2012.4-	Laser/radar	√	√	√	√		
Hong kong	INFINITI M25/M37	Y51	2012.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hong kong	INFINITI M25/M37	Y51	2012.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Hong kong	INFINITI M25/M37	Y51	2012.4-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hong kong	INFINITI M25/M37	Y51	2012.4-	Air bag	√	√	√	√		
Hong kong	INFINITI M25/M37	Y51	2012.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hong kong	INFINITI M25/M37	Y51	2012.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hong kong	INFINITI M25/M37	Y51	2012.4-	Transmission	√	√	√	√		SP0274
Hong kong	INFINITI M25/M37	Y51	2012.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Hong kong	INFINITI M25/M37	Y51	2012.4-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Hong kong	INFINITI M25/M37	Y51	2012.4-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI M25/M37	Y51	2012.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hong kong	INFINITI M25/M37	Y51	2012.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hong kong	INFINITI M25/M37	Y51	2012.4-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI M25/M37	Y51	2012.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hong kong	INFINITI M25/M37	Y51	2012.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hong kong	INFINITI M25/M37	Y51	2012.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hong kong	INFINITI M25/M37	Y51	2012.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Hong kong	INFINITI M25/M37	Y51	2012.4-	CAN gateway	√	√	√			
Hong kong	INFINITI M25/M37	Y51	2012.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Hong kong	INFINITI M25/M37	Y51	2012.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hong kong	INFINITI M25/M37	Y51	2012.4-	Side radar left	√	√	√	√	AC1025	SP0582
Hong kong	INFINITI M25/M37	Y51	2012.4-	Side radar right	√	√	√	√	AC1026	SP0583
Hong kong	INFINITI M35H	HY51	2012.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hong kong	INFINITI M35H	HY51	2012.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hong kong	INFINITI M35H	HY51	2012.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hong kong	INFINITI M35H	HY51	2012.7-	Air bag	√	√	√	√		
Hong kong	INFINITI M35H	HY51	2012.7-	EPS/DAST 3	√	√	√	√		
Hong kong	INFINITI M35H	HY51	2012.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hong kong	INFINITI M35H	HY51	2012.7-	Motor control	√	√	√	√		
Hong kong	INFINITI M35H	HY51	2012.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hong kong	INFINITI M35H	HY51	2012.7-	Transmission	√	√	√	√		SP0274, SP0276
Hong kong	INFINITI M35H	HY51	2012.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Hong kong	INFINITI M35H	HY51	2012.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Hong kong	INFINITI M35H	HY51	2012.7-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI M35H	HY51	2012.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hong kong	INFINITI M35H	HY51	2012.7-	HV battery	√	√	√	√	AC1121	
Hong kong	INFINITI M35H	HY51	2012.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI M35H	HY51	2012.7-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hong kong	INFINITI M35H	HY51	2012.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hong kong	INFINITI M35H	HY51	2012.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hong kong	INFINITI M35H	HY51	2012.7-	Precrash seatbelt	√	√	√	√		SP0612
Hong kong	INFINITI M35H	HY51	2012.7-	CAN gateway	√	√	√			
Hong kong	INFINITI M35H	HY51	2012.7-	Brake	√	√	√	√	AC1127	
Hong kong	INFINITI M35H	HY51	2012.7-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Hong kong	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Hong kong	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Hong kong	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Hong kong	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Hong kong	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Hong kong	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Hong kong	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Hong kong	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	

Hong kong	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Hong kong	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Hong kong	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Hong kong	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Hong kong	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Hong kong	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Hong kong	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Hong kong	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Hong kong	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Hong kong	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Hong kong	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Hong kong	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Hong kong	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Hong kong	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Hong kong	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hong kong	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Hong kong	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Hong kong	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Hong kong	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Hong kong	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Hong kong	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Hong kong	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Hong kong	INFINITI Q45	F50	ALL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hong kong	INFINITI Q45	F50	ALL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Hong kong	INFINITI Q45	F50	ALL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hong kong	INFINITI Q45	F50	ALL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hong kong	INFINITI Q45	F50	ALL	Air bag	√	√	√	√		
Hong kong	INFINITI Q45	F50	ALL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Hong kong	INFINITI Q45	F50	ALL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Hong kong	INFINITI Q45	F50	ALL	Motor control						
Hong kong	INFINITI Q45	F50	ALL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hong kong	INFINITI Q45	F50	ALL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Hong kong	INFINITI Q45	F50	ALL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Hong kong	INFINITI Q45	F50	ALL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hong kong	INFINITI Q45	F50	ALL	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI Q45	F50	ALL	HVAC	√	√	√	√		

Hong kong	INFINITI Q45	F50	ALL	Difference lock	√	√	√	√		
Hong kong	INFINITI Q45	F50	ALL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI Q45	F50	ALL	Auto slide door	√	√	√	√	AC0941	
Hong kong	INFINITI Q45	F50	ALL	DIU		√	√	√		
Hong kong	INFINITI Q45	F50	ALL	Adaptive light	√	√	√	√		
Hong kong	INFINITI Q45	F50	ALL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hong kong	INFINITI Q45	F50	ALL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Hong kong	INFINITI Q45	F50	ALL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hong kong	INFINITI Q45	F50	ALL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hong kong	INFINITI Q45	F50	ALL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Hong kong	INFINITI Q45	F50	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hong kong	INFINITI Q45	F50	ALL	IVMS	√	√		√		
Hong kong	INFINITI Q45	F50	ALL	Distance control	√	√		√		
Hong kong	INFINITI Q45	F50	ALL	Active suspense system	√	√	√	√		
Hong kong	INFINITI Q45	F50	ALL	Motor assist		√	√	√		SP0574
Hong kong	INFINITI Q45	F50	ALL	ASCD	√	√	√	√		
Hong kong	INFINITI Q45	F50	ALL	Active engine mount	√	√	√	√		
Hong kong	INFINITI Q45	F50	ALL	TCS	√	√	√	√		
Hong kong	INFINITI Q45	F50	ALL	S/blind camera	√			√		SP0572, SP0573
Hong kong	INFINITI Q45	F50	ALL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hong kong	INFINITI Q45	F50	ALL	Nats immu	√	√	√			
Hong kong	INFINITI Q45	F50	ALL	Rearview camera	√			√		SP0570, SP0571
Hong kong	INFINITI Q45	F50	ALL	Smart entrance						SP0568
Hong kong	INFINITI Q50	V37	2014.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hong kong	INFINITI Q50	V37	2014.1-	Laser/radar	√	√	√	√	AC0994	
Hong kong	INFINITI Q50	V37	2014.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hong kong	INFINITI Q50	V37	2014.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hong kong	INFINITI Q50	V37	2014.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hong kong	INFINITI Q50	V37	2014.1-	Air bag	√	√	√	√		
Hong kong	INFINITI Q50	V37	2014.1-	EPS/DAST 3	√	√	√	√		SP0507
Hong kong	INFINITI Q50	V37	2014.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hong kong	INFINITI Q50	V37	2014.1-	Motor control	√	√	√	√		
Hong kong	INFINITI Q50	V37	2014.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hong kong	INFINITI Q50	V37	2014.1-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Hong kong	INFINITI Q50	V37	2014.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Hong kong	INFINITI Q50	V37	2014.1-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hong kong	INFINITI Q50	V37	2014.1-	Pop up hood	√	√	√	√		
Hong kong	INFINITI Q50	V37	2014.1-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI Q50	V37	2014.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hong kong	INFINITI Q50	V37	2014.1-	HV battery	√	√	√	√	AC1121	
Hong kong	INFINITI Q50	V37	2014.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hong kong	INFINITI Q50	V37	2014.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hong kong	INFINITI Q50	V37	2014.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI Q50	V37	2014.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hong kong	INFINITI Q50	V37	2014.1-	Occupant detection			√	√		SP0584
Hong kong	INFINITI Q50	V37	2014.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hong kong	INFINITI Q50	V37	2014.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hong kong	INFINITI Q50	V37	2014.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hong kong	INFINITI Q50	V37	2014.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Hong kong	INFINITI Q50	V37	2014.1-	DAST 2	√	√	√	√		
Hong kong	INFINITI Q50	V37	2014.1-	Precrash seatbelt	√	√	√	√		SP0612
Hong kong	INFINITI Q50	V37	2014.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hong kong	INFINITI Q50	V37	2014.1-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Hong kong	INFINITI Q50	V37	2014.1-	CAN gateway	√	√	√			
Hong kong	INFINITI Q50	V37	2014.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Hong kong	INFINITI Q50	V37	2014.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hong kong	INFINITI Q50	V37	2014.1-	DAST 1	√	√	√	√		
Hong kong	INFINITI Q50	V37	2014.1-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Hong kong	INFINITI Q50	V37	2014.1-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Hong kong	INFINITI Q50	V37	2014.1-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Hong kong	INFINITI Q50	V37	2014.1-	ANC	√	√	√	√	AC1024	
Hong kong	INFINITI Q50	V37	2014.1-	Side radar left	√	√	√	√	AC1025	SP0582
Hong kong	INFINITI Q50	V37	2014.1-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Hong kong	INFINITI Q50	V37	2014.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hong kong	INFINITI Q50	V37	2014.1-	HIGH BEAM ASSIST	√	√	√	√		
Hong kong	INFINITI Q50	V37	2014.1-	Side radar right	√	√	√	√	AC1026	SP0583
Hong kong	INFINITI Q50	V37	2014.1-	CAN monitor unit	√	√	√	√		
Hong kong	INFINITI Q50	V37	2014.1-	Brake	√	√	√	√	AC1127	
Hong kong	INFINITI Q50	V37	2014.1-	HDmap	√	√	√	√		
Hong kong	INFINITI Q50	V37	2014.1-	6ch CAN GATEWAY	√	√	√	√		
Hong kong	INFINITI Q50	V37	2014.1-	3ch CAN GATEWAY	√	√	√	√		
Hong kong	INFINITI Q50	V37	2014.1-	ICC/ADAS 2	√	√	√	√		
Hong kong	INFINITI Q50	V37	2014.1-	PMAS	√	√	√	√		
Hong kong	INFINITI Q50	V37	2014.1-	FSCM	√	√	√	√	AC1109	
Hong kong	INFINITI Q50	V37	2014.1-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Laser/radar	√	√	√	√	AC0994	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Air bag	√	√	√	√		
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Motor control	√	√	√	√		
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Pop up hood	√	√	√	√		
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	HV battery	√	√	√	√	AC1121	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Occupant detection			√	√		SP0584
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	DAST 2	√	√	√	√		
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Precrash seatbelt	√	√	√	√		SP0612

Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	CAN gateway	√	√	√			
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	DAST 1	√	√	√	√		
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	ANC	√	√	√	√	AC1024	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	CAN monitor unit	√	√	√	√		
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	VSP	√	√	√	√		
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Brake	√	√	√	√	AC1127	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	HDmap	√	√	√	√		
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	6ch CAN GATEWAY	√	√	√	√		
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	ICC/ADAS 2	√	√	√	√		
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	FSCM	√	√	√	√	AC1109	
Hong kong	INFINITI Q50 HYBRID	HV37	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Hong kong	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hong kong	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Hong kong	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hong kong	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hong kong	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hong kong	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Hong kong	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Hong kong	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hong kong	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hong kong	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Hong kong	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Hong kong	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hong kong	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Hong kong	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hong kong	INFINITI Q60	CV37	2016.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hong kong	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Hong kong	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hong kong	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hong kong	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hong kong	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Hong kong	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Hong kong	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Hong kong	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hong kong	INFINITI Q60	CV37	2016.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Hong kong	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Hong kong	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Hong kong	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hong kong	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Hong kong	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Hong kong	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Hong kong	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Hong kong	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Hong kong	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hong kong	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Hong kong	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Hong kong	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Hong kong	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Hong kong	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Hong kong	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Laser/radar	√	√	√	√	AC0994	
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Air bag	√	√	√	√		
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Transmission	√	√	√	√		SP0274
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Pop up hood	√	√	√	√		
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Precrash seatbelt	√	√	√	√		
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hong kong	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hong kong	INFINITI Q70	Y51	2013.11-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hong kong	INFINITI Q70	Y51	2013.11-	Laser/radar	√	√	√	√	AC0994	
Hong kong	INFINITI Q70	Y51	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Hong kong	INFINITI Q70	Y51	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hong kong	INFINITI Q70	Y51	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hong kong	INFINITI Q70	Y51	2013.11-	Air bag	√	√	√	√		
Hong kong	INFINITI Q70	Y51	2013.11-	EPS/DAST 3	√	√	√	√		
Hong kong	INFINITI Q70	Y51	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hong kong	INFINITI Q70	Y51	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hong kong	INFINITI Q70	Y51	2013.11-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Hong kong	INFINITI Q70	Y51	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Hong kong	INFINITI Q70	Y51	2013.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Hong kong	INFINITI Q70	Y51	2013.11-	Pop up hood	√	√	√	√		
Hong kong	INFINITI Q70	Y51	2013.11-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI Q70	Y51	2013.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hong kong	INFINITI Q70	Y51	2013.11-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hong kong	INFINITI Q70	Y51	2013.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hong kong	INFINITI Q70	Y51	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI Q70	Y51	2013.11-	Occupant detection			√	√		SP0584
Hong kong	INFINITI Q70	Y51	2013.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hong kong	INFINITI Q70	Y51	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hong kong	INFINITI Q70	Y51	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hong kong	INFINITI Q70	Y51	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Hong kong	INFINITI Q70	Y51	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Hong kong	INFINITI Q70	Y51	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hong kong	INFINITI Q70	Y51	2013.11-	CAN gateway	√	√	√	√		
Hong kong	INFINITI Q70	Y51	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Hong kong	INFINITI Q70	Y51	2013.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hong kong	INFINITI Q70	Y51	2013.11-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Hong kong	INFINITI Q70	Y51	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hong kong	INFINITI Q70	Y51	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Hong kong	INFINITI Q70	Y51	2013.11-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Hong kong	INFINITI Q70	Y51	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hong kong	INFINITI Q70	Y51	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Hong kong	INFINITI Q70	Y51	2013.11-	6ch CAN GATEWAY	√	√	√	√		
Hong kong	INFINITI Q70	Y51	2013.11-	FSCM	√	√	√	√	AC1109	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√		SP0274, SP0276
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√	√		
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	ANC	√	√	√	√	AC1024	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	FSCM	√	√	√	√	AC1109	
Hong kong	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Hong kong	INFINITI Q70L	HGY51	2013.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hong kong	INFINITI Q70L	HGY51	2013.10-	Laser/radar	√	√	√	√		
Hong kong	INFINITI Q70L	HGY51	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hong kong	INFINITI Q70L	HGY51	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Hong kong	INFINITI Q70L	HGY51	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hong kong	INFINITI Q70L	HGY51	2013.10-	Air bag	√	√	√	√		
Hong kong	INFINITI Q70L	HGY51	2013.10-	EPS/DAST 3	√	√	√	√		
Hong kong	INFINITI Q70L	HGY51	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hong kong	INFINITI Q70L	HGY51	2013.10-	Motor control	√	√	√	√		
Hong kong	INFINITI Q70L	HGY51	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hong kong	INFINITI Q70L	HGY51	2013.10-	Transmission	√	√	√	√		SP0274, SP0276
Hong kong	INFINITI Q70L	HGY51	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Hong kong	INFINITI Q70L	HGY51	2013.10-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hong kong	INFINITI Q70L	HGY51	2013.10-	Pop up hood	√	√	√	√		
Hong kong	INFINITI Q70L	HGY51	2013.10-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI Q70L	HGY51	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hong kong	INFINITI Q70L	HGY51	2013.10-	HV battery	√	√	√	√	AC1121	
Hong kong	INFINITI Q70L	HGY51	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI Q70L	HGY51	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hong kong	INFINITI Q70L	HGY51	2013.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hong kong	INFINITI Q70L	HGY51	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hong kong	INFINITI Q70L	HGY51	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Hong kong	INFINITI Q70L	HGY51	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Hong kong	INFINITI Q70L	HGY51	2013.10-	CAN gateway	√	√	√			

Hong kong	INFINITI Q70L	HGY51	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Hong kong	INFINITI Q70L	HGY51	2013.10-	Brake	√	√	√	√	AC1127	
Hong kong	INFINITI Q70L	HGY51	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Hong kong	INFINITI QX50	I55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Hong kong	INFINITI QX50	I55	2018.5-	Laser/radar	√	√	√	√		
Hong kong	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Hong kong	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Hong kong	INFINITI QX50	I55	2018.5-	Air bag	√	√	√	√		
Hong kong	INFINITI QX50	I55	2018.5-	EPS/DAST 3	√	√	√	√		
Hong kong	INFINITI QX50	I55	2018.5-	Meter/M&A	√	√	√	√		
Hong kong	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hong kong	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Hong kong	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Hong kong	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Hong kong	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Hong kong	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Hong kong	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Hong kong	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Hong kong	INFINITI QX50	I55	2018.5-	Auto back door	√	√	√	√		SP0611
Hong kong	INFINITI QX50	I55	2018.5-	Occupant detection			√	√		SP0584
Hong kong	INFINITI QX50	I55	2018.5-	Shift						
Hong kong	INFINITI QX50	I55	2018.5-	Adaptive light	√	√	√	√		SP0562
Hong kong	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hong kong	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hong kong	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Hong kong	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Hong kong	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hong kong	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Hong kong	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Hong kong	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Hong kong	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Hong kong	INFINITI QX50	J55	2018.5-	ANC						
Hong kong	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Hong kong	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Hong kong	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hong kong	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Hong kong	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Hong kong	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Hong kong	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Hong kong	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hong kong	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Hong kong	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hong kong	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hong kong	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hong kong	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Hong kong	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Hong kong	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hong kong	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hong kong	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Hong kong	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hong kong	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Hong kong	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Hong kong	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hong kong	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hong kong	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Hong kong	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Hong kong	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hong kong	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hong kong	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hong kong	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Hong kong	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Hong kong	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hong kong	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Hong kong	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Hong kong	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hong kong	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hong kong	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Hong kong	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Hong kong	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hong kong	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Hong kong	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Hong kong	INFINITI QX80	Z62	2014.11-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hong kong	INFINITI QX80	Z62	2014.11-	Laser/radar	√	√	√	√	AC0994	
Hong kong	INFINITI QX80	Z62	2014.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hong kong	INFINITI QX80	Z62	2014.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hong kong	INFINITI QX80	Z62	2014.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hong kong	INFINITI QX80	Z62	2014.11-	Air bag	√	√	√	√		
Hong kong	INFINITI QX80	Z62	2014.11-	EPS/DAST 3	√	√	√	√		SP0507
Hong kong	INFINITI QX80	Z62	2014.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Hong kong	INFINITI QX80	Z62	2014.11-	Motor control	√	√	√	√		
Hong kong	INFINITI QX80	Z62	2014.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hong kong	INFINITI QX80	Z62	2014.11-	Transmission	√	√	√	√	AC0439, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0246, SP0270, SP0274, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Hong kong	INFINITI QX80	Z62	2014.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Hong kong	INFINITI QX80	Z62	2014.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hong kong	INFINITI QX80	Z62	2014.11-	Multi AV	√	√	√	√		SP0503
Hong kong	INFINITI QX80	Z62	2014.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Hong kong	INFINITI QX80	Z62	2014.11-	HV battery	√	√	√	√	AC1121	
Hong kong	INFINITI QX80	Z62	2014.11-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Hong kong	INFINITI QX80	Z62	2014.11-	Difference lock	√	√	√	√		
Hong kong	INFINITI QX80	Z62	2014.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hong kong	INFINITI QX80	Z62	2014.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hong kong	INFINITI QX80	Z62	2014.11-	Auto back door	√	√	√	√		SP0611
Hong kong	INFINITI QX80	Z62	2014.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Hong kong	INFINITI QX80	Z62	2014.11-	Occupant detection			√	√		SP0584
Hong kong	INFINITI QX80	Z62	2014.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hong kong	INFINITI QX80	Z62	2014.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	

Hong kong	INFINITI QX80	Z62	2014.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hong kong	INFINITI QX80	Z62	2014.11-	All mode AWD/4WD	√	√	√	√	AC0956	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Hong kong	INFINITI QX80	Z62	2014.11-	Precrash seatbelt	√	√	√	√		SP0612
Hong kong	INFINITI QX80	Z62	2014.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hong kong	INFINITI QX80	Z62	2014.11-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Hong kong	INFINITI QX80	Z62	2014.11-	CAN gateway	√	√	√			
Hong kong	INFINITI QX80	Z62	2014.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Hong kong	INFINITI QX80	Z62	2014.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hong kong	INFINITI QX80	Z62	2014.11-	Side radar left	√	√	√	√	AC1025	SP0582
Hong kong	INFINITI QX80	Z62	2014.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hong kong	INFINITI QX80	Z62	2014.11-	HIGH BEAM ASSIST	√	√	√	√		
Hong kong	INFINITI QX80	Z62	2014.11-	Side radar right	√	√	√	√	AC1026	SP0583
Hong kong	INFINITI QX80	Z62	2014.11-	Vehicle data transmitter	√	√	√	√		
Hong kong	INFINITI QX80	Z62	2014.11-	6ch CAN GATEWAY	√	√	√	√		
Hong kong	INFINITI QX80	Z62	2014.11-	ICC/ADAS 2	√	√	√	√		
Hong kong	INFINITI QX80	Z62	2014.11-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hong kong	INFINITI QX80	Z62	2014.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hungary	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Hungary	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hungary	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hungary	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Hungary	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Hungary	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Hungary	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hungary	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hungary	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Hungary	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hungary	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hungary	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Hungary	INFINITI EX37	I50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hungary	INFINITI EX37	I50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Hungary	INFINITI EX37	I50	2008.6-	Multi AV	√	√	√	√		
Hungary	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hungary	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hungary	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Hungary	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hungary	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Hungary	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Hungary	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hungary	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Hungary	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Hungary	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Hungary	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Hungary	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hungary	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Hungary	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hungary	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Hungary	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Hungary	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hungary	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hungary	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Hungary	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hungary	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Hungary	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Hungary	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Hungary	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hungary	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hungary	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hungary	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Hungary	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Hungary	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Hungary	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Hungary	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hungary	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hungary	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Hungary	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hungary	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Hungary	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Hungary	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Hungary	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Hungary	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hungary	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hungary	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Hungary	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hungary	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hungary	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Hungary	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Hungary	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Hungary	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hungary	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hungary	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hungary	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Hungary	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Hungary	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Hungary	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hungary	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Hungary	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hungary	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hungary	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Hungary	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hungary	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Hungary	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hungary	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hungary	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hungary	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Hungary	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hungary	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Hungary	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Hungary	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Hungary	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Hungary	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hungary	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Hungary	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Hungary	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Hungary	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Hungary	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Hungary	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Hungary	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Hungary	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Hungary	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Hungary	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hungary	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Hungary	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Hungary	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Hungary	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Hungary	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hungary	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Hungary	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hungary	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Hungary	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Hungary	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hungary	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Hungary	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Hungary	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hungary	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Hungary	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hungary	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hungary	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hungary	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hungary	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Hungary	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Hungary	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Hungary	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Hungary	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Hungary	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Hungary	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		

Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Hungary	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Hungary	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Hungary	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Hungary	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Hungary	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Hungary	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Hungary	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Hungary	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Hungary	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Hungary	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Hungary	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Hungary	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Hungary	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Hungary	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Hungary	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Hungary	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Hungary	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Hungary	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Hungary	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Hungary	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Hungary	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Hungary	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Hungary	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Hungary	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Hungary	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Hungary	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Hungary	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Hungary	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Hungary	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Hungary	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		

Hungary	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Hungary	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Hungary	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Hungary	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Hungary	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Hungary	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Hungary	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Hungary	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Hungary	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Hungary	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hungary	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Hungary	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hungary	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Hungary	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Hungary	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hungary	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Hungary	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hungary	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Hungary	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Hungary	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hungary	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Hungary	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hungary	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Hungary	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hungary	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hungary	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hungary	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Hungary	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hungary	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hungary	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hungary	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Hungary	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Hungary	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Hungary	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hungary	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Hungary	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Hungary	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Hungary	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Hungary	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Hungary	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Hungary	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Hungary	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Hungary	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Hungary	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Hungary	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hungary	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Hungary	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Hungary	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Hungary	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Hungary	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Hungary	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Hungary	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Hungary	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Hungary	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503

Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Hungary	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Hungary	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Hungary	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hungary	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Hungary	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hungary	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Hungary	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Hungary	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hungary	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hungary	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Hungary	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Hungary	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Hungary	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Hungary	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hungary	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Hungary	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hungary	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hungary	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hungary	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Hungary	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Hungary	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Hungary	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Hungary	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Hungary	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Hungary	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Hungary	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Hungary	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Hungary	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Hungary	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Hungary	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hungary	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Hungary	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583

Hungary	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Hungary	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Hungary	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Hungary	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hungary	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hungary	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hungary	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Hungary	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hungary	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Hungary	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Hungary	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hungary	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hungary	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Hungary	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Hungary	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Hungary	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hungary	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hungary	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hungary	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Hungary	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hungary	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hungary	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hungary	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Hungary	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Hungary	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hungary	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Hungary	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Hungary	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Hungary	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hungary	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Hungary	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Hungary	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hungary	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Hungary	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Hungary	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Hungary	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		

Hungary	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Hungary	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Hungary	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Hungary	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Hungary	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hungary	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Hungary	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Hungary	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Hungary	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hungary	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Hungary	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hungary	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hungary	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hungary	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hungary	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Hungary	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Hungary	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Hungary	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Hungary	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Hungary	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Hungary	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hungary	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Hungary	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Hungary	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Hungary	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Hungary	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Hungary	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Hungary	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Hungary	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Hungary	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Hungary	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Hungary	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Hungary	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Hungary	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Hungary	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Hungary	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Hungary	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Hungary	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Hungary	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Hungary	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Hungary	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Hungary	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Hungary	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Hungary	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Hungary	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Hungary	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Hungary	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Hungary	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Hungary	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Hungary	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Hungary	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Hungary	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Hungary	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Hungary	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Hungary	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Hungary	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Hungary	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Hungary	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Hungary	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Hungary	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Hungary	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Hungary	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Hungary	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Hungary	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Hungary	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Hungary	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Hungary	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Hungary	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Hungary	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Hungary	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Hungary	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iceland	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Iceland	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iceland	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iceland	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Iceland	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Iceland	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Iceland	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Iceland	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Iceland	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Iceland	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Iceland	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Iceland	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Iceland	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iceland	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Iceland	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Iceland	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Iceland	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Iceland	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Iceland	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iceland	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Iceland	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Iceland	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iceland	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iceland	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Iceland	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Iceland	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Iceland	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Iceland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iceland	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Iceland	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Iceland	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iceland	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iceland	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Iceland	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iceland	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iceland	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Iceland	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iceland	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iceland	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iceland	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Iceland	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Iceland	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Iceland	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iceland	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Iceland	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iceland	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iceland	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Iceland	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Iceland	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iceland	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Iceland	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iceland	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iceland	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iceland	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Iceland	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Iceland	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Iceland	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Iceland	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Iceland	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Iceland	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Iceland	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Iceland	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Iceland	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iceland	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Iceland	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Iceland	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Iceland	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Iceland	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Iceland	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Iceland	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Iceland	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Iceland	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Iceland	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Iceland	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Iceland	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Iceland	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iceland	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Iceland	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Iceland	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Iceland	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Iceland	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Iceland	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Iceland	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Iceland	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iceland	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Iceland	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Iceland	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iceland	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iceland	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iceland	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Iceland	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Iceland	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Iceland	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Iceland	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Iceland	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Iceland	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Iceland	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Iceland	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Iceland	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Iceland	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Iceland	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Iceland	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Iceland	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Iceland	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Iceland	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Iceland	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Iceland	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Iceland	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Iceland	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Iceland	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Iceland	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Iceland	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Iceland	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Iceland	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Iceland	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Iceland	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Iceland	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Iceland	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Iceland	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Iceland	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Iceland	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Iceland	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Iceland	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Iceland	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Iceland	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Iceland	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Iceland	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Iceland	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Iceland	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Iceland	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Iceland	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Iceland	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Iceland	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		

Iceland	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Iceland	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Iceland	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iceland	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Iceland	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iceland	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Iceland	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Iceland	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iceland	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Iceland	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iceland	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Iceland	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Iceland	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Iceland	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Iceland	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iceland	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Iceland	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Iceland	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iceland	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Iceland	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Iceland	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Iceland	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iceland	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iceland	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Iceland	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Iceland	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Iceland	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iceland	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Iceland	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Iceland	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Iceland	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Iceland	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Iceland	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Iceland	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Iceland	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Iceland	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Iceland	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Iceland	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iceland	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Iceland	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Iceland	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Iceland	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Iceland	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Iceland	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Iceland	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Iceland	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Iceland	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Iceland	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Iceland	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Iceland	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iceland	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Iceland	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iceland	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Iceland	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Iceland	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iceland	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iceland	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√	AC0247, SP0265, SP0270, SP0274	
Iceland	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Iceland	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Iceland	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Iceland	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iceland	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Iceland	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Iceland	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iceland	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iceland	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Iceland	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Iceland	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Iceland	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Iceland	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Iceland	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Iceland	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Iceland	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Iceland	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Iceland	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Iceland	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Iceland	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iceland	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Iceland	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Iceland	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Iceland	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Iceland	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Iceland	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319

Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iceland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iceland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Iceland	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Iceland	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iceland	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Iceland	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Iceland	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iceland	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Iceland	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Iceland	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Iceland	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Iceland	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Iceland	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iceland	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Iceland	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iceland	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Iceland	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Iceland	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iceland	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iceland	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Iceland	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Iceland	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iceland	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Iceland	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Iceland	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Iceland	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Iceland	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Iceland	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Iceland	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iceland	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Iceland	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Iceland	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Iceland	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Iceland	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	

Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Iceland	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Iceland	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iceland	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Iceland	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iceland	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Iceland	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Iceland	INFINITI QX50	I50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iceland	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Iceland	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Iceland	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iceland	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Iceland	INFINITI QX50	I50	2013.9-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iceland	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iceland	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iceland	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Iceland	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Iceland	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iceland	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Iceland	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Iceland	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Iceland	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iceland	INFINITI QX50	I50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Iceland	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Iceland	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Iceland	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Iceland	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Iceland	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Iceland	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Iceland	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Iceland	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iceland	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Iceland	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Iceland	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Iceland	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iceland	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Iceland	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Iceland	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Iceland	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Iceland	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Iceland	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Iceland	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iceland	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iceland	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iceland	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Iceland	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Iceland	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iceland	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Iceland	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Iceland	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iceland	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Iceland	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Iceland	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Iceland	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Iceland	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iceland	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iceland	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Iceland	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Iceland	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iceland	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iceland	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Iceland	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Iceland	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Iceland	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Iceland	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Iceland	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Iceland	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iceland	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Iceland	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Iceland	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iceland	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Iceland	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
India	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
India	INFINITI Q45	F50	ALL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
India	INFINITI Q45	F50	ALL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
India	INFINITI Q45	F50	ALL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
India	INFINITI Q45	F50	ALL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
India	INFINITI Q45	F50	ALL	Air bag	√	√	√	√		
India	INFINITI Q45	F50	ALL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
India	INFINITI Q45	F50	ALL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
India	INFINITI Q45	F50	ALL	Motor control						
India	INFINITI Q45	F50	ALL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
India	INFINITI Q45	F50	ALL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
India	INFINITI Q45	F50	ALL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
India	INFINITI Q45	F50	ALL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
India	INFINITI Q45	F50	ALL	Multi AV	√	√	√	√		SP0503
India	INFINITI Q45	F50	ALL	HVAC	√	√	√	√		
India	INFINITI Q45	F50	ALL	Difference lock	√	√	√	√		
India	INFINITI Q45	F50	ALL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
India	INFINITI Q45	F50	ALL	Auto slide door	√	√	√	√	AC0941	
India	INFINITI Q45	F50	ALL	DIU		√	√	√		
India	INFINITI Q45	F50	ALL	Adaptive light	√	√	√	√		
India	INFINITI Q45	F50	ALL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
India	INFINITI Q45	F50	ALL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
India	INFINITI Q45	F50	ALL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
India	INFINITI Q45	F50	ALL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
India	INFINITI Q45	F50	ALL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
India	INFINITI Q45	F50	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
India	INFINITI Q45	F50	ALL	IVMS	√	√		√		
India	INFINITI Q45	F50	ALL	Distance control	√	√		√		
India	INFINITI Q45	F50	ALL	Active suspense system	√	√	√	√		
India	INFINITI Q45	F50	ALL	Motor assist		√	√	√		SP0574
India	INFINITI Q45	F50	ALL	ASCD	√	√	√	√		
India	INFINITI Q45	F50	ALL	Active engine mount	√	√	√	√		
India	INFINITI Q45	F50	ALL	TCS	√	√	√	√		
India	INFINITI Q45	F50	ALL	S/blind camera	√			√		SP0572, SP0573
India	INFINITI Q45	F50	ALL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
India	INFINITI Q45	F50	ALL	Nats immu	√	√	√			
India	INFINITI Q45	F50	ALL	Rearview camera	√			√		SP0570, SP0571
India	INFINITI Q45	F50	ALL	Smart entrance						SP0568
India	INFINITI Q50 HYBRID	HV37	2014.1-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
India	INFINITI Q50 HYBRID	HV37	2014.1-	Laser/radar	√	√	√	√		
India	INFINITI Q50 HYBRID	HV37	2014.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
India	INFINITI Q50 HYBRID	HV37	2014.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
India	INFINITI Q50 HYBRID	HV37	2014.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
India	INFINITI Q50 HYBRID	HV37	2014.1-	Air bag	√	√	√	√		
India	INFINITI Q50 HYBRID	HV37	2014.1-	EPS/DAST 3	√	√	√	√		
India	INFINITI Q50 HYBRID	HV37	2014.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
India	INFINITI Q50 HYBRID	HV37	2014.1-	Motor control	√	√	√	√		
India	INFINITI Q50 HYBRID	HV37	2014.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
India	INFINITI Q50 HYBRID	HV37	2014.1-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
India	INFINITI Q50 HYBRID	HV37	2014.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
India	INFINITI Q50 HYBRID	HV37	2014.1-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
India	INFINITI Q50 HYBRID	HV37	2014.1-	Pop up hood	√	√	√	√		
India	INFINITI Q50 HYBRID	HV37	2014.1-	Multi AV	√	√	√	√		SP0503
India	INFINITI Q50 HYBRID	HV37	2014.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
India	INFINITI Q50 HYBRID	HV37	2014.1-	HV battery	√	√	√	√	AC1121	
India	INFINITI Q50 HYBRID	HV37	2014.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
India	INFINITI Q50 HYBRID	HV37	2014.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
India	INFINITI Q50 HYBRID	HV37	2014.1-	Occupant detection			√	√		SP0584
India	INFINITI Q50 HYBRID	HV37	2014.1-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
India	INFINITI Q50 HYBRID	HV37	2014.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
India	INFINITI Q50 HYBRID	HV37	2014.1-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
India	INFINITI Q50 HYBRID	HV37	2014.1-	All mode AWD/4WD	√	√	√	√	AC0956	
India	INFINITI Q50 HYBRID	HV37	2014.1-	DAST 2	√	√	√	√		
India	INFINITI Q50 HYBRID	HV37	2014.1-	Precrash seatbelt	√	√	√	√		SP0612
India	INFINITI Q50 HYBRID	HV37	2014.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
India	INFINITI Q50 HYBRID	HV37	2014.1-	CAN gateway	√	√	√			
India	INFINITI Q50 HYBRID	HV37	2014.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
India	INFINITI Q50 HYBRID	HV37	2014.1-	DAST 1	√	√	√	√		
India	INFINITI Q50 HYBRID	HV37	2014.1-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
India	INFINITI Q50 HYBRID	HV37	2014.1-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	

India	INFINITI Q50 HYBRID	HV37	2014.1-	ANC	√	√	√	√	AC1024	
India	INFINITI Q50 HYBRID	HV37	2014.1-	Side radar left	√	√	√	√	AC1025	SP0582
India	INFINITI Q50 HYBRID	HV37	2014.1-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
India	INFINITI Q50 HYBRID	HV37	2014.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
India	INFINITI Q50 HYBRID	HV37	2014.1-	HIGH BEAM ASSIST	√	√	√	√		
India	INFINITI Q50 HYBRID	HV37	2014.1-	Side radar right	√	√	√	√	AC1026	SP0583
India	INFINITI Q50 HYBRID	HV37	2014.1-	Brake	√	√	√	√	AC1127	
India	INFINITI Q50 HYBRID	HV37	2014.1-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
India	INFINITI Q50 HYBRID	HV37	2014.1-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Indonesia	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Indonesia	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Indonesia	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Indonesia	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Indonesia	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Indonesia	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Indonesia	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Indonesia	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Indonesia	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Indonesia	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Indonesia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Indonesia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Indonesia	INFINITI M25/M37	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Indonesia	INFINITI M25/M37	Y51	2011.1-	Laser/radar	√	√	√	√		
Indonesia	INFINITI M25/M37	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Indonesia	INFINITI M25/M37	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Indonesia	INFINITI M25/M37	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Indonesia	INFINITI M25/M37	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Indonesia	INFINITI M25/M37	Y51	2011.1-	Air bag	√	√	√	√		
Indonesia	INFINITI M25/M37	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Indonesia	INFINITI M25/M37	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Indonesia	INFINITI M25/M37	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Indonesia	INFINITI M25/M37	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Indonesia	INFINITI M25/M37	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319

Indonesia	INFINITI M25/M37	Y51	2011.1-	Pop up hood	√	√	√	√		
Indonesia	INFINITI M25/M37	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Indonesia	INFINITI M25/M37	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Indonesia	INFINITI M25/M37	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Indonesia	INFINITI M25/M37	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Indonesia	INFINITI M25/M37	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Indonesia	INFINITI M25/M37	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Indonesia	INFINITI M25/M37	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Indonesia	INFINITI M25/M37	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Indonesia	INFINITI M25/M37	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Indonesia	INFINITI M25/M37	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Indonesia	INFINITI M25/M37	Y51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Indonesia	INFINITI M25/M37	Y51	2011.1-	CAN gateway	√	√	√			
Indonesia	INFINITI M25/M37	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Indonesia	INFINITI M25/M37	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Indonesia	INFINITI M25/M37	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Indonesia	INFINITI M25/M37	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Indonesia	INFINITI Q45	F50	ALL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Indonesia	INFINITI Q45	F50	ALL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Indonesia	INFINITI Q45	F50	ALL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Indonesia	INFINITI Q45	F50	ALL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Indonesia	INFINITI Q45	F50	ALL	Air bag	√	√	√	√		
Indonesia	INFINITI Q45	F50	ALL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Indonesia	INFINITI Q45	F50	ALL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Indonesia	INFINITI Q45	F50	ALL	Motor control						
Indonesia	INFINITI Q45	F50	ALL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Indonesia	INFINITI Q45	F50	ALL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Indonesia	INFINITI Q45	F50	ALL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Indonesia	INFINITI Q45	F50	ALL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Indonesia	INFINITI Q45	F50	ALL	Multi AV	√	√	√	√		SP0503
Indonesia	INFINITI Q45	F50	ALL	HVAC	√	√	√	√		
Indonesia	INFINITI Q45	F50	ALL	Difference lock	√	√	√	√		
Indonesia	INFINITI Q45	F50	ALL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Indonesia	INFINITI Q45	F50	ALL	Auto slide door	√	√	√	√	AC0941	
Indonesia	INFINITI Q45	F50	ALL	DIU		√	√	√		
Indonesia	INFINITI Q45	F50	ALL	Adaptive light	√	√	√	√		
Indonesia	INFINITI Q45	F50	ALL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Indonesia	INFINITI Q45	F50	ALL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Indonesia	INFINITI Q45	F50	ALL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Indonesia	INFINITI Q45	F50	ALL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Indonesia	INFINITI Q45	F50	ALL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Indonesia	INFINITI Q45	F50	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Indonesia	INFINITI Q45	F50	ALL	IVMS	√	√		√		
Indonesia	INFINITI Q45	F50	ALL	Distance control	√	√		√		
Indonesia	INFINITI Q45	F50	ALL	Active suspense system	√	√	√	√		
Indonesia	INFINITI Q45	F50	ALL	Motor assist		√	√	√		SP0574
Indonesia	INFINITI Q45	F50	ALL	ASCD	√	√	√	√		
Indonesia	INFINITI Q45	F50	ALL	Active engine mount	√	√	√	√		
Indonesia	INFINITI Q45	F50	ALL	TCS	√	√	√	√		
Indonesia	INFINITI Q45	F50	ALL	S/blind camera	√			√		SP0572, SP0573
Indonesia	INFINITI Q45	F50	ALL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Indonesia	INFINITI Q45	F50	ALL	Nats immu	√	√	√			
Indonesia	INFINITI Q45	F50	ALL	Rearview camera	√			√		SP0570, SP0571
Indonesia	INFINITI Q45	F50	ALL	Smart entrance						SP0568
Indonesia	INFINITI Q50	V37	2014.1-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Indonesia	INFINITI Q50	V37	2014.1-	Laser/radar	√	√	√	√	AC0994	
Indonesia	INFINITI Q50	V37	2014.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Indonesia	INFINITI Q50	V37	2014.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Indonesia	INFINITI Q50	V37	2014.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Indonesia	INFINITI Q50	V37	2014.1-	Air bag	√	√	√	√		
Indonesia	INFINITI Q50	V37	2014.1-	EPS/DAST 3	√	√	√	√		SP0507
Indonesia	INFINITI Q50	V37	2014.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Indonesia	INFINITI Q50	V37	2014.1-	Motor control	√	√	√	√		
Indonesia	INFINITI Q50	V37	2014.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Indonesia	INFINITI Q50	V37	2014.1-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Indonesia	INFINITI Q50	V37	2014.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Indonesia	INFINITI Q50	V37	2014.1-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Indonesia	INFINITI Q50	V37	2014.1-	Pop up hood	√	√	√	√		
Indonesia	INFINITI Q50	V37	2014.1-	Multi AV	√	√	√	√		SP0503
Indonesia	INFINITI Q50	V37	2014.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Indonesia	INFINITI Q50	V37	2014.1-	HV battery	√	√	√	√	AC1121	
Indonesia	INFINITI Q50	V37	2014.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Indonesia	INFINITI Q50	V37	2014.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Indonesia	INFINITI Q50	V37	2014.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Indonesia	INFINITI Q50	V37	2014.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Indonesia	INFINITI Q50	V37	2014.1-	Occupant detection			√	√		SP0584
Indonesia	INFINITI Q50	V37	2014.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Indonesia	INFINITI Q50	V37	2014.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Indonesia	INFINITI Q50	V37	2014.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Indonesia	INFINITI Q50	V37	2014.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Indonesia	INFINITI Q50	V37	2014.1-	DAST 2	√	√	√	√		
Indonesia	INFINITI Q50	V37	2014.1-	Precrash seatbelt	√	√	√	√		SP0612
Indonesia	INFINITI Q50	V37	2014.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Indonesia	INFINITI Q50	V37	2014.1-	CAN gateway	√	√	√			
Indonesia	INFINITI Q50	V37	2014.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Indonesia	INFINITI Q50	V37	2014.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Indonesia	INFINITI Q50	V37	2014.1-	DAST 1	√	√	√	√		
Indonesia	INFINITI Q50	V37	2014.1-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Indonesia	INFINITI Q50	V37	2014.1-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Indonesia	INFINITI Q50	V37	2014.1-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Indonesia	INFINITI Q50	V37	2014.1-	ANC	√	√	√	√	AC1024	
Indonesia	INFINITI Q50	V37	2014.1-	Side radar left	√	√	√	√	AC1025	SP0582
Indonesia	INFINITI Q50	V37	2014.1-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Indonesia	INFINITI Q50	V37	2014.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Indonesia	INFINITI Q50	V37	2014.1-	HIGH BEAM ASSIST	√	√	√	√		
Indonesia	INFINITI Q50	V37	2014.1-	Side radar right	√	√	√	√	AC1026	SP0583
Indonesia	INFINITI Q50	V37	2014.1-	Brake	√	√	√	√	AC1127	

Indonesia	INFINITI Q50	V37	2014.1-	6ch CAN GATEWAY	√	√	√	√		
Indonesia	INFINITI Q50	V37	2014.1-	3ch CAN GATEWAY	√	√	√	√		
Indonesia	INFINITI Q50	V37	2014.1-	ICC/ADAS 2	√	√	√	√		
Indonesia	INFINITI Q50	V37	2014.1-	PMAS	√	√	√	√		
Indonesia	INFINITI Q50	V37	2014.1-	FSCM	√	√	√	√	AC1109	
Indonesia	INFINITI Q50	V37	2014.1-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Laser/radar	√	√	√	√	AC0994	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Air bag	√	√	√	√		
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Motor control	√	√	√	√		
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Pop up hood	√	√	√	√		
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Multi AV	√	√	√	√		SP0503
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	HV battery	√	√	√	√	AC1121	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	EV/HEV	√	√	√	√	AC1084. AC1085. AC1086. AC1087. AC1088. AC1089. AC1106	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Occupant detection			√	√		SP0584
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	DAST 2	√	√	√	√		
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	CAN gateway	√	√	√			
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	DAST 1	√	√	√	√		
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	ANC	√	√	√	√	AC1024	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Brake	√	√	√	√	AC1127	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	6ch CAN GATEWAY	√	√	√	√		
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	FSCM	√	√	√	√	AC1109	
Indonesia	INFINITI Q50 HYBRID	HV37	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Indonesia	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Indonesia	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Indonesia	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Indonesia	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Indonesia	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Indonesia	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Indonesia	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Indonesia	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Indonesia	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Indonesia	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Indonesia	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Indonesia	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Indonesia	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Indonesia	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Indonesia	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Indonesia	INFINITI Q60	CV37	2016.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Indonesia	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Indonesia	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Indonesia	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Indonesia	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Indonesia	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Indonesia	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Indonesia	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Indonesia	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Indonesia	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Indonesia	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Indonesia	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√		
Indonesia	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Indonesia	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Indonesia	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Indonesia	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Indonesia	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Indonesia	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Indonesia	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Indonesia	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Indonesia	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Indonesia	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Indonesia	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Indonesia	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	Laser/radar	√	√	√	√	AC0994	
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	ICC/ADAS	√	√	√	√	AC0865. AC0866. AC0867. AC0868. AC0876. AC0877. AC0884	SP0494
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	IPDM E/R	√	√	√	√	AC0811. AC0815. AC0816. AC0817. AC0818. AC0819. AC0821. AC0822. AC0825. AC0831	
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	Air bag	√	√	√	√		
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	Transmission	√	√	√	√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0274
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	BCM				√		SP0372, SP0429
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	Pop up hood	√	√	√	√		
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	Multi AV	√	√	√	√		SP0503
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	Precrash seatbelt	√	√	√	√		
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Indonesia	INFINITI Q60 COUPE	CV36	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Indonesia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Indonesia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Indonesia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Indonesia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Indonesia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Indonesia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Indonesia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Indonesia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Indonesia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Indonesia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Indonesia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Indonesia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Indonesia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Indonesia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Indonesia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Indonesia	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Indonesia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Indonesia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Indonesia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Indonesia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Indonesia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Indonesia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Indonesia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Indonesia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Indonesia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Indonesia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Indonesia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Indonesia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Indonesia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Indonesia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Indonesia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Indonesia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Indonesia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Indonesia	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Indonesia	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Indonesia	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Indonesia	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Indonesia	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Indonesia	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Indonesia	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Indonesia	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Indonesia	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Indonesia	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Indonesia	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Indonesia	INFINITI QX50	J55	2018.5-	Shift						
Indonesia	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Indonesia	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Indonesia	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Indonesia	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Indonesia	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	ANC						
Indonesia	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Indonesia	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Indonesia	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Indonesia	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Indonesia	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Indonesia	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Indonesia	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Indonesia	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Indonesia	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Indonesia	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Indonesia	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Indonesia	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Indonesia	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Indonesia	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Indonesia	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Indonesia	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Indonesia	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Indonesia	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Indonesia	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Indonesia	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Indonesia	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Indonesia	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Indonesia	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Indonesia	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Indonesia	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Indonesia	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Indonesia	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Indonesia	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Indonesia	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Indonesia	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Indonesia	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Indonesia	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Indonesia	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Indonesia	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Indonesia	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Indonesia	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Indonesia	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Indonesia	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Indonesia	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Indonesia	INFINITI QX80	Z62	2014.11-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Indonesia	INFINITI QX80	Z62	2014.11-	Laser/radar	√	√	√	√	AC0994	
Indonesia	INFINITI QX80	Z62	2014.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Indonesia	INFINITI QX80	Z62	2014.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Indonesia	INFINITI QX80	Z62	2014.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Indonesia	INFINITI QX80	Z62	2014.11-	Air bag	√	√	√	√		
Indonesia	INFINITI QX80	Z62	2014.11-	EPS/DAST 3	√	√	√	√		SP0507
Indonesia	INFINITI QX80	Z62	2014.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Indonesia	INFINITI QX80	Z62	2014.11-	Motor control	√	√	√	√		
Indonesia	INFINITI QX80	Z62	2014.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Indonesia	INFINITI QX80	Z62	2014.11-	Transmission	√	√	√	√	AC0439, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0246, SP0270, SP0274, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Indonesia	INFINITI QX80	Z62	2014.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Indonesia	INFINITI QX80	Z62	2014.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Indonesia	INFINITI QX80	Z62	2014.11-	Multi AV	√	√	√	√		SP0503
Indonesia	INFINITI QX80	Z62	2014.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Indonesia	INFINITI QX80	Z62	2014.11-	HV battery	√	√	√	√	AC1121	
Indonesia	INFINITI QX80	Z62	2014.11-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Indonesia	INFINITI QX80	Z62	2014.11-	Difference lock	√	√	√	√		
Indonesia	INFINITI QX80	Z62	2014.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Indonesia	INFINITI QX80	Z62	2014.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Indonesia	INFINITI QX80	Z62	2014.11-	Auto back door	√	√	√	√		SP0611
Indonesia	INFINITI QX80	Z62	2014.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Indonesia	INFINITI QX80	Z62	2014.11-	Occupant detection			√	√		SP0584
Indonesia	INFINITI QX80	Z62	2014.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Indonesia	INFINITI QX80	Z62	2014.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Indonesia	INFINITI QX80	Z62	2014.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Indonesia	INFINITI QX80	Z62	2014.11-	All mode AWD/4WD	√	√	√	√	AC0956	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Indonesia	INFINITI QX80	Z62	2014.11-	Precrash seatbelt	√	√	√	√		SP0612
Indonesia	INFINITI QX80	Z62	2014.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Indonesia	INFINITI QX80	Z62	2014.11-	CAN gateway	√	√	√			
Indonesia	INFINITI QX80	Z62	2014.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Indonesia	INFINITI QX80	Z62	2014.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Indonesia	INFINITI QX80	Z62	2014.11-	Side radar left	√	√	√	√	AC1025	SP0582
Indonesia	INFINITI QX80	Z62	2014.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Indonesia	INFINITI QX80	Z62	2014.11-	HIGH BEAM ASSIST	√	√	√	√		
Indonesia	INFINITI QX80	Z62	2014.11-	Side radar right	√	√	√	√	AC1026	SP0583
Indonesia	INFINITI QX80	Z62	2014.11-	Vehicle data transmitter	√	√	√	√		
Indonesia	INFINITI QX80	Z62	2014.11-	6ch CAN GATEWAY	√	√	√	√		
Indonesia	INFINITI QX80	Z62	2014.11-	ICC/ADAS 2	√	√	√	√		
Indonesia	INFINITI QX80	Z62	2014.11-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Indonesia	INFINITI QX80	Z62	2014.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Iraq	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iraq	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Iraq	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iraq	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Iraq	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Iraq	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iraq	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iraq	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iraq	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Iraq	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Iraq	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iraq	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Iraq	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iraq	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Iraq	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Iraq	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Iraq	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iraq	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI EX35/EX37	I50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iraq	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Iraq	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Iraq	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Iraq	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Iraq	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iraq	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Iraq	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Iraq	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Iraq	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Iraq	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Iraq	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Iraq	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Iraq	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Iraq	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Iraq	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Iraq	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Iraq	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Iraq	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Iraq	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Iraq	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Iraq	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Iraq	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Iraq	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Iraq	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Iraq	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Iraq	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Iraq	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Iraq	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Iraq	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Iraq	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Iraq	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Iraq	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Iraq	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Iraq	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iraq	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Iraq	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iraq	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Iraq	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Iraq	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iraq	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Iraq	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Iraq	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Iraq	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Iraq	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Iraq	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iraq	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Iraq	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Iraq	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Iraq	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Iraq	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Iraq	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Iraq	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iraq	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Iraq	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Iraq	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Iraq	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Iraq	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Iraq	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Iraq	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Iraq	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Iraq	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Iraq	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Iraq	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Iraq	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iraq	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Iraq	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Iraq	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Iraq	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Iraq	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Iraq	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Iraq	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Iraq	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Iraq	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Iraq	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Iraq	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Iraq	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Iraq	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iraq	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239

Iraq	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Iraq	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iraq	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Iraq	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Iraq	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Iraq	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iraq	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iraq	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Iraq	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iraq	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Iraq	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iraq	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Iraq	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iraq	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iraq	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iraq	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Iraq	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Iraq	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Iraq	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iraq	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Iraq	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Iraq	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iraq	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Iraq	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iraq	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iraq	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iraq	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Iraq	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Iraq	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Iraq	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Iraq	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Iraq	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Iraq	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iraq	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Iraq	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Iraq	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Iraq	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Iraq	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Iraq	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Iraq	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Iraq	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Iraq	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Iraq	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Iraq	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510

Iraq	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Iraq	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Iraq	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Iraq	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Iraq	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Iraq	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Iraq	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Iraq	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Iraq	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Iraq	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Iraq	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Iraq	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Iraq	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Iraq	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Iraq	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Iraq	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Iraq	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Iraq	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Iraq	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Iraq	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iraq	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Iraq	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Iraq	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Iraq	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iraq	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Iraq	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iraq	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iraq	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iraq	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Iraq	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Iraq	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Iraq	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Iraq	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Iraq	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Iraq	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Iraq	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Iraq	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Iraq	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Iraq	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Iraq	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Iraq	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Iraq	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Iraq	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Iraq	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Iraq	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Iraq	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Iraq	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Iraq	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Iraq	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Iraq	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Iraq	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Iraq	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Iraq	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Iraq	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Iraq	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344

Iraq	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Iraq	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Iraq	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Iraq	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Iraq	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Iraq	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Iraq	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Iraq	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Iraq	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Iraq	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Iraq	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Iraq	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Iraq	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Iraq	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Iraq	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iraq	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Iraq	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Iraq	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Iraq	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Iraq	INFINITI Q45	F50	2001.8-	Motor control						
Iraq	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Iraq	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Iraq	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Iraq	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Iraq	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Iraq	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Iraq	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Iraq	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Iraq	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Iraq	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Iraq	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Iraq	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Iraq	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Iraq	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Iraq	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Iraq	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Iraq	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Iraq	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Iraq	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Iraq	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Iraq	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Iraq	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Iraq	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Iraq	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Iraq	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iraq	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Iraq	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Iraq	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Iraq	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Iraq	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Iraq	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Iraq	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Iraq	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iraq	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Iraq	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iraq	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Iraq	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980. AC0981. AC0982	SP0561. SP0562
Iraq	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Iraq	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Iraq	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Iraq	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Iraq	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Iraq	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Iraq	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Iraq	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Iraq	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Iraq	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Iraq	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Iraq	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Iraq	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iraq	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Iraq	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Iraq	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Iraq	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Iraq	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Iraq	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Iraq	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Iraq	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Iraq	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980. AC0981. AC0982	SP0561. SP0562
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962. AC0963. AC0964. AC0966. AC0967. AC0968. AC0969. AC0970	SP0553. SP0554. SP0555. SP0556. SP0557. SP0558. SP0559
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Iraq	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613. AC0618. AC0663. AC0690. AC0692. AC0702	SP0372. SP0429
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		

Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Iraq	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Iraq	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iraq	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Iraq	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iraq	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Iraq	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Iraq	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iraq	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Iraq	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Iraq	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Iraq	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Iraq	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iraq	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iraq	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Iraq	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Iraq	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Iraq	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Iraq	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Iraq	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Iraq	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Iraq	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Iraq	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Iraq	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Iraq	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Iraq	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iraq	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Iraq	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Iraq	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Iraq	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Iraq	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		

Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Iraq	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Iraq	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iraq	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Iraq	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Iraq	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iraq	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Iraq	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Iraq	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Iraq	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Iraq	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Iraq	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Iraq	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Iraq	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Iraq	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iraq	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Iraq	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Iraq	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Iraq	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Iraq	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Iraq	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Iraq	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Iraq	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Iraq	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Iraq	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iraq	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Iraq	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Iraq	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Iraq	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Iraq	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Iraq	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iraq	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Iraq	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iraq	INFINITI QX50	I50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI QX50	I50	2013.6-	Air bag	√	√	√	√		
Iraq	INFINITI QX50	I50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Iraq	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iraq	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Iraq	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Iraq	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iraq	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Iraq	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iraq	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Iraq	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI QX50	I50	2013.6-	CAN gateway	√	√	√	√		
Iraq	INFINITI QX50	I50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Iraq	INFINITI QX50	I50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	

Iraq	INFINITI QX50	I50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI QX50	I50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iraq	INFINITI QX50	I50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI QX50	I55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Iraq	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Iraq	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Iraq	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Iraq	INFINITI QX50	I55	2018.5-	Air bag	√	√	√	√		
Iraq	INFINITI QX50	I55	2018.5-	EPS/DAST 3	√	√	√	√		
Iraq	INFINITI QX50	I55	2018.5-	Meter/M&A	√	√	√	√		
Iraq	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Iraq	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Iraq	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Iraq	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Iraq	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Iraq	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Iraq	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Iraq	INFINITI QX50	I55	2018.5-	Auto back door	√	√	√	√		SP0611
Iraq	INFINITI QX50	I55	2018.5-	Occupant detection			√	√		SP0584
Iraq	INFINITI QX50	I55	2018.5-	Shift						
Iraq	INFINITI QX50	I55	2018.5-	Adaptive light	√	√	√	√		SP0562
Iraq	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Iraq	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Iraq	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Iraq	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Iraq	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Iraq	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Iraq	INFINITI QX50	J55	2018.5-	ANC						
Iraq	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Iraq	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iraq	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Iraq	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Iraq	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Iraq	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Iraq	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Iraq	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Iraq	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Iraq	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Iraq	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Iraq	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Iraq	INFINITI QX56	JA60	2004.10-	Motor control						
Iraq	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Iraq	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Iraq	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Iraq	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Iraq	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Iraq	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Iraq	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Iraq	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Iraq	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Iraq	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Iraq	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Iraq	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Iraq	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Iraq	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Iraq	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Iraq	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Iraq	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Iraq	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Iraq	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Iraq	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Iraq	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Iraq	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Iraq	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Iraq	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Iraq	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Iraq	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Iraq	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Iraq	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Iraq	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270, SP0274
Iraq	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Iraq	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Iraq	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Iraq	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Iraq	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Iraq	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Iraq	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Iraq	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√	AC0956	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Iraq	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√	AC1024	SP0612
Iraq	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Iraq	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Iraq	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iraq	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iraq	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Iraq	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iraq	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Iraq	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Iraq	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iraq	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Iraq	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Iraq	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Iraq	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Iraq	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Iraq	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Iraq	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Iraq	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Iraq	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Iraq	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Iraq	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Iraq	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Iraq	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Iraq	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Iraq	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Iraq	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iraq	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Iraq	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Iraq	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Iraq	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Iraq	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Iraq	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Iraq	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Iraq	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Iraq	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iraq	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Iraq	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		
Iraq	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Iraq	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Iraq	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Iraq	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Iraq	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Iraq	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Iraq	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Iraq	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Iraq	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Iraq	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Iraq	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Iraq	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Iraq	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Iraq	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Iraq	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Iraq	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Iraq	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Iraq	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iraq	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Iraq	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Iraq	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Iraq	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Iraq	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Iraq	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Iraq	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Iraq	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Iraq	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Iraq	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Iraq	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Iraq	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Iraq	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Iraq	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Iraq	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Iraq	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Iraq	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Iraq	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Iraq	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Iraq	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Iraq	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Iraq	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Iraq	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Iraq	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Iraq	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Iraq	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Iraq	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Iraq	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Iraq	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Iraq	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Iraq	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Iraq	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Iraq	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Iraq	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Iraq	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Iraq	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Iraq	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Iraq	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Iraq	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ireland	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ireland	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ireland	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ireland	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Ireland	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Ireland	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Ireland	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ireland	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ireland	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Ireland	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ireland	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ireland	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ireland	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ireland	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Ireland	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Ireland	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ireland	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ireland	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Ireland	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Ireland	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Ireland	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349

Ireland	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ireland	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Ireland	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Ireland	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Ireland	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Ireland	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Ireland	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Ireland	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ireland	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Ireland	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Ireland	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ireland	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ireland	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Ireland	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ireland	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Ireland	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Ireland	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Ireland	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ireland	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ireland	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ireland	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Ireland	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Ireland	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Ireland	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Ireland	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ireland	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ireland	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Ireland	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ireland	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Ireland	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Ireland	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Ireland	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Ireland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ireland	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Ireland	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Ireland	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ireland	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ireland	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ireland	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ireland	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Ireland	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ireland	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ireland	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ireland	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Ireland	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Ireland	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Ireland	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ireland	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Ireland	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ireland	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ireland	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Ireland	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ireland	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Ireland	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ireland	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ireland	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ireland	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Ireland	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ireland	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Ireland	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Ireland	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Ireland	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Ireland	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ireland	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ireland	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Ireland	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Ireland	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Ireland	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Ireland	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Ireland	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Ireland	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Ireland	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Ireland	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ireland	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Ireland	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ireland	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Ireland	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Ireland	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ireland	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		

Ireland	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ireland	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Ireland	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ireland	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ireland	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Ireland	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Ireland	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ireland	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Ireland	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Ireland	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ireland	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ireland	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ireland	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Ireland	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Ireland	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ireland	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Ireland	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Ireland	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Ireland	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Ireland	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Ireland	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Ireland	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Ireland	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Ireland	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Ireland	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Ireland	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Ireland	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Ireland	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Ireland	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Ireland	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		

XTOOL

Ireland	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Ireland	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Ireland	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Ireland	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Ireland	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Ireland	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Ireland	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Ireland	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Ireland	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Ireland	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Ireland	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Ireland	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Ireland	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Ireland	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Ireland	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Ireland	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Ireland	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Ireland	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Ireland	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Ireland	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Ireland	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Ireland	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Ireland	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Ireland	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Ireland	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Ireland	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Ireland	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Ireland	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ireland	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Ireland	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ireland	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Ireland	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Ireland	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ireland	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Ireland	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ireland	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Ireland	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ireland	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ireland	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Ireland	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ireland	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Ireland	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ireland	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ireland	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Ireland	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Ireland	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ireland	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ireland	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ireland	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Ireland	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Ireland	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Ireland	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ireland	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540

Ireland	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Ireland	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ireland	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Ireland	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Ireland	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Ireland	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Ireland	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Ireland	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Ireland	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ireland	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ireland	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Ireland	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Ireland	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Ireland	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Ireland	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Ireland	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Ireland	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Ireland	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Ireland	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Ireland	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Ireland	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Ireland	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Ireland	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Ireland	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ireland	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Ireland	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Ireland	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ireland	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ireland	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Ireland	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ireland	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ireland	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Ireland	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ireland	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Ireland	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ireland	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ireland	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ireland	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Ireland	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Ireland	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Ireland	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985. AC0986. AC0987. AC0988. AC0989	SP0563. SP0564. SP0565. SP0566. SP0567
Ireland	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Ireland	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971. AC0972. AC0973. AC0974. AC0975. AC0976. AC0977	SP0560
Ireland	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Ireland	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Ireland	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Ireland	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Ireland	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ireland	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ireland	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Ireland	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Ireland	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Ireland	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Ireland	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Ireland	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ireland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983. AC0984. AC0985. AC0986. AC0987. AC0988. AC0989. AC0990	SP0563. SP0564. SP0565. SP0566. SP0567
Ireland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894. AC0895. AC0896. AC0897. AC0898. AC0899. AC0900. AC0901. AC0902	SP0508. SP0509. SP0510
Ireland	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Ireland	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

Ireland	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Ireland	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Ireland	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ireland	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ireland	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Ireland	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ireland	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Ireland	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ireland	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ireland	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ireland	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Ireland	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ireland	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ireland	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ireland	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Ireland	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Ireland	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ireland	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Ireland	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ireland	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Ireland	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ireland	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Ireland	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ireland	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ireland	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Ireland	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Ireland	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Ireland	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Ireland	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Ireland	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Ireland	INFINITI QX50	I50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ireland	INFINITI QX50	I50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Ireland	INFINITI QX50	I50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ireland	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Ireland	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Ireland	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ireland	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ireland	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Ireland	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ireland	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ireland	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ireland	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ireland	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	

Ireland	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Ireland	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ireland	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ireland	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Ireland	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Ireland	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ireland	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Ireland	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Ireland	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Ireland	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Ireland	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Ireland	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ireland	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Ireland	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Ireland	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ireland	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Ireland	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Ireland	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Ireland	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ireland	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Ireland	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Ireland	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Ireland	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Ireland	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Ireland	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Ireland	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ireland	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ireland	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ireland	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Ireland	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Ireland	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ireland	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ireland	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Ireland	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ireland	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Ireland	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Ireland	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Ireland	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ireland	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ireland	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ireland	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Ireland	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Ireland	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ireland	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ireland	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Ireland	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Ireland	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Ireland	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Ireland	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Ireland	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ireland	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ireland	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ireland	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Ireland	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ireland	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Ireland	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Israel	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Israel	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Israel	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Israel	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Israel	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Israel	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Israel	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Israel	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Israel	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Israel	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Israel	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Israel	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Israel	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Israel	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Israel	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Israel	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Israel	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Israel	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Israel	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Israel	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Israel	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Israel	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Israel	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Israel	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Israel	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Israel	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Israel	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Israel	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556

Israel	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Israel	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Israel	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Israel	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Israel	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Israel	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Israel	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Israel	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Israel	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Israel	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Israel	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Israel	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Israel	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Israel	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Israel	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Israel	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Israel	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Israel	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Israel	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Israel	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Israel	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Israel	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Israel	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Israel	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Israel	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Israel	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Israel	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Israel	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Israel	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Israel	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Israel	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Israel	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Israel	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Israel	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Israel	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Israel	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Israel	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Israel	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494

Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Israel	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Israel	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Israel	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Israel	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Israel	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Israel	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Israel	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Israel	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Israel	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Israel	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Israel	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Israel	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Israel	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Israel	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Israel	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Israel	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Israel	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Israel	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Israel	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Israel	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Israel	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Israel	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Israel	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Israel	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Israel	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Israel	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Israel	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Israel	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Israel	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Israel	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Israel	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Israel	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Israel	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Israel	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Israel	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Israel	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Israel	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Israel	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Israel	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Israel	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Israel	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Israel	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Israel	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Israel	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Israel	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Israel	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497

Israel	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Israel	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Israel	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Israel	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Israel	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Israel	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Israel	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Israel	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Israel	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Israel	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Israel	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Israel	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Israel	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Israel	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Israel	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Israel	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Israel	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Israel	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Israel	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Israel	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Israel	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Israel	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Israel	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Israel	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Israel	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Israel	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Israel	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Israel	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Israel	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Israel	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Israel	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Israel	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	

Israel	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Israel	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Israel	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Israel	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Israel	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Israel	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Israel	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Israel	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Israel	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Israel	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Israel	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Israel	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Israel	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Israel	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Israel	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Israel	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Israel	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Israel	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Israel	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Israel	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Israel	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Israel	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Israel	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Israel	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Israel	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Israel	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Israel	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Israel	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Israel	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Israel	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Israel	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Israel	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Israel	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Israel	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Israel	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Israel	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Israel	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Israel	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Israel	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Israel	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Israel	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Israel	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Israel	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Israel	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Israel	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Israel	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Israel	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Israel	INFINITI Q50	V37	2013.6-	Occupant detection				√		SP0584
Israel	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Israel	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Israel	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Israel	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551

Israel	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Israel	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Israel	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Israel	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Israel	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Israel	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Israel	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Israel	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Israel	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Israel	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Israel	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Israel	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Israel	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Israel	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Israel	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Israel	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Israel	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Israel	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Israel	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Israel	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Israel	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Israel	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Israel	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Israel	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	

Israel	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Israel	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Israel	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Israel	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Israel	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Israel	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Israel	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Israel	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Israel	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Israel	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Israel	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Israel	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Israel	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Israel	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Israel	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Israel	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Israel	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Israel	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Israel	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Israel	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Israel	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Israel	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Israel	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Israel	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Israel	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Israel	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Israel	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Israel	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Israel	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Israel	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Israel	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Israel	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Israel	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Israel	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Israel	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Israel	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Israel	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Israel	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Israel	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Israel	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Israel	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Israel	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Israel	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Israel	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Israel	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Israel	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Israel	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Israel	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Israel	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Israel	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Israel	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Israel	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Israel	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	

Israel	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Israel	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Israel	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Israel	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Israel	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Israel	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Israel	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Israel	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Israel	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Israel	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Israel	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Israel	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Israel	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Israel	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Israel	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Israel	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Israel	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Israel	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Israel	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Israel	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Israel	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Israel	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Israel	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Israel	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Israel	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Israel	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Israel	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Israel	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Israel	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Israel	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Israel	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Israel	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Israel	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Israel	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Israel	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Israel	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Israel	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Israel	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Israel	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Israel	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Israel	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Israel	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Israel	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Israel	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Israel	INFINITI QX50	I50	2013.9-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Israel	INFINITI QX50	I50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Israel	INFINITI QX50	I50	2013.9-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Israel	INFINITI QX50	I50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Israel	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Israel	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Israel	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Israel	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Israel	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Israel	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Israel	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Israel	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Israel	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Israel	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Israel	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347,SP0348
Israel	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Israel	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270
Israel	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613,AC0653,AC0663,AC0689,AC0692,AC0695,AC0702,AC0719	SP0372,SP0429
Israel	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Israel	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Israel	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Israel	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Israel	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Israel	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Israel	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Israel	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Israel	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Israel	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570,SP0571
Israel	INFINITI QX60	L50	2013.11-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Israel	INFINITI QX60	L50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Israel	INFINITI QX60	L50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI QX60	L50	2013.11-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Israel	INFINITI QX60	L50	2013.11-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Israel	INFINITI QX60	L50	2013.11-	Air bag	√	√	√	√		
Israel	INFINITI QX60	L50	2013.11-	EPS/DAST 3	√	√	√	√		
Israel	INFINITI QX60	L50	2013.11-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Israel	INFINITI QX60	L50	2013.11-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Israel	INFINITI QX60	L50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246,SP0274,SP0275,SP0276,SP0278,SP0279,SP0281,SP0282,SP0283,SP0287,SP0288,SP0289,SP0290,SP0292
Israel	INFINITI QX60	L50	2013.11-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Israel	INFINITI QX60	L50	2013.11-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Israel	INFINITI QX60	L50	2013.11-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI QX60	L50	2013.11-	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0487
Israel	INFINITI QX60	L50	2013.11-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Israel	INFINITI QX60	L50	2013.11-	Auto back door	√	√	√	√		SP0611
Israel	INFINITI QX60	L50	2013.11-	Occupant detection			√	√		SP0584
Israel	INFINITI QX60	L50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Israel	INFINITI QX60	L50	2013.11-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Israel	INFINITI QX60	L50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Israel	INFINITI QX60	L50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Israel	INFINITI QX60	L50	2013.11-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Israel	INFINITI QX60	L50	2013.11-	CAN gateway	√	√	√			
Israel	INFINITI QX60	L50	2013.11-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Israel	INFINITI QX60	L50	2013.11-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Israel	INFINITI QX60	L50	2013.11-	ANC	√	√	√	√	AC1024	
Israel	INFINITI QX60	L50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Israel	INFINITI QX60	L50	2013.11-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Israel	INFINITI QX60	L50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Israel	INFINITI QX60	L50	2013.11-	3ch CAN GATEWAY	√	√	√	√		
Israel	INFINITI QX60	L50	2013.11-	ICC/ADAS 2	√	√	√	√		
Israel	INFINITI QX60	L50	2013.11-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Israel	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Israel	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Israel	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Israel	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Israel	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Israel	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Israel	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Israel	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Israel	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Israel	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Israel	INFINITI QX70	S51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Israel	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Israel	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Israel	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Israel	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Israel	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Israel	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Israel	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Israel	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Israel	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Israel	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Israel	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0555,SP0556,SP0557
Israel	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Israel	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Israel	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Israel	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Israel	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Israel	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Israel	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Israel	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Israel	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Israel	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Israel	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Italy	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Italy	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Italy	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Italy	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Italy	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350

Italy	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Italy	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Italy	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Italy	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Italy	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Italy	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Italy	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Italy	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Italy	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Italy	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Italy	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Italy	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Italy	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Italy	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Italy	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Italy	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Italy	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Italy	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Italy	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Italy	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Italy	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Italy	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Italy	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Italy	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Italy	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Italy	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Italy	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Italy	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Italy	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Italy	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Italy	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Italy	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Italy	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Italy	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Italy	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Italy	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Italy	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Italy	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Italy	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Italy	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Italy	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Italy	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Italy	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Italy	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Italy	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Italy	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Italy	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Italy	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Italy	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Italy	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Italy	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Italy	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611

Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Italy	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Italy	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Italy	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Italy	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Italy	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Italy	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Italy	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Italy	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Italy	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Italy	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Italy	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Italy	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Italy	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Italy	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Italy	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Italy	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Italy	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Italy	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Italy	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Italy	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Italy	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Italy	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Italy	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Italy	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Italy	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Italy	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Italy	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Italy	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Italy	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Italy	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Italy	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Italy	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Italy	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Italy	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Italy	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Italy	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Italy	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Italy	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Italy	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Italy	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Italy	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Italy	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Italy	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Italy	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Italy	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Italy	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Italy	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Italy	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Italy	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Italy	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Italy	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Italy	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Italy	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Italy	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Italy	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Italy	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Italy	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Italy	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Italy	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Italy	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Italy	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Italy	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Italy	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Italy	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Italy	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Italy	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Italy	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Italy	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Italy	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Italy	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Italy	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Italy	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Italy	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Italy	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Italy	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Italy	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Italy	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Italy	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Italy	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	

Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Italy	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Italy	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Italy	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Italy	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Italy	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Italy	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Italy	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Italy	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Italy	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Italy	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Italy	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Italy	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Italy	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Italy	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Italy	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Italy	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Italy	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Italy	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Italy	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Italy	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Italy	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Italy	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Italy	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Italy	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Italy	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Italy	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Italy	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Italy	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Italy	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Italy	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Italy	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Italy	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Italy	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Italy	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Italy	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Italy	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Italy	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Italy	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		

XTOOL

Italy	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Italy	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Italy	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509
Italy	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Italy	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0869、AC0870、AC0871、AC0872、AC0873、AC0874、AC0875、AC0876、AC0877、AC0878、AC0879、AC0880、AC0881、AC0882、AC0883、AC0884、AC0885	SP0494、SP0495、SP0496、SP0497
Italy	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Italy	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Italy	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Italy	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348、SP0349、SP0350、SP0351
Italy	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Italy	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0225、AC0226、AC0229、AC0256、AC0266、AC0270、AC0272、AC0277、AC0282、AC0283、AC0284、AC0307、AC0308、AC0309、AC0311、AC0312、AC0313、AC0314、AC0315、AC0316、AC0317、AC0318、AC0319、AC0320、AC0321、AC0322、AC0323、AC0324、AC0325、AC0326、AC0327、AC0330、AC0331、AC0332、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0009、SP0016、SP0017、SP0018、SP0032、SP0033、SP0034、SP0038、SP0039、SP0043、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0082、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0128、SP0140、SP0143、SP0150、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0193、SP0194、SP0195、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Italy	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247、SP0265、SP0274、SP0276
Italy	INFINITI Q50	V37	2013.6-	BCM				√	AC0613、AC0618、AC0663、AC0690、AC0692、AC0702	SP0372、SP0429
Italy	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498、AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533、AC0536	SP0300、SP0313、SP0315
Italy	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Italy	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472、SP0473、SP0474、SP0475、SP0477、SP0479、SP0480、SP0481、SP0482、SP0486、SP0487
Italy	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Italy	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034、AC1035、AC1036、AC1037、AC1038、AC1039	
Italy	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027、AC1028	
Italy	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Italy	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084、AC1085、AC1086、AC1087、AC1088、AC1089、AC1106	
Italy	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Italy	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980、AC0981、AC0982	SP0561、SP0562
Italy	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Italy	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962、AC0963、AC0964、AC0966、AC0967、AC0968、AC0969、AC0970	SP0553、SP0554、SP0555、SP0556、SP0557、SP0558、SP0559
Italy	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956、AC0958、AC0959、AC0960	SP0544、SP0545、SP0546、SP0547、SP0548、SP0549、SP0550、SP0551
Italy	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Italy	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Italy	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983、AC0984、AC0985、AC0986、AC0987、AC0988、AC0989、AC0990	SP0563、SP0564、SP0565、SP0566、SP0567
Italy	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511、SP0515、SP0516、SP0538、SP0539、SP0540
Italy	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Italy	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973、AC0974、AC0976、AC0977	
Italy	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Italy	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604、SP0605、SP0606
Italy	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043、AC1044、AC1045、AC1046、AC1047、AC1048、AC1049、AC1050、AC1051、AC1052、AC1053、AC1054、AC1055、AC1056、AC1057、AC1058、AC1059、AC1060、AC1061、AC1062、AC1063、AC1064、AC1065、AC1066、AC1067、AC1068、AC1069、AC1070、AC1071、AC1072、AC1073、AC1074、AC1075、AC1076、AC1077	
Italy	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014、AC1015、AC1016、AC1017、AC1018、AC1019、AC1020、AC1021、AC1022、AC1023	
Italy	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Italy	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Italy	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111、AC1112	SP0608、SP0609、SP0610
Italy	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590、SP0591、SP0592
Italy	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Italy	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Italy	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Italy	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Italy	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Italy	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Italy	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Italy	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Italy	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122、AC1123、AC1124、AC1125、AC1126	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0869、AC0870、AC0871、AC0872、AC0873、AC0874、AC0875、AC0876、AC0877、AC0878、AC0879、AC0880、AC0881、AC0882、AC0883、AC0884、AC0885	SP0494、SP0495、SP0496、SP0497
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348、SP0349、SP0350、SP0351
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0225、AC0226、AC0229、AC0256、AC0282、AC0283、AC0284、AC0307、AC0311、AC0314、AC0315、AC0320、AC0325、AC0327、AC0330、AC0331、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0009、SP0016、SP0017、SP0018、SP0032、SP0033、SP0034、SP0038、SP0039、SP0043、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0082、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0140、SP0143、SP0150、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0193、SP0194、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247、SP0265、SP0274、SP0276
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613、AC0618、AC0663、AC0690、AC0692、AC0702	SP0372、SP0429
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498、AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533、AC0536	SP0300、SP0313、SP0315
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472、SP0473、SP0474、SP0475、SP0477、SP0479、SP0480、SP0481、SP0482、SP0486、SP0487
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084、AC1085、AC1086、AC1087、AC1088、AC1089、AC1106	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980、AC0981、AC0982	SP0561、SP0562
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966、AC0967、AC0968	SP0557
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985、AC0986、AC0987、AC0988、AC0989	SP0563、SP0564、SP0565、SP0566、SP0567
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973、AC0974、AC0976、AC0977	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043、AC1044、AC1045、AC1046、AC1047、AC1048、AC1049、AC1050、AC1051、AC1052、AC1053、AC1054、AC1055、AC1056、AC1057、AC1058、AC1059、AC1060、AC1061、AC1062、AC1063、AC1064、AC1065、AC1066、AC1067、AC1068、AC1069、AC1070、AC1071、AC1072、AC1073、AC1074、AC1075、AC1076、AC1077	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014、AC1015、AC1016、AC1017、AC1018、AC1019、AC1020、AC1021	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590、SP0591、SP0592
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Italy	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122、AC1123、AC1124、AC1125、AC1126	
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509

Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Italy	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Italy	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Italy	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Italy	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Italy	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Italy	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Italy	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Italy	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Italy	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Italy	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Italy	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Italy	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Italy	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Italy	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Italy	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Italy	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Italy	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Italy	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Italy	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Italy	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Italy	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Italy	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Italy	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Italy	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Italy	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Italy	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Italy	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Italy	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Italy	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Italy	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Italy	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Italy	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Italy	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Italy	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Italy	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Italy	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Italy	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Italy	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Italy	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Italy	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Italy	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Italy	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Italy	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Italy	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Italy	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Italy	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Italy	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Italy	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Italy	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Italy	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Italy	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Italy	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Italy	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Italy	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Italy	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Italy	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Italy	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Italy	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Italy	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Italy	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Italy	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Italy	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Italy	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Italy	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Italy	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Italy	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Italy	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Italy	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Italy	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Italy	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Italy	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Italy	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Italy	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Italy	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Italy	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Italy	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Italy	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Italy	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Italy	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Italy	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Italy	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Italy	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Italy	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503

Italy	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Italy	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Italy	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Italy	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Italy	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Italy	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Italy	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Italy	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Italy	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Italy	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Italy	INFINITI QX50	I50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Italy	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Italy	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI QX50	I50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Italy	INFINITI QX50	I50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Italy	INFINITI QX50	I50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Italy	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Italy	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Italy	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Italy	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Italy	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Italy	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Italy	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Italy	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Italy	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Italy	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Italy	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Italy	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Italy	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Italy	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Italy	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Italy	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Italy	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Italy	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Italy	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Italy	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Italy	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Italy	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Italy	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Italy	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Italy	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Italy	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Italy	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Italy	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Italy	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Italy	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Italy	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Italy	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Italy	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Italy	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Italy	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Italy	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Italy	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Italy	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Italy	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Italy	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Italy	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Italy	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Italy	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Italy	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Italy	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Italy	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Italy	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Italy	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Italy	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Italy	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Italy	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Italy	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Italy	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Italy	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Italy	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Italy	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583

Italy	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Ivory coast	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ivory coast	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Ivory coast	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ivory coast	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Ivory coast	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ivory coast	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ivory coast	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ivory coast	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ivory coast	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ivory coast	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ivory coast	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Ivory coast	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ivory coast	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Ivory coast	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ivory coast	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Ivory coast	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Ivory coast	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Ivory coast	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Ivory coast	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Ivory coast	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Ivory coast	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Ivory coast	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Ivory coast	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Ivory coast	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Ivory coast	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Ivory coast	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Ivory coast	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Ivory coast	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Ivory coast	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Ivory coast	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Ivory coast	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Ivory coast	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Ivory coast	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Ivory coast	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Ivory coast	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Ivory coast	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Ivory coast	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Ivory coast	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Ivory coast	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Ivory coast	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ivory coast	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Ivory coast	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ivory coast	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Ivory coast	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Ivory coast	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Ivory coast	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ivory coast	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Ivory coast	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ivory coast	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Ivory coast	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Ivory coast	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ivory coast	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ivory coast	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Ivory coast	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Ivory coast	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ivory coast	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ivory coast	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Ivory coast	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Ivory coast	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Ivory coast	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ivory coast	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Ivory coast	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ivory coast	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ivory coast	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Ivory coast	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Ivory coast	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Ivory coast	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ivory coast	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Ivory coast	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Ivory coast	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ivory coast	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ivory coast	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Ivory coast	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Ivory coast	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			

Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Ivory coast	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Ivory coast	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ivory coast	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Ivory coast	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ivory coast	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Ivory coast	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Ivory coast	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ivory coast	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ivory coast	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Ivory coast	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ivory coast	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ivory coast	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Ivory coast	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ivory coast	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ivory coast	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Ivory coast	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ivory coast	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ivory coast	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ivory coast	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Ivory coast	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Ivory coast	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Ivory coast	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Ivory coast	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Ivory coast	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Ivory coast	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ivory coast	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Ivory coast	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Ivory coast	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Ivory coast	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Ivory coast	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ivory coast	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ivory coast	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Ivory coast	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Ivory coast	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Ivory coast	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Ivory coast	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

XTOOL

Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ivory coast	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ivory coast	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ivory coast	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Ivory coast	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Ivory coast	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ivory coast	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Ivory coast	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Ivory coast	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ivory coast	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ivory coast	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Ivory coast	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ivory coast	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Ivory coast	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Ivory coast	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ivory coast	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ivory coast	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Ivory coast	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562

Ivory coast	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ivory coast	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Ivory coast	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Ivory coast	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Ivory coast	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ivory coast	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Ivory coast	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ivory coast	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ivory coast	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ivory coast	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Ivory coast	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ivory coast	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Ivory coast	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ivory coast	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Ivory coast	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ivory coast	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Ivory coast	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Ivory coast	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ivory coast	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ivory coast	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Ivory coast	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ivory coast	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ivory coast	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ivory coast	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ivory coast	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ivory coast	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Ivory coast	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Ivory coast	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ivory coast	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Ivory coast	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ivory coast	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Ivory coast	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Ivory coast	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ivory coast	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Ivory coast	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Ivory coast	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Ivory coast	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ivory coast	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Ivory coast	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Ivory coast	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ivory coast	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ivory coast	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Ivory coast	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ivory coast	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Ivory coast	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Ivory coast	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ivory coast	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ivory coast	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Ivory coast	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Ivory coast	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ivory coast	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	

XTOOL

Ivory coast	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ivory coast	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Ivory coast	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Ivory coast	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ivory coast	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Ivory coast	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ivory coast	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ivory coast	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ivory coast	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Ivory coast	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Ivory coast	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ivory coast	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Ivory coast	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Ivory coast	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ivory coast	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Ivory coast	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ivory coast	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ivory coast	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ivory coast	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Ivory coast	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Ivory coast	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ivory coast	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ivory coast	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ivory coast	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ivory coast	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Ivory coast	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Ivory coast	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Ivory coast	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Ivory coast	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ivory coast	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Ivory coast	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Ivory coast	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ivory coast	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ivory coast	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ivory coast	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Ivory coast	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Ivory coast	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Ivory coast	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Ivory coast	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ivory coast	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ivory coast	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Ivory coast	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ivory coast	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Ivory coast	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Ivory coast	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Ivory coast	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Ivory coast	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Jamaica	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jamaica	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Jamaica	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jamaica	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Jamaica	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Jamaica	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Jamaica	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jamaica	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Jamaica	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Jamaica	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jamaica	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jamaica	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jamaica	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jamaica	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Jamaica	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Jamaica	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Jamaica	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jamaica	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Jamaica	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Jamaica	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Jamaica	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jamaica	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Jamaica	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Jamaica	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Jamaica	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Jamaica	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Jamaica	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jamaica	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Jamaica	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Jamaica	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Jamaica	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Jamaica	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jamaica	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Jamaica	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Jamaica	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jamaica	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Jamaica	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Jamaica	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Jamaica	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Jamaica	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Jamaica	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Jamaica	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Jamaica	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Jamaica	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jamaica	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Jamaica	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jamaica	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Jamaica	INFINITI TX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Jamaica	INFINITI TX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Jamaica	INFINITI TX35	L50	2012.9-	CAN gateway	√	√	√			
Jamaica	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Jamaica	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Jamaica	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Jamaica	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Jamaica	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Jamaica	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jamaica	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Jamaica	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Jamaica	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jamaica	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Jamaica	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Jamaica	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Jamaica	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Jamaica	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Jamaica	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Jamaica	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Jamaica	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Jamaica	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Jamaica	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Jamaica	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jamaica	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jamaica	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jamaica	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jamaica	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jamaica	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Jamaica	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Jamaica	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Jamaica	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Jamaica	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jamaica	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Jamaica	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Jamaica	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Jamaica	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Jamaica	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Jamaica	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Jamaica	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Jamaica	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Jamaica	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Jamaica	INFINITI Q45	F50	2001.8-	Motor control						
Jamaica	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jamaica	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Jamaica	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Jamaica	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Jamaica	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Jamaica	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Jamaica	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Jamaica	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jamaica	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Jamaica	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Jamaica	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Jamaica	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jamaica	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Jamaica	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Jamaica	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Jamaica	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Jamaica	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jamaica	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Jamaica	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Jamaica	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Jamaica	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Jamaica	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Jamaica	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Jamaica	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Jamaica	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Jamaica	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Jamaica	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Jamaica	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Jamaica	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Jamaica	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894. AC0895. AC0896	SP0510
Jamaica	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Jamaica	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Jamaica	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Jamaica	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Jamaica	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347. SP0348. SP0349. SP0350. SP0351
Jamaica	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jamaica	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Jamaica	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Jamaica	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Jamaica	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Jamaica	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Jamaica	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Jamaica	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jamaica	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Jamaica	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Jamaica	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jamaica	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Jamaica	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553. SP0554. SP0556
Jamaica	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544. SP0545. SP0546. SP0547. SP0548. SP0549
Jamaica	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985. AC0986. AC0987. AC0988. AC0989	SP0563. SP0564. SP0565. SP0566. SP0567
Jamaica	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Jamaica	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Jamaica	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Jamaica	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Jamaica	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Japan	INFINITI EX35	J50	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Japan	INFINITI EX35	J50	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Japan	INFINITI EX35	J50	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Japan	INFINITI EX35	J50	2009.6-	Air bag	√	√	√	√		
Japan	INFINITI EX35	J50	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Japan	INFINITI EX35	J50	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187. AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Japan	INFINITI EX35	J50	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Japan	INFINITI EX35	J50	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Japan	INFINITI EX35	J50	2009.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Japan	INFINITI EX35	J50	2009.6-	Multi AV	√	√	√	√		SP0503
Japan	INFINITI EX35	J50	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Japan	INFINITI EX35	J50	2009.6-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980	SP0561. SP0562
Japan	INFINITI EX35	J50	2009.6-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Japan	INFINITI EX35	J50	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Japan	INFINITI EX35	J50	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Japan	INFINITI EX35	J50	2009.6-	Precrash seatbelt	√	√	√	√		SP0612
Japan	INFINITI EX35	J50	2009.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Japan	INFINITI M35H	HY51	2010.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Japan	INFINITI M35H	HY51	2010.10-	Laser/radar	√	√	√	√	AC0994	
Japan	INFINITI M35H	HY51	2010.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Japan	INFINITI M35H	HY51	2010.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Japan	INFINITI M35H	HY51	2010.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Japan	INFINITI M35H	HY51	2010.10-	Air bag	√	√	√	√		
Japan	INFINITI M35H	HY51	2010.10-	EPS/DAST 3	√	√	√	√		
Japan	INFINITI M35H	HY51	2010.10-	Meter/M&A	√	√	√	√		SP0348. SP0349. SP0350. SP0351
Japan	INFINITI M35H	HY51	2010.10-	Motor control	√	√	√	√		
Japan	INFINITI M35H	HY51	2010.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Japan	INFINITI M35H	HY51	2010.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Japan	INFINITI M35H	HY51	2010.10-	BCM				√	AC0613. AC0618. AC0663. AC0690. AC0692. AC0702	SP0372. SP0429. SP0471
Japan	INFINITI M35H	HY51	2010.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Japan	INFINITI M35H	HY51	2010.10-	Diag data recorder	√					
Japan	INFINITI M35H	HY51	2010.10-	Pop up hood	√	√	√	√		
Japan	INFINITI M35H	HY51	2010.10-	Multi AV	√	√	√	√		SP0503
Japan	INFINITI M35H	HY51	2010.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Japan	INFINITI M35H	HY51	2010.10-	HV battery	√	√	√	√	AC1121	
Japan	INFINITI M35H	HY51	2010.10-	E-SUS	√	√	√	√	AC1034. AC1035. AC1036. AC1037. AC1038. AC1039	
Japan	INFINITI M35H	HY51	2010.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Japan	INFINITI M35H	HY51	2010.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Japan	INFINITI M35H	HY51	2010.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Japan	INFINITI M35H	HY51	2010.10-	Occupant detection			√	√		SP0584
Japan	INFINITI M35H	HY51	2010.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Japan	INFINITI M35H	HY51	2010.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Japan	INFINITI M35H	HY51	2010.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Japan	INFINITI M35H	HY51	2010.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Japan	INFINITI M35H	HY51	2010.10-	DAST 2	√	√	√	√		
Japan	INFINITI M35H	HY51	2010.10-	Precrash seatbelt	√	√	√	√		SP0612
Japan	INFINITI M35H	HY51	2010.10-	AVM	√	√	√	√	AC0985. AC0986. AC0987. AC0988. AC0989	SP0563. SP0564. SP0565. SP0566. SP0567
Japan	INFINITI M35H	HY51	2010.10-	CAN gateway	√	√	√			
Japan	INFINITI M35H	HY51	2010.10-	Lane camera	√	√	√	√	AC0973. AC0974. AC0976. AC0977	
Japan	INFINITI M35H	HY51	2010.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Japan	INFINITI M35H	HY51	2010.10-	DAST 1	√	√	√	√		
Japan	INFINITI M35H	HY51	2010.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Japan	INFINITI M35H	HY51	2010.10-	BSW/buzzer	√	√	√	√	AC1014. AC1015. AC1016. AC1017. AC1018. AC1019. AC1020. AC1021	
Japan	INFINITI M35H	HY51	2010.10-	ANC	√	√	√	√	AC1024	

Japan	INFINITI M35H	HY51	2010.10-	Side radar left	√	√	√	√	AC1025	SP0582
Japan	INFINITI M35H	HY51	2010.10-	Telematics						
Japan	INFINITI M35H	HY51	2010.10-	HIGH BEAM ASSIST	√	√	√	√		
Japan	INFINITI M35H	HY51	2010.10-	Side radar right	√	√	√	√	AC1026	SP0583
Japan	INFINITI M35H	HY51	2010.10-	Brake	√	√	√	√	AC1127	
Japan	INFINITI M35H	HY51	2010.10-	6ch CAN GATEWAY	√	√	√	√		
Japan	INFINITI M35H	HY51	2010.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		SP0507
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0265, SP0274, SP0276
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics						
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	6ch CAN GATEWAY	√	√	√	√		
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	3ch CAN GATEWAY	√	√	√	√		
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS 2	√	√	√	√		
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	FSCM	√	√	√	√	AC1109	
Japan	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Laser/radar	√	√	√	√		
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Air bag	√	√	√	√		
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	EPS/DAST 3	√	√	√	√		
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Motor control	√	√	√	√		
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Transmission	√	√	√	√		SP0276
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Pop up hood	√	√	√	√		
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Multi AV	√	√	√	√		SP0503
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	HV battery	√	√	√	√	AC1121	
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Occupant detection			√	√		SP0584
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	DAST 2	√	√	√	√		
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Precrash seatbelt	√	√	√	√		SP0612
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Lane camera	√	√	√	√		
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	DAST 1	√	√	√	√		
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Side radar left	√	√	√	√	AC1025	SP0582
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	HIGH BEAM ASSIST	√	√	√	√		
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Side radar right	√	√	√	√	AC1026	SP0583
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	VSP	√	√	√	√		
Japan	INFINITI Q50 Hybrid	HV37	2018.3-	Brake	√	√	√	√	AC1127	
Jordan	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Jordan	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Jordan	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Jordan	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Jordan	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Jordan	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jordan	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Jordan	INFINITI EX35	I50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI EX35	I50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jordan	INFINITI EX35	I50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Jordan	INFINITI EX35	I50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Jordan	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Jordan	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Jordan	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Jordan	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Jordan	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Jordan	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jordan	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jordan	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI EX35/EX37	I50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jordan	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Jordan	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Jordan	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Jordan	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Jordan	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Jordan	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Jordan	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Jordan	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Jordan	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Jordan	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Jordan	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Jordan	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Jordan	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Jordan	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Jordan	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Jordan	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Jordan	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Jordan	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Jordan	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Jordan	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Jordan	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Jordan	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Jordan	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Jordan	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Jordan	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Jordan	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Jordan	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Jordan	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Jordan	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Jordan	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Jordan	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Jordan	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Jordan	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Jordan	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Jordan	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Jordan	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Jordan	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Jordan	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Jordan	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jordan	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Jordan	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Jordan	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Jordan	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Jordan	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Jordan	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jordan	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Jordan	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Jordan	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Jordan	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Jordan	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		

Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Jordan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Jordan	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Jordan	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Jordan	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Jordan	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Jordan	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Jordan	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Jordan	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Jordan	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Jordan	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Jordan	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Jordan	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Jordan	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Jordan	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Jordan	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Jordan	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Jordan	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Jordan	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Jordan	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Jordan	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	

Jordan	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Jordan	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Jordan	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Jordan	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Jordan	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Jordan	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Jordan	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Jordan	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Jordan	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Jordan	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jordan	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Jordan	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Jordan	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Jordan	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jordan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Jordan	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Jordan	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Jordan	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Jordan	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jordan	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Jordan	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jordan	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jordan	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jordan	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Jordan	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Jordan	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Jordan	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Jordan	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Jordan	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Jordan	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jordan	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Jordan	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jordan	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jordan	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jordan	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Jordan	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Jordan	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Jordan	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Jordan	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Jordan	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Jordan	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

XTOOL

Jordan	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Jordan	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Jordan	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Jordan	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Jordan	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Jordan	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Jordan	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Jordan	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Jordan	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Jordan	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Jordan	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Jordan	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Jordan	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Jordan	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Jordan	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Jordan	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Jordan	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Jordan	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Jordan	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Jordan	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Jordan	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Jordan	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Jordan	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Jordan	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Jordan	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Jordan	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Jordan	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Jordan	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Jordan	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Jordan	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Jordan	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Jordan	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Jordan	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Jordan	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Jordan	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Jordan	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Jordan	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jordan	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jordan	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jordan	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Jordan	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Jordan	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Jordan	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Jordan	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Jordan	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Jordan	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Jordan	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Jordan	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Jordan	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Jordan	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Jordan	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Jordan	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Jordan	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Jordan	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Jordan	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Jordan	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Jordan	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					

Jordan	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Jordan	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Jordan	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Jordan	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Jordan	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Jordan	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Jordan	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Jordan	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Jordan	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Jordan	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Jordan	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Jordan	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Jordan	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Jordan	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Jordan	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Jordan	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Jordan	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Jordan	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Jordan	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Jordan	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Jordan	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Jordan	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Jordan	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Jordan	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Jordan	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Jordan	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Jordan	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Jordan	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Jordan	INFINITI Q45	F50	2001.8-	Motor control						
Jordan	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Jordan	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Jordan	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Jordan	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Jordan	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Jordan	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Jordan	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Jordan	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Jordan	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537

Jordan	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Jordan	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Jordan	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Jordan	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Jordan	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Jordan	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Jordan	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Jordan	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Jordan	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Jordan	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Jordan	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Jordan	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Jordan	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Jordan	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Jordan	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Jordan	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Jordan	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Jordan	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Jordan	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Jordan	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, ,AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392 ,AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Jordan	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Jordan	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Jordan	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Jordan	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Jordan	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Jordan	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jordan	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Jordan	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Jordan	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Jordan	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Jordan	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Jordan	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Jordan	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Jordan	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Jordan	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Jordan	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Jordan	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Jordan	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Jordan	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Jordan	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Jordan	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Jordan	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Jordan	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Jordan	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Jordan	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Jordan	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Jordan	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Jordan	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Jordan	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, ,AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	

Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Jordan	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Jordan	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Jordan	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Jordan	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Jordan	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Jordan	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Jordan	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Jordan	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Jordan	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Jordan	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Jordan	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Jordan	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Jordan	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Jordan	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jordan	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Jordan	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Jordan	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Jordan	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Jordan	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Jordan	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Jordan	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Jordan	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Jordan	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Jordan	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Jordan	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Jordan	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Jordan	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Jordan	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Jordan	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Jordan	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Jordan	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Jordan	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Jordan	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Jordan	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Jordan	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Jordan	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Jordan	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Jordan	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Jordan	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Jordan	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Jordan	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Jordan	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Jordan	INFINITI Q70	Y51	2013.9-	HV batterv	√	√	√	√	AC1121	
Jordan	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Jordan	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jordan	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Jordan	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Jordan	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Jordan	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Jordan	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Jordan	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Jordan	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Jordan	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Jordan	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Jordan	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Jordan	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Jordan	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Jordan	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Jordan	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Jordan	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Jordan	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Jordan	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Jordan	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Jordan	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		

Jordan	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Jordan	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Jordan	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Jordan	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Jordan	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jordan	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Jordan	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jordan	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Jordan	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Jordan	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Jordan	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Jordan	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590. SP0591. SP0592
Jordan	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894. AC0895. AC0896. AC0898. AC0900. AC0901. AC0902	SP0508. SP0510
Jordan	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Jordan	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Jordan	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Jordan	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Jordan	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Jordan	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Jordan	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Jordan	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Jordan	INFINITI QX50	J55	2018.5-	Shift						
Jordan	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Jordan	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	ANC						
Jordan	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Jordan	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Jordan	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Jordan	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894. AC0895. AC0896. AC0897. AC0898. AC0899. AC0900. AC0901. AC0902	SP0508. SP0509. SP0510
Jordan	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492. SP0493
Jordan	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865. AC0866. AC0867. AC0868. AC0876. AC0877. AC0884	SP0494
Jordan	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Jordan	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Jordan	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Jordan	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Jordan	INFINITI QX56	JA60	2004.10-	Motor control						
Jordan	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Jordan	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Jordan	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Jordan	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Jordan	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Jordan	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Jordan	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Jordan	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Jordan	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Jordan	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Jordan	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Jordan	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Jordan	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Jordan	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Jordan	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Jordan	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Jordan	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Jordan	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Jordan	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Jordan	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Jordan	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			

Jordan	INFINITI QX56	IA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Jordan	INFINITI QX56	IA60	2004.10-	Smart entrance						SP0568
Jordan	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Jordan	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Jordan	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Jordan	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Jordan	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Jordan	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270, SP0274
Jordan	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Jordan	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Jordan	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Jordan	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Jordan	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Jordan	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Jordan	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jordan	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Jordan	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Jordan	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Jordan	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Jordan	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Jordan	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Jordan	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Jordan	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Jordan	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Jordan	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Jordan	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Jordan	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Jordan	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Jordan	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Jordan	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Jordan	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Jordan	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Jordan	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Jordan	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Jordan	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Jordan	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Jordan	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Jordan	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Jordan	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Jordan	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Jordan	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Jordan	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Jordan	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Jordan	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Jordan	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Jordan	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		

Jordan	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Jordan	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Jordan	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Jordan	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Jordan	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Jordan	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Jordan	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Jordan	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Jordan	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Jordan	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Jordan	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Jordan	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Jordan	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Jordan	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jordan	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Jordan	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Jordan	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Jordan	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Jordan	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Jordan	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Jordan	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Jordan	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Jordan	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Jordan	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Jordan	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Jordan	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Jordan	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Jordan	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Jordan	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Jordan	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Jordan	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Jordan	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Jordan	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Jordan	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Jordan	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Jordan	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Jordan	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Jordan	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Jordan	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Jordan	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031. AC1032. AC1033	SP0585. SP0586. SP0587
Jordan	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Jordan	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Jordan	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Jordan	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Jordan	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Jordan	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Jordan	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Jordan	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Jordan	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Jordan	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Jordan	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Jordan	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Jordan	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Jordan	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Jordan	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Jordan	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Jordan	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Jordan	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Jordan	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Jordan	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Jordan	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Jordan	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Jordan	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kazakhsta n	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Kazakhsta n	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kazakhsta n	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Kazakhsta n	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Kazakhsta	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Kazakhsta	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Kazakhstan	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Kazakhstan	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Kazakhstan	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Kazakhstan	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Kazakhstan	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Kazakhstan	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Kazakhstan	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kazakhstan	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhstan	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Kazakhstan	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Kazakhstan	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Kazakhstan	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kazakhstan	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Kazakhstan	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhstan	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhstan	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Kazakhstan	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kazakhstan	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Kazakhstan	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Kazakhstan	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kazakhstan	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kazakhstan	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Kazakhstan	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhstan	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Kazakhstan	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Kazakhstan	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	

Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Kazakhstan	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Kazakhstan	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Kazakhstan	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kazakhstan	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Kazakhstan	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Kazakhstan	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Kazakhstan	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhstan	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kazakhstan	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhstan	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Kazakhstan	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Kazakhstan	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kazakhstan	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Kazakhstan	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kazakhstan	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Kazakhstan	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kazakhstan	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kazakhstan	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Kazakhstan	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Kazakhstan	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Kazakhstan	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kazakhstan	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Kazakhstan	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhstan	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Kazakhstan	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kazakhstan	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kazakhstan	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kazakhstan	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Kazakhstan	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Kazakhstan	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kazakhstan	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Kazakhstan	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Kazakhstan	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Kazakhstan	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		

Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Kazakhstan	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Kazakhstan	INFINITI Q50	V37	2017.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kazakhstan	INFINITI Q50	V37	2017.7-	Laser/radar	√	√	√	√	AC0994	
Kazakhstan	INFINITI Q50	V37	2017.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhstan	INFINITI Q50	V37	2017.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kazakhstan	INFINITI Q50	V37	2017.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhstan	INFINITI Q50	V37	2017.7-	Air bag	√	√	√	√		
Kazakhstan	INFINITI Q50	V37	2017.7-	EPS/DAST 3	√	√	√	√		SP0507
Kazakhstan	INFINITI Q50	V37	2017.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kazakhstan	INFINITI Q50	V37	2017.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kazakhstan	INFINITI Q50	V37	2017.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Kazakhstan	INFINITI Q50	V37	2017.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kazakhstan	INFINITI Q50	V37	2017.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kazakhstan	INFINITI Q50	V37	2017.7-	Pop up hood	√	√	√	√		
Kazakhstan	INFINITI Q50	V37	2017.7-	Multi AV	√	√	√	√		SP0503
Kazakhstan	INFINITI Q50	V37	2017.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kazakhstan	INFINITI Q50	V37	2017.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhstan	INFINITI Q50	V37	2017.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kazakhstan	INFINITI Q50	V37	2017.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kazakhstan	INFINITI Q50	V37	2017.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kazakhstan	INFINITI Q50	V37	2017.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Kazakhstan	INFINITI Q50	V37	2017.7-	DAST 2	√	√	√	√		
Kazakhstan	INFINITI Q50	V37	2017.7-	Precrash seatbelt	√	√	√	√		SP0612
Kazakhstan	INFINITI Q50	V37	2017.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kazakhstan	INFINITI Q50	V37	2017.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Kazakhstan	INFINITI Q50	V37	2017.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kazakhstan	INFINITI Q50	V37	2017.7-	DAST 1	√	√	√	√		
Kazakhstan	INFINITI Q50	V37	2017.7-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Kazakhstan	INFINITI Q50	V37	2017.7-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Kazakhstan	INFINITI Q50	V37	2017.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Kazakhstan	INFINITI Q50	V37	2017.7-	ANC	√	√	√	√	AC1024	
Kazakhstan	INFINITI Q50	V37	2017.7-	Side radar left	√	√	√	√	AC1025	SP0582
Kazakhstan	INFINITI Q50	V37	2017.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Kazakhstan	INFINITI Q50	V37	2017.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kazakhstan	INFINITI Q50	V37	2017.7-	HIGH BEAM ASSIST	√	√	√	√		
Kazakhstan	INFINITI Q50	V37	2017.7-	Side radar right	√	√	√	√	AC1026	SP0583
Kazakhstan	INFINITI Q50	V37	2017.7-	6ch CAN GATEWAY	√	√	√	√		
Kazakhstan	INFINITI Q50	V37	2017.7-	ICC/ADAS 2	√	√	√	√		
Kazakhstan	INFINITI Q50	V37	2017.7-	PMAS	√	√	√	√		
Kazakhstan	INFINITI Q50	V37	2017.7-	FSCM	√	√	√	√	AC1109	
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Laser/radar	√	√	√	√	AC0994	
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Air bag	√	√	√	√		
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	EPS/DAST 3	√	√	√	√		
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Motor control	√	√	√	√		

Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0117, SP0118, SP0119, SP0120, SP0121, SP0122, SP0123, SP0124, SP0125, SP0126, SP0127, SP0128, SP0129, SP0130, SP0131, SP0132, SP0133, SP0134, SP0135, SP0136, SP0137, SP0138, SP0139, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Transmission	√	√	√	√		SP0276
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Pop up hood	√	√	√	√		
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Multi AV	√	√	√	√		SP0503
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	HV battery	√	√	√	√	AC1121	
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	DAST 2	√	√	√	√		
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Precrash seatbelt	√	√	√	√		SP0612
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	DAST 1	√	√	√	√		
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	ANC	√	√	√	√	AC1024	
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Side radar left	√	√	√	√	AC1025	SP0582
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	HIGH BEAM ASSIST	√	√	√	√		
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Side radar right	√	√	√	√	AC1026	SP0583
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	Brake	√	√	√	√	AC1127	
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	6ch CAN GATEWAY	√	√	√	√		
Kazakhstan	INFINITI Q50 HYBRID	HV37	2017.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kazakhstan	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Kazakhstan	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kazakhstan	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kazakhstan	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Kazakhstan	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhstan	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kazakhstan	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhstan	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Kazakhstan	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Kazakhstan	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kazakhstan	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kazakhstan	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Kazakhstan	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471

Kazakhstan	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Kazakhsta	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Kazakhsta	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Kazakhstan	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kazakhsta	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kazakhsta	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhsta	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kazakhsta	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kazakhsta	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kazakhsta	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Kazakhsta	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Kazakhsta	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kazakhsta	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Kazakhsta	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kazakhsta	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kazakhsta	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Kazakhsta	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kazakhsta	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Kazakhsta	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Kazakhsta	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kazakhsta	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Kazakhsta	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Kazakhsta	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Kazakhsta	INFINITI QX50	J50	2014.4-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kazakhsta	INFINITI QX50	J50	2014.4-	Laser/radar	√	√	√	√	AC0994	
Kazakhsta	INFINITI QX50	J50	2014.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhstan	INFINITI QX50	J50	2014.4-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kazakhsta	INFINITI QX50	J50	2014.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhsta	INFINITI QX50	J50	2014.4-	Air bag	√	√	√	√		
Kazakhsta	INFINITI QX50	J50	2014.4-	EPS/DAST 3	√	√	√	√		SP0507
Kazakhsta	INFINITI QX50	J50	2014.4-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kazakhstan	INFINITI QX50	J50	2014.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kazakhsta	INFINITI QX50	I50	2014.4-	Transmission	√	√	√	√		SP0274
Kazakhsta	INFINITI QX50	I50	2014.4-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kazakhstan	INFINITI QX50	J50	2014.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kazakhsta	INFINITI QX50	J50	2014.4-	Multi AV	√	√	√	√		SP0503
Kazakhsta	INFINITI QX50	J50	2014.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhsta	INFINITI QX50	I50	2014.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kazakhsta	INFINITI QX50	I50	2014.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kazakhsta	INFINITI QX50	J50	2014.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kazakhsta	INFINITI QX50	J50	2014.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Kazakhsta	INFINITI QX50	J50	2014.4-	Precrash seatbelt	√	√	√	√		SP0612
Kazakhsta	INFINITI QX50	J50	2014.4-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kazakhsta	INFINITI QX50	J50	2014.4-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kazakhsta	INFINITI QX50	J50	2014.4-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Kazakhsta	INFINITI QX50	J50	2014.4-	Side radar left	√	√	√	√	AC1025	SP0582
Kazakhsta	INFINITI QX50	J50	2014.4-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kazakhsta	INFINITI QX50	J50	2014.4-	Side radar right	√	√	√	√	AC1026	SP0583
Kazakhsta	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Kazakhstan	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Kazakhsta	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Kazakhsta	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Kazakhstan	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Kazakhsta	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Kazakhsta	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Kazakhsta	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kazakhsta	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Kazakhsta	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Kazakhsta	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Kazakhsta	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhsta	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kazakhsta	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Kazakhsta	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Kazakhsta	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Kazakhsta	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Kazakhsta	INFINITI QX70	S51	2014.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kazakhsta	INFINITI QX70	S51	2014.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kazakhsta	INFINITI QX70	S51	2014.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kazakhsta	INFINITI QX70	S51	2014.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhsta	INFINITI QX70	S51	2014.3-	Air bag	√	√	√	√		
Kazakhsta	INFINITI QX70	S51	2014.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
Kazakhstan	INFINITI QX70	S51	2014.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kazakhsta	INFINITI QX70	S51	2014.3-	Transmission	√	√	√	√		SP0274
Kazakhsta	INFINITI QX70	S51	2014.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kazakhsta	INFINITI QX70	S51	2014.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Kazakhsta	INFINITI QX70	S51	2014.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Kazakhsta	INFINITI QX70	S51	2014.3-	Multi AV	√	√	√	√		SP0503
Kazakhsta	INFINITI QX70	S51	2014.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kazakhstan	INFINITI QX70	S51	2014.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhsta	INFINITI QX70	S51	2014.3-	Auto back door	√	√	√	√		SP0611
Kazakhsta	INFINITI QX70	S51	2014.3-	Occupant detection			√	√		SP0584
Kazakhsta	INFINITI QX70	S51	2014.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kazakhsta	INFINITI QX70	S51	2014.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kazakhsta	INFINITI QX70	S51	2014.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Kazakhsta	INFINITI QX70	S51	2014.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Kazakhsta	INFINITI QX70	S51	2014.3-	Precrash seatbelt	√	√	√	√		SP0612
Kazakhsta	INFINITI QX70	S51	2014.3-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Kazakhsta	INFINITI QX70	S51	2014.3-	CAN gateway	√	√	√			
Kazakhsta	INFINITI QX70	S51	2014.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kazakhsta	INFINITI QX70	S51	2014.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kazakhsta	INFINITI QX70	S51	2014.3-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kazakhsta	INFINITI QX70	S51	2014.3-	Side radar left	√	√	√	√	AC1025	SP0582
Kazakhsta	INFINITI QX70	S51	2014.3-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kazakhsta	INFINITI QX70	S51	2014.3-	Side radar right	√	√	√	√	AC1026	SP0583
Kazakhsta	INFINITI QX80	Z62	2014.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kazakhsta	INFINITI QX80	Z62	2014.8-	Laser/radar	√	√	√	√		
Kazakhsta	INFINITI QX80	Z62	2014.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Kazakhstan	INFINITI QX80	Z62	2014.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kazakhsta	INFINITI QX80	Z62	2014.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kazakhsta	INFINITI QX80	Z62	2014.8-	Air bag	√	√	√	√		
Kazakhsta	INFINITI QX80	Z62	2014.8-	EPS/DAST 3	√	√	√	√		SP0507
Kazakhsta	INFINITI QX80	Z62	2014.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Kazakhstan	INFINITI QX80	Z62	2014.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kazakhsta	INFINITI QX80	Z62	2014.8-	Transmission	√	√	√	√		SP0270, SP0274
Kazakhsta	INFINITI QX80	Z62	2014.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kazakhsta	INFINITI QX80	Z62	2014.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Kazakhsta	INFINITI QX80	Z62	2014.8-	Multi AV	√	√	√	√		SP0503
Kazakhstan	INFINITI QX80	Z62	2014.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Kazakhsta	INFINITI QX80	Z62	2014.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Kazakhsta	INFINITI QX80	Z62	2014.8-	Difference lock	√	√	√	√		
Kazakhsta	INFINITI QX80	Z62	2014.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kazakhstan	INFINITI QX80	Z62	2014.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kazakhsta	INFINITI QX80	Z62	2014.8-	Auto back door	√	√	√	√		
Kazakhsta	INFINITI QX80	Z62	2014.8-	Occupant detection			√	√		SP0584
Kazakhsta	INFINITI QX80	Z62	2014.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kazakhsta	INFINITI QX80	Z62	2014.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kazakhsta	INFINITI QX80	Z62	2014.8-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Kazakhsta	INFINITI QX80	Z62	2014.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Kazakhsta	INFINITI QX80	Z62	2014.8-	Precrash seatbelt	√	√	√	√		SP0612
Kazakhsta	INFINITI QX80	Z62	2014.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Kazakhsta	INFINITI QX80	Z62	2014.8-	CAN gateway	√	√	√			
Kazakhsta	INFINITI QX80	Z62	2014.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kazakhsta	INFINITI QX80	Z62	2014.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kazakhsta	INFINITI QX80	Z62	2014.8-	Side radar left	√	√	√	√	AC1025	SP0582
Kazakhsta	INFINITI QX80	Z62	2014.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kazakhsta	INFINITI QX80	Z62	2014.8-	HIGH BEAM ASSIST	√	√	√	√		
Kazakhsta	INFINITI QX80	Z62	2014.8-	Side radar right	√	√	√	√	AC1026	SP0583
Kenya	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kenya	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kenya	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Kenya	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kenya	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kenya	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Kenya	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kenya	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kenya	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kenya	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kenya	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kenya	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kenya	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Kenya	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Kenya	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Kenya	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Kenya	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Kenya	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Kenya	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kenya	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kenya	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Kenya	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kenya	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kenya	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Kenya	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kenya	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Kenya	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Kenya	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kenya	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kenya	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Kenya	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Kenya	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kenya	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kenya	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Kenya	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Kenya	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Kenya	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Kenya	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kenya	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		

Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Kenya	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Kenya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Kenya	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kenya	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kenya	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Kenya	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kenya	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kenya	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Kenya	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kenya	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kenya	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Kenya	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kenya	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kenya	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kenya	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kenya	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Kenya	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kenya	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Kenya	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Kenya	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Kenya	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kenya	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kenya	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Kenya	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kenya	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kenya	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kenya	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kenya	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Kenya	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Kenya	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kenya	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kenya	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kenya	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kenya	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kenya	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kenya	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553. SP0554. SP0555. SP0556
Kenya	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Kenya	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Kenya	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Kenya	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kenya	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kenya	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Kenya	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Kenya	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Kenya	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Kenya	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Kenya	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		

Xtool

Kenya	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Kenya	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Kenya	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Kenya	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Kenya	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Kenya	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Kenya	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Kenya	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Kenya	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Kenya	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Kenya	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Kenya	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Kenya	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Kenya	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Kenya	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Kenya	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Kenya	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Kenya	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Kenya	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Kenya	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Kenya	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kenya	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Kenya	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kenya	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kenya	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Kenya	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Kenya	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kenya	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kenya	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Kenya	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kenya	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Kenya	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Kenya	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kenya	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kenya	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kenya	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Kenya	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Kenya	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kenya	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Kenya	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Kenya	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Kenya	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Kenya	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kenya	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Kenya	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kenya	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kenya	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Kenya	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Kenya	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Kenya	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kenya	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Kenya	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Kenya	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Kenya	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kenya	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Kenya	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Kenya	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	

Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979.AC0981.AC0982	SP0562
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966.AC0967.AC0968	SP0557
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
Kenya	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Kenya	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Kenya	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Kenya	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Kenya	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kenya	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Kenya	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Kenya	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Kenya	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Kenya	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247.SP0265.SP0270.SP0274
Kenya	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613.AC0618.AC0663.AC0690.AC0692.AC0702	SP0372.SP0429
Kenya	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Kenya	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Kenya	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Kenya	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027.AC1028	
Kenya	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Kenya	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Kenya	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Kenya	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Kenya	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Kenya	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Kenya	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Kenya	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Kenya	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Kenya	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Kenya	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Kenya	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kenya	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Kenya	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Kenya	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Kenya	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Kenya	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Kenya	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Kenya	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Kenya	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Kenya	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Kenya	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Kenya	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Kenya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507

Kenya	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kenya	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kenya	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kenya	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Kenya	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kenya	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kenya	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Kenya	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Kenya	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kenya	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kenya	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Kenya	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kenya	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Kenya	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Kenya	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kenya	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kenya	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kenya	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Kenya	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kenya	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kenya	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Kenya	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Kenya	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Kenya	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kenya	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Kenya	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kenya	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kenya	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kenya	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Kenya	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kenya	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Kenya	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kenya	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Kenya	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kenya	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kenya	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Kenya	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Kenya	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kenya	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kenya	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Kenya	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kenya	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kenya	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kenya	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kenya	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kenya	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kenya	INFINITI QX50	I50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Kenya	INFINITI QX50	I50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Kenya	INFINITI QX50	I50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kenya	INFINITI QX50	I50	2013.8-	CAN gateway	√	√	√	√		
Kenya	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kenya	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Kenya	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Kenya	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kenya	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Kenya	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kenya	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Kenya	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kenya	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kenya	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Kenya	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Kenya	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kenya	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kenya	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Kenya	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Kenya	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Kenya	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Kenya	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kenya	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kenya	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kenya	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Kenya	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Kenya	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kenya	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kenya	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kenya	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Kenya	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Kenya	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kenya	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Kenya	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kenya	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kenya	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kenya	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Kenya	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Kenya	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kenya	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Kenya	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Kenya	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kenya	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Kenya	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kenya	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kenya	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kenya	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Kenya	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Kenya	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kenya	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kenya	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kenya	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kenya	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Kenya	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Kenya	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Kenya	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Kenya	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kenya	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Kenya	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Kenya	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kenya	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kenya	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Kenya	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Kenya	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Kenya	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Kenya	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Kenya	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kenya	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kenya	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Kenya	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kenya	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Kenya	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Kenya	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Kenya	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Kenya	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Korea	INFINITI EX35	J50	2007.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI EX35	J50	2007.12-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Korea	INFINITI EX35	J50	2007.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI EX35	J50	2007.12-	Air bag	√	√	√	√		
Korea	INFINITI EX35	J50	2007.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Korea	INFINITI EX35	J50	2007.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Korea	INFINITI EX35	J50	2007.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Korea	INFINITI EX35	J50	2007.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Korea	INFINITI EX35	J50	2007.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Korea	INFINITI EX35	J50	2007.12-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI EX35	J50	2007.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI EX35	J50	2007.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Korea	INFINITI EX35	J50	2007.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI EX35	J50	2007.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Korea	INFINITI EX35	J50	2007.12-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI EX35	J50	2007.12-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI EX35	J50	2007.12-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Korea	INFINITI EX35	J50	2007.12-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Korea	INFINITI EX35	J50	2007.12-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI EX35	J50	2007.12-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI EX35/EX30D	J50	2011.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI EX35/EX30D	J50	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI EX35/EX30D	J50	2011.8-	Air bag	√	√	√	√		
Korea	INFINITI EX35/EX30D	J50	2011.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
Korea	INFINITI EX35/EX30D	J50	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Korea	INFINITI EX35/EX30D	J50	2011.8-	Transmission	√	√	√	√		SP0274
Korea	INFINITI EX35/EX30D	J50	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Korea	INFINITI EX35/EX30D	J50	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Korea	INFINITI EX35/EX30D	J50	2011.8-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI EX35/EX30D	J50	2011.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI EX35/EX30D	J50	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI EX35/EX30D	J50	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Korea	INFINITI EX35/EX30D	J50	2011.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI EX37	J50	2012.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI EX37	J50	2012.12-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Korea	INFINITI EX37	J50	2012.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI EX37	J50	2012.12-	Air bag	√	√	√	√		
Korea	INFINITI EX37	J50	2012.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350

Korea	INFINITI EX37	J50	2012.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Korea	INFINITI EX37	J50	2012.12-	Transmission	√	√	√	√		SP0274
Korea	INFINITI EX37	J50	2012.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Korea	INFINITI EX37	J50	2012.12-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Korea	INFINITI EX37	J50	2012.12-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI EX37	J50	2012.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI EX37	J50	2012.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Korea	INFINITI EX37	J50	2012.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI EX37	J50	2012.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Korea	INFINITI EX37	J50	2012.12-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI EX37	J50	2012.12-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI EX37	J50	2012.12-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Korea	INFINITI EX37	J50	2012.12-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI EX37	J50	2012.12-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI FX35/FX45	S50	2005.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Korea	INFINITI FX35/FX45	S50	2005.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Korea	INFINITI FX35/FX45	S50	2005.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Korea	INFINITI FX35/FX45	S50	2005.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Korea	INFINITI FX35/FX45	S50	2005.8-	Air bag	√	√	√	√		
Korea	INFINITI FX35/FX45	S50	2005.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Korea	INFINITI FX35/FX45	S50	2005.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Korea	INFINITI FX35/FX45	S50	2005.8-	Motor control						
Korea	INFINITI FX35/FX45	S50	2005.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI FX35/FX45	S50	2005.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Korea	INFINITI FX35/FX45	S50	2005.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Korea	INFINITI FX35/FX45	S50	2005.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Korea	INFINITI FX35/FX45	S50	2005.8-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI FX35/FX45	S50	2005.8-	HVAC	√	√	√	√		
Korea	INFINITI FX35/FX45	S50	2005.8-	Difference lock	√	√	√	√		
Korea	INFINITI FX35/FX45	S50	2005.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI FX35/FX45	S50	2005.8-	Auto slide door	√	√	√	√	AC0941	
Korea	INFINITI FX35/FX45	S50	2005.8-	DIU		√	√	√		
Korea	INFINITI FX35/FX45	S50	2005.8-	Adaptive light	√	√	√	√		
Korea	INFINITI FX35/FX45	S50	2005.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Korea	INFINITI FX35/FX45	S50	2005.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Korea	INFINITI FX35/FX45	S50	2005.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI FX35/FX45	S50	2005.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Korea	INFINITI FX35/FX45	S50	2005.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Korea	INFINITI FX35/FX45	S50	2005.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI FX35/FX45	S50	2005.8-	IVMS	√	√		√		
Korea	INFINITI FX35/FX45	S50	2005.8-	Distance control	√	√		√		
Korea	INFINITI FX35/FX45	S50	2005.8-	Active suspense system	√	√	√	√		
Korea	INFINITI FX35/FX45	S50	2005.8-	Motor assist		√	√	√		SP0574
Korea	INFINITI FX35/FX45	S50	2005.8-	ASCD	√	√	√	√		
Korea	INFINITI FX35/FX45	S50	2005.8-	Active engine mount	√	√	√	√		
Korea	INFINITI FX35/FX45	S50	2005.8-	TCS	√	√	√	√		
Korea	INFINITI FX35/FX45	S50	2005.8-	S/blind camera	√			√		SP0572, SP0573
Korea	INFINITI FX35/FX45	S50	2005.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Korea	INFINITI FX35/FX45	S50	2005.8-	Nats immu	√	√	√			
Korea	INFINITI FX35/FX45	S50	2005.8-	Rearview camera	√			√		SP0570, SP0571
Korea	INFINITI FX35/FX45	S50	2005.8-	Smart entrance						SP0568
Korea	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Korea	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Korea	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Korea	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Korea	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Korea	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Korea	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Korea	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Korea	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Korea	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Korea	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Korea	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Korea	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Korea	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Korea	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Korea	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Korea	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI FX35/FX50	S51	2008.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Korea	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	Air bag	√	√	√	√		
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350

Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	Transmission	√	√	√	√		SP0274
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	Auto back door	√	√	√	√		SP0611
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	Occupant detection			√	√		SP0584
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	CAN gateway	√	√	√			
Korea	INFINITI FX35/FX50/FX30D	S51	2011.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Korea	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI G35 COUPE	CV35	2005.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Korea	INFINITI G35 COUPE	CV35	2005.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Korea	INFINITI G35 COUPE	CV35	2005.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Korea	INFINITI G35 COUPE	CV35	2005.5-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Korea	INFINITI G35 COUPE	CV35	2005.5-	Air bag	√	√	√	√		
Korea	INFINITI G35 COUPE	CV35	2005.5-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Korea	INFINITI G35 COUPE	CV35	2005.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Korea	INFINITI G35 COUPE	CV35	2005.5-	Motor control						
Korea	INFINITI G35 COUPE	CV35	2005.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI G35 COUPE	CV35	2005.5-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Korea	INFINITI G35 COUPE	CV35	2005.5-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Korea	INFINITI G35 COUPE	CV35	2005.5-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Korea	INFINITI G35 COUPE	CV35	2005.5-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI G35 COUPE	CV35	2005.5-	HVAC	√	√	√	√		
Korea	INFINITI G35 COUPE	CV35	2005.5-	Difference lock	√	√	√	√		
Korea	INFINITI G35 COUPE	CV35	2005.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI G35 COUPE	CV35	2005.5-	Auto slide door	√	√	√	√	AC0941	
Korea	INFINITI G35 COUPE	CV35	2005.5-	DIU		√	√	√		
Korea	INFINITI G35 COUPE	CV35	2005.5-	Adaptive light	√	√	√	√		
Korea	INFINITI G35 COUPE	CV35	2005.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Korea	INFINITI G35 COUPE	CV35	2005.5-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Korea	INFINITI G35 COUPE	CV35	2005.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI G35 COUPE	CV35	2005.5-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Korea	INFINITI G35 COUPE	CV35	2005.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Korea	INFINITI G35 COUPE	CV35	2005.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI G35 COUPE	CV35	2005.5-	IVMS	√	√		√		
Korea	INFINITI G35 COUPE	CV35	2005.5-	Distance control	√	√		√		
Korea	INFINITI G35 COUPE	CV35	2005.5-	Active suspense system	√	√	√	√		
Korea	INFINITI G35 COUPE	CV35	2005.5-	Motor assist		√	√	√		SP0574
Korea	INFINITI G35 COUPE	CV35	2005.5-	ASCD	√	√	√	√		
Korea	INFINITI G35 COUPE	CV35	2005.5-	Active engine mount	√	√	√	√		
Korea	INFINITI G35 COUPE	CV35	2005.5-	TCS	√	√	√	√		
Korea	INFINITI G35 COUPE	CV35	2005.5-	S/blind camera	√			√		SP0572, SP0573

Korea	INFINITI G35 COUPE	CV35	2005.5-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Korea	INFINITI G35 COUPE	CV35	2005.5-	Nats immu	√	√	√			
Korea	INFINITI G35 COUPE	CV35	2005.5-	Rearview camera	√			√		SP0570,SP0571
Korea	INFINITI G35 COUPE	CV35	2005.5-	Smart entrance						SP0568
Korea	INFINITI G35 SEDAN	V35	2005.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Korea	INFINITI G35 SEDAN	V35	2005.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Korea	INFINITI G35 SEDAN	V35	2005.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Korea	INFINITI G35 SEDAN	V35	2005.5-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Korea	INFINITI G35 SEDAN	V35	2005.5-	Air bag	√	√	√	√		
Korea	INFINITI G35 SEDAN	V35	2005.5-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Korea	INFINITI G35 SEDAN	V35	2005.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Korea	INFINITI G35 SEDAN	V35	2005.5-	Motor control						
Korea	INFINITI G35 SEDAN	V35	2005.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI G35 SEDAN	V35	2005.5-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Korea	INFINITI G35 SEDAN	V35	2005.5-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Korea	INFINITI G35 SEDAN	V35	2005.5-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Korea	INFINITI G35 SEDAN	V35	2005.5-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI G35 SEDAN	V35	2005.5-	HVAC	√	√	√	√		
Korea	INFINITI G35 SEDAN	V35	2005.5-	Difference lock	√	√	√	√		
Korea	INFINITI G35 SEDAN	V35	2005.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI G35 SEDAN	V35	2005.5-	Auto slide door	√	√	√	√	AC0941	
Korea	INFINITI G35 SEDAN	V35	2005.5-	DIU		√	√	√		
Korea	INFINITI G35 SEDAN	V35	2005.5-	Adaptive light	√	√	√	√		
Korea	INFINITI G35 SEDAN	V35	2005.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Korea	INFINITI G35 SEDAN	V35	2005.5-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Korea	INFINITI G35 SEDAN	V35	2005.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI G35 SEDAN	V35	2005.5-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Korea	INFINITI G35 SEDAN	V35	2005.5-	Lane camera	√	√	√	√	AC0971.AC0972.AC0973	
Korea	INFINITI G35 SEDAN	V35	2005.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI G35 SEDAN	V35	2005.5-	IVMS	√	√		√		
Korea	INFINITI G35 SEDAN	V35	2005.5-	Distance control	√	√		√		
Korea	INFINITI G35 SEDAN	V35	2005.5-	Active suspense system	√	√	√	√		
Korea	INFINITI G35 SEDAN	V35	2005.5-	Motor assist		√	√	√		SP0574
Korea	INFINITI G35 SEDAN	V35	2005.5-	ASCD	√	√	√	√		
Korea	INFINITI G35 SEDAN	V35	2005.5-	Active engine mount	√	√	√	√		
Korea	INFINITI G35 SEDAN	V35	2005.5-	TCS	√	√	√	√		
Korea	INFINITI G35 SEDAN	V35	2005.5-	S/blind camera	√			√		SP0572, SP0573
Korea	INFINITI G35 SEDAN	V35	2005.5-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Korea	INFINITI G35 SEDAN	V35	2005.5-	Nats immu	√	√	√			
Korea	INFINITI G35 SEDAN	V35	2005.5-	Rearview camera	√			√		SP0570, SP0571
Korea	INFINITI G35 SEDAN	V35	2005.5-	Smart entrance						SP0568
Korea	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Korea	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Korea	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Korea	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Korea	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Korea	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Korea	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Korea	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI G35 SEDAN	V36	2006.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Korea	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Korea	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	Air bag	√	√	√	√		
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	Pop up hood	√	√	√	√		
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	Precrash seatbelt	√	√	√	√		
Korea	INFINITI G37 CONVERTIBLE	HV36	2009.2-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI G37 COUPE	CV36	2007.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI G37 COUPE	CV36	2007.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Korea	INFINITI G37 COUPE	CV36	2007.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI G37 COUPE	CV36	2007.7-	Air bag	√	√	√	√		
Korea	INFINITI G37 COUPE	CV36	2007.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Korea	INFINITI G37 COUPE	CV36	2007.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI G37 COUPE	CV36	2007.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Korea	INFINITI G37 COUPE	CV36	2007.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Korea	INFINITI G37 COUPE	CV36	2007.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Korea	INFINITI G37 COUPE	CV36	2007.7-	Pop up hood	√	√	√	√		
Korea	INFINITI G37 COUPE	CV36	2007.7-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI G37 COUPE	CV36	2007.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Korea	INFINITI G37 COUPE	CV36	2007.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI G37 COUPE	CV36	2007.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Korea	INFINITI G37 COUPE	CV36	2007.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Korea	INFINITI G37 COUPE	CV36	2007.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Korea	INFINITI G37 COUPE	CV36	2007.7-	Precrash seatbelt	√	√	√	√		
Korea	INFINITI G37 COUPE	CV36	2007.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI G37 SEDAN	V36	2008.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI G37 SEDAN	V36	2008.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI G37 SEDAN	V36	2008.8-	Air bag	√	√	√	√		
Korea	INFINITI G37 SEDAN	V36	2008.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Korea	INFINITI G37 SEDAN	V36	2008.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Korea	INFINITI G37 SEDAN	V36	2008.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Korea	INFINITI G37 SEDAN	V36	2008.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Korea	INFINITI G37 SEDAN	V36	2008.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Korea	INFINITI G37 SEDAN	V36	2008.8-	Multi AV	√	√	√	√		
Korea	INFINITI G37 SEDAN	V36	2008.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Korea	INFINITI G37 SEDAN	V36	2008.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI G37 SEDAN	V36	2008.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Korea	INFINITI G37 SEDAN	V36	2008.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Korea	INFINITI G37 SEDAN	V36	2008.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Korea	INFINITI G37 SEDAN	V36	2008.8-	Precrash seatbelt	√	√	√	√		
Korea	INFINITI G37 SEDAN	V36	2008.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Korea	INFINITI JX35	L50	2012.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Korea	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI JX35	L50	2012.9-	Air bag	√	√	√	√		
Korea	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Korea	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Korea	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Korea	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Korea	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Korea	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Korea	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Korea	INFINITI JX35	L50	2012.9-	Occupant detection			√	√		SP0584
Korea	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Korea	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Korea	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Korea	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI M35/M45	Y50	2005.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Korea	INFINITI M35/M45	Y50	2005.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Korea	INFINITI M35/M45	Y50	2005.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Korea	INFINITI M35/M45	Y50	2005.5-	Air bag	√	√	√	√		
Korea	INFINITI M35/M45	Y50	2005.5-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Korea	INFINITI M35/M45	Y50	2005.5-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Korea	INFINITI M35/M45	Y50	2005.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Korea	INFINITI M35/M45	Y50	2005.5-	BCM					AC0653, AC0698	SP0391, SP0393
Korea	INFINITI M35/M45	Y50	2005.5-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Korea	INFINITI M35/M45	Y50	2005.5-	Multi AV	√	√	√	√		
Korea	INFINITI M35/M45	Y50	2005.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI M35/M45	Y50	2005.5-	Adaptive light	√	√	√	√		SP0561, SP0562
Korea	INFINITI M35/M45	Y50	2005.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Korea	INFINITI M35/M45	Y50	2005.5-	All mode AWD/4WD	√	√	√	√	AC0957	
Korea	INFINITI M35/M45	Y50	2005.5-	Precrash seatbelt	√	√	√	√		
Korea	INFINITI M35/M45	Y50	2005.5-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Korea	INFINITI M35/M45	Y50	2005.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI M35/M45	Y50	2005.5-	Rearview camera	√			√		SP0570, SP0571
Korea	INFINITI M37/M56	Y51	2010.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Korea	INFINITI M37/M56	Y51	2010.5-	Laser/radar	√	√	√	√		
Korea	INFINITI M37/M56	Y51	2010.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI M37/M56	Y51	2010.5-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Korea	INFINITI M37/M56	Y51	2010.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Korea	INFINITI M37/M56	Y51	2010.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI M37/M56	Y51	2010.5-	Air bag	√	√	√	√		
Korea	INFINITI M37/M56	Y51	2010.5-	EPS/DAST 3	√	√	√	√		
Korea	INFINITI M37/M56	Y51	2010.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Korea	INFINITI M37/M56	Y51	2010.5-	Motor control	√	√	√	√		
Korea	INFINITI M37/M56	Y51	2010.5-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Korea	INFINITI M37/M56	Y51	2010.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Korea	INFINITI M37/M56	Y51	2010.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Korea	INFINITI M37/M56	Y51	2010.5-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319

Xtec

Korea	INFINITI M37/M56	Y51	2010.5-	Pop up hood	√	√	√	√		
Korea	INFINITI M37/M56	Y51	2010.5-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI M37/M56	Y51	2010.5-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Korea	INFINITI M37/M56	Y51	2010.5-	HV battery	√	√	√	√	AC1121	
Korea	INFINITI M37/M56	Y51	2010.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Korea	INFINITI M37/M56	Y51	2010.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Korea	INFINITI M37/M56	Y51	2010.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI M37/M56	Y51	2010.5-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Korea	INFINITI M37/M56	Y51	2010.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Korea	INFINITI M37/M56	Y51	2010.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI M37/M56	Y51	2010.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Korea	INFINITI M37/M56	Y51	2010.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI M37/M56	Y51	2010.5-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI M37/M56	Y51	2010.5-	CAN gateway	√	√	√			
Korea	INFINITI M37/M56	Y51	2010.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Korea	INFINITI M37/M56	Y51	2010.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI M37/M56	Y51	2010.5-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI M37/M56	Y51	2010.5-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI M37/M56	Y51	2010.5-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Laser/radar	√	√	√	√		
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Air bag	√	√	√	√		
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Transmission	√	√	√	√		SP0274
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Pop up hood	√	√	√	√		
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	CAN gateway	√	√	√			
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI M37/M56/M30D	Y51	2011.3-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI Q30	H15	2016.1-	Air pressure monitor	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	Air bag	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	EPS/DAST 3	√	√	√			
Korea	INFINITI Q30	H15	2016.1-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Korea	INFINITI Q30	H15	2016.1-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Korea	INFINITI Q30	H15	2016.1-	EHS/PKB	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	Transmission	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Korea	INFINITI Q30	H15	2016.1-	ABS	√	√	√	√		SP0308
Korea	INFINITI Q30	H15	2016.1-	Multi AV	√	√	√	√		SP0501
Korea	INFINITI Q30	H15	2016.1-	HVAC	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	Auto drive position	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	Shift	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	All mode AWD/4WD	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	AVM	√	√		√		
Korea	INFINITI Q30	H15	2016.1-	Intelligent key	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	CAN gateway	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	ANC	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	Telematics	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	FSCM	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	Siren control unit	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Korea	INFINITI Q30	H15	2016.1-	Overhead Control Panel Unit	√			√		
Korea	INFINITI Q30	H15	2016.1-	Universal Garage Door Opener	√			√		
Korea	INFINITI Q30	H15	2016.1-	Upper control panel cont unit	√					
Korea	INFINITI Q30	H15	2016.1-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Korea	INFINITI Q30	H15	2016.1-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Korea	INFINITI Q30	H15	2016.1-	Light/Rain Sensor Module	√			√		
Korea	INFINITI Q30	H15	2016.1-	EC Mirror Compass	√					
Korea	INFINITI Q30	H15	2016.1-	Intelligent Battery Sensor	√					
Korea	INFINITI Q30	H15	2016.1-	Alarm siren	√			√		
Korea	INFINITI Q30	H15	2016.1-	Radar sensor	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	Steering column cont module	√	√	√			
Korea	INFINITI Q30	H15	2016.1-	ICC sensor	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	Trailer recognition control unit	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	H/L control module LH	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	Powertrain cont module	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	Side radar LH	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	LED H/L control module LH	√			√		
Korea	INFINITI Q30	H15	2016.1-	Steering Wheel Switch Pad	√			√		
Korea	INFINITI Q30	H15	2016.1-	Parking assist	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	Occupant Classification Unit	√			√		
Korea	INFINITI Q30	H15	2016.1-	Electronic Ignition Switch cont unit	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	H/L control module RH	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	Front camera unit	√	√	√	√		

XTOOL

Korea	INFINITI Q30	H15	2016.1-	Side radar RH	√	√	√	√		
Korea	INFINITI Q30	H15	2016.1-	LED H/L control module RH	√			√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Korea	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Korea	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Korea	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Korea	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Korea	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Korea	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Korea	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Korea	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Korea	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Korea	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Korea	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Korea	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Korea	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Korea	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Korea	INFINITI Q45	F50	ALL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Korea	INFINITI Q45	F50	ALL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Korea	INFINITI Q45	F50	ALL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Korea	INFINITI Q45	F50	ALL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Korea	INFINITI Q45	F50	ALL	Air bag	√	√	√	√		
Korea	INFINITI Q45	F50	ALL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Korea	INFINITI Q45	F50	ALL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Korea	INFINITI Q45	F50	ALL	Motor control						
Korea	INFINITI Q45	F50	ALL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI Q45	F50	ALL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Korea	INFINITI Q45	F50	ALL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Korea	INFINITI Q45	F50	ALL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Korea	INFINITI Q45	F50	ALL	Multi AV	√	√	√	√		SP0503
Korea	INFINITI Q45	F50	ALL	HVAC	√	√	√	√		
Korea	INFINITI Q45	F50	ALL	Difference lock	√	√	√	√		
Korea	INFINITI Q45	F50	ALL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI Q45	F50	ALL	Auto slide door	√	√	√	√	AC0941	
Korea	INFINITI Q45	F50	ALL	DIU		√	√	√		
Korea	INFINITI Q45	F50	ALL	Adaptive light	√	√	√	√		
Korea	INFINITI Q45	F50	ALL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Korea	INFINITI Q45	F50	ALL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Korea	INFINITI Q45	F50	ALL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI Q45	F50	ALL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Korea	INFINITI Q45	F50	ALL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Korea	INFINITI Q45	F50	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI Q45	F50	ALL	IVMS	√	√		√		
Korea	INFINITI Q45	F50	ALL	Distance control	√	√		√		
Korea	INFINITI Q45	F50	ALL	Active suspense system	√	√	√	√		
Korea	INFINITI Q45	F50	ALL	Motor assist		√	√	√		SP0574
Korea	INFINITI Q45	F50	ALL	ASCD	√	√	√	√		
Korea	INFINITI Q45	F50	ALL	Active engine mount	√	√	√	√		
Korea	INFINITI Q45	F50	ALL	TCS	√	√	√	√		
Korea	INFINITI Q45	F50	ALL	S/blind camera	√			√		SP0572, SP0573
Korea	INFINITI Q45	F50	ALL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Korea	INFINITI Q45	F50	ALL	Nats immu	√	√	√			
Korea	INFINITI Q45	F50	ALL	Rearview camera	√			√		SP0570, SP0571
Korea	INFINITI Q45	F50	ALL	Smart entrance						SP0568
Korea	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Korea	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Korea	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Korea	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

XTOOL

Korea	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Korea	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Korea	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Korea	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Korea	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Korea	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Korea	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Korea	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Korea	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Korea	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Korea	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Korea	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Korea	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Korea	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Korea	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Korea	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Korea	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Korea	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Korea	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√			
Korea	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Korea	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Korea	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Korea	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Korea	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Korea	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Korea	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Korea	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Korea	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Korea	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Korea	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Korea	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Korea	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Korea	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Korea	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Korea	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Korea	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Korea	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Korea	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Korea	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Korea	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Korea	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Korea	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√	SP0247, SP0265, SP0270, SP0274	
Korea	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Korea	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Korea	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Korea	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Korea	INFINITI Q60	CV37	2016.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Korea	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Korea	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Korea	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Korea	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Korea	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Korea	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√		
Korea	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Korea	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Korea	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Korea	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Korea	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Korea	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Korea	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Korea	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Korea	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Korea	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Laser/radar	√	√	√	√	AC0994	
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Air bag	√	√	√	√		
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Transmission	√	√	√	√		SP0274
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Pop up hood	√	√	√	√		
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Precrash seatbelt	√	√	√	√		
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI Q60 COUPE	CV36	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Korea	INFINITI Q60 COUPE	CV36	2013.9-	Laser/radar	√	√	√	√	AC0994	
Korea	INFINITI Q60 COUPE	CV36	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI Q60 COUPE	CV36	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Korea	INFINITI Q60 COUPE	CV36	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI Q60 COUPE	CV36	2013.9-	Air bag	√	√	√	√		
Korea	INFINITI Q60 COUPE	CV36	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Korea	INFINITI Q60 COUPE	CV36	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Korea	INFINITI Q60 COUPE	CV36	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI Q60 COUPE	CV36	2013.9-	Transmission	√	√	√	√	SP0274	
Korea	INFINITI Q60 COUPE	CV36	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Korea	INFINITI Q60 COUPE	CV36	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Korea	INFINITI Q60 COUPE	CV36	2013.9-	Pop up hood	√	√	√	√		
Korea	INFINITI Q60 COUPE	CV36	2013.9-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI Q60 COUPE	CV36	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Korea	INFINITI Q60 COUPE	CV36	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Korea	INFINITI Q60 COUPE	CV36	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI Q60 COUPE	CV36	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Korea	INFINITI Q60 COUPE	CV36	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Korea	INFINITI Q60 COUPE	CV36	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Korea	INFINITI Q60 COUPE	CV36	2013.9-	Precrash seatbelt	√	√	√	√		
Korea	INFINITI Q60 COUPE	CV36	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI Q60 COUPE	CV36	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI Q70	Y51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Korea	INFINITI Q70	Y51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Korea	INFINITI Q70	Y51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Korea	INFINITI Q70	Y51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Korea	INFINITI Q70	Y51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI Q70	Y51	2013.7-	Air bag	√	√	√	√		
Korea	INFINITI Q70	Y51	2013.7-	EPS/DAST 3	√	√	√	√		
Korea	INFINITI Q70	Y51	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Korea	INFINITI Q70	Y51	2013.7-	Motor control	√	√	√	√		
Korea	INFINITI Q70	Y51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Korea	INFINITI Q70	Y51	2013.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Korea	INFINITI Q70	Y51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Korea	INFINITI Q70	Y51	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Korea	INFINITI Q70	Y51	2013.7-	Pop up hood	√	√	√	√		
Korea	INFINITI Q70	Y51	2013.7-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI Q70	Y51	2013.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Korea	INFINITI Q70	Y51	2013.7-	HV battery	√	√	√	√	AC1121	
Korea	INFINITI Q70	Y51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Korea	INFINITI Q70	Y51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Korea	INFINITI Q70	Y51	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI Q70	Y51	2013.7-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Korea	INFINITI Q70	Y51	2013.7-	Occupant detection			√	√		SP0584
Korea	INFINITI Q70	Y51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Korea	INFINITI Q70	Y51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI Q70	Y51	2013.7-	Sonar	√	√	√	√	AC0962. AC0963. AC0964. AC0966. AC0967. AC0968. AC0969. AC0970	SP0553. SP0554. SP0555. SP0556. SP0557. SP0558. SP0559
Korea	INFINITI Q70	Y51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956. AC0957. AC0958. AC0959. AC0960	SP0544. SP0545. SP0546. SP0547. SP0548. SP0549. SP0550. SP0551
Korea	INFINITI Q70	Y51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI Q70	Y51	2013.7-	AVM	√	√	√	√	AC0983. AC0984. AC0985. AC0986. AC0987. AC0988. AC0989. AC0990	SP0563. SP0564. SP0565. SP0566. SP0567
Korea	INFINITI Q70	Y51	2013.7-	CAN gateway	√	√	√	√		
Korea	INFINITI Q70	Y51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Korea	INFINITI Q70	Y51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI Q70	Y51	2013.7-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Korea	INFINITI Q70	Y51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Korea	INFINITI Q70	Y51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI Q70	Y51	2013.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Korea	INFINITI Q70	Y51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Korea	INFINITI Q70	Y51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI Q70	Y51	2013.7-	VSP	√	√	√	√		
Korea	INFINITI Q70	Y51	2013.7-	Brake	√	√	√	√	AC1127	
Korea	INFINITI Q70	Y51	2013.7-	6ch CAN GATEWAY	√	√	√	√		
Korea	INFINITI Q70	Y51	2013.7-	ICC/ADAS 2	√	√	√	√		
Korea	INFINITI Q70	Y51	2013.7-	FSCM	√	√	√	√	AC1109	
Korea	INFINITI QX50	J50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Korea	INFINITI QX50	J50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Korea	INFINITI QX50	J50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI QX50	J50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Korea	INFINITI QX50	J50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI QX50	J50	2013.7-	Air bag	√	√	√	√		
Korea	INFINITI QX50	J50	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Korea	INFINITI QX50	J50	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Korea	INFINITI QX50	J50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Korea	INFINITI QX50	J50	2013.7-	Transmission	√	√	√	√		SP0274
Korea	INFINITI QX50	J50	2013.7-	BCM				√	AC0613. AC0618. AC0663. AC0692. AC0702. AC0719	SP0372. SP0429
Korea	INFINITI QX50	J50	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Korea	INFINITI QX50	J50	2013.7-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI QX50	J50	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI QX50	J50	2013.7-	Occupant detection			√	√		SP0584
Korea	INFINITI QX50	J50	2013.7-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980	SP0561. SP0562
Korea	INFINITI QX50	J50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI QX50	J50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Korea	INFINITI QX50	J50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI QX50	J50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI QX50	J50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI QX50	J50	2013.7-	CAN gateway	√	√	√	√		
Korea	INFINITI QX50	J50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Korea	INFINITI QX50	J50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Korea	INFINITI QX50	J50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI QX50	J50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Korea	INFINITI QX50	J50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Korea	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Korea	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Korea	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Korea	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Korea	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Korea	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Korea	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Korea	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Korea	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Korea	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Korea	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Korea	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Korea	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Korea	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Korea	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Korea	INFINITI QX50	J55	2018.5-	Shift						
Korea	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Korea	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Korea	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Korea	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Korea	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI QX50	I55	2018.5-	CAN gateway	√	√	√	√		
Korea	INFINITI QX50	I55	2018.5-	Lane camera	√	√	√	√		
Korea	INFINITI QX50	I55	2018.5-	DAST 1	√	√	√	√		
Korea	INFINITI QX50	I55	2018.5-	Chassis control	√	√	√	√		

Korea	INFINITI QX50	J55	2018.5-	ANC						
Korea	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Korea	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Korea	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Korea	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Korea	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Korea	INFINITI QX56	Z62	2010.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Korea	INFINITI QX56	Z62	2010.5-	Laser/radar	√	√	√	√		
Korea	INFINITI QX56	Z62	2010.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI QX56	Z62	2010.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Korea	INFINITI QX56	Z62	2010.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI QX56	Z62	2010.5-	Air bag	√	√	√	√		
Korea	INFINITI QX56	Z62	2010.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Korea	INFINITI QX56	Z62	2010.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI QX56	Z62	2010.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Korea	INFINITI QX56	Z62	2010.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Korea	INFINITI QX56	Z62	2010.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Korea	INFINITI QX56	Z62	2010.5-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI QX56	Z62	2010.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Korea	INFINITI QX56	Z62	2010.5-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Korea	INFINITI QX56	Z62	2010.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI QX56	Z62	2010.5-	Auto back door	√	√	√	√		
Korea	INFINITI QX56	Z62	2010.5-	Occupant detection			√	√		SP0584
Korea	INFINITI QX56	Z62	2010.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Korea	INFINITI QX56	Z62	2010.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI QX56	Z62	2010.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Korea	INFINITI QX56	Z62	2010.5-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Korea	INFINITI QX56	Z62	2010.5-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI QX56	Z62	2010.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI QX56	Z62	2010.5-	CAN gateway	√	√	√			
Korea	INFINITI QX56	Z62	2010.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Korea	INFINITI QX56	Z62	2010.5-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI QX56	Z62	2010.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Korea	INFINITI QX56	Z62	2010.5-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI QX56	Z62	2010.5-	Rearview camera	√			√		SP0570, SP0571
Korea	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Korea	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Korea	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Korea	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Korea	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Korea	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Korea	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Korea	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Korea	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Korea	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Korea	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Korea	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Korea	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Korea	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Korea	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Korea	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Korea	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Korea	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Korea	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Korea	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Korea	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Korea	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Korea	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Korea	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Korea	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Korea	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Korea	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560

Korea	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Korea	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Korea	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Korea	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Korea	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Korea	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Korea	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Korea	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Korea	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Korea	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Korea	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Korea	INFINITI QX70	S51	2013.5-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Korea	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Korea	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Korea	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Korea	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Korea	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Korea	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Korea	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Korea	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Korea	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Korea	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Korea	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Korea	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Korea	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Korea	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Korea	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Korea	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Korea	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Korea	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Korea	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Korea	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Korea	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√		
Korea	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Korea	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Korea	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Korea	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Korea	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Korea	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350,SP0351
Korea	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Korea	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Korea	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Korea	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Korea	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Korea	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0484,SP0485,SP0486,SP0487,SP0488
Korea	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031,AC1032,AC1033	SP0585,SP0586,SP0587
Korea	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Korea	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Korea	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Korea	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Korea	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Korea	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Korea	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Korea	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Korea	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544,SP0545,SP0546,SP0547,SP0548,SP0549
Korea	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Korea	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Korea	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Korea	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Korea	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Korea	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Korea	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Korea	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Korea	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Korea	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Korea	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Korea	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Kuwait	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Kuwait	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kuwait	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Kuwait	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Kuwait	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Kuwait	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Kuwait	INFINITI EX35	J50	2008.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Kuwait	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Kuwait	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Kuwait	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Kuwait	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Kuwait	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Kuwait	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Kuwait	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Kuwait	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Kuwait	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kuwait	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Kuwait	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350

Kuwait	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kuwait	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Kuwait	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kuwait	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kuwait	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kuwait	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kuwait	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Kuwait	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Kuwait	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Kuwait	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kuwait	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Kuwait	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Kuwait	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Kuwait	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Kuwait	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Kuwait	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Kuwait	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Kuwait	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Kuwait	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Kuwait	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Kuwait	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kuwait	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Kuwait	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kuwait	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Kuwait	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Kuwait	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Kuwait	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Kuwait	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		

Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572,SP0573
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570,SP0571
Kuwait	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Kuwait	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kuwait	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Kuwait	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Kuwait	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Kuwait	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270
Kuwait	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Kuwait	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Kuwait	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Kuwait	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Kuwait	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
Kuwait	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Kuwait	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570,SP0571
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0200,SP0202,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Kuwait	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957	
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Kuwait	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957	
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Kuwait	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Kuwait	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Kuwait	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kuwait	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Kuwait	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Kuwait	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351

Kuwait	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Kuwait	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kuwait	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kuwait	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Kuwait	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Kuwait	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Kuwait	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Kuwait	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Kuwait	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Kuwait	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kuwait	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Kuwait	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Kuwait	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Kuwait	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Kuwait	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Kuwait	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Kuwait	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kuwait	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Kuwait	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kuwait	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Kuwait	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Kuwait	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Kuwait	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Kuwait	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Kuwait	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Kuwait	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Kuwait	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Kuwait	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Kuwait	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Kuwait	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kuwait	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Kuwait	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kuwait	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kuwait	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kuwait	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Kuwait	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Kuwait	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kuwait	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kuwait	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kuwait	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kuwait	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kuwait	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Kuwait	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Kuwait	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kuwait	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Kuwait	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Kuwait	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Kuwait	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Kuwait	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Kuwait	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Kuwait	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Kuwait	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Kuwait	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Kuwait	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Kuwait	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Kuwait	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Kuwait	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Kuwait	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Kuwait	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					

Kuwait	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Kuwait	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Kuwait	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Kuwait	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Kuwait	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Kuwait	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Kuwait	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Kuwait	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Kuwait	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Kuwait	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Kuwait	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Kuwait	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Kuwait	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Kuwait	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Kuwait	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kuwait	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Kuwait	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kuwait	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Kuwait	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Kuwait	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Kuwait	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Kuwait	INFINITI Q45	F50	2001.8-	Motor control						
Kuwait	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Kuwait	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Kuwait	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kuwait	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Kuwait	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Kuwait	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Kuwait	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Kuwait	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Kuwait	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Kuwait	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537

Xtool

Kuwait	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Kuwait	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Kuwait	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Kuwait	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Kuwait	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Kuwait	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Kuwait	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Kuwait	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Kuwait	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Kuwait	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Kuwait	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Kuwait	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Kuwait	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Kuwait	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kuwait	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Kuwait	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kuwait	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Kuwait	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Kuwait	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kuwait	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Kuwait	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kuwait	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kuwait	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Kuwait	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kuwait	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kuwait	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kuwait	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Kuwait	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kuwait	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Kuwait	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Kuwait	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Kuwait	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Kuwait	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kuwait	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Kuwait	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Kuwait	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Kuwait	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Kuwait	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Kuwait	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Kuwait	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kuwait	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Kuwait	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Kuwait	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Kuwait	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Kuwait	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Kuwait	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Kuwait	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Kuwait	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Kuwait	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	

Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Kuwait	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Kuwait	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Kuwait	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kuwait	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Kuwait	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kuwait	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Kuwait	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Kuwait	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kuwait	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Kuwait	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kuwait	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kuwait	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Kuwait	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kuwait	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kuwait	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Kuwait	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kuwait	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Kuwait	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Kuwait	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Kuwait	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Kuwait	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kuwait	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Kuwait	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Kuwait	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Kuwait	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Kuwait	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kuwait	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Kuwait	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Kuwait	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Kuwait	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Kuwait	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kuwait	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Kuwait	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kuwait	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Kuwait	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Kuwait	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kuwait	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Kuwait	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kuwait	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Kuwait	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kuwait	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Kuwait	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Kuwait	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kuwait	INFINITI Q70	Y51	2013.9-	HV batterv	√	√	√	√	AC1121	
Kuwait	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kuwait	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kuwait	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Kuwait	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Kuwait	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kuwait	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Kuwait	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Kuwait	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kuwait	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Kuwait	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kuwait	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Kuwait	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kuwait	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Kuwait	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Kuwait	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Kuwait	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Kuwait	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Kuwait	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kuwait	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Kuwait	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kuwait	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		

Kuwait	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Kuwait	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kuwait	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kuwait	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Kuwait	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kuwait	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kuwait	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Kuwait	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kuwait	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Kuwait	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Kuwait	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kuwait	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Kuwait	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kuwait	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Kuwait	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kuwait	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Kuwait	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kuwait	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Kuwait	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Kuwait	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Kuwait	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Kuwait	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Kuwait	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Kuwait	INFINITI QX50	J55	2018.5-	Shift						
Kuwait	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Kuwait	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	ANC						
Kuwait	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kuwait	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Kuwait	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Kuwait	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kuwait	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Kuwait	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kuwait	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Kuwait	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Kuwait	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Kuwait	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Kuwait	INFINITI QX56	JA60	2004.10-	Motor control						
Kuwait	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Kuwait	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Kuwait	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kuwait	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Kuwait	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Kuwait	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Kuwait	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Kuwait	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Kuwait	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Kuwait	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Kuwait	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Kuwait	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Kuwait	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Kuwait	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Kuwait	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Kuwait	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Kuwait	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Kuwait	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Kuwait	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Kuwait	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Kuwait	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			

Kuwait	INFINITI QX56	IA60	2004.10-	Rearview camera	√			√		SP0570,SP0571
Kuwait	INFINITI QX56	IA60	2004.10-	Smart entrance						SP0568
Kuwait	INFINITI QX56	Z62	2010.3-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Kuwait	INFINITI QX56	Z62	2010.3-	Laser/radar	√	√	√	√		
Kuwait	INFINITI QX56	Z62	2010.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI QX56	Z62	2010.3-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kuwait	INFINITI QX56	Z62	2010.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI QX56	Z62	2010.3-	Air bag	√	√	√	√		
Kuwait	INFINITI QX56	Z62	2010.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Kuwait	INFINITI QX56	Z62	2010.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI QX56	Z62	2010.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kuwait	INFINITI QX56	Z62	2010.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kuwait	INFINITI QX56	Z62	2010.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kuwait	INFINITI QX56	Z62	2010.3-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI QX56	Z62	2010.3-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Kuwait	INFINITI QX56	Z62	2010.3-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Kuwait	INFINITI QX56	Z62	2010.3-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI QX56	Z62	2010.3-	Auto back door	√	√	√	√		
Kuwait	INFINITI QX56	Z62	2010.3-	Occupant detection			√	√		SP0584
Kuwait	INFINITI QX56	Z62	2010.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561,SP0562
Kuwait	INFINITI QX56	Z62	2010.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI QX56	Z62	2010.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI QX56	Z62	2010.3-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Kuwait	INFINITI QX56	Z62	2010.3-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI QX56	Z62	2010.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI QX56	Z62	2010.3-	CAN gateway	√	√	√			
Kuwait	INFINITI QX56	Z62	2010.3-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kuwait	INFINITI QX56	Z62	2010.3-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI QX56	Z62	2010.3-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kuwait	INFINITI QX56	Z62	2010.3-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI QX56	Z62	2010.3-	Rearview camera	√			√		SP0570, SP0571
Kuwait	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kuwait	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Kuwait	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kuwait	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Kuwait	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Kuwait	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kuwait	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Kuwait	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Kuwait	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kuwait	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kuwait	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Kuwait	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Kuwait	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Kuwait	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Kuwait	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Kuwait	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Kuwait	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		
Kuwait	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Kuwait	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Kuwait	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kuwait	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kuwait	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Kuwait	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kuwait	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Kuwait	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Kuwait	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Kuwait	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Kuwait	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583

Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Kuwait	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Kuwait	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kuwait	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Kuwait	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kuwait	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Kuwait	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Kuwait	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kuwait	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kuwait	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Kuwait	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kuwait	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Kuwait	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Kuwait	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kuwait	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kuwait	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Kuwait	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Kuwait	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kuwait	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Kuwait	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Kuwait	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kuwait	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kuwait	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kuwait	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Kuwait	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kuwait	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Kuwait	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kuwait	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Kuwait	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kuwait	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kuwait	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kuwait	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Kuwait	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Kuwait	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Kuwait	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kuwait	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kuwait	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kuwait	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kuwait	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Kuwait	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Kuwait	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Kuwait	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Kuwait	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kuwait	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kuwait	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Kuwait	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Kuwait	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kuwait	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kuwait	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kuwait	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Kuwait	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Kuwait	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kuwait	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Kuwait	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Kuwait	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kuwait	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kuwait	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Kuwait	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kuwait	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Kuwait	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Kuwait	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Kuwait	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Kuwait	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Kuwait	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Kyrgyzsta	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kyrgyzsta	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kyrgyzsta n	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Kyrgyzsta n	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kyrgyzsta	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kyrgyzsta n	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kyrgyzsta	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta n	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kyrgyzsta	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzsta	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kyrgyzsta	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Kyrgyzsta	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzsta	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Kyrgyzsta	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kyrgyzsta	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzstan	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Kyrgyzstan	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzstan	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Kyrgyzstan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kyrgyzstan	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Kyrgyzstan	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzstan	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Kyrgyzstan	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Kyrgyzstan	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Kyrgyzstan	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzstan	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Kyrgyzsta	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kyrgyzstan	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Kyrgyzstan	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzstan	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Kyrgyzstan	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Kyrgyzstan	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Kyrgyzstan	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzstan	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		

Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572,SP0573
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570,SP0571
Kyrgyzsta	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Kyrgyzsta	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kyrgyzsta	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Kyrgyzsta n	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Kyrgyzsta n	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270
Kyrgyzsta	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Kyrgyzsta n	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Kyrgyzsta	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Kyrgyzsta n	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Kyrgyzsta	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
Kyrgyzsta	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Kyrgyzsta	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570,SP0571
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0200,SP0202,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Kyrgyzsta n	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Kyrgyzsta n	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Kyrgyzsta n	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Kyrgyzsta n	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Kyrgyzsta n	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957	
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Kyrgyzsta	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kyrgyzsta	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Kyrgyzsta n	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Kyrgyzsta n	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Kyrgyzsta	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Kyrgyzsta n	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Kyrgyzsta	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Kyrgyzsta	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Kyrgyzsta n	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Kyrgyzsta	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Kyrgyzsta	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Kyrgyzsta	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957	
Kyrgyzsta	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Kyrgyzsta	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Kyrgyzsta	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta n	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Kyrgyzsta	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Kyrgyzsta	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Kyrgyzsta	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351

Kyrgyzstan	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzstan	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Kyrgyzstan	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kyrgyzstan	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kyrgyzstan	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Kyrgyzstan	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Kyrgyzstan	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzstan	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Kyrgyzstan	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Kyrgyzstan	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzstan	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Kyrgyzstan	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Kyrgyzstan	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzstan	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Kyrgyzstan	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kyrgyzstan	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzstan	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzstan	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzstan	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Kyrgyzstan	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Kyrgyzstan	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Kyrgyzstan	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Kyrgyzstan	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Kyrgyzstan	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					

Kyrgyzstan	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Kyrgyzstan	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Kyrgyzstan	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Kyrgyzstan	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Kyrgyzstan	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kyrgyzstan	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Kyrgyzstan	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Motor control						
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Kyrgyzstan	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Kyrgyzstan	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Kyrgyzstan	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Kyrgyzstan	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzstan	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Kyrgyzstan	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzstan	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537

Kyrgyzsta	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Kyrgyzsta	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Kyrgyzsta	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Kyrgyzsta	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Kyrgyzsta	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Kyrgyzsta	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Kyrgyzsta	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Kyrgyzsta	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Kyrgyzsta	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Kyrgyzsta	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Kyrgyzsta	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Kyrgyzsta	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Kyrgyzsta	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta n	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kyrgyzsta	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kyrgyzsta n	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Kyrgyzsta	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kyrgyzsta n	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta n	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kyrgyzsta	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kyrgyzsta	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kyrgyzsta n	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Kyrgyzsta	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzsta	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Kyrgyzsta	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kyrgyzsta	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Kyrgyzsta	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Kyrgyzsta n	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Kyrgyzsta	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Kyrgyzsta	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzsta	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kyrgyzsta	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Kyrgyzsta	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzsta	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Kyrgyzsta	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Kyrgyzsta	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Kyrgyzsta	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Kyrgyzsta	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Kyrgyzsta	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Kyrgyzsta	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Kyrgyzsta	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta n	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Kyrgyzsta n	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kyrgyzsta n	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta n	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Kyrgyzsta n	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Kyrgyzsta n	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	

Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Kyrgyzsta	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta n	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Kyrgyzsta n	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kyrgyzsta n	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta n	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Kyrgyzsta n	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Kyrgyzsta n	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Kyrgyzsta	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta n	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kyrgyzsta n	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kyrgyzsta n	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta n	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kyrgyzsta n	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Kyrgyzsta	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Kyrgyzsta n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kyrgyzsta n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Kyrgyzsta n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Kyrgyzsta n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kyrgyzsta n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Kyrgyzsta n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Kyrgyzsta n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Kyrgyzstan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzstan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Kyrgyzstan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kyrgyzstan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kyrgyzstan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Kyrgyzstan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Kyrgyzstan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kyrgyzstan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzstan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kyrgyzstan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kyrgyzstan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Kyrgyzstan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzstan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kyrgyzstan	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kyrgyzstan	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kyrgyzstan	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzstan	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Kyrgyzstan	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kyrgyzstan	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kyrgyzstan	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Kyrgyzstan	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	HV batterv	√	√	√	√	AC1121	
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kyrgyzstan	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Kyrgyzsta	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzstan	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kyrgyzsta	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		

Kyrgyzsta	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Kyrgyzsta n	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Kyrgyzsta	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kyrgyzsta n	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta n	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzsta	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kyrgyzsta	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kyrgyzsta	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Kyrgyzsta n	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kyrgyzsta n	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Kyrgyzsta n	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kyrgyzsta	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Kyrgyzsta n	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Kyrgyzsta	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Kyrgyzsta	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Shift						
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	ANC						
Kyrgyzsta	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kyrgyzsta	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzsta	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Kyrgyzsta	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Kyrgyzsta n	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Motor control						
Kyrgyzsta n	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzsta n	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Kyrgyzsta n	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Kyrgyzsta n	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Kyrgyzsta n	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta n	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Kyrgyzsta	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			

Kyrgyzsta	INFINITI QX56	IA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Kyrgyzsta	INFINITI QX56	IA60	2004.10-	Smart entrance						SP0568
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta n	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Kyrgyzsta n	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270, SP0274
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta n	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kyrgyzsta	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta n	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kyrgyzsta	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Kyrgyzsta n	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzsta n	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Kyrgyzsta	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kyrgyzsta n	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Kyrgyzsta	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Kyrgyzsta	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzsta	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Kyrgyzsta	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kyrgyzsta	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kyrgyzsta	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kyrgyzsta	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Kyrgyzsta	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzsta	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Kyrgyzsta	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Kyrgyzsta	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Kyrgyzsta	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta n	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Kyrgyzsta n	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzsta n	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Kyrgyzsta n	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		

Kyrgyzsta	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta n	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kyrgyzsta	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Kyrgyzsta n	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Kyrgyzsta n	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Kyrgyzsta	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Kyrgyzsta	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Kyrgyzsta	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kyrgyzsta n	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzsta	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kyrgyzsta	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Kyrgyzsta	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kyrgyzsta	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kyrgyzsta	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzsta	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Kyrgyzsta n	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Kyrgyzsta n	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Kyrgyzsta n	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Kyrgyzsta n	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Kyrgyzsta n	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Kyrgyzsta n	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Kyrgyzsta	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556

Laos	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Laser/radar	√	√	√	√		
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Air bag	√	√	√	√		
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	EPS/DAST 3	√	√	√	√		
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Motor control	√	√	√	√		
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Pop up hood	√	√	√	√		
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Multi AV	√	√	√	√		SP0503
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	HV battery	√	√	√	√	AC1121	
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Occupant detection			√	√		SP0584
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	DAST 2	√	√	√	√		
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Precrash seatbelt	√	√	√	√		SP0612
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	CAN gateway	√	√	√			
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	DAST 1	√	√	√	√		
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	ANC	√	√	√	√	AC1024	
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Side radar left	√	√	√	√	AC1025	SP0582
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	HIGH BEAM ASSIST	√	√	√	√		
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Side radar right	√	√	√	√	AC1026	SP0583
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Brake	√	√	√	√	AC1127	
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Laos	INFINITI Q50 HYBRID	HV37	2014.1-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Latin america common	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latin america common	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Latin america common	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latin america common	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Latin america common	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Latin america common	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Latin america common	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latin america common	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Latin america common	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Latin america common	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latin america common	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latin america common	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latin america common	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latin america common	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Latin america common	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Latin america common	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Latin america common	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latin america common	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Latin america common	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239

Latin america common	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Latin america common	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latin america common	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Latin america common	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Latin america common	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Latin america common	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Latin america common	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Latin america common	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latin america common	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Latin america common	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

XTOOL

Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Latin america common	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Latin america common	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latin america common	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Latin america common	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Latin america common	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latin america common	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Latin america common	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Latin america common	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Latin america common	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Latin america common	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Latin america common	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Latin america common	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503

Latin america common	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Latin america common	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latin america common	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Latin america common	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latin america common	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Latin america common	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Latin america common	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Latin america common	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Latin america common	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Latin america common	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Latin america common	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Latin america common	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Latin america common	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Latin america common	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latin america common	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Latin america common	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Latin america common	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latin america common	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Latin america common	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Latin america common	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Latin america common	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Latin america common	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Latin america common	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Latin america common	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Latin america common	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Latin america common	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Latin america common	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Latin america common	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Latin america common	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latin america common	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latin america common	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latin america common	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latin america common	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Latin america common	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Latin america common	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Latin america common	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Latin america common	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latin america common	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Latin america common	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Latin america common	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Latin america common	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Latin america common	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Latin america common	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Latin america common	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		

Latin america common	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Latin america common	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Latin america common	INFINITI Q45	F50	2001.8-	Motor control						
Latin america common	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Latin america common	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Latin america common	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Latin america common	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Latin america common	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Latin america common	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Latin america common	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Latin america common	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latin america common	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Latin america common	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Latin america common	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Latin america common	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Latin america common	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Latin america common	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Latin america common	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Latin america common	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Latin america common	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latin america common	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Latin america common	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Latin america common	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Latin america common	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Latin america common	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Latin america common	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Latin america common	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Latin america common	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Latin america common	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Latin america common	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Latin america common	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Latin america common	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Latvia	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Latvia	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Latvia	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Latvia	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Latvia	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Latvia	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Latvia	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latvia	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Latvia	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latvia	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latvia	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latvia	INFINITI EX35/EX30D	I50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Latvia	INFINITI EX35/EX30D	I50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Latvia	INFINITI EX35/EX30D	I50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Latvia	INFINITI EX35/EX30D	I50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Latvia	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Latvia	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583

XTOOL

Latvia	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Latvia	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Latvia	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Latvia	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Latvia	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Latvia	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Latvia	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Latvia	INFINITI EX37	J50	2008.6-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Latvia	INFINITI EX37	I50	2008.6-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Latvia	INFINITI EX37	I50	2008.6-	Multi AV	√	√	√	√		
Latvia	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Latvia	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Latvia	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Latvia	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Latvia	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Latvia	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Latvia	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347,SP0348,SP0349
Latvia	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Latvia	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270
Latvia	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653,AC0695	SP0372,SP0429
Latvia	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Latvia	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Latvia	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
Latvia	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Latvia	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Latvia	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570,SP0571
Latvia	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Latvia	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Latvia	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Latvia	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Latvia	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Latvia	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Latvia	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Latvia	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Latvia	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Latvia	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Latvia	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Latvia	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Latvia	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Latvia	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Latvia	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Latvia	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Latvia	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Latvia	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0555,SP0556,SP0557
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570,SP0571
Latvia	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Latvia	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Latvia	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350

XTOOL

Latvia	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Latvia	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Latvia	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latvia	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Latvia	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Latvia	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Latvia	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Latvia	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Latvia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Latvia	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Latvia	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Latvia	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Latvia	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Latvia	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Latvia	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latvia	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Latvia	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Latvia	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Latvia	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latvia	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latvia	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Latvia	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Latvia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Latvia	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Latvia	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Latvia	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Latvia	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Latvia	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Latvia	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latvia	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Latvia	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Latvia	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Latvia	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latvia	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latvia	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Latvia	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Latvia	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Latvia	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Latvia	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Latvia	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349

Latvia	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Latvia	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Latvia	INFINITI M35/M45	Y50	2006.7-	BCM				√	AC0653, AC0698	SP0391, SP0393
Latvia	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Latvia	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Latvia	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Latvia	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Latvia	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Latvia	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Latvia	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Latvia	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Latvia	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Latvia	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Latvia	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Latvia	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Latvia	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Latvia	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Latvia	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Latvia	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Latvia	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Latvia	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Latvia	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Latvia	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Latvia	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Latvia	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Latvia	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Latvia	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Latvia	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latvia	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latvia	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latvia	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Latvia	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Latvia	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Latvia	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Latvia	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Latvia	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Latvia	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583

XTOOL

Latvia	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Latvia	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Latvia	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Latvia	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Latvia	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Latvia	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Latvia	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Latvia	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Latvia	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Latvia	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Latvia	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Latvia	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Latvia	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Latvia	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Latvia	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Latvia	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Latvia	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Latvia	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Latvia	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Latvia	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Latvia	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Latvia	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Latvia	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Latvia	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Latvia	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Latvia	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Latvia	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Latvia	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Latvia	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Latvia	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Latvia	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Latvia	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Latvia	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Latvia	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Latvia	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Latvia	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Latvia	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Latvia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Latvia	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Latvia	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Latvia	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Latvia	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Latvia	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Latvia	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Latvia	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		

Latvia	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Latvia	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Latvia	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Latvia	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Latvia	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Latvia	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Latvia	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Latvia	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Latvia	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Latvia	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084. AC1085. AC1086. AC1087. AC1088. AC1089. AC1106	
Latvia	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Latvia	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Latvia	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latvia	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Latvia	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Latvia	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Latvia	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Latvia	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Latvia	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Latvia	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Latvia	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Latvia	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Latvia	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Latvia	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Latvia	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Latvia	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Latvia	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Latvia	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Latvia	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Latvia	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Latvia	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Latvia	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Latvia	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Latvia	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Latvia	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Latvia	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Latvia	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Latvia	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084. AC1085. AC1086. AC1087. AC1088. AC1089. AC1106	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980. AC0981. AC0982	SP0561. SP0562
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Latvia	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897. AC0898. AC0899. AC0900. AC0901. AC0902	SP0508. SP0509
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429

Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Latvia	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Latvia	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Latvia	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Latvia	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Latvia	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Latvia	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Latvia	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Latvia	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Latvia	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Latvia	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Latvia	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Latvia	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Latvia	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Latvia	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Latvia	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Latvia	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latvia	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Latvia	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Latvia	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Latvia	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Latvia	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Latvia	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Latvia	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Latvia	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Latvia	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Latvia	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Latvia	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Latvia	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Latvia	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Latvia	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Latvia	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Latvia	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Latvia	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Latvia	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Latvia	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Latvia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Latvia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Latvia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Latvia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Latvia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Latvia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Latvia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Latvia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Latvia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Latvia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Latvia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Latvia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Latvia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Latvia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Latvia	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Latvia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Latvia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Latvia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Latvia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latvia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Latvia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Latvia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Latvia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Latvia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√			
Latvia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Latvia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Latvia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Latvia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Latvia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Latvia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Latvia	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Latvia	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Latvia	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Latvia	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583

Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Latvia	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Latvia	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Latvia	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Latvia	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Latvia	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Latvia	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Latvia	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Latvia	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Latvia	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Latvia	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latvia	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Latvia	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latvia	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latvia	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latvia	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Latvia	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Latvia	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Latvia	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Latvia	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Latvia	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Latvia	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Latvia	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Latvia	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Latvia	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Latvia	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Latvia	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Latvia	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Latvia	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Latvia	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Latvia	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Latvia	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Latvia	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Latvia	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Latvia	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Latvia	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Latvia	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Latvia	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Latvia	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Latvia	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Latvia	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Latvia	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Latvia	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Latvia	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Latvia	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Latvia	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Latvia	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Latvia	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Latvia	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Latvia	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Latvia	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Latvia	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Latvia	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Latvia	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Latvia	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Latvia	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Latvia	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Latvia	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Latvia	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Latvia	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Latvia	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Latvia	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Latvia	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Latvia	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Latvia	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Latvia	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Latvia	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Latvia	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Latvia	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Latvia	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Latvia	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Latvia	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Lebanon	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lebanon	INFINITI EX35	I50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI EX35	I50	2008.1-	Air bag	√	√	√	√		
Lebanon	INFINITI EX35	I50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lebanon	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Lebanon	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lebanon	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lebanon	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Lebanon	INFINITI EX35	I50	2008.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Lebanon	INFINITI EX35	I50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Lebanon	INFINITI EX35	I50	2008.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Lebanon	INFINITI EX35	I50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Lebanon	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Lebanon	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Lebanon	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Lebanon	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Lebanon	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Lebanon	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Lebanon	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270,SP0274
Lebanon	INFINITI EX35/EX37	I50	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Lebanon	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Lebanon	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Lebanon	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Lebanon	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Lebanon	INFINITI EX35/EX37	I50	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Lebanon	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Lebanon	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Lebanon	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
Lebanon	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Lebanon	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Lebanon	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
Lebanon	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
Lebanon	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Lebanon	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Lebanon	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Lebanon	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Lebanon	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Lebanon	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Lebanon	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Lebanon	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572,SP0573
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570,SP0571
Lebanon	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Lebanon	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Lebanon	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Lebanon	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0555,SP0556,SP0557
Lebanon	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Lebanon	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Lebanon	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570,SP0571
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	

Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Lebanon	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Lebanon	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Lebanon	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Lebanon	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Lebanon	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lebanon	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Lebanon	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Lebanon	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lebanon	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Lebanon	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Lebanon	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Lebanon	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lebanon	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Lebanon	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Lebanon	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Lebanon	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Lebanon	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Lebanon	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Lebanon	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Lebanon	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Lebanon	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Lebanon	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lebanon	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Lebanon	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Lebanon	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Lebanon	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Lebanon	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Lebanon	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Lebanon	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lebanon	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Lebanon	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Lebanon	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Lebanon	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Lebanon	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Lebanon	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Lebanon	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lebanon	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Lebanon	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Lebanon	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Lebanon	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Lebanon	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Lebanon	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Lebanon	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Lebanon	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Lebanon	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Lebanon	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Lebanon	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Lebanon	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Lebanon	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Lebanon	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lebanon	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lebanon	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Lebanon	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Lebanon	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lebanon	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lebanon	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lebanon	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lebanon	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lebanon	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Lebanon	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Lebanon	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lebanon	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Lebanon	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Lebanon	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Lebanon	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Lebanon	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Lebanon	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Lebanon	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Lebanon	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Lebanon	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Lebanon	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Lebanon	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Lebanon	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Lebanon	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Lebanon	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Lebanon	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					

Lebanon	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Lebanon	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Lebanon	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Lebanon	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Lebanon	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Lebanon	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Lebanon	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Lebanon	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Lebanon	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Lebanon	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Lebanon	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Lebanon	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Lebanon	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Lebanon	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Lebanon	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Lebanon	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Lebanon	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lebanon	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Lebanon	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Lebanon	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Lebanon	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Lebanon	INFINITI Q45	F50	2001.8-	Motor control						
Lebanon	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Lebanon	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Lebanon	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Lebanon	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Lebanon	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Lebanon	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Lebanon	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Lebanon	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Lebanon	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537

Xtool

Lebanon	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Lebanon	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Lebanon	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Lebanon	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Lebanon	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Lebanon	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Lebanon	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Lebanon	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Lebanon	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Lebanon	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Lebanon	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Lebanon	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Lebanon	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Lebanon	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Lebanon	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Lebanon	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lebanon	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Lebanon	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Lebanon	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lebanon	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, ,AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392 ,AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Lebanon	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Lebanon	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lebanon	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Lebanon	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lebanon	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lebanon	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lebanon	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Lebanon	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lebanon	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Lebanon	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Lebanon	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Lebanon	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Lebanon	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lebanon	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Lebanon	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Lebanon	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Lebanon	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Lebanon	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Lebanon	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Lebanon	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lebanon	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Lebanon	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Lebanon	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Lebanon	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Lebanon	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Lebanon	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Lebanon	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Lebanon	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Lebanon	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, ,AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	

Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Lebanon	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122.AC1123.AC1124.AC1125.AC1126	
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897.AC0898.AC0899.AC0900.AC0901.AC0902	SP0508.SP0509
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Lebanon	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Lebanon	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lebanon	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Lebanon	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lebanon	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Lebanon	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Lebanon	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lebanon	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Lebanon	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Lebanon	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lebanon	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Lebanon	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lebanon	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lebanon	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Lebanon	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lebanon	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Lebanon	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Lebanon	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Lebanon	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Lebanon	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lebanon	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Lebanon	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Lebanon	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Lebanon	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111.AC1112	SP0608.SP0609.SP0610
Lebanon	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590.SP0591.SP0592
Lebanon	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Lebanon	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Lebanon	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Lebanon	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Lebanon	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Lebanon	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Lebanon	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lebanon	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Lebanon	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Lebanon	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lebanon	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Lebanon	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lebanon	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Lebanon	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Lebanon	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Lebanon	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lebanon	INFINITI Q70	Y51	2013.9-	HV batterv	√	√	√	√	AC1121	
Lebanon	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lebanon	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lebanon	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Lebanon	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Lebanon	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lebanon	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Lebanon	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Lebanon	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lebanon	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Lebanon	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lebanon	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Lebanon	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lebanon	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Lebanon	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Lebanon	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Lebanon	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Lebanon	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Lebanon	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lebanon	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Lebanon	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lebanon	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		

Lebanon	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Lebanon	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lebanon	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lebanon	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Lebanon	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lebanon	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Lebanon	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lebanon	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Lebanon	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Lebanon	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lebanon	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Lebanon	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lebanon	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Lebanon	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Lebanon	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Lebanon	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Lebanon	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Lebanon	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Lebanon	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Lebanon	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Lebanon	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Lebanon	INFINITI QX50	J55	2018.5-	Shift						
Lebanon	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Lebanon	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	ANC						
Lebanon	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lebanon	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Lebanon	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Lebanon	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Lebanon	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Lebanon	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lebanon	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Lebanon	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Lebanon	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Lebanon	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Lebanon	INFINITI QX56	JA60	2004.10-	Motor control						
Lebanon	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Lebanon	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Lebanon	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Lebanon	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Lebanon	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Lebanon	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Lebanon	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Lebanon	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Lebanon	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Lebanon	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Lebanon	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Lebanon	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Lebanon	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Lebanon	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Lebanon	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Lebanon	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Lebanon	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Lebanon	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Lebanon	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Lebanon	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Lebanon	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			

Lebanon	INFINITI QX56	IA60	2004.10-	Rearview camera	√			√		SP0570,SP0571
Lebanon	INFINITI QX56	IA60	2004.10-	Smart entrance						SP0568
Lebanon	INFINITI QX56	Z62	2010.3-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Lebanon	INFINITI QX56	Z62	2010.3-	Laser/radar	√	√	√	√		
Lebanon	INFINITI QX56	Z62	2010.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI QX56	Z62	2010.3-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Lebanon	INFINITI QX56	Z62	2010.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI QX56	Z62	2010.3-	Air bag	√	√	√	√		
Lebanon	INFINITI QX56	Z62	2010.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Lebanon	INFINITI QX56	Z62	2010.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI QX56	Z62	2010.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lebanon	INFINITI QX56	Z62	2010.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Lebanon	INFINITI QX56	Z62	2010.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lebanon	INFINITI QX56	Z62	2010.3-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI QX56	Z62	2010.3-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Lebanon	INFINITI QX56	Z62	2010.3-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Lebanon	INFINITI QX56	Z62	2010.3-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI QX56	Z62	2010.3-	Auto back door	√	√	√	√		
Lebanon	INFINITI QX56	Z62	2010.3-	Occupant detection			√	√		SP0584
Lebanon	INFINITI QX56	Z62	2010.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lebanon	INFINITI QX56	Z62	2010.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI QX56	Z62	2010.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI QX56	Z62	2010.3-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Lebanon	INFINITI QX56	Z62	2010.3-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI QX56	Z62	2010.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI QX56	Z62	2010.3-	CAN gateway	√	√	√			
Lebanon	INFINITI QX56	Z62	2010.3-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lebanon	INFINITI QX56	Z62	2010.3-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI QX56	Z62	2010.3-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lebanon	INFINITI QX56	Z62	2010.3-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI QX56	Z62	2010.3-	Rearview camera	√			√		SP0570, SP0571
Lebanon	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lebanon	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Lebanon	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lebanon	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Lebanon	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Lebanon	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lebanon	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Lebanon	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Lebanon	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Lebanon	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lebanon	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Lebanon	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Lebanon	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Lebanon	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Lebanon	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Lebanon	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Lebanon	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Lebanon	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Lebanon	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lebanon	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lebanon	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Lebanon	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lebanon	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Lebanon	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Lebanon	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Lebanon	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Lebanon	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583

Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Lebanon	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Lebanon	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Lebanon	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Lebanon	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lebanon	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Lebanon	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Lebanon	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lebanon	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lebanon	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Lebanon	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lebanon	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Lebanon	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Lebanon	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lebanon	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lebanon	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Lebanon	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Lebanon	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lebanon	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Lebanon	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Lebanon	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lebanon	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lebanon	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lebanon	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Lebanon	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lebanon	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Lebanon	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Lebanon	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Lebanon	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lebanon	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lebanon	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lebanon	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Lebanon	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Lebanon	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Lebanon	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lebanon	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lebanon	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Lebanon	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lebanon	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Lebanon	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Lebanon	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Lebanon	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Lebanon	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lebanon	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lebanon	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Lebanon	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Lebanon	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lebanon	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lebanon	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lebanon	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Lebanon	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Lebanon	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lebanon	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Lebanon	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Lebanon	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lebanon	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lebanon	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Lebanon	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lebanon	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Lebanon	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Lebanon	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Lebanon	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Lebanon	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Lebanon	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Lesotho	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lesotho	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lesotho	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Lesotho	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lesotho	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lesotho	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Lesotho	INFINITI EX35/EX37	I50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lesotho	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Lesotho	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI EX35/EX37	I50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lesotho	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lesotho	INFINITI EX35/EX37	I50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lesotho	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Lesotho	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Lesotho	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Lesotho	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Lesotho	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Lesotho	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lesotho	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Lesotho	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lesotho	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lesotho	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Lesotho	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Lesotho	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lesotho	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Lesotho	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Lesotho	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		

Lesotho	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Lesotho	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lesotho	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Lesotho	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Lesotho	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lesotho	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Lesotho	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Lesotho	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Lesotho	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lesotho	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lesotho	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lesotho	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Lesotho	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Lesotho	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Lesotho	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lesotho	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lesotho	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lesotho	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lesotho	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lesotho	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lesotho	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Lesotho	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Lesotho	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Lesotho	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lesotho	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lesotho	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Lesotho	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Lesotho	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Lesotho	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Lesotho	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Lesotho	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Lesotho	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Lesotho	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Lesotho	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Lesotho	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Lesotho	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Lesotho	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Lesotho	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Lesotho	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Lesotho	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Lesotho	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Lesotho	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Lesotho	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Lesotho	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Lesotho	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Lesotho	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Lesotho	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Lesotho	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Lesotho	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Lesotho	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Lesotho	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lesotho	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Lesotho	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lesotho	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lesotho	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Lesotho	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Lesotho	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lesotho	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lesotho	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Lesotho	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429

Lesotho	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Lesotho	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Lesotho	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lesotho	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lesotho	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Lesotho	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Lesotho	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lesotho	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Lesotho	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Lesotho	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Lesotho	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Lesotho	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lesotho	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Lesotho	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lesotho	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lesotho	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Lesotho	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Lesotho	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Lesotho	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lesotho	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Lesotho	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Lesotho	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Lesotho	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lesotho	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Lesotho	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Lesotho	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Lesotho	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Lesotho	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lesotho	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Lesotho	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lesotho	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lesotho	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Lesotho	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Lesotho	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lesotho	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lesotho	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Lesotho	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Lesotho	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lesotho	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Lesotho	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lesotho	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lesotho	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Lesotho	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lesotho	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lesotho	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Lesotho	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Lesotho	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Lesotho	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Lesotho	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Lesotho	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Lesotho	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Lesotho	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lesotho	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Lesotho	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Lesotho	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Lesotho	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Lesotho	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Lesotho	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lesotho	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Lesotho	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Lesotho	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		

Lesotho	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Lesotho	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lesotho	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lesotho	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lesotho	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Lesotho	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Lesotho	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lesotho	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lesotho	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Lesotho	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Lesotho	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lesotho	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lesotho	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Lesotho	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Lesotho	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Lesotho	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Lesotho	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lesotho	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lesotho	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Lesotho	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lesotho	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lesotho	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Lesotho	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Lesotho	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Lesotho	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lesotho	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Lesotho	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lesotho	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lesotho	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lesotho	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Lesotho	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lesotho	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Lesotho	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lesotho	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Lesotho	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Lesotho	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lesotho	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Lesotho	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Lesotho	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lesotho	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lesotho	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Lesotho	INFINITI QX50	I50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lesotho	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Lesotho	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI QX50	I50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lesotho	INFINITI QX50	I50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lesotho	INFINITI QX50	I50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lesotho	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Lesotho	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Lesotho	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lesotho	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Lesotho	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lesotho	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Lesotho	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Lesotho	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lesotho	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Lesotho	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Lesotho	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Lesotho	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lesotho	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lesotho	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Lesotho	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Lesotho	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lesotho	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lesotho	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Lesotho	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lesotho	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Lesotho	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Lesotho	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lesotho	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lesotho	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Lesotho	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Lesotho	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lesotho	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lesotho	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lesotho	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Lesotho	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Lesotho	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lesotho	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Lesotho	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lesotho	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lesotho	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lesotho	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Lesotho	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Lesotho	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lesotho	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Lesotho	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Lesotho	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lesotho	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Lesotho	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lesotho	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Lesotho	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lesotho	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Lesotho	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Lesotho	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lesotho	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lesotho	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Lesotho	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lesotho	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Lesotho	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Lesotho	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Lesotho	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Lesotho	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lesotho	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Lesotho	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Lesotho	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lesotho	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lesotho	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Lesotho	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Lesotho	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Lesotho	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Lesotho	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Lesotho	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lesotho	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lesotho	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Lesotho	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lesotho	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Lesotho	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Lesotho	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Lesotho	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Lesotho	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Liberia	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Liberia	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI EX35/EX37	I50	2011.1-	Air bag	√	√	√	√		
Liberia	INFINITI EX35/EX37	I50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Liberia	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Liberia	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Liberia	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Liberia	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Liberia	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Liberia	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Liberia	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Liberia	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Liberia	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Liberia	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Liberia	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Liberia	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Liberia	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Liberia	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Liberia	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Liberia	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Liberia	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Liberia	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Liberia	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Liberia	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Liberia	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Liberia	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Liberia	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Liberia	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Liberia	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Liberia	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Liberia	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Liberia	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Liberia	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Liberia	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Liberia	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Liberia	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Liberia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

XTOOL

Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Liberia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Liberia	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Liberia	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Liberia	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Liberia	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Liberia	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Liberia	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Liberia	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Liberia	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Liberia	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Liberia	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Liberia	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Liberia	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Liberia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Liberia	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Liberia	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Liberia	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Liberia	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Liberia	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Liberia	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Liberia	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Liberia	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Liberia	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Liberia	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Liberia	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Liberia	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Liberia	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Liberia	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Liberia	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Liberia	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Liberia	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Liberia	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Liberia	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Liberia	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Liberia	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Liberia	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Liberia	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Liberia	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Liberia	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Liberia	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Liberia	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Liberia	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Liberia	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Liberia	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Liberia	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Liberia	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Liberia	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Liberia	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Liberia	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Liberia	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Liberia	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Liberia	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Liberia	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Liberia	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Liberia	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Liberia	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Liberia	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Liberia	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Liberia	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Liberia	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		

Liberia	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Liberia	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Liberia	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Liberia	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Liberia	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Liberia	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Liberia	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Liberia	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Liberia	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Liberia	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Liberia	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Liberia	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Liberia	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Liberia	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Liberia	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Liberia	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Liberia	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Liberia	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Liberia	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Liberia	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Liberia	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Liberia	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Liberia	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Liberia	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Liberia	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Liberia	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Liberia	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Liberia	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Liberia	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Liberia	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Liberia	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Liberia	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Liberia	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Liberia	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Liberia	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Liberia	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Liberia	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Liberia	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Liberia	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Liberia	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Liberia	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Liberia	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Liberia	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Liberia	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Liberia	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Liberia	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274

Liberia	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Liberia	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Liberia	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Liberia	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Liberia	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Liberia	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Liberia	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Liberia	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Liberia	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Liberia	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Liberia	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Liberia	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Liberia	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Liberia	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Liberia	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Liberia	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Liberia	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Liberia	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Liberia	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Liberia	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Liberia	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Liberia	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Liberia	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Liberia	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Liberia	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Liberia	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Liberia	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Liberia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Liberia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Liberia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Liberia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Liberia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Liberia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Liberia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Liberia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Xtool

Liberia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Liberia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Liberia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Liberia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Liberia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Liberia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Liberia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Liberia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Liberia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Liberia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Liberia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Liberia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Liberia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Liberia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Liberia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Liberia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Liberia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Liberia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Liberia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Liberia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Liberia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Liberia	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Liberia	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Liberia	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Liberia	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Liberia	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Liberia	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Liberia	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Liberia	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Liberia	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Liberia	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Liberia	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Liberia	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Liberia	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Liberia	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Liberia	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Liberia	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Liberia	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Liberia	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Liberia	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Liberia	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Liberia	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Liberia	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Liberia	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Liberia	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Liberia	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Liberia	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Liberia	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Liberia	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Liberia	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Liberia	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Liberia	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Liberia	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Liberia	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Liberia	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Liberia	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Liberia	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Liberia	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Liberia	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Liberia	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Liberia	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Liberia	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Liberia	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Liberia	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Liberia	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Liberia	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Liberia	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Liberia	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Liberia	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Liberia	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Liberia	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Liberia	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Liberia	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Liberia	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Liberia	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Liberia	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Liberia	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Liberia	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Liberia	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Liberia	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Liberia	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Liberia	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Liberia	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Liberia	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Liberia	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Liberia	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Liberia	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Liberia	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Liberia	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Liberia	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Liberia	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Liberia	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Liberia	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Liberia	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Liberia	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Liberia	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Liberia	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Liberia	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Liberia	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Liberia	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Liberia	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Liberia	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Liberia	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Liberia	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Liberia	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Liberia	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Liberia	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Libya	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Libya	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Libya	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Libya	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Libya	INFINITI EX35/EX37	I50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Libya	INFINITI EX35/EX37	I50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Libya	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Libya	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI EX35/EX37	I50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Libya	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Libya	INFINITI EX35/EX37	I50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Libya	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Libya	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Libya	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Libya	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Libya	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Libya	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Libya	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Libya	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Libya	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Libya	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Libya	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Libya	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Libya	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Libya	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Libya	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Libya	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Libya	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Libya	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Libya	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Libya	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Libya	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Libya	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Libya	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Libya	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Libya	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Libya	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√	AC0956	SP0274
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Libya	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Libya	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Libya	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Libya	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Libya	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Libya	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Libya	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Libya	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Libya	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Libya	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Libya	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Libya	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Libya	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Libya	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Libya	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Libya	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Libya	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Libya	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Libya	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Libya	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Libya	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Libya	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Libya	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Libya	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Libya	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Libya	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Libya	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Libya	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Libya	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Libya	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Libya	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Libya	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Libya	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Libya	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Libya	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Libya	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Libya	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Libya	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Libya	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Libya	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Libya	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Libya	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Libya	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Libya	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501

Libya	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Libya	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Libya	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Libya	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Libya	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Libya	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Libya	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Libya	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Libya	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Libya	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Libya	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Libya	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Libya	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Libya	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Libya	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Libya	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Libya	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Libya	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Libya	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Libya	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Libya	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Libya	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Libya	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Libya	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Libya	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Libya	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Libya	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Libya	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Libya	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Libya	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Libya	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Libya	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Libya	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Libya	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Libya	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Libya	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Libya	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Libya	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Libya	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Libya	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Libya	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Libya	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Libya	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Libya	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Libya	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Libya	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Libya	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Libya	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Libya	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Libya	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Libya	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Libya	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		

Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Libya	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Libya	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Libya	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Libya	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Libya	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Libya	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Libya	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Libya	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Libya	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Libya	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Libya	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Libya	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Libya	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Libya	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Libya	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Libya	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Libya	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Libya	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Libya	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Libya	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Libya	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Libya	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Libya	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Libya	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Libya	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Libya	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Libya	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Libya	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Libya	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Libya	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Libya	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Libya	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Libya	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Libya	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Libya	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Libya	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Libya	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Libya	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Libya	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Libya	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Libya	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Libya	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Libya	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Libya	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Libya	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Libya	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Libya	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Libya	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Libya	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Libya	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Libya	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Libya	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Libya	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Libya	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Libya	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Libya	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Libya	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Libya	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Libya	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Libya	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Libya	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Libya	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Libya	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Libya	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Libya	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Libya	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Libya	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Libya	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Libya	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Libya	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Libya	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Libya	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Libya	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Libya	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Libya	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Libya	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Libya	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Libya	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Libya	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Libya	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Libya	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Libya	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Libya	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Libya	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Libya	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Libya	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Libya	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Libya	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Libya	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Libya	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Libya	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Libya	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Libya	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Libya	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Libya	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Libya	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Libya	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Libya	INFINITI QX50	I50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Libya	INFINITI QX50	I50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Libya	INFINITI QX50	I50	2013.8-	CAN gateway	√	√	√	√		
Libya	INFINITI QX50	I50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Libya	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Libya	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Libya	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Libya	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Libya	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Libya	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Libya	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Libya	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Libya	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Libya	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Libya	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Libya	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Libya	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Libya	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315

Libya	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Libya	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Libya	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Libya	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Libya	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Libya	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Libya	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Libya	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Libya	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Libya	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Libya	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Libya	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Libya	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Libya	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Libya	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Libya	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Libya	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Libya	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Libya	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Libya	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Libya	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Libya	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Libya	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Libya	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Libya	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Libya	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Libya	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Libya	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Libya	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Libya	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Libya	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Libya	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Libya	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Libya	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Libya	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Libya	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Libya	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Libya	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Libya	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Libya	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Libya	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Libya	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Libya	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Libya	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Libya	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Libya	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Libya	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Libya	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Libya	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Libya	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Libya	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Libya	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Libya	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Libya	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Lithuania	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Lithuania	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Lithuania	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lithuania	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Lithuania	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lithuania	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Lithuania	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lithuania	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lithuania	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Lithuania	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Lithuania	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lithuania	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lithuania	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Lithuania	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Lithuania	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Lithuania	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Lithuania	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239

Lithuania	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Lithuania	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Lithuania	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lithuania	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Lithuania	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Lithuania	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Lithuania	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Lithuania	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Lithuania	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Lithuania	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Lithuania	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lithuania	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Lithuania	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Lithuania	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lithuania	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Lithuania	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Lithuania	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Lithuania	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lithuania	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lithuania	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lithuania	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Lithuania	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Lithuania	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Lithuania	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Lithuania	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lithuania	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Lithuania	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Lithuania	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lithuania	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lithuania	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Lithuania	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Lithuania	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Lithuania	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Xtool

Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Lithuania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Lithuania	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Lithuania	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Lithuania	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Lithuania	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Lithuania	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Lithuania	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Lithuania	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Lithuania	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lithuania	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Lithuania	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lithuania	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Lithuania	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Lithuania	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Lithuania	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Lithuania	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Lithuania	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Lithuania	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Lithuania	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Lithuania	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Lithuania	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Lithuania	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Lithuania	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Lithuania	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lithuania	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		

Lithuania	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lithuania	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Lithuania	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Lithuania	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lithuania	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Lithuania	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Lithuania	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lithuania	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Lithuania	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Lithuania	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lithuania	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lithuania	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lithuania	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Lithuania	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Lithuania	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lithuania	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Lithuania	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Lithuania	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Lithuania	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Lithuania	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Lithuania	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Lithuania	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Lithuania	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Lithuania	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Lithuania	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Lithuania	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Lithuania	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Lithuania	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Lithuania	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Lithuania	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		

XTOOL

Lithuania	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Lithuania	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Lithuania	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Lithuania	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Lithuania	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Lithuania	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Lithuania	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Lithuania	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Lithuania	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Lithuania	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Lithuania	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Lithuania	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Lithuania	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Lithuania	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Lithuania	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Lithuania	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Lithuania	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Lithuania	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Lithuania	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Lithuania	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Lithuania	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lithuania	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Lithuania	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lithuania	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Lithuania	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Lithuania	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lithuania	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Lithuania	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lithuania	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Lithuania	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Lithuania	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lithuania	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Lithuania	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lithuania	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Lithuania	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lithuania	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lithuania	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Lithuania	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Lithuania	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lithuania	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lithuania	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lithuania	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Lithuania	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Lithuania	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Lithuania	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lithuania	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540

Lithuania	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Lithuania	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lithuania	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Lithuania	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Lithuania	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Lithuania	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Lithuania	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Lithuania	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Lithuania	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Lithuania	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lithuania	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Lithuania	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Lithuania	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Lithuania	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Lithuania	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Lithuania	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Lithuania	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Lithuania	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Lithuania	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Lithuania	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Lithuania	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Lithuania	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Lithuania	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Lithuania	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lithuania	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Lithuania	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Lithuania	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lithuania	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lithuania	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Lithuania	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Lithuania	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Lithuania	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Lithuania	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lithuania	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Lithuania	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lithuania	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lithuania	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lithuania	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Lithuania	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Lithuania	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Lithuania	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985. AC0986. AC0987. AC0988. AC0989	SP0563. SP0564. SP0565. SP0566. SP0567
Lithuania	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Lithuania	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971. AC0972. AC0973. AC0974. AC0975. AC0976. AC0977	SP0560
Lithuania	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Lithuania	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Lithuania	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Lithuania	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Lithuania	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Lithuania	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lithuania	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Lithuania	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Lithuania	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Lithuania	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Lithuania	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Lithuania	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lithuania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983. AC0984. AC0985. AC0986. AC0987. AC0988. AC0989. AC0990	SP0563. SP0564. SP0565. SP0566. SP0567
Lithuania	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894. AC0895. AC0896. AC0897. AC0898. AC0899. AC0900. AC0901. AC0902	SP0508. SP0509. SP0510
Lithuania	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Lithuania	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

Lithuania	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Lithuania	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Lithuania	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lithuania	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lithuania	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Lithuania	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Lithuania	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Lithuania	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Lithuania	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lithuania	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lithuania	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lithuania	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Lithuania	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lithuania	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lithuania	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lithuania	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Lithuania	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Lithuania	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lithuania	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Lithuania	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lithuania	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Lithuania	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lithuania	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Lithuania	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Lithuania	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lithuania	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Lithuania	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Lithuania	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Lithuania	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Lithuania	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Lithuania	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Lithuania	INFINITI QX50	I50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Lithuania	INFINITI QX50	I50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Lithuania	INFINITI QX50	I50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Lithuania	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Lithuania	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Lithuania	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Lithuania	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Lithuania	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Lithuania	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Lithuania	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Lithuania	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Lithuania	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Lithuania	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Lithuania	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Lithuania	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Lithuania	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	

Lithuania	INFINITI QX50	I50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Lithuania	INFINITI QX50	I50	2013.9-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Lithuania	INFINITI QX50	I50	2013.9-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Lithuania	INFINITI QX50	I50	2013.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Lithuania	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Lithuania	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Lithuania	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Lithuania	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Lithuania	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Lithuania	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Lithuania	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347,SP0348
Lithuania	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Lithuania	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270
Lithuania	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613,AC0653,AC0663,AC0689,AC0692,AC0695,AC0702,AC0719	SP0372,SP0429
Lithuania	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Lithuania	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Lithuania	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Lithuania	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Lithuania	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Lithuania	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Lithuania	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Lithuania	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Lithuania	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Lithuania	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570,SP0571
Lithuania	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Lithuania	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Lithuania	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Lithuania	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Lithuania	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Lithuania	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Lithuania	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Lithuania	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Lithuania	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Lithuania	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Lithuania	INFINITI QX70	S51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Lithuania	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Lithuania	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Lithuania	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Lithuania	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Lithuania	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Lithuania	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Lithuania	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Lithuania	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Lithuania	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Lithuania	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Lithuania	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0555,SP0556,SP0557
Lithuania	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Lithuania	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Lithuania	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Lithuania	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Lithuania	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Lithuania	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Lithuania	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Lithuania	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Lithuania	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Lithuania	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Lithuania	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Luxembour g	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0202,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0236,SP0237,SP0238,SP0239
Luxembour g	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Luxembour g	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Luxembour g	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022,AC1023	
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Luxembour	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Luxembour	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Luxembour	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembour	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Luxembour	INFINITI EX37	I50	2008.6-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Luxembour	INFINITI EX37	I50	2008.6-	Air bag	√	√	√	√		
Luxembour	INFINITI EX37	I50	2008.6-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Luxembour g	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Luxembour g	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Luxembour	INFINITI EX37	J50	2008.6-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Luxembour	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Luxembour	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Luxembour g	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Luxembour	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Luxembour	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556

Luxembourg	INFINITI EX37	I50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Luxembourg	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Luxembourg	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Luxembourg	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Luxembourg	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Luxembourg	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Luxembourg	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Luxembourg	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Luxembourg	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembourg	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Luxembourg	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Luxembourg	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Luxembourg	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Luxembourg	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembourg	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Luxembourg	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembourg	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Luxembourg	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Luxembourg	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Luxembourg	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Luxembourg	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Luxembourg	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Luxembourg	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Luxembourg	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembourg	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Luxembourg	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Luxembourg	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494

Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Luxembourg	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Luxembourg	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Luxembourg	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembourg	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Luxembourg	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Luxembourg	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Luxembourg	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Luxembourg	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Luxembourg	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Luxembourg	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Luxembourg	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Luxembourg	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Luxembourg	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Luxembourg	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembourg	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Luxembourg	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Luxembourg	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Luxembourg	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Luxembourg	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Luxembourg	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembourg	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Luxembourg	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Luxembourg	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Luxembourg	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497

Luxembour	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembour	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Luxembour	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Luxembour	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Luxembour	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Luxembourg	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Luxembourg	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Luxembour	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Luxembour	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Luxembour	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Luxembour	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Luxembour	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Luxembour	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Luxembour	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembour	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Luxembour	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Luxembour	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Luxembour	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Luxembour	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Luxembour	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Luxembour	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Luxembour	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Luxembour	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Luxembour	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Luxembour	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Luxembourg	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Luxembour	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Luxembour	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Luxembourg	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Luxembour	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Luxembourg	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Luxembour	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Luxembour	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Luxembour	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Luxembour	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Luxembourg	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	

Luxembourg	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Luxembourg	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Luxembourg	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Luxembourg	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Luxembourg	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Luxembour	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Luxembour	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Luxembourg	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Luxembour	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Luxembour	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Luxembourg	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Luxembour	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Luxembourg	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Luxembour	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Luxembour	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Luxembourg	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Luxembourg	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Luxembour	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Luxembourg	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Luxembour	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Luxembourg	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Luxembour	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Luxembour	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Luxembourg	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Luxembourg	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Luxembourg	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Luxembourg	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Luxembourg	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Luxembourg	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Luxembourg	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Luxembourg	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Luxembour	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Luxembourg	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Luxembourg	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Luxembourg	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Luxembour	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Luxembour	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Luxembour	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Luxembour	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Luxembour	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembour	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Luxembour	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Luxembour	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Luxembour	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Luxembourg	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Luxembour	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Luxembour	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Luxembourg	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Luxembour	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Luxembour	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Luxembour	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Luxembour	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Luxembour	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Luxembourg	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembour	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Luxembour	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Luxembour	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Luxembour	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Luxembour	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Luxembour	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551

Luxembour	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Luxembour	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Luxembour	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Luxembour	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Luxembour	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Luxembour	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Luxembour	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembour	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Luxembour	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Luxembourg	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Luxembour	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Luxembour	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Luxembour	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Luxembour	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Luxembour	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Luxembour	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Luxembour	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Luxembour	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Luxembour	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Luxembour	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Luxembour	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Luxembour	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Luxembour	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Luxembour	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Luxembourg	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Luxembourg	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Luxembourg	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Luxembourg	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Luxembour	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Luxembourg	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Luxembourg	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Luxembourg	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Luxembourg	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	

Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Luxembour	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Luxembour	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509
Luxembour	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Luxembour	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0869、AC0870、AC0871、AC0872、AC0873、AC0874、AC0875、AC0876、AC0877、AC0878、AC0879、AC0880、AC0881、AC0882、AC0883、AC0884、AC0885	SP0494、SP0495、SP0496、SP0497
Luxembour	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Luxembour	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Luxembour	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Luxembour	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348、SP0349、SP0350、SP0351
Luxembourg	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0225、AC0226、AC0229、AC0256、AC0266、AC0270、AC0272、AC0277、AC0282、AC0283、AC0284、AC0307、AC0308、AC0309、AC0311、AC0312、AC0313、AC0314、AC0315、AC0316、AC0317、AC0318、AC0319、AC0320、AC0321、AC0322、AC0323、AC0324、AC0325、AC0326、AC0327、AC0330、AC0331、AC0332、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0009、SP0016、SP0017、SP0018、SP0032、SP0033、SP0034、SP0038、SP0039、SP0043、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0082、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0120、SP0128、SP0140、SP0143、SP0150、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0193、SP0194、SP0195、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Luxembour	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247、SP0265、SP0270、SP0274
Luxembour	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613、AC0618、AC0663、AC0690、AC0692、AC0702	SP0372、SP0429
Luxembourg	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498、AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533、AC0536	SP0300、SP0313、SP0315
Luxembour	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Luxembour	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472、SP0473、SP0474、SP0475、SP0477、SP0479、SP0480、SP0481、SP0482、SP0486、SP0487
Luxembourg	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Luxembour	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Luxembour	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980、AC0981、AC0982	SP0561、SP0562
Luxembour	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Luxembour	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962、AC0963、AC0964、AC0966、AC0967、AC0968、AC0969、AC0970	SP0553、SP0554、SP0555、SP0556、SP0557、SP0558、SP0559
Luxembour	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Luxembour	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Luxembour	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Luxembour	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985、AC0986、AC0987、AC0988、AC0989	SP0563、SP0564、SP0565、SP0566、SP0567
Luxembour	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Luxembour	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971、AC0972、AC0973、AC0974、AC0975、AC0976、AC0977	SP0560
Luxembour	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembour	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Luxembour	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Luxembour	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Luxembour	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Luxembour	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111、AC1112	SP0608、SP0609、SP0610
Luxembour	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590、SP0591、SP0592
Luxembour	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Luxembour	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Luxembour	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Luxembour	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Luxembour	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Luxembour	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006、AC1007、AC1008、AC1009、AC1010	SP0575、SP0576、SP0577、SP0578、SP0579、SP0580
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0876、AC0877	SP0494
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0225、AC0226、AC0282、AC0283、AC0307、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0016、SP0017、SP0018、SP0032、SP0033、SP0038、SP0043、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0140、SP0143、SP0150、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613、AC0618、AC0663、AC0692、AC0702、AC0719	SP0372、SP0429
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498、AC0507、AC0508、AC0509、AC0510、AC0511、AC0512、AC0513、AC0514、AC0515、AC0516、AC0517、AC0527、AC0528、AC0529、AC0530、AC0531、AC0532、AC0533、AC0534、AC0535	SP0315、SP0316、SP0317、SP0319
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980	SP0561、SP0562
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962、AC0963、AC0964	SP0553、SP0554、SP0555、SP0556
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983、AC0984、AC0985、AC0986、AC0987、AC0988、AC0989、AC0990	SP0563、SP0564、SP0565、SP0566、SP0567
Luxembourg	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0876、AC0877、AC0884	SP0494
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350
Luxembourg	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0225、AC0226、AC0282、AC0283、AC0307、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0016、SP0017、SP0018、SP0032、SP0033、SP0038、SP0043、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0140、SP0143、SP0150、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613、AC0618、AC0663、AC0692、AC0702、AC0719	SP0372、SP0429
Luxembourg	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498、AC0507、AC0508、AC0509、AC0510、AC0511、AC0512、AC0513、AC0514、AC0515、AC0516、AC0517、AC0527、AC0528、AC0529、AC0530、AC0531、AC0532、AC0533、AC0534、AC0535	SP0315、SP0316、SP0317、SP0319
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027、AC1028	
Luxembourg	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980	SP0561、SP0562
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962、AC0963、AC0964	SP0553、SP0554、SP0555、SP0556
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956、AC0957、AC0958、AC0959、AC0960	SP0544、SP0545、SP0546、SP0547、SP0548、SP0549、SP0550、SP0551
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983、AC0984、AC0985、AC0986、AC0987、AC0988、AC0989、AC0990	SP0563、SP0564、SP0565、SP0566、SP0567
Luxembour	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembour	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894、AC0895、AC0896、AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509、SP0510
Luxembour	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	

Luxembour	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Luxembour	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembour	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Luxembour	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Luxembour	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Luxembourg	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Luxembourg	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Luxembour	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Luxembourg	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Luxembour	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Luxembour	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Luxembour	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Luxembour	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Luxembourg	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembour	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Luxembour	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Luxembour	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Luxembour	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Luxembour	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Luxembour	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Luxembour	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Luxembour	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Luxembour	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Luxembour	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembour	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Luxembour	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Luxembour	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Luxembour	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Luxembour	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Luxembour	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Luxembour	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Luxembour	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Luxembour	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Luxembour	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Luxembourg	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Luxembourg	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Luxembourg	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Luxembourg	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Luxembour	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Luxembour	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Luxembour	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Luxembour	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembourg	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Luxembour	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembour	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Luxembour	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Luxembour	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Luxembourg	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Luxembour	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Luxembour	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Luxembourg	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Luxembour	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Luxembourg	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Luxembour	INFINITI QX50	I50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Luxembour	INFINITI QX50	I50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Luxembour	INFINITI QX50	I50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Luxembour	INFINITI QX50	I50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Luxembour	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Luxembour	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Luxembour	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Luxembour	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Luxembour	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Luxembour	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Luxembour	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Luxembour	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Luxembour g	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Luxembour	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Luxembour	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Luxembour g	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Luxembour g	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Luxembour	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Luxembour g	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Luxembour	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Luxembour	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Luxembour	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Luxembour g	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembour	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Luxembour	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Luxembour g	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Luxembour	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Luxembour	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Luxembour	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Luxembour	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Luxembour	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Luxembour g	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Luxembour	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Luxembour	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Luxembour	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Luxembour	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Luxembour g	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Luxembour g	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Luxembour	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Luxembour	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Luxembour	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Luxembour	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Luxembour	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Luxembour	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Luxembour g	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Luxembour	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Luxembour	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Luxembour	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Luxembour	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Luxembour	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Luxembour	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Luxembour	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Luxembour	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Luxembour	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Luxembour	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Luxembour	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Luxembour	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Luxembour	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Luxembour	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Luxembour	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Luxembour	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Macau	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Laser/radar	√	√	√	√		
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Air bag	√	√	√	√		
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	EPS/DAST 3	√	√	√	√		SP0507
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Motor control	√	√	√	√		

Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Transmission	√	√	√	√		SP0276
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Pop up hood	√	√	√	√		
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Multi AV	√	√	√	√		SP0503
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	HV battery	√	√	√	√	AC1121	
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Occupant detection			√	√		SP0584
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	DAST 2	√	√	√	√		
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Precrash seatbelt	√	√	√	√		SP0612
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	CAN gateway	√	√	√			
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	DAST 1	√	√	√	√		
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	ANC	√	√	√	√	AC1024	
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Side radar left	√	√	√	√	AC1025	SP0582
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	HIGH BEAM ASSIST	√	√	√	√		
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Side radar right	√	√	√	√	AC1026	SP0583
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	Brake	√	√	√	√	AC1127	
Macau	INFINITI Q50 HYBRID	HV37	2016.2-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Macedonia	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Macedonia	INFINITI EX35/EX30D	I50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Macedonia	INFINITI EX35/EX30D	I50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Macedonia	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Macedonia	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Macedonia	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Macedonia	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Macedonia	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Macedonia	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Macedonia	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Macedonia	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Macedonia	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Macedonia	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Macedonia	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0555,SP0556,SP0557
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570,SP0571
Macedonia	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Macedonia	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Macedonia	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Macedonia	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Macedonia	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270
Macedonia	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Macedonia	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Macedonia	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Macedonia	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Macedonia	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
Macedonia	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Macedonia	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570,SP0571
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Macedonia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Macedonia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350

Macedonia	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Macedonia	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Macedonia	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Macedonia	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Macedonia	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Macedonia	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Macedonia	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Macedonia	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Macedonia	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Macedonia	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Macedonia	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Macedonia	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Macedonia	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Macedonia	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Macedonia	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Macedonia	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Macedonia	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Macedonia	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Macedonia	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Macedonia	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Macedonia	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Macedonia	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Macedonia	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Macedonia	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Macedonia	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Macedonia	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Macedonia	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Macedonia	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Macedonia	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Macedonia	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Macedonia	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Macedonia	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Macedonia	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Macedonia	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Macedonia	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Macedonia	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Macedonia	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Macedonia	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Macedonia	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Macedonia	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Macedonia	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Macedonia	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Macedonia	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503

Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Macedonia	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Macedonia	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Macedonia	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Macedonia	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Macedonia	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Macedonia	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Macedonia	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Macedonia	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Macedonia	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Macedonia	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Macedonia	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Macedonia	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Macedonia	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Macedonia	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Macedonia	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Macedonia	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Macedonia	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Macedonia	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Macedonia	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Macedonia	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Macedonia	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Macedonia	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Macedonia	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Macedonia	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Macedonia	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Macedonia	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Macedonia	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Macedonia	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Macedonia	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		

Macedonia	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Macedonia	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Macedonia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Macedonia	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Macedonia	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Macedonia	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Macedonia	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Macedonia	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Macedonia	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Macedonia	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Macedonia	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Macedonia	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Macedonia	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Macedonia	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Macedonia	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Macedonia	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Macedonia	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Macedonia	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Macedonia	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Macedonia	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Macedonia	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Macedonia	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Macedonia	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Macedonia	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Macedonia	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Macedonia	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Macedonia	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Macedonia	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Macedonia	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Macedonia	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Macedonia	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Macedonia	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Macedonia	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Macedonia	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Macedonia	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Macedonia	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Macedonia	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Macedonia	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Macedonia	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Macedonia	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Macedonia	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Macedonia	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Macedonia	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Macedonia	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Macedonia	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Macedonia	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Macedonia	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Macedonia	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	

Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Macedonia	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Macedonia	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Macedonia	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Macedonia	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Macedonia	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Macedonia	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Macedonia	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Macedonia	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Macedonia	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Macedonia	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Macedonia	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Macedonia	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Macedonia	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Macedonia	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Macedonia	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Macedonia	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Macedonia	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Macedonia	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Macedonia	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Macedonia	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Macedonia	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Macedonia	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Macedonia	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Macedonia	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Macedonia	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Macedonia	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Macedonia	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Macedonia	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Macedonia	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Macedonia	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Macedonia	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Macedonia	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Macedonia	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Macedonia	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Macedonia	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Macedonia	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Macedonia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Macedonia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Macedonia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Macedonia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Macedonia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Macedonia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Macedonia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Macedonia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Macedonia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Macedonia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Macedonia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Macedonia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Macedonia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Macedonia	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Macedonia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Macedonia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Macedonia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Macedonia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Macedonia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Macedonia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Macedonia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Macedonia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Macedonia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Macedonia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Macedonia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Macedonia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Macedonia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Macedonia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Macedonia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Macedonia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Macedonia	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Macedonia	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Macedonia	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Macedonia	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		

Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Macedonia	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Macedonia	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Macedonia	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Macedonia	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Macedonia	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Macedonia	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Macedonia	INFINITI QX50	I50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Macedonia	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Macedonia	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Macedonia	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Macedonia	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Macedonia	INFINITI QX50	I50	2013.9-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Macedonia	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Macedonia	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Macedonia	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Macedonia	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Macedonia	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Macedonia	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Macedonia	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Macedonia	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Macedonia	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Macedonia	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Macedonia	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Macedonia	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Macedonia	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Macedonia	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Macedonia	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Macedonia	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Macedonia	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Macedonia	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Macedonia	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Macedonia	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Macedonia	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Macedonia	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Macedonia	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Macedonia	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Macedonia	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Macedonia	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Macedonia	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Macedonia	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Macedonia	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Macedonia	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Macedonia	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Macedonia	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Macedonia	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Macedonia	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Macedonia	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Macedonia	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Macedonia	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Macedonia	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Macedonia	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621

Xtool

Macedonia	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Macedonia	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Macedonia	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Macedonia	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Macedonia	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Macedonia	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Macedonia	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Macedonia	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Macedonia	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Macedonia	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Macedonia	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Macedonia	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Macedonia	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Macedonia	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Macedonia	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Macedonia	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Macedonia	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Macedonia	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Macedonia	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Macedonia	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Madagascar	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagascar	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Madagascar	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Madagascar	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Madagascar	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Madagascar	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Madagascar	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Madagascar	INFINITI EX35/EX37	I50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Madagascar	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Madagascar	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Madagascar	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Madagascar	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Madagascar	INFINITI EX35/EX37	I50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Madagascar	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Madagascar	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Madagascar	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Madagascar	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Madagascar	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagascar	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Madagascar	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Madagascar	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Madagascar	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Madagascar	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Madagascar	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Madagascar	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Madagascar	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Madagascar	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Madagascar	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Madagascar	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Madagascar	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Madagascar	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Madagasca	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Madagasca	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Madagasca	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Madagasca	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagasca	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Madagascar	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Madagasca	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Madagasca	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Madagasca	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Madagascar	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Madagascar	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Madagasca	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Madagascar	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Madagasca	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Madagasca	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Madagasca	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Madagasca	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Madagascar	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Madagasca	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Madagasca	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Madagasca	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Madagasca	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Madagasca	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Madagasca	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Madagasca	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Madagasca	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Madagasca	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Madagasca	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Madagasca	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Madagasca	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Madagascar	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Madagasca	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Madagascar	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Madagasca	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Madagasca	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Madagasca	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Madagasca	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Madagascar	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Madagascar	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Madagascar	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		

Madagascar	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Madagascar	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Madagascar	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Madagasca	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Madagasca	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Madagascar	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Madagasca	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Madagasca	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Madagascar	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Madagasca	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Madagascar	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Madagasca	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Madagasca	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Madagascar	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Madagascar	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Madagasca	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Madagasca	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Madagasca	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Madagasca	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagascar	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Madagasca	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Madagasca	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Madagasca	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Madagasca	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Madagascar	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Madagasca	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Madagasca	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Madagasca	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Madagasca	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Madagasca	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Madagasca	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Madagasca	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Madagasca	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Madagasca	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Madagasca	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Madagasca	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Madagasca	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Madagasca	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Madagasca	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Madagasca	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Madagasca	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Madagasca	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Madagasca	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Madagasca	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Madagasca	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Madagascar	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Madagasca	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Madagasca	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Madagasca	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Madagasca	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Madagasca	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Madagasca	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Madagasca	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Madagasca	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagascar	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Madagascar	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Madagascar	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Madagasca	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	

Madagascar	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
Madagascar	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Madagascar	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Madagascar	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Madagascar	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagascar	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Madagascar	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Madagascar	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Madagascar	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Madagascar	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Madagascar	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Madagascar	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Madagascar	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Madagascar	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Madagascar	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Madagascar	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Madagascar	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Madagascar	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Madagascar	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Madagascar	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Madagascar	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Madagascar	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966.AC0967.AC0968	SP0557
Madagascar	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Madagascar	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Madagascar	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Madagascar	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Madagascar	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Madagascar	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Madagascar	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Madagascar	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Madagascar	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Madagascar	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Madagascar	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Madagascar	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Madagascar	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Madagascar	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Madagascar	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Madagascar	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Madagascar	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Madagascar	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Madagascar	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543

Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Madagascar	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Madagascar	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Madagascar	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Madagascar	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagascar	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Madagascar	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Madagascar	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Madagascar	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Madagascar	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Madagascar	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Madagascar	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Madagascar	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Madagascar	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Madagascar	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Madagascar	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Madagascar	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Madagascar	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Madagascar	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Madagascar	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Madagascar	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Madagascar	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Madagascar	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Madagascar	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Madagascar	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Madagascar	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Madagascar	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Madagascar	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Madagascar	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Madagascar	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Madagascar	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Madagascar	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Madagascar	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Madagascar	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Madagascar	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagascar	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Madagascar	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Madagascar	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Madagascar	INFINITI QX50	I50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Madagascar	INFINITI QX50	I50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Madagascar	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Madagascar	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Madagascar	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Madagascar	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Madagascar	INFINITI QX50	I50	2013.8-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Madagascar	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Madagascar	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Madagascar	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Madagascar	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Madagascar	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Madagascar	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Madagascar	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Madagascar	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Madagascar	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Madagascar	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Madagascar	INFINITI QX50	I50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Madagascar	INFINITI QX50	I50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Madagascar	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Madagascar	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Madagascar	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagascar	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Madagascar	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Madagascar	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Madagascar	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Madagascar	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Madagascar	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Madagascar	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Madagascar	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Madagascar	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Madagascar	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Madagascar	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Madagascar	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Madagascar	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Madagascar	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Madagascar	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Madagascar	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Madagascar	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Madagascar	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Madagascar	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Madagascar	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Madagascar	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Madagascar	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Madagascar	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Madagascar	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Madagascar	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Madagascar	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Madagascar	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Madagascar	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Madagascar	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583

Madagascar	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Madagascar	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Madagascar	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Madagascar	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Madagascar	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Madagascar	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Madagascar	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Madagascar	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Madagascar	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Madagascar	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Madagascar	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Madagascar	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Madagascar	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Madagascar	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Madagascar	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Madagascar	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Madagascar	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Madagascar	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Madagascar	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Madagascar	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Madagascar	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Madagascar	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Madagascar	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Madagascar	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Madagascar	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Madagascar	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Madagascar	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Madagascar	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Madagascar	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Madagascar	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Madagascar	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Madagascar	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Madagascar	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Madagascar	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Madagascar	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Malawi	INFINITI EX35/EX37	I50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI EX35/EX37	I50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malawi	INFINITI EX35/EX37	I50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Malawi	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malawi	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malawi	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Malawi	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malawi	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Malawi	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malawi	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malawi	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malawi	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Malawi	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Malawi	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Malawi	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Malawi	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Malawi	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Malawi	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malawi	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Malawi	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malawi	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malawi	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Malawi	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malawi	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Malawi	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Malawi	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malawi	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Malawi	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Malawi	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malawi	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malawi	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Malawi	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Malawi	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Malawi	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Malawi	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malawi	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Malawi	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Malawi	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Malawi	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malawi	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Malawi	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malawi	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malawi	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Malawi	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malawi	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malawi	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Malawi	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malawi	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malawi	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malawi	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Malawi	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malawi	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Malawi	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Malawi	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Malawi	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Malawi	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Malawi	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malawi	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malawi	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Malawi	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Malawi	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Malawi	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Malawi	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malawi	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malawi	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malawi	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malawi	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malawi	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malawi	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Malawi	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Malawi	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Malawi	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Malawi	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malawi	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Malawi	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Malawi	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Malawi	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344

Malawi	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Malawi	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Malawi	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Malawi	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Malawi	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Malawi	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Malawi	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Malawi	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Malawi	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Malawi	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Malawi	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Malawi	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Malawi	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Malawi	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Malawi	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Malawi	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Malawi	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Malawi	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Malawi	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Malawi	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Malawi	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Malawi	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malawi	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Malawi	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malawi	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Malawi	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Malawi	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malawi	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malawi	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Malawi	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Malawi	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Malawi	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Malawi	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malawi	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malawi	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Malawi	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Malawi	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malawi	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Malawi	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Malawi	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Malawi	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Malawi	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malawi	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Malawi	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Malawi	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malawi	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Malawi	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Malawi	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Malawi	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malawi	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Malawi	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Malawi	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Malawi	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malawi	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Malawi	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Malawi	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		

Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Malawi	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Malawi	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malawi	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Malawi	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malawi	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Malawi	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Malawi	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malawi	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malawi	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Malawi	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Malawi	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Malawi	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Malawi	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malawi	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malawi	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Malawi	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malawi	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malawi	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Malawi	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Malawi	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Malawi	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Malawi	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Malawi	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Malawi	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Malawi	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malawi	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Malawi	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Malawi	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Malawi	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Malawi	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Malawi	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malawi	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Malawi	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Malawi	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Malawi	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Malawi	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malawi	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Malawi	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malawi	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malawi	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Malawi	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Malawi	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malawi	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Malawi	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Malawi	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malawi	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malawi	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Malawi	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Malawi	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Malawi	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Malawi	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malawi	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malawi	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Malawi	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malawi	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malawi	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Malawi	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Malawi	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Malawi	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malawi	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Malawi	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malawi	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malawi	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malawi	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Malawi	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malawi	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Malawi	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malawi	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Malawi	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malawi	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Malawi	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Malawi	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malawi	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malawi	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Malawi	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malawi	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Malawi	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malawi	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malawi	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Malawi	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Malawi	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Malawi	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malawi	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Malawi	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malawi	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Malawi	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Malawi	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malawi	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Malawi	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Malawi	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Malawi	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malawi	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Malawi	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Malawi	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Malawi	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malawi	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Malawi	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malawi	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Malawi	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Malawi	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malawi	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malawi	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Malawi	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Malawi	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malawi	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malawi	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Malawi	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Malawi	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Malawi	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malawi	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Malawi	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malawi	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malawi	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malawi	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Malawi	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Malawi	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malawi	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Malawi	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Malawi	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malawi	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Malawi	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malawi	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Malawi	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malawi	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Malawi	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Malawi	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malawi	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Malawi	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Malawi	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Malawi	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Malawi	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Malawi	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Malawi	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Malawi	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malawi	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Malawi	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Malawi	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malawi	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malawi	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Malawi	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Malawi	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Malawi	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Malawi	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Malawi	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malawi	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malawi	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Malawi	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malawi	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Malawi	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Malawi	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Malawi	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Malawi	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Malaysia	INFINITI EX25/EX35	J50	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI EX25/EX35	J50	2011.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Malaysia	INFINITI EX25/EX35	J50	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Malaysia	INFINITI EX25/EX35	J50	2011.7-	Air bag	√	√	√	√		
Malaysia	INFINITI EX25/EX35	J50	2011.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malaysia	INFINITI EX25/EX35	J50	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malaysia	INFINITI EX25/EX35	J50	2011.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Malaysia	INFINITI EX25/EX35	J50	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malaysia	INFINITI EX25/EX35	J50	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Malaysia	INFINITI EX25/EX35	J50	2011.7-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI EX25/EX35	J50	2011.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI EX25/EX35	J50	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malaysia	INFINITI EX25/EX35	J50	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malaysia	INFINITI EX25/EX35	J50	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Malaysia	INFINITI EX25/EX35	J50	2011.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Malaysia	INFINITI EX25/EX35	J50	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Malaysia	INFINITI EX25/EX35	J50	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI EX25/EX35	J50	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI EX35	J50	2012.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI EX35	J50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI EX35	J50	2012.9-	Air bag	√	√	√	√		
Malaysia	INFINITI EX35	J50	2012.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
Malaysia	INFINITI EX35	J50	2012.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Malaysia	INFINITI EX35	J50	2012.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Malaysia	INFINITI EX35	J50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malaysia	INFINITI EX35	J50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Malaysia	INFINITI EX35	J50	2012.9-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI EX35	J50	2012.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI EX35	J50	2012.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malaysia	INFINITI EX35	J50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malaysia	INFINITI EX35	J50	2012.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malaysia	INFINITI EX35	J50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	

Malaysia	INFINITI EX35	I50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Malaysia	INFINITI EX35	I50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI EX35	I50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI FX35/FX50	S51	2011.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malaysia	INFINITI FX35/FX50	S51	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Air bag	√	√	√	√		
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Transmission	√	√	√	√		SP0274
Malaysia	INFINITI FX35/FX50	S51	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malaysia	INFINITI FX35/FX50	S51	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI FX35/FX50	S51	2011.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Auto back door	√	√	√	√		SP0611
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Occupant detection			√	√		SP0584
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Malaysia	INFINITI FX35/FX50	S51	2011.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Malaysia	INFINITI FX35/FX50	S51	2011.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Malaysia	INFINITI FX35/FX50	S51	2011.7-	CAN gateway	√	√	√			
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malaysia	INFINITI FX35/FX50	S51	2011.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malaysia	INFINITI FX35/FX50	S51	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malaysia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Malaysia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malaysia	INFINITI M25/M37	Y51	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Malaysia	INFINITI M25/M37	Y51	2011.7-	Laser/radar	√	√	√	√		
Malaysia	INFINITI M25/M37	Y51	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI M25/M37	Y51	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Malaysia	INFINITI M25/M37	Y51	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI M25/M37	Y51	2011.7-	Air bag	√	√	√	√		
Malaysia	INFINITI M25/M37	Y51	2011.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malaysia	INFINITI M25/M37	Y51	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malaysia	INFINITI M25/M37	Y51	2011.7-	Transmission	√	√	√	√		SP0274
Malaysia	INFINITI M25/M37	Y51	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Malaysia	INFINITI M25/M37	Y51	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Malaysia	INFINITI M25/M37	Y51	2011.7-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI M25/M37	Y51	2011.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malaysia	INFINITI M25/M37	Y51	2011.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malaysia	INFINITI M25/M37	Y51	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI M25/M37	Y51	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malaysia	INFINITI M25/M37	Y51	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malaysia	INFINITI M25/M37	Y51	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malaysia	INFINITI M25/M37	Y51	2011.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Malaysia	INFINITI M25/M37	Y51	2011.7-	CAN gateway	√	√	√			
Malaysia	INFINITI M25/M37	Y51	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	

Xtool

Malaysia	INFINITI M25/M37	Y51	2011.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malaysia	INFINITI M25/M37	Y51	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI M25/M37	Y51	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI M35H	HY51	2012.1-	Air pressure monitor	√	√	√	√	AC0894、AC0895、AC0896	SP0510
Malaysia	INFINITI M35H	HY51	2012.1-	Laser/radar	√	√	√	√		
Malaysia	INFINITI M35H	HY51	2012.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI M35H	HY51	2012.1-	ICC/ADAS	√	√	√	√	AC0867、AC0868、AC0869、AC0870、AC0871、AC0872、AC0873、AC0874、AC0875、AC0878、AC0879、AC0880、AC0881、AC0882、AC0883、AC0884、AC0885	SP0495、SP0496、SP0497
Malaysia	INFINITI M35H	HY51	2012.1-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Malaysia	INFINITI M35H	HY51	2012.1-	Air bag	√	√	√	√		
Malaysia	INFINITI M35H	HY51	2012.1-	EPS/DAST 3	√	√	√	√		
Malaysia	INFINITI M35H	HY51	2012.1-	Meter/M&A	√	√	√	√		SP0348、SP0349、SP0350、SP0351
Malaysia	INFINITI M35H	HY51	2012.1-	Motor control	√	√	√	√		
Malaysia	INFINITI M35H	HY51	2012.1-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0282、AC0283、AC0307、AC0333、AC0334、AC0335、AC0336、AC0337、AC0338、AC0339、AC0351、AC0352、AC0365、AC0366、AC0367、AC0369、AC0371、AC0372、AC0373、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0016、SP0017、SP0018、SP0032、SP0033、SP0043、SP0045、SP0051、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0083、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0196、SP0197、SP0198、SP0199、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0225、SP0237、SP0238、SP0239
Malaysia	INFINITI M35H	HY51	2012.1-	Transmission	√	√	√	√		SP0274、SP0276
Malaysia	INFINITI M35H	HY51	2012.1-	BCM				√	AC0613、AC0618、AC0663、AC0690、AC0692、AC0702	SP0372、SP0429、SP0471
Malaysia	INFINITI M35H	HY51	2012.1-	ABS	√	√	√	√	AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533、AC0536	SP0300、SP0313、SP0315
Malaysia	INFINITI M35H	HY51	2012.1-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI M35H	HY51	2012.1-	HVAC	√	√	√	√	AC0809	SP0472、SP0473、SP0474、SP0475、SP0477、SP0479、SP0480、SP0481、SP0482、SP0486、SP0487
Malaysia	INFINITI M35H	HY51	2012.1-	HV battery	√	√	√	√	AC1121	
Malaysia	INFINITI M35H	HY51	2012.1-	Auto drive position	√	√	√	√	AC0946、AC0947、AC0948、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Malaysia	INFINITI M35H	HY51	2012.1-	EV/HEV	√	√	√	√	AC1084、AC1085、AC1086、AC1087、AC1088、AC1089、AC1106	
Malaysia	INFINITI M35H	HY51	2012.1-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980	SP0561、SP0562
Malaysia	INFINITI M35H	HY51	2012.1-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Malaysia	INFINITI M35H	HY51	2012.1-	Sonar	√	√	√	√	AC0962、AC0963、AC0964	SP0553、SP0554、SP0555、SP0556
Malaysia	INFINITI M35H	HY51	2012.1-	Precrash seatbelt	√	√	√	√		SP0612
Malaysia	INFINITI M35H	HY51	2012.1-	CAN gateway	√	√	√			
Malaysia	INFINITI M35H	HY51	2012.1-	Brake	√	√	√	√	AC1127	
Malaysia	INFINITI M35H	HY51	2012.1-	VSP	√	√	√	√	AC1124、AC1125、AC1126	
Malaysia	INFINITI Q30	H15	2016.1-	Air pressure monitor	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	Air bag	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	EPS/DAST 3	√	√	√			
Malaysia	INFINITI Q30	H15	2016.1-	Meter/M&A	√	√	√	√	AC0546、AC0547、AC0548、AC0549	SP0342、SP0343、SP0344
Malaysia	INFINITI Q30	H15	2016.1-	Engine	√	√	√	√	AC0002、AC0103、AC0214、AC0264、AC0265、AC0266、AC0267、AC0268、AC0269、AC0270、AC0271、AC0272、AC0273、AC0274、AC0275、AC0276、AC0277、AC0308、AC0310、AC0311、AC0312、AC0314、AC0315、AC0317、AC0320、AC0325、AC0327、AC0328、AC0329、AC0330、AC0331、AC0332	SP0034、SP0035、SP0159、SP0193、SP0194
Malaysia	INFINITI Q30	H15	2016.1-	EHS/PKB	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	Transmission	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	BCM	√	√	√	√	AC0580、AC0674、AC0739、AC0740、AC0741、AC0742、AC0743、AC0744、AC0745、AC0746、AC0747、AC0748、AC0749、AC0750、AC0751、AC0752、AC0753、AC0754、AC0755、AC0756、AC0757、AC0758、AC0759、AC0760、AC0761、AC0762、AC0763、AC0764、AC0765、AC0766、AC0767、AC0768、AC0769、AC0770	
Malaysia	INFINITI Q30	H15	2016.1-	ABS	√	√	√	√		SP0308
Malaysia	INFINITI Q30	H15	2016.1-	Multi AV	√	√	√	√		SP0501
Malaysia	INFINITI Q30	H15	2016.1-	HVAC	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	Auto drive position	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	Shift	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	All mode AWD/4WD	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	AVM	√	√		√		
Malaysia	INFINITI Q30	H15	2016.1-	Intelligent key	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	CAN gateway	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	ANC	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	Telematics	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	FSCM	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	Siren control unit	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143、AC1144、AC1145、AC1146、AC1147、AC1148、AC1149、AC1150、AC1151、AC1152、AC1153、AC1154、AC1155、AC1156	
Malaysia	INFINITI Q30	H15	2016.1-	Overhead Control Panel Unit	√			√		
Malaysia	INFINITI Q30	H15	2016.1-	Universal Garage Door Opener	√			√		
Malaysia	INFINITI Q30	H15	2016.1-	Upper control panel cont unit	√					
Malaysia	INFINITI Q30	H15	2016.1-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171、AC1172、AC1173、AC1174、AC1175	
Malaysia	INFINITI Q30	H15	2016.1-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157、AC1158、AC1159、AC1160、AC1161、AC1162、AC1163、AC1164、AC1165、AC1166、AC1167、AC1168、AC1169、AC1170	SP0622
Malaysia	INFINITI Q30	H15	2016.1-	Light/Rain Sensor Module	√			√		
Malaysia	INFINITI Q30	H15	2016.1-	EC Mirror Compass	√					
Malaysia	INFINITI Q30	H15	2016.1-	Intelligent Battery Sensor	√					
Malaysia	INFINITI Q30	H15	2016.1-	Alarm siren	√			√		
Malaysia	INFINITI Q30	H15	2016.1-	Radar sensor	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	Steering column cont module	√	√	√			
Malaysia	INFINITI Q30	H15	2016.1-	ICC sensor	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	Trailer recognition control unit	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	H/L control module LH	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	Powertrain cont module	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	Side radar LH	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	LED H/L control module LH	√			√		
Malaysia	INFINITI Q30	H15	2016.1-	Steering Wheel Switch Pad	√			√		
Malaysia	INFINITI Q30	H15	2016.1-	Parking assist	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	Occupant Classification Unit	√			√		
Malaysia	INFINITI Q30	H15	2016.1-	Electronic Ignition Switch cont unit	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	H/L control module RH	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	Front camera unit	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	Side radar RH	√	√	√	√		
Malaysia	INFINITI Q30	H15	2016.1-	LED H/L control module RH	√			√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546、AC0547、AC0548、AC0549	SP0342、SP0343、SP0344
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002、AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0103、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0214、AC0225、AC0226、AC0229、AC0256、AC0264、AC0265、AC0266、AC0267、AC0268、AC0269、AC0270、AC0271、AC0272、AC0273、AC0274、AC0275、AC0276、AC0277、AC0282、AC0283、AC0284、AC0307、AC0308、AC0310、AC0311、AC0312、AC0314、AC0315、AC0317、AC0320、AC0325、AC0327、AC0328、AC0329、AC0330、AC0331、AC0332、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0009、SP0016、SP0017、SP0018、SP0032、SP0033、SP0034、SP0035、SP0038、SP0039、SP0043、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0082、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0140、SP0143、SP0150、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0193、SP0194、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Malaysia	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580、AC0674、AC0739、AC0740、AC0741、AC0742、AC0743、AC0744、AC0745、AC0746、AC0747、AC0748、AC0749、AC0750、AC0751、AC0752、AC0753、AC0754、AC0755、AC0756、AC0757、AC0758、AC0759、AC0760、AC0761、AC0762、AC0763、AC0764、AC0765、AC0766、AC0767、AC0768、AC0769、AC0770	
Malaysia	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Malaysia	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		

XTOOL

Malaysia	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Malaysia	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Malaysia	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Malaysia	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Malaysia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Malaysia	INFINITI Q50	V37	2014.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Malaysia	INFINITI Q50	V37	2014.1-	Laser/radar	√	√	√	√	AC0994	
Malaysia	INFINITI Q50	V37	2014.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI Q50	V37	2014.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malaysia	INFINITI Q50	V37	2014.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI Q50	V37	2014.1-	Air bag	√	√	√	√		
Malaysia	INFINITI Q50	V37	2014.1-	EPS/DAST 3	√	√	√	√		SP0507
Malaysia	INFINITI Q50	V37	2014.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malaysia	INFINITI Q50	V37	2014.1-	Motor control	√	√	√	√		
Malaysia	INFINITI Q50	V37	2014.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malaysia	INFINITI Q50	V37	2014.1-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Malaysia	INFINITI Q50	V37	2014.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Malaysia	INFINITI Q50	V37	2014.1-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Malaysia	INFINITI Q50	V37	2014.1-	Pop up hood	√	√	√	√		
Malaysia	INFINITI Q50	V37	2014.1-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI Q50	V37	2014.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malaysia	INFINITI Q50	V37	2014.1-	HV battery	√	√	√	√	AC1121	
Malaysia	INFINITI Q50	V37	2014.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malaysia	INFINITI Q50	V37	2014.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malaysia	INFINITI Q50	V37	2014.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI Q50	V37	2014.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Malaysia	INFINITI Q50	V37	2014.1-	Occupant detection			√	√		SP0584
Malaysia	INFINITI Q50	V37	2014.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malaysia	INFINITI Q50	V37	2014.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malaysia	INFINITI Q50	V37	2014.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Malaysia	INFINITI Q50	V37	2014.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Malaysia	INFINITI Q50	V37	2014.1-	DAST 2	√	√	√	√		
Malaysia	INFINITI Q50	V37	2014.1-	Precrash seatbelt	√	√	√	√		SP0612
Malaysia	INFINITI Q50	V37	2014.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malaysia	INFINITI Q50	V37	2014.1-	CAN gateway	√	√	√			
Malaysia	INFINITI Q50	V37	2014.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malaysia	INFINITI Q50	V37	2014.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malaysia	INFINITI Q50	V37	2014.1-	DAST 1	√	√	√	√		
Malaysia	INFINITI Q50	V37	2014.1-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Malaysia	INFINITI Q50	V37	2014.1-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Malaysia	INFINITI Q50	V37	2014.1-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Malaysia	INFINITI Q50	V37	2014.1-	ANC	√	√	√	√	AC1024	
Malaysia	INFINITI Q50	V37	2014.1-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI Q50	V37	2014.1-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Malaysia	INFINITI Q50	V37	2014.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malaysia	INFINITI Q50	V37	2014.1-	HIGH BEAM ASSIST	√	√	√	√		
Malaysia	INFINITI Q50	V37	2014.1-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI Q50	V37	2014.1-	Brake	√	√	√	√	AC1127	
Malaysia	INFINITI Q50	V37	2014.1-	6ch CAN GATEWAY	√	√	√	√		
Malaysia	INFINITI Q50	V37	2014.1-	3ch CAN GATEWAY	√	√	√	√		
Malaysia	INFINITI Q50	V37	2014.1-	ICC/ADAS 2	√	√	√	√		
Malaysia	INFINITI Q50	V37	2014.1-	PMAS	√	√	√	√		
Malaysia	INFINITI Q50	V37	2014.1-	PSCM	√	√	√	√	AC1109	
Malaysia	INFINITI Q50	V37	2014.1-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Laser/radar	√	√	√	√	AC0994	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Air bag	√	√	√	√		
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Motor control	√	√	√	√		
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Pop up hood	√	√	√	√		
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	HV battery	√	√	√	√	AC1121	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Occupant detection			√	√		SP0584
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	DAST 2	√	√	√	√		
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	CAN gateway	√	√	√			
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	DAST 1	√	√	√	√		
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	ANC	√	√	√	√	AC1024	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Brake	√	√	√	√	AC1127	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	6ch CAN GATEWAY	√	√	√	√		
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	FSCM	√	√	√	√	AC1109	
Malaysia	INFINITI Q50 HYBRID	HV37	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Laser/radar	√	√	√	√		
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Air bag	√	√	√	√		
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	EPS/DAST 3	√	√	√	√		
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Motor control	√	√	√	√		
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Transmission	√	√	√	√		SP0276
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Pop up hood	√	√	√	√		
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	HV battery	√	√	√	√	AC1121	
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Occupant detection			√	√		SP0584
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	DAST 2	√	√	√	√		
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Precrash seatbelt	√	√	√	√		SP0612
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	DAST 1	√	√	√	√		
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	ANC	√	√	√	√	AC1024	
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	HIGH BEAM ASSIST	√	√	√	√		
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	VSP	√	√	√	√		
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	Brake	√	√	√	√	AC1127	
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Malaysia	INFINITI Q50 Hybrid	HV37	2018.5-	ICC/ADAS 2	√	√	√	√		
Malaysia	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malaysia	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Malaysia	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malaysia	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Malaysia	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Malaysia	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malaysia	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malaysia	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Malaysia	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Malaysia	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Malaysia	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Malaysia	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malaysia	INFINITI Q60	CV37	2016.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malaysia	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Malaysia	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malaysia	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malaysia	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Malaysia	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Malaysia	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Malaysia	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Malaysia	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malaysia	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Malaysia	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√		
Malaysia	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malaysia	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Malaysia	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Malaysia	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Malaysia	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Malaysia	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malaysia	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Malaysia	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Malaysia	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Malaysia	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Malaysia	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	Laser/radar	√	√	√	√	AC0994	
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	Air bag	√	√	√	√		
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	Transmission	√	√	√	√		SP0274
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	Pop up hood	√	√	√	√		
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	Precrash seatbelt	√	√	√	√		
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malaysia	INFINITI Q60 COUPE	CV36	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malaysia	INFINITI Q70	Y51	2013.11-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Malaysia	INFINITI Q70	Y51	2013.11-	Laser/radar	√	√	√	√	AC0994	
Malaysia	INFINITI Q70	Y51	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI Q70	Y51	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malaysia	INFINITI Q70	Y51	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI Q70	Y51	2013.11-	Air bag	√	√	√	√		
Malaysia	INFINITI Q70	Y51	2013.11-	EPS/DAST 3	√	√	√	√		
Malaysia	INFINITI Q70	Y51	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malaysia	INFINITI Q70	Y51	2013.11-	Motor control	√	√	√	√		
Malaysia	INFINITI Q70	Y51	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malaysia	INFINITI Q70	Y51	2013.11-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Malaysia	INFINITI Q70	Y51	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Malaysia	INFINITI Q70	Y51	2013.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Malaysia	INFINITI Q70	Y51	2013.11-	Pop up hood	√	√	√	√		
Malaysia	INFINITI Q70	Y51	2013.11-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI Q70	Y51	2013.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malaysia	INFINITI Q70	Y51	2013.11-	HV battery	√	√	√	√	AC1121	
Malaysia	INFINITI Q70	Y51	2013.11-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malaysia	INFINITI Q70	Y51	2013.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malaysia	INFINITI Q70	Y51	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI Q70	Y51	2013.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Malaysia	INFINITI Q70	Y51	2013.11-	Occupant detection			√	√		SP0584
Malaysia	INFINITI Q70	Y51	2013.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malaysia	INFINITI Q70	Y51	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malaysia	INFINITI Q70	Y51	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Malaysia	INFINITI Q70	Y51	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Malaysia	INFINITI Q70	Y51	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Malaysia	INFINITI Q70	Y51	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malaysia	INFINITI Q70	Y51	2013.11-	CAN gateway	√	√	√	√		
Malaysia	INFINITI Q70	Y51	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malaysia	INFINITI Q70	Y51	2013.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malaysia	INFINITI Q70	Y51	2013.11-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Malaysia	INFINITI Q70	Y51	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malaysia	INFINITI Q70	Y51	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI Q70	Y51	2013.11-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Malaysia	INFINITI Q70	Y51	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malaysia	INFINITI Q70	Y51	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI Q70	Y51	2013.11-	VSP	√	√	√	√		
Malaysia	INFINITI Q70	Y51	2013.11-	Brake	√	√	√	√	AC1127	
Malaysia	INFINITI Q70	Y51	2013.11-	6ch CAN GATEWAY	√	√	√	√		
Malaysia	INFINITI Q70	Y51	2013.11-	ICC/ADAS 2	√	√	√	√		
Malaysia	INFINITI Q70	Y51	2013.11-	FSCM	√	√	√	√	AC1109	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√		SP0274, SP0276
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√	√		
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	ANC	√	√	√	√	AC1024	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610

Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	FSCM	√	√	√	√	AC1109	
Malaysia	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Laser/radar	√	√	√	√		
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Air bag	√	√	√	√		
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	EPS/DAST 3	√	√	√	√		
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Motor control	√	√	√	√		
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Pop up hood	√	√	√	√		
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	HV battery	√	√	√	√	AC1121	
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Precrash seatbelt	√	√	√	√		SP0612
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	VSP	√	√	√	√		
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	Brake	√	√	√	√	AC1127	
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	ICC/ADAS 2	√	√	√	√		
Malaysia	INFINITI Q70L Hybrid	HY51	2018.5-	FSCM	√	√	√	√	AC1109	
Malaysia	INFINITI QX50	J50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malaysia	INFINITI QX50	J50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Malaysia	INFINITI QX50	I50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI QX50	J50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malaysia	INFINITI QX50	J50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malaysia	INFINITI QX50	J50	2013.7-	Air bag	√	√	√	√		
Malaysia	INFINITI QX50	J50	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Malaysia	INFINITI QX50	J50	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malaysia	INFINITI QX50	J50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malaysia	INFINITI QX50	I50	2013.7-	Transmission	√	√	√	√		SP0274
Malaysia	INFINITI QX50	J50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malaysia	INFINITI QX50	J50	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Malaysia	INFINITI QX50	J50	2013.7-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI QX50	J50	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malaysia	INFINITI QX50	I50	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malaysia	INFINITI QX50	I50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malaysia	INFINITI QX50	J50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Malaysia	INFINITI QX50	I50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Malaysia	INFINITI QX50	I50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Malaysia	INFINITI QX50	I50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malaysia	INFINITI QX50	I50	2013.7-	CAN gateway	√	√	√	√		
Malaysia	INFINITI QX50	I50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malaysia	INFINITI QX50	I50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Malaysia	INFINITI QX50	I50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI QX50	I50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malaysia	INFINITI QX50	I50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Malaysia	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Malaysia	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Malaysia	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Malaysia	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Malaysia	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Malaysia	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Malaysia	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malaysia	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Malaysia	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Malaysia	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Malaysia	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Malaysia	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Malaysia	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Malaysia	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Malaysia	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Malaysia	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Malaysia	INFINITI QX50	J55	2018.5-	Shift						
Malaysia	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Malaysia	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malaysia	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Malaysia	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Malaysia	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Malaysia	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malaysia	INFINITI QX50	I55	2018.5-	CAN gateway	√	√	√	√		
Malaysia	INFINITI QX50	I55	2018.5-	Lane camera	√	√	√	√		
Malaysia	INFINITI QX50	I55	2018.5-	DAST 1	√	√	√	√		
Malaysia	INFINITI QX50	I55	2018.5-	Chassis control	√	√	√	√		

Malaysia	INFINITI QX50	I55	2018.5-	ANC						
Malaysia	INFINITI QX50	I55	2018.5-	E-HUD	√	√	√	√		
Malaysia	INFINITI QX50	I55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI QX50	I55	2018.5-	Telematics	√	√	√	√		SP0590、SP0591、SP0592
Malaysia	INFINITI QX50	I55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI QX50	I55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Malaysia	INFINITI QX50	I55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Malaysia	INFINITI QX50	I55	2018.5-	ICC/ADAS 2	√	√	√	√		
Malaysia	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894、AC0895、AC0896、AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509、SP0510
Malaysia	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Malaysia	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0869、AC0870、AC0871、AC0872、AC0873、AC0874、AC0875、AC0876、AC0877、AC0878、AC0879、AC0880、AC0881、AC0882、AC0883、AC0884、AC0885	SP0494、SP0495、SP0496、SP0497
Malaysia	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Malaysia	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Malaysia	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Malaysia	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350
Malaysia	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0225、AC0226、AC0229、AC0256、AC0282、AC0283、AC0284、AC0307、AC0333、AC0334、AC0335、AC0336、AC0337、AC0338、AC0339、AC0351、AC0352、AC0365、AC0366、AC0367、AC0369、AC0371、AC0372、AC0373、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0009、SP0016、SP0017、SP0018、SP0032、SP0033、SP0038、SP0039、SP0043、SP0045、SP0051、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0082、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0140、SP0143、SP0150、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0196、SP0197、SP0198、SP0199、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0225、SP0237、SP0238、SP0239
Malaysia	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460、AC0461、AC0462、AC0463、AC0464、AC0465、AC0466、AC0467、AC0468、AC0469、AC0470、AC0471、AC0472、AC0473、AC0474	SP0274
Malaysia	INFINITI QX70	S51	2013.5-	BCM				√	AC0613、AC0618、AC0663、AC0692、AC0702、AC0719	SP0372、SP0429
Malaysia	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533	SP0301、SP0313、SP0315
Malaysia	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133、AC1134、AC1135、AC1136、AC1137、AC1138、AC1139、AC1140、AC1141、AC1142	SP0614、SP0615、SP0616、SP0617、SP0618、SP0619、SP0620、SP0621
Malaysia	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034、AC1035、AC1036、AC1037、AC1038、AC1039	
Malaysia	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027、AC1028	
Malaysia	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Malaysia	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Malaysia	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Malaysia	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980	SP0561、SP0562
Malaysia	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Malaysia	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962、AC0963、AC0964、AC0966、AC0967、AC0968、AC0969、AC0970	SP0553、SP0554、SP0555、SP0556、SP0557、SP0558、SP0559
Malaysia	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Malaysia	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Malaysia	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983、AC0984、AC0985、AC0986、AC0987、AC0988、AC0989、AC0990	SP0563、SP0564、SP0565、SP0566、SP0567
Malaysia	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Malaysia	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971、AC0972、AC0973、AC0974、AC0975、AC0976、AC0977	SP0560
Malaysia	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malaysia	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014、AC1015、AC1016、AC1017、AC1018、AC1019、AC1020、AC1021	
Malaysia	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Malaysia	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590、SP0591、SP0592
Malaysia	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Malaysia	INFINITI QX80	Z62	2014.11-	Air pressure monitor	√	√	√	√	AC0894、AC0895、AC0896、AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509、SP0510
Malaysia	INFINITI QX80	Z62	2014.11-	Laser/radar	√	√	√	√	AC0994	
Malaysia	INFINITI QX80	Z62	2014.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malaysia	INFINITI QX80	Z62	2014.11-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0869、AC0870、AC0871、AC0872、AC0873、AC0874、AC0875、AC0876、AC0877、AC0878、AC0879、AC0880、AC0881、AC0882、AC0883、AC0884、AC0885	SP0494、SP0495、SP0496、SP0497
Malaysia	INFINITI QX80	Z62	2014.11-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Malaysia	INFINITI QX80	Z62	2014.11-	Air bag	√	√	√	√		
Malaysia	INFINITI QX80	Z62	2014.11-	EPS/DAST 3	√	√	√	√		SP0507
Malaysia	INFINITI QX80	Z62	2014.11-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350、SP0351
Malaysia	INFINITI QX80	Z62	2014.11-	Motor control	√	√	√	√		
Malaysia	INFINITI QX80	Z62	2014.11-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0225、AC0226、AC0229、AC0256、AC0282、AC0283、AC0284、AC0307、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0009、SP0016、SP0017、SP0018、SP0032、SP0033、SP0038、SP0039、SP0043、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0082、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0140、SP0143、SP0150、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Malaysia	INFINITI QX80	Z62	2014.11-	Transmission	√	√	√	√	AC0439、AC0460、AC0461、AC0462、AC0463、AC0464、AC0465、AC0466、AC0467、AC0468、AC0469、AC0470、AC0471、AC0472、AC0473、AC0474	SP0246、SP0270、SP0274、SP0276、SP0279、SP0281、SP0282、SP0283、SP0287、SP0289、SP0290、SP0292
Malaysia	INFINITI QX80	Z62	2014.11-	BCM				√	AC0613、AC0618、AC0663、AC0690、AC0692、AC0702	SP0372、SP0429、SP0471
Malaysia	INFINITI QX80	Z62	2014.11-	ABS	√	√	√	√	AC0498、AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533、AC0536	SP0300、SP0313、SP0315
Malaysia	INFINITI QX80	Z62	2014.11-	Multi AV	√	√	√	√		SP0503
Malaysia	INFINITI QX80	Z62	2014.11-	HVAC	√	√	√	√	AC0808、AC0809	SP0472、SP0473、SP0474、SP0475、SP0477、SP0478、SP0483、SP0484、SP0485、SP0486、SP0487、SP0488
Malaysia	INFINITI QX80	Z62	2014.11-	HV battery	√	√	√	√	AC1121	
Malaysia	INFINITI QX80	Z62	2014.11-	E-SUS	√	√	√	√	AC1031、AC1032、AC1033	SP0585、SP0586、SP0587
Malaysia	INFINITI QX80	Z62	2014.11-	Difference lock	√	√	√	√		
Malaysia	INFINITI QX80	Z62	2014.11-	4WAS(front)	√	√	√	√	AC1027、AC1028	
Malaysia	INFINITI QX80	Z62	2014.11-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Malaysia	INFINITI QX80	Z62	2014.11-	Auto back door	√	√	√	√		SP0611
Malaysia	INFINITI QX80	Z62	2014.11-	EV/HEV	√	√	√	√	AC1081、AC1084、AC1085、AC1086、AC1087、AC1088、AC1089	
Malaysia	INFINITI QX80	Z62	2014.11-	Occupant detection			√	√		SP0584
Malaysia	INFINITI QX80	Z62	2014.11-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980、AC0981、AC0982	SP0561、SP0562
Malaysia	INFINITI QX80	Z62	2014.11-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Malaysia	INFINITI QX80	Z62	2014.11-	Sonar	√	√	√	√	AC0962、AC0963、AC0964、AC0966、AC0967、AC0968、AC0969、AC0970	SP0553、SP0554、SP0555、SP0556、SP0557、SP0558、SP0559
Malaysia	INFINITI QX80	Z62	2014.11-	All mode AWD/4WD	√	√	√	√	AC0956	SP0544、SP0545、SP0546、SP0547、SP0548、SP0549
Malaysia	INFINITI QX80	Z62	2014.11-	Precrash seatbelt	√	√	√	√		SP0612
Malaysia	INFINITI QX80	Z62	2014.11-	AVM	√	√	√	√	AC0983、AC0984、AC0985、AC0986、AC0987、AC0988、AC0989、AC0990	SP0563、SP0564、SP0565、SP0566、SP0567
Malaysia	INFINITI QX80	Z62	2014.11-	Intelligent key	√	√	√	√	AC0903、AC0904、AC0905、AC0906、AC0907、AC0908、AC0909、AC0910、AC0911、AC0912、AC0913、AC0914、AC0915、AC0916、AC0917、AC0918、AC0919、AC0920、AC0921、AC0922、AC0923、AC0924、AC0925、AC0926、AC0927、AC0928、AC0929、AC0930、AC0931、AC0932、AC0933、AC0934、AC0935	SP0511、SP0512、SP0515、SP0516、SP0517、SP0518、SP0519、SP0520、SP0521、SP0522、SP0523、SP0524、SP0525、SP0526、SP0527、SP0528、SP0529、SP0530、SP0531、SP0532、SP0533、SP0534、SP0535、SP0536、SP0537、SP0538、SP0539、SP0540
Malaysia	INFINITI QX80	Z62	2014.11-	CAN gateway	√	√	√			
Malaysia	INFINITI QX80	Z62	2014.11-	Lane camera	√	√	√	√	AC0971、AC0972、AC0973、AC0974、AC0975、AC0976、AC0977	SP0560
Malaysia	INFINITI QX80	Z62	2014.11-	BSW/buzzer	√	√	√	√	AC1014、AC1015、AC1016、AC1017、AC1018、AC1019、AC1020、AC1021	
Malaysia	INFINITI QX80	Z62	2014.11-	Side radar left	√	√	√	√	AC1025	SP0582
Malaysia	INFINITI QX80	Z62	2014.11-	Telematics	√	√	√	√		SP0590、SP0591、SP0592
Malaysia	INFINITI QX80	Z62	2014.11-	HIGH BEAM ASSIST	√	√	√	√		
Malaysia	INFINITI QX80	Z62	2014.11-	Side radar right	√	√	√	√	AC1026	SP0583
Malaysia	INFINITI QX80	Z62	2014.11-	Vehicle data transmitter	√	√	√	√		
Malaysia	INFINITI QX80	Z62	2014.11-	6ch CAN GATEWAY	√	√	√	√		
Malaysia	INFINITI QX80	Z62	2014.11-	ICC/ADAS 2	√	√	√	√		
Malaysia	INFINITI QX80	Z62	2014.11-	Air levelizer	√	√	√	√	AC0991、AC0992、AC0993	
Malaysia	INFINITI QX80	Z62	2014.11-	VSP	√	√	√	√	AC1122、AC1123、AC1124、AC1125、AC1126	
Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006、AC1007、AC1008、AC1009、AC1010	SP0575、SP0576、SP0577、SP0578、SP0579、SP0580
Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350
Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0282、AC0283、AC0307、AC0333、AC0334、AC0335、AC0336、AC0337、AC0338、AC0339、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0009、SP0016、SP0017、SP0018、SP0032、SP0033、SP0043、SP0051、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0196、SP0197、SP0198、SP0200、SP0202、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270、SP0274
Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613、AC0618、AC0663、AC0692、AC0702、AC0719	SP0372、SP0429

Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Maldives	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Laser/radar	√	√	√	√		
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Air bag	√	√	√	√		
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	EPS/DAST 3	√	√	√	√		SP0507
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Motor control	√	√	√	√		
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Transmission	√	√	√	√		SP0276
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Pop up hood	√	√	√	√		
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Multi AV	√	√	√	√		SP0503
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	HV battery	√	√	√	√	AC1121	
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Occupant detection			√	√		SP0584
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	DAST 2	√	√	√	√		
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Precrash seatbelt	√	√	√	√		SP0612
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	CAN gateway	√	√	√			
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	DAST 1	√	√	√	√		
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	ANC	√	√	√	√	AC1024	
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Side radar left	√	√	√	√	AC1025	SP0582
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	HIGH BEAM ASSIST	√	√	√	√		
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Side radar right	√	√	√	√	AC1026	SP0583
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	Brake	√	√	√	√	AC1127	
Maldives	INFINITI Q50 HYBRID	HV37	2016.2-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Mali	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mali	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI EX35/EX37	I50	2011.1-	Air bag	√	√	√	√		
Mali	INFINITI EX35/EX37	I50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mali	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mali	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Mali	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mali	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Mali	INFINITI EX35/EX37	I50	2011.1-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mali	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mali	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mali	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mali	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Mali	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Mali	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Mali	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Mali	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Mali	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mali	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Mali	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mali	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mali	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Mali	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mali	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Mali	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Mali	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mali	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Mali	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Mali	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mali	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mali	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mali	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Mali	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Mali	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Mali	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mali	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Mali	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mali	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Mali	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mali	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Mali	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mali	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mali	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Mali	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mali	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mali	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Mali	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mali	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mali	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mali	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Mali	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mali	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Mali	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Mali	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Mali	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mali	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Mali	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mali	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mali	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Mali	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Mali	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Mali	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Mali	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mali	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	

Mali	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mali	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mali	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mali	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mali	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mali	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Mali	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Mali	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mali	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mali	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Mali	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Mali	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Mali	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Mali	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Mali	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Mali	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Mali	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Mali	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Mali	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Mali	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Mali	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Mali	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Mali	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Mali	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Mali	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Mali	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Mali	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Mali	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Mali	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Mali	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Mali	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Mali	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Mali	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Mali	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Mali	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mali	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Mali	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mali	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Mali	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Mali	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mali	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mali	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Mali	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mali	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Mali	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Mali	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mali	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mali	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Mali	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Mali	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mali	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mali	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Mali	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Mali	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Mali	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mali	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Mali	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mali	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mali	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Mali	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Mali	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Mali	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mali	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Mali	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Mali	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Mali	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mali	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Mali	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Mali	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		

XTOOL

Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Mali	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Mali	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mali	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Mali	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mali	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Mali	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Mali	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mali	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mali	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Mali	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mali	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mali	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Mali	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mali	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mali	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Mali	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Mali	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mali	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mali	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Mali	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Mali	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Mali	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Mali	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Mali	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Mali	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mali	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Mali	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Mali	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Mali	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Mali	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Mali	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mali	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Mali	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Mali	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Mali	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Mali	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		

Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mali	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mali	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mali	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Mali	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mali	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Mali	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Mali	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mali	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mali	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Mali	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mali	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mali	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Mali	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mali	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mali	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mali	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mali	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Mali	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Mali	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mali	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mali	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Mali	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Mali	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mali	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Mali	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Mali	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mali	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mali	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Mali	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Mali	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Mali	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Mali	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mali	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mali	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Mali	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Mali	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mali	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Mali	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Mali	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Mali	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mali	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Mali	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mali	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mali	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mali	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Mali	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mali	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Mali	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mali	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Mali	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mali	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Mali	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Mali	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mali	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mali	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Mali	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mali	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Mali	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mali	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mali	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mali	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Mali	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Mali	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mali	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Mali	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mali	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Mali	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Mali	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mali	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Mali	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Mali	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	

Mali	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mali	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Mali	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Mali	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mali	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mali	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Mali	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mali	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Mali	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Mali	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mali	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mali	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Mali	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Mali	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mali	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mali	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mali	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Mali	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Mali	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mali	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Mali	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mali	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mali	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mali	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Mali	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Mali	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mali	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Mali	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Mali	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mali	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Mali	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mali	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mali	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mali	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Mali	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Mali	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mali	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Mali	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Mali	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mali	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Mali	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Mali	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Mali	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Mali	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mali	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Mali	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Mali	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Mali	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mali	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mali	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Mali	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Mali	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Mali	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Mali	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mali	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mali	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Mali	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mali	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Mali	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Mali	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Mali	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Mali	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Malta	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Malta	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malta	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Malta	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malta	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Malta	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Malta	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malta	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Malta	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malta	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malta	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malta	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Malta	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Malta	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Malta	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Malta	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Malta	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Malta	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Malta	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Malta	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Malta	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239

Malta	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Malta	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Malta	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malta	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Malta	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Malta	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Malta	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Malta	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Malta	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malta	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Malta	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Malta	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malta	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malta	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Malta	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Malta	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Malta	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	

XTOOL

Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Malta	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malta	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Malta	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Malta	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malta	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malta	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Malta	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malta	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malta	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Malta	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malta	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malta	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malta	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Malta	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Malta	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Malta	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malta	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Malta	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malta	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malta	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Malta	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malta	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malta	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Malta	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malta	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malta	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malta	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Malta	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Malta	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Malta	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Malta	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Malta	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Malta	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Malta	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Malta	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Malta	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malta	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Malta	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Malta	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Malta	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Malta	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Malta	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Malta	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Malta	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Malta	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Malta	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Malta	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Malta	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Malta	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		
Malta	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malta	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malta	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Malta	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Malta	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Malta	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Malta	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Malta	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malta	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Malta	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Malta	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malta	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malta	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malta	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Malta	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Malta	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Malta	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Malta	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Malta	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	

Malta	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124,AC1125,AC1126	
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Malta	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Malta	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Malta	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Malta	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Malta	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Malta	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Malta	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Malta	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Malta	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Malta	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Malta	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Malta	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Malta	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Malta	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Malta	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Malta	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Malta	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Malta	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Malta	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Malta	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Malta	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Malta	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Malta	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Malta	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		

Malta	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Malta	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Malta	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Malta	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Malta	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Malta	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Malta	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Malta	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Malta	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Malta	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Malta	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Malta	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Malta	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Malta	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Malta	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Malta	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Malta	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malta	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Malta	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malta	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Malta	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Malta	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malta	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Malta	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malta	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Malta	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Malta	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Malta	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Malta	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malta	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Malta	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malta	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malta	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Malta	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Malta	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malta	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malta	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Malta	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Malta	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Malta	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Malta	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malta	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Malta	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Malta	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Malta	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Malta	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Malta	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Malta	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Malta	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Malta	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Malta	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Malta	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malta	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Malta	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Malta	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Malta	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Malta	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Malta	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Malta	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Malta	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Malta	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Malta	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Malta	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Malta	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malta	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Malta	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malta	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Malta	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Malta	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malta	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malta	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Malta	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Malta	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Malta	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Malta	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malta	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Malta	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Malta	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malta	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malta	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Malta	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Malta	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Malta	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Malta	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Malta	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Malta	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malta	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Malta	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Malta	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Malta	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Malta	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Malta	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malta	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Malta	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Malta	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Malta	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Malta	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Malta	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malta	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malta	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Malta	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Malta	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malta	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Malta	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Malta	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malta	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malta	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Malta	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malta	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malta	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malta	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Malta	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Malta	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malta	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Malta	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Malta	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malta	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Malta	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Malta	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malta	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malta	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Malta	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Malta	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Malta	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Malta	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malta	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malta	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malta	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Malta	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Malta	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malta	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malta	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Malta	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Malta	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Malta	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malta	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Malta	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Malta	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Malta	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malta	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Malta	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Malta	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malta	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Malta	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Malta	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Malta	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Malta	INFINITI Q70	Y51	2013.9-	PSCM	√	√	√	√	AC1109	
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Malta	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Malta	INFINITI QX50	I50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Malta	INFINITI QX50	I50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Malta	INFINITI QX50	I50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malta	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Malta	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Malta	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malta	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malta	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Malta	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malta	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Malta	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malta	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malta	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malta	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Malta	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Malta	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Malta	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malta	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Malta	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Malta	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malta	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Malta	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Malta	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Malta	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Malta	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Malta	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Malta	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Malta	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Malta	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Malta	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Malta	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Malta	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Malta	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Malta	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544

Malta	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Malta	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Malta	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Malta	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Malta	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Malta	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Malta	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Malta	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Malta	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Malta	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Malta	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Malta	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Malta	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Malta	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Malta	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Malta	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Malta	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Malta	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Malta	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Malta	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Malta	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Malta	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Malta	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Malta	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Malta	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Malta	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Malta	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Malta	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Malta	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Malta	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Malta	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Malta	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Malta	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Malta	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Malta	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Malta	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Martiniqu e	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Martiniqu e	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Martiniqu e	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Martiniqu e	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Martiniqu	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Martiniqu	INFINITI EX35/EX30D	I50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Martiniqu	INFINITI EX35/EX30D	I50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Martiniqu	INFINITI EX35/EX30D	I50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Martiniqu	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu e	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Martiniqu	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Martiniqu	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Martiniqu e	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Martiniqu e	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Martiniqu	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Martiniqu e	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Martiniqu	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Martiniqu	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Martiniqu e	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Martiniqu	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martiniqu e	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Martiniqu	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Martiniqu	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Martiniqu e	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Martiniqu e	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Martiniqu	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Martiniqu e	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Martiniqu	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Martiniqu e	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Martiniqu	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Martiniqu	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Martiniqu e	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martiniqu	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Martiniqu e	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Martiniqu	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Martiniqu	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Martiniqu e	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Martiniqu e	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Martiniqu	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Martiniqu e	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Martiniqu	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Martiniqu	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Martiniqu	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Martiniqu e	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Martiniqu	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Martiniqu	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Martiniqu	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Martiniqu	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		

Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Martiniqu e	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Martiniqu e	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Martiniqu e	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Martiniqu e	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Martiniqu	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martiniqu	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Martiniqu	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Martiniqu e	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Martiniqu	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Martiniqu	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Martiniqu e	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Martiniqu e	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Martiniqu	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Martiniqu e	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Martiniqu	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Martiniqu e	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Martiniqu	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Martiniqu	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Martiniqu	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Martiniqu e	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Martiniqu	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martiniqu	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Martiniqu	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Martiniqu	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Martiniqu	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu e	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Martiniqu	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Martiniqu	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Martiniqu	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Martiniqu	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Martiniqu e	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Martiniqu e	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Martiniqu	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Martiniqu	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Martiniqu	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Martiniqu	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Martiniqu	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Martiniqu e	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Martiniqu	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Martiniqu	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Martiniqu	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Martiniqu	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Martiniqu	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Martiniqu	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Martiniqu	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Martiniqu	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Martiniqu	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Martiniqu	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Martiniqu	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Martiniqu	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503

Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Martiniqu e	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Martiniqu	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Martiniqu	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Martiniqu e	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Martiniqu	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Martiniqu e	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Martiniqu	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Martiniqu	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Martiniqu	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Martiniqu	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Martiniqu e	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Martiniqu e	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Martiniqu e	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Martiniqu e	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Martiniqu e	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Martiniqu e	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Martiniqu	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Martiniqu	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Martiniqu e	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Martiniqu	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Martiniqu	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Martiniqu e	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Martiniqu	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Martiniqu e	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Martiniqu	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Martiniqu	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Martiniqu e	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Martiniqu e	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Martiniqu	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Martiniqu e	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Martiniqu e	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Martiniqu e	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Martiniqu e	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Martiniqu e	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Martiniqu e	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Martiniqu e	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Martiniqu e	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Martiniqu e	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		

Martiniqu e	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Martiniqu e	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Martiniqu e	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Martiniqu e	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Martiniqu	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Martiniqu	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Martiniqu	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Martiniqu	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu e	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Martiniqu	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Martiniqu	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Martiniqu	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Martiniqu	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Martiniqu e	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Martiniqu	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Martiniqu	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Martiniqu e	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Martiniqu	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Martiniqu	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Martiniqu e	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Martiniqu	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Martiniqu	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Martiniqu	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Martiniqu e	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Martiniqu	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Martiniqu	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Martiniqu	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Martiniqu	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Martiniqu	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Martiniqu	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Martiniqu	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Martiniqu	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Martiniqu	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Martiniqu	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Martiniqu	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Martiniqu	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martiniqu	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Martiniqu	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Martiniqu e	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Martiniqu	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Martiniqu	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Martiniqu	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Martiniqu	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Martiniqu	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Martiniqu	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Martiniqu	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Martiniqu	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Martiniqu	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Martiniqu	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Martiniqu	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Martiniqu	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Martiniqu	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Martiniqu	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu e	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Martiniqu e	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Martiniqu e	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Martiniqu e	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Martiniqu e	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Martiniqu e	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	

Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Martiniqu	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu e	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Martiniqu e	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Martiniqu e	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Martiniqu e	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Martiniqu e	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Martiniqu e	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Martiniqu	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Martiniqu	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Martiniqu	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Martiniqu	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu e	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Martiniqu	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Martiniqu	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Martiniqu	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Martiniqu e	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Martiniqu	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Martiniqu	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Martiniqu e	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Martiniqu	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Martiniqu	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Martiniqu e	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Martiniqu e	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Martiniqu	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Martiniqu	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Martiniqu	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Martiniqu	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Martiniqu	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Martiniqu	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Martiniqu	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Martiniqu	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Martiniqu	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Martiniqu	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martiniqu	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Martiniqu	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Martiniqu	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Martiniqu	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Martiniqu	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Martiniqu	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Martiniqu	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Martiniqu	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Martiniqu	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Martiniqu	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Martiniqu	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Martiniqu	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Martiniqu e	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Martiniqu e	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Martiniqu e	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Martiniqu e	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Martiniqu	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martiniqu	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Martiniqu	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Martiniqu	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu e	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Martiniqu	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Martiniqu	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Martiniqu	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Martiniqu e	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Martiniqu e	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Martiniqu	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Martiniqu e	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Martiniqu	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Martiniqu	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Martiniqu e	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Martiniqu	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Martiniqu	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Martiniqu e	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Martiniqu	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Martiniqu	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Martiniqu	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Martiniqu	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Martiniqu	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Martiniqu	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Martiniqu	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Martiniqu	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Martiniqu	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martiniqu	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Martiniqu	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Martiniqu	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Martiniqu	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Martiniqu	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Martiniqu	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Martiniqu	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Martiniqu	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Martiniqu	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Martiniqu	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Martiniqu	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Martiniqu	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Martiniqu	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martiniqu e	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Martiniqu	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martiniqu	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Martiniqu	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Martiniqu	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Martiniqu	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		

Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Martinique	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Martinique	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Martinique	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Martinique	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martinique	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Martinique	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martinique	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Martinique	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Martinique	INFINITI QX50	I50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Martinique	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Martinique	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Martinique	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Martinique	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Martinique	INFINITI QX50	I50	2013.9-	Multi AV	√	√	√	√		SP0503
Martinique	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martinique	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Martinique	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Martinique	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Martinique	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Martinique	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Martinique	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Martinique	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Martinique	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Martinique	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Martinique	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Martinique	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Martinique	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Martinique	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Martinique	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Martinique	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Martinique	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Martinique	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Martinique	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Martinique	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Martinique	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Martinique	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Martinique	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Martinique	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martinique	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Martinique	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Martinique	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Martinique	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Martinique	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Martinique	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Martinique	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Martinique	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Martinique	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Martinique	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Martinique	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Martinique	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Martinique	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Martinique	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Martinique	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Martinique	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Martinique	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Martinique	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621

Martiniqu	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Martiniqu	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Martiniqu	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Martiniqu e	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Martiniqu	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Martiniqu	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Martiniqu	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Martiniqu	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Martiniqu	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Martiniqu	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Martiniqu	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Martiniqu	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Martiniqu	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Martiniqu	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Martiniqu	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Martiniqu	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Martiniqu	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Martiniqu	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Martiniqu	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Martiniqu	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
MauritaNi	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNi	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
MauritaNi	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
MauritaNi	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
MauritaNi	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
MauritaNi a	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
MauritaNi	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
MauritaNi	INFINITI EX35/EX37	I50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
MauritaNi a	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
MauritaNi	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
MauritaNi a	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
MauritaNi	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
MauritaNi	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
MauritaNi	INFINITI EX35/EX37	I50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
MauritaNi	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
MauritaNi	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
MauritaNi	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
MauritaNi	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
MauritaNi	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
MauritaNi a	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
MauritaNi a	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
MauritaNi	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
MauritaNi a	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
MauritaNi a	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNi a	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
MauritaNi a	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
MauritaNi a	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

MauritaNia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
MauritaNia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
MauritaNia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
MauritaNia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
MauritaNia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
MauritaNia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
MauritaNia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
MauritaNia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
MauritaNia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
MauritaNia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
MauritaNia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
MauritaNia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
MauritaNia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
MauritaNia	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
MauritaNia	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
MauritaNia	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
MauritaNi	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
MauritaNia	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
MauritaNi	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
MauritaNia	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
MauritaNia	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
MauritaNi	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
MauritaNia	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
MauritaNia	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
MauritaNi	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
MauritaNi	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
MauritaNia	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
MauritaNi	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
MauritaNi	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
MauritaNi	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
MauritaNi	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
MauritaNi	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
MauritaNi	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
MauritaNia	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
MauritaNi	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
MauritaNia	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
MauritaNi	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
MauritaNi	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
MauritaNi	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
MauritaNi	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
MauritaNia	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
MauritaNia	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
MauritaNia	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		

MauritaNia	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
MauritaNia	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
MauritaNia	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
MauritaNi	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
MauritaNi	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
MauritaNia	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
MauritaNi	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
MauritaNi	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
MauritaNia	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
MauritaNi	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
MauritaNia	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
MauritaNi	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
MauritaNi	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
MauritaNia	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
MauritaNia	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
MauritaNi	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
MauritaNi	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
MauritaNi	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
MauritaNi	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNia	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
MauritaNi	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
MauritaNi	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
MauritaNi	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
MauritaNi	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
MauritaNia	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
MauritaNi	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
MauritaNi	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
MauritaNi	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
MauritaNi	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
MauritaNi	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
MauritaNia	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
MauritaNi	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
MauritaNi	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
MauritaNi	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
MauritaNi	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
MauritaNi	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
MauritaNi	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
MauritaNi	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
MauritaNi	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
MauritaNi	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
MauritaNi	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
MauritaNi	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
MauritaNi	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
MauritaNi	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
MauritaNi	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
MauritaNi	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
MauritaNia	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
MauritaNi	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
MauritaNi	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
MauritaNi	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
MauritaNi	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
MauritaNi	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
MauritaNi	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
MauritaNi	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
MauritaNi	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNia	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
MauritaNia	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
MauritaNia	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
MauritaNia	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
MauritaNi	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	

MauritaNia	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
MauritaNia	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
MauritaNia	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
MauritaNia	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
MauritaNia	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNia	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
MauritaNia	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
MauritaNia	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
MauritaNia	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
MauritaNia	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
MauritaNia	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
MauritaNia	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
MauritaNia	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
MauritaNia	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
MauritaNia	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
MauritaNia	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
MauritaNia	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
MauritaNia	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
MauritaNia	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
MauritaNia	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
MauritaNia	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
MauritaNia	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
MauritaNia	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966.AC0967.AC0968	SP0557
MauritaNia	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
MauritaNia	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
MauritaNia	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
MauritaNia	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
MauritaNia	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
MauritaNia	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
MauritaNia	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
MauritaNia	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
MauritaNia	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
MauritaNia	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
MauritaNia	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
MauritaNia	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
MauritaNia	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
MauritaNia	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
MauritaNia	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
MauritaNia	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
MauritaNia	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
MauritaNia	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
MauritaNia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
MauritaNia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543

MauritaNi	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
MauritaNi	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
MauritaNi	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
MauritaNi	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
MauritaNi	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
MauritaNi	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
MauritaNi	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
MauritaNi	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
MauritaNi	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
MauritaNi	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
MauritaNi	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
MauritaNi	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
MauritaNi	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
MauritaNia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, , AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
MauritaNi	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
MauritaNi	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
MauritaNia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
MauritaNi	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
MauritaNi	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
MauritaNia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
MauritaNi	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
MauritaNi	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
MauritaNi	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
MauritaNi	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
MauritaNi	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
MauritaNi	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
MauritaNi	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
MauritaNi	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
MauritaNi	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
MauritaNi	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
MauritaNi	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
MauritaNi	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
MauritaNi	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
MauritaNi	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
MauritaNi	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
MauritaNi	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
MauritaNi	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
MauritaNi	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
MauritaNi	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNia	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
MauritaNi	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
MauritaNi	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
MauritaNi	INFINITI QX50	I50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
MauritaNi	INFINITI QX50	I50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
MauritaNia	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, , AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
MauritaNi	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
MauritaNi	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
MauritaNia	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
MauritaNi	INFINITI QX50	I50	2013.8-	Multi AV	√	√	√	√		SP0503
MauritaNia	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
MauritaNi	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
MauritaNi	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
MauritaNi	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
MauritaNi	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
MauritaNi	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
MauritaNi	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
MauritaNi	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
MauritaNi	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
MauritaNi	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
MauritaNi	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
MauritaNi	INFINITI QX50	I50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
MauritaNi	INFINITI QX50	I50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
MauritaNi	INFINITI QX50	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
MauritaNi	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
MauritaNi	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNia	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
MauritaNi	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
MauritaNi	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
MauritaNi	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
MauritaNi	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
MauritaNia	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, , AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
MauritaNia	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
MauritaNi	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
MauritaNi	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
MauritaNi	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
MauritaNi	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
MauritaNi	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
MauritaNi	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
MauritaNia	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
MauritaNi	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
MauritaNi	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
MauritaNi	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
MauritaNi	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
MauritaNi	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
MauritaNi	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
MauritaNi	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
MauritaNi	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
MauritaNi	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
MauritaNi	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
MauritaNi	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
MauritaNi	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
MauritaNi	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
MauritaNi	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
MauritaNi	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
MauritaNi	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583

MauritaNi	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
MauritaNi	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
MauritaNi	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
MauritaNi	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
MauritaNia	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
MauritaNi	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
MauritaNi	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
MauritaNi	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
MauritaNia	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
MauritaNia	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
MauritaNi	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
MauritaNi	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
MauritaNi	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
MauritaNia	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
MauritaNi	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
MauritaNi	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
MauritaNia	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
MauritaNi	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
MauritaNi	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
MauritaNi	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
MauritaNi	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
MauritaNi	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
MauritaNi	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
MauritaNi	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
MauritaNi	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
MauritaNi	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
MauritaNi	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
MauritaNi	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
MauritaNi	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
MauritaNi	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
MauritaNi	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
MauritaNi	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
MauritaNi	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
MauritaNi	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
MauritaNi	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Mauritius	INFINITI EX35/EX37	I50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI EX35/EX37	I50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mauritius	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Mauritius	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mauritius	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mauritius	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Mauritius	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mauritius	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Mauritius	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mauritius	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mauritius	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mauritius	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mauritius	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Mauritius	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Mauritius	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Mauritius	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mauritius	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Mauritius	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mauritius	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mauritius	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Mauritius	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Mauritius	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mauritius	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Mauritius	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mauritius	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Mauritius	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mauritius	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Mauritius	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Mauritius	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Mauritius	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mauritius	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Mauritius	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mauritius	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mauritius	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Mauritius	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Mauritius	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Mauritius	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Mauritius	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mauritius	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mauritius	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mauritius	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mauritius	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mauritius	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mauritius	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mauritius	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Mauritius	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Mauritius	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mauritius	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mauritius	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Mauritius	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Mauritius	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Mauritius	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344

Mauritius	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Mauritius	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Mauritius	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Mauritius	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Mauritius	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Mauritius	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Mauritius	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Mauritius	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Mauritius	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Mauritius	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Mauritius	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Mauritius	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Mauritius	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Mauritius	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Mauritius	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Mauritius	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Mauritius	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Mauritius	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Mauritius	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Mauritius	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Mauritius	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Mauritius	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mauritius	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Mauritius	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mauritius	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Mauritius	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Mauritius	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mauritius	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mauritius	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Mauritius	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mauritius	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Mauritius	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Mauritius	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mauritius	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mauritius	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Mauritius	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Mauritius	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mauritius	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mauritius	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Mauritius	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Mauritius	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Mauritius	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mauritius	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Mauritius	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mauritius	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mauritius	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Mauritius	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Mauritius	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Mauritius	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mauritius	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Mauritius	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Mauritius	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Mauritius	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mauritius	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Mauritius	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Mauritius	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		

Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Mauritius	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Mauritius	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mauritius	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Mauritius	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mauritius	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Mauritius	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Mauritius	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mauritius	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mauritius	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Mauritius	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mauritius	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mauritius	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Mauritius	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mauritius	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mauritius	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Mauritius	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Mauritius	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mauritius	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mauritius	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Mauritius	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Mauritius	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Mauritius	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Mauritius	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Mauritius	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Mauritius	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mauritius	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Mauritius	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Mauritius	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Mauritius	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Mauritius	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Mauritius	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mauritius	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Mauritius	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Mauritius	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Mauritius	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Mauritius	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mauritius	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mauritius	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mauritius	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Mauritius	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Mauritius	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mauritius	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Mauritius	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Mauritius	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mauritius	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mauritius	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Mauritius	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Mauritius	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Mauritius	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Mauritius	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mauritius	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mauritius	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Mauritius	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Mauritius	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mauritius	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Mauritius	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Mauritius	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Mauritius	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mauritius	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Mauritius	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mauritius	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mauritius	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mauritius	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Mauritius	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mauritius	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Mauritius	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mauritius	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Mauritius	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mauritius	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Mauritius	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Mauritius	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mauritius	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mauritius	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Mauritius	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mauritius	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Mauritius	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mauritius	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mauritius	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mauritius	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Mauritius	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Mauritius	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mauritius	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Mauritius	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mauritius	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Mauritius	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Mauritius	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mauritius	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Mauritius	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Mauritius	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Mauritius	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mauritius	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Mauritius	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Mauritius	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Mauritius	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mauritius	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Mauritius	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mauritius	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Mauritius	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Mauritius	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mauritius	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mauritius	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Mauritius	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Mauritius	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mauritius	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mauritius	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mauritius	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Mauritius	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Mauritius	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mauritius	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Mauritius	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mauritius	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mauritius	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mauritius	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Mauritius	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Mauritius	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mauritius	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Mauritius	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Mauritius	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mauritius	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Mauritius	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mauritius	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mauritius	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mauritius	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Mauritius	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Mauritius	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mauritius	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Mauritius	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Mauritius	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mauritius	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Mauritius	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Mauritius	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Mauritius	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Mauritius	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mauritius	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Mauritius	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Mauritius	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Mauritius	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mauritius	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mauritius	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Mauritius	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Mauritius	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Mauritius	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Mauritius	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mauritius	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mauritius	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Mauritius	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mauritius	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Mauritius	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Mauritius	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Mauritius	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Mauritius	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Mexico	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Mexico	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Mexico	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Mexico	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Mexico	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mexico	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Mexico	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mexico	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mexico	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mexico	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mexico	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Mexico	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Mexico	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Mexico	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Mexico	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mexico	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mexico	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Mexico	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mexico	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Mexico	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Mexico	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mexico	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Mexico	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Mexico	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mexico	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mexico	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Mexico	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	

Mexico	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Mexico	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Mexico	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Mexico	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mexico	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Mexico	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Mexico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mexico	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Mexico	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Mexico	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mexico	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Mexico	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mexico	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mexico	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Mexico	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mexico	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mexico	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mexico	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mexico	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Mexico	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mexico	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Mexico	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mexico	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Mexico	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Mexico	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Mexico	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Mexico	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mexico	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mexico	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Mexico	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Mexico	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mexico	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mexico	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Mexico	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Mexico	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mexico	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Mexico	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Mexico	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Mexico	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mexico	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Mexico	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mexico	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mexico	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Mexico	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Mexico	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Mexico	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Mexico	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mexico	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mexico	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mexico	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mexico	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mexico	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mexico	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mexico	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Mexico	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Mexico	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mexico	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mexico	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Mexico	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Mexico	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mexico	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Mexico	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Mexico	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Mexico	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Mexico	INFINITI Q45	F50	2001.8-	Motor control						
Mexico	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Mexico	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Mexico	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Mexico	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Mexico	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Mexico	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Mexico	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Mexico	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Mexico	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mexico	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Mexico	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Mexico	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Mexico	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mexico	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Mexico	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Mexico	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Mexico	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Mexico	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Mexico	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Mexico	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Mexico	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Mexico	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Mexico	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Mexico	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Mexico	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Mexico	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mexico	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Mexico	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mexico	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Mexico	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Mexico	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Mexico	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√	AC0247, AC0265, AC0270, AC0274	
Mexico	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mexico	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mexico	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Mexico	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mexico	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mexico	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mexico	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Mexico	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980. AC0981. AC0982	SP0561. SP0562
Mexico	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Mexico	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mexico	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Mexico	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Mexico	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Mexico	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Mexico	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Mexico	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mexico	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mexico	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Mexico	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Mexico	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Mexico	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Mexico	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Mexico	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mexico	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Mexico	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Mexico	INFINITI Q50	V37	2013.9-	Brake	√	√	√	√	AC1127	
Mexico	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Mexico	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Mexico	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Mexico	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Mexico	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Mexico	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Mexico	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Laser/radar	√	√	√	√	AC0994	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Air bag	√	√	√	√		
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Motor control	√	√	√	√		
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Pop up hood	√	√	√	√		
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	HV battery	√	√	√	√	AC1121	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	EV/HEV	√	√	√	√	AC1084. AC1085. AC1086. AC1087. AC1088. AC1089. AC1106	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Occupant detection			√	√		SP0584
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980. AC0981. AC0982	SP0561. SP0562
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	DAST 2	√	√	√	√		
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	CAN gateway	√	√	√			
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	DAST 1	√	√	√	√		
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	ANC	√	√	√	√	AC1024	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	Brake	√	√	√	√	AC1127	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	6ch CAN GATEWAY	√	√	√	√		
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	FSCM	√	√	√	√	AC1109	
Mexico	INFINITI Q50 HYBRID	HV37	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315

Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Mexico	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Mexico	INFINITI Q60	CV37	2016.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mexico	INFINITI Q60	CV37	2016.8-	Laser/radar	√	√	√	√	AC0994	
Mexico	INFINITI Q60	CV37	2016.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI Q60	CV37	2016.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mexico	INFINITI Q60	CV37	2016.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI Q60	CV37	2016.8-	Air bag	√	√	√	√		
Mexico	INFINITI Q60	CV37	2016.8-	EPS/DAST 3	√	√	√	√		
Mexico	INFINITI Q60	CV37	2016.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mexico	INFINITI Q60	CV37	2016.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI Q60	CV37	2016.8-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Mexico	INFINITI Q60	CV37	2016.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mexico	INFINITI Q60	CV37	2016.8-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mexico	INFINITI Q60	CV37	2016.8-	Pop up hood	√	√	√	√		
Mexico	INFINITI Q60	CV37	2016.8-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI Q60	CV37	2016.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mexico	INFINITI Q60	CV37	2016.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI Q60	CV37	2016.8-	Occupant detection			√	√		SP0584
Mexico	INFINITI Q60	CV37	2016.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Mexico	INFINITI Q60	CV37	2016.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mexico	INFINITI Q60	CV37	2016.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mexico	INFINITI Q60	CV37	2016.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Mexico	INFINITI Q60	CV37	2016.8-	DAST 2	√	√	√	√		
Mexico	INFINITI Q60	CV37	2016.8-	Precrash seatbelt	√	√	√	√		SP0612
Mexico	INFINITI Q60	CV37	2016.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI Q60	CV37	2016.8-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Mexico	INFINITI Q60	CV37	2016.8-	CAN gateway	√	√	√			
Mexico	INFINITI Q60	CV37	2016.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mexico	INFINITI Q60	CV37	2016.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mexico	INFINITI Q60	CV37	2016.8-	DAST 1	√	√	√	√		
Mexico	INFINITI Q60	CV37	2016.8-	Chassis control	√	√	√	√		
Mexico	INFINITI Q60	CV37	2016.8-	ANC	√	√	√	√		
Mexico	INFINITI Q60	CV37	2016.8-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI Q60	CV37	2016.8-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Mexico	INFINITI Q60	CV37	2016.8-	HIGH BEAM ASSIST	√	√	√	√		
Mexico	INFINITI Q60	CV37	2016.8-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI Q60	CV37	2016.8-	Lane camera 2	√	√	√	√		
Mexico	INFINITI Q60	CV37	2016.8-	6ch CAN GATEWAY	√	√	√	√		
Mexico	INFINITI Q60	CV37	2016.8-	ICC/ADAS 2	√	√	√	√		
Mexico	INFINITI Q60	CV37	2016.8-	FSCM	√	√	√	√	AC1109	
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	Laser/radar	√	√	√	√	AC0994	
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	Air bag	√	√	√	√		
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	Transmission	√	√	√	√		SP0274
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	Pop up hood	√	√	√	√		
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	Precrash seatbelt	√	√	√	√		
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI Q60 COUPE	CV36	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mexico	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Mexico	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Mexico	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mexico	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Mexico	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Mexico	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Mexico	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mexico	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Mexico	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Mexico	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Mexico	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Mexico	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mexico	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mexico	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Mexico	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Mexico	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mexico	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mexico	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Mexico	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Mexico	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√			
Mexico	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mexico	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mexico	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mexico	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Mexico	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Mexico	INFINITI QX30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	Air bag	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	EPS/DAST 3	√	√	√			
Mexico	INFINITI QX30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Mexico	INFINITI QX30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI QX30	H15	2016.4-	EHS/PKB	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	Transmission	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Mexico	INFINITI QX30	H15	2016.4-	ABS	√	√	√	√		SP0308
Mexico	INFINITI QX30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Mexico	INFINITI QX30	H15	2016.4-	HVAC	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	Auto drive position	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	Shift	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	AVM	√	√		√		
Mexico	INFINITI QX30	H15	2016.4-	Intelligent key	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	CAN gateway	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	ANC	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	Telematics	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	FSCM	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	Siren control unit	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Mexico	INFINITI QX30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Mexico	INFINITI QX30	H15	2016.4-	Universal Garage Door Opener	√			√		
Mexico	INFINITI QX30	H15	2016.4-	Upper control panel cont unit	√					
Mexico	INFINITI QX30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Mexico	INFINITI QX30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Mexico	INFINITI QX30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Mexico	INFINITI QX30	H15	2016.4-	EC Mirror Compass	√					
Mexico	INFINITI QX30	H15	2016.4-	Intelligent Battery Sensor	√					
Mexico	INFINITI QX30	H15	2016.4-	Alarm siren	√			√		
Mexico	INFINITI QX30	H15	2016.4-	Radar sensor	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	Steering column cont module	√	√	√			
Mexico	INFINITI QX30	H15	2016.4-	ICC sensor	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	H/L control module LH	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	Side radar LH	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	LED H/L control module LH	√			√		
Mexico	INFINITI QX30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Mexico	INFINITI QX30	H15	2016.4-	Parking assist	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	Occupant Classification Unit	√			√		
Mexico	INFINITI QX30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	H/L control module RH	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	Front camera unit	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	Side radar RH	√	√	√	√		
Mexico	INFINITI QX30	H15	2016.4-	LED H/L control module RH	√			√		
Mexico	INFINITI QX50	J55	2018.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Mexico	INFINITI QX50	J55	2018.4-	Laser/radar	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mexico	INFINITI QX50	J55	2018.4-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Mexico	INFINITI QX50	J55	2018.4-	Air bag	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	EPS/DAST 3	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	Meter/M&A	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI QX50	J55	2018.4-	EHS/PKB	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Mexico	INFINITI QX50	J55	2018.4-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Mexico	INFINITI QX50	J55	2018.4-	ABS	√	√	√	√		SP0313, SP0315
Mexico	INFINITI QX50	J55	2018.4-	Total illum C/U	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI QX50	I55	2018.4-	HVAC	√	√	√	√		

Mexico	INFINITI QX50	J55	2018.4-	Auto drive position	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	Auto back door	√	√	√	√		SP0611
Mexico	INFINITI QX50	J55	2018.4-	Occupant detection			√	√		SP0584
Mexico	INFINITI QX50	J55	2018.4-	Shift						
Mexico	INFINITI QX50	J55	2018.4-	Adaptive light	√	√	√	√		SP0562
Mexico	INFINITI QX50	J55	2018.4-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Mexico	INFINITI QX50	J55	2018.4-	Sonar	√	√	√	√	AC0968	
Mexico	INFINITI QX50	J55	2018.4-	All mode AWD/4WD	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	DAST 2	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI QX50	J55	2018.4-	CAN gateway	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	Lane camera	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	DAST 1	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	Chassis control	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	ANC						
Mexico	INFINITI QX50	J55	2018.4-	E-HUD	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	Side radar left	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mexico	INFINITI QX50	J55	2018.4-	Side radar right	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	6ch CAN GATEWAY	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	3ch CAN GATEWAY	√	√	√	√		
Mexico	INFINITI QX50	J55	2018.4-	ICC/ADAS 2	√	√	√	√		
Mexico	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Mexico	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Mexico	INFINITI QX56	Z62	2011.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mexico	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Mexico	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Mexico	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Mexico	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Mexico	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Mexico	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Mexico	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Mexico	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Mexico	INFINITI QX56	Z62	2011.8-	Difference lock	√	√	√	√		
Mexico	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Mexico	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Mexico	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mexico	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mexico	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Mexico	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Mexico	INFINITI QX56	Z62	2011.8-	Precrash seatbelt	√	√	√	√		SP0612
Mexico	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI QX56	Z62	2011.8-	SVT	√	√	√	√		SP0595
Mexico	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Mexico	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mexico	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mexico	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mexico	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Mexico	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mexico	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Mexico	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Mexico	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mexico	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Mexico	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Mexico	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mexico	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mexico	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Mexico	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Mexico	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Mexico	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Mexico	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Mexico	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mexico	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mexico	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Mexico	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Mexico	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Mexico	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mexico	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mexico	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Mexico	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590. SP0591. SP0592
Mexico	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Mexico	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Mexico	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Mexico	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348. SP0349. SP0350. SP0351
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503

Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Mexico	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Laser/radar	√	√	√	√		
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Air bag	√	√	√	√		
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	EPS/DAST 3	√	√	√	√		
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Motor control	√	√	√	√		
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Transmission	√	√	√	√		SP0281, SP0282
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	HV battery	√	√	√	√	AC1121	
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Auto back door	√	√	√	√		SP0611
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Occupant detection			√	√		SP0584
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Precrash seatbelt	√	√	√	√		SP0612
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Lane camera	√	√	√	√		
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	VSP	√	√	√	√		
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	6ch CAN GATEWAY	√	√	√	√		
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	3ch CAN GATEWAY	√	√	√	√		
Mexico	INFINITI QX60 Hybrid	HL50	2018.8-	ICC/ADAS 2	√	√	√	√		
Mexico	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Mexico	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Mexico	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mexico	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Mexico	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Mexico	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mexico	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mexico	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√		SP0274
Mexico	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mexico	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Mexico	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Mexico	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mexico	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mexico	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Mexico	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Mexico	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mexico	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mexico	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mexico	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Mexico	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Mexico	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Mexico	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mexico	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mexico	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Mexico	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Mexico	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mexico	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mexico	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mexico	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Mexico	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Mexico	INFINITI QX80	Z62	2013.6-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Mexico	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mexico	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√		SP0270, SP0274
Mexico	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Mexico	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mexico	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Mexico	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Mexico	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Mexico	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Mexico	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mexico	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mexico	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Mexico	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Mexico	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Mexico	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mexico	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mexico	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Mexico	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Mexico	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mexico	INFINITI QX80	Z62	2013.6-	SVT	√	√	√	√		SP0595
Mexico	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			

Mexico	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mexico	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mexico	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Mexico	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mexico	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Mexico	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Mexico	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Mexico	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Mexico	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Middle east common	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Middle east common	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Middle east common	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Middle east common	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Middle east common	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Middle east common	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Middle east common	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Middle east common	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Middle east common	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Middle east common	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Middle east common	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Middle east common	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Middle east common	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Middle east common	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Middle east common	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Middle east common	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	

Middle east common	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Middle east common	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
Middle east common	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
Middle east common	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Middle east common	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Middle east common	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Middle east common	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Middle east common	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Middle east common	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Middle east common	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Middle east common	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572,SP0573
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570,SP0571
Middle east common	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Middle east common	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274

XTOOL

Middle east common	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Middle east common	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Middle east common	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Middle east common	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Middle east common	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Motor control						

Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Middle east common	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471

XTOOL

Middle east common	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Middle east common	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Middle east common	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Middle east common	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Middle east common	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Middle east common	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Middle east common	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Middle east common	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Middle east common	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Middle east common	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Middle east common	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

XTOOL

Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Middle east common	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Middle east common	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	

XTOOL

Middle east common	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Middle east common	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Middle east common	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Middle east common	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Middle east common	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Middle east common	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Middle east common	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Middle east common	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Middle east common	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Middle east common	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Middle east common	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Middle east common	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Middle east common	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Middle east common	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Middle east common	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Middle east common	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Middle east common	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Middle east common	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Middle east common	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Middle east common	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Middle east common	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Middle east common	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Middle east common	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Middle east common	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Middle east common	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Middle east common	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Middle east common	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Middle east common	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Middle east common	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Middle east common	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Middle east common	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

XTOOL

Middle east common	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Middle east common	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Middle east common	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Middle east common	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Middle east common	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Middle east common	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Middle east common	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Middle east common	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Middle east common	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Middle east common	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Middle east common	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Middle east common	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Middle east common	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Middle east common	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Middle east common	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Middle east common	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Middle east common	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Middle east common	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Middle east common	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Middle east common	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Middle east common	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Middle east common	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Middle east common	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Middle east common	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Middle east common	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	AVM	√	√		√		

XTOOL

Middle east common	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Middle east common	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Middle east common	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Middle east common	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Middle east common	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Middle east common	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Middle east common	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Middle east common	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Middle east common	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Middle east common	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Middle east common	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Middle east common	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Middle east common	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Middle east common	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Middle east common	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Middle east common	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Middle east common	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Middle east common	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		

XTOOL

Middle east common	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Middle east common	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Middle east common	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Middle east common	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Middle east common	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Middle east common	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Middle east common	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Middle east common	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Middle east common	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Middle east common	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Middle east common	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Middle east common	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Middle east common	INFINITI Q45	F50	2001.8-	Motor control						

XTOOL

Middle east common	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Middle east common	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Middle east common	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Middle east common	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Middle east common	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Middle east common	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Middle east common	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Middle east common	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Middle east common	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Middle east common	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Middle east common	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Middle east common	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Middle east common	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Middle east common	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Middle east common	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Middle east common	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Middle east common	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Middle east common	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Middle east common	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Middle east common	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Middle east common	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Middle east common	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Middle east common	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Middle east common	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Middle east common	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Middle east common	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Middle east common	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Middle east common	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Middle east common	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Middle east common	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429

XTOOL

Middle east common	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Middle east common	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Middle east common	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Middle east common	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Middle east common	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Middle east common	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Middle east common	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Middle east common	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Middle east common	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Middle east common	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Middle east common	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Middle east common	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Middle east common	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Middle east common	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Middle east common	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Middle east common	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Middle east common	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Middle east common	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Middle east common	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Middle east common	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Middle east common	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Middle east common	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Middle east common	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Middle east common	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Middle east common	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Middle east common	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Middle east common	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Middle east common	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		

XTOOL

Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Middle east common	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		

XTOOL

Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Middle east common	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Middle east common	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Middle east common	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Middle east common	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Middle east common	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Middle east common	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Middle east common	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Middle east common	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Middle east common	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Middle east common	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Middle east common	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Middle east common	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Middle east common	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Middle east common	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Middle east common	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Middle east common	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Middle east common	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Middle east common	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Middle east common	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Middle east common	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Middle east common	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Middle east common	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Middle east common	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Middle east common	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Middle east common	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Middle east common	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Middle east common	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Middle east common	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Middle east common	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Middle east common	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Middle east common	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319

XTOOL

Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Middle east common	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Middle east common	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Middle east common	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Middle east common	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Middle east common	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Middle east common	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		

Middle east common	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Middle east common	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Middle east common	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Middle east common	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Middle east common	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Middle east common	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Middle east common	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Middle east common	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Middle east common	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Middle east common	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Middle east common	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Middle east common	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Middle east common	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Middle east common	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Middle east common	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Middle east common	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Middle east common	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Middle east common	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Middle east common	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Middle east common	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Middle east common	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Middle east common	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Middle east common	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Middle east common	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Middle east common	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Middle east common	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Middle east common	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Middle east common	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Middle east common	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

XTOOL

Middle east common	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Middle east common	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Middle east common	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Middle east common	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Middle east common	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Middle east common	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Middle east common	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Middle east common	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Middle east common	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Middle east common	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Middle east common	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Middle east common	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Middle east common	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Middle east common	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Middle east common	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Middle east common	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Middle east common	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Middle east common	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Middle east common	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Middle east common	INFINITI QX50	J55	2018.5-	Shift						
Middle east common	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Middle east common	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		

Middle east common	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	ANC						
Middle east common	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Middle east common	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Middle east common	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Middle east common	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Middle east common	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Middle east common	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Middle east common	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Middle east common	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Middle east common	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Middle east common	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Middle east common	INFINITI QX56	JA60	2004.10-	Motor control						
Middle east common	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Middle east common	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Middle east common	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Middle east common	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Middle east common	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Middle east common	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Middle east common	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Middle east common	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Middle east common	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Middle east common	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Middle east common	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Middle east common	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Middle east common	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Middle east common	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Middle east common	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Middle east common	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		

Middle east common	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Middle east common	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Middle east common	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572,SP0573
Middle east common	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Middle east common	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Middle east common	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570,SP0571
Middle east common	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Middle east common	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Middle east common	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Middle east common	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Middle east common	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Middle east common	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Middle east common	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347,SP0348,SP0349,SP0350,SP0351
Middle east common	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Middle east common	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270,SP0274
Middle east common	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Middle east common	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0313,SP0315
Middle east common	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0484,SP0485,SP0486,SP0487,SP0488
Middle east common	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031,AC1032,AC1033	SP0585,SP0586,SP0587
Middle east common	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Middle east common	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Middle east common	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Middle east common	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Middle east common	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Middle east common	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Middle east common	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√		SP0544,SP0545,SP0546,SP0547,SP0548,SP0549
Middle east common	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Middle east common	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Middle east common	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Middle east common	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Middle east common	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Middle east common	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Middle east common	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Middle east common	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Middle east common	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Middle east common	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Middle east common	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Middle east common	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		

Middle east common	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Middle east common	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Middle east common	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Middle east common	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Middle east common	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Middle east common	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Middle east common	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Middle east common	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Middle east common	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Middle east common	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Middle east common	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Middle east common	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Middle east common	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Middle east common	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Middle east common	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Middle east common	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Middle east common	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Middle east common	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Middle east common	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Middle east common	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315

XTOOL

Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Middle east common	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Middle east common	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Middle east common	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Middle east common	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Middle east common	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Middle east common	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Middle east common	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Middle east common	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Middle east common	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Middle east common	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Middle east common	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Middle east common	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Middle east common	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Middle east common	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Middle east common	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Middle east common	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Middle east common	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Middle east common	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	

Middle east common	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Middle east common	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Middle east common	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Middle east common	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Middle east common	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Middle east common	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Middle east common	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Middle east common	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Middle east common	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Middle east common	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Middle east common	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Middle east common	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Middle east common	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Middle east common	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Middle east common	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Middle east common	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Middle east common	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Middle east common	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Middle east common	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Middle east common	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Middle east common	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Middle east common	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Middle east common	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Middle east common	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Middle east common	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Middle east common	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Middle east common	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Middle east common	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Middle east common	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Middle east common	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Middle east common	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Middle east common	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Middle east common	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Middle east common	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Middle east common	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Middle east common	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Middle east common	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Middle east common	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Middle east common	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Middle east common	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582

Middle east common	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Middle east common	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Middle east common	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Middle east common	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Middle east common	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Middle east common	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Middle east common	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Moldova	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Moldova	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Moldova	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Moldova	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Moldova	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Moldova	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Moldova	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Moldova	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Moldova	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Moldova	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Moldova	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Moldova	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Moldova	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Moldova	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Moldova	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Moldova	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

Moldova	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Moldova	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Moldova	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Moldova	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Moldova	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Moldova	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Moldova	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Moldova	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Moldova	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Moldova	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Moldova	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Moldova	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Moldova	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Moldova	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Moldova	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Moldova	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Moldova	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Moldova	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Moldova	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Moldova	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Moldova	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Moldova	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Moldova	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Moldova	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Moldova	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Moldova	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Moldova	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Moldova	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Moldova	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Moldova	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Moldova	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Moldova	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Moldova	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Moldova	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Moldova	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Moldova	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Moldova	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Moldova	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Moldova	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Moldova	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Moldova	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Moldova	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Moldova	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349

Moldova	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Moldova	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Moldova	INFINITI M35/M45	Y50	2006.7-	BCM				√	AC0653, AC0698	SP0391, SP0393
Moldova	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Moldova	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Moldova	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Moldova	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Moldova	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Moldova	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Moldova	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Moldova	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Moldova	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Moldova	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Moldova	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Moldova	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Moldova	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Moldova	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Moldova	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Moldova	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Moldova	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Moldova	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Moldova	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Moldova	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Moldova	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Moldova	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Moldova	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Moldova	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Moldova	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Moldova	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Moldova	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Moldova	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Moldova	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Moldova	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Moldova	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Moldova	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Moldova	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Moldova	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583

XTOOL

Moldova	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Moldova	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Moldova	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Moldova	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Moldova	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Moldova	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Moldova	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Moldova	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Moldova	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Moldova	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Moldova	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Moldova	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Moldova	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Moldova	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Moldova	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Moldova	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Moldova	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Moldova	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Moldova	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Moldova	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Moldova	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Moldova	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Moldova	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Moldova	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Moldova	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Moldova	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Moldova	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Moldova	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Moldova	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Moldova	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Moldova	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Moldova	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Moldova	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Moldova	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Moldova	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Moldova	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Moldova	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Moldova	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Moldova	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Moldova	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Moldova	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Moldova	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Moldova	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Moldova	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Moldova	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		

Moldova	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Moldova	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Moldova	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Moldova	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Moldova	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Moldova	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Moldova	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Moldova	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Moldova	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Moldova	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084. AC1085. AC1086. AC1087. AC1088. AC1089. AC1106	
Moldova	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Moldova	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Moldova	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Moldova	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Moldova	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Moldova	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Moldova	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Moldova	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Moldova	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Moldova	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Moldova	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Moldova	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Moldova	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Moldova	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Moldova	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Moldova	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Moldova	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Moldova	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Moldova	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Moldova	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Moldova	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Moldova	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Moldova	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Moldova	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Moldova	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Moldova	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Moldova	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Moldova	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Moldova	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084. AC1085. AC1086. AC1087. AC1088. AC1089. AC1106	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980. AC0981. AC0982	SP0561. SP0562
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Moldova	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897. AC0898. AC0899. AC0900. AC0901. AC0902	SP0508. SP0509
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429

Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Moldova	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Moldova	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Moldova	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Moldova	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Moldova	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Moldova	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Moldova	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Moldova	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Moldova	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Moldova	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Moldova	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Moldova	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Moldova	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Moldova	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Moldova	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Moldova	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Moldova	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Moldova	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Moldova	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Moldova	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Moldova	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Moldova	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Moldova	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Moldova	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Moldova	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Moldova	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Moldova	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Moldova	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Moldova	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Moldova	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Moldova	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Moldova	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Moldova	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Moldova	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Moldova	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Moldova	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Moldova	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Moldova	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Moldova	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Moldova	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Moldova	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Moldova	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Moldova	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Moldova	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Moldova	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Moldova	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Moldova	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Moldova	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Moldova	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Moldova	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Moldova	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Moldova	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Moldova	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Moldova	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Moldova	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Moldova	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Moldova	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Moldova	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Moldova	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Moldova	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Moldova	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Moldova	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Moldova	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Moldova	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Moldova	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Moldova	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Moldova	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Moldova	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Moldova	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Moldova	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Moldova	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Moldova	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583

Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Moldova	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Moldova	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Moldova	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Moldova	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Moldova	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Moldova	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Moldova	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Moldova	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Moldova	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Moldova	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Moldova	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Moldova	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Moldova	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Moldova	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Moldova	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Moldova	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Moldova	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Moldova	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Moldova	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Moldova	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Moldova	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Moldova	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Moldova	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Moldova	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Moldova	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Moldova	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Moldova	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Moldova	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Moldova	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Moldova	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Moldova	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Moldova	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Moldova	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Moldova	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Moldova	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Moldova	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Moldova	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Moldova	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Moldova	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Moldova	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Moldova	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Moldova	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Moldova	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Moldova	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Moldova	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Moldova	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Moldova	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Moldova	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Moldova	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Moldova	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Moldova	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Moldova	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Moldova	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Moldova	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Moldova	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Moldova	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Moldova	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Moldova	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Moldova	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Moldova	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Moldova	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Moldova	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Moldova	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Moldova	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Moldova	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Moldova	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Moldova	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Moldova	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Moldova	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Moldova	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mongolia	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Laser/radar	√	√	√	√		
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Air bag	√	√	√	√		
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	EPS/DAST 3	√	√	√	√		SP0507
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Motor control	√	√	√	√		
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Transmission	√	√	√	√		SP0276
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Pop up hood	√	√	√	√		
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Multi AV	√	√	√	√		SP0503
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	HV battery	√	√	√	√	AC1121	
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Occupant detection			√	√		SP0584
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	DAST 2	√	√	√	√		
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Precrash seatbelt	√	√	√	√		SP0612
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	CAN gateway	√	√	√			
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	DAST 1	√	√	√	√		
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	ANC	√	√	√	√	AC1024	
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Side radar left	√	√	√	√	AC1025	SP0582
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	HIGH BEAM ASSIST	√	√	√	√		
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Side radar right	√	√	√	√	AC1026	SP0583
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	Brake	√	√	√	√	AC1127	
Mongolia	INFINITI Q50 HYBRID	HV37	2016.2-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Montenegro	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Montenegro	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Montenegro	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Montenegro	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Montenegro	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Montenegro	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Montenegro	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Montenegro	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Montenegro	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegro	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Montenegro	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Montenegro	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Montenegro	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		

Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegro	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Montenegr	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegr	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegr	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Montenegr	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Montenegro	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Montenegro	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Montenegr	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montenegro	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Montenegr	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Montenegro	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegr	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Montenegr	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Montenegr	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Montenegro	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegr	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegr	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Montenegro	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Montenegr	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Montenegr	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Montenegro	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Montenegro	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Montenegr	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Montenegro	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Montenegro	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Montenegro	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Montenegro	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegro	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montenegro	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montenegro	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Montenegro	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Montenegro	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Montenegro	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegro	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Montenegro	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Montenegro	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Montenegro	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Montenegro	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Montenegro	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Montenegro	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Montenegro	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Montenegro	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Montenegro	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Montenegro	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegro	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Montenegro	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Montenegro	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Montenegro	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Montenegro	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Montenegro	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegro	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Montenegro	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Montenegro	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Montenegro	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Montenegro	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegro	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Montenegro	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Montenegro	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Montenegro	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Montenegro	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Montenegro	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Montenegro	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Montenegro	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Montenegro	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Montenegro	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Montenegro	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Montenegro	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Montenegro	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegro	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Montenegro	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montenegro	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montenegro	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montenegro	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Montenegro	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Montenegro	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Montenegro	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Montenegro	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Montenegro	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Montenegro	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		

Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Montenegro	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Montenegr	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Montenegr	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Montenegro	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Montenegr	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Montenegro	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Montenegr	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Montenegr	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Montenegr	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Montenegr	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Montenegro	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Montenegro	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Montenegro	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Montenegro	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Montenegro	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Montenegro	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Montenegr	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Montenegr	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Montenegro	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Montenegr	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Montenegr	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Montenegro	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Montenegr	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Montenegro	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Montenegr	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Montenegr	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Montenegro	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Montenegro	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Montenegr	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Montenegr	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Montenegr	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Montenegr	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Montenegr	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Montenegr	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Montenegr	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Montenegr	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Montenegr	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Montenegr	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Montenegr	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Montenegr	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Montenegr	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Montenegr	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Montenegr	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		

Montenegro	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Montenegro	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Montenegro	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Montenegro	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Montenegro	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Montenegro	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Montenegro	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Montenegro	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Montenegro	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegro	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Montenegro	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Montenegro	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Montenegro	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Montenegro	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Montenegro	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Montenegro	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Montenegro	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Montenegro	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Montenegro	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Montenegro	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Montenegro	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Montenegro	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Montenegro	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegro	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Montenegro	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Montenegro	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Montenegro	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montenegro	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Montenegro	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Montenegro	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Montenegro	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Montenegro	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Montenegro	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Montenegro	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Montenegro	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Montenegro	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegro	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Montenegro	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Montenegro	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Montenegro	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Montenegro	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Montenegro	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Montenegro	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Montenegro	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Montenegro	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Montenegro	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Montenegro	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Montenegro	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Montenegro	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Montenegro	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Montenegro	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Montenegro	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Montenegro	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503

Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Montenegro	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Montenegr	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Montenegro	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Montenegro	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Montenegro	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Montenegro	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Montenegr	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Montenegr	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Montenegr	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Montenegr	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Montenegr	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegr	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Montenegr	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Montenegr	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Montenegro	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Montenegr	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Montenegr	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Montenegro	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Montenegr	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Montenegr	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Montenegro	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegr	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Montenegr	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Montenegr	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montenegr	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Montenegr	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Montenegr	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Montenegr	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Montenegr	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Montenegr	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Montenegr	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Montenegr	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegr	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Montenegr	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Montenegr	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Montenegr	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Montenegr	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Montenegr	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Montenegr	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Montenegr	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583

Montenegr	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Montenegr	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Montenegr	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Montenegr	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Montenegro	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Montenegro	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montenegro	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Montenegro	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Montenegr	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegr	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Montenegr	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Montenegr	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Montenegr	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegr	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Montenegr	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Montenegr	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Montenegro	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Montenegro	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Montenegr	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Montenegro	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Montenegr	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Montenegr	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Montenegr	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Montenegr	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Montenegro	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegr	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Montenegr	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Montenegr	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montenegr	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Montenegr	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Montenegr	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Montenegr	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Montenegr	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Montenegr	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Montenegr	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegr	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Montenegr	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Montenegr	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Montenegr	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Montenegr	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Montenegr	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Montenegr	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Montenegr	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Montenegr	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		

Montenegr	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Montenegro	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Montenegro	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Montenegro	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Montenegro	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Montenegr	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Montenegr	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Montenegr	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Montenegr	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Montenegr	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegr	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Montenegr	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Montenegr	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Montenegro	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Montenegr	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Montenegr	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montenegro	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Montenegr	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Montenegro	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegr	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montenegr	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montenegr	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montenegr	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Montenegr	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Montenegr	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Montenegr	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Montenegr	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Montenegr	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Montenegr	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Montenegr	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Montenegr	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Montenegro	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Montenegr	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Montenegr	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Montenegro	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Montenegro	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Montenegr	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Montenegro	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Montenegr	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Montenegr	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Montenegr	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Montenegro	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegr	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montenegr	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Montenegro	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Montenegr	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Montenegr	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Montenegr	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Montenegr	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Montenegr	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montenegro	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Montenegr	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montenegr	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Montenegr	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Montenegr	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Montenegro	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Montenegro	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Montenegr	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montenegr	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Montenegr	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Montenegr	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Montenegr	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Montenegr	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Montenegro	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montenegr	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Montenegr	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Montenegr	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montenegr	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montenegr	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Montenegr	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Montenegr	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Montenegr	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Montenegr	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Montenegr	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Montenegr	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montenegr	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Montenegr	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Montenegr	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Montenegr	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Montenegr	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Montserra	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montserra	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Montserra	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montserra	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Montserra	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Montserra	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Montserra	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montserra	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Montserra	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Montserra	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montserra	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montserra	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montserra	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montserra	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Montserra	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Montserra	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Montserra	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Montserra	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Montserra	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montserra	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Montserra	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montserra	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Montserra	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Montserra	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Montserra	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Montserra	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montserra	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Montserra	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Montserra	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Montserra	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Montserra	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montserra	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Montserra	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Montserra	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montserra	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montserra	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Montserra	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Montserra	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Montserra	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Montserra	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Montserra	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Montserra	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montserra	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montserra	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556

Montserrat	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Montserrat	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Montserrat	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Montserrat	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montserra	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montserra	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Montserra	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montserra	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Montserra	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Montserrat	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Montserra	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Montserra	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Montserra	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Montserra	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Montserra	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Montserra	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Montserra	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montserra	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montserra	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montserra	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Montserra	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Montserra	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montserra	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Montserrat	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Montserra	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montserra	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Montserra	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Montserrat	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Montserrat	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Montserra	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Montserra	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Montserra	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Montserra	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Montserra	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montserra	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Montserra	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montserra	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Montserra	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Montserra	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Montserra	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Montserra	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Montserra	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Montserra	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Montserra	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Montserra	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Montserra	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Montserra	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Montserrat	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Montserra	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Montserra	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Montserra	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Montserrat	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Montserra	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Montserra	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Montserra	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Montserra	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Montserra	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503

Montserrat	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Montserrat	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Montserrat	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Montserrat	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montserrat	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montserrat	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montserrat	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Montserrat	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Montserrat	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Montserrat	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Montserrat	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Montserrat	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montserrat	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Montserrat	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Montserrat	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Montserrat	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Montserrat	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Montserrat	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Montserrat	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Montserrat	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Montserrat	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Montserrat	INFINITI Q45	F50	2001.8-	Motor control						
Montserrat	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Montserrat	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Montserrat	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Montserrat	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Montserrat	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Montserrat	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Montserrat	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Montserrat	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montserrat	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Montserrat	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Montserrat	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Montserrat	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Montserrat	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Montserrat	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Montserrat	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Montserrat	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Montserrat	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Montserrat	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Montserrat	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Montserrat	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Montserrat	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Montserrat	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Montserrat	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Montserrat	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Montserrat	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Montserrat	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Montserrat	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Montserrat	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Montserrat	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Montserrat	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Montserrat	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Montserrat	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Montserrat	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Montserrat	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Montserrat	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Montserrat	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Montserrat	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Montserrat	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Montserrat	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Montserrat	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Montserrat	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Montserrat	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Montserrat	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Montserrat	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Montserrat	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Montserrat	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Montserrat	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Montserrat	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Montserrat	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Montserrat	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Montserrat	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Montserrat	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Montserrat	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Montserrat	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Montserrat	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Morocco	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Morocco	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Morocco	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Morocco	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Morocco	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Morocco	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Morocco	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Morocco	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Morocco	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Morocco	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Morocco	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Morocco	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556

Morocco	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Morocco	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Morocco	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Morocco	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Morocco	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Morocco	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Morocco	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Morocco	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Morocco	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Morocco	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Morocco	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Morocco	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Morocco	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Morocco	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Morocco	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Morocco	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Morocco	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Morocco	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Morocco	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Morocco	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Morocco	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Morocco	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Morocco	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Morocco	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Morocco	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Morocco	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Morocco	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Morocco	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Morocco	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Morocco	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Morocco	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Morocco	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Morocco	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

XTOOL

Morocco	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Morocco	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Morocco	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Morocco	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Morocco	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Morocco	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Morocco	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Morocco	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Morocco	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Morocco	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Morocco	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Morocco	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Morocco	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Morocco	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Morocco	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Morocco	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Morocco	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Morocco	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Morocco	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Morocco	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Morocco	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Morocco	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Morocco	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Morocco	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Morocco	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Morocco	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Morocco	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Morocco	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Morocco	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Morocco	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Morocco	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Morocco	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Morocco	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Morocco	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Morocco	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Morocco	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Morocco	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Morocco	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Morocco	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Morocco	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Morocco	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Morocco	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Morocco	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Morocco	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Morocco	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Morocco	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Morocco	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Morocco	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Morocco	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Morocco	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Morocco	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Morocco	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Morocco	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Morocco	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Morocco	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Morocco	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Morocco	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Morocco	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Morocco	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Morocco	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Morocco	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Morocco	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Morocco	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Morocco	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Morocco	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Morocco	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		

Morocco	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Morocco	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Morocco	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0274
Morocco	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Morocco	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Morocco	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Morocco	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Morocco	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Morocco	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Morocco	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Morocco	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Morocco	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Morocco	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Morocco	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Morocco	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Morocco	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Morocco	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Morocco	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Morocco	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Morocco	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Morocco	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Morocco	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Morocco	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Morocco	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Morocco	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Morocco	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Morocco	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Morocco	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Morocco	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Morocco	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Morocco	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247,SP0274,SP0276
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Morocco	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Morocco	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Morocco	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Morocco	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Morocco	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Morocco	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Morocco	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Morocco	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Morocco	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Morocco	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Morocco	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Morocco	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Morocco	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Morocco	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Morocco	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Morocco	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Morocco	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Morocco	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Morocco	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	

Morocco	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Morocco	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Morocco	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Morocco	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Morocco	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Morocco	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Morocco	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Morocco	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Morocco	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Morocco	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Morocco	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Morocco	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Morocco	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Morocco	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Morocco	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Morocco	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Morocco	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Morocco	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Morocco	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Morocco	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Morocco	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Morocco	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Morocco	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Morocco	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Morocco	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Morocco	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Morocco	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Morocco	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Morocco	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Morocco	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Morocco	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Morocco	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Morocco	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Morocco	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Morocco	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Morocco	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Morocco	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584

XTOOL

Morocco	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Morocco	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Morocco	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0555,SP0556,SP0557
Morocco	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Morocco	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Morocco	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Morocco	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Morocco	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Morocco	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Morocco	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Morocco	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Morocco	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Morocco	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Morocco	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Morocco	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Morocco	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Morocco	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Morocco	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Morocco	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Morocco	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Morocco	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Morocco	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Morocco	INFINITI QX50	J50	2013.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Morocco	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Morocco	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Morocco	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Morocco	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Morocco	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Morocco	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Morocco	INFINITI QX50	I50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Morocco	INFINITI QX50	I50	2013.8-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Morocco	INFINITI QX50	I50	2013.8-	CAN gateway	√	√	√	√		
Morocco	INFINITI QX50	I50	2013.8-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Morocco	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Morocco	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Morocco	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Morocco	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Morocco	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Morocco	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Morocco	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Morocco	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Morocco	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Morocco	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Morocco	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Morocco	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Morocco	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Morocco	INFINITI QX70	S51	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Morocco	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Morocco	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Morocco	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Morocco	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Morocco	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Morocco	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Morocco	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Morocco	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Morocco	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Morocco	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Morocco	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Morocco	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Morocco	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Morocco	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Morocco	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Morocco	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Morocco	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Morocco	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Morocco	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Morocco	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Morocco	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Morocco	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Morocco	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Morocco	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Morocco	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Morocco	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Morocco	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Morocco	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Morocco	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347,SP0348,SP0349,SP0350,SP0351
Morocco	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Morocco	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Morocco	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Morocco	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Morocco	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Morocco	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0484,SP0485,SP0486,SP0487,SP0488
Morocco	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031,AC1032,AC1033	SP0585,SP0586,SP0587
Morocco	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Morocco	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Morocco	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Morocco	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Morocco	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Morocco	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Morocco	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Morocco	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544,SP0545,SP0546,SP0547,SP0548,SP0549
Morocco	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Morocco	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Morocco	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			

Morocco	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Morocco	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Morocco	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Morocco	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Morocco	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Morocco	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Morocco	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Morocco	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Morocco	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Mozambique	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mozambique	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mozambique	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Mozambique	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mozambique	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mozambique	INFINITI EX35/EX37	I50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Mozambique	INFINITI EX35/EX37	I50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mozambique	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Mozambique	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mozambique	INFINITI EX35/EX37	I50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mozambique	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mozambique	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mozambique	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mozambique	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Mozambique	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Mozambique	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Mozambique	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mozambique	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Mozambique	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mozambique	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mozambique	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Mozambique	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Mozambique	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mozambique	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Mozambique	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mozambique	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Mozambique	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mozambique	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Mozambique	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Mozambique	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Mozambique	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mozambique	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mozambique	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Mozambique	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Mozambique	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mozambique	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Mozambique	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Mozambique	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Mozambique	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Mozambique	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mozambique	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mozambique	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mozambique	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mozambique	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mozambique	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mozambique	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553. SP0554. SP0555. SP0556
Mozambique	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Mozambique	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Mozambique	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Mozambique	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Mozambique	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mozambique	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Mozambique	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Mozambique	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Mozambique	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Mozambique	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Mozambique	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Mozambique	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Mozambique	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Mozambique	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Mozambique	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Mozambique	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Mozambique	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Mozambique	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Mozambique	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Mozambique	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Mozambique	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Mozambique	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Mozambique	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Mozambique	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Mozambique	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			

Mozambique	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Mozambique	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Mozambique	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Mozambique	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Mozambique	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Mozambique	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Mozambique	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Mozambique	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Mozambique	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Mozambique	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Mozambique	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Mozambique	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Mozambique	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Mozambique	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0274
Mozambique	INFINITI Q50	V37	2013.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Mozambique	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
Mozambique	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Mozambique	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Mozambique	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Mozambique	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Mozambique	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Mozambique	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979,AC0981,AC0982	SP0562
Mozambique	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Mozambique	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Mozambique	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Mozambique	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Mozambique	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Mozambique	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Mozambique	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Mozambique	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Mozambique	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mozambique	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Mozambique	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604,SP0605,SP0606
Mozambique	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Mozambique	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Mozambique	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Mozambique	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Mozambique	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Mozambique	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Mozambique	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Mozambique	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Mozambique	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0330,AC0331,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247,SP0274,SP0276
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979,AC0981,AC0982	SP0562
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
Mozambique	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Mozambique	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Mozambique	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Mozambique	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Mozambique	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Mozambique	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Mozambique	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Mozambique	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351

Mozambique	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mozambique	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Mozambique	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Mozambique	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mozambique	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Mozambique	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mozambique	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mozambique	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mozambique	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Mozambique	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Mozambique	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mozambique	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mozambique	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Mozambique	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Mozambique	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Mozambique	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Mozambique	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Mozambique	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Mozambique	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mozambique	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Mozambique	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Mozambique	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Mozambique	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Mozambique	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Mozambique	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mozambique	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Mozambique	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Mozambique	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Mozambique	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Mozambique	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mozambique	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mozambique	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mozambique	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Mozambique	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Mozambique	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

Mozambiqu	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Mozambiqu	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Mozambiqu	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Mozambiqu	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Mozambique	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mozambiqu	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Mozambiqu	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Mozambique	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Mozambiqu	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Mozambiqu	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Mozambiqu	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mozambiqu	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mozambiqu	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Mozambiqu	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Mozambiqu	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mozambiqu	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Mozambiqu	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Mozambiqu	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Mozambiqu	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mozambiqu	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Mozambiqu	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mozambiqu	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mozambiqu	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mozambiqu	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Mozambiqu	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mozambiqu	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Mozambiqu	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mozambiqu	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Mozambiqu	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mozambiqu	INFINITI QX50	I50	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Mozambiqu	INFINITI QX50	I50	2013.8-	Air bag	√	√	√	√		
Mozambiqu	INFINITI QX50	I50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Mozambiqu	INFINITI QX50	I50	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Mozambique	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mozambiqu	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Mozambiqu	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mozambique	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Mozambiqu	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mozambiqu	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mozambiqu	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mozambiqu	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mozambiqu	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Mozambiqu	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Mozambiqu	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mozambiqu	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Mozambiqu	INFINITI QX50	I50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mozambiqu	INFINITI QX50	I50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Mozambiqu	INFINITI QX50	I50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Mozambiqu	INFINITI QX50	I50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mozambiqu	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Mozambiqu	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Mozambiqu	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Mozambiqu	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Mozambiqu	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Mozambiqu	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Mozambiqu	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Mozambiqu	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Mozambique	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Mozambiqu	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Mozambiqu	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Mozambiqu	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Mozambiqu	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Mozambiqu	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Mozambiqu	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Mozambiqu	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Mozambique	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mozambiqu	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Mozambiqu	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Mozambiqu	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Mozambiqu	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mozambiqu	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Mozambiqu	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Mozambiqu	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Mozambiqu	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Mozambiqu	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Mozambiqu	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mozambiqu	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Mozambiqu	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mozambiqu	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Mozambiqu	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Mozambiqu	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mozambiqu	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Mozambiqu	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Mozambiqu	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Mozambiqu	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Mozambiqu	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Mozambique	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Mozambiqu	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Mozambiqu	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Mozambiqu	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Mozambique	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Mozambique	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Mozambique	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Mozambique	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Mozambique	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Mozambique	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Mozambique	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Mozambique	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Mozambique	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Mozambique	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Mozambique	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Mozambique	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Mozambique	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Mozambique	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Mozambique	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Mozambique	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Mozambique	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Mozambique	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Mozambique	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Mozambique	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Mozambique	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Mozambique	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Mozambique	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Mozambique	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Mozambique	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Mozambique	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Mozambique	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Namibia	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Namibia	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Namibia	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Namibia	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Namibia	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Namibia	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Namibia	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Namibia	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Namibia	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Namibia	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Namibia	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Namibia	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Namibia	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Namibia	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Namibia	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Namibia	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Namibia	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Namibia	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Namibia	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Namibia	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Namibia	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Namibia	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Namibia	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Namibia	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Namibia	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Namibia	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Namibia	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Namibia	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Namibia	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Namibia	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Namibia	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Namibia	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Namibia	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Namibia	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Namibia	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Namibia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Namibia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Namibia	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Namibia	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Namibia	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Namibia	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Namibia	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Namibia	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Namibia	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Namibia	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Namibia	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Namibia	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Namibia	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Namibia	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Namibia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Namibia	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Namibia	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Namibia	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Namibia	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Namibia	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Namibia	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Namibia	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Namibia	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Namibia	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Namibia	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Namibia	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Namibia	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Namibia	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Namibia	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Namibia	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Namibia	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Namibia	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Namibia	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Namibia	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Namibia	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Namibia	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Namibia	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Namibia	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Namibia	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Namibia	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Namibia	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Namibia	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Namibia	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Namibia	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Namibia	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501

Namibia	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Namibia	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Namibia	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Namibia	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Namibia	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Namibia	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Namibia	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Namibia	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Namibia	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Namibia	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Namibia	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Namibia	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Namibia	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Namibia	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Namibia	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Namibia	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Namibia	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Namibia	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Namibia	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Namibia	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Namibia	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Namibia	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Namibia	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Namibia	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Namibia	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Namibia	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Namibia	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Namibia	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Namibia	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Namibia	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Namibia	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Namibia	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Namibia	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Namibia	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Namibia	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Namibia	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Namibia	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Namibia	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Namibia	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Namibia	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Namibia	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Namibia	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Namibia	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Namibia	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Namibia	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Namibia	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Namibia	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Namibia	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Namibia	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Namibia	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Namibia	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Namibia	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		

Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Namibia	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Namibia	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Namibia	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Namibia	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Namibia	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Namibia	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Namibia	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Namibia	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Namibia	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Namibia	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Namibia	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Namibia	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Namibia	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Namibia	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Namibia	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Namibia	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Namibia	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Namibia	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Namibia	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Namibia	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Namibia	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Namibia	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Namibia	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Namibia	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Namibia	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Namibia	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Namibia	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Namibia	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Namibia	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Namibia	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Namibia	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Namibia	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Namibia	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Namibia	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Namibia	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Namibia	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Namibia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Namibia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Namibia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Namibia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Namibia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Namibia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Namibia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Namibia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Namibia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Namibia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Namibia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Namibia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Namibia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Namibia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Namibia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Namibia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Namibia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Namibia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Namibia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Namibia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Namibia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Namibia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Namibia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Namibia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Namibia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Namibia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Namibia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Namibia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Namibia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Namibia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Namibia	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Namibia	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Namibia	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Namibia	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Namibia	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Namibia	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Namibia	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Namibia	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Namibia	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Namibia	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Namibia	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Namibia	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Namibia	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Namibia	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Namibia	INFINITI QX50	I50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Namibia	INFINITI QX50	I50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Namibia	INFINITI QX50	I50	2013.8-	CAN gateway	√	√	√	√		
Namibia	INFINITI QX50	I50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Namibia	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Namibia	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Namibia	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Namibia	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Namibia	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Namibia	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Namibia	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Namibia	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Namibia	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Namibia	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Namibia	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Namibia	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Namibia	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Namibia	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315

Namibia	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Namibia	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Namibia	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Namibia	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Namibia	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Namibia	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Namibia	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Namibia	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Namibia	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Namibia	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Namibia	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Namibia	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Namibia	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Namibia	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Namibia	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Namibia	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Namibia	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Namibia	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Namibia	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Namibia	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Namibia	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Namibia	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Namibia	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Namibia	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Namibia	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Namibia	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Namibia	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Namibia	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Namibia	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Namibia	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Namibia	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Namibia	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Namibia	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Namibia	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Namibia	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Namibia	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Namibia	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Namibia	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Namibia	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Namibia	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Namibia	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Namibia	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Namibia	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Namibia	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Namibia	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Namibia	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Namibia	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Namibia	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Namibia	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Namibia	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Namibia	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Namibia	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Namibia	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Namibia	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nepal	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Laser/radar	√	√	√	√		
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Air bag	√	√	√	√		
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	EPS/DAST 3	√	√	√	√		SP0507
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Motor control	√	√	√	√		
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Pop up hood	√	√	√	√		
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Multi AV	√	√	√	√		SP0503
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	HV battery	√	√	√	√	AC1121	
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Occupant detection			√	√		SP0584

Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Adaptive light	√	√	√	√	AC0979,AC0981,AC0982	SP0562
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	DAST 2	√	√	√	√		
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Precrash seatbelt	√	√	√	√		SP0612
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	CAN gateway	√	√	√			
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	DAST 1	√	√	√	√		
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	ANC	√	√	√	√	AC1024	
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Side radar left	√	√	√	√	AC1025	SP0582
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	HIGH BEAM ASSIST	√	√	√	√		
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Side radar right	√	√	√	√	AC1026	SP0583
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	Brake	√	√	√	√	AC1127	
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	FSCM	√	√	√	√	AC1109	
Nepal	INFINITI Q50 HYBRID	HV37	2016.3-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
New zealand	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
New zealand	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546,AC0547,AC0548,AC0549	SP0342,SP0343,SP0344
New zealand	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002,AC0103,AC0214,AC0264,AC0265,AC0266,AC0267,AC0268,AC0269,AC0270,AC0271,AC0272,AC0273,AC0274,AC0275,AC0276,AC0277,AC0308,AC0310,AC0311,AC0312,AC0314,AC0315,AC0317,AC0320,AC0325,AC0327,AC0328,AC0329,AC0330,AC0331,AC0332	SP0034,SP0035,SP0159,SP0193,SP0194
New zealand	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580,AC0674,AC0739,AC0740,AC0741,AC0742,AC0743,AC0744,AC0745,AC0746,AC0747,AC0748,AC0749,AC0750,AC0751,AC0752,AC0753,AC0754,AC0755,AC0756,AC0757,AC0758,AC0759,AC0760,AC0761,AC0762,AC0763,AC0764,AC0765,AC0766,AC0767,AC0768,AC0769,AC0770	
New zealand	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
New zealand	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
New zealand	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
New zealand	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143,AC1144,AC1145,AC1146,AC1147,AC1148,AC1149,AC1150,AC1151,AC1152,AC1153,AC1154,AC1155,AC1156	
New zealand	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
New zealand	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
New zealand	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
New zealand	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171,AC1172,AC1173,AC1174,AC1175	
New zealand	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157,AC1158,AC1159,AC1160,AC1161,AC1162,AC1163,AC1164,AC1165,AC1166,AC1167,AC1168,AC1169,AC1170	SP0622
New zealand	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
New zealand	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
New zealand	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
New zealand	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
New zealand	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
New zealand	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
New zealand	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
New zealand	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
New zealand	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
New zealand	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
New zealand	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546,AC0547,AC0548,AC0549	SP0342,SP0343,SP0344

XTOOL

New zealand	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
New zealand	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
New zealand	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
New zealand	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
New zealand	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
New zealand	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
New zealand	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
New zealand	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
New zealand	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
New zealand	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
New zealand	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
New zealand	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
New zealand	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
New zealand	INFINITI Q50	V37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
New zealand	INFINITI Q50	V37	2016.10-	Laser/radar	√	√	√	√	AC0994	
New zealand	INFINITI Q50	V37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
New zealand	INFINITI Q50	V37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
New zealand	INFINITI Q50	V37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
New zealand	INFINITI Q50	V37	2016.10-	Air bag	√	√	√	√		
New zealand	INFINITI Q50	V37	2016.10-	EPS/DAST 3	√	√	√	√		SP0507
New zealand	INFINITI Q50	V37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
New zealand	INFINITI Q50	V37	2016.10-	Motor control	√	√	√	√		
New zealand	INFINITI Q50	V37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
New zealand	INFINITI Q50	V37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
New zealand	INFINITI Q50	V37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
New zealand	INFINITI Q50	V37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
New zealand	INFINITI Q50	V37	2016.10-	Pop up hood	√	√	√	√		

XTOOL

New zealand	INFINITI Q50	V37	2016.10-	Multi AV	√	√	√	√		SP0503
New zealand	INFINITI Q50	V37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
New zealand	INFINITI Q50	V37	2016.10-	HV battery	√	√	√	√	AC1121	
New zealand	INFINITI Q50	V37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
New zealand	INFINITI Q50	V37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
New zealand	INFINITI Q50	V37	2016.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
New zealand	INFINITI Q50	V37	2016.10-	Occupant detection			√	√		SP0584
New zealand	INFINITI Q50	V37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
New zealand	INFINITI Q50	V37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
New zealand	INFINITI Q50	V37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
New zealand	INFINITI Q50	V37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
New zealand	INFINITI Q50	V37	2016.10-	DAST 2	√	√	√	√		
New zealand	INFINITI Q50	V37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
New zealand	INFINITI Q50	V37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
New zealand	INFINITI Q50	V37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
New zealand	INFINITI Q50	V37	2016.10-	CAN gateway	√	√	√			
New zealand	INFINITI Q50	V37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
New zealand	INFINITI Q50	V37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
New zealand	INFINITI Q50	V37	2016.10-	DAST 1	√	√	√	√		
New zealand	INFINITI Q50	V37	2016.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
New zealand	INFINITI Q50	V37	2016.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
New zealand	INFINITI Q50	V37	2016.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
New zealand	INFINITI Q50	V37	2016.10-	ANC	√	√	√	√	AC1024	
New zealand	INFINITI Q50	V37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
New zealand	INFINITI Q50	V37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
New zealand	INFINITI Q50	V37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
New zealand	INFINITI Q50	V37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
New zealand	INFINITI Q50	V37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
New zealand	INFINITI Q50	V37	2016.10-	CAN monitor unit	√	√	√	√		
New zealand	INFINITI Q50	V37	2016.10-	Brake	√	√	√	√	AC1127	
New zealand	INFINITI Q50	V37	2016.10-	HDmap	√	√	√	√		
New zealand	INFINITI Q50	V37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
New zealand	INFINITI Q50	V37	2016.10-	3ch CAN GATEWAY	√	√	√	√		
New zealand	INFINITI Q50	V37	2016.10-	ICC/ADAS 2	√	√	√	√		
New zealand	INFINITI Q50	V37	2016.10-	FSCM	√	√	√	√	AC1109	
New zealand	INFINITI Q50	V37	2016.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Laser/radar	√	√	√	√	AC0994	
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Air bag	√	√	√	√		
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	EPS/DAST 3	√	√	√	√		
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Motor control	√	√	√	√		
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Transmission	√	√	√	√		SP0276
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Pop up hood	√	√	√	√		
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Multi AV	√	√	√	√		SP0503
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	HV battery	√	√	√	√	AC1121	
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Occupant detection			√	√		SP0584
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	All mode AWD/4WD	√	√	√	√	AC0956	
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	DAST 2	√	√	√	√		
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Precrash seatbelt	√	√	√	√		SP0612
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	DAST 1	√	√	√	√		

New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	ANC	√	√	√	√	AC1024	
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Side radar left	√	√	√	√	AC1025	SP0582
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	HIGH BEAM ASSIST	√	√	√	√		
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Side radar right	√	√	√	√	AC1026	SP0583
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	Brake	√	√	√	√	AC1127	
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	6ch CAN GATEWAY	√	√	√	√		
New zealand	INFINITI Q50 HYBRID	HV37	2017.8-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
New zealand	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
New zealand	INFINITI Q60	CV37	2016.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
New zealand	INFINITI Q60	CV37	2016.8-	Laser/radar	√	√	√	√	AC0994	
New zealand	INFINITI Q60	CV37	2016.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
New zealand	INFINITI Q60	CV37	2016.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
New zealand	INFINITI Q60	CV37	2016.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
New zealand	INFINITI Q60	CV37	2016.8-	Air bag	√	√	√	√		
New zealand	INFINITI Q60	CV37	2016.8-	EPS/DAST 3	√	√	√	√		
New zealand	INFINITI Q60	CV37	2016.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

New zealand	INFINITI Q60	CV37	2016.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
New zealand	INFINITI Q60	CV37	2016.8-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
New zealand	INFINITI Q60	CV37	2016.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
New zealand	INFINITI Q60	CV37	2016.8-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
New zealand	INFINITI Q60	CV37	2016.8-	Pop up hood	√	√	√	√		
New zealand	INFINITI Q60	CV37	2016.8-	Multi AV	√	√	√	√		SP0503
New zealand	INFINITI Q60	CV37	2016.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
New zealand	INFINITI Q60	CV37	2016.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
New zealand	INFINITI Q60	CV37	2016.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
New zealand	INFINITI Q60	CV37	2016.8-	Occupant detection			√	√		SP0584
New zealand	INFINITI Q60	CV37	2016.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
New zealand	INFINITI Q60	CV37	2016.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
New zealand	INFINITI Q60	CV37	2016.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
New zealand	INFINITI Q60	CV37	2016.8-	All mode AWD/4WD	√	√	√	√	AC0956	
New zealand	INFINITI Q60	CV37	2016.8-	DAST 2	√	√	√	√		
New zealand	INFINITI Q60	CV37	2016.8-	Precrash seatbelt	√	√	√	√		SP0612
New zealand	INFINITI Q60	CV37	2016.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
New zealand	INFINITI Q60	CV37	2016.8-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
New zealand	INFINITI Q60	CV37	2016.8-	CAN gateway	√	√	√			
New zealand	INFINITI Q60	CV37	2016.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
New zealand	INFINITI Q60	CV37	2016.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
New zealand	INFINITI Q60	CV37	2016.8-	DAST 1	√	√	√	√		
New zealand	INFINITI Q60	CV37	2016.8-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
New zealand	INFINITI Q60	CV37	2016.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
New zealand	INFINITI Q60	CV37	2016.8-	ANC	√	√	√	√	AC1024	
New zealand	INFINITI Q60	CV37	2016.8-	Side radar left	√	√	√	√	AC1025	SP0582
New zealand	INFINITI Q60	CV37	2016.8-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
New zealand	INFINITI Q60	CV37	2016.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
New zealand	INFINITI Q60	CV37	2016.8-	HIGH BEAM ASSIST	√	√	√	√		
New zealand	INFINITI Q60	CV37	2016.8-	Side radar right	√	√	√	√	AC1026	SP0583
New zealand	INFINITI Q60	CV37	2016.8-	Lane camera 2	√	√	√	√		
New zealand	INFINITI Q60	CV37	2016.8-	6ch CAN GATEWAY	√	√	√	√		
New zealand	INFINITI Q60	CV37	2016.8-	ICC/ADAS 2	√	√	√	√		
New zealand	INFINITI Q60	CV37	2016.8-	FSCM	√	√	√	√	AC1109	
New zealand	INFINITI QX60	L50	2014.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
New zealand	INFINITI QX60	L50	2014.9-	Laser/radar	√	√	√	√		
New zealand	INFINITI QX60	L50	2014.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
New zealand	INFINITI QX60	L50	2014.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
New zealand	INFINITI QX60	L50	2014.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
New zealand	INFINITI QX60	L50	2014.9-	Air bag	√	√	√	√		
New zealand	INFINITI QX60	L50	2014.9-	EPS/DAST 3	√	√	√	√		
New zealand	INFINITI QX60	L50	2014.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
New zealand	INFINITI QX60	L50	2014.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
New zealand	INFINITI QX60	L50	2014.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
New zealand	INFINITI QX60	L50	2014.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
New zealand	INFINITI QX60	L50	2014.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
New zealand	INFINITI QX60	L50	2014.9-	Multi AV	√	√	√	√		SP0503
New zealand	INFINITI QX60	L50	2014.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
New zealand	INFINITI QX60	L50	2014.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
New zealand	INFINITI QX60	L50	2014.9-	Auto back door	√	√	√	√		SP0611
New zealand	INFINITI QX60	L50	2014.9-	Occupant detection			√	√		SP0584
New zealand	INFINITI QX60	L50	2014.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
New zealand	INFINITI QX60	L50	2014.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
New zealand	INFINITI QX60	L50	2014.9-	All mode AWD/4WD	√	√	√	√	AC0956	
New zealand	INFINITI QX60	L50	2014.9-	Precrash seatbelt	√	√	√	√		SP0612
New zealand	INFINITI QX60	L50	2014.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
New zealand	INFINITI QX60	L50	2014.9-	CAN gateway	√	√	√			
New zealand	INFINITI QX60	L50	2014.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
New zealand	INFINITI QX60	L50	2014.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	

New zealand	INFINITI QX60	L50	2014.9-	Side radar left	√	√	√	√	AC1025	SP0582
New zealand	INFINITI QX60	L50	2014.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
New zealand	INFINITI QX60	L50	2014.9-	Side radar right	√	√	√	√	AC1026	SP0583
New zealand	INFINITI QX60	L50	2014.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
New zealand	INFINITI QX70	S51	2016.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
New zealand	INFINITI QX70	S51	2016.7-	Laser/radar	√	√	√	√	AC0994	
New zealand	INFINITI QX70	S51	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
New zealand	INFINITI QX70	S51	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
New zealand	INFINITI QX70	S51	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
New zealand	INFINITI QX70	S51	2016.7-	Air bag	√	√	√	√		
New zealand	INFINITI QX70	S51	2016.7-	EPS/DAST 3	√	√	√	√		SP0507
New zealand	INFINITI QX70	S51	2016.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
New zealand	INFINITI QX70	S51	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
New zealand	INFINITI QX70	S51	2016.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
New zealand	INFINITI QX70	S51	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
New zealand	INFINITI QX70	S51	2016.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
New zealand	INFINITI QX70	S51	2016.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
New zealand	INFINITI QX70	S51	2016.7-	Multi AV	√	√	√	√		SP0503
New zealand	INFINITI QX70	S51	2016.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
New zealand	INFINITI QX70	S51	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
New zealand	INFINITI QX70	S51	2016.7-	Auto back door	√	√	√	√		SP0611
New zealand	INFINITI QX70	S51	2016.7-	Occupant detection			√	√		SP0584
New zealand	INFINITI QX70	S51	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
New zealand	INFINITI QX70	S51	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
New zealand	INFINITI QX70	S51	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
New zealand	INFINITI QX70	S51	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
New zealand	INFINITI QX70	S51	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
New zealand	INFINITI QX70	S51	2016.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
New zealand	INFINITI QX70	S51	2016.7-	CAN gateway	√	√	√			
New zealand	INFINITI QX70	S51	2016.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
New zealand	INFINITI QX70	S51	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
New zealand	INFINITI QX70	S51	2016.7-	ANC	√	√	√	√		
New zealand	INFINITI QX70	S51	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
New zealand	INFINITI QX70	S51	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
New zealand	INFINITI QX70	S51	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
New zealand	INFINITI QX70	S51	2016.7-	ICC/ADAS 2	√	√	√	√		
New zealand	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
New zealand	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√	AC0994	
New zealand	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
New zealand	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
New zealand	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
New zealand	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
New zealand	INFINITI QX80	Z62	2016.9-	EPS/DAST 3	√	√	√	√		SP0507
New zealand	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
New zealand	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
New zealand	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
New zealand	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
New zealand	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
New zealand	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
New zealand	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
New zealand	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
New zealand	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
New zealand	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
New zealand	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
New zealand	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
New zealand	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
New zealand	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
New zealand	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
New zealand	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
New zealand	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
New zealand	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

New zealand	INFINITI QX80	Z62	2016.9-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
New zealand	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
New zealand	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
New zealand	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
New zealand	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
New zealand	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
New zealand	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
New zealand	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
New zealand	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
New zealand	INFINITI QX80	Z62	2016.9-	6ch CAN GATEWAY	√	√	√	√		
New zealand	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
New zealand	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Nicaragua	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nicaragua	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Nicaragua	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494

Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Nicaragua	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Nicaragua	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nicaragua	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Nicaragua	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Nicaragua	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nicaragua	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Nicaragua	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Nicaragua	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Nicaragua	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Nicaragua	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Nicaragua	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Nicaragua	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Nicaragua	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Nicaragua	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nicaragua	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Nicaragua	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Nicaragua	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Nicaragua	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Nicaragua	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Nicaragua	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Nicaragua	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Nicaragua	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Nicaragua	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Nicaragua	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Nicaragua	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Nicaragua	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Nicaragua	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Nicaragua	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Nicaragua	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Nicaragua	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nicaragua	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Nicaragua	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	

Nicaragua	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Nicaragua	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Nicaragua	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894、AC0895、AC0896、AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509、SP0510
Nicaragua	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492、SP0493
Nicaragua	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0876、AC0877、AC0884	SP0494
Nicaragua	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811、AC0812、AC0814、AC0815、AC0816、AC0817、AC0818、AC0819、AC0820、AC0821、AC0822、AC0823、AC0825、AC0831	
Nicaragua	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Nicaragua	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506、SP0507
Nicaragua	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349
Nicaragua	INFINITI Q45	F50	2001.8-	Motor control						
Nicaragua	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0104、AC0105、AC0106、AC0107、AC0108、AC0109、AC0110、AC0111、AC0112、AC0113、AC0114、AC0115、AC0116、AC0117、AC0118、AC0119、AC0120、AC0121、AC0122、AC0123、AC0124、AC0125、AC0126、AC0127、AC0128、AC0129、AC0131、AC0145、AC0146、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0225、AC0226、AC0229、AC0256、AC0282、AC0283、AC0284、AC0307、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0016、SP0017、SP0018、SP0032、SP0033、SP0038、SP0043、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0068、SP0074、SP0075、SP0076、SP0077、SP0078、SP0079、SP0080、SP0081、SP0085、SP0086、SP0087、SP0093、SP0094、SP0098、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0140、SP0143、SP0150、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Nicaragua	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398、AC0399、AC0417、AC0418、AC0419、AC0420、AC0421、AC0422、AC0423、AC0424、AC0460、AC0461、AC0462、AC0463、AC0464、AC0465、AC0466、AC0467、AC0468、AC0469、AC0470、AC0471、AC0472、AC0473、AC0474	SP0270、SP0271、SP0272、SP0273、SP0274、SP0275、SP0276、SP0278、SP0279、SP0280、SP0287、SP0288
Nicaragua	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586、AC0587、AC0588、AC0602、AC0603、AC0604、AC0605、AC0606、AC0607、AC0608、AC0609、AC0610、AC0613、AC0618、AC0626、AC0630、AC0653、AC0660、AC0663、AC0672、AC0678、AC0689、AC0690、AC0692、AC0695、AC0698、AC0702、AC0712、AC0719	SP0372、SP0381、SP0382、SP0385、SP0387、SP0388、SP0390、SP0391、SP0392、SP0393、SP0394、SP0397、SP0399、SP0402、SP0403、SP0419、SP0428、SP0429、SP0438、SP0450、SP0458、SP0469、SP0471
Nicaragua	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498、AC0507、AC0508、AC0509、AC0510、AC0511、AC0512、AC0513、AC0514、AC0515、AC0516、AC0517、AC0527、AC0528、AC0529、AC0530、AC0531、AC0532、AC0533、AC0534、AC0535、AC0536	SP0300、SP0301、SP0313、SP0315、SP0316、SP0317、SP0319
Nicaragua	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Nicaragua	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Nicaragua	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Nicaragua	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Nicaragua	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Nicaragua	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Nicaragua	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Nicaragua	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962、AC0963、AC0964、AC0966、AC0967、AC0968、AC0969、AC0970	SP0553、SP0554、SP0555、SP0556、SP0557、SP0558、SP0559
Nicaragua	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Nicaragua	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983、AC0984、AC0985、AC0986、AC0987、AC0988、AC0989、AC0990	SP0563、SP0564、SP0565、SP0566、SP0567
Nicaragua	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903、AC0904、AC0905、AC0906、AC0907、AC0908、AC0909、AC0910、AC0911、AC0912、AC0913、AC0914、AC0915、AC0916、AC0917、AC0918、AC0919、AC0920、AC0921、AC0922、AC0923、AC0924、AC0925、AC0926、AC0927、AC0928、AC0929、AC0930、AC0931、AC0932	SP0511、SP0512、SP0517、SP0518、SP0519、SP0520、SP0521、SP0522、SP0523、SP0524、SP0525、SP0526、SP0527、SP0528、SP0529、SP0530、SP0531、SP0532、SP0533、SP0534、SP0535、SP0536、SP0537
Nicaragua	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971、AC0972、AC0973	
Nicaragua	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nicaragua	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Nicaragua	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Nicaragua	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Nicaragua	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Nicaragua	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Nicaragua	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Nicaragua	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Nicaragua	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572、SP0573
Nicaragua	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991、AC0992、AC0993	
Nicaragua	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Nicaragua	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570、SP0571
Nicaragua	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Nicaragua	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894、AC0895、AC0896	SP0510
Nicaragua	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Nicaragua	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867、AC0868、AC0869、AC0870、AC0871、AC0872、AC0873、AC0874、AC0875、AC0878、AC0879、AC0880、AC0881、AC0882、AC0883、AC0884、AC0885	SP0495、SP0496、SP0497
Nicaragua	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811、AC0812、AC0814、AC0815、AC0816、AC0817、AC0818、AC0819、AC0820、AC0821、AC0822、AC0823、AC0825、AC0831	
Nicaragua	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Nicaragua	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347、SP0348、SP0349、SP0350、SP0351
Nicaragua	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0282、AC0283、AC0307、AC0351、AC0352、AC0365、AC0366、AC0369、AC0371、AC0372、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0016、SP0017、SP0018、SP0032、SP0033、SP0043、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0237、SP0238、SP0239
Nicaragua	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270、SP0274
Nicaragua	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613、AC0618、AC0663、AC0690、AC0692、AC0702	SP0372、SP0429、SP0471
Nicaragua	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509、AC0510、AC0514、AC0515、AC0528、AC0529、AC0531、AC0532、AC0533、AC0536	SP0313、SP0315
Nicaragua	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Nicaragua	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808、AC0809	SP0472、SP0473、SP0474、SP0475、SP0477、SP0478、SP0483、SP0484、SP0485、SP0486、SP0487、SP0488
Nicaragua	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031、AC1032、AC1033	SP0585、SP0586、SP0587
Nicaragua	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946、AC0947、AC0948、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Nicaragua	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Nicaragua	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Nicaragua	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980	SP0561、SP0562
Nicaragua	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Nicaragua	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962、AC0963、AC0964	SP0553、SP0554、SP0556
Nicaragua	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544、SP0545、SP0546、SP0547、SP0548、SP0549
Nicaragua	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985、AC0986、AC0987、AC0988、AC0989	SP0563、SP0564、SP0565、SP0566、SP0567
Nicaragua	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Nicaragua	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973、AC0974、AC0976、AC0977	
Nicaragua	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Nicaragua	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590、SP0591、SP0592
Nicaragua	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Niger	INFINITI EX35/EX37	I50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI EX35/EX37	I50	2011.1-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0876、AC0877、AC0884	SP0494
Niger	INFINITI EX35/EX37	I50	2011.1-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Niger	INFINITI EX35/EX37	I50	2011.1-	Air bag	√	√	√	√		
Niger	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350
Niger	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004、AC0005、AC0006、AC0007、AC0008、AC0009、AC0034、AC0035、AC0036、AC0037、AC0038、AC0039、AC0040、AC0041、AC0042、AC0049、AC0051、AC0052、AC0053、AC0054、AC0060、AC0061、AC0062、AC0063、AC0065、AC0066、AC0067、AC0068、AC0069、AC0070、AC0131、AC0147、AC0148、AC0149、AC0150、AC0151、AC0152、AC0153、AC0154、AC0155、AC0156、AC0157、AC0158、AC0159、AC0160、AC0161、AC0162、AC0163、AC0164、AC0165、AC0166、AC0167、AC0168、AC0169、AC0170、AC0171、AC0172、AC0173、AC0174、AC0175、AC0176、AC0177、AC0178、AC0179、AC0180、AC0181、AC0182、AC0183、AC0184、AC0185、AC0186、AC0187、AC0188、AC0189、AC0190、AC0191、AC0192、AC0193、AC0194、AC0195、AC0196、AC0197、AC0198、AC0199、AC0200、AC0282、AC0283、AC0307、AC0333、AC0334、AC0335、AC0336、AC0337、AC0338、AC0339、AC0351、AC0352、AC0365、AC0366、AC0367、AC0369、AC0371、AC0372、AC0373、AC0375、AC0388、AC0389、AC0390、AC0391、AC0392、AC0393、AC0394	SP0001、SP0002、SP0003、SP0004、SP0005、SP0006、SP0007、SP0016、SP0017、SP0018、SP0032、SP0033、SP0043、SP0045、SP0051、SP0053、SP0056、SP0057、SP0058、SP0059、SP0060、SP0061、SP0062、SP0063、SP0064、SP0067、SP0074、SP0078、SP0079、SP0080、SP0081、SP0083、SP0085、SP0086、SP0087、SP0100、SP0103、SP0104、SP0105、SP0109、SP0110、SP0111、SP0112、SP0113、SP0114、SP0115、SP0116、SP0152、SP0153、SP0158、SP0159、SP0160、SP0172、SP0173、SP0191、SP0192、SP0196、SP0197、SP0198、SP0199、SP0200、SP0212、SP0213、SP0216、SP0217、SP0218、SP0219、SP0221、SP0223、SP0225、SP0237、SP0238、SP0239
Niger	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270、SP0274
Niger	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613、AC0618、AC0663、AC0692、AC0702、AC0719	SP0372、SP0429
Niger	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498、AC0507、AC0508、AC0509、AC0510、AC0511、AC0512、AC0513、AC0514、AC0515、AC0516、AC0517、AC0527、AC0528、AC0529、AC0530、AC0531、AC0532、AC0533、AC0534、AC0535	SP0301、SP0313、SP0315、SP0316、SP0317、SP0319
Niger	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945、AC0946、AC0947、AC0948、AC0949、AC0950、AC0951、AC0952、AC0953、AC0954、AC0955	SP0541、SP0542、SP0543
Niger	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980	SP0561、SP0562
Niger	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Niger	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962、AC0963、AC0964	SP0553、SP0554、SP0555、SP0556
Niger	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Niger	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Niger	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973、AC0974、AC0975、AC0976	SP0560
Niger	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Niger	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Niger	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894、AC0895、AC0896	SP0510
Niger	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865、AC0866、AC0867、AC0868、AC0876、AC0877、AC0884	SP0494
Niger	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811、AC0815、AC0816、AC0817、AC0818、AC0819、AC0821、AC0822、AC0825、AC0831	
Niger	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Niger	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347、SP0348、SP0349、SP0350

Niger	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Niger	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Niger	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Niger	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Niger	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Niger	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Niger	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Niger	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Niger	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Niger	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Niger	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Niger	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Niger	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Niger	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Niger	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Niger	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Niger	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Niger	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Niger	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Niger	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Niger	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Niger	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Niger	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Niger	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Niger	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Niger	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Niger	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Niger	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Niger	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Niger	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

XTOOL

Niger	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Niger	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Niger	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Niger	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Niger	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Niger	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Niger	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Niger	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Niger	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Niger	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Niger	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Niger	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Niger	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Niger	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Niger	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Niger	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Niger	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Niger	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Niger	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Niger	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Niger	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Niger	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Niger	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Niger	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Niger	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Niger	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Niger	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Niger	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Niger	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Niger	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Niger	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Niger	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546,AC0547,AC0548,AC0549	SP0342,SP0343,SP0344
Niger	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002,AC0103,AC0214,AC0264,AC0265,AC0266,AC0267,AC0268,AC0269,AC0270,AC0271,AC0272,AC0273,AC0274,AC0275,AC0276,AC0277,AC0308,AC0310,AC0311,AC0312,AC0314,AC0315,AC0317,AC0320,AC0325,AC0327,AC0328,AC0329,AC0330,AC0331,AC0332	SP0034,SP0035,SP0159,SP0193,SP0194
Niger	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580,AC0674,AC0739,AC0740,AC0741,AC0742,AC0743,AC0744,AC0745,AC0746,AC0747,AC0748,AC0749,AC0750,AC0751,AC0752,AC0753,AC0754,AC0755,AC0756,AC0757,AC0758,AC0759,AC0760,AC0761,AC0762,AC0763,AC0764,AC0765,AC0766,AC0767,AC0768,AC0769,AC0770	
Niger	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Niger	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Niger	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Niger	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143,AC1144,AC1145,AC1146,AC1147,AC1148,AC1149,AC1150,AC1151,AC1152,AC1153,AC1154,AC1155,AC1156	
Niger	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Niger	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Niger	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Niger	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171,AC1172,AC1173,AC1174,AC1175	
Niger	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157,AC1158,AC1159,AC1160,AC1161,AC1162,AC1163,AC1164,AC1165,AC1166,AC1167,AC1168,AC1169,AC1170	SP0622
Niger	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Niger	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Niger	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Niger	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Niger	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Niger	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Niger	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Niger	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Niger	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Niger	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Niger	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Niger	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Niger	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Niger	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Niger	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Niger	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Niger	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Niger	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Niger	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0274
Niger	INFINITI Q50	V37	2013.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Niger	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
Niger	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Niger	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503

Niger	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Niger	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Niger	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Niger	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Niger	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Niger	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Niger	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Niger	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Niger	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Niger	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Niger	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Niger	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Niger	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Niger	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Niger	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Niger	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Niger	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Niger	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Niger	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Niger	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Niger	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Niger	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Niger	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Niger	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Niger	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Niger	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Niger	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Niger	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Niger	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Niger	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Niger	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Niger	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Niger	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Niger	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Niger	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Niger	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Niger	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Niger	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Niger	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Niger	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Niger	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Niger	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Niger	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Niger	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Niger	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Niger	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Niger	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Niger	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Niger	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Niger	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Niger	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Niger	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Niger	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Niger	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Niger	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Niger	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Niger	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Niger	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Niger	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Niger	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Niger	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Niger	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Niger	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	

Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Niger	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Niger	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Niger	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Niger	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Niger	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Niger	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Niger	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Niger	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Niger	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Niger	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Niger	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Niger	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Niger	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Niger	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Niger	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Niger	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Niger	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Niger	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Niger	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Niger	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Niger	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Niger	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Niger	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Niger	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Niger	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Niger	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Niger	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Niger	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Niger	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Niger	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Niger	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Niger	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Niger	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Niger	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Niger	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Niger	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Niger	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Niger	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Niger	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Niger	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Niger	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Niger	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Niger	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Niger	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Niger	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Niger	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Niger	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Niger	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Niger	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Niger	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Niger	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Niger	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Niger	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Niger	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

Niger	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Niger	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Niger	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Niger	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Niger	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Niger	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Niger	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Niger	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Niger	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Niger	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Niger	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Niger	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Niger	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Niger	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Niger	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Niger	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Niger	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Niger	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Niger	INFINITI QX50	I50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Niger	INFINITI QX50	I50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Niger	INFINITI QX50	I50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Niger	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Niger	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Niger	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Niger	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Niger	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Niger	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Niger	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Niger	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Niger	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Niger	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Niger	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Niger	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Niger	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Niger	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Niger	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Niger	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Niger	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Niger	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Niger	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Niger	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Niger	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Niger	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Niger	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Niger	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Niger	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Niger	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Niger	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Niger	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Niger	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Niger	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Niger	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Niger	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Niger	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Niger	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Niger	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Niger	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Niger	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Niger	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Niger	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Niger	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Niger	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Niger	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Niger	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Niger	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Niger	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Niger	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031,AC1032,AC1033	SP0585, SP0586, SP0587
Niger	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Niger	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Niger	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Niger	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Niger	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Niger	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Niger	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Niger	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Niger	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Niger	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Niger	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Niger	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Niger	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Niger	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Niger	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Niger	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Niger	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Niger	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Niger	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Niger	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Nigeria	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Nigeria	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Nigeria	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Nigeria	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Nigeria	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Nigeria	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nigeria	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Nigeria	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nigeria	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Nigeria	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nigeria	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Nigeria	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Nigeria	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Nigeria	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Nigeria	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Nigeria	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Nigeria	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nigeria	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nigeria	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Nigeria	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Nigeria	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nigeria	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Nigeria	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

XTOOL

Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Nigeria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Nigeria	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nigeria	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Nigeria	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Nigeria	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Nigeria	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Nigeria	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Nigeria	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Nigeria	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Nigeria	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Nigeria	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Nigeria	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Nigeria	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Nigeria	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Nigeria	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Nigeria	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Nigeria	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nigeria	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Nigeria	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nigeria	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Nigeria	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Nigeria	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Nigeria	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Nigeria	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nigeria	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Nigeria	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Nigeria	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Nigeria	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Nigeria	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Nigeria	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Nigeria	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Nigeria	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Nigeria	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Nigeria	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Nigeria	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Nigeria	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Nigeria	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Nigeria	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Nigeria	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Nigeria	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Nigeria	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Nigeria	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Nigeria	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Nigeria	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Nigeria	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Nigeria	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Nigeria	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Nigeria	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		

Nigeria	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Nigeria	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Nigeria	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Nigeria	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Nigeria	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Nigeria	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Nigeria	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Nigeria	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Nigeria	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nigeria	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Nigeria	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Nigeria	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Nigeria	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Nigeria	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Nigeria	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Nigeria	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Nigeria	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Nigeria	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Nigeria	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Nigeria	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Nigeria	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Nigeria	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Nigeria	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Nigeria	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Nigeria	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Nigeria	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nigeria	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Nigeria	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Nigeria	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Nigeria	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Nigeria	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Nigeria	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Nigeria	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Nigeria	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Nigeria	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Nigeria	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Nigeria	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Nigeria	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Nigeria	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Nigeria	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Nigeria	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Nigeria	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Nigeria	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Nigeria	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Nigeria	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nigeria	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274

Nigeria	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Nigeria	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Nigeria	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Nigeria	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Nigeria	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Nigeria	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Nigeria	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Nigeria	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Nigeria	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Nigeria	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Nigeria	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Nigeria	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Nigeria	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Nigeria	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Nigeria	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Nigeria	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nigeria	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Nigeria	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Nigeria	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Nigeria	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Nigeria	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Nigeria	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Nigeria	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Nigeria	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Nigeria	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Nigeria	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Nigeria	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Nigeria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Nigeria	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nigeria	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Nigeria	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Nigeria	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Nigeria	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Nigeria	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Nigeria	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Xtool

Nigeria	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Nigeria	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Nigeria	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Nigeria	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Nigeria	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Nigeria	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Nigeria	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Nigeria	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Nigeria	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Nigeria	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Nigeria	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Nigeria	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Nigeria	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Nigeria	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Nigeria	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Nigeria	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Nigeria	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nigeria	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Nigeria	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Nigeria	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Nigeria	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Nigeria	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Nigeria	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Nigeria	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Nigeria	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Nigeria	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Nigeria	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Nigeria	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Nigeria	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Nigeria	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nigeria	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Nigeria	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nigeria	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Nigeria	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Nigeria	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Nigeria	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Nigeria	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Nigeria	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Nigeria	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Nigeria	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Nigeria	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Nigeria	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Nigeria	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Nigeria	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Nigeria	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Nigeria	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Nigeria	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Nigeria	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Nigeria	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Nigeria	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Nigeria	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Nigeria	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Nigeria	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Nigeria	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Nigeria	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Nigeria	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Nigeria	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Nigeria	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Nigeria	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Nigeria	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Nigeria	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Nigeria	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Nigeria	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Nigeria	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Nigeria	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Nigeria	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Nigeria	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Nigeria	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Nigeria	INFINITI QX70	S51	2013.7-	ANC	√	√	√			
Nigeria	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Nigeria	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Nigeria	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Nigeria	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Nigeria	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Nigeria	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Nigeria	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Nigeria	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Nigeria	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Nigeria	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Nigeria	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Nigeria	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Nigeria	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Nigeria	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Nigeria	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Nigeria	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Nigeria	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Nigeria	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Nigeria	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Nigeria	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Nigeria	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Nigeria	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Nigeria	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Nigeria	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Nigeria	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Nigeria	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Nigeria	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Nigeria	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Nigeria	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Nigeria	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Nigeria	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Nigeria	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Nigeria	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Nigeria	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Nigeria	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Nigeria	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Nigeria	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Nigeria	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
North america common	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Air bag	√	√	√	√		
North america common	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	
North america common	INFINITI EX35	J50	2008.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI EX35	J50	2008.NULL-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI EX35	J50	2008.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI EX35	J50	2008.NULL-	Air bag	√	√	√	√		
North america common	INFINITI EX35	J50	2008.NULL-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
North america common	INFINITI EX35	J50	2008.NULL-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
North america common	INFINITI EX35	J50	2008.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
North america common	INFINITI EX35	J50	2008.NULL-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
North america common	INFINITI EX35	J50	2008.NULL-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI EX35	J50	2008.NULL-	Multi AV	√	√	√	√		SP0503
North america common	INFINITI EX35	J50	2008.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI EX35	J50	2008.NULL-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI EX35	J50	2008.NULL-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI EX35	J50	2008.NULL-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
North america common	INFINITI EX35	J50	2008.NULL-	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI EX35	J50	2008.NULL-	CAN gateway	√	√	√			
North america common	INFINITI EX35	J50	2008.NULL-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
North america common	INFINITI EX35	J50	2008.NULL-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
North america common	INFINITI EX35	J50	2008.NULL-	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI EX35	J50	2008.NULL-	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI EX35	J50	2008.NULL-	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI FX35/FX45	S50	2003.NULL-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
North america common	INFINITI FX35/FX45	S50	2003.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
North america common	INFINITI FX35/FX45	S50	2003.NULL-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI FX35/FX45	S50	2003.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
North america common	INFINITI FX35/FX45	S50	2003.NULL-	Air bag	√	√	√	√		
North america common	INFINITI FX35/FX45	S50	2003.NULL-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
North america common	INFINITI FX35/FX45	S50	2003.NULL-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
North america common	INFINITI FX35/FX45	S50	2003.NULL-	Motor control						

North america common	INFINITI FX35/FX45	S50	2003.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI FX35/FX45	S50	2003.NULL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
North america common	INFINITI FX35/FX45	S50	2003.NULL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
North america common	INFINITI FX35/FX45	S50	2003.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI FX35/FX45	S50	2003.NULL	Multi AV	√	√	√	√		SP0503
North america common	INFINITI FX35/FX45	S50	2003.NULL	HVAC	√	√	√	√		
North america common	INFINITI FX35/FX45	S50	2003.NULL	Difference lock	√	√	√	√		
North america common	INFINITI FX35/FX45	S50	2003.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI FX35/FX45	S50	2003.NULL	Auto slide door	√	√	√	√	AC0941	
North america common	INFINITI FX35/FX45	S50	2003.NULL	DIU		√	√	√		
North america common	INFINITI FX35/FX45	S50	2003.NULL	Adaptive light	√	√	√	√		
North america common	INFINITI FX35/FX45	S50	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI FX35/FX45	S50	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
North america common	INFINITI FX35/FX45	S50	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI FX35/FX45	S50	2003.NULL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
North america common	INFINITI FX35/FX45	S50	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
North america common	INFINITI FX35/FX45	S50	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI FX35/FX45	S50	2003.NULL	IVMS	√	√		√		
North america common	INFINITI FX35/FX45	S50	2003.NULL	Distance control	√	√		√		
North america common	INFINITI FX35/FX45	S50	2003.NULL	Active suspense system	√	√	√	√		
North america common	INFINITI FX35/FX45	S50	2003.NULL	Motor assist		√	√	√		SP0574
North america common	INFINITI FX35/FX45	S50	2003.NULL	ASCD	√	√	√	√		
North america common	INFINITI FX35/FX45	S50	2003.NULL	Active engine mount	√	√	√	√		
North america common	INFINITI FX35/FX45	S50	2003.NULL	TCS	√	√	√	√		
North america common	INFINITI FX35/FX45	S50	2003.NULL	S/blind camera	√			√		SP0572, SP0573
North america common	INFINITI FX35/FX45	S50	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
North america common	INFINITI FX35/FX45	S50	2003.NULL	Nats immu	√	√	√			
North america common	INFINITI FX35/FX45	S50	2003.NULL	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI FX35/FX45	S50	2003.NULL	Smart entrance						SP0568
North america common	INFINITI FX35/FX50	S51	2009.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
North america common	INFINITI FX35/FX50	S51	2009.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI FX35/FX50	S51	2009.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
North america common	INFINITI FX35/FX50	S51	2009.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI FX35/FX50	S51	2009.NULL	Air bag	√	√	√	√		
North america common	INFINITI FX35/FX50	S51	2009.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
North america common	INFINITI FX35/FX50	S51	2009.NULL	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0045, SP0051, SP0053, SP0063, SP0064, SP0074, SP0079, SP0083, SP0085, SP0086, SP0087, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0225, SP0239
North america common	INFINITI FX35/FX50	S51	2009.NULL	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
North america common	INFINITI FX35/FX50	S51	2009.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
North america common	INFINITI FX35/FX50	S51	2009.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
North america common	INFINITI FX35/FX50	S51	2009.NULL	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
North america common	INFINITI FX35/FX50	S51	2009.NULL	Multi AV	√	√	√	√		SP0503
North america common	INFINITI FX35/FX50	S51	2009.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	

XTOOL

North america common	INFINITI FX35/FX50	S51	2009.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI FX35/FX50	S51	2009.NULL –	Auto back door	√	√	√	√		SP0611
North america common	INFINITI FX35/FX50	S51	2009.NULL –	Occupant detection			√	√		SP0584
North america common	INFINITI FX35/FX50	S51	2009.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI FX35/FX50	S51	2009.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI FX35/FX50	S51	2009.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
North america common	INFINITI FX35/FX50	S51	2009.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI FX35/FX50	S51	2009.NULL –	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI FX35/FX50	S51	2009.NULL –	CAN gateway	√	√	√			
North america common	INFINITI FX35/FX50	S51	2009.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
North america common	INFINITI FX35/FX50	S51	2009.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI FX35/FX50	S51	2009.NULL –	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
North america common	INFINITI FX37/FX50	S51	2013.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
North america common	INFINITI FX37/FX50	S51	2013.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Air bag	√	√	√	√		
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Transmission	√	√	√	√		SP0274
North america common	INFINITI FX37/FX50	S51	2013.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
North america common	INFINITI FX37/FX50	S51	2013.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI FX37/FX50	S51	2013.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Auto back door	√	√	√	√		SP0611
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Occupant detection			√	√		SP0584
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
North america common	INFINITI FX37/FX50	S51	2013.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI FX37/FX50	S51	2013.NULL –	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI FX37/FX50	S51	2013.NULL –	CAN gateway	√	√	√			
North america common	INFINITI FX37/FX50	S51	2013.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
North america common	INFINITI FX37/FX50	S51	2013.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI G20	CA33	2002.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
North america common	INFINITI G20	CA33	2002.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
North america common	INFINITI G20	CA33	2002.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI G20	CA33	2002.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
North america common	INFINITI G20	CA33	2002.NULL –	Air bag	√	√	√	√		
North america common	INFINITI G20	CA33	2002.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
North america common	INFINITI G20	CA33	2002.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
North america common	INFINITI G20	CA33	2002.NULL –	Motor control						

XTOOL

North america common	INFINITI G20	CA33	2002.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI G20	CA33	2002.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
North america common	INFINITI G20	CA33	2002.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
North america common	INFINITI G20	CA33	2002.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI G20	CA33	2002.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI G20	CA33	2002.NULL –	HVAC	√	√	√	√		
North america common	INFINITI G20	CA33	2002.NULL –	Difference lock	√	√	√	√		
North america common	INFINITI G20	CA33	2002.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI G20	CA33	2002.NULL –	Auto slide door	√	√	√	√	AC0941	
North america common	INFINITI G20	CA33	2002.NULL –	DIU		√	√	√		
North america common	INFINITI G20	CA33	2002.NULL –	Adaptive light	√	√	√	√		
North america common	INFINITI G20	CA33	2002.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI G20	CA33	2002.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
North america common	INFINITI G20	CA33	2002.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI G20	CA33	2002.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
North america common	INFINITI G20	CA33	2002.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
North america common	INFINITI G20	CA33	2002.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI G20	CA33	2002.NULL –	IVMS	√	√		√		
North america common	INFINITI G20	CA33	2002.NULL –	Distance control	√	√		√		
North america common	INFINITI G20	CA33	2002.NULL –	Active suspense system	√	√	√	√		
North america common	INFINITI G20	CA33	2002.NULL –	Motor assist		√	√	√		SP0574
North america common	INFINITI G20	CA33	2002.NULL –	ASCD	√	√	√	√		
North america common	INFINITI G20	CA33	2002.NULL –	Active engine mount	√	√	√	√		
North america common	INFINITI G20	CA33	2002.NULL –	TCS	√	√	√	√		
North america common	INFINITI G20	CA33	2002.NULL –	S/blind camera	√			√		SP0572, SP0573
North america common	INFINITI G20	CA33	2002.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
North america common	INFINITI G20	CA33	2002.NULL –	Nats immu	√	√	√			
North america common	INFINITI G20	CA33	2002.NULL –	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI G20	CA33	2002.NULL –	Smart entrance						SP0568
North america common	INFINITI G20	P11	1999.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
North america common	INFINITI G20	P11	1999.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
North america common	INFINITI G20	P11	1999.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI G20	P11	1999.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
North america common	INFINITI G20	P11	1999.NULL –	Air bag	√	√	√	√		
North america common	INFINITI G20	P11	1999.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
North america common	INFINITI G20	P11	1999.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
North america common	INFINITI G20	P11	1999.NULL –	Motor control						
North america common	INFINITI G20	P11	1999.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI G20	P11	1999.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
North america common	INFINITI G20	P11	1999.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471

XTOOL

North america common	INFINITI G20	P11	1999.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI G20	P11	1999.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI G20	P11	1999.NULL –	HVAC	√	√	√	√		
North america common	INFINITI G20	P11	1999.NULL –	Difference lock	√	√	√	√		
North america common	INFINITI G20	P11	1999.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI G20	P11	1999.NULL –	Auto slide door	√	√	√	√	AC0941	
North america common	INFINITI G20	P11	1999.NULL –	DIU		√	√	√		
North america common	INFINITI G20	P11	1999.NULL –	Adaptive light	√	√	√	√		
North america common	INFINITI G20	P11	1999.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI G20	P11	1999.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
North america common	INFINITI G20	P11	1999.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI G20	P11	1999.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
North america common	INFINITI G20	P11	1999.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
North america common	INFINITI G20	P11	1999.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI G20	P11	1999.NULL –	IVMS	√	√		√		
North america common	INFINITI G20	P11	1999.NULL –	Distance control	√	√		√		
North america common	INFINITI G20	P11	1999.NULL –	Active suspense system	√	√	√	√		
North america common	INFINITI G20	P11	1999.NULL –	Motor assist		√	√	√		SP0574
North america common	INFINITI G20	P11	1999.NULL –	ASCD	√	√	√	√		
North america common	INFINITI G20	P11	1999.NULL –	Active engine mount	√	√	√	√		
North america common	INFINITI G20	P11	1999.NULL –	TCS	√	√	√	√		
North america common	INFINITI G20	P11	1999.NULL –	S/blind camera	√			√		SP0572, SP0573
North america common	INFINITI G20	P11	1999.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
North america common	INFINITI G20	P11	1999.NULL –	Nats immu	√	√	√			
North america common	INFINITI G20	P11	1999.NULL –	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI G20	P11	1999.NULL –	Smart entrance						SP0568
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Air bag	√	√	√	√		
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Transmission	√	√	√	√		SP0274
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Pop up hood	√	√	√	√		
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Precrash seatbelt	√	√	√	√		
North america common	INFINITI G25/G37 SEDAN	V36	2011.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510

XTOOL

North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Air bag	√	√	√	√		
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Motor control						
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	HVAC	√	√	√	√		
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Difference lock	√	√	√	√		
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Auto slide door	√	√	√	√	AC0941	
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	DIU		√	√	√		
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Adaptive light	√	√	√	√		
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	IVMS	√	√		√		
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Distance control	√	√		√		
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Active suspense system	√	√	√	√		
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Motor assist		√	√	√		SP0574
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	ASCD	√	√	√	√		
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Active engine mount	√	√	√	√		
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	TCS	√	√	√	√		
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	S/blind camera	√			√		SP0572, SP0573
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Nats immu	√	√	√			
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI G35 COUPE	CV35	2003.NULL –	Smart entrance						SP0568
North america common	INFINITI G35 SEDAN	V35	2003.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
North america common	INFINITI G35 SEDAN	V35	2003.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
North america common	INFINITI G35 SEDAN	V35	2003.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI G35 SEDAN	V35	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
North america common	INFINITI G35 SEDAN	V35	2003.NULL –	Air bag	√	√	√	√		
North america common	INFINITI G35 SEDAN	V35	2003.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
North america common	INFINITI G35 SEDAN	V35	2003.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
North america common	INFINITI G35 SEDAN	V35	2003.NULL –	Motor control						

North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Multi AV	√	√	√	√		SP0503
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	HVAC	√	√	√	√		
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Difference lock	√	√	√	√		
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Auto slide door	√	√	√	√	AC0941	
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	DIU		√	√	√		
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Adaptive light	√	√	√	√		
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	IVMS	√	√		√		
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Distance control	√	√		√		
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Active suspense system	√	√	√	√		
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Motor assist		√	√	√		SP0574
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	ASCD	√	√	√	√		
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Active engine mount	√	√	√	√		
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	TCS	√	√	√	√		
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	S/blind camera	√			√		SP0572, SP0573
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Nats immu	√	√	√			
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI G35 SEDAN	V35	2003.NULL-	Smart entrance						SP0568
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	Air bag	√	√	√	√		
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	Multi AV	√	√	√	√		
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	4WAS(front)	√	√	√	√	AC1027, AC1028	
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI G35 SEDAN	V36	2007.NULL-	All mode AWD/4WD	√	√	√	√	AC0957	

XTOOL

North america common	INFINITI G35 SEDAN	V36	2007.NULL –	Precrash seatbelt	√	√	√	√		
North america common	INFINITI G35 SEDAN	V36	2007.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Air bag	√	√	√	√		
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Pop up hood	√	√	√	√		
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Precrash seatbelt	√	√	√	√		
North america common	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	Air bag	√	√	√	√		
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	Pop up hood	√	√	√	√		
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	Precrash seatbelt	√	√	√	√		
North america common	INFINITI G37 COUPE	CV36	2008.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	Air bag	√	√	√	√		
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

North america common	INFINITI G37 SEDAN	V36	2009.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	Precrash seatbelt	√	√	√	√		
North america common	INFINITI G37 SEDAN	V36	2009.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI I30	CA32	1996.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
North america common	INFINITI I30	CA32	1996.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
North america common	INFINITI I30	CA32	1996.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI I30	CA32	1996.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
North america common	INFINITI I30	CA32	1996.NULL –	Air bag	√	√	√	√		
North america common	INFINITI I30	CA32	1996.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
North america common	INFINITI I30	CA32	1996.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
North america common	INFINITI I30	CA32	1996.NULL –	Motor control						
North america common	INFINITI I30	CA32	1996.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI I30	CA32	1996.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
North america common	INFINITI I30	CA32	1996.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
North america common	INFINITI I30	CA32	1996.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI I30	CA32	1996.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI I30	CA32	1996.NULL –	HVAC	√	√	√	√		
North america common	INFINITI I30	CA32	1996.NULL –	Difference lock	√	√	√	√		
North america common	INFINITI I30	CA32	1996.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI I30	CA32	1996.NULL –	Auto slide door	√	√	√	√	AC0941	
North america common	INFINITI I30	CA32	1996.NULL –	DIU		√	√	√		
North america common	INFINITI I30	CA32	1996.NULL –	Adaptive light	√	√	√	√		
North america common	INFINITI I30	CA32	1996.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI I30	CA32	1996.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
North america common	INFINITI I30	CA32	1996.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI I30	CA32	1996.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
North america common	INFINITI I30	CA32	1996.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
North america common	INFINITI I30	CA32	1996.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI I30	CA32	1996.NULL –	IVMS	√	√		√		
North america common	INFINITI I30	CA32	1996.NULL –	Distance control	√	√		√		
North america common	INFINITI I30	CA32	1996.NULL –	Active suspense system	√	√	√	√		
North america common	INFINITI I30	CA32	1996.NULL –	Motor assist		√	√	√		SP0574
North america common	INFINITI I30	CA32	1996.NULL –	ASCD	√	√	√	√		
North america common	INFINITI I30	CA32	1996.NULL –	Active engine mount	√	√	√	√		

North america common	INFINITI I30	CA32	1996.NULL –	TCS	√	√	√	√		
North america common	INFINITI I30	CA32	1996.NULL –	S/blind camera	√			√		SP0572, SP0573
North america common	INFINITI I30	CA32	1996.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
North america common	INFINITI I30	CA32	1996.NULL –	Nats immu	√	√	√			
North america common	INFINITI I30	CA32	1996.NULL –	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI I30	CA32	1996.NULL –	Smart entrance						SP0568
North america common	INFINITI I35	CA33	2002.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
North america common	INFINITI I35	CA33	2002.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
North america common	INFINITI I35	CA33	2002.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI I35	CA33	2002.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
North america common	INFINITI I35	CA33	2002.NULL –	Air bag	√	√	√	√		
North america common	INFINITI I35	CA33	2002.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
North america common	INFINITI I35	CA33	2002.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
North america common	INFINITI I35	CA33	2002.NULL –	Motor control						
North america common	INFINITI I35	CA33	2002.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI I35	CA33	2002.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
North america common	INFINITI I35	CA33	2002.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
North america common	INFINITI I35	CA33	2002.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI I35	CA33	2002.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI I35	CA33	2002.NULL –	HVAC	√	√	√	√		
North america common	INFINITI I35	CA33	2002.NULL –	Difference lock	√	√	√	√		
North america common	INFINITI I35	CA33	2002.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI I35	CA33	2002.NULL –	Auto slide door	√	√	√	√	AC0941	
North america common	INFINITI I35	CA33	2002.NULL –	DIU		√	√	√		
North america common	INFINITI I35	CA33	2002.NULL –	Adaptive light	√	√	√	√		
North america common	INFINITI I35	CA33	2002.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI I35	CA33	2002.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
North america common	INFINITI I35	CA33	2002.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI I35	CA33	2002.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
North america common	INFINITI I35	CA33	2002.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
North america common	INFINITI I35	CA33	2002.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI I35	CA33	2002.NULL –	IVMS	√	√		√		
North america common	INFINITI I35	CA33	2002.NULL –	Distance control	√	√		√		
North america common	INFINITI I35	CA33	2002.NULL –	Active suspense system	√	√	√	√		
North america common	INFINITI I35	CA33	2002.NULL –	Motor assist		√	√	√		SP0574
North america common	INFINITI I35	CA33	2002.NULL –	ASCD	√	√	√	√		
North america common	INFINITI I35	CA33	2002.NULL –	Active engine mount	√	√	√	√		
North america common	INFINITI I35	CA33	2002.NULL –	TCS	√	√	√	√		
North america common	INFINITI I35	CA33	2002.NULL –	S/blind camera	√			√		SP0572, SP0573
North america common	INFINITI I35	CA33	2002.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
North america common	INFINITI I35	CA33	2002.NULL –	Nats immu	√	√	√			
North america common	INFINITI I35	CA33	2002.NULL –	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI I35	CA33	2002.NULL –	Smart entrance						SP0568
North america common	INFINITI JX35	L50	2013.NULL –	Laser/radar	√	√	√	√		

XTOOL

North america common	INFINITI JX35	L50	2013.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI JX35	L50	2013.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
North america common	INFINITI JX35	L50	2013.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI JX35	L50	2013.NULL –	Air bag	√	√	√	√		
North america common	INFINITI JX35	L50	2013.NULL –	EPS/DAST 3	√	√	√	√		
North america common	INFINITI JX35	L50	2013.NULL –	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
North america common	INFINITI JX35	L50	2013.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI JX35	L50	2013.NULL –	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
North america common	INFINITI JX35	L50	2013.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
North america common	INFINITI JX35	L50	2013.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
North america common	INFINITI JX35	L50	2013.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI JX35	L50	2013.NULL –	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
North america common	INFINITI JX35	L50	2013.NULL –	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI JX35	L50	2013.NULL –	Auto back door	√	√	√	√		SP0611
North america common	INFINITI JX35	L50	2013.NULL –	Occupant detection			√	√		SP0584
North america common	INFINITI JX35	L50	2013.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI JX35	L50	2013.NULL –	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
North america common	INFINITI JX35	L50	2013.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI JX35	L50	2013.NULL –	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI JX35	L50	2013.NULL –	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI JX35	L50	2013.NULL –	CAN gateway	√	√	√			
North america common	INFINITI JX35	L50	2013.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
North america common	INFINITI JX35	L50	2013.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI JX35	L50	2013.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI JX35	L50	2013.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI M35/M45	Y50	2006.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
North america common	INFINITI M35/M45	Y50	2006.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
North america common	INFINITI M35/M45	Y50	2006.NULL –	IPDM E/R	√	√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
North america common	INFINITI M35/M45	Y50	2006.NULL –	Air bag	√	√	√	√		
North america common	INFINITI M35/M45	Y50	2006.NULL –	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
North america common	INFINITI M35/M45	Y50	2006.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
North america common	INFINITI M35/M45	Y50	2006.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
North america common	INFINITI M35/M45	Y50	2006.NULL –	BCM					AC0653, AC0698	SP0391, SP0393
North america common	INFINITI M35/M45	Y50	2006.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
North america common	INFINITI M35/M45	Y50	2006.NULL –	Multi AV	√	√	√	√		
North america common	INFINITI M35/M45	Y50	2006.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI M35/M45	Y50	2006.NULL –	Adaptive light	√	√	√	√		SP0561, SP0562
North america common	INFINITI M35/M45	Y50	2006.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	
North america common	INFINITI M35/M45	Y50	2006.NULL –	Precrash seatbelt	√	√	√	√		
North america common	INFINITI M35/M45	Y50	2006.NULL –	Intelligent key	√	√	√	√	AC0911, AC0913, AC0915, AC0916, AC0917, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
North america common	INFINITI M35/M45	Y50	2006.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976	SP0560
North america common	INFINITI M35/M45	Y50	2006.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI M35H	HY51	2012.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510

XTOOL

North america common	INFINITI M35H	HY51	2012.NULL –	Laser/radar	√	√	√	√		
North america common	INFINITI M35H	HY51	2012.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI M35H	HY51	2012.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
North america common	INFINITI M35H	HY51	2012.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI M35H	HY51	2012.NULL –	Air bag	√	√	√	√		
North america common	INFINITI M35H	HY51	2012.NULL –	EPS/DAST 3	√	√	√	√		
North america common	INFINITI M35H	HY51	2012.NULL –	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
North america common	INFINITI M35H	HY51	2012.NULL –	Motor control	√	√	√	√		
North america common	INFINITI M35H	HY51	2012.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
North america common	INFINITI M35H	HY51	2012.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
North america common	INFINITI M35H	HY51	2012.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
North america common	INFINITI M35H	HY51	2012.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
North america common	INFINITI M35H	HY51	2012.NULL –	Diag data recorder	√					
North america common	INFINITI M35H	HY51	2012.NULL –	Pop up hood	√	√	√	√		
North america common	INFINITI M35H	HY51	2012.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI M35H	HY51	2012.NULL –	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
North america common	INFINITI M35H	HY51	2012.NULL –	HV battery	√	√	√	√	AC1121	
North america common	INFINITI M35H	HY51	2012.NULL –	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI M35H	HY51	2012.NULL –	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
North america common	INFINITI M35H	HY51	2012.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI M35H	HY51	2012.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI M35H	HY51	2012.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
North america common	INFINITI M35H	HY51	2012.NULL –	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI M35H	HY51	2012.NULL –	CAN gateway	√	√	√			
North america common	INFINITI M35H	HY51	2012.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
North america common	INFINITI M35H	HY51	2012.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI M35H	HY51	2012.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI M35H	HY51	2012.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI M35H	HY51	2012.NULL –	Brake	√	√	√	√	AC1127	
North america common	INFINITI M35H	HY51	2012.NULL –	VSP	√	√	√	√	AC1124, AC1125, AC1126	
North america common	INFINITI M37/M56	Y51	2011.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
North america common	INFINITI M37/M56	Y51	2011.NULL –	Laser/radar	√	√	√	√		
North america common	INFINITI M37/M56	Y51	2011.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI M37/M56	Y51	2011.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
North america common	INFINITI M37/M56	Y51	2011.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
North america common	INFINITI M37/M56	Y51	2011.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI M37/M56	Y51	2011.NULL –	Air bag	√	√	√	√		
North america common	INFINITI M37/M56	Y51	2011.NULL –	EPS/DAST 3	√	√	√	√		
North america common	INFINITI M37/M56	Y51	2011.NULL –	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
North america common	INFINITI M37/M56	Y51	2011.NULL –	Motor control	√	√	√	√		
North america common	INFINITI M37/M56	Y51	2011.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
North america common	INFINITI M37/M56	Y51	2011.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
North america common	INFINITI M37/M56	Y51	2011.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471

XTOOL

North america common	INFINITI M37/M56	Y51	2011.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI M37/M56	Y51	2011.NULL_	Pop up hood	√	√	√	√		
North america common	INFINITI M37/M56	Y51	2011.NULL_	Multi AV	√	√	√	√		SP0503
North america common	INFINITI M37/M56	Y51	2011.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
North america common	INFINITI M37/M56	Y51	2011.NULL_	HV battery	√	√	√	√	AC1121	
North america common	INFINITI M37/M56	Y51	2011.NULL_	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
North america common	INFINITI M37/M56	Y51	2011.NULL_	4WAS(front)	√	√	√	√	AC1027, AC1028	
North america common	INFINITI M37/M56	Y51	2011.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI M37/M56	Y51	2011.NULL_	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
North america common	INFINITI M37/M56	Y51	2011.NULL_	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI M37/M56	Y51	2011.NULL_	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI M37/M56	Y51	2011.NULL_	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
North america common	INFINITI M37/M56	Y51	2011.NULL_	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI M37/M56	Y51	2011.NULL_	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI M37/M56	Y51	2011.NULL_	CAN gateway	√	√	√			
North america common	INFINITI M37/M56	Y51	2011.NULL_	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
North america common	INFINITI M37/M56	Y51	2011.NULL_	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI M37/M56	Y51	2011.NULL_	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI M37/M56	Y51	2011.NULL_	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI M37/M56	Y51	2011.NULL_	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI M37/M56	Y51	2011.NULL_	VSP	√	√	√	√	AC1124, AC1125, AC1126	
North america common	INFINITI M45	Y34	2003.NULL_	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
North america common	INFINITI M45	Y34	2003.NULL_	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
North america common	INFINITI M45	Y34	2003.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI M45	Y34	2003.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
North america common	INFINITI M45	Y34	2003.NULL_	Air bag	√	√	√	√		
North america common	INFINITI M45	Y34	2003.NULL_	EPS/DAST 3	√	√	√	√		SP0506, SP0507
North america common	INFINITI M45	Y34	2003.NULL_	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
North america common	INFINITI M45	Y34	2003.NULL_	Motor control						
North america common	INFINITI M45	Y34	2003.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI M45	Y34	2003.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
North america common	INFINITI M45	Y34	2003.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
North america common	INFINITI M45	Y34	2003.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI M45	Y34	2003.NULL_	Multi AV	√	√	√	√		SP0503
North america common	INFINITI M45	Y34	2003.NULL_	HVAC	√	√	√	√		
North america common	INFINITI M45	Y34	2003.NULL_	Difference lock	√	√	√	√		
North america common	INFINITI M45	Y34	2003.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI M45	Y34	2003.NULL_	Auto slide door	√	√	√	√	AC0941	
North america common	INFINITI M45	Y34	2003.NULL_	DIU		√	√	√		
North america common	INFINITI M45	Y34	2003.NULL_	Adaptive light	√	√	√	√		
North america common	INFINITI M45	Y34	2003.NULL_	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI M45	Y34	2003.NULL_	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
North america common	INFINITI M45	Y34	2003.NULL_	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI M45	Y34	2003.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537

North america common	INFINITI M45	Y34	2003.NULL –	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
North america common	INFINITI M45	Y34	2003.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI M45	Y34	2003.NULL –	IVMS	√	√		√		
North america common	INFINITI M45	Y34	2003.NULL –	Distance control	√	√		√		
North america common	INFINITI M45	Y34	2003.NULL –	Active suspense system	√	√	√	√		
North america common	INFINITI M45	Y34	2003.NULL –	Motor assist		√	√	√		SP0574
North america common	INFINITI M45	Y34	2003.NULL –	ASCD	√	√	√	√		
North america common	INFINITI M45	Y34	2003.NULL –	Active engine mount	√	√	√	√		
North america common	INFINITI M45	Y34	2003.NULL –	TCS	√	√	√	√		
North america common	INFINITI M45	Y34	2003.NULL –	S/blind camera	√			√		SP0572,SP0573
North america common	INFINITI M45	Y34	2003.NULL –	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
North america common	INFINITI M45	Y34	2003.NULL –	Nats immu	√	√	√			
North america common	INFINITI M45	Y34	2003.NULL –	Rearview camera	√			√		SP0570,SP0571
North america common	INFINITI M45	Y34	2003.NULL –	Smart entrance						SP0568
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	Air bag	√	√	√	√		
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0038,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	Transmission	√	√	√	√		SP0274
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	Pop up hood	√	√	√	√		
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI Q40 SEDAN	V36	2015.NULL –	Precrash seatbelt	√	√	√	√		
North america common	INFINITI Q45	F50	2002.NULL –	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
North america common	INFINITI Q45	F50	2002.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
North america common	INFINITI Q45	F50	2002.NULL –	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
North america common	INFINITI Q45	F50	2002.NULL –	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
North america common	INFINITI Q45	F50	2002.NULL –	Air bag	√	√	√	√		
North america common	INFINITI Q45	F50	2002.NULL –	EPS/DAST 3	√	√	√	√		SP0506,SP0507
North america common	INFINITI Q45	F50	2002.NULL –	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
North america common	INFINITI Q45	F50	2002.NULL –	Motor control						
North america common	INFINITI Q45	F50	2002.NULL –	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
North america common	INFINITI Q45	F50	2002.NULL –	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
North america common	INFINITI Q45	F50	2002.NULL –	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
North america common	INFINITI Q45	F50	2002.NULL –	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
North america common	INFINITI Q45	F50	2002.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI Q45	F50	2002.NULL –	HVAC	√	√	√	√		

North america common	INFINITI Q45	F50	2002.NULL –	Difference lock	√	√	√	√		
North america common	INFINITI Q45	F50	2002.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI Q45	F50	2002.NULL –	Auto slide door	√	√	√	√	AC0941	
North america common	INFINITI Q45	F50	2002.NULL –	DIU		√	√	√		
North america common	INFINITI Q45	F50	2002.NULL –	Adaptive light	√	√	√	√		
North america common	INFINITI Q45	F50	2002.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI Q45	F50	2002.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
North america common	INFINITI Q45	F50	2002.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI Q45	F50	2002.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
North america common	INFINITI Q45	F50	2002.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
North america common	INFINITI Q45	F50	2002.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI Q45	F50	2002.NULL –	IVMS	√	√		√		
North america common	INFINITI Q45	F50	2002.NULL –	Distance control	√	√		√		
North america common	INFINITI Q45	F50	2002.NULL –	Active suspense system	√	√	√	√		
North america common	INFINITI Q45	F50	2002.NULL –	Motor assist		√	√	√		SP0574
North america common	INFINITI Q45	F50	2002.NULL –	ASCD	√	√	√	√		
North america common	INFINITI Q45	F50	2002.NULL –	Active engine mount	√	√	√	√		
North america common	INFINITI Q45	F50	2002.NULL –	TCS	√	√	√	√		
North america common	INFINITI Q45	F50	2002.NULL –	S/blind camera	√			√		SP0572, SP0573
North america common	INFINITI Q45	F50	2002.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
North america common	INFINITI Q45	F50	2002.NULL –	Nats immu	√	√	√			
North america common	INFINITI Q45	F50	2002.NULL –	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI Q45	F50	2002.NULL –	Smart entrance						SP0568
North america common	INFINITI Q45	FY33	1995.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
North america common	INFINITI Q45	FY33	1995.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
North america common	INFINITI Q45	FY33	1995.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI Q45	FY33	1995.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
North america common	INFINITI Q45	FY33	1995.NULL –	Air bag	√	√	√	√		
North america common	INFINITI Q45	FY33	1995.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
North america common	INFINITI Q45	FY33	1995.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
North america common	INFINITI Q45	FY33	1995.NULL –	Motor control						
North america common	INFINITI Q45	FY33	1995.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI Q45	FY33	1995.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
North america common	INFINITI Q45	FY33	1995.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
North america common	INFINITI Q45	FY33	1995.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI Q45	FY33	1995.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI Q45	FY33	1995.NULL –	HVAC	√	√	√	√		
North america common	INFINITI Q45	FY33	1995.NULL –	Difference lock	√	√	√	√		
North america common	INFINITI Q45	FY33	1995.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI Q45	FY33	1995.NULL –	Auto slide door	√	√	√	√	AC0941	
North america common	INFINITI Q45	FY33	1995.NULL –	DIU		√	√	√		
North america common	INFINITI Q45	FY33	1995.NULL –	Adaptive light	√	√	√	√		
North america common	INFINITI Q45	FY33	1995.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI Q45	FY33	1995.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544

XTOOL

North america common	INFINITI Q45	FY33	1995.NULL_	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI Q45	FY33	1995.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
North america common	INFINITI Q45	FY33	1995.NULL_	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
North america common	INFINITI Q45	FY33	1995.NULL_	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI Q45	FY33	1995.NULL_	IVMS	√	√		√		
North america common	INFINITI Q45	FY33	1995.NULL_	Distance control	√	√		√		
North america common	INFINITI Q45	FY33	1995.NULL_	Active suspense system	√	√	√	√		
North america common	INFINITI Q45	FY33	1995.NULL_	Motor assist		√	√	√		SP0574
North america common	INFINITI Q45	FY33	1995.NULL_	ASCD	√	√	√	√		
North america common	INFINITI Q45	FY33	1995.NULL_	Active engine mount	√	√	√	√		
North america common	INFINITI Q45	FY33	1995.NULL_	TCS	√	√	√	√		
North america common	INFINITI Q45	FY33	1995.NULL_	S/blind camera	√			√		SP0572, SP0573
North america common	INFINITI Q45	FY33	1995.NULL_	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
North america common	INFINITI Q45	FY33	1995.NULL_	Nats immu	√	√	√			
North america common	INFINITI Q45	FY33	1995.NULL_	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI Q45	FY33	1995.NULL_	Smart entrance						SP0568
North america common	INFINITI Q50	V37	2019.NULL_	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
North america common	INFINITI Q50	V37	2019.NULL_	Laser/radar	√	√	√	√	AC0994	
North america common	INFINITI Q50	V37	2019.NULL_	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI Q50	V37	2019.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
North america common	INFINITI Q50	V37	2019.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI Q50	V37	2019.NULL_	Air bag	√	√	√	√		
North america common	INFINITI Q50	V37	2019.NULL_	EPS/DAST 3	√	√	√	√		SP0507
North america common	INFINITI Q50	V37	2019.NULL_	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
North america common	INFINITI Q50	V37	2019.NULL_	Motor control	√	√	√	√		
North america common	INFINITI Q50	V37	2019.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI Q50	V37	2019.NULL_	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
North america common	INFINITI Q50	V37	2019.NULL_	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
North america common	INFINITI Q50	V37	2019.NULL_	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
North america common	INFINITI Q50	V37	2019.NULL_	Pop up hood	√	√	√	√		
North america common	INFINITI Q50	V37	2019.NULL_	Multi AV	√	√	√	√		SP0503
North america common	INFINITI Q50	V37	2019.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
North america common	INFINITI Q50	V37	2019.NULL_	HV battery	√	√	√	√	AC1121	
North america common	INFINITI Q50	V37	2019.NULL_	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
North america common	INFINITI Q50	V37	2019.NULL_	4WAS(front)	√	√	√	√	AC1027, AC1028	
North america common	INFINITI Q50	V37	2019.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI Q50	V37	2019.NULL_	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
North america common	INFINITI Q50	V37	2019.NULL_	Occupant detection			√	√		SP0584
North america common	INFINITI Q50	V37	2019.NULL_	Shift	√	√	√	√		SP0613
North america common	INFINITI Q50	V37	2019.NULL_	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
North america common	INFINITI Q50	V37	2019.NULL_	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI Q50	V37	2019.NULL_	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI Q50	V37	2019.NULL_	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI Q50	V37	2019.NULL_	DAST 2	√	√	√	√		

North america common	INFINITI Q50	V37	2019.NULL –	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI Q50	V37	2019.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI Q50	V37	2019.NULL –	CAN gateway	√	√	√			
North america common	INFINITI Q50	V37	2019.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
North america common	INFINITI Q50	V37	2019.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI Q50	V37	2019.NULL –	DAST 1	√	√	√	√		
North america common	INFINITI Q50	V37	2019.NULL –	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
North america common	INFINITI Q50	V37	2019.NULL –	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
North america common	INFINITI Q50	V37	2019.NULL –	ANC	√	√	√	√	AC1024	
North america common	INFINITI Q50	V37	2019.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI Q50	V37	2019.NULL –	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
North america common	INFINITI Q50	V37	2019.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI Q50	V37	2019.NULL –	HIGH BEAM ASSIST	√	√	√	√		
North america common	INFINITI Q50	V37	2019.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI Q50	V37	2019.NULL –	Brake	√	√	√	√	AC1127	
North america common	INFINITI Q50	V37	2019.NULL –	6ch CAN GATEWAY	√	√	√	√		
North america common	INFINITI Q50	V37	2019.NULL –	3ch CAN GATEWAY	√	√	√	√		
North america common	INFINITI Q50	V37	2019.NULL –	ICC/ADAS 2	√	√	√	√		
North america common	INFINITI Q50	V37	2019.NULL –	FSCM	√	√	√	√	AC1109	
North america common	INFINITI Q50	V37	2019.NULL –	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Laser/radar	√	√	√	√		
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Air bag	√	√	√	√		
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	EPS/DAST 3	√	√	√	√		SP0507
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Motor control	√	√	√	√		
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Transmission	√	√	√	√		SP0274, SP0276
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Pop up hood	√	√	√	√		
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	HV battery	√	√	√	√	AC1121	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Occupant detection			√	√		SP0584
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Shift	√	√	√	√		SP0613
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559

North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	DAST 2	√	√	√	√		
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	CAN gateway	√	√	√			
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	DAST 1	√	√	√	√		
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	ANC	√	√	√	√	AC1024	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	HIGH BEAM ASSIST	√	√	√	√		
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	Brake	√	√	√	√	AC1127	
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	6ch CAN GATEWAY	√	√	√	√		
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	3ch CAN GATEWAY	√	√	√	√		
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	ICC/ADAS 2	√	√	√	√		
North america common	INFINITI Q50 HYBRID	HV37	2014.NULL-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Laser/radar	√	√	√	√		
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Air bag	√	√	√	√		
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	EPS/DAST 3	√	√	√	√		
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Motor control	√	√	√	√		
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Transmission	√	√	√	√		SP0276
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Pop up hood	√	√	√	√		
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Multi AV	√	√	√	√		SP0503
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	HV battery	√	√	√	√	AC1121	
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Occupant detection			√	√		SP0584
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	All mode AWD/4WD	√	√	√	√	AC0956	

XTOOL

North america common	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 2	√	√	√	√		
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Lane camera	√	√	√	√		
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 1	√	√	√	√		
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	ANC	√	√	√	√	AC1024	
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	HIGH BEAM ASSIST	√	√	√	√		
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√		
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	Brake	√	√	√	√	AC1127	
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	6ch CAN GATEWAY	√	√	√	√		
North america common	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
North america common	INFINITI Q60	CV37	2019.NULL-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
North america common	INFINITI Q60	CV37	2019.NULL-	Laser/radar	√	√	√	√	AC0994	
North america common	INFINITI Q60	CV37	2019.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI Q60	CV37	2019.NULL-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
North america common	INFINITI Q60	CV37	2019.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI Q60	CV37	2019.NULL-	Air bag	√	√	√	√		
North america common	INFINITI Q60	CV37	2019.NULL-	EPS/DAST 3	√	√	√	√		
North america common	INFINITI Q60	CV37	2019.NULL-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
North america common	INFINITI Q60	CV37	2019.NULL-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI Q60	CV37	2019.NULL-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
North america common	INFINITI Q60	CV37	2019.NULL-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
North america common	INFINITI Q60	CV37	2019.NULL-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
North america common	INFINITI Q60	CV37	2019.NULL-	Pop up hood	√	√	√	√		
North america common	INFINITI Q60	CV37	2019.NULL-	Multi AV	√	√	√	√		SP0503
North america common	INFINITI Q60	CV37	2019.NULL-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
North america common	INFINITI Q60	CV37	2019.NULL-	4WAS(front)	√	√	√	√	AC1027, AC1028	
North america common	INFINITI Q60	CV37	2019.NULL-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI Q60	CV37	2019.NULL-	Occupant detection			√	√		SP0584
North america common	INFINITI Q60	CV37	2019.NULL-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
North america common	INFINITI Q60	CV37	2019.NULL-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI Q60	CV37	2019.NULL-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
North america common	INFINITI Q60	CV37	2019.NULL-	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI Q60	CV37	2019.NULL-	DAST 2	√	√	√	√		
North america common	INFINITI Q60	CV37	2019.NULL-	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI Q60	CV37	2019.NULL-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI Q60	CV37	2019.NULL-	CAN gateway	√	√	√			

XTOOL

North america common	INFINITI Q60	CV37	2019.NULL –	Lane camera	√	√	√	√		
North america common	INFINITI Q60	CV37	2019.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI Q60	CV37	2019.NULL –	DAST 1	√	√	√	√		
North america common	INFINITI Q60	CV37	2019.NULL –	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
North america common	INFINITI Q60	CV37	2019.NULL –	ANC	√	√	√	√	AC1024	
North america common	INFINITI Q60	CV37	2019.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI Q60	CV37	2019.NULL –	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
North america common	INFINITI Q60	CV37	2019.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI Q60	CV37	2019.NULL –	HIGH BEAM ASSIST	√	√	√	√		
North america common	INFINITI Q60	CV37	2019.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI Q60	CV37	2019.NULL –	Lane camera 2	√	√	√	√		
North america common	INFINITI Q60	CV37	2019.NULL –	6ch CAN GATEWAY	√	√	√	√		
North america common	INFINITI Q60	CV37	2019.NULL –	3ch CAN GATEWAY	√	√	√	√		
North america common	INFINITI Q60	CV37	2019.NULL –	ICC/ADAS 2	√	√	√	√		
North america common	INFINITI Q60	CV37	2019.NULL –	FSCM	√	√	√	√	AC1109	
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Air bag	√	√	√	√		
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Transmission	√	√	√	√		SP0274
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Pop up hood	√	√	√	√		
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
North america common	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Precrash seatbelt	√	√	√	√		
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	Air bag	√	√	√	√		
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	Transmission	√	√	√	√		SP0274
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	Pop up hood	√	√	√	√		

North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI Q60 COUPE	CV36	2014.NULL –	Precrash seatbelt	√	√	√	√		
North america common	INFINITI Q70	Y51	2019.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
North america common	INFINITI Q70	Y51	2019.NULL –	Laser/radar	√	√	√	√	AC0994	
North america common	INFINITI Q70	Y51	2019.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI Q70	Y51	2019.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
North america common	INFINITI Q70	Y51	2019.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI Q70	Y51	2019.NULL –	Air bag	√	√	√	√		
North america common	INFINITI Q70	Y51	2019.NULL –	EPS/DAST 3	√	√	√	√		SP0507
North america common	INFINITI Q70	Y51	2019.NULL –	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
North america common	INFINITI Q70	Y51	2019.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
North america common	INFINITI Q70	Y51	2019.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
North america common	INFINITI Q70	Y51	2019.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
North america common	INFINITI Q70	Y51	2019.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI Q70	Y51	2019.NULL –	Pop up hood	√	√	√	√		
North america common	INFINITI Q70	Y51	2019.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI Q70	Y51	2019.NULL –	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
North america common	INFINITI Q70	Y51	2019.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
North america common	INFINITI Q70	Y51	2019.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
North america common	INFINITI Q70	Y51	2019.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI Q70	Y51	2019.NULL –	Occupant detection			√	√		SP0584
North america common	INFINITI Q70	Y51	2019.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
North america common	INFINITI Q70	Y51	2019.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI Q70	Y51	2019.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI Q70	Y51	2019.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI Q70	Y51	2019.NULL –	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI Q70	Y51	2019.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI Q70	Y51	2019.NULL –	CAN gateway	√	√	√			
North america common	INFINITI Q70	Y51	2019.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
North america common	INFINITI Q70	Y51	2019.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI Q70	Y51	2019.NULL –	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
North america common	INFINITI Q70	Y51	2019.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI Q70	Y51	2019.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI Q70	Y51	2019.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI Q70	Y51	2019.NULL –	6ch CAN GATEWAY	√	√	√	√		
North america common	INFINITI Q70	Y51	2019.NULL –	ICC/ADAS 2	√	√	√	√		
North america common	INFINITI Q70	Y51	2019.NULL –	FSCM	√	√	√	√	AC1109	
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL –	Laser/radar	√	√	√	√	AC0994	

North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Air bag	√	√	√	√		
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	EPS/DAST 3	√	√	√	√		
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Motor control	√	√	√	√		
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	BCM				√	AC0613, AC0618, AC0653, AC0663, AC0690, AC0692, AC0698, AC0702	SP0372, SP0429, SP0471
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Pop up hood	√	√	√	√		
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Multi AV	√	√	√	√		SP0503
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	HV battery	√	√	√	√	AC1121	
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	4WAS(front)	√	√	√	√	AC1027, AC1028	
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Occupant detection			√	√		SP0584
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	CAN gateway	√	√	√			
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	Brake	√	√	√	√	AC1127	
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	6ch CAN GATEWAY	√	√	√	√		
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	ICC/ADAS 2	√	√	√	√		
North america common	INFINITI Q70 HYBRID	HY51	2014.NULL-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
North america common	INFINITI QX30	H15	2019.NULL-	Air pressure monitor	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL-	Air bag	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL-	EPS/DAST 3	√	√	√			
North america common	INFINITI QX30	H15	2019.NULL-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344

XTOOL

North america common	INFINITI QX30	H15	2019.NULL –	Engine	√	√	√	√	AC0002, AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0103, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
North america common	INFINITI QX30	H15	2019.NULL –	EHS/PKB	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	Transmission	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
North america common	INFINITI QX30	H15	2019.NULL –	ABS	√	√	√	√		SP0308
North america common	INFINITI QX30	H15	2019.NULL –	Multi AV	√	√	√	√		SP0501
North america common	INFINITI QX30	H15	2019.NULL –	HVAC	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	Auto drive position	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	Shift	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	All mode AWD/4WD	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	AVM	√	√		√		
North america common	INFINITI QX30	H15	2019.NULL –	Intelligent key	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	CAN gateway	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	ANC	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	Telematics	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	FSCM	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	Siren control unit	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
North america common	INFINITI QX30	H15	2019.NULL –	Overhead Control Panel Unit	√			√		
North america common	INFINITI QX30	H15	2019.NULL –	Universal Garage Door Opener	√			√		
North america common	INFINITI QX30	H15	2019.NULL –	Upper control panel cont unit	√					
North america common	INFINITI QX30	H15	2019.NULL –	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
North america common	INFINITI QX30	H15	2019.NULL –	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
North america common	INFINITI QX30	H15	2019.NULL –	Light/Rain Sensor Module	√			√		
North america common	INFINITI QX30	H15	2019.NULL –	EC Mirror Compass	√					
North america common	INFINITI QX30	H15	2019.NULL –	Intelligent Battery Sensor	√					
North america common	INFINITI QX30	H15	2019.NULL –	Alarm siren	√			√		
North america common	INFINITI QX30	H15	2019.NULL –	Radar sensor	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	Steering column cont module	√	√	√			
North america common	INFINITI QX30	H15	2019.NULL –	ICC sensor	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	Trailer recognition control unit	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	H/L control module LH	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	Powertrain cont module	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	Side radar LH	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	LED H/L control module LH	√			√		
North america common	INFINITI QX30	H15	2019.NULL –	Steering Wheel Switch Pad	√			√		
North america common	INFINITI QX30	H15	2019.NULL –	Parking assist	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	Occupant Classification Unit	√			√		
North america common	INFINITI QX30	H15	2019.NULL –	Electronic Ignition Switch cont unit	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	H/L control module RH	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	Front camera unit	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	Side radar RH	√	√	√	√		
North america common	INFINITI QX30	H15	2019.NULL –	LED H/L control module RH	√			√		
North america common	INFINITI QX4	JR50	1997.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
North america common	INFINITI QX4	JR50	1997.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493

XTOOL

North america common	INFINITI QX4	JR50	1997.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI QX4	JR50	1997.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
North america common	INFINITI QX4	JR50	1997.NULL –	Air bag	√	√	√	√		
North america common	INFINITI QX4	JR50	1997.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
North america common	INFINITI QX4	JR50	1997.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
North america common	INFINITI QX4	JR50	1997.NULL –	Motor control						
North america common	INFINITI QX4	JR50	1997.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI QX4	JR50	1997.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
North america common	INFINITI QX4	JR50	1997.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
North america common	INFINITI QX4	JR50	1997.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI QX4	JR50	1997.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI QX4	JR50	1997.NULL –	HVAC	√	√	√	√		
North america common	INFINITI QX4	JR50	1997.NULL –	Difference lock	√	√	√	√		
North america common	INFINITI QX4	JR50	1997.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI QX4	JR50	1997.NULL –	Auto slide door	√	√	√	√	AC0941	
North america common	INFINITI QX4	JR50	1997.NULL –	DIU		√	√	√		
North america common	INFINITI QX4	JR50	1997.NULL –	Adaptive light	√	√	√	√		
North america common	INFINITI QX4	JR50	1997.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI QX4	JR50	1997.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
North america common	INFINITI QX4	JR50	1997.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI QX4	JR50	1997.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
North america common	INFINITI QX4	JR50	1997.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
North america common	INFINITI QX4	JR50	1997.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI QX4	JR50	1997.NULL –	IVMS	√	√		√		
North america common	INFINITI QX4	JR50	1997.NULL –	Distance control	√	√		√		
North america common	INFINITI QX4	JR50	1997.NULL –	Active suspense system	√	√	√	√		
North america common	INFINITI QX4	JR50	1997.NULL –	Motor assist		√	√	√		SP0574
North america common	INFINITI QX4	JR50	1997.NULL –	ASCD	√	√	√	√		
North america common	INFINITI QX4	JR50	1997.NULL –	Active engine mount	√	√	√	√		
North america common	INFINITI QX4	JR50	1997.NULL –	TCS	√	√	√	√		
North america common	INFINITI QX4	JR50	1997.NULL –	S/blind camera	√			√		SP0572, SP0573
North america common	INFINITI QX4	JR50	1997.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
North america common	INFINITI QX4	JR50	1997.NULL –	Nats immu	√	√	√			
North america common	INFINITI QX4	JR50	1997.NULL –	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI QX4	JR50	1997.NULL –	Smart entrance						SP0568
North america common	INFINITI QX50	J50	2014.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
North america common	INFINITI QX50	J50	2014.NULL –	Laser/radar	√	√	√	√	AC0994	
North america common	INFINITI QX50	J50	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI QX50	J50	2014.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI QX50	J50	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI QX50	J50	2014.NULL –	Air bag	√	√	√	√		
North america common	INFINITI QX50	J50	2014.NULL –	EPS/DAST 3	√	√	√	√		SP0507
North america common	INFINITI QX50	J50	2014.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

North america common	INFINITI QX50	J50	2014.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
North america common	INFINITI QX50	J50	2014.NULL_	Transmission	√	√	√	√		SP0274
North america common	INFINITI QX50	J50	2014.NULL_	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
North america common	INFINITI QX50	J50	2014.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
North america common	INFINITI QX50	J50	2014.NULL_	Multi AV	√	√	√	√		SP0503
North america common	INFINITI QX50	J50	2014.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI QX50	J50	2014.NULL_	Occupant detection			√	√		SP0584
North america common	INFINITI QX50	J50	2014.NULL_	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI QX50	J50	2014.NULL_	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI QX50	J50	2014.NULL_	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
North america common	INFINITI QX50	J50	2014.NULL_	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI QX50	J50	2014.NULL_	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI QX50	J50	2014.NULL_	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI QX50	J50	2014.NULL_	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
North america common	INFINITI QX50	J50	2014.NULL_	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
North america common	INFINITI QX50	J50	2014.NULL_	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI QX50	J50	2014.NULL_	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI QX50	J50	2014.NULL_	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI QX50	J55	2019.NULL_	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
North america common	INFINITI QX50	J55	2019.NULL_	Laser/radar	√	√	√	√		
North america common	INFINITI QX50	J55	2019.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
North america common	INFINITI QX50	J55	2019.NULL_	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
North america common	INFINITI QX50	J55	2019.NULL_	Air bag	√	√	√	√		
North america common	INFINITI QX50	J55	2019.NULL_	EPS/DAST 3	√	√	√	√		
North america common	INFINITI QX50	J55	2019.NULL_	Meter/M&A	√	√	√	√		
North america common	INFINITI QX50	J55	2019.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
North america common	INFINITI QX50	J55	2019.NULL_	EHS/PKB	√	√	√	√		
North america common	INFINITI QX50	J55	2019.NULL_	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
North america common	INFINITI QX50	J55	2019.NULL_	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
North america common	INFINITI QX50	J55	2019.NULL_	ABS	√	√	√	√		SP0313, SP0315
North america common	INFINITI QX50	J55	2019.NULL_	Total illum C/U	√	√	√	√		
North america common	INFINITI QX50	J55	2019.NULL_	Multi AV	√	√	√	√		SP0503
North america common	INFINITI QX50	J55	2019.NULL_	HVAC	√	√	√	√		
North america common	INFINITI QX50	J55	2019.NULL_	Auto drive position	√	√	√	√		
North america common	INFINITI QX50	J55	2019.NULL_	Auto back door	√	√	√	√		SP0611
North america common	INFINITI QX50	J55	2019.NULL_	Occupant detection			√	√		SP0584
North america common	INFINITI QX50	J55	2019.NULL_	Shift						
North america common	INFINITI QX50	J55	2019.NULL_	Adaptive light	√	√	√	√		SP0562
North america common	INFINITI QX50	J55	2019.NULL_	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI QX50	J55	2019.NULL_	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI QX50	J55	2019.NULL_	All mode AWD/4WD	√	√	√	√		
North america common	INFINITI QX50	J55	2019.NULL_	DAST 2	√	√	√	√		
North america common	INFINITI QX50	J55	2019.NULL_	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

North america common	INFINITI QX50	J55	2019,NULL,-	CAN gateway	√	√	√	√		
North america common	INFINITI QX50	J55	2019,NULL,-	Lane camera	√	√	√	√		
North america common	INFINITI QX50	J55	2019,NULL,-	DAST 1	√	√	√	√		
North america common	INFINITI QX50	J55	2019,NULL,-	Chassis control	√	√	√	√		
North america common	INFINITI QX50	J55	2019,NULL,-	ANC						
North america common	INFINITI QX50	J55	2019,NULL,-	E-HUD	√	√	√	√		
North america common	INFINITI QX50	J55	2019,NULL,-	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI QX50	J55	2019,NULL,-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
North america common	INFINITI QX50	J55	2019,NULL,-	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI QX50	J55	2019,NULL,-	6ch CAN GATEWAY	√	√	√	√		
North america common	INFINITI QX50	J55	2019,NULL,-	3ch CAN GATEWAY	√	√	√	√		
North america common	INFINITI QX50	J55	2019,NULL,-	ICC/ADAS 2	√	√	√	√		
North america common	INFINITI QX56	JA60	2004,NULL,-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
North america common	INFINITI QX56	JA60	2004,NULL,-	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
North america common	INFINITI QX56	JA60	2004,NULL,-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
North america common	INFINITI QX56	JA60	2004,NULL,-	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
North america common	INFINITI QX56	JA60	2004,NULL,-	Air bag	√	√	√	√		
North america common	INFINITI QX56	JA60	2004,NULL,-	EPS/DAST 3	√	√	√	√		SP0506,SP0507
North america common	INFINITI QX56	JA60	2004,NULL,-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
North america common	INFINITI QX56	JA60	2004,NULL,-	Motor control						
North america common	INFINITI QX56	JA60	2004,NULL,-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
North america common	INFINITI QX56	JA60	2004,NULL,-	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
North america common	INFINITI QX56	JA60	2004,NULL,-	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
North america common	INFINITI QX56	JA60	2004,NULL,-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
North america common	INFINITI QX56	JA60	2004,NULL,-	Multi AV	√	√	√	√		SP0503
North america common	INFINITI QX56	JA60	2004,NULL,-	HVAC	√	√	√	√		
North america common	INFINITI QX56	JA60	2004,NULL,-	Difference lock	√	√	√	√		
North america common	INFINITI QX56	JA60	2004,NULL,-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
North america common	INFINITI QX56	JA60	2004,NULL,-	Auto slide door	√	√	√	√	AC0941	
North america common	INFINITI QX56	JA60	2004,NULL,-	DIU		√	√	√		
North america common	INFINITI QX56	JA60	2004,NULL,-	Adaptive light	√	√	√	√		
North america common	INFINITI QX56	JA60	2004,NULL,-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
North america common	INFINITI QX56	JA60	2004,NULL,-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
North america common	INFINITI QX56	JA60	2004,NULL,-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
North america common	INFINITI QX56	JA60	2004,NULL,-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
North america common	INFINITI QX56	JA60	2004,NULL,-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
North america common	INFINITI QX56	JA60	2004,NULL,-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI QX56	JA60	2004,NULL,-	IVMS	√	√		√		
North america common	INFINITI QX56	JA60	2004,NULL,-	Distance control	√	√		√		
North america common	INFINITI QX56	JA60	2004,NULL,-	Active suspense system	√	√	√	√		
North america common	INFINITI QX56	JA60	2004,NULL,-	Motor assist		√	√	√		SP0574
North america common	INFINITI QX56	JA60	2004,NULL,-	ASCD	√	√	√	√		
North america common	INFINITI QX56	JA60	2004,NULL,-	Active engine mount	√	√	√	√		
North america common	INFINITI QX56	JA60	2004,NULL,-	TCS	√	√	√	√		

North america common	INFINITI QX56	JA60	2004.NULL-	S/blind camera	√			√		SP0572, SP0573
North america common	INFINITI QX56	JA60	2004.NULL-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
North america common	INFINITI QX56	JA60	2004.NULL-	Nats immu	√	√	√			
North america common	INFINITI QX56	JA60	2004.NULL-	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI QX56	JA60	2004.NULL-	Smart entrance						SP0568
North america common	INFINITI QX56	Z62	2011.NULL-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
North america common	INFINITI QX56	Z62	2011.NULL-	Laser/radar	√	√	√	√		
North america common	INFINITI QX56	Z62	2011.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI QX56	Z62	2011.NULL-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
North america common	INFINITI QX56	Z62	2011.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI QX56	Z62	2011.NULL-	Air bag	√	√	√	√		
North america common	INFINITI QX56	Z62	2011.NULL-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
North america common	INFINITI QX56	Z62	2011.NULL-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
North america common	INFINITI QX56	Z62	2011.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
North america common	INFINITI QX56	Z62	2011.NULL-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
North america common	INFINITI QX56	Z62	2011.NULL-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
North america common	INFINITI QX56	Z62	2011.NULL-	Multi AV	√	√	√	√		SP0503
North america common	INFINITI QX56	Z62	2011.NULL-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0476, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488, SP0489, SP0490
North america common	INFINITI QX56	Z62	2011.NULL-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
North america common	INFINITI QX56	Z62	2011.NULL-	Difference lock	√	√	√	√		
North america common	INFINITI QX56	Z62	2011.NULL-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI QX56	Z62	2011.NULL-	Auto back door	√	√	√	√		
North america common	INFINITI QX56	Z62	2011.NULL-	Occupant detection			√	√		SP0584
North america common	INFINITI QX56	Z62	2011.NULL-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
North america common	INFINITI QX56	Z62	2011.NULL-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI QX56	Z62	2011.NULL-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
North america common	INFINITI QX56	Z62	2011.NULL-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
North america common	INFINITI QX56	Z62	2011.NULL-	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI QX56	Z62	2011.NULL-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI QX56	Z62	2011.NULL-	CAN gateway	√	√	√			
North america common	INFINITI QX56	Z62	2011.NULL-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
North america common	INFINITI QX56	Z62	2011.NULL-	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI QX56	Z62	2011.NULL-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI QX56	Z62	2011.NULL-	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI QX56	Z62	2011.NULL-	Rearview camera	√			√		SP0570, SP0571
North america common	INFINITI QX60	L50	2019.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
North america common	INFINITI QX60	L50	2019.2-	Laser/radar	√	√	√	√	AC0994	
North america common	INFINITI QX60	L50	2019.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI QX60	L50	2019.2-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
North america common	INFINITI QX60	L50	2019.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI QX60	L50	2019.2-	Air bag	√	√	√	√		
North america common	INFINITI QX60	L50	2019.2-	EPS/DAST 3	√	√	√	√		
North america common	INFINITI QX60	L50	2019.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
North america common	INFINITI QX60	L50	2019.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239

XTOOL

North america common	INFINITI QX60	L50	2019.2-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
North america common	INFINITI QX60	L50	2019.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
North america common	INFINITI QX60	L50	2019.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
North america common	INFINITI QX60	L50	2019.2-	Multi AV	√	√	√	√		SP0503
North america common	INFINITI QX60	L50	2019.2-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
North america common	INFINITI QX60	L50	2019.2-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI QX60	L50	2019.2-	Auto back door	√	√	√	√		SP0611
North america common	INFINITI QX60	L50	2019.2-	Occupant detection			√	√		SP0584
North america common	INFINITI QX60	L50	2019.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI QX60	L50	2019.2-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI QX60	L50	2019.2-	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI QX60	L50	2019.2-	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI QX60	L50	2019.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI QX60	L50	2019.2-	CAN gateway	√	√	√			
North america common	INFINITI QX60	L50	2019.2-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
North america common	INFINITI QX60	L50	2019.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
North america common	INFINITI QX60	L50	2019.2-	ANC	√	√	√	√	AC1024	
North america common	INFINITI QX60	L50	2019.2-	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI QX60	L50	2019.2-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI QX60	L50	2019.2-	HIGH BEAM ASSIST	√	√	√	√		
North america common	INFINITI QX60	L50	2019.2-	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI QX60	L50	2019.2-	3ch CAN GATEWAY	√	√	√	√		
North america common	INFINITI QX60	L50	2019.2-	ICC/ADAS 2	√	√	√	√		
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Laser/radar	√	√	√	√		
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Air bag	√	√	√	√		
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	EPS/DAST 3	√	√	√	√		
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Motor control	√	√	√	√		
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0038, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Multi AV	√	√	√	√		SP0503
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	HV battery	√	√	√	√	AC1121	
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Auto back door	√	√	√	√		SP0611
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Occupant detection			√	√		SP0584
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL-	All mode AWD/4WD	√	√	√	√	AC0956	

North america common	INFINITI QX60 HYBRID	HL50	2014.NULL –	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL –	CAN gateway	√	√	√			
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL –	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL –	ANC	√	√	√	√		
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL –	HIGH BEAM ASSIST	√	√	√	√		
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL –	ICC/ADAS 2	√	√	√	√		
North america common	INFINITI QX60 HYBRID	HL50	2014.NULL –	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
North america common	INFINITI QX70	S51	2014.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
North america common	INFINITI QX70	S51	2014.NULL –	Laser/radar	√	√	√	√	AC0994	
North america common	INFINITI QX70	S51	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI QX70	S51	2014.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
North america common	INFINITI QX70	S51	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI QX70	S51	2014.NULL –	Air bag	√	√	√	√		
North america common	INFINITI QX70	S51	2014.NULL –	EPS/DAST 3	√	√	√	√		SP0507
North america common	INFINITI QX70	S51	2014.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
North america common	INFINITI QX70	S51	2014.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
North america common	INFINITI QX70	S51	2014.NULL –	Transmission	√	√	√	√		SP0274
North america common	INFINITI QX70	S51	2014.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
North america common	INFINITI QX70	S51	2014.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
North america common	INFINITI QX70	S51	2014.NULL –	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
North america common	INFINITI QX70	S51	2014.NULL –	Multi AV	√	√	√	√		SP0503
North america common	INFINITI QX70	S51	2014.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
North america common	INFINITI QX70	S51	2014.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
North america common	INFINITI QX70	S51	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI QX70	S51	2014.NULL –	Auto back door	√	√	√	√		SP0611
North america common	INFINITI QX70	S51	2014.NULL –	Occupant detection			√	√		SP0584
North america common	INFINITI QX70	S51	2014.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
North america common	INFINITI QX70	S51	2014.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI QX70	S51	2014.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
North america common	INFINITI QX70	S51	2014.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
North america common	INFINITI QX70	S51	2014.NULL –	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI QX70	S51	2014.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI QX70	S51	2014.NULL –	CAN gateway	√	√	√			
North america common	INFINITI QX70	S51	2014.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
North america common	INFINITI QX70	S51	2014.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
North america common	INFINITI QX80	Z62	2019.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
North america common	INFINITI QX80	Z62	2019.NULL –	Laser/radar	√	√	√	√	AC0994	
North america common	INFINITI QX80	Z62	2019.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
North america common	INFINITI QX80	Z62	2019.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497

North america common	INFINITI QX80	Z62	2019.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
North america common	INFINITI QX80	Z62	2019.NULL-	Air bag	√	√	√	√		
North america common	INFINITI QX80	Z62	2019.NULL-	EPS/DAST 3	√	√	√	√		SP0507
North america common	INFINITI QX80	Z62	2019.NULL-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
North america common	INFINITI QX80	Z62	2019.NULL-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
North america common	INFINITI QX80	Z62	2019.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
North america common	INFINITI QX80	Z62	2019.NULL-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
North america common	INFINITI QX80	Z62	2019.NULL-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
North america common	INFINITI QX80	Z62	2019.NULL-	Multi AV	√	√	√	√		SP0503
North america common	INFINITI QX80	Z62	2019.NULL-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
North america common	INFINITI QX80	Z62	2019.NULL-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
North america common	INFINITI QX80	Z62	2019.NULL-	Difference lock	√	√	√	√		
North america common	INFINITI QX80	Z62	2019.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
North america common	INFINITI QX80	Z62	2019.NULL-	Auto back door	√	√	√	√		
North america common	INFINITI QX80	Z62	2019.NULL-	Occupant detection			√	√		SP0584
North america common	INFINITI QX80	Z62	2019.NULL-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
North america common	INFINITI QX80	Z62	2019.NULL-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
North america common	INFINITI QX80	Z62	2019.NULL-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
North america common	INFINITI QX80	Z62	2019.NULL-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
North america common	INFINITI QX80	Z62	2019.NULL-	Precrash seatbelt	√	√	√	√		SP0612
North america common	INFINITI QX80	Z62	2019.NULL-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
North america common	INFINITI QX80	Z62	2019.NULL-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
North america common	INFINITI QX80	Z62	2019.NULL-	CAN gateway	√	√	√			
North america common	INFINITI QX80	Z62	2019.NULL-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
North america common	INFINITI QX80	Z62	2019.NULL-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
North america common	INFINITI QX80	Z62	2019.NULL-	Side radar left	√	√	√	√	AC1025	SP0582
North america common	INFINITI QX80	Z62	2019.NULL-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
North america common	INFINITI QX80	Z62	2019.NULL-	HIGH BEAM ASSIST	√	√	√	√		
North america common	INFINITI QX80	Z62	2019.NULL-	Side radar right	√	√	√	√	AC1026	SP0583
North america common	INFINITI QX80	Z62	2019.NULL-	6ch CAN GATEWAY	√	√	√	√		
North america common	INFINITI QX80	Z62	2019.NULL-	ICC/ADAS 2	√	√	√	√		
North america common	INFINITI QX80	Z62	2019.NULL-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Norway	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Norway	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Norway	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Norway	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Norway	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Norway	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Norway	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Norway	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Norway	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Norway	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Norway	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Norway	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Norway	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Norway	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Norway	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Norway	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Norway	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Norway	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Norway	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Norway	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Norway	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Norway	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Norway	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Norway	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Norway	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Norway	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Norway	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Norway	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Norway	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Norway	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Norway	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Norway	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Norway	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Norway	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Norway	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Norway	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Norway	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Norway	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Norway	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503

Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Norway	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Norway	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Norway	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Norway	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Norway	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Norway	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Norway	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Norway	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Norway	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Norway	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Norway	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Norway	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Norway	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Norway	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Norway	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Norway	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Norway	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Norway	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Norway	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Norway	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Norway	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Norway	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Norway	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Norway	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Norway	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Norway	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Norway	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Norway	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Norway	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Norway	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Norway	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Norway	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Norway	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Norway	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Norway	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Norway	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Norway	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Norway	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Norway	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Norway	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Norway	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Norway	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Norway	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Norway	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Norway	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Norway	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Norway	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Norway	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Norway	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Norway	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Norway	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Norway	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Norway	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Norway	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Norway	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Norway	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Norway	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Norway	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Norway	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Norway	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Norway	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Norway	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Norway	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553, SP0554, SP0555, SP0556
Norway	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Norway	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Norway	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Norway	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Norway	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Norway	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Norway	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Norway	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Norway	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Norway	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Norway	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Norway	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Norway	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Norway	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Norway	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Norway	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Norway	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Norway	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Norway	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Norway	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Norway	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Norway	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Norway	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Norway	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Norway	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Norway	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Norway	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Norway	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Norway	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		

XTOOL

Norway	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Norway	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Norway	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Norway	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Norway	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Norway	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Norway	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Norway	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Norway	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Norway	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Norway	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Norway	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Norway	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Norway	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Norway	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Norway	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Norway	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Norway	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Norway	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Norway	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Norway	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Norway	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Norway	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Norway	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Norway	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Norway	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Norway	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Norway	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Norway	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Norway	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Norway	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Norway	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Norway	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Norway	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Norway	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Norway	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Norway	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Norway	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Norway	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Norway	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Norway	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Norway	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Norway	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Norway	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Norway	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Norway	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Norway	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Norway	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Norway	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Norway	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Norway	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Norway	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Norway	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Norway	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Norway	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Norway	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Norway	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Norway	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Norway	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Norway	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Norway	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Norway	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Norway	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	

Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Norway	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Norway	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Norway	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Norway	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Norway	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Norway	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Norway	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Norway	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Norway	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Norway	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Norway	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Norway	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Norway	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Norway	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Norway	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Norway	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Norway	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Norway	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Norway	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Norway	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Norway	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Norway	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Norway	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Norway	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Norway	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Norway	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Norway	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Norway	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Norway	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Norway	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Norway	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Norway	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Norway	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Norway	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Norway	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Norway	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Norway	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Norway	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Norway	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Norway	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Norway	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Norway	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Norway	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Norway	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Norway	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Norway	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Norway	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Norway	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Norway	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Norway	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Norway	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Norway	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Norway	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Norway	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Norway	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Norway	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Norway	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Norway	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Norway	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Norway	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Norway	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Norway	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Norway	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0247,SP0265,SP0270,SP0274
Norway	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471

Norway	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Norway	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Norway	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Norway	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Norway	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Norway	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Norway	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Norway	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Norway	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Norway	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Norway	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Norway	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Norway	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Norway	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Norway	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Norway	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Norway	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Norway	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Norway	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Norway	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Norway	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Norway	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Norway	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Norway	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Norway	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Norway	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Norway	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Norway	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Norway	INFINITI QX50	I50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI QX50	I50	2013.9-	Air bag	√	√	√	√		
Norway	INFINITI QX50	I50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Norway	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Norway	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Norway	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Norway	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Norway	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Norway	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Norway	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Norway	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Norway	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Norway	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Norway	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Norway	INFINITI QX50	I50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Norway	INFINITI QX50	I50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Norway	INFINITI QX50	I50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Norway	INFINITI QX50	I50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Norway	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Norway	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Norway	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Norway	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Norway	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Norway	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Norway	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Norway	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429

Norway	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Norway	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Norway	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Norway	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Norway	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Norway	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Norway	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Norway	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Norway	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Norway	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Norway	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Norway	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Norway	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Norway	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Norway	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Norway	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Norway	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Norway	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Norway	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Norway	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Norway	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Norway	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Norway	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Norway	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Norway	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Norway	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Norway	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Norway	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Norway	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Norway	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Norway	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Norway	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Norway	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Norway	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Norway	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Norway	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Norway	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Norway	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Norway	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Norway	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Norway	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Norway	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Oman	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Oman	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Oman	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Oman	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Oman	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Oman	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Oman	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Oman	INFINITI EX35	I50	2008.1-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Oman	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Oman	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Oman	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Oman	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Oman	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI EX35/EX37	I50	2011.1-	Air bag	√	√	√	√		
Oman	INFINITI EX35/EX37	I50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Oman	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Oman	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Oman	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Oman	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Oman	INFINITI EX35/EX37	I50	2011.1-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Oman	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Oman	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Oman	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Oman	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Oman	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Oman	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Oman	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Oman	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Oman	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Oman	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Oman	INFINITI FX35/FX45	S50	2005.3-	Motor control						

Oman	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Oman	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Oman	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Oman	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Oman	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Oman	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Oman	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Oman	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Oman	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Oman	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Oman	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Oman	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Oman	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Oman	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Oman	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Oman	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Oman	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Oman	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Oman	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Oman	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Oman	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Oman	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Oman	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Oman	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Oman	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Oman	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Oman	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Oman	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Oman	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Oman	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Oman	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Oman	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Oman	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Oman	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Oman	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Oman	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Oman	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Oman	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Oman	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Oman	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Oman	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Oman	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Oman	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Oman	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Oman	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Oman	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Oman	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Oman	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Oman	INFINITI G35 COUPE	CV35	2005.1-	Motor control						

Oman	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Oman	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Oman	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Oman	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Oman	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Oman	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Oman	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Oman	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Oman	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Oman	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Oman	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Oman	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Oman	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Oman	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Oman	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Oman	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Oman	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Oman	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Oman	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Oman	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Oman	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Oman	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Oman	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Oman	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Oman	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Oman	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Oman	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Oman	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Oman	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Oman	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Oman	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Oman	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Oman	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Oman	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Oman	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Oman	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Oman	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Oman	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Oman	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Oman	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Oman	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Oman	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Oman	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Oman	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Oman	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Oman	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Oman	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Oman	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Oman	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Oman	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Oman	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Oman	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Oman	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Oman	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Oman	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Oman	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Oman	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Oman	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Oman	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Oman	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Oman	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Oman	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Oman	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Oman	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Oman	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Oman	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Oman	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Oman	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Oman	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Oman	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Oman	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Oman	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Oman	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Oman	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Oman	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Oman	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Oman	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Oman	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Oman	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Oman	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Oman	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Oman	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Oman	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Oman	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Oman	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Oman	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Oman	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Oman	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Oman	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Oman	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Oman	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Oman	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Oman	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Oman	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0276, SP0278, SP0279
Oman	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Oman	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Oman	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Oman	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Oman	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Oman	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Oman	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Oman	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Oman	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Oman	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Oman	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Oman	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Oman	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Oman	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Oman	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Oman	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Oman	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Oman	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Oman	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Oman	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562

Oman	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Oman	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Oman	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Oman	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Oman	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Oman	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Oman	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Oman	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Oman	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Oman	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Oman	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Oman	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0174, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Oman	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Oman	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Oman	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Oman	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Oman	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Oman	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Oman	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Oman	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Oman	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Oman	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Oman	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Oman	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Oman	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Oman	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Oman	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Oman	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Oman	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Oman	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Oman	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Oman	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Oman	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Oman	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Oman	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Oman	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Oman	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Oman	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Oman	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Oman	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Oman	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Oman	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Oman	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Oman	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Oman	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Oman	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Oman	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Oman	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Oman	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Oman	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Oman	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		

Oman	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Oman	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Oman	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Oman	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Oman	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Oman	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Oman	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Oman	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Oman	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Oman	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Oman	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Oman	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Oman	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Oman	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Oman	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Oman	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Oman	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Oman	INFINITI Q45	F50	2001.8-	Motor control						
Oman	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Oman	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Oman	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Oman	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Oman	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Oman	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Oman	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Oman	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Oman	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Oman	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Oman	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Oman	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Oman	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Oman	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Oman	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Oman	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Oman	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Oman	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Oman	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Oman	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Oman	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Oman	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Oman	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Oman	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Oman	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Oman	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Oman	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Oman	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Oman	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Oman	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Oman	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Oman	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Oman	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Oman	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Oman	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Oman	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Oman	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Oman	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Oman	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Oman	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Oman	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Oman	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Oman	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Oman	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Oman	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Oman	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Oman	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Oman	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Oman	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Oman	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Oman	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Oman	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Oman	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Oman	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Oman	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Oman	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Oman	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Oman	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Oman	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Oman	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Oman	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		

Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Oman	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Oman	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Oman	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Oman	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Oman	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Oman	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Oman	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Oman	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Oman	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Oman	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Oman	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Oman	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Oman	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Oman	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Oman	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Oman	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Oman	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Oman	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Oman	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Oman	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Oman	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Oman	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Oman	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Oman	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Oman	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Oman	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Oman	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Oman	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Oman	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Oman	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Oman	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Oman	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Oman	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Oman	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Oman	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Oman	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Oman	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Oman	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Oman	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Oman	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Oman	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Oman	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Oman	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Oman	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Oman	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Oman	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Oman	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Oman	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Oman	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Oman	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Oman	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Oman	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Oman	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Oman	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Oman	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Oman	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Oman	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Oman	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Oman	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Oman	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Oman	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Oman	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Oman	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Oman	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Oman	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Oman	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Oman	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Oman	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Oman	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Oman	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Oman	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Oman	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Oman	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Oman	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Oman	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Oman	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Oman	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Oman	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Oman	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Oman	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Oman	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Oman	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Oman	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Oman	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Oman	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Oman	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Oman	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Oman	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Oman	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Oman	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Oman	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Oman	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Oman	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Oman	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Oman	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Oman	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Oman	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Oman	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Oman	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Oman	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Oman	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588

Oman	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Oman	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Oman	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Oman	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Oman	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Oman	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Oman	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Oman	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Oman	INFINITI QX50	J55	2018.5-	Shift						
Oman	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Oman	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Oman	INFINITI QX50	I55	2018.5-	DAST 2	√	√	√	√		
Oman	INFINITI QX50	I55	2018.5-	AVM	√	√	√	√	AC0983. AC0984. AC0985. AC0986. AC0987. AC0988. AC0989. AC0990	SP0563. SP0564. SP0565. SP0566. SP0567
Oman	INFINITI QX50	I55	2018.5-	CAN gateway	√	√	√	√		
Oman	INFINITI QX50	I55	2018.5-	Lane camera	√	√	√	√		
Oman	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Oman	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Oman	INFINITI QX50	J55	2018.5-	ANC						
Oman	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Oman	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Oman	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Oman	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Oman	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Oman	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Oman	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Oman	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Oman	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Oman	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Oman	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Oman	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Oman	INFINITI QX56	JA60	2004.10-	Motor control						
Oman	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Oman	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Oman	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Oman	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Oman	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Oman	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Oman	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Oman	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Oman	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Oman	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983. AC0984. AC0985. AC0986. AC0987. AC0988. AC0989. AC0990	SP0563. SP0564. SP0565. SP0566. SP0567
Oman	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Oman	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Oman	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Oman	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Oman	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Oman	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Oman	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Oman	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Oman	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Oman	INFINITI QX56	IA60	2004.10-	S/blind camera	√			√		SP0572. SP0573
Oman	INFINITI QX56	IA60	2004.10-	Air levelizer	√	√	√	√	AC0991. AC0992. AC0993	
Oman	INFINITI QX56	IA60	2004.10-	Nats immu	√	√	√			
Oman	INFINITI QX56	IA60	2004.10-	Rearview camera	√			√		SP0570. SP0571
Oman	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Oman	INFINITI QX56	Z62	2010.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Oman	INFINITI QX56	Z62	2010.3-	Laser/radar	√	√	√	√		
Oman	INFINITI QX56	Z62	2010.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI QX56	Z62	2010.3-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Oman	INFINITI QX56	Z62	2010.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI QX56	Z62	2010.3-	Air bag	√	√	√	√		
Oman	INFINITI QX56	Z62	2010.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Oman	INFINITI QX56	Z62	2010.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI QX56	Z62	2010.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Oman	INFINITI QX56	Z62	2010.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Oman	INFINITI QX56	Z62	2010.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Oman	INFINITI QX56	Z62	2010.3-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI QX56	Z62	2010.3-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Oman	INFINITI QX56	Z62	2010.3-	E-SUS	√	√	√	√	AC1031. AC1032. AC1033	SP0585. SP0586. SP0587
Oman	INFINITI QX56	Z62	2010.3-	Auto drive position	√	√	√	√	AC0946. AC0947. AC0948. AC0950. AC0951. AC0952. AC0953. AC0954. AC0955	SP0541. SP0542. SP0543
Oman	INFINITI QX56	Z62	2010.3-	Auto back door	√	√	√	√		
Oman	INFINITI QX56	Z62	2010.3-	Occupant detection			√	√		SP0584
Oman	INFINITI QX56	Z62	2010.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Oman	INFINITI QX56	Z62	2010.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI QX56	Z62	2010.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI QX56	Z62	2010.3-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Oman	INFINITI QX56	Z62	2010.3-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI QX56	Z62	2010.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI QX56	Z62	2010.3-	CAN gateway	√	√	√			
Oman	INFINITI QX56	Z62	2010.3-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Oman	INFINITI QX56	Z62	2010.3-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI QX56	Z62	2010.3-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Oman	INFINITI QX56	Z62	2010.3-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI QX56	Z62	2010.3-	Rearview camera	√			√		SP0570, SP0571
Oman	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Oman	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Oman	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Oman	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Oman	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Oman	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Oman	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		

Oman	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Oman	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Oman	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Oman	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Oman	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Oman	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Oman	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Oman	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Oman	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Oman	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Oman	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Oman	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Oman	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Oman	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Oman	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Oman	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Oman	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Oman	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Oman	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Oman	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Oman	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Oman	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Oman	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Oman	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Oman	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Oman	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Oman	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Oman	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Oman	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Oman	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Oman	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Oman	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Oman	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Oman	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Oman	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Oman	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Oman	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Oman	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Oman	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Oman	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Oman	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Oman	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Oman	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Oman	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Oman	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Oman	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Oman	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Oman	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Oman	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Oman	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Oman	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Oman	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Oman	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Oman	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Oman	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Oman	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Oman	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Oman	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Oman	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Oman	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Oman	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Oman	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Oman	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Oman	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Oman	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Oman	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Oman	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Oman	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Oman	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Oman	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Oman	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Oman	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Oman	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Oman	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Oman	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Oman	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Oman	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Oman	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Oman	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Oman	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Oman	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Oman	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Oman	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Oman	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Pakistan	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Laser/radar	√	√	√	√		
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Air bag	√	√	√	√		
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	EPS/DAST 3	√	√	√	√		SP0507
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Motor control	√	√	√	√		
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Pop up hood	√	√	√	√		
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Multi AV	√	√	√	√		SP0503
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	HV battery	√	√	√	√	AC1121	
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Occupant detection			√	√		SP0584
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	DAST 2	√	√	√	√		
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Precrash seatbelt	√	√	√	√		SP0612
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	CAN gateway	√	√	√			
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	DAST 1	√	√	√	√		
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	ANC	√	√	√	√	AC1024	
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Side radar left	√	√	√	√	AC1025	SP0582

Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	HIGH BEAM ASSIST	√	√	√	√		
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Side radar right	√	√	√	√	AC1026	SP0583
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	Brake	√	√	√	√	AC1127	
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	FSCM	√	√	√	√	AC1109	
Pakistan	INFINITI Q50 HYBRID	HV37	2016.3-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Panama	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Panama	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Panama	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Panama	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Panama	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270,SP0274
Panama	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Panama	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Panama	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Panama	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Panama	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Panama	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Panama	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Panama	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Panama	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Panama	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Panama	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Panama	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Panama	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Panama	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Panama	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Panama	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Panama	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Panama	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Panama	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Panama	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Panama	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Panama	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Panama	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Panama	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0556,SP0557
Panama	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Panama	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Panama	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Panama	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Panama	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570,SP0571
Panama	INFINITI FX37	S51	2012.6-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Panama	INFINITI FX37	S51	2012.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI FX37	S51	2012.6-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Panama	INFINITI FX37	S51	2012.6-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Panama	INFINITI FX37	S51	2012.6-	Air bag	√	√	√	√		
Panama	INFINITI FX37	S51	2012.6-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0350
Panama	INFINITI FX37	S51	2012.6-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Panama	INFINITI FX37	S51	2012.6-	Transmission	√	√	√	√		SP0274
Panama	INFINITI FX37	S51	2012.6-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Panama	INFINITI FX37	S51	2012.6-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	
Panama	INFINITI FX37	S51	2012.6-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Panama	INFINITI FX37	S51	2012.6-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI FX37	S51	2012.6-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Panama	INFINITI FX37	S51	2012.6-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Panama	INFINITI FX37	S51	2012.6-	Auto back door	√	√	√	√		SP0611
Panama	INFINITI FX37	S51	2012.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Panama	INFINITI FX37	S51	2012.6-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Panama	INFINITI FX37	S51	2012.6-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0556,SP0557
Panama	INFINITI FX37	S51	2012.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI FX37	S51	2012.6-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Panama	INFINITI FX37	S51	2012.6-	CAN gateway	√	√	√			
Panama	INFINITI FX37	S51	2012.6-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562

Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Panama	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Panama	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Panama	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Panama	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Panama	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Panama	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Panama	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Panama	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Panama	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Panama	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Panama	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Panama	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Panama	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Panama	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Panama	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Panama	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Panama	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Panama	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Panama	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Panama	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Panama	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Panama	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Panama	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Panama	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Panama	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Panama	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Panama	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Panama	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Panama	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Panama	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI M37	Y51	2012.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Panama	INFINITI M37	Y51	2012.4-	Laser/radar	√	√	√	√		
Panama	INFINITI M37	Y51	2012.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI M37	Y51	2012.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Panama	INFINITI M37	Y51	2012.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Panama	INFINITI M37	Y51	2012.4-	Air bag	√	√	√	√		
Panama	INFINITI M37	Y51	2012.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Panama	INFINITI M37	Y51	2012.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Panama	INFINITI M37	Y51	2012.4-	Transmission	√	√	√	√		SP0274
Panama	INFINITI M37	Y51	2012.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Panama	INFINITI M37	Y51	2012.4-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Panama	INFINITI M37	Y51	2012.4-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI M37	Y51	2012.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Panama	INFINITI M37	Y51	2012.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Panama	INFINITI M37	Y51	2012.4-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Panama	INFINITI M37	Y51	2012.4-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Panama	INFINITI M37	Y51	2012.4-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Panama	INFINITI M37	Y51	2012.4-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Panama	INFINITI M37	Y51	2012.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI M37	Y51	2012.4-	CAN gateway	√	√	√			
Panama	INFINITI M37	Y51	2012.4-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Panama	INFINITI M37	Y51	2012.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI M37	Y51	2012.4-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI M37	Y51	2012.4-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Panama	INFINITI M37	Y51	2012.4-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Panama	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Panama	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Panama	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Panama	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Panama	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Panama	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Panama	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Panama	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Panama	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Panama	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Panama	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Panama	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Panama	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Panama	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Panama	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Panama	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Panama	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Panama	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Panama	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Panama	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Panama	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Panama	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Panama	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
Panama	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Panama	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Panama	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Panama	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Panama	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Panama	INFINITI Q45	F50	2001.8-	Motor control						
Panama	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Panama	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
Panama	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
Panama	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Panama	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Panama	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Panama	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Panama	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Panama	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Panama	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Panama	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Panama	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Panama	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Panama	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Panama	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Panama	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Panama	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Panama	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Panama	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Panama	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Panama	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Panama	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Panama	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572,SP0573
Panama	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Panama	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Panama	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570,SP0571
Panama	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Panama	INFINITI Q50	V37	2013.12-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Panama	INFINITI Q50	V37	2013.12-	Laser/radar	√	√	√	√	AC0994	
Panama	INFINITI Q50	V37	2013.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI Q50	V37	2013.12-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Panama	INFINITI Q50	V37	2013.12-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Panama	INFINITI Q50	V37	2013.12-	Air bag	√	√	√	√		
Panama	INFINITI Q50	V37	2013.12-	EPS/DAST 3	√	√	√	√		SP0507
Panama	INFINITI Q50	V37	2013.12-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Panama	INFINITI Q50	V37	2013.12-	Motor control	√	√	√	√		
Panama	INFINITI Q50	V37	2013.12-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Panama	INFINITI Q50	V37	2013.12-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274,SP0276
Panama	INFINITI Q50	V37	2013.12-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429

Panama	INFINITI Q50	V37	2013.12-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Panama	INFINITI Q50	V37	2013.12-	Pop up hood	√	√	√	√		
Panama	INFINITI Q50	V37	2013.12-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI Q50	V37	2013.12-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Panama	INFINITI Q50	V37	2013.12-	HV battery	√	√	√	√	AC1121	
Panama	INFINITI Q50	V37	2013.12-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Panama	INFINITI Q50	V37	2013.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Panama	INFINITI Q50	V37	2013.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI Q50	V37	2013.12-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Panama	INFINITI Q50	V37	2013.12-	Occupant detection			√	√		SP0584
Panama	INFINITI Q50	V37	2013.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Panama	INFINITI Q50	V37	2013.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Panama	INFINITI Q50	V37	2013.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Panama	INFINITI Q50	V37	2013.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Panama	INFINITI Q50	V37	2013.12-	DAST 2	√	√	√	√		
Panama	INFINITI Q50	V37	2013.12-	Precrash seatbelt	√	√	√	√		SP0612
Panama	INFINITI Q50	V37	2013.12-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI Q50	V37	2013.12-	CAN gateway	√	√	√			
Panama	INFINITI Q50	V37	2013.12-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Panama	INFINITI Q50	V37	2013.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI Q50	V37	2013.12-	DAST 1	√	√	√	√		
Panama	INFINITI Q50	V37	2013.12-	ADCM	√	√	√	√		SP0604. SP0605. SP0606
Panama	INFINITI Q50	V37	2013.12-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Panama	INFINITI Q50	V37	2013.12-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Panama	INFINITI Q50	V37	2013.12-	ANC	√	√	√	√	AC1024	
Panama	INFINITI Q50	V37	2013.12-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI Q50	V37	2013.12-	EMCM	√	√	√	√	AC1111, AC1112	SP0608. SP0609. SP0610
Panama	INFINITI Q50	V37	2013.12-	Telematics	√	√	√	√		SP0590. SP0591. SP0592
Panama	INFINITI Q50	V37	2013.12-	HIGH BEAM ASSIST	√	√	√	√		
Panama	INFINITI Q50	V37	2013.12-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI Q50	V37	2013.12-	Brake	√	√	√	√	AC1127	
Panama	INFINITI Q50	V37	2013.12-	6ch CAN GATEWAY	√	√	√	√		
Panama	INFINITI Q50	V37	2013.12-	3ch CAN GATEWAY	√	√	√	√		
Panama	INFINITI Q50	V37	2013.12-	ICC/ADAS 2	√	√	√	√		
Panama	INFINITI Q50	V37	2013.12-	PMAS	√	√	√	√		
Panama	INFINITI Q50	V37	2013.12-	FSCM	√	√	√	√	AC1109	
Panama	INFINITI Q50	V37	2013.12-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811. AC0815. AC0816. AC0817. AC0818. AC0819. AC0821. AC0822. AC0825. AC0831	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		SP0507
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590. SP0591. SP0592
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	6ch CAN GATEWAY	√	√	√	√		
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	FSCM	√	√	√	√	AC1109	
Panama	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Laser/radar	√	√	√	√		
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Air bag	√	√	√	√		
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	EPS/DAST 3	√	√	√	√		
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Meter/M&A	√	√	√	√		SP0348. SP0349. SP0350. SP0351
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Motor control	√	√	√	√		
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Transmission	√	√	√	√		SP0276
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Pop up hood	√	√	√	√		
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	HV battery	√	√	√	√	AC1121	
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Occupant detection			√	√		SP0584
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	All mode AWD/4WD	√	√	√	√	AC0956	

Panama	INFINITI Q50 Hybrid	HV37	2018.6-	DAST 2	√	√	√	√		
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Precrash seatbelt	√	√	√	√		SP0612
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	DAST 1	√	√	√	√		
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	ANC	√	√	√	√	AC1024	
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	HIGH BEAM ASSIST	√	√	√	√		
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	VSP	√	√	√	√		
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	Brake	√	√	√	√	AC1127	
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	6ch CAN GATEWAY	√	√	√	√		
Panama	INFINITI Q50 Hybrid	HV37	2018.6-	ICC/ADAS 2	√	√	√	√		
Panama	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Panama	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Panama	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Panama	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Panama	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Panama	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Panama	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Panama	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Panama	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Panama	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Panama	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Panama	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Panama	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Panama	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Panama	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Panama	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Panama	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Panama	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Panama	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Panama	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Panama	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Panama	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Panama	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Panama	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Panama	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Panama	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Panama	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Panama	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Panama	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Panama	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Panama	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Panama	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Laser/radar	√	√	√	√	AC0994	
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Air bag	√	√	√	√		
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	EPS/DAST 3	√	√	√	√		SP0507
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Transmission	√	√	√	√		SP0274
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Pop up hood	√	√	√	√		
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	Precrash seatbelt	√	√	√	√		
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI Q60 CONVERTIBLE	HV36	2014.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI Q60 COUPE	CV36	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Panama	INFINITI Q60 COUPE	CV36	2013.6-	Laser/radar	√	√	√	√	AC0994	
Panama	INFINITI Q60 COUPE	CV36	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI Q60 COUPE	CV36	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Panama	INFINITI Q60 COUPE	CV36	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Panama	INFINITI Q60 COUPE	CV36	2013.6-	Air bag	√	√	√	√		
Panama	INFINITI Q60 COUPE	CV36	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Panama	INFINITI Q60 COUPE	CV36	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Panama	INFINITI Q60 COUPE	CV36	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Panama	INFINITI Q60 COUPE	CV36	2013.6-	Transmission	√	√	√	√		SP0274
Panama	INFINITI Q60 COUPE	CV36	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Panama	INFINITI Q60 COUPE	CV36	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Panama	INFINITI Q60 COUPE	CV36	2013.6-	Pop up hood	√	√	√	√		
Panama	INFINITI Q60 COUPE	CV36	2013.6-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI Q60 COUPE	CV36	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Panama	INFINITI Q60 COUPE	CV36	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Panama	INFINITI Q60 COUPE	CV36	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI Q60 COUPE	CV36	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Panama	INFINITI Q60 COUPE	CV36	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Panama	INFINITI Q60 COUPE	CV36	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Panama	INFINITI Q60 COUPE	CV36	2013.6-	Precrash seatbelt	√	√	√	√		
Panama	INFINITI Q60 COUPE	CV36	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI Q60 COUPE	CV36	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI Q70	Y51	2013.11-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Panama	INFINITI Q70	Y51	2013.11-	Laser/radar	√	√	√	√		
Panama	INFINITI Q70	Y51	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI Q70	Y51	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Panama	INFINITI Q70	Y51	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Panama	INFINITI Q70	Y51	2013.11-	Air bag	√	√	√	√		
Panama	INFINITI Q70	Y51	2013.11-	EPS/DAST 3	√	√	√	√		
Panama	INFINITI Q70	Y51	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Panama	INFINITI Q70	Y51	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Panama	INFINITI Q70	Y51	2013.11-	Transmission	√	√	√	√		SP0274
Panama	INFINITI Q70	Y51	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Panama	INFINITI Q70	Y51	2013.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Panama	INFINITI Q70	Y51	2013.11-	Pop up hood	√	√	√	√		
Panama	INFINITI Q70	Y51	2013.11-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI Q70	Y51	2013.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Panama	INFINITI Q70	Y51	2013.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Panama	INFINITI Q70	Y51	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI Q70	Y51	2013.11-	Occupant detection			√	√		SP0584
Panama	INFINITI Q70	Y51	2013.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Panama	INFINITI Q70	Y51	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Panama	INFINITI Q70	Y51	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Panama	INFINITI Q70	Y51	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Panama	INFINITI Q70	Y51	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Panama	INFINITI Q70	Y51	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI Q70	Y51	2013.11-	CAN gateway	√	√	√	√		
Panama	INFINITI Q70	Y51	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Panama	INFINITI Q70	Y51	2013.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI Q70	Y51	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Panama	INFINITI Q70	Y51	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI Q70	Y51	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Panama	INFINITI Q70	Y51	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI QX30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	Air bag	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	EPS/DAST 3	√	√	√			
Panama	INFINITI QX30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Panama	INFINITI QX30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Panama	INFINITI QX30	H15	2016.4-	EHS/PKB	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	Transmission	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Panama	INFINITI QX30	H15	2016.4-	ABS	√	√	√	√		SP0308
Panama	INFINITI QX30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Panama	INFINITI QX30	H15	2016.4-	HVAC	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	Auto drive position	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	Shift	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	AVM	√	√		√		
Panama	INFINITI QX30	H15	2016.4-	Intelligent key	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	CAN gateway	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	ANC	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	Telematics	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	FSCM	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	Siren control unit	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Panama	INFINITI QX30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Panama	INFINITI QX30	H15	2016.4-	Universal Garage Door Opener	√			√		
Panama	INFINITI QX30	H15	2016.4-	Upper control panel cont unit	√					
Panama	INFINITI QX30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Panama	INFINITI QX30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Panama	INFINITI QX30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Panama	INFINITI QX30	H15	2016.4-	EC Mirror Compass	√					
Panama	INFINITI QX30	H15	2016.4-	Intelligent Battery Sensor	√					
Panama	INFINITI QX30	H15	2016.4-	Alarm siren	√			√		
Panama	INFINITI QX30	H15	2016.4-	Radar sensor	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	Steering column cont module	√	√	√			
Panama	INFINITI QX30	H15	2016.4-	ICC sensor	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	H/L control module LH	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	Side radar LH	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	LED H/L control module LH	√			√		
Panama	INFINITI QX30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Panama	INFINITI QX30	H15	2016.4-	Parking assist	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	Occupant Classification Unit	√			√		
Panama	INFINITI QX30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	H/L control module RH	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	Front camera unit	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	Side radar RH	√	√	√	√		
Panama	INFINITI QX30	H15	2016.4-	LED H/L control module RH	√			√		
Panama	INFINITI QX50	J50	2014.4-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Panama	INFINITI QX50	J50	2014.4-	Laser/radar	√	√	√	√	AC0994	
Panama	INFINITI QX50	J50	2014.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Panama	INFINITI QX50	J50	2014.4-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Panama	INFINITI QX50	J50	2014.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Panama	INFINITI QX50	J50	2014.4-	Air bag	√	√	√	√		
Panama	INFINITI QX50	J50	2014.4-	EPS/DAST 3	√	√	√	√		SP0507
Panama	INFINITI QX50	J50	2014.4-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Panama	INFINITI QX50	J50	2014.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Panama	INFINITI QX50	J50	2014.4-	Transmission	√	√	√	√		SP0274
Panama	INFINITI QX50	J50	2014.4-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Panama	INFINITI QX50	J50	2014.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Panama	INFINITI QX50	J50	2014.4-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI QX50	J50	2014.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI QX50	J50	2014.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Panama	INFINITI QX50	J50	2014.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Panama	INFINITI QX50	J50	2014.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Panama	INFINITI QX50	J50	2014.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI QX50	J50	2014.4-	Precrash seatbelt	√	√	√	√		SP0612
Panama	INFINITI QX50	J50	2014.4-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI QX50	J50	2014.4-	CAN gateway	√	√	√	√		
Panama	INFINITI QX50	J50	2014.4-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Panama	INFINITI QX50	J50	2014.4-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Panama	INFINITI QX50	J50	2014.4-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI QX50	J50	2014.4-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Panama	INFINITI QX50	J50	2014.4-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Panama	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Panama	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Panama	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Panama	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Panama	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Panama	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Panama	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Panama	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Panama	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Panama	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Panama	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Panama	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Panama	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Panama	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Panama	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Panama	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Panama	INFINITI QX50	J55	2018.5-	Shift						
Panama	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Panama	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Panama	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Panama	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Panama	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Panama	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Panama	INFINITI QX50	I55	2018.5-	Lane camera	√	√	√	√		
Panama	INFINITI QX50	I55	2018.5-	DAST 1	√	√	√	√		
Panama	INFINITI QX50	I55	2018.5-	Chassis control	√	√	√	√		
Panama	INFINITI QX50	I55	2018.5-	ANC						
Panama	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Panama	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Panama	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Panama	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Panama	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Panama	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Panama	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Panama	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Panama	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Panama	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Panama	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Panama	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Panama	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Panama	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Panama	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Panama	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Panama	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Panama	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Panama	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Panama	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Panama	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Panama	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Panama	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Panama	INFINITI QX56	Z62	2011.8-	Precrash seatbelt	√	√	√	√		SP0612
Panama	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Panama	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Panama	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Panama	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI QX60	L50	2014.12-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Panama	INFINITI QX60	L50	2014.12-	Laser/radar	√	√	√	√	AC0994	
Panama	INFINITI QX60	L50	2014.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI QX60	L50	2014.12-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Panama	INFINITI QX60	L50	2014.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Panama	INFINITI QX60	L50	2014.12-	Air bag	√	√	√	√		
Panama	INFINITI QX60	L50	2014.12-	EPS/DAST 3	√	√	√	√		
Panama	INFINITI QX60	L50	2014.12-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Panama	INFINITI QX60	L50	2014.12-	Motor control	√	√	√	√		

Xtool

Panama	INFINITI QX60	L50	2014.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Panama	INFINITI QX60	L50	2014.12-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Panama	INFINITI QX60	L50	2014.12-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Panama	INFINITI QX60	L50	2014.12-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Panama	INFINITI QX60	L50	2014.12-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI QX60	L50	2014.12-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Panama	INFINITI QX60	L50	2014.12-	HV battery	√	√	√	√	AC1121	
Panama	INFINITI QX60	L50	2014.12-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI QX60	L50	2014.12-	Auto back door	√	√	√	√		SP0611
Panama	INFINITI QX60	L50	2014.12-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Panama	INFINITI QX60	L50	2014.12-	Occupant detection			√	√		SP0584
Panama	INFINITI QX60	L50	2014.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Panama	INFINITI QX60	L50	2014.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Panama	INFINITI QX60	L50	2014.12-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI QX60	L50	2014.12-	Precrash seatbelt	√	√	√	√		SP0612
Panama	INFINITI QX60	L50	2014.12-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI QX60	L50	2014.12-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Panama	INFINITI QX60	L50	2014.12-	CAN gateway	√	√	√			
Panama	INFINITI QX60	L50	2014.12-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Panama	INFINITI QX60	L50	2014.12-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Panama	INFINITI QX60	L50	2014.12-	ANC	√	√	√	√	AC1024	
Panama	INFINITI QX60	L50	2014.12-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI QX60	L50	2014.12-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Panama	INFINITI QX60	L50	2014.12-	HIGH BEAM ASSIST	√	√	√	√		
Panama	INFINITI QX60	L50	2014.12-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI QX60	L50	2014.12-	3ch CAN GATEWAY	√	√	√	√		
Panama	INFINITI QX60	L50	2014.12-	ICC/ADAS 2	√	√	√	√		
Panama	INFINITI QX60	L50	2014.12-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Panama	INFINITI QX60	L50	2014.12-	A-IVC(Renault common)	√	√	√	√		
Panama	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Panama	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Panama	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Panama	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Panama	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Panama	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Panama	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Panama	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Panama	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Panama	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Panama	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Panama	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Panama	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Panama	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Panama	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Panama	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Panama	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Panama	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Panama	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Panama	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Panama	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Panama	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Panama	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Panama	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Panama	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Panama	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Panama	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Panama	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Panama	INFINITI QX80	Z62	2014.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Panama	INFINITI QX80	Z62	2014.1-	Laser/radar	√	√	√	√	AC0994	
Panama	INFINITI QX80	Z62	2014.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Panama	INFINITI QX80	Z62	2014.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Panama	INFINITI QX80	Z62	2014.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Panama	INFINITI QX80	Z62	2014.1-	Air bag	√	√	√	√		
Panama	INFINITI QX80	Z62	2014.1-	EPS/DAST 3	√	√	√	√		SP0507
Panama	INFINITI QX80	Z62	2014.1-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Panama	INFINITI QX80	Z62	2014.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Panama	INFINITI QX80	Z62	2014.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Panama	INFINITI QX80	Z62	2014.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Panama	INFINITI QX80	Z62	2014.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Panama	INFINITI QX80	Z62	2014.1-	Multi AV	√	√	√	√		SP0503
Panama	INFINITI QX80	Z62	2014.1-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Panama	INFINITI QX80	Z62	2014.1-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Panama	INFINITI QX80	Z62	2014.1-	Difference lock	√	√	√	√		
Panama	INFINITI QX80	Z62	2014.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Panama	INFINITI QX80	Z62	2014.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Panama	INFINITI QX80	Z62	2014.1-	Auto back door	√	√	√	√		
Panama	INFINITI QX80	Z62	2014.1-	Occupant detection			√	√		SP0584
Panama	INFINITI QX80	Z62	2014.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Panama	INFINITI QX80	Z62	2014.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Panama	INFINITI QX80	Z62	2014.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Panama	INFINITI QX80	Z62	2014.1-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Panama	INFINITI QX80	Z62	2014.1-	Precrash seatbelt	√	√	√	√		SP0612
Panama	INFINITI QX80	Z62	2014.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Panama	INFINITI QX80	Z62	2014.1-	CAN gateway	√	√	√			
Panama	INFINITI QX80	Z62	2014.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Panama	INFINITI QX80	Z62	2014.1-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Panama	INFINITI QX80	Z62	2014.1-	Side radar left	√	√	√	√	AC1025	SP0582
Panama	INFINITI QX80	Z62	2014.1-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Panama	INFINITI QX80	Z62	2014.1-	HIGH BEAM ASSIST	√	√	√	√		
Panama	INFINITI QX80	Z62	2014.1-	Side radar right	√	√	√	√	AC1026	SP0583
Panama	INFINITI QX80	Z62	2014.1-	Vehicle data transmitter	√	√	√	√		
Panama	INFINITI QX80	Z62	2014.1-	6ch CAN GATEWAY	√	√	√	√		
Panama	INFINITI QX80	Z62	2014.1-	ICC/ADAS 2	√	√	√	√		
Panama	INFINITI QX80	Z62	2014.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Paraguay	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Paraguay	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Paraguay	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Paraguay	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Paraguay	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Paraguay	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Paraguay	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Paraguay	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Paraguay	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Paraguay	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Paraguay	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Paraguay	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Paraguay	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Paraguay	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Paraguay	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Paraguay	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Paraguay	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Paraguay	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Paraguay	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Paraguay	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Paraguay	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Paraguay	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Paraguay	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Paraguay	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Paraguay	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Paraguay	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Paraguay	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Paraguay	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503

XTOOL

Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Paraguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Paraguay	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Paraguay	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Paraguay	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Paraguay	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Paraguay	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Paraguay	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Paraguay	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Paraguay	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Paraguay	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Paraguay	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Paraguay	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Paraguay	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Paraguay	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Paraguay	INFINITI TX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Paraguay	INFINITI TX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Paraguay	INFINITI TX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Paraguay	INFINITI TX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Paraguay	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Paraguay	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Paraguay	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Paraguay	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Paraguay	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Paraguay	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Paraguay	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Paraguay	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Paraguay	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Paraguay	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Paraguay	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Paraguay	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Paraguay	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Paraguay	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Paraguay	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Paraguay	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Paraguay	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Paraguay	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Paraguay	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Paraguay	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Paraguay	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Paraguay	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Paraguay	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Paraguay	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Paraguay	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Paraguay	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Paraguay	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Paraguay	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Paraguay	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Paraguay	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Paraguay	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Paraguay	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Paraguay	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Paraguay	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Paraguay	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Paraguay	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Paraguay	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Paraguay	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Paraguay	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Paraguay	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Paraguay	INFINITI Q45	F50	2001.8-	Motor control						
Paraguay	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Paraguay	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Paraguay	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Paraguay	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Paraguay	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Paraguay	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Paraguay	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Paraguay	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Paraguay	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Paraguay	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Paraguay	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Paraguay	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Paraguay	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Paraguay	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Paraguay	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Paraguay	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Paraguay	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Paraguay	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Paraguay	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Paraguay	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Paraguay	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Paraguay	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Paraguay	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Paraguay	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Paraguay	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Paraguay	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Paraguay	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Paraguay	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Paraguay	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Paraguay	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Paraguay	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Paraguay	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Paraguay	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Paraguay	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Paraguay	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Paraguay	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Paraguay	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Paraguay	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Paraguay	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Paraguay	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Paraguay	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Paraguay	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Paraguay	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Paraguay	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Paraguay	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Paraguay	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Paraguay	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Paraguay	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Paraguay	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Paraguay	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Paraguay	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Paraguay	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Paraguay	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Paraguay	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Paraguay	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√		SP0583
PerU	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
PerU	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
PerU	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
PerU	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
PerU	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
PerU	INFINITI EX35/EX37	I50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
PerU	INFINITI EX35/EX37	I50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
PerU	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
PerU	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
PerU	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
PerU	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
PerU	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
PerU	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
PerU	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
PerU	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
PerU	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
PerU	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
PerU	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
PerU	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
PerU	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
PerU	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
PerU	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
PerU	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
PerU	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
PerU	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
PerU	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
PerU	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
PerU	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
PerU	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
PerU	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
PerU	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
PerU	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
PerU	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
PerU	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
PerU	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
PerU	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
PerU	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
PerU	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
PerU	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
PerU	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
PerU	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
PerU	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
PerU	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580

PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
PerU	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
PerU	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
PerU	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
PerU	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
PerU	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
PerU	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
PerU	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
PerU	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
PerU	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
PerU	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
PerU	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
PerU	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
PerU	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
PerU	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
PerU	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
PerU	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
PerU	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
PerU	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
PerU	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
PerU	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
PerU	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
PerU	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
PerU	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
PerU	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
PerU	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
PerU	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
PerU	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
PerU	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
PerU	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
PerU	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
PerU	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
PerU	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

PerU	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
PerU	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029.AC1030	
PerU	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966.AC0967.AC0968	SP0557
PerU	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
PerU	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
PerU	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
PerU	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
PerU	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
PerU	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
PerU	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
PerU	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
PerU	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
PerU	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
PerU	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
PerU	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
PerU	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
PerU	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
PerU	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
PerU	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
PerU	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
PerU	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
PerU	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
PerU	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
PerU	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
PerU	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034.AC1035.AC1036.AC1037.AC1038.AC1039	
PerU	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027.AC1028	
PerU	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
PerU	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
PerU	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
PerU	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
PerU	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
PerU	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
PerU	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
PerU	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
PerU	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
PerU	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
PerU	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
PerU	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
PerU	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
PerU	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
PerU	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
PerU	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
PerU	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
PerU	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
PerU	INFINITI Q45	F50	2001.8-	Motor control						
PerU	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
PerU	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
PerU	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
PerU	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
PerU	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
PerU	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
PerU	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
PerU	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
PerU	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
PerU	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
PerU	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
PerU	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
PerU	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
PerU	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
PerU	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
PerU	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
PerU	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
PerU	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
PerU	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
PerU	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
PerU	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
PerU	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
PerU	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
PerU	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
PerU	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
PerU	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
PerU	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
PerU	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
PerU	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
PerU	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
PerU	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
PerU	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
PerU	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
PerU	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
PerU	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
PerU	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
PerU	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
PerU	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
PerU	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
PerU	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
PerU	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
PerU	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
PerU	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
PerU	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
PerU	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584

PerU	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
PerU	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
PerU	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
PerU	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544,SP0545,SP0546,SP0547,SP0548,SP0549
PerU	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
PerU	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
PerU	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
PerU	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
PerU	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
PerU	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0200,SP0202,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270,SP0274
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Philippines	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Laser/radar	√	√	√	√		
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Air bag	√	√	√	√		
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	EPS/DAST 3	√	√	√	√		SP0507
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Motor control	√	√	√	√		
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0311,AC0314,AC0315,AC0320,AC0325,AC0327,AC0330,AC0331,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Transmission	√	√	√	√		SP0247,SP0265,SP0274,SP0276
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Pop up hood	√	√	√	√		
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Multi AV	√	√	√	√		SP0503
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	HV battery	√	√	√	√	AC1121	
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Occupant detection			√	√		SP0584
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Adaptive light	√	√	√	√	AC0979,AC0981,AC0982	SP0562
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	DAST 2	√	√	√	√		
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Precrash seatbelt	√	√	√	√		SP0612
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	CAN gateway	√	√	√			
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	DAST 1	√	√	√	√		
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	ANC	√	√	√	√	AC1024	
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Side radar left	√	√	√	√	AC1025	SP0582
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	HIGH BEAM ASSIST	√	√	√	√		
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Side radar right	√	√	√	√	AC1026	SP0583
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	Brake	√	√	√	√	AC1127	
Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	FSCM	√	√	√	√	AC1109	

Philippines	INFINITI Q50 HYBRID	HV37	2016.3-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Poland	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Poland	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Poland	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Poland	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Poland	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Poland	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Poland	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Poland	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Poland	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Poland	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Poland	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Poland	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Poland	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Poland	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Poland	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Poland	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Poland	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Poland	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Poland	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI EX37	I50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Poland	INFINITI EX37	I50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI EX37	I50	2008.6-	Air bag	√	√	√	√		
Poland	INFINITI EX37	I50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Poland	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Poland	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Poland	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Poland	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Poland	INFINITI EX37	I50	2008.6-	Multi AV	√	√	√	√		
Poland	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Poland	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Poland	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Poland	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Poland	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Poland	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Poland	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Poland	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Poland	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Poland	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Poland	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Poland	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Poland	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Poland	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Poland	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Poland	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Poland	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Poland	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Poland	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Poland	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Poland	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Poland	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Poland	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Poland	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Poland	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Poland	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Poland	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Poland	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Poland	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Poland	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621

Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Poland	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Poland	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Poland	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Poland	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Poland	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Poland	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Poland	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Poland	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Poland	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Poland	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Poland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Poland	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Poland	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Poland	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Poland	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Poland	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Poland	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Poland	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Poland	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Poland	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Poland	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Poland	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Poland	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Poland	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Poland	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Poland	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Poland	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Poland	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Poland	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Poland	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Poland	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Poland	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Poland	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Poland	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Poland	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Poland	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Poland	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Poland	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Poland	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Poland	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Poland	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Poland	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Poland	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Poland	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Poland	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Poland	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Poland	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Poland	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Poland	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Poland	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Poland	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Poland	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Poland	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Poland	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Poland	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Poland	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Poland	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Poland	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Poland	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Poland	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Poland	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Poland	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Poland	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Poland	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Poland	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Poland	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Poland	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Poland	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Poland	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Poland	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Poland	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Poland	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Poland	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Poland	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Poland	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Poland	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Poland	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Poland	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Poland	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503

Poland	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Poland	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Poland	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Poland	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Poland	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Poland	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Poland	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Poland	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Poland	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Poland	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Poland	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Poland	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Poland	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Poland	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Poland	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Poland	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Poland	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Poland	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Poland	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Poland	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Poland	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Poland	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Poland	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Poland	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Poland	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Poland	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Poland	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Poland	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Poland	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Poland	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Poland	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Poland	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Poland	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Poland	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Poland	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Poland	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Poland	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Poland	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		

Poland	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Poland	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Poland	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Poland	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Poland	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Poland	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Poland	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Poland	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Poland	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Poland	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Poland	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Poland	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Poland	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Poland	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Poland	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Poland	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Poland	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Poland	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Poland	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Poland	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Poland	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Poland	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Poland	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Poland	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Poland	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Poland	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Poland	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Poland	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Poland	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Poland	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Poland	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Poland	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Poland	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Poland	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Poland	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Poland	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Poland	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Poland	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Poland	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Poland	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Poland	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Poland	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Poland	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Poland	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Poland	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Poland	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Poland	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Poland	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	

Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Poland	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Poland	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Poland	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Poland	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Poland	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Poland	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Poland	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Poland	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Poland	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Poland	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Poland	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Poland	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Poland	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Poland	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Poland	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Poland	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Poland	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Poland	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Poland	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Poland	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Poland	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Poland	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Poland	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Poland	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Poland	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Poland	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Poland	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Poland	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Poland	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Poland	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Poland	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Poland	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Poland	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Poland	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Poland	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Poland	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Poland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Poland	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Poland	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Poland	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Poland	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Poland	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Poland	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Poland	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Poland	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Poland	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Poland	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Poland	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Poland	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Poland	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Poland	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Poland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Poland	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Poland	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Poland	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Poland	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Poland	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Poland	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Poland	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Poland	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Poland	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Poland	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Poland	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Poland	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Poland	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Poland	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Poland	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Poland	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Poland	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Poland	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Poland	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Poland	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Poland	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Poland	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Poland	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Poland	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Poland	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Poland	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Poland	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Poland	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Poland	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Poland	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Poland	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Poland	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		

Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Poland	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Poland	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Poland	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Poland	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Poland	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Poland	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Poland	INFINITI QX50	I50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Poland	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Poland	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Poland	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Poland	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Poland	INFINITI QX50	I50	2013.9-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Poland	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Poland	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Poland	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Poland	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Poland	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Poland	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Poland	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Poland	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Poland	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Poland	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Poland	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Poland	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Poland	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Poland	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Poland	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Poland	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Poland	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Poland	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Poland	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Poland	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Poland	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Poland	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Poland	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Poland	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Poland	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Poland	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Poland	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Poland	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Poland	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Poland	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Poland	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Poland	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Poland	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Poland	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Poland	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Poland	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Poland	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Poland	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Poland	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621

Poland	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Poland	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Poland	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Poland	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Poland	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Poland	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Poland	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Poland	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Poland	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Poland	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Poland	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Poland	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Poland	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Poland	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Poland	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Poland	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Poland	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Poland	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Poland	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Poland	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Portugal	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0303, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Portugal	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Portugal	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Portugal	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Portugal	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Portugal	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Portugal	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Portugal	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Portugal	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Portugal	INFINITI EX37	I50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Portugal	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Portugal	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Portugal	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Portugal	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Portugal	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Portugal	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Portugal	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Portugal	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Portugal	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Portugal	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Portugal	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Portugal	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Portugal	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Portugal	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Portugal	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Portugal	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Portugal	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Portugal	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Portugal	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Portugal	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Portugal	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Portugal	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Portugal	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0303, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Portugal	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Portugal	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Portugal	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Portugal	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Portugal	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Portugal	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Portugal	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Portugal	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Portugal	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Portugal	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Portugal	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Portugal	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Portugal	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Portugal	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Portugal	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Portugal	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Portugal	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Portugal	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Portugal	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Portugal	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Portugal	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Portugal	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Portugal	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Portugal	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Portugal	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Portugal	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Portugal	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Portugal	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Portugal	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Portugal	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Portugal	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Portugal	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Portugal	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Portugal	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Portugal	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Portugal	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Portugal	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Portugal	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Portugal	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Portugal	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Portugal	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Portugal	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Portugal	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Portugal	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Portugal	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Portugal	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Portugal	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Portugal	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Portugal	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Portugal	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Portugal	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Portugal	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Portugal	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Portugal	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Portugal	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Portugal	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Portugal	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Portugal	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Portugal	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Portugal	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Portugal	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Portugal	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Portugal	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Portugal	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Portugal	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Portugal	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Portugal	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Portugal	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Portugal	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Portugal	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Portugal	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Portugal	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Portugal	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Portugal	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Portugal	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Portugal	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Portugal	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Portugal	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Portugal	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Portugal	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Portugal	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Portugal	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Portugal	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Portugal	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Portugal	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Portugal	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		

Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Portugal	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Portugal	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Portugal	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Portugal	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Portugal	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Portugal	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Portugal	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Portugal	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Portugal	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Portugal	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Portugal	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Portugal	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Portugal	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Portugal	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Portugal	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Portugal	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Portugal	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Portugal	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Portugal	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Portugal	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Portugal	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Portugal	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Portugal	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Portugal	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Portugal	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Portugal	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Portugal	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Portugal	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Portugal	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Portugal	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		

Portugal	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Portugal	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Portugal	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Portugal	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Portugal	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Portugal	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Portugal	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Portugal	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Portugal	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Portugal	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Portugal	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Portugal	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Portugal	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Portugal	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Portugal	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Portugal	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Portugal	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Portugal	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Portugal	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Portugal	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Portugal	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Portugal	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Portugal	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Portugal	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Portugal	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Portugal	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Portugal	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Portugal	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Portugal	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Portugal	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Portugal	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Portugal	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Portugal	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Portugal	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Portugal	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Portugal	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Portugal	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Portugal	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Portugal	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Portugal	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Portugal	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Portugal	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Portugal	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Portugal	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Portugal	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Portugal	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Portugal	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Portugal	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Portugal	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Portugal	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Portugal	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Portugal	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Portugal	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Portugal	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503

Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Portugal	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Portugal	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Portugal	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Portugal	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Portugal	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Portugal	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Portugal	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Portugal	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Portugal	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Portugal	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Portugal	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Portugal	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Portugal	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Portugal	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Portugal	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Portugal	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Portugal	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Portugal	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Portugal	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Portugal	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Portugal	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Portugal	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Portugal	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Portugal	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Portugal	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Portugal	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Portugal	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Portugal	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Portugal	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Portugal	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Portugal	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Portugal	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583

Portugal	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Portugal	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Portugal	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Portugal	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Portugal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Portugal	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Portugal	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Portugal	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Portugal	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Portugal	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Portugal	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Portugal	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Portugal	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Portugal	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Portugal	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Portugal	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Portugal	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Portugal	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Portugal	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Portugal	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Portugal	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Portugal	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Portugal	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Portugal	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Portugal	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Portugal	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Portugal	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Portugal	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Portugal	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Portugal	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Portugal	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Portugal	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Portugal	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Portugal	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Portugal	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Portugal	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		

Portugal	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Portugal	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Portugal	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Portugal	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Portugal	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Portugal	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Portugal	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Portugal	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Portugal	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Portugal	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Portugal	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Portugal	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Portugal	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Portugal	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Portugal	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Portugal	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Portugal	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Portugal	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Portugal	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Portugal	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Portugal	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Portugal	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Portugal	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Portugal	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Portugal	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Portugal	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Portugal	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Portugal	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Portugal	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Portugal	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Portugal	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Portugal	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Portugal	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Portugal	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Portugal	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Portugal	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Portugal	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Portugal	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Portugal	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Portugal	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Portugal	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Portugal	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Portugal	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Portugal	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Portugal	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Portugal	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Portugal	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Portugal	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Portugal	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Portugal	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Portugal	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Portugal	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Portugal	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Portugal	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Portugal	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Portugal	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Portugal	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Portugal	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Portugal	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Portugal	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Portugal	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Portugal	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Portugal	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Portugal	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Portugal	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Portugal	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Portugal	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Portugal	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Portugal	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Portugal	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Portugal	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Puerto rico	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Puerto rico	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Puerto rico	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Puerto rico	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Puerto rico	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Puerto rico	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		

Puerto rico	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Puerto rico	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Puerto rico	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Puerto rico	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Puerto rico	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Puerto rico	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Puerto rico	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Puerto rico	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Puerto rico	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Puerto rico	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Puerto rico	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Puerto rico	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Puerto rico	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Puerto rico	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Puerto rico	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Puerto rico	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Puerto rico	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Puerto rico	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Puerto rico	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Puerto rico	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Puerto rico	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Puerto rico	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Puerto rico	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Puerto rico	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Puerto rico	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Puerto rico	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Puerto rico	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Puerto rico	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Puerto rico	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Puerto rico	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Puerto rico	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Puerto rico	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Puerto rico	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Puerto rico	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Puerto rico	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Puerto rico	INFINITI Q45	F50	2001.8-	Motor control						
Puerto rico	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Puerto rico	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Puerto rico	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Puerto rico	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Puerto rico	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Puerto rico	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Puerto rico	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Puerto rico	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Puerto rico	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Puerto rico	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Puerto rico	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Puerto rico	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Puerto rico	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Puerto rico	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Puerto rico	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Puerto rico	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Puerto rico	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Puerto rico	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Puerto rico	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Puerto rico	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Puerto rico	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Puerto rico	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Puerto rico	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Puerto rico	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Puerto rico	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Puerto rico	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Puerto rico	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Puerto rico	INFINITI Q50	V37	2016.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Puerto rico	INFINITI Q50	V37	2016.6-	Laser/radar	√	√	√	√	AC0994	
Puerto rico	INFINITI Q50	V37	2016.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Puerto rico	INFINITI Q50	V37	2016.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Puerto rico	INFINITI Q50	V37	2016.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Puerto rico	INFINITI Q50	V37	2016.6-	Air bag	√	√	√	√		
Puerto rico	INFINITI Q50	V37	2016.6-	EPS/DAST 3	√	√	√	√		
Puerto rico	INFINITI Q50	V37	2016.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Puerto rico	INFINITI Q50	V37	2016.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Puerto rico	INFINITI Q50	V37	2016.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Puerto rico	INFINITI Q50	V37	2016.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Puerto rico	INFINITI Q50	V37	2016.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Puerto rico	INFINITI Q50	V37	2016.6-	Pop up hood	√	√	√	√		
Puerto rico	INFINITI Q50	V37	2016.6-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI Q50	V37	2016.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Puerto rico	INFINITI Q50	V37	2016.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI Q50	V37	2016.6-	Occupant detection			√	√		SP0584
Puerto rico	INFINITI Q50	V37	2016.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Puerto rico	INFINITI Q50	V37	2016.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Puerto rico	INFINITI Q50	V37	2016.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Puerto rico	INFINITI Q50	V37	2016.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Puerto rico	INFINITI Q50	V37	2016.6-	DAST 2	√	√	√	√		
Puerto rico	INFINITI Q50	V37	2016.6-	Precrash seatbelt	√	√	√	√		SP0612
Puerto rico	INFINITI Q50	V37	2016.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Puerto rico	INFINITI Q50	V37	2016.6-	CAN gateway	√	√	√			
Puerto rico	INFINITI Q50	V37	2016.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Puerto rico	INFINITI Q50	V37	2016.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Puerto rico	INFINITI Q50	V37	2016.6-	DAST 1	√	√	√	√		
Puerto rico	INFINITI Q50	V37	2016.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Puerto rico	INFINITI Q50	V37	2016.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Puerto rico	INFINITI Q50	V37	2016.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Puerto rico	INFINITI Q50	V37	2016.6-	ANC	√	√	√	√	AC1024	
Puerto rico	INFINITI Q50	V37	2016.6-	Side radar left	√	√	√	√	AC1025	SP0582

Puerto rico	INFINITI Q50	V37	2016.6-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Puerto rico	INFINITI Q50	V37	2016.6-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Puerto rico	INFINITI Q50	V37	2016.6-	HIGH BEAM ASSIST	√	√	√	√		
Puerto rico	INFINITI Q50	V37	2016.6-	Side radar right	√	√	√	√	AC1026	SP0583
Puerto rico	INFINITI Q50	V37	2016.6-	6ch CAN GATEWAY	√	√	√	√		
Puerto rico	INFINITI Q50	V37	2016.6-	3ch CAN GATEWAY	√	√	√	√		
Puerto rico	INFINITI Q50	V37	2016.6-	ICC/ADAS 2	√	√	√	√		
Puerto rico	INFINITI Q50	V37	2016.6-	FSCM	√	√	√	√	AC1109	
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Laser/radar	√	√	√	√		
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Air bag	√	√	√	√		
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	EPS/DAST 3	√	√	√	√		SP0507
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Motor control	√	√	√	√		
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Pop up hood	√	√	√	√		
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	HV battery	√	√	√	√	AC1121	
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Occupant detection			√	√		SP0584
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	DAST 2	√	√	√	√		
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Precrash seatbelt	√	√	√	√		SP0612
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	CAN gateway	√	√	√			
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	DAST 1	√	√	√	√		
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	ANC	√	√	√	√	AC1024	
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Side radar left	√	√	√	√	AC1025	SP0582
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	HIGH BEAM ASSIST	√	√	√	√		
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Side radar right	√	√	√	√	AC1026	SP0583
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	Brake	√	√	√	√	AC1127	
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	FSCM	√	√	√	√	AC1109	
Puerto rico	INFINITI Q50 HYBRID	HV37	2016.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Laser/radar	√	√	√	√		
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Air bag	√	√	√	√		
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	EPS/DAST 3	√	√	√	√		
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Motor control	√	√	√	√		
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Transmission	√	√	√	√		SP0276
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429

Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Pop up hood	√	√	√	√		
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	HV battery	√	√	√	√	AC1121	
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Occupant detection			√	√		SP0584
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	DAST 2	√	√	√	√		
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Precrash seatbelt	√	√	√	√		SP0612
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	DAST 1	√	√	√	√		
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	ANC	√	√	√	√	AC1024	
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Side radar left	√	√	√	√	AC1025	SP0582
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	HIGH BEAM ASSIST	√	√	√	√		
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Side radar right	√	√	√	√	AC1026	SP0583
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	VSP	√	√	√	√		
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	Brake	√	√	√	√	AC1127	
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	6ch CAN GATEWAY	√	√	√	√		
Puerto rico	INFINITI Q50 Hybrid	HV37	2018.6-	ICC/ADAS 2	√	√	√	√		
Puerto rico	INFINITI Q70	Y51	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Puerto rico	INFINITI Q70	Y51	2018.5-	Laser/radar	√	√	√	√		
Puerto rico	INFINITI Q70	Y51	2018.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Puerto rico	INFINITI Q70	Y51	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Puerto rico	INFINITI Q70	Y51	2018.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Puerto rico	INFINITI Q70	Y51	2018.5-	Air bag	√	√	√	√		
Puerto rico	INFINITI Q70	Y51	2018.5-	EPS/DAST 3	√	√	√	√		
Puerto rico	INFINITI Q70	Y51	2018.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Puerto rico	INFINITI Q70	Y51	2018.5-	Motor control	√	√	√	√		
Puerto rico	INFINITI Q70	Y51	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Puerto rico	INFINITI Q70	Y51	2018.5-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Puerto rico	INFINITI Q70	Y51	2018.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Puerto rico	INFINITI Q70	Y51	2018.5-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Puerto rico	INFINITI Q70	Y51	2018.5-	Pop up hood	√	√	√	√		
Puerto rico	INFINITI Q70	Y51	2018.5-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI Q70	Y51	2018.5-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Puerto rico	INFINITI Q70	Y51	2018.5-	HV battery	√	√	√	√	AC1121	
Puerto rico	INFINITI Q70	Y51	2018.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Puerto rico	INFINITI Q70	Y51	2018.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI Q70	Y51	2018.5-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Puerto rico	INFINITI Q70	Y51	2018.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Puerto rico	INFINITI Q70	Y51	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Puerto rico	INFINITI Q70	Y51	2018.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Puerto rico	INFINITI Q70	Y51	2018.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Puerto rico	INFINITI Q70	Y51	2018.5-	Precrash seatbelt	√	√	√	√		SP0612
Puerto rico	INFINITI Q70	Y51	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Puerto rico	INFINITI Q70	Y51	2018.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Puerto rico	INFINITI Q70	Y51	2018.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Puerto rico	INFINITI Q70	Y51	2018.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Puerto rico	INFINITI Q70	Y51	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Puerto rico	INFINITI Q70	Y51	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Puerto rico	INFINITI Q70	Y51	2018.5-	VSP	√	√	√	√		
Puerto rico	INFINITI Q70	Y51	2018.5-	Brake	√	√	√	√	AC1127	
Puerto rico	INFINITI Q70	Y51	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Puerto rico	INFINITI Q70	Y51	2018.5-	ICC/ADAS 2	√	√	√	√		
Puerto rico	INFINITI Q70	Y51	2018.5-	FSCM	√	√	√	√	AC1109	

XTOOL

Puerto rico	INFINITI QX30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	Air bag	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	EPS/DAST 3	√	√	√			
Puerto rico	INFINITI QX30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Puerto rico	INFINITI QX30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Puerto rico	INFINITI QX30	H15	2016.4-	EHS/PKB	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	Transmission	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Puerto rico	INFINITI QX30	H15	2016.4-	ABS	√	√	√	√		SP0308
Puerto rico	INFINITI QX30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Puerto rico	INFINITI QX30	H15	2016.4-	HVAC	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	Auto drive position	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	Shift	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	AVM	√	√		√		
Puerto rico	INFINITI QX30	H15	2016.4-	Intelligent key	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	CAN gateway	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	ANC	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	Telematics	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	FSCM	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	Siren control unit	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Puerto rico	INFINITI QX30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Puerto rico	INFINITI QX30	H15	2016.4-	Universal Garage Door Opener	√			√		
Puerto rico	INFINITI QX30	H15	2016.4-	Upper control panel cont unit	√					
Puerto rico	INFINITI QX30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Puerto rico	INFINITI QX30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Puerto rico	INFINITI QX30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Puerto rico	INFINITI QX30	H15	2016.4-	EC Mirror Compass	√					
Puerto rico	INFINITI QX30	H15	2016.4-	Intelligent Battery Sensor	√					
Puerto rico	INFINITI QX30	H15	2016.4-	Alarm siren	√			√		
Puerto rico	INFINITI QX30	H15	2016.4-	Radar sensor	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	Steering column cont module	√	√	√			
Puerto rico	INFINITI QX30	H15	2016.4-	ICC sensor	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	H/L control module LH	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	Side radar LH	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	LED H/L control module LH	√			√		
Puerto rico	INFINITI QX30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Puerto rico	INFINITI QX30	H15	2016.4-	Parking assist	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	Occupant Classification Unit	√			√		
Puerto rico	INFINITI QX30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	H/L control module RH	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	Front camera unit	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	Side radar RH	√	√	√	√		
Puerto rico	INFINITI QX30	H15	2016.4-	LED H/L control module RH	√			√		
Puerto rico	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Puerto rico	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Puerto rico	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Puerto rico	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Puerto rico	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Puerto rico	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Puerto rico	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Puerto rico	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Puerto rico	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Puerto rico	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Puerto rico	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Puerto rico	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Puerto rico	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Puerto rico	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Puerto rico	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

XTOOL

Puerto rico	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Puerto rico	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Puerto rico	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Puerto rico	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Puerto rico	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Puerto rico	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Puerto rico	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Puerto rico	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Puerto rico	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Puerto rico	INFINITI QX70	S51	2016.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Puerto rico	INFINITI QX70	S51	2016.5-	Laser/radar	√	√	√	√	AC0994	
Puerto rico	INFINITI QX70	S51	2016.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Puerto rico	INFINITI QX70	S51	2016.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Puerto rico	INFINITI QX70	S51	2016.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Puerto rico	INFINITI QX70	S51	2016.5-	Air bag	√	√	√	√		
Puerto rico	INFINITI QX70	S51	2016.5-	EPS/DAST 3	√	√	√	√		SP0507
Puerto rico	INFINITI QX70	S51	2016.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Puerto rico	INFINITI QX70	S51	2016.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Puerto rico	INFINITI QX70	S51	2016.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Puerto rico	INFINITI QX70	S51	2016.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Puerto rico	INFINITI QX70	S51	2016.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Puerto rico	INFINITI QX70	S51	2016.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Puerto rico	INFINITI QX70	S51	2016.5-	Multi AV	√	√	√	√		SP0503
Puerto rico	INFINITI QX70	S51	2016.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Puerto rico	INFINITI QX70	S51	2016.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Puerto rico	INFINITI QX70	S51	2016.5-	Auto back door	√	√	√	√		SP0611
Puerto rico	INFINITI QX70	S51	2016.5-	Occupant detection			√	√		SP0584
Puerto rico	INFINITI QX70	S51	2016.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Puerto rico	INFINITI QX70	S51	2016.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Puerto rico	INFINITI QX70	S51	2016.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Puerto rico	INFINITI QX70	S51	2016.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Puerto rico	INFINITI QX70	S51	2016.5-	Precrash seatbelt	√	√	√	√		SP0612
Puerto rico	INFINITI QX70	S51	2016.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Puerto rico	INFINITI QX70	S51	2016.5-	CAN gateway	√	√	√			
Puerto rico	INFINITI QX70	S51	2016.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Puerto rico	INFINITI QX70	S51	2016.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Puerto rico	INFINITI QX70	S51	2016.5-	ANC	√	√	√	√		
Puerto rico	INFINITI QX70	S51	2016.5-	Side radar left	√	√	√	√	AC1025	SP0582
Puerto rico	INFINITI QX70	S51	2016.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Puerto rico	INFINITI QX70	S51	2016.5-	Side radar right	√	√	√	√	AC1026	SP0583
Puerto rico	INFINITI QX70	S51	2016.5-	ICC/ADAS 2	√	√	√	√		
Qatar	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Qatar	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Qatar	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Qatar	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Qatar	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Qatar	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Qatar	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Qatar	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Qatar	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Qatar	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Qatar	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Qatar	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Qatar	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Qatar	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Qatar	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Qatar	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Qatar	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Qatar	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319

Qatar	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Qatar	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Qatar	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Qatar	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Qatar	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Qatar	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Qatar	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Qatar	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Qatar	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Qatar	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Qatar	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Qatar	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Qatar	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Qatar	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Qatar	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Qatar	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Qatar	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Qatar	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Qatar	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Qatar	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Qatar	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Qatar	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Qatar	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Qatar	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Qatar	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Qatar	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Qatar	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Qatar	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Qatar	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Qatar	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Qatar	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Qatar	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Qatar	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Qatar	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Qatar	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Qatar	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Qatar	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Qatar	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Qatar	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Qatar	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Qatar	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Qatar	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Qatar	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Qatar	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Qatar	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Qatar	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Qatar	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Qatar	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Qatar	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Qatar	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Qatar	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Qatar	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Qatar	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Qatar	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Qatar	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Qatar	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Qatar	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Qatar	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Qatar	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Qatar	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Qatar	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Qatar	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Qatar	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Qatar	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Qatar	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Qatar	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Qatar	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Qatar	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Qatar	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Qatar	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Qatar	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Qatar	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Qatar	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Qatar	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Qatar	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Qatar	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Qatar	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Qatar	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Qatar	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Qatar	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Qatar	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Qatar	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Qatar	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Qatar	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Qatar	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Qatar	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Qatar	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Qatar	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Qatar	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Qatar	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Qatar	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Qatar	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Qatar	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Qatar	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Qatar	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Qatar	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Qatar	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Qatar	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Qatar	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Qatar	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Qatar	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Qatar	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Qatar	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Qatar	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Qatar	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Qatar	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Qatar	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Qatar	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Qatar	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Qatar	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Qatar	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Qatar	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Qatar	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Qatar	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Qatar	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Qatar	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Qatar	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Qatar	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Qatar	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Qatar	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Qatar	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Qatar	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Qatar	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Qatar	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Qatar	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Qatar	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Qatar	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Qatar	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Qatar	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Qatar	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Qatar	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Qatar	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	

Qatar	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Qatar	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Qatar	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Qatar	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Qatar	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Qatar	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Qatar	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Qatar	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Qatar	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Qatar	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Qatar	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Qatar	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Qatar	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Qatar	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Qatar	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Qatar	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Qatar	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Qatar	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Qatar	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Qatar	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Qatar	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Qatar	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Qatar	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Qatar	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Qatar	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Qatar	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Qatar	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Qatar	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Qatar	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Qatar	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Qatar	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Qatar	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Qatar	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Qatar	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Qatar	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Qatar	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Qatar	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Qatar	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Qatar	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Qatar	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Qatar	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Qatar	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Qatar	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Qatar	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Qatar	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Qatar	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Qatar	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Qatar	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Qatar	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Qatar	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Qatar	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Qatar	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Qatar	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Qatar	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344

XTOOL

Qatar	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Qatar	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Qatar	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Qatar	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Qatar	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Qatar	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Qatar	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Qatar	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Qatar	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Qatar	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Qatar	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Qatar	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Qatar	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Qatar	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Qatar	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Qatar	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Qatar	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Qatar	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Qatar	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Qatar	INFINITI Q45	F50	2001.8-	Motor control						
Qatar	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Qatar	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Qatar	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Qatar	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Qatar	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Qatar	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Qatar	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Qatar	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Qatar	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Qatar	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Qatar	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Qatar	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Qatar	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Qatar	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Qatar	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Qatar	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Qatar	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Qatar	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Qatar	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Qatar	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Qatar	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Qatar	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Qatar	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Qatar	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Qatar	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Qatar	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Qatar	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Qatar	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Qatar	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Qatar	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Qatar	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Qatar	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Qatar	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Qatar	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Qatar	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Qatar	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Qatar	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Qatar	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980. AC0981. AC0982	SP0561. SP0562
Qatar	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Qatar	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Qatar	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Qatar	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Qatar	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Qatar	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Qatar	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Qatar	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Qatar	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Qatar	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Qatar	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Qatar	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Qatar	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Qatar	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Qatar	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Qatar	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Qatar	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Qatar	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Qatar	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Qatar	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Qatar	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Qatar	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Qatar	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980. AC0981. AC0982	SP0561. SP0562
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962. AC0963. AC0964. AC0966. AC0967. AC0968. AC0969. AC0970	SP0553. SP0554. SP0555. SP0556. SP0557. SP0558. SP0559
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Qatar	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613. AC0618. AC0663. AC0690. AC0692. AC0702	SP0372. SP0429
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		

Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Qatar	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Qatar	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Qatar	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Qatar	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Qatar	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Qatar	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Qatar	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Qatar	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Qatar	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Qatar	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Qatar	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Qatar	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Qatar	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Qatar	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Qatar	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Qatar	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Qatar	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Qatar	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Qatar	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Qatar	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Qatar	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Qatar	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Qatar	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Qatar	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Qatar	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Qatar	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Qatar	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Qatar	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Qatar	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Qatar	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Qatar	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Qatar	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		

Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Qatar	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Qatar	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Qatar	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Qatar	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Qatar	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Qatar	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Qatar	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Qatar	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Qatar	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Qatar	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Qatar	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Qatar	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Qatar	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Qatar	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Qatar	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Qatar	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Qatar	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Qatar	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Qatar	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Qatar	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Qatar	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Qatar	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Qatar	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Qatar	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Qatar	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Qatar	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Qatar	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Qatar	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Qatar	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Qatar	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Qatar	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Qatar	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Qatar	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Qatar	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Qatar	INFINITI QX50	I50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI QX50	I50	2013.6-	Air bag	√	√	√	√		
Qatar	INFINITI QX50	I50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Qatar	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Qatar	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Qatar	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Qatar	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Qatar	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Qatar	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Qatar	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Qatar	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Qatar	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Qatar	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI QX50	I50	2013.6-	CAN gateway	√	√	√	√		
Qatar	INFINITI QX50	I50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Qatar	INFINITI QX50	I50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	

Qatar	INFINITI QX50	I50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI QX50	I50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Qatar	INFINITI QX50	I50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI QX50	I55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Qatar	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Qatar	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Qatar	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Qatar	INFINITI QX50	I55	2018.5-	Air bag	√	√	√	√		
Qatar	INFINITI QX50	I55	2018.5-	EPS/DAST 3	√	√	√	√		
Qatar	INFINITI QX50	I55	2018.5-	Meter/M&A	√	√	√	√		
Qatar	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Qatar	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Qatar	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Qatar	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Qatar	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Qatar	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Qatar	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Qatar	INFINITI QX50	I55	2018.5-	Auto back door	√	√	√	√		SP0611
Qatar	INFINITI QX50	I55	2018.5-	Occupant detection			√	√		SP0584
Qatar	INFINITI QX50	I55	2018.5-	Shift						
Qatar	INFINITI QX50	I55	2018.5-	Adaptive light	√	√	√	√		SP0562
Qatar	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Qatar	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Qatar	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Qatar	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Qatar	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Qatar	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Qatar	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Qatar	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Qatar	INFINITI QX50	J55	2018.5-	ANC						
Qatar	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Qatar	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Qatar	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Qatar	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Qatar	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Qatar	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Qatar	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Qatar	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Qatar	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Qatar	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Qatar	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Qatar	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Qatar	INFINITI QX56	JA60	2004.10-	Motor control						
Qatar	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Qatar	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Qatar	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Qatar	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Qatar	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Qatar	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Qatar	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Qatar	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Qatar	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Qatar	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Qatar	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Qatar	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Qatar	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Qatar	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Qatar	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Qatar	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Qatar	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Qatar	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Qatar	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Qatar	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Qatar	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Qatar	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Qatar	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Qatar	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Qatar	INFINITI QX56	Z62	2010.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Qatar	INFINITI QX56	Z62	2010.3-	Laser/radar	√	√	√	√		
Qatar	INFINITI QX56	Z62	2010.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI QX56	Z62	2010.3-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Qatar	INFINITI QX56	Z62	2010.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI QX56	Z62	2010.3-	Air bag	√	√	√	√		
Qatar	INFINITI QX56	Z62	2010.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Qatar	INFINITI QX56	Z62	2010.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI QX56	Z62	2010.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Qatar	INFINITI QX56	Z62	2010.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Qatar	INFINITI QX56	Z62	2010.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Qatar	INFINITI QX56	Z62	2010.3-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI QX56	Z62	2010.3-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Qatar	INFINITI QX56	Z62	2010.3-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Qatar	INFINITI QX56	Z62	2010.3-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI QX56	Z62	2010.3-	Auto back door	√	√	√	√		
Qatar	INFINITI QX56	Z62	2010.3-	Occupant detection			√	√		SP0584

Qatar	INFINITI QX56	Z62	2010.3-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Qatar	INFINITI QX56	Z62	2010.3-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Qatar	INFINITI QX56	Z62	2010.3-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Qatar	INFINITI QX56	Z62	2010.3-	All mode AWD/4WD	√	√	√	√		SP0544,SP0545,SP0546,SP0547,SP0548,SP0549
Qatar	INFINITI QX56	Z62	2010.3-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI QX56	Z62	2010.3-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Qatar	INFINITI QX56	Z62	2010.3-	CAN gateway	√	√	√			
Qatar	INFINITI QX56	Z62	2010.3-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Qatar	INFINITI QX56	Z62	2010.3-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI QX56	Z62	2010.3-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Qatar	INFINITI QX56	Z62	2010.3-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI QX56	Z62	2010.3-	Rearview camera	√			√		SP0570,SP0571
Qatar	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Qatar	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Qatar	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Qatar	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Qatar	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Qatar	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Qatar	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Qatar	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Qatar	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Qatar	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246,SP0274,SP0275,SP0276,SP0278,SP0279,SP0281,SP0282,SP0283,SP0287,SP0288,SP0289,SP0290,SP0292
Qatar	INFINITI QX60	L50	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Qatar	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Qatar	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0487
Qatar	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Qatar	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Qatar	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Qatar	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081,AC1084,AC1085,AC1086,AC1087,AC1088,AC1089	
Qatar	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Qatar	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Qatar	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Qatar	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Qatar	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Qatar	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Qatar	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Qatar	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Qatar	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Qatar	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Qatar	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Qatar	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Qatar	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Qatar	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Qatar	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Qatar	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246,SP0276,SP0279,SP0281,SP0282,SP0283,SP0287,SP0289,SP0290,SP0292
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0487
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081,AC1084,AC1085,AC1086,AC1087,AC1088,AC1089	
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Qatar	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Qatar	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Qatar	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Qatar	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Qatar	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Qatar	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Qatar	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Qatar	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Qatar	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Qatar	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Qatar	INFINITI QX70	S51	2013.5-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Qatar	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Qatar	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Qatar	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	

Yeol

Qatar	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Qatar	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Qatar	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Qatar	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Qatar	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Qatar	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Qatar	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Qatar	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Qatar	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Qatar	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Qatar	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Qatar	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Qatar	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590. SP0591. SP0592
Qatar	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Qatar	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Qatar	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Qatar	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Qatar	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Qatar	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Qatar	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Qatar	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Qatar	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Qatar	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Qatar	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Qatar	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Qatar	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Qatar	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Qatar	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Qatar	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585. SP0586. SP0587
Qatar	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Qatar	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Qatar	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Qatar	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Qatar	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Qatar	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Qatar	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Qatar	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Qatar	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Qatar	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Qatar	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Qatar	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Qatar	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Qatar	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Qatar	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Qatar	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Qatar	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590. SP0591. SP0592
Qatar	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Qatar	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Qatar	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Qatar	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Qatar	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Qatar	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Rep. of armenia	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rep. of armenia	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rep. of armenia	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Rep. of armenia	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rep. of armenia	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rep. of armenia	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rep. of armenia	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rep. of armenia	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Rep. of armenia	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Rep. of armenia	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Rep. of armenia	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Rep. of armenia	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

XTOOL

Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Rep. of armenia	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Rep. of armenia	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Rep. of armenia	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rep. of armenia	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Rep. of armenia	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Rep. of armenia	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rep. of armenia	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Rep. of armenia	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556

Rep. of armenia	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Rep. of armenia	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rep. of armenia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Rep. of armenia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Rep. of armenia	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Rep. of armenia	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Rep. of armenia	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Rep. of armenia	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

XTOOL

Rep. of armenia	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Rep. of armenia	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Rep. of armenia	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Rep. of armenia	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Rep. of armenia	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Rep. of armenia	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Rep. of armenia	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Rep. of armenia	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Rep. of armenia	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Rep. of armenia	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Rep. of armenia	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612

XTOOL

Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Rep. of armenia	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Rep. of armenia	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Rep. of armenia	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Rep. of armenia	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Rep. of armenia	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Rep. of armenia	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Rep. of armenia	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Rep. of armenia	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Rep. of armenia	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Rep. of armenia	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Rep. of armenia	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Rep. of armenia	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Rep. of armenia	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Rep. of armenia	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501

XTOOL

Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Rep. of armenia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Rep. of armenia	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rep. of armenia	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Rep. of armenia	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rep. of armenia	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Rep. of armenia	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Rep. of armenia	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Rep. of armenia	INFINITI Q45	F50	2001.8-	Motor control						
Rep. of armenia	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Rep. of armenia	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Rep. of armenia	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Rep. of armenia	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Rep. of armenia	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Rep. of armenia	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Rep. of armenia	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Rep. of armenia	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Rep. of armenia	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Rep. of armenia	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Rep. of armenia	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		

XTOOL

Rep. of armenia	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Rep. of armenia	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Rep. of armenia	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Rep. of armenia	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Rep. of armenia	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Rep. of armenia	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Rep. of armenia	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Rep. of armenia	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Rep. of armenia	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Rep. of armenia	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Rep. of armenia	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Rep. of armenia	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rep. of armenia	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Rep. of armenia	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rep. of armenia	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Rep. of armenia	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rep. of armenia	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Rep. of armenia	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Rep. of armenia	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Rep. of armenia	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Rep. of armenia	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rep. of armenia	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rep. of armenia	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rep. of armenia	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI Q50	V37	2013.9-	Occupant detection		√	√			SP0584
Rep. of armenia	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Rep. of armenia	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Rep. of armenia	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Rep. of armenia	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Rep. of armenia	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Rep. of armenia	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Rep. of armenia	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rep. of armenia	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Rep. of armenia	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Rep. of armenia	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Rep. of armenia	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Rep. of armenia	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Rep. of armenia	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Rep. of armenia	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rep. of armenia	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Rep. of armenia	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Rep. of armenia	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Rep. of armenia	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Rep. of armenia	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Rep. of armenia	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Rep. of armenia	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Rep. of armenia	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Rep. of armenia	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

XTOOL

Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Rep. of armenia	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557

XTOOL

Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Rep. of armenia	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rep. of armenia	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Rep. of armenia	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Rep. of armenia	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rep. of armenia	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Rep. of armenia	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Rep. of armenia	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Rep. of armenia	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rep. of armenia	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Rep. of armenia	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rep. of armenia	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Rep. of armenia	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Rep. of armenia	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Rep. of armenia	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rep. of armenia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Rep. of armenia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471

Rep. of armenia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rep. of armenia	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Rep. of armenia	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rep. of armenia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Rep. of armenia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Rep. of armenia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Rep. of armenia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Rep. of armenia	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Rep. of armenia	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Rep. of armenia	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Rep. of armenia	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Rep. of armenia	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rep. of armenia	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Rep. of armenia	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rep. of armenia	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Rep. of armenia	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rep. of armenia	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Rep. of armenia	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rep. of armenia	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Rep. of armenia	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rep. of armenia	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Rep. of armenia	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Rep. of armenia	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Rep. of armenia	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rep. of armenia	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Rep. of armenia	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rep. of armenia	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Rep. of armenia	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Rep. of armenia	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Rep. of armenia	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		

Rep. of armenia	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Rep. of armenia	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Rep. of armenia	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Rep. of armenia	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Rep. of armenia	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Rep. of armenia	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Rep. of armenia	INFINITI QX50	J55	2018.5-	Shift						
Rep. of armenia	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Rep. of armenia	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	ANC						
Rep. of armenia	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rep. of armenia	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Rep. of armenia	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Rep. of armenia	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rep. of armenia	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Motor control						
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Rep. of armenia	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Rep. of armenia	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Rep. of armenia	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Rep. of armenia	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Rep. of armenia	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		

XTOOL

Rep. of armenia	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Rep. of armenia	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Rep. of armenia	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Rep. of armenia	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Rep. of armenia	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Rep. of armenia	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270, SP0274
Rep. of armenia	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Rep. of armenia	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Rep. of armenia	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Rep. of armenia	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rep. of armenia	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rep. of armenia	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Rep. of armenia	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rep. of armenia	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Rep. of armenia	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rep. of armenia	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Rep. of armenia	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Rep. of armenia	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Rep. of armenia	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Rep. of armenia	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Rep. of armenia	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Rep. of armenia	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Rep. of armenia	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Rep. of armenia	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Rep. of armenia	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Rep. of armenia	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612

Rep. of armenia	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Rep. of armenia	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Rep. of armenia	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rep. of armenia	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rep. of armenia	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Rep. of armenia	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rep. of armenia	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Rep. of armenia	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Rep. of armenia	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Rep. of armenia	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Rep. of armenia	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Rep. of armenia	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Rep. of armenia	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rep. of armenia	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Rep. of armenia	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rep. of armenia	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Rep. of armenia	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rep. of armenia	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274

Rep. of armenia	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rep. of armenia	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Rep. of armenia	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Rep. of armenia	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rep. of armenia	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rep. of armenia	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Rep. of armenia	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Rep. of armenia	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rep. of armenia	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Rep. of armenia	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Rep. of armenia	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Rep. of armenia	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rep. of armenia	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rep. of armenia	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rep. of armenia	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Rep. of armenia	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rep. of armenia	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rep. of armenia	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rep. of armenia	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Rep. of armenia	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rep. of armenia	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Rep. of armenia	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Rep. of armenia	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Rep. of armenia	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Rep. of armenia	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rep. of armenia	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Rep. of armenia	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Rep. of armenia	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rep. of armenia	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rep. of armenia	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Rep. of armenia	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Rep. of armenia	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Rep. of armenia	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Reunion	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Reunion	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Reunion	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Reunion	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Reunion	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Reunion	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Reunion	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Reunion	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Reunion	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Reunion	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Reunion	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Reunion	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Reunion	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Reunion	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Reunion	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Reunion	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Reunion	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Reunion	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Reunion	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Reunion	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Reunion	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Reunion	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Reunion	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Reunion	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Reunion	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Reunion	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Reunion	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Reunion	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Reunion	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Reunion	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Reunion	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Reunion	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Reunion	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Reunion	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Reunion	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Reunion	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Reunion	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Reunion	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Reunion	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Reunion	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Reunion	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Reunion	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Reunion	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Reunion	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Reunion	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Reunion	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Reunion	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Reunion	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Reunion	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Reunion	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Reunion	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Reunion	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Reunion	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Reunion	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Reunion	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Reunion	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347.SP0348.SP0349
Reunion	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Reunion	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Reunion	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Reunion	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Reunion	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Reunion	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Reunion	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Reunion	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Reunion	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Reunion	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Reunion	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510

Reunion	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Reunion	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Reunion	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Reunion	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Reunion	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Reunion	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Reunion	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Reunion	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Reunion	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Reunion	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Reunion	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Reunion	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Reunion	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Reunion	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Reunion	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Reunion	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Reunion	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Reunion	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Reunion	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Reunion	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Reunion	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Reunion	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Reunion	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Reunion	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Reunion	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Reunion	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Reunion	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Reunion	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Reunion	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Reunion	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Reunion	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Reunion	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Reunion	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Reunion	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		

Reunion	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Reunion	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Reunion	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Reunion	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Reunion	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Reunion	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Reunion	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Reunion	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Reunion	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Reunion	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Reunion	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Reunion	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Reunion	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Reunion	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Reunion	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Reunion	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Reunion	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Reunion	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Reunion	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Reunion	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Reunion	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Reunion	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Reunion	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Reunion	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Reunion	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Reunion	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Reunion	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Reunion	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Reunion	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Reunion	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Reunion	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Reunion	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Reunion	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Reunion	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Reunion	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Reunion	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Reunion	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Reunion	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Reunion	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Reunion	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Reunion	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Reunion	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Reunion	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Reunion	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Reunion	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Reunion	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Reunion	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Reunion	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584

XTOOL

Reunion	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Reunion	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Reunion	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Reunion	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Reunion	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Reunion	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Reunion	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Reunion	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Reunion	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Reunion	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Reunion	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Reunion	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604,SP0605,SP0606
Reunion	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Reunion	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Reunion	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Reunion	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Reunion	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Reunion	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Reunion	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Reunion	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Reunion	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Reunion	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Reunion	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Reunion	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Reunion	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Reunion	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Reunion	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0311,AC0314,AC0315,AC0320,AC0325,AC0327,AC0330,AC0331,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247,SP0265,SP0274,SP0276
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Reunion	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0009,SP0016,SP0032,SP0033,SP0038,SP0039,SP0053,SP0063,SP0064,SP0074,SP0079,SP0082,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592

Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Reunion	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Reunion	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Reunion	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Reunion	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Reunion	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Reunion	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Reunion	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Reunion	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Reunion	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Reunion	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Reunion	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Reunion	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Reunion	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Reunion	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Reunion	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Reunion	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Reunion	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Reunion	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Reunion	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Reunion	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Reunion	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Reunion	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Reunion	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Reunion	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Reunion	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Reunion	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Reunion	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Reunion	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Reunion	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Reunion	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Reunion	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Reunion	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Reunion	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Reunion	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Reunion	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Reunion	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		

Reunion	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Reunion	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Reunion	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Reunion	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Reunion	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Reunion	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Reunion	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Reunion	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Reunion	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Reunion	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Reunion	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Reunion	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Reunion	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Reunion	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Reunion	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Reunion	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Reunion	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Reunion	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Reunion	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Reunion	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Reunion	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Reunion	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Reunion	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Reunion	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Reunion	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Reunion	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Reunion	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Reunion	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Reunion	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Reunion	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Reunion	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Reunion	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Reunion	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Reunion	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Reunion	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Reunion	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Reunion	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Reunion	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Reunion	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Reunion	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Reunion	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Reunion	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Reunion	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Reunion	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Reunion	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Reunion	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Reunion	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Reunion	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Reunion	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Reunion	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Reunion	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Reunion	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Reunion	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Reunion	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Reunion	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Reunion	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Reunion	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Reunion	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Reunion	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Reunion	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Reunion	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Reunion	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Reunion	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Reunion	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Reunion	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Reunion	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Reunion	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Reunion	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Reunion	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Reunion	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Reunion	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Reunion	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Reunion	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Reunion	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Reunion	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Reunion	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Reunion	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Reunion	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Reunion	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Reunion	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Reunion	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Reunion	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Reunion	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Reunion	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Reunion	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Reunion	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Reunion	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Reunion	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Reunion	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Reunion	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Reunion	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Reunion	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Reunion	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Reunion	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Reunion	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Reunion	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Reunion	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Reunion	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Reunion	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Reunion	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Reunion	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Reunion	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Reunion	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494
Rumania	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rumania	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rumania	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rumania	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Rumania	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Rumania	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Rumania	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Rumania	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rumania	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Rumania	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Rumania	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Rumania	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rumania	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rumania	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Rumania	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Rumania	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rumania	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rumania	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Rumania	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Rumania	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Rumania	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Rumania	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Rumania	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Rumania	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Rumania	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rumania	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Rumania	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Rumania	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Rumania	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Rumania	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Rumania	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Rumania	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Rumania	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rumania	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Rumania	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Rumania	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rumania	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Rumania	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Rumania	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Rumania	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rumania	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rumania	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rumania	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Rumania	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Rumania	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Rumania	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Rumania	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rumania	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Rumania	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Rumania	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Rumania	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rumania	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Rumania	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Rumania	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Rumania	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Rumania	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rumania	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Rumania	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Rumania	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rumania	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rumania	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rumania	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rumania	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rumania	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Rumania	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rumania	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rumania	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rumania	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Rumania	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Rumania	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Rumania	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rumania	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Rumania	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rumania	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rumania	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Rumania	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rumania	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rumania	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Rumania	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rumania	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rumania	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rumania	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Rumania	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Rumania	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Rumania	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Rumania	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Rumania	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Rumania	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Rumania	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rumania	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Rumania	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rumania	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		

Rumania	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Rumania	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Rumania	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Rumania	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Rumania	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Rumania	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Rumania	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Rumania	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Rumania	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Rumania	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Rumania	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Rumania	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rumania	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Rumania	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rumania	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Rumania	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Rumania	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Rumania	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Rumania	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Rumania	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rumania	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Rumania	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Rumania	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rumania	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rumania	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rumania	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Rumania	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Rumania	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Rumania	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Rumania	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Rumania	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Rumania	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Rumania	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Rumania	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Rumania	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Rumania	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Rumania	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		

Rumania	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Rumania	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Rumania	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Rumania	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Rumania	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Rumania	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Rumania	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Rumania	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Rumania	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Rumania	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Rumania	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Rumania	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Rumania	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Rumania	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Rumania	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Rumania	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Rumania	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Rumania	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Rumania	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Rumania	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Rumania	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Rumania	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Rumania	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Rumania	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Rumania	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Rumania	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Rumania	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Rumania	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Rumania	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Rumania	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Rumania	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Rumania	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Rumania	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Rumania	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Rumania	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rumania	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Rumania	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rumania	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Rumania	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Rumania	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rumania	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Rumania	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Rumania	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247,SP0265,SP0274,SP0276
Rumania	INFINITI Q50	V37	2013.6-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Rumania	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Rumania	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Rumania	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Rumania	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Rumania	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Rumania	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Rumania	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Rumania	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Rumania	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Rumania	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Rumania	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Rumania	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Rumania	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Rumania	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Rumania	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Rumania	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Rumania	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Rumania	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Rumania	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Rumania	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Rumania	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604,SP0605,SP0606
Rumania	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Rumania	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Rumania	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Rumania	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Rumania	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Rumania	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Rumania	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Rumania	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Rumania	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Rumania	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Rumania	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Rumania	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Rumania	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Rumania	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Rumania	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0311,AC0314,AC0315,AC0320,AC0325,AC0327,AC0330,AC0331,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247,SP0265,SP0274,SP0276
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Rumania	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0009,SP0016,SP0032,SP0033,SP0038,SP0039,SP0053,SP0063,SP0064,SP0074,SP0079,SP0082,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557

Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983.AC0984.AC0985.AC0986.AC0987.AC0988.AC0989.AC0990	SP0563.SP0564.SP0565.SP0566.SP0567
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014.AC1015.AC1016.AC1017.AC1018.AC1019.AC1020.AC1021	
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Rumania	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Rumania	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Rumania	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Rumania	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Rumania	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Rumania	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Rumania	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Rumania	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Rumania	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Rumania	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Rumania	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613.AC0618.AC0663.AC0690.AC0692.AC0702	SP0372.SP0429
Rumania	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Rumania	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Rumania	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Rumania	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Rumania	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Rumania	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Rumania	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Rumania	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Rumania	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Rumania	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Rumania	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Rumania	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Rumania	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Rumania	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Rumania	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Rumania	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Rumania	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Rumania	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Rumania	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111.AC1112	SP0608.SP0609.SP0610
Rumania	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590.SP0591.SP0592
Rumania	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Rumania	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Rumania	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Rumania	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Rumania	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Rumania	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Rumania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897.AC0898.AC0899.AC0900.AC0901.AC0902	SP0508,SP0509
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350

Rumania	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√	AC0391, AC0392, AC0393, AC0394	SP0274
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rumania	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rumania	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Rumania	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rumania	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Rumania	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Rumania	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rumania	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rumania	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Rumania	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Rumania	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Rumania	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Rumania	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rumania	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rumania	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rumania	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Rumania	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Rumania	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rumania	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rumania	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Rumania	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Rumania	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rumania	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Rumania	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Rumania	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Rumania	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rumania	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Rumania	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Rumania	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rumania	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Rumania	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Rumania	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Rumania	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Rumania	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Rumania	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Rumania	INFINITI QX50	I50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Rumania	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Rumania	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rumania	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Rumania	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Rumania	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rumania	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rumania	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Rumania	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rumania	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rumania	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rumania	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rumania	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rumania	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Rumania	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Rumania	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rumania	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rumania	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Rumania	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Rumania	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rumania	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Rumania	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Rumania	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Rumania	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Rumania	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Rumania	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Rumania	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Rumania	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Rumania	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rumania	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Rumania	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Rumania	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Rumania	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rumania	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Rumania	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Rumania	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Rumania	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Rumania	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rumania	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Rumania	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rumania	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rumania	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rumania	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Rumania	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Rumania	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rumania	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rumania	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Rumania	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rumania	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Rumania	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Rumania	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Rumania	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rumania	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rumania	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rumania	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Rumania	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Rumania	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rumania	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rumania	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Rumania	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Rumania	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Rumania	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Rumania	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Rumania	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rumania	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rumania	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rumania	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Rumania	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rumania	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Rumania	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Russia	INFINITI EX35	J50	2008.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI EX35	J50	2008.4-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Russia	INFINITI EX35	J50	2008.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI EX35	J50	2008.4-	Air bag	√	√	√	√		
Russia	INFINITI EX35	J50	2008.4-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Russia	INFINITI EX35	J50	2008.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Russia	INFINITI EX35	J50	2008.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Russia	INFINITI EX35	J50	2008.4-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Russia	INFINITI EX35	J50	2008.4-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Russia	INFINITI EX35	J50	2008.4-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI EX35	J50	2008.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI EX35	J50	2008.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Russia	INFINITI EX35	J50	2008.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI EX35	J50	2008.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Russia	INFINITI EX35	J50	2008.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI EX35	J50	2008.4-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI EX35	J50	2008.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Russia	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Russia	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Russia	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Russia	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Russia	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Russia	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Russia	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Russia	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Russia	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Russia	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Russia	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Russia	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Russia	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Russia	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Russia	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Russia	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Russia	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Russia	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Russia	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Russia	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Russia	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Russia	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Russia	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Russia	INFINITI FX37/FX50	S51	2008.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Russia	INFINITI FX37/FX50	S51	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI FX37/FX50	S51	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Russia	INFINITI FX37/FX50	S51	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI FX37/FX50	S51	2008.7-	Air bag	√	√	√	√		
Russia	INFINITI FX37/FX50	S51	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Russia	INFINITI FX37/FX50	S51	2008.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Russia	INFINITI FX37/FX50	S51	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Russia	INFINITI FX37/FX50	S51	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Russia	INFINITI FX37/FX50	S51	2008.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Russia	INFINITI FX37/FX50	S51	2008.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Russia	INFINITI FX37/FX50	S51	2008.7-	Multi AV	√	√	√	√		
Russia	INFINITI FX37/FX50	S51	2008.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Russia	INFINITI FX37/FX50	S51	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI FX37/FX50	S51	2008.7-	Occupant detection			√	√		SP0584
Russia	INFINITI FX37/FX50	S51	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Russia	INFINITI FX37/FX50	S51	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Russia	INFINITI FX37/FX50	S51	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI FX37/FX50	S51	2008.7-	CAN gateway	√	√	√			
Russia	INFINITI FX37/FX50	S51	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	

Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Russia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Russia	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Russia	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Russia	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Russia	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Russia	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Russia	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Russia	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Russia	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Russia	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Russia	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Russia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Russia	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Russia	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Russia	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Russia	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Russia	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Russia	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Russia	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Russia	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Russia	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Russia	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Russia	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Russia	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Russia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Russia	INFINITI G37 SEDAN	V36	2008.12-	Laser/radar	√	√	√	√		
Russia	INFINITI G37 SEDAN	V36	2008.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI G37 SEDAN	V36	2008.12-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Russia	INFINITI G37 SEDAN	V36	2008.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI G37 SEDAN	V36	2008.12-	Air bag	√	√	√	√		
Russia	INFINITI G37 SEDAN	V36	2008.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Russia	INFINITI G37 SEDAN	V36	2008.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Russia	INFINITI G37 SEDAN	V36	2008.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Russia	INFINITI G37 SEDAN	V36	2008.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Russia	INFINITI G37 SEDAN	V36	2008.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Russia	INFINITI G37 SEDAN	V36	2008.12-	Pop up hood	√	√	√	√		
Russia	INFINITI G37 SEDAN	V36	2008.12-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI G37 SEDAN	V36	2008.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Russia	INFINITI G37 SEDAN	V36	2008.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI G37 SEDAN	V36	2008.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Russia	INFINITI G37 SEDAN	V36	2008.12-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Russia	INFINITI G37 SEDAN	V36	2008.12-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957	
Russia	INFINITI G37 SEDAN	V36	2008.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Russia	INFINITI JX35	L50	2012.11-	Laser/radar	√	√	√	√		
Russia	INFINITI JX35	L50	2012.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI JX35	L50	2012.11-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Russia	INFINITI JX35	L50	2012.11-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Russia	INFINITI JX35	L50	2012.11-	Air bag	√	√	√	√		
Russia	INFINITI JX35	L50	2012.11-	EPS/DAST 3	√	√	√	√		
Russia	INFINITI JX35	L50	2012.11-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Russia	INFINITI JX35	L50	2012.11-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Russia	INFINITI JX35	L50	2012.11-	Transmission	√	√	√	√	AC0439	SP0246,SP0274,SP0276,SP0278,SP0279,SP0281,SP0282,SP0283,SP0286,SP0287,SP0288,SP0289,SP0290,SP0291,SP0292
Russia	INFINITI JX35	L50	2012.11-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Russia	INFINITI JX35	L50	2012.11-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Russia	INFINITI JX35	L50	2012.11-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI JX35	L50	2012.11-	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0487
Russia	INFINITI JX35	L50	2012.11-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Russia	INFINITI JX35	L50	2012.11-	Auto back door	√	√	√	√		SP0611
Russia	INFINITI JX35	L50	2012.11-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Russia	INFINITI JX35	L50	2012.11-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Russia	INFINITI JX35	L50	2012.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI JX35	L50	2012.11-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Russia	INFINITI JX35	L50	2012.11-	CAN gateway	√	√	√			
Russia	INFINITI JX35	L50	2012.11-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Russia	INFINITI JX35	L50	2012.11-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI JX35	L50	2012.11-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Laser/radar	√	√	√	√		
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI M25/M37/M56	Y51	2012.7-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Russia	INFINITI M25/M37/M56	Y51	2012.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Air bag	√	√	√	√		
Russia	INFINITI M25/M37/M56	Y51	2012.7-	EPS/DAST 3	√	√	√	√		
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Motor control	√	√	√	√		
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Transmission	√	√	√	√		SP0274
Russia	INFINITI M25/M37/M56	Y51	2012.7-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Russia	INFINITI M25/M37/M56	Y51	2012.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0313,SP0315,SP0316,SP0317,SP0319
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Pop up hood	√	√	√	√		
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI M25/M37/M56	Y51	2012.7-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Russia	INFINITI M25/M37/M56	Y51	2012.7-	HV battery	√	√	√	√	AC1121	
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Russia	INFINITI M25/M37/M56	Y51	2012.7-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Russia	INFINITI M25/M37/M56	Y51	2012.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI M25/M37/M56	Y51	2012.7-	CAN gateway	√	√	√			
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI M25/M37/M56	Y51	2012.7-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Russia	INFINITI M25/M37/M56	Y51	2012.7-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Russia	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Russia	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831,AC0856	
Russia	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Russia	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347,SP0348,SP0349
Russia	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Russia	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Russia	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653,AC0698	SP0391,SP0393
Russia	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Russia	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Russia	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Russia	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561,SP0562
Russia	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
Russia	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Russia	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Russia	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0922,AC0923,AC0924,AC0925,AC0926,AC0928	SP0511,SP0512,SP0518,SP0520,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0529,SP0530,SP0531,SP0532,SP0534,SP0535,SP0536,SP0537
Russia	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Russia	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570,SP0571
Russia	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Russia	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Russia	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Russia	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Russia	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Russia	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Russia	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Russia	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Russia	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Russia	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274,SP0276
Russia	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Russia	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Russia	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Russia	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Russia	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503

Russia	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Russia	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Russia	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Russia	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Russia	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Russia	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Russia	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Russia	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Russia	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Russia	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Russia	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Russia	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Russia	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Russia	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Russia	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Russia	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Russia	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Russia	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Russia	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Russia	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Russia	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Russia	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Russia	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Russia	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Russia	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Russia	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Russia	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Russia	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Russia	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Russia	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		

XTOOL

Russia	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Russia	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Air pressure monitor	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Air bag	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	EPS/DAST 3	√	√	√			
Russia	INFINITI Q30/QX30	H15	2018.1-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Russia	INFINITI Q30/QX30	H15	2018.1-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Russia	INFINITI Q30/QX30	H15	2018.1-	EHS/PKB	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Transmission	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Russia	INFINITI Q30/QX30	H15	2018.1-	ABS	√	√	√	√		SP0308
Russia	INFINITI Q30/QX30	H15	2018.1-	Multi AV	√	√	√	√		SP0501
Russia	INFINITI Q30/QX30	H15	2018.1-	HVAC	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Auto drive position	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Shift	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	All mode AWD/4WD	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	AVM	√	√		√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Intelligent key	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	CAN gateway	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	ANC	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Telematics	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	FSCM	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Siren control unit	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Russia	INFINITI Q30/QX30	H15	2018.1-	Overhead Control Panel Unit	√			√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Universal Garage Door Opener	√			√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Upper control panel cont unit	√					
Russia	INFINITI Q30/QX30	H15	2018.1-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Russia	INFINITI Q30/QX30	H15	2018.1-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Russia	INFINITI Q30/QX30	H15	2018.1-	Light/Rain Sensor Module	√			√		
Russia	INFINITI Q30/QX30	H15	2018.1-	EC Mirror Compass	√					
Russia	INFINITI Q30/QX30	H15	2018.1-	Intelligent Battery Sensor	√					
Russia	INFINITI Q30/QX30	H15	2018.1-	Alarm siren	√			√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Radar sensor	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Steering column cont module	√	√	√			
Russia	INFINITI Q30/QX30	H15	2018.1-	ICC sensor	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Trailer recognition control unit	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	H/L control module LH	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Powertrain cont module	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Side radar LH	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	LED H/L control module LH	√			√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Steering Wheel Switch Pad	√			√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Parking assist	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Occupant Classification Unit	√			√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Electronic Ignition Switch cont unit	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	H/L control module RH	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Front camera unit	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	Side radar RH	√	√	√	√		
Russia	INFINITI Q30/QX30	H15	2018.1-	LED H/L control module RH	√			√		
Russia	INFINITI Q50	V37	2014.5-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Russia	INFINITI Q50	V37	2014.5-	Laser/radar	√	√	√	√	AC0994	
Russia	INFINITI Q50	V37	2014.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI Q50	V37	2014.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Russia	INFINITI Q50	V37	2014.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI Q50	V37	2014.5-	Air bag	√	√	√	√		
Russia	INFINITI Q50	V37	2014.5-	EPS/DAST 3	√	√	√	√		SP0507
Russia	INFINITI Q50	V37	2014.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Russia	INFINITI Q50	V37	2014.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Russia	INFINITI Q50	V37	2014.5-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Russia	INFINITI Q50	V37	2014.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Russia	INFINITI Q50	V37	2014.5-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Russia	INFINITI Q50	V37	2014.5-	Pop up hood	√	√	√	√		
Russia	INFINITI Q50	V37	2014.5-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI Q50	V37	2014.5-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Russia	INFINITI Q50	V37	2014.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Russia	INFINITI Q50	V37	2014.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI Q50	V37	2014.5-	Occupant detection			√	√		SP0584
Russia	INFINITI Q50	V37	2014.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Russia	INFINITI Q50	V37	2014.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI Q50	V37	2014.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Russia	INFINITI Q50	V37	2014.5-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Russia	INFINITI Q50	V37	2014.5-	DAST 2	√	√	√	√		
Russia	INFINITI Q50	V37	2014.5-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI Q50	V37	2014.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI Q50	V37	2014.5-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Russia	INFINITI Q50	V37	2014.5-	CAN gateway	√	√	√			
Russia	INFINITI Q50	V37	2014.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Russia	INFINITI Q50	V37	2014.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Russia	INFINITI Q50	V37	2014.5-	DAST 1	√	√	√	√		
Russia	INFINITI Q50	V37	2014.5-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Russia	INFINITI Q50	V37	2014.5-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Russia	INFINITI Q50	V37	2014.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Russia	INFINITI Q50	V37	2014.5-	ANC	√	√	√	√	AC1024	
Russia	INFINITI Q50	V37	2014.5-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI Q50	V37	2014.5-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Russia	INFINITI Q50	V37	2014.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Russia	INFINITI Q50	V37	2014.5-	HIGH BEAM ASSIST	√	√	√	√		
Russia	INFINITI Q50	V37	2014.5-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI Q50	V37	2014.5-	6ch CAN GATEWAY	√	√	√	√		
Russia	INFINITI Q50	V37	2014.5-	3ch CAN GATEWAY	√	√	√	√		
Russia	INFINITI Q50	V37	2014.5-	ICC/ADAS 2	√	√	√	√		
Russia	INFINITI Q50	V37	2014.5-	PMAS	√	√	√	√		
Russia	INFINITI Q50	V37	2014.5-	FSCM	√	√	√	√	AC1109	
Russia	INFINITI Q50	V37	2014.5-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Russia	INFINITI Q50	V37	2014.5-	A-IVC(Renault common)	√	√	√	√		
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√		
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507

Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Russia	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Laser/radar	√	√	√	√		
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Air bag	√	√	√	√		
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	EPS/DAST 3	√	√	√	√		
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Motor control	√	√	√	√		
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Transmission	√	√	√	√		SP0276
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Pop up hood	√	√	√	√		
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	HV battery	√	√	√	√	AC1121	
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Occupant detection			√	√		SP0584
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	DAST 2	√	√	√	√		
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Lane camera	√	√	√	√		
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	DAST 1	√	√	√	√		
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	HIGH BEAM ASSIST	√	√	√	√		
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	VSP	√	√	√	√		
Russia	INFINITI Q50 Hybrid	HV37	2018.4-	Brake	√	√	√	√	AC1127	
Russia	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Russia	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Russia	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Russia	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Russia	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Russia	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Russia	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Russia	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Russia	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Russia	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Russia	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Russia	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Russia	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Russia	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Russia	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Russia	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Russia	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612

Russia	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Russia	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Russia	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Russia	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Russia	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Russia	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Russia	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Russia	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Russia	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Russia	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Russia	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Russia	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Russia	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Russia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Russia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Russia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Russia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Russia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Russia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Russia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Russia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Russia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Russia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Russia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Russia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Russia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Russia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Russia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Russia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Russia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Russia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Russia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Russia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Russia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Russia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Russia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0265, SP0270, SP0274
Russia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Russia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Russia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Russia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Russia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Russia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Russia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Russia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Russia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Russia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Russia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

Russia	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Russia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Russia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Russia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Russia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Russia	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Russia	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Russia	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Russia	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Russia	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Russia	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Russia	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Russia	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Russia	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Russia	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Russia	INFINITI QX50	I50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Russia	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Russia	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI QX50	I50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Russia	INFINITI QX50	I50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI QX50	I50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Russia	INFINITI QX50	I50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Russia	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Russia	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Russia	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI QX50	J50	2013.6-	ICC/ADAS 2	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Russia	INFINITI QX50	J55	2018.4-	Laser/radar	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Russia	INFINITI QX50	J55	2018.4-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Russia	INFINITI QX50	J55	2018.4-	Air bag	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	EPS/DAST 3	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	Meter/M&A	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Russia	INFINITI QX50	J55	2018.4-	EHS/PKB	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Russia	INFINITI QX50	J55	2018.4-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Russia	INFINITI QX50	J55	2018.4-	ABS	√	√	√	√		SP0313, SP0315
Russia	INFINITI QX50	J55	2018.4-	Total illum C/U	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI QX50	J55	2018.4-	HVAC	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	Auto drive position	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	Auto back door	√	√	√	√		SP0611
Russia	INFINITI QX50	J55	2018.4-	Shift						
Russia	INFINITI QX50	J55	2018.4-	Adaptive light	√	√	√	√		SP0562
Russia	INFINITI QX50	J55	2018.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI QX50	J55	2018.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Russia	INFINITI QX50	J55	2018.4-	All mode AWD/4WD	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	DAST 2	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI QX50	J55	2018.4-	CAN gateway	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	Lane camera	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	DAST 1	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	Chassis control	√	√	√	√		
Russia	INFINITI QX50	I55	2018.4-	ANC						
Russia	INFINITI QX50	I55	2018.4-	E-HUD	√	√	√	√		
Russia	INFINITI QX50	I55	2018.4-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI QX50	I55	2018.4-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Russia	INFINITI QX50	J55	2018.4-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI QX50	J55	2018.4-	6ch CAN GATEWAY	√	√	√	√		
Russia	INFINITI QX50	J55	2018.4-	ICC/ADAS 2	√	√	√	√		
Russia	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Russia	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Russia	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Russia	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Russia	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Russia	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Russia	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Russia	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Russia	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Russia	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Russia	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Russia	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Russia	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Russia	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Russia	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Russia	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Russia	INFINITI QX56	Z62	2010.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Russia	INFINITI QX56	Z62	2010.3-	Laser/radar	√	√	√	√		
Russia	INFINITI QX56	Z62	2010.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI QX56	Z62	2010.3-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Russia	INFINITI QX56	Z62	2010.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI QX56	Z62	2010.3-	Air bag	√	√	√	√		
Russia	INFINITI QX56	Z62	2010.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Russia	INFINITI QX56	Z62	2010.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Russia	INFINITI QX56	Z62	2010.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Russia	INFINITI QX56	Z62	2010.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Russia	INFINITI QX56	Z62	2010.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Russia	INFINITI QX56	Z62	2010.3-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI QX56	Z62	2010.3-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0476, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488, SP0489, SP0490
Russia	INFINITI QX56	Z62	2010.3-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Russia	INFINITI QX56	Z62	2010.3-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI QX56	Z62	2010.3-	Auto back door	√	√	√	√		
Russia	INFINITI QX56	Z62	2010.3-	Occupant detection			√	√		SP0584
Russia	INFINITI QX56	Z62	2010.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Russia	INFINITI QX56	Z62	2010.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI QX56	Z62	2010.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Russia	INFINITI QX56	Z62	2010.3-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Russia	INFINITI QX56	Z62	2010.3-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI QX56	Z62	2010.3-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI QX56	Z62	2010.3-	CAN gateway	√	√	√			
Russia	INFINITI QX56	Z62	2010.3-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Russia	INFINITI QX56	Z62	2010.3-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI QX56	Z62	2010.3-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI QX56	Z62	2010.3-	Rearview camera	√			√		SP0570, SP0571
Russia	INFINITI QX60	L50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Russia	INFINITI QX60	L50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Russia	INFINITI QX60	L50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI QX60	L50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Russia	INFINITI QX60	L50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI QX60	L50	2013.11-	Air bag	√	√	√	√		
Russia	INFINITI QX60	L50	2013.11-	EPS/DAST 3	√	√	√	√		
Russia	INFINITI QX60	L50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Russia	INFINITI QX60	L50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Russia	INFINITI QX60	L50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Russia	INFINITI QX60	L50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Russia	INFINITI QX60	L50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Russia	INFINITI QX60	L50	2013.11-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI QX60	L50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Russia	INFINITI QX60	L50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI QX60	L50	2013.11-	Auto back door	√	√	√	√		SP0611
Russia	INFINITI QX60	L50	2013.11-	Occupant detection			√	√		SP0584
Russia	INFINITI QX60	L50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI QX60	L50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Russia	INFINITI QX60	L50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI QX60	L50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI QX60	L50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI QX60	L50	2013.11-	CAN gateway	√	√	√			
Russia	INFINITI QX60	L50	2013.11-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Russia	INFINITI QX60	L50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Russia	INFINITI QX60	L50	2013.11-	ANC	√	√	√	√	AC1024	
Russia	INFINITI QX60	L50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI QX60	L50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Russia	INFINITI QX60	L50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI QX60	L50	2013.11-	ICC/ADAS 2	√	√	√	√		
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√		
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	PTC heater	√	√	√	√	AC1107, AC1108	
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Russia	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Russia	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Russia	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Russia	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Russia	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Russia	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Russia	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Russia	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Russia	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√		SP0274
Russia	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Russia	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Russia	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Russia	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Russia	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Russia	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Russia	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Russia	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Russia	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Russia	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Russia	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Russia	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Russia	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Russia	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Russia	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Russia	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Russia	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√		
Russia	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Russia	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Russia	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Russia	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Russia	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Russia	INFINITI QX80	Z62	2013.6-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Russia	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Russia	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Russia	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Russia	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Russia	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Russia	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Russia	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Russia	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Russia	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Russia	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Russia	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Russia	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Russia	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Russia	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Russia	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Russia	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Russia	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Russia	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Russia	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Russia	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Russia	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Russia	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Russia	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Russia	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Russia	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Russia	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Russia	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Russia	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Rwanda	INFINITI EX35/EX37	I50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI EX35/EX37	I50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rwanda	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Rwanda	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rwanda	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rwanda	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Rwanda	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rwanda	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rwanda	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rwanda	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rwanda	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rwanda	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Rwanda	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Rwanda	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Rwanda	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Rwanda	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rwanda	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Rwanda	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rwanda	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503

Rwanda	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rwanda	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Rwanda	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Rwanda	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rwanda	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Rwanda	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rwanda	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Rwanda	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Rwanda	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Rwanda	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Rwanda	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Rwanda	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Rwanda	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rwanda	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rwanda	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Rwanda	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Rwanda	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Rwanda	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rwanda	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rwanda	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rwanda	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rwanda	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rwanda	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rwanda	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Rwanda	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Rwanda	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Rwanda	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Rwanda	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rwanda	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Rwanda	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Rwanda	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Rwanda	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Rwanda	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Rwanda	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Rwanda	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Rwanda	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Rwanda	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Rwanda	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Rwanda	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Rwanda	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Rwanda	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Rwanda	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Rwanda	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Rwanda	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Rwanda	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Rwanda	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Rwanda	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Rwanda	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Rwanda	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Rwanda	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Rwanda	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Rwanda	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Rwanda	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Rwanda	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rwanda	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Rwanda	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rwanda	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Rwanda	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Rwanda	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rwanda	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rwanda	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Rwanda	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Rwanda	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Rwanda	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Rwanda	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rwanda	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rwanda	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Rwanda	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Rwanda	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rwanda	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Rwanda	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Rwanda	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Rwanda	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Rwanda	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rwanda	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Rwanda	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	

Rwanda	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rwanda	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Rwanda	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Rwanda	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Rwanda	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rwanda	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Rwanda	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Rwanda	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Rwanda	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rwanda	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Rwanda	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Rwanda	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Rwanda	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rwanda	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Rwanda	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rwanda	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Rwanda	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Rwanda	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rwanda	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rwanda	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Rwanda	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Rwanda	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Rwanda	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Rwanda	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rwanda	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rwanda	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Rwanda	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Rwanda	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rwanda	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Rwanda	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Rwanda	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Rwanda	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Rwanda	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Rwanda	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Rwanda	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Rwanda	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rwanda	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Rwanda	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Rwanda	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Rwanda	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Rwanda	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Rwanda	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rwanda	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Rwanda	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Rwanda	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Rwanda	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Rwanda	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		

Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rwanda	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rwanda	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rwanda	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Rwanda	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rwanda	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Rwanda	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Rwanda	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Rwanda	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rwanda	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Rwanda	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Rwanda	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Rwanda	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Rwanda	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Rwanda	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rwanda	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Rwanda	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Rwanda	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rwanda	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Rwanda	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Rwanda	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Rwanda	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rwanda	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Rwanda	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rwanda	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rwanda	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rwanda	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Rwanda	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rwanda	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Rwanda	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rwanda	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Rwanda	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rwanda	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Rwanda	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Rwanda	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Rwanda	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rwanda	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Rwanda	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rwanda	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Rwanda	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rwanda	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rwanda	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rwanda	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Rwanda	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Rwanda	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rwanda	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Rwanda	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rwanda	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Rwanda	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Rwanda	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rwanda	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Rwanda	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Rwanda	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Rwanda	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Rwanda	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Rwanda	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Rwanda	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Rwanda	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Rwanda	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Rwanda	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Rwanda	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Rwanda	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Rwanda	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Rwanda	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Rwanda	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Rwanda	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Rwanda	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Rwanda	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rwanda	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Rwanda	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Rwanda	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Rwanda	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Rwanda	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Rwanda	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rwanda	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Rwanda	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rwanda	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Rwanda	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Rwanda	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rwanda	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Rwanda	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Rwanda	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Rwanda	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Rwanda	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Rwanda	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Rwanda	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Rwanda	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Rwanda	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Rwanda	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Rwanda	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Rwanda	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Rwanda	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Rwanda	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Rwanda	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Rwanda	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Rwanda	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Rwanda	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Rwanda	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Rwanda	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Rwanda	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Rwanda	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Rwanda	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Rwanda	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Rwanda	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Rwanda	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Rwanda	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Rwanda	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Rwanda	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Rwanda	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Rwanda	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Rwanda	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Rwanda	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Rwanda	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Rwanda	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Rwanda	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		

Saint kitts	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Saint kitts	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint kitts	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Saint kitts	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Saint kitts	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Saint kitts	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint kitts	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Saint kitts	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saint kitts	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint kitts	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Saint kitts	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saint kitts	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saint kitts	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Saint kitts	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saint kitts	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saint kitts	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Saint kitts	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Saint kitts	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint kitts	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Saint kitts	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint kitts	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Saint kitts	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint kitts	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saint kitts	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Saint kitts	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saint kitts	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Saint kitts	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510

Saint kitts	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saint kitts	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saint kitts	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saint kitts	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saint kitts	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Saint kitts	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saint kitts	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saint kitts	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint kitts	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Saint kitts	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saint kitts	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Saint kitts	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Saint kitts	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saint kitts	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saint kitts	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saint kitts	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saint kitts	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Saint kitts	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saint kitts	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saint kitts	INFINITI Q45	F50	2001.8-	Motor control						
Saint kitts	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint kitts	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saint kitts	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saint kitts	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saint kitts	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Saint kitts	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Saint kitts	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Saint kitts	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint kitts	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Saint kitts	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Saint kitts	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Saint kitts	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saint kitts	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saint kitts	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saint kitts	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saint kitts	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saint kitts	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint kitts	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Saint kitts	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Saint kitts	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Saint kitts	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Saint kitts	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		

Saint kitts	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Saint kitts	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Saint kitts	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Saint kitts	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saint kitts	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Saint kitts	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Saint kitts	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Saint kitts	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saint kitts	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Saint kitts	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saint kitts	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saint kitts	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Saint kitts	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Saint kitts	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint kitts	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Saint kitts	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saint kitts	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Saint kitts	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Saint kitts	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Saint kitts	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Saint kitts	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint kitts	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Saint kitts	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Saint kitts	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint kitts	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint kitts	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Saint kitts	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Saint kitts	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saint kitts	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Saint kitts	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saint kitts	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Saint kitts	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saint kitts	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Saint lucia	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

XTOOL

Saint lucia	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint lucia	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Saint lucia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Saint lucia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Saint lucia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint lucia	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Saint lucia	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saint lucia	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint lucia	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Saint lucia	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saint lucia	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saint lucia	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Saint lucia	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saint lucia	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saint lucia	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Saint lucia	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Saint lucia	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint lucia	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Saint lucia	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint lucia	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Saint lucia	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint lucia	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saint lucia	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Saint lucia	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saint lucia	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Saint lucia	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saint lucia	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saint lucia	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saint lucia	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saint lucia	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Saint lucia	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saint lucia	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saint lucia	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint lucia	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Saint lucia	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			

Saint lucia	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saint lucia	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Saint lucia	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Saint lucia	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saint lucia	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saint lucia	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saint lucia	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saint lucia	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Saint lucia	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saint lucia	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saint lucia	INFINITI Q45	F50	2001.8-	Motor control						
Saint lucia	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint lucia	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saint lucia	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saint lucia	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saint lucia	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Saint lucia	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Saint lucia	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Saint lucia	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint lucia	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Saint lucia	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Saint lucia	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Saint lucia	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saint lucia	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saint lucia	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saint lucia	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saint lucia	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saint lucia	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint lucia	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Saint lucia	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Saint lucia	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Saint lucia	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Saint lucia	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Saint lucia	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Saint lucia	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Saint lucia	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Saint lucia	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saint lucia	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Saint lucia	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Saint lucia	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Saint lucia	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saint lucia	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Saint lucia	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saint lucia	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saint lucia	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Saint lucia	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Saint lucia	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint lucia	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Saint lucia	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saint lucia	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Saint lucia	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Saint lucia	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Saint lucia	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Saint lucia	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint lucia	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Saint lucia	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Saint lucia	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Saint lucia	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint lucia	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Saint lucia	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Saint lucia	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saint lucia	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Saint lucia	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saint lucia	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Saint lucia	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saint lucia	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Saint martin	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint martin	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Saint martin	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint martin	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Saint martin	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saint martin	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Saint martin	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint martin	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Saint martin	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Saint martin	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint martin	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint martin	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint martin	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint martin	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint martin	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Saint martin	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Saint martin	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint martin	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Saint martin	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Saint martin	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint martin	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Saint martin	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Saint martin	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Saint martin	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saint martin	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Saint martin	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint martin	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Saint martin	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Saint martin	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Saint martin	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint martin	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Saint martin	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saint martin	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint martin	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Saint martin	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saint martin	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saint martin	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Saint martin	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saint martin	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315

Saint martin	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Saint martin	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Saint martin	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint martin	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Saint martin	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint martin	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Saint martin	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint martin	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saint martin	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Saint martin	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saint martin	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Saint martin	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Saint martin	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saint martin	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Saint martin	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint martin	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saint martin	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saint martin	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint martin	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Saint martin	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saint martin	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saint martin	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saint martin	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saint martin	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Saint martin	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Saint martin	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Saint martin	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saint martin	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saint martin	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint martin	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint martin	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint martin	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint martin	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint martin	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint martin	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Saint martin	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Saint martin	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saint martin	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint martin	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Saint martin	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Saint martin	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saint martin	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saint martin	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saint martin	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saint martin	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Saint martin	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saint martin	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saint martin	INFINITI Q45	F50	2001.8-	Motor control						
Saint martin	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint martin	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saint martin	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saint martin	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saint martin	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Saint martin	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Saint martin	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Saint martin	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint martin	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Saint martin	INFINITI Q45	F50	2001.8-	DIU		√	√	√		

Saint martin	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Saint martin	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saint martin	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saint martin	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saint martin	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saint martin	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saint martin	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint martin	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Saint martin	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Saint martin	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Saint martin	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Saint martin	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Saint martin	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Saint martin	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Saint martin	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Saint martin	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saint martin	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Saint martin	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Saint martin	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Saint martin	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saint martin	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Saint martin	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saint martin	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saint martin	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Saint martin	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Saint martin	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint martin	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Saint martin	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saint martin	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Saint martin	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Saint martin	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Saint martin	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Saint martin	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint martin	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Saint martin	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Saint martin	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint martin	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint martin	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Saint martin	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Saint martin	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saint martin	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Saint martin	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saint martin	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Saint martin	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saint martin	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Saint vincent	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510

Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint vincent	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Saint vincent	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503

Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Saint vincent	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Saint vincent	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint vincent	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Saint vincent	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saint vincent	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint vincent	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Saint vincent	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saint vincent	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saint vincent	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Saint vincent	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saint vincent	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saint vincent	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Saint vincent	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Saint vincent	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint vincent	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Saint vincent	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint vincent	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Saint vincent	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint vincent	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saint vincent	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Saint vincent	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saint vincent	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Saint vincent	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saint vincent	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saint vincent	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saint vincent	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saint vincent	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319

Saint vincent	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Saint vincent	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saint vincent	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saint vincent	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saint vincent	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Saint vincent	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saint vincent	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Saint vincent	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Saint vincent	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saint vincent	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saint vincent	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saint vincent	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saint vincent	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Saint vincent	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saint vincent	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saint vincent	INFINITI Q45	F50	2001.8-	Motor control						
Saint vincent	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint vincent	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saint vincent	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saint vincent	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saint vincent	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Saint vincent	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Saint vincent	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Saint vincent	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint vincent	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Saint vincent	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Saint vincent	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Saint vincent	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saint vincent	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saint vincent	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saint vincent	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saint vincent	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saint vincent	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saint vincent	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Saint vincent	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Saint vincent	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Saint vincent	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Saint vincent	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Saint vincent	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Saint vincent	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Saint vincent	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Saint vincent	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saint vincent	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Saint vincent	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Saint vincent	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Saint vincent	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saint vincent	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Saint vincent	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saint vincent	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saint vincent	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Saint vincent	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Saint vincent	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saint vincent	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Saint vincent	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saint vincent	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Saint vincent	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Saint vincent	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Saint vincent	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Saint vincent	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saint vincent	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Saint vincent	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Saint vincent	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saint vincent	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saint vincent	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Saint vincent	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Saint vincent	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saint vincent	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Saint vincent	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saint vincent	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Saint vincent	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saint vincent	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saipan	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Air bag	√	√	√	√		
Saipan	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	
Saipan	INFINITI EX35	I50	2008.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI EX35	J50	2008.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saipan	INFINITI EX35	J50	2008.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saipan	INFINITI EX35	J50	2008.NULL	Air bag	√	√	√	√		
Saipan	INFINITI EX35	J50	2008.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saipan	INFINITI EX35	J50	2008.NULL-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saipan	INFINITI EX35	J50	2008.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saipan	INFINITI EX35	I50	2008.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saipan	INFINITI EX35	J50	2008.NULL-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI EX35	J50	2008.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI EX35	J50	2008.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI EX35	I50	2008.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saipan	INFINITI EX35	I50	2008.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saipan	INFINITI EX35	I50	2008.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saipan	INFINITI EX35	J50	2008.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI EX35	J50	2008.NULL	CAN gateway	√	√	√			
Saipan	INFINITI EX35	J50	2008.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Saipan	INFINITI EX35	J50	2008.NULL	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Saipan	INFINITI EX35	J50	2008.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI EX35	J50	2008.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI EX35	J50	2008.NULL	Rearview camera	√			√		SP0570, SP0571
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saipan	INFINITI FX35/FX45	S50	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saipan	INFINITI FX35/FX45	S50	2003.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Air bag	√	√	√	√		
Saipan	INFINITI FX35/FX45	S50	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Motor control						
Saipan	INFINITI FX35/FX45	S50	2003.NULL-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saipan	INFINITI FX35/FX45	S50	2003.NULL-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saipan	INFINITI FX35/FX45	S50	2003.NULL-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saipan	INFINITI FX35/FX45	S50	2003.NULL-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI FX35/FX45	S50	2003.NULL	HVAC	√	√	√	√		
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI FX35/FX45	S50	2003.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Saipan	INFINITI FX35/FX45	S50	2003.NULL	DIU		√	√	√		
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Adaptive light	√	√	√	√		
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saipan	INFINITI FX35/FX45	S50	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saipan	INFINITI FX35/FX45	S50	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI FX35/FX45	S50	2003.NULL-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saipan	INFINITI FX35/FX45	S50	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI FX35/FX45	S50	2003.NULL	IVMS	√	√		√		
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Distance control	√	√		√		
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Active suspense system	√	√	√	√		
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Motor assist		√	√	√		SP0574
Saipan	INFINITI FX35/FX45	S50	2003.NULL	ASCD	√	√	√	√		
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Active engine mount	√	√	√	√		
Saipan	INFINITI FX35/FX45	S50	2003.NULL	TCS	√	√	√	√		
Saipan	INFINITI FX35/FX45	S50	2003.NULL	S/blind camera	√			√		SP0572, SP0573
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	

Saipan	INFINITI FX35/FX45	S50	2003.NULL	Nats immu	√	√	√			
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Rearview camera	√			√		SP0570,SP0571
Saipan	INFINITI FX35/FX45	S50	2003.NULL	Smart entrance						SP0568
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI FX35/FX50	S51	2009.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Saipan	INFINITI FX35/FX50	S51	2009.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Air bag	√	√	√	√		
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Saipan	INFINITI FX35/FX50	S51	2009.NULL_	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0045,SP0051,SP0053,SP0063,SP0064,SP0074,SP0079,SP0083,SP0085,SP0086,SP0087,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0225,SP0239
Saipan	INFINITI FX35/FX50	S51	2009.NULL_	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Saipan	INFINITI FX35/FX50	S51	2009.NULL	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Saipan	INFINITI FX35/FX50	S51	2009.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI FX35/FX50	S51	2009.NULL	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Saipan	INFINITI FX35/FX50	S51	2009.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Auto back door	√	√	√	√		SP0611
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
Saipan	INFINITI FX35/FX50	S51	2009.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI FX35/FX50	S51	2009.NULL	CAN gateway	√	√	√			
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Saipan	INFINITI FX35/FX50	S51	2009.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI FX35/FX50	S51	2009.NULL	Rearview camera	√			√		SP0570,SP0571
Saipan	INFINITI FX37/FX50	S51	2013.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Saipan	INFINITI FX37/FX50	S51	2013.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Saipan	INFINITI FX37/FX50	S51	2013.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI FX37/FX50	S51	2013.NULL	Air bag	√	√	√	√		
Saipan	INFINITI FX37/FX50	S51	2013.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0350
Saipan	INFINITI FX37/FX50	S51	2013.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Saipan	INFINITI FX37/FX50	S51	2013.NULL	Transmission	√	√	√	√		SP0274
Saipan	INFINITI FX37/FX50	S51	2013.NULL	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Saipan	INFINITI FX37/FX50	S51	2013.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Saipan	INFINITI FX37/FX50	S51	2013.NULL	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Saipan	INFINITI FX37/FX50	S51	2013.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI FX37/FX50	S51	2013.NULL	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Saipan	INFINITI FX37/FX50	S51	2013.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI FX37/FX50	S51	2013.NULL	Auto back door	√	√	√	√		SP0611
Saipan	INFINITI FX37/FX50	S51	2013.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI FX37/FX50	S51	2013.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Saipan	INFINITI FX37/FX50	S51	2013.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Saipan	INFINITI FX37/FX50	S51	2013.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0556,SP0557
Saipan	INFINITI FX37/FX50	S51	2013.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI FX37/FX50	S51	2013.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI FX37/FX50	S51	2013.NULL	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Saipan	INFINITI FX37/FX50	S51	2013.NULL	CAN gateway	√	√	√			
Saipan	INFINITI FX37/FX50	S51	2013.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Saipan	INFINITI FX37/FX50	S51	2013.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI G20	CA33	2002.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Saipan	INFINITI G20	CA33	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
Saipan	INFINITI G20	CA33	2002.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Saipan	INFINITI G20	CA33	2002.NULL_	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Saipan	INFINITI G20	CA33	2002.NULL	Air bag	√	√	√	√		
Saipan	INFINITI G20	CA33	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Saipan	INFINITI G20	CA33	2002.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Saipan	INFINITI G20	CA33	2002.NULL	Motor control						
Saipan	INFINITI G20	CA33	2002.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Saipan	INFINITI G20	CA33	2002.NULL_	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
Saipan	INFINITI G20	CA33	2002.NULL_	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
Saipan	INFINITI G20	CA33	2002.NULL_	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Saipan	INFINITI G20	CA33	2002.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI G20	CA33	2002.NULL	HVAC	√	√	√	√		
Saipan	INFINITI G20	CA33	2002.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI G20	CA33	2002.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI G20	CA33	2002.NULL	Auto slide door	√	√	√	√	AC0941	
Saipan	INFINITI G20	CA33	2002.NULL	DIU		√	√	√		
Saipan	INFINITI G20	CA33	2002.NULL	Adaptive light	√	√	√	√		
Saipan	INFINITI G20	CA33	2002.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Saipan	INFINITI G20	CA33	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saipan	INFINITI G20	CA33	2002.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Saipan	INFINITI G20	CA33	2002.NULL_	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Saipan	INFINITI G20	CA33	2002.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Saipan	INFINITI G20	CA33	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI G20	CA33	2002.NULL	IVMS	√	√		√		
Saipan	INFINITI G20	CA33	2002.NULL	Distance control	√	√		√		
Saipan	INFINITI G20	CA33	2002.NULL	Active suspense system	√	√	√	√		
Saipan	INFINITI G20	CA33	2002.NULL	Motor assist		√	√	√		SP0574
Saipan	INFINITI G20	CA33	2002.NULL	ASCD	√	√	√	√		
Saipan	INFINITI G20	CA33	2002.NULL	Active engine mount	√	√	√	√		
Saipan	INFINITI G20	CA33	2002.NULL	TCS	√	√	√	√		
Saipan	INFINITI G20	CA33	2002.NULL	S/blind camera	√			√		SP0572,SP0573
Saipan	INFINITI G20	CA33	2002.NULL	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Saipan	INFINITI G20	CA33	2002.NULL	Nats immu	√	√	√			
Saipan	INFINITI G20	CA33	2002.NULL	Rearview camera	√			√		SP0570,SP0571
Saipan	INFINITI G20	CA33	2002.NULL	Smart entrance						SP0568
Saipan	INFINITI G20	P11	1999.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Saipan	INFINITI G20	P11	1999.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
Saipan	INFINITI G20	P11	1999.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Saipan	INFINITI G20	P11	1999.NULL_	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Saipan	INFINITI G20	P11	1999.NULL	Air bag	√	√	√	√		
Saipan	INFINITI G20	P11	1999.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Saipan	INFINITI G20	P11	1999.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Saipan	INFINITI G20	P11	1999.NULL	Motor control						

Saipan	INFINITI G20	P11	1999.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saipan	INFINITI G20	P11	1999.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saipan	INFINITI G20	P11	1999.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saipan	INFINITI G20	P11	1999.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI G20	P11	1999.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI G20	P11	1999.NULL	HVAC	√	√	√	√		
Saipan	INFINITI G20	P11	1999.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI G20	P11	1999.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI G20	P11	1999.NULL	Auto slide door	√	√	√	√	AC0941	
Saipan	INFINITI G20	P11	1999.NULL	DIU		√	√	√		
Saipan	INFINITI G20	P11	1999.NULL	Adaptive light	√	√	√	√		
Saipan	INFINITI G20	P11	1999.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saipan	INFINITI G20	P11	1999.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saipan	INFINITI G20	P11	1999.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI G20	P11	1999.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saipan	INFINITI G20	P11	1999.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saipan	INFINITI G20	P11	1999.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI G20	P11	1999.NULL	IVMS	√	√		√		
Saipan	INFINITI G20	P11	1999.NULL	Distance control	√	√		√		
Saipan	INFINITI G20	P11	1999.NULL	Active suspense system	√	√	√	√		
Saipan	INFINITI G20	P11	1999.NULL	Motor assist		√	√	√		SP0574
Saipan	INFINITI G20	P11	1999.NULL	ASCD	√	√	√	√		
Saipan	INFINITI G20	P11	1999.NULL	Active engine mount	√	√	√	√		
Saipan	INFINITI G20	P11	1999.NULL	TCS	√	√	√	√		
Saipan	INFINITI G20	P11	1999.NULL	S/blind camera	√			√		SP0572, SP0573
Saipan	INFINITI G20	P11	1999.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saipan	INFINITI G20	P11	1999.NULL	Nats immu	√	√	√			
Saipan	INFINITI G20	P11	1999.NULL	Rearview camera	√			√		SP0570, SP0571
Saipan	INFINITI G20	P11	1999.NULL	Smart entrance						SP0568
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Air bag	√	√	√	√		
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Transmission	√	√	√	√		SP0274
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Pop up hood	√	√	√	√		
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Precrash seatbelt	√	√	√	√		
Saipan	INFINITI G25/G37 SEDAN	V36	2011.NULL_	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saipan	INFINITI G35 COUPE	CV35	2003.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Air bag	√	√	√	√		
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Motor control						
Saipan	INFINITI G35 COUPE	CV35	2003.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saipan	INFINITI G35 COUPE	CV35	2003.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saipan	INFINITI G35 COUPE	CV35	2003.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saipan	INFINITI G35 COUPE	CV35	2003.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	HVAC	√	√	√	√		
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI G35 COUPE	CV35	2003.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	DIU		√	√	√		
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Adaptive light	√	√	√	√		
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI G35 COUPE	CV35	2003.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	

XTOOL

Saipan	INFINITI G35 COUPE	CV35	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	IVMS	√	√		√		
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Distance control	√	√		√		
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Active suspense system	√	√	√	√		
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Motor assist		√	√	√		SP0574
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	ASCD	√	√	√	√		
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Active engine mount	√	√	√	√		
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	TCS	√	√	√	√		
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	S/blind camera	√			√		SP0572,SP0573
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Nats immu	√	√	√			
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Rearview camera	√			√		SP0570,SP0571
Saipan	INFINITI G35 COUPE	CV35	2003.NULL	Smart entrance						SP0568
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Saipan	INFINITI G35 SEDAN	V35	2003.NULL_	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Air bag	√	√	√	√		
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Motor control						
Saipan	INFINITI G35 SEDAN	V35	2003.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Saipan	INFINITI G35 SEDAN	V35	2003.NULL_	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
Saipan	INFINITI G35 SEDAN	V35	2003.NULL_	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
Saipan	INFINITI G35 SEDAN	V35	2003.NULL_	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	HVAC	√	√	√	√		
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI G35 SEDAN	V35	2003.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	DIU		√	√	√		
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Adaptive light	√	√	√	√		
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Saipan	INFINITI G35 SEDAN	V35	2003.NULL_	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	IVMS	√	√		√		
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Distance control	√	√		√		
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Active suspense system	√	√	√	√		
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Motor assist		√	√	√		SP0574
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	ASCD	√	√	√	√		
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Active engine mount	√	√	√	√		
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	TCS	√	√	√	√		
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	S/blind camera	√			√		SP0572,SP0573
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Nats immu	√	√	√			
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Rearview camera	√			√		SP0570,SP0571
Saipan	INFINITI G35 SEDAN	V35	2003.NULL	Smart entrance						SP0568
Saipan	INFINITI G35 SEDAN	V36	2007.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI G35 SEDAN	V36	2007.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Saipan	INFINITI G35 SEDAN	V36	2007.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI G35 SEDAN	V36	2007.NULL	Air bag	√	√	√	√		
Saipan	INFINITI G35 SEDAN	V36	2007.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Saipan	INFINITI G35 SEDAN	V36	2007.NULL_	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Saipan	INFINITI G35 SEDAN	V36	2007.NULL_	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270
Saipan	INFINITI G35 SEDAN	V36	2007.NULL	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Saipan	INFINITI G35 SEDAN	V36	2007.NULL_	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Saipan	INFINITI G35 SEDAN	V36	2007.NULL	Multi AV	√	√	√	√		
Saipan	INFINITI G35 SEDAN	V36	2007.NULL	4WAS(front)	√	√	√	√	AC1027,AC1028	
Saipan	INFINITI G35 SEDAN	V36	2007.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI G35 SEDAN	V36	2007.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Saipan	INFINITI G35 SEDAN	V36	2007.NULL	All mode AWD/4WD	√	√	√	√	AC0957	
Saipan	INFINITI G35 SEDAN	V36	2007.NULL	Precrash seatbelt	√	√	√	√		
Saipan	INFINITI G35 SEDAN	V36	2007.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Air bag	√	√	√	√		
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0161,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0176,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Pop up hood	√	√	√	√		
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	4WAS(front)	√	√	√	√	AC1027,AC1028	
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Precrash seatbelt	√	√	√	√		

Saipan	INFINITI G37 CONVERTIBLE	HV36	2009.NULL-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	Air bag	√	√	√	√		
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Saipan	INFINITI G37 COUPE	CV36	2008.NULL-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0049,AC0052,AC0053,AC0054,AC0062,AC0066,AC0067,AC0068,AC0069,AC0070,AC0148,AC0149,AC0150,AC0156,AC0161,AC0164,AC0166,AC0168,AC0173,AC0174,AC0176,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Saipan	INFINITI G37 COUPE	CV36	2008.NULL-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Saipan	INFINITI G37 COUPE	CV36	2008.NULL-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	Pop up hood	√	√	√	√		
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	4WAS(front)	√	√	√	√	AC1027,AC1028	
Saipan	INFINITI G37 COUPE	CV36	2008.NULL-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	All mode AWD/4WD	√	√	√	√	AC0956,AC0957	
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	Precrash seatbelt	√	√	√	√		
Saipan	INFINITI G37 COUPE	CV36	2008.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI G37 SEDAN	V36	2009.NULL	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Saipan	INFINITI G37 SEDAN	V36	2009.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Saipan	INFINITI G37 SEDAN	V36	2009.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI G37 SEDAN	V36	2009.NULL	Air bag	√	√	√	√		
Saipan	INFINITI G37 SEDAN	V36	2009.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Saipan	INFINITI G37 SEDAN	V36	2009.NULL-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Saipan	INFINITI G37 SEDAN	V36	2009.NULL-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Saipan	INFINITI G37 SEDAN	V36	2009.NULL	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Saipan	INFINITI G37 SEDAN	V36	2009.NULL-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Saipan	INFINITI G37 SEDAN	V36	2009.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI G37 SEDAN	V36	2009.NULL	4WAS(front)	√	√	√	√	AC1027,AC1028	
Saipan	INFINITI G37 SEDAN	V36	2009.NULL-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI G37 SEDAN	V36	2009.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Saipan	INFINITI G37 SEDAN	V36	2009.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Saipan	INFINITI G37 SEDAN	V36	2009.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI G37 SEDAN	V36	2009.NULL	Precrash seatbelt	√	√	√	√		
Saipan	INFINITI G37 SEDAN	V36	2009.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI I30	CA32	1996.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Saipan	INFINITI I30	CA32	1996.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
Saipan	INFINITI I30	CA32	1996.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Saipan	INFINITI I30	CA32	1996.NULL-	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Saipan	INFINITI I30	CA32	1996.NULL	Air bag	√	√	√	√		
Saipan	INFINITI I30	CA32	1996.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Saipan	INFINITI I30	CA32	1996.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Saipan	INFINITI I30	CA32	1996.NULL	Motor control						
Saipan	INFINITI I30	CA32	1996.NULL-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Saipan	INFINITI I30	CA32	1996.NULL-	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
Saipan	INFINITI I30	CA32	1996.NULL-	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
Saipan	INFINITI I30	CA32	1996.NULL-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Saipan	INFINITI I30	CA32	1996.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI I30	CA32	1996.NULL	HVAC	√	√	√	√		
Saipan	INFINITI I30	CA32	1996.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI I30	CA32	1996.NULL-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI I30	CA32	1996.NULL	Auto slide door	√	√	√	√	AC0941	
Saipan	INFINITI I30	CA32	1996.NULL	DIU		√	√	√		
Saipan	INFINITI I30	CA32	1996.NULL	Adaptive light	√	√	√	√		
Saipan	INFINITI I30	CA32	1996.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Saipan	INFINITI I30	CA32	1996.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saipan	INFINITI I30	CA32	1996.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Saipan	INFINITI I30	CA32	1996.NULL-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Saipan	INFINITI I30	CA32	1996.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
Saipan	INFINITI I30	CA32	1996.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI I30	CA32	1996.NULL	IVMS	√	√		√		
Saipan	INFINITI I30	CA32	1996.NULL	Distance control	√	√		√		
Saipan	INFINITI I30	CA32	1996.NULL	Active suspense system	√	√	√	√		
Saipan	INFINITI I30	CA32	1996.NULL	Motor assist		√	√	√		SP0574
Saipan	INFINITI I30	CA32	1996.NULL	ASCD	√	√	√	√		
Saipan	INFINITI I30	CA32	1996.NULL	Active engine mount	√	√	√	√		
Saipan	INFINITI I30	CA32	1996.NULL	TCS	√	√	√	√		
Saipan	INFINITI I30	CA32	1996.NULL	S/blind camera	√			√		SP0572,SP0573
Saipan	INFINITI I30	CA32	1996.NULL	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Saipan	INFINITI I30	CA32	1996.NULL	Nats immu	√	√	√			
Saipan	INFINITI I30	CA32	1996.NULL	Rearview camera	√			√		SP0570,SP0571
Saipan	INFINITI I30	CA32	1996.NULL	Smart entrance						SP0568
Saipan	INFINITI I35	CA33	2002.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Saipan	INFINITI I35	CA33	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
Saipan	INFINITI I35	CA33	2002.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Saipan	INFINITI I35	CA33	2002.NULL-	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Saipan	INFINITI I35	CA33	2002.NULL	Air bag	√	√	√	√		
Saipan	INFINITI I35	CA33	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
Saipan	INFINITI I35	CA33	2002.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
Saipan	INFINITI I35	CA33	2002.NULL	Motor control						
Saipan	INFINITI I35	CA33	2002.NULL-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Saipan	INFINITI I35	CA33	2002.NULL-	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288

Saipan	INFINITI I35	CA33	2002.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saipan	INFINITI I35	CA33	2002.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI I35	CA33	2002.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI I35	CA33	2002.NULL	HVAC	√	√	√	√		
Saipan	INFINITI I35	CA33	2002.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI I35	CA33	2002.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI I35	CA33	2002.NULL	Auto slide door	√	√	√	√	AC0941	
Saipan	INFINITI I35	CA33	2002.NULL	DIU		√	√	√		
Saipan	INFINITI I35	CA33	2002.NULL	Adaptive light	√	√	√	√		
Saipan	INFINITI I35	CA33	2002.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saipan	INFINITI I35	CA33	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saipan	INFINITI I35	CA33	2002.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI I35	CA33	2002.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saipan	INFINITI I35	CA33	2002.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saipan	INFINITI I35	CA33	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI I35	CA33	2002.NULL	IVMS	√	√		√		
Saipan	INFINITI I35	CA33	2002.NULL	Distance control	√	√		√		
Saipan	INFINITI I35	CA33	2002.NULL	Active suspense system	√	√	√	√		
Saipan	INFINITI I35	CA33	2002.NULL	Motor assist		√	√	√		SP0574
Saipan	INFINITI I35	CA33	2002.NULL	ASCD	√	√	√	√		
Saipan	INFINITI I35	CA33	2002.NULL	Active engine mount	√	√	√	√		
Saipan	INFINITI I35	CA33	2002.NULL	TCS	√	√	√	√		
Saipan	INFINITI I35	CA33	2002.NULL	S/blind camera	√			√		SP0572, SP0573
Saipan	INFINITI I35	CA33	2002.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saipan	INFINITI I35	CA33	2002.NULL	Nats immu	√	√	√			
Saipan	INFINITI I35	CA33	2002.NULL	Rearview camera	√			√		SP0570, SP0571
Saipan	INFINITI I35	CA33	2002.NULL	Smart entrance						SP0568
Saipan	INFINITI JX35	L50	2013.NULL	Laser/radar	√	√	√	√		
Saipan	INFINITI JX35	L50	2013.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI JX35	L50	2013.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saipan	INFINITI JX35	L50	2013.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saipan	INFINITI JX35	L50	2013.NULL	Air bag	√	√	√	√		
Saipan	INFINITI JX35	L50	2013.NULL	EPS/DAST 3	√	√	√	√		
Saipan	INFINITI JX35	L50	2013.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saipan	INFINITI JX35	L50	2013.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saipan	INFINITI JX35	L50	2013.NULL_	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Saipan	INFINITI JX35	L50	2013.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saipan	INFINITI JX35	L50	2013.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saipan	INFINITI JX35	L50	2013.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI JX35	L50	2013.NULL	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Saipan	INFINITI JX35	L50	2013.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI JX35	L50	2013.NULL	Auto back door	√	√	√	√		SP0611
Saipan	INFINITI JX35	L50	2013.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI JX35	L50	2013.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saipan	INFINITI JX35	L50	2013.NULL	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Saipan	INFINITI JX35	L50	2013.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI JX35	L50	2013.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI JX35	L50	2013.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI JX35	L50	2013.NULL	CAN gateway	√	√	√			
Saipan	INFINITI JX35	L50	2013.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saipan	INFINITI JX35	L50	2013.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI JX35	L50	2013.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saipan	INFINITI JX35	L50	2013.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI M35/M45	Y50	2006.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saipan	INFINITI M35/M45	Y50	2006.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Saipan	INFINITI M35/M45	Y50	2006.NULL_	IPDM E/R	√	√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Saipan	INFINITI M35/M45	Y50	2006.NULL	Air bag	√	√	√	√		
Saipan	INFINITI M35/M45	Y50	2006.NULL	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Saipan	INFINITI M35/M45	Y50	2006.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saipan	INFINITI M35/M45	Y50	2006.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saipan	INFINITI M35/M45	Y50	2006.NULL	BCM					AC0653, AC0698	SP0391, SP0393
Saipan	INFINITI M35/M45	Y50	2006.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI M35/M45	Y50	2006.NULL	Multi AV	√	√	√	√		
Saipan	INFINITI M35/M45	Y50	2006.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI M35/M45	Y50	2006.NULL	Adaptive light	√	√	√	√		SP0561, SP0562
Saipan	INFINITI M35/M45	Y50	2006.NULL	All mode AWD/4WD	√	√	√	√	AC0957	
Saipan	INFINITI M35/M45	Y50	2006.NULL	Precrash seatbelt	√	√	√	√		
Saipan	INFINITI M35/M45	Y50	2006.NULL_	Intelligent key	√	√	√	√	AC0911, AC0913, AC0915, AC0916, AC0917, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Saipan	INFINITI M35/M45	Y50	2006.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976	SP0560
Saipan	INFINITI M35/M45	Y50	2006.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI M35H	HY51	2012.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saipan	INFINITI M35H	HY51	2012.NULL	Laser/radar	√	√	√	√		
Saipan	INFINITI M35H	HY51	2012.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI M35H	HY51	2012.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saipan	INFINITI M35H	HY51	2012.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saipan	INFINITI M35H	HY51	2012.NULL	Air bag	√	√	√	√		
Saipan	INFINITI M35H	HY51	2012.NULL	EPS/DAST 3	√	√	√	√		
Saipan	INFINITI M35H	HY51	2012.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saipan	INFINITI M35H	HY51	2012.NULL	Motor control	√	√	√	√		
Saipan	INFINITI M35H	HY51	2012.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saipan	INFINITI M35H	HY51	2012.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Saipan	INFINITI M35H	HY51	2012.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saipan	INFINITI M35H	HY51	2012.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saipan	INFINITI M35H	HY51	2012.NULL	Diag data recorder	√					
Saipan	INFINITI M35H	HY51	2012.NULL	Pop up hood	√	√	√	√		
Saipan	INFINITI M35H	HY51	2012.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI M35H	HY51	2012.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saipan	INFINITI M35H	HY51	2012.NULL	HV battery	√	√	√	√	AC1121	
Saipan	INFINITI M35H	HY51	2012.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI M35H	HY51	2012.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Saipan	INFINITI M35H	HY51	2012.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saipan	INFINITI M35H	HY51	2012.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saipan	INFINITI M35H	HY51	2012.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saipan	INFINITI M35H	HY51	2012.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI M35H	HY51	2012.NULL	CAN gateway	√	√	√			
Saipan	INFINITI M35H	HY51	2012.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saipan	INFINITI M35H	HY51	2012.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI M35H	HY51	2012.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saipan	INFINITI M35H	HY51	2012.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI M35H	HY51	2012.NULL	Brake	√	√	√	√	AC1127	
Saipan	INFINITI M35H	HY51	2012.NULL	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Saipan	INFINITI M37/M56	Y51	2011.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saipan	INFINITI M37/M56	Y51	2011.NULL	Laser/radar	√	√	√	√		

Saipan	INFINITI M37/M56	Y51	2011.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI M37/M56	Y51	2011.NULL	Convertible roof	√	√	√	√	AC1006.AC1007.AC1008.AC1009.AC1010	SP0575.SP0576.SP0577.SP0578.SP0579.SP0580
Saipan	INFINITI M37/M56	Y51	2011.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saipan	INFINITI M37/M56	Y51	2011.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saipan	INFINITI M37/M56	Y51	2011.NULL	Air bag	√	√	√	√		
Saipan	INFINITI M37/M56	Y51	2011.NULL	EPS/DAST 3	√	√	√	√		
Saipan	INFINITI M37/M56	Y51	2011.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saipan	INFINITI M37/M56	Y51	2011.NULL	Motor control	√	√	√	√		
Saipan	INFINITI M37/M56	Y51	2011.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saipan	INFINITI M37/M56	Y51	2011.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saipan	INFINITI M37/M56	Y51	2011.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saipan	INFINITI M37/M56	Y51	2011.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI M37/M56	Y51	2011.NULL	Pop up hood	√	√	√	√		
Saipan	INFINITI M37/M56	Y51	2011.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI M37/M56	Y51	2011.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saipan	INFINITI M37/M56	Y51	2011.NULL	HV battery	√	√	√	√	AC1121	
Saipan	INFINITI M37/M56	Y51	2011.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saipan	INFINITI M37/M56	Y51	2011.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saipan	INFINITI M37/M56	Y51	2011.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI M37/M56	Y51	2011.NULL	EV/HEV	√	√	√	√	AC1084.AC1085.AC1086.AC1087.AC1088.AC1089.AC1106	
Saipan	INFINITI M37/M56	Y51	2011.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saipan	INFINITI M37/M56	Y51	2011.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saipan	INFINITI M37/M56	Y51	2011.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saipan	INFINITI M37/M56	Y51	2011.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI M37/M56	Y51	2011.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI M37/M56	Y51	2011.NULL	CAN gateway	√	√	√			
Saipan	INFINITI M37/M56	Y51	2011.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saipan	INFINITI M37/M56	Y51	2011.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI M37/M56	Y51	2011.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI M37/M56	Y51	2011.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saipan	INFINITI M37/M56	Y51	2011.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI M37/M56	Y51	2011.NULL	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Saipan	INFINITI M45	Y34	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saipan	INFINITI M45	Y34	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saipan	INFINITI M45	Y34	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saipan	INFINITI M45	Y34	2003.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saipan	INFINITI M45	Y34	2003.NULL	Air bag	√	√	√	√		
Saipan	INFINITI M45	Y34	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saipan	INFINITI M45	Y34	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saipan	INFINITI M45	Y34	2003.NULL	Motor control						
Saipan	INFINITI M45	Y34	2003.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saipan	INFINITI M45	Y34	2003.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saipan	INFINITI M45	Y34	2003.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saipan	INFINITI M45	Y34	2003.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI M45	Y34	2003.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI M45	Y34	2003.NULL	HVAC	√	√	√	√		
Saipan	INFINITI M45	Y34	2003.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI M45	Y34	2003.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI M45	Y34	2003.NULL	Auto slide door	√	√	√	√	AC0941	
Saipan	INFINITI M45	Y34	2003.NULL	DIU		√	√	√		
Saipan	INFINITI M45	Y34	2003.NULL	Adaptive light	√	√	√	√		
Saipan	INFINITI M45	Y34	2003.NULL	Sonar	√	√	√	√	AC0962.AC0963.AC0964.AC0966.AC0967.AC0968.AC0969.AC0970	SP0553.SP0554.SP0555.SP0556.SP0557.SP0558.SP0559
Saipan	INFINITI M45	Y34	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saipan	INFINITI M45	Y34	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI M45	Y34	2003.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saipan	INFINITI M45	Y34	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saipan	INFINITI M45	Y34	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI M45	Y34	2003.NULL	IVMS	√	√		√		
Saipan	INFINITI M45	Y34	2003.NULL	Distance control	√	√		√		
Saipan	INFINITI M45	Y34	2003.NULL	Active suspense system	√	√	√	√		
Saipan	INFINITI M45	Y34	2003.NULL	Motor assist		√	√	√		SP0574
Saipan	INFINITI M45	Y34	2003.NULL	ASCD	√	√	√	√		
Saipan	INFINITI M45	Y34	2003.NULL	Active engine mount	√	√	√	√		
Saipan	INFINITI M45	Y34	2003.NULL	TCS	√	√	√	√		
Saipan	INFINITI M45	Y34	2003.NULL	S/blind camera	√			√		SP0572.SP0573
Saipan	INFINITI M45	Y34	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saipan	INFINITI M45	Y34	2003.NULL	Nats immu	√	√	√			
Saipan	INFINITI M45	Y34	2003.NULL	Rearview camera	√			√		SP0570, SP0571
Saipan	INFINITI M45	Y34	2003.NULL	Smart entrance						SP0568
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL	Air bag	√	√	√	√		
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0038, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL	Transmission	√	√	√	√		SP0274
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL	Pop up hood	√	√	√	√		
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI Q40 SEDAN	V36	2015.NULL	Precrash seatbelt	√	√	√	√		
Saipan	INFINITI Q45	F50	2002.NULL	Air pressure monitor	√	√	√	√	AC0894.AC0895.AC0896.AC0897.AC0898.AC0899.AC0900.AC0901.AC0902	SP0508.SP0509.SP0510
Saipan	INFINITI Q45	F50	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492.SP0493
Saipan	INFINITI Q45	F50	2002.NULL	ICC/ADAS	√	√	√	√	AC0865.AC0866.AC0867.AC0868.AC0876.AC0877.AC0884	SP0494
Saipan	INFINITI Q45	F50	2002.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saipan	INFINITI Q45	F50	2002.NULL	Air bag	√	√	√	√		
Saipan	INFINITI Q45	F50	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saipan	INFINITI Q45	F50	2002.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saipan	INFINITI Q45	F50	2002.NULL	Motor control						

Saipan	INFINITI Q45	F50	2002.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saipan	INFINITI Q45	F50	2002.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saipan	INFINITI Q45	F50	2002.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saipan	INFINITI Q45	F50	2002.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI Q45	F50	2002.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI Q45	F50	2002.NULL	HVAC	√	√	√	√		
Saipan	INFINITI Q45	F50	2002.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI Q45	F50	2002.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI Q45	F50	2002.NULL	Auto slide door	√	√	√	√	AC0941	
Saipan	INFINITI Q45	F50	2002.NULL	DIU		√	√	√		
Saipan	INFINITI Q45	F50	2002.NULL	Adaptive light	√	√	√	√		
Saipan	INFINITI Q45	F50	2002.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saipan	INFINITI Q45	F50	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saipan	INFINITI Q45	F50	2002.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI Q45	F50	2002.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saipan	INFINITI Q45	F50	2002.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saipan	INFINITI Q45	F50	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI Q45	F50	2002.NULL	IVMS	√	√		√		
Saipan	INFINITI Q45	F50	2002.NULL	Distance control	√	√		√		
Saipan	INFINITI Q45	F50	2002.NULL	Active suspense system	√	√	√	√		
Saipan	INFINITI Q45	F50	2002.NULL	Motor assist		√	√	√		SP0574
Saipan	INFINITI Q45	F50	2002.NULL	ASCD	√	√	√	√		
Saipan	INFINITI Q45	F50	2002.NULL	Active engine mount	√	√	√	√		
Saipan	INFINITI Q45	F50	2002.NULL	TCS	√	√	√	√		
Saipan	INFINITI Q45	F50	2002.NULL	S/blind camera	√			√		SP0572, SP0573
Saipan	INFINITI Q45	F50	2002.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saipan	INFINITI Q45	F50	2002.NULL	Nats immu	√	√	√			
Saipan	INFINITI Q45	F50	2002.NULL	Rearview camera	√			√		SP0570, SP0571
Saipan	INFINITI Q45	F50	2002.NULL	Smart entrance						SP0568
Saipan	INFINITI Q45	FY33	1995.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saipan	INFINITI Q45	FY33	1995.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saipan	INFINITI Q45	FY33	1995.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saipan	INFINITI Q45	FY33	1995.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saipan	INFINITI Q45	FY33	1995.NULL	Air bag	√	√	√	√		
Saipan	INFINITI Q45	FY33	1995.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saipan	INFINITI Q45	FY33	1995.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saipan	INFINITI Q45	FY33	1995.NULL	Motor control						
Saipan	INFINITI Q45	FY33	1995.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saipan	INFINITI Q45	FY33	1995.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saipan	INFINITI Q45	FY33	1995.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saipan	INFINITI Q45	FY33	1995.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI Q45	FY33	1995.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI Q45	FY33	1995.NULL	HVAC	√	√	√	√		
Saipan	INFINITI Q45	FY33	1995.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI Q45	FY33	1995.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI Q45	FY33	1995.NULL	Auto slide door	√	√	√	√	AC0941	
Saipan	INFINITI Q45	FY33	1995.NULL	DIU		√	√	√		
Saipan	INFINITI Q45	FY33	1995.NULL	Adaptive light	√	√	√	√		
Saipan	INFINITI Q45	FY33	1995.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saipan	INFINITI Q45	FY33	1995.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saipan	INFINITI Q45	FY33	1995.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI Q45	FY33	1995.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saipan	INFINITI Q45	FY33	1995.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saipan	INFINITI Q45	FY33	1995.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI Q45	FY33	1995.NULL	IVMS	√	√		√		
Saipan	INFINITI Q45	FY33	1995.NULL	Distance control	√	√		√		
Saipan	INFINITI Q45	FY33	1995.NULL	Active suspense system	√	√	√	√		
Saipan	INFINITI Q45	FY33	1995.NULL	Motor assist		√	√	√		SP0574
Saipan	INFINITI Q45	FY33	1995.NULL	ASCD	√	√	√	√		
Saipan	INFINITI Q45	FY33	1995.NULL	Active engine mount	√	√	√	√		
Saipan	INFINITI Q45	FY33	1995.NULL	TCS	√	√	√	√		
Saipan	INFINITI Q45	FY33	1995.NULL	S/blind camera	√			√		SP0572, SP0573
Saipan	INFINITI Q45	FY33	1995.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saipan	INFINITI Q45	FY33	1995.NULL	Nats immu	√	√	√			
Saipan	INFINITI Q45	FY33	1995.NULL	Rearview camera	√			√		SP0570, SP0571
Saipan	INFINITI Q45	FY33	1995.NULL	Smart entrance						SP0568
Saipan	INFINITI Q50	V37	2019.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Saipan	INFINITI Q50	V37	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Saipan	INFINITI Q50	V37	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI Q50	V37	2019.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Saipan	INFINITI Q50	V37	2019.NULL	IPDM E/R	√	√	√	√	AC0811.AC0815.AC0816.AC0817.AC0818.AC0819.AC0821.AC0822.AC0825.AC0831	
Saipan	INFINITI Q50	V37	2019.NULL	Air bag	√	√	√	√		
Saipan	INFINITI Q50	V37	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
Saipan	INFINITI Q50	V37	2019.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saipan	INFINITI Q50	V37	2019.NULL	Motor control	√	√	√	√		
Saipan	INFINITI Q50	V37	2019.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saipan	INFINITI Q50	V37	2019.NULL	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Saipan	INFINITI Q50	V37	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saipan	INFINITI Q50	V37	2019.NULL_	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saipan	INFINITI Q50	V37	2019.NULL	Pop up hood	√	√	√	√		
Saipan	INFINITI Q50	V37	2019.NULL	Multi AV	√	√	√	√		SP0503

Saipan	INFINITI Q50	V37	2019.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saipan	INFINITI Q50	V37	2019.NULL	HV battery	√	√	√	√	AC1121	
Saipan	INFINITI Q50	V37	2019.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saipan	INFINITI Q50	V37	2019.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saipan	INFINITI Q50	V37	2019.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI Q50	V37	2019.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Saipan	INFINITI Q50	V37	2019.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI Q50	V37	2019.NULL	Shift	√	√	√	√		SP0613
Saipan	INFINITI Q50	V37	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Saipan	INFINITI Q50	V37	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saipan	INFINITI Q50	V37	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saipan	INFINITI Q50	V37	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI Q50	V37	2019.NULL	DAST 2	√	√	√	√		
Saipan	INFINITI Q50	V37	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI Q50	V37	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI Q50	V37	2019.NULL	CAN gateway	√	√	√			
Saipan	INFINITI Q50	V37	2019.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saipan	INFINITI Q50	V37	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI Q50	V37	2019.NULL	DAST 1	√	√	√	√		
Saipan	INFINITI Q50	V37	2019.NULL_	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Saipan	INFINITI Q50	V37	2019.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Saipan	INFINITI Q50	V37	2019.NULL	ANC	√	√	√	√	AC1024	
Saipan	INFINITI Q50	V37	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI Q50	V37	2019.NULL	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Saipan	INFINITI Q50	V37	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saipan	INFINITI Q50	V37	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
Saipan	INFINITI Q50	V37	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI Q50	V37	2019.NULL	Brake	√	√	√	√	AC1127	
Saipan	INFINITI Q50	V37	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Saipan	INFINITI Q50	V37	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
Saipan	INFINITI Q50	V37	2019.NULL	ICC/ADAS 2	√	√	√	√		
Saipan	INFINITI Q50	V37	2019.NULL	FSCM	√	√	√	√	AC1109	
Saipan	INFINITI Q50	V37	2019.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Laser/radar	√	√	√	√		
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Air bag	√	√	√	√		
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Motor control	√	√	√	√		
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Transmission	√	√	√	√		SP0274, SP0276
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL_	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Pop up hood	√	√	√	√		
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	HV battery	√	√	√	√	AC1121	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Shift	√	√	√	√		SP0613
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	DAST 2	√	√	√	√		
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	CAN gateway	√	√	√			
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	DAST 1	√	√	√	√		
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL_	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	ANC	√	√	√	√	AC1024	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	HIGH BEAM ASSIST	√	√	√	√		
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	Brake	√	√	√	√	AC1127	
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	6ch CAN GATEWAY	√	√	√	√		
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	3ch CAN GATEWAY	√	√	√	√		
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	ICC/ADAS 2	√	√	√	√		
Saipan	INFINITI Q50 HYBRID	HV37	2014.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Laser/radar	√	√	√	√		
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Air bag	√	√	√	√		
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	EPS/DAST 3	√	√	√	√		
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Motor control	√	√	√	√		
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Transmission	√	√	√	√		SP0276
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Pop up hood	√	√	√	√		
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	HV battery	√	√	√	√	AC1121	
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Occupant detection			√	√		SP0584
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 2	√	√	√	√		
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Lane camera	√	√	√	√		
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 1	√	√	√	√		
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	

Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	ANC	√	√	√	√	AC1024	
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	HIGH BEAM ASSIST	√	√	√	√		
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√		
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	Brake	√	√	√	√	AC1127	
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	6ch CAN GATEWAY	√	√	√	√		
Saipan	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Saipan	INFINITI Q60	CV37	2019.NULL	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Saipan	INFINITI Q60	CV37	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Saipan	INFINITI Q60	CV37	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI Q60	CV37	2019.NULL_	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Saipan	INFINITI Q60	CV37	2019.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI Q60	CV37	2019.NULL	Air bag	√	√	√	√		
Saipan	INFINITI Q60	CV37	2019.NULL	EPS/DAST 3	√	√	√	√		
Saipan	INFINITI Q60	CV37	2019.NULL	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Saipan	INFINITI Q60	CV37	2019.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Saipan	INFINITI Q60	CV37	2019.NULL	Transmission	√	√	√	√		SP0247,SP0265,SP0274
Saipan	INFINITI Q60	CV37	2019.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Saipan	INFINITI Q60	CV37	2019.NULL_	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Saipan	INFINITI Q60	CV37	2019.NULL	Pop up hood	√	√	√	√		
Saipan	INFINITI Q60	CV37	2019.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI Q60	CV37	2019.NULL_	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Saipan	INFINITI Q60	CV37	2019.NULL	4WAS(front)	√	√	√	√	AC1027,AC1028	
Saipan	INFINITI Q60	CV37	2019.NULL	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI Q60	CV37	2019.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI Q60	CV37	2019.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Saipan	INFINITI Q60	CV37	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Saipan	INFINITI Q60	CV37	2019.NULL	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Saipan	INFINITI Q60	CV37	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI Q60	CV37	2019.NULL	DAST 2	√	√	√	√		
Saipan	INFINITI Q60	CV37	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI Q60	CV37	2019.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Saipan	INFINITI Q60	CV37	2019.NULL	CAN gateway	√	√	√			
Saipan	INFINITI Q60	CV37	2019.NULL	Lane camera	√	√	√	√		
Saipan	INFINITI Q60	CV37	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI Q60	CV37	2019.NULL	DAST 1	√	√	√	√		
Saipan	INFINITI Q60	CV37	2019.NULL_	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Saipan	INFINITI Q60	CV37	2019.NULL	ANC	√	√	√	√	AC1024	
Saipan	INFINITI Q60	CV37	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI Q60	CV37	2019.NULL	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Saipan	INFINITI Q60	CV37	2019.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Saipan	INFINITI Q60	CV37	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
Saipan	INFINITI Q60	CV37	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI Q60	CV37	2019.NULL	Lane camera 2	√	√	√	√		
Saipan	INFINITI Q60	CV37	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Saipan	INFINITI Q60	CV37	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
Saipan	INFINITI Q60	CV37	2019.NULL	ICC/ADAS 2	√	√	√	√		
Saipan	INFINITI Q60	CV37	2019.NULL	FSCM	√	√	√	√	AC1109	
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Air bag	√	√	√	√		
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Transmission	√	√	√	√		SP0274
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Pop up hood	√	√	√	√		
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Saipan	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL_	Precrash seatbelt	√	√	√	√		
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	Air bag	√	√	√	√		
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	Transmission	√	√	√	√		SP0274
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL_	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	Pop up hood	√	√	√	√		
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI Q60 COUPE	CV36	2014.NULL	Precrash seatbelt	√	√	√	√		

Saipan	INFINITI Q70	Y51	2019.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Saipan	INFINITI Q70	Y51	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Saipan	INFINITI Q70	Y51	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI Q70	Y51	2019.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Saipan	INFINITI Q70	Y51	2019.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI Q70	Y51	2019.NULL	Air bag	√	√	√	√		
Saipan	INFINITI Q70	Y51	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
Saipan	INFINITI Q70	Y51	2019.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saipan	INFINITI Q70	Y51	2019.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saipan	INFINITI Q70	Y51	2019.NULL	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Saipan	INFINITI Q70	Y51	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saipan	INFINITI Q70	Y51	2019.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI Q70	Y51	2019.NULL	Pop up hood	√	√	√	√		
Saipan	INFINITI Q70	Y51	2019.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI Q70	Y51	2019.NULL	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saipan	INFINITI Q70	Y51	2019.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saipan	INFINITI Q70	Y51	2019.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saipan	INFINITI Q70	Y51	2019.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI Q70	Y51	2019.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI Q70	Y51	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Saipan	INFINITI Q70	Y51	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saipan	INFINITI Q70	Y51	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saipan	INFINITI Q70	Y51	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI Q70	Y51	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI Q70	Y51	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI Q70	Y51	2019.NULL	CAN gateway	√	√	√			
Saipan	INFINITI Q70	Y51	2019.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
Saipan	INFINITI Q70	Y51	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI Q70	Y51	2019.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Saipan	INFINITI Q70	Y51	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI Q70	Y51	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saipan	INFINITI Q70	Y51	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI Q70	Y51	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Saipan	INFINITI Q70	Y51	2019.NULL	ICC/ADAS 2	√	√	√	√		
Saipan	INFINITI Q70	Y51	2019.NULL	FSCM	√	√	√	√	AC1109	
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Laser/radar	√	√	√	√	AC0994	
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Air bag	√	√	√	√		
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	EPS/DAST 3	√	√	√	√		
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Motor control	√	√	√	√		
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	BCM				√	AC0613, AC0618, AC0653, AC0663, AC0690, AC0692, AC0698, AC0702	SP0372, SP0429, SP0471
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Pop up hood	√	√	√	√		
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	HV battery	√	√	√	√	AC1121	
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	CAN gateway	√	√	√			
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	Brake	√	√	√	√	AC1127	
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	6ch CAN GATEWAY	√	√	√	√		
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	ICC/ADAS 2	√	√	√	√		
Saipan	INFINITI Q70 HYBRID	HY51	2014.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Saipan	INFINITI QX30	H15	2019.NULL	Air pressure monitor	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	Air bag	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	EPS/DAST 3	√	√	√			
Saipan	INFINITI QX30	H15	2019.NULL	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Saipan	INFINITI QX30	H15	2019.NULL	Engine	√	√	√	√	AC0002, AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0103, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saipan	INFINITI QX30	H15	2019.NULL	EHS/PKB	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	Transmission	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Saipan	INFINITI QX30	H15	2019.NULL	ABS	√	√	√	√		SP0308
Saipan	INFINITI QX30	H15	2019.NULL	Multi AV	√	√	√	√		SP0501
Saipan	INFINITI QX30	H15	2019.NULL	HVAC	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	Auto drive position	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	Shift	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	All mode AWD/4WD	√	√	√	√		

Saipan	INFINITI QX30	H15	2019.NULL	AVM	√	√		√		
Saipan	INFINITI QX30	H15	2019.NULL	Intelligent key	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	CAN gateway	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	ANC	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	Telematics	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	FSCM	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	Siren control unit	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL –	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Saipan	INFINITI QX30	H15	2019.NULL –	Overhead Control Panel Unit	√			√		
Saipan	INFINITI QX30	H15	2019.NULL –	Universal Garage Door Opener	√			√		
Saipan	INFINITI QX30	H15	2019.NULL –	Upper control panel cont unit	√					
Saipan	INFINITI QX30	H15	2019.NULL –	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Saipan	INFINITI QX30	H15	2019.NULL –	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Saipan	INFINITI QX30	H15	2019.NULL	Light/Rain Sensor Module	√			√		
Saipan	INFINITI QX30	H15	2019.NULL	EC Mirror Compass	√					
Saipan	INFINITI QX30	H15	2019.NULL –	Intelligent Battery Sensor	√					
Saipan	INFINITI QX30	H15	2019.NULL	Alarm siren	√			√		
Saipan	INFINITI QX30	H15	2019.NULL	Radar sensor	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL –	Steering column cont module	√	√	√			
Saipan	INFINITI QX30	H15	2019.NULL	ICC sensor	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL –	Trailer recognition control unit	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	H/L control module LH	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	Powertrain cont module	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	Side radar LH	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	LED H/L control module LH	√			√		
Saipan	INFINITI QX30	H15	2019.NULL	Steering Wheel Switch Pad	√			√		
Saipan	INFINITI QX30	H15	2019.NULL	Parking assist	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL –	Occupant Classification Unit	√			√		
Saipan	INFINITI QX30	H15	2019.NULL –	Electronic Ignition Switch cont unit	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	H/L control module RH	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	Front camera unit	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	Side radar RH	√	√	√	√		
Saipan	INFINITI QX30	H15	2019.NULL	LED H/L control module RH	√			√		
Saipan	INFINITI QX4	JR50	1997.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saipan	INFINITI QX4	JR50	1997.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saipan	INFINITI QX4	JR50	1997.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saipan	INFINITI QX4	JR50	1997.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saipan	INFINITI QX4	JR50	1997.NULL	Air bag	√	√	√	√		
Saipan	INFINITI QX4	JR50	1997.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saipan	INFINITI QX4	JR50	1997.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saipan	INFINITI QX4	JR50	1997.NULL	Motor control						
Saipan	INFINITI QX4	JR50	1997.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saipan	INFINITI QX4	JR50	1997.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saipan	INFINITI QX4	JR50	1997.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saipan	INFINITI QX4	JR50	1997.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI QX4	JR50	1997.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI QX4	JR50	1997.NULL	HVAC	√	√	√	√		
Saipan	INFINITI QX4	JR50	1997.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI QX4	JR50	1997.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI QX4	JR50	1997.NULL	Auto slide door	√	√	√	√	AC0941	
Saipan	INFINITI QX4	JR50	1997.NULL	DIU		√	√	√		
Saipan	INFINITI QX4	JR50	1997.NULL	Adaptive light	√	√	√	√		
Saipan	INFINITI QX4	JR50	1997.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saipan	INFINITI QX4	JR50	1997.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saipan	INFINITI QX4	JR50	1997.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI QX4	JR50	1997.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saipan	INFINITI QX4	JR50	1997.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saipan	INFINITI QX4	JR50	1997.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI QX4	JR50	1997.NULL	IVMS	√	√		√		
Saipan	INFINITI QX4	JR50	1997.NULL	Distance control	√	√		√		
Saipan	INFINITI QX4	JR50	1997.NULL	Active suspense system	√	√	√	√		
Saipan	INFINITI QX4	JR50	1997.NULL	Motor assist		√	√	√		SP0574
Saipan	INFINITI QX4	JR50	1997.NULL	ASCD	√	√	√	√		
Saipan	INFINITI QX4	JR50	1997.NULL	Active engine mount	√	√	√	√		
Saipan	INFINITI QX4	JR50	1997.NULL	TCS	√	√	√	√		
Saipan	INFINITI QX4	JR50	1997.NULL	S/blind camera	√			√		SP0572, SP0573
Saipan	INFINITI QX4	JR50	1997.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saipan	INFINITI QX4	JR50	1997.NULL	Nats immu	√	√	√			
Saipan	INFINITI QX4	IR50	1997.NULL	Rearview camera	√			√		SP0570, SP0571
Saipan	INFINITI QX4	IR50	1997.NULL	Smart entrance						SP0568
Saipan	INFINITI QX50	I50	2014.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saipan	INFINITI QX50	J50	2014.NULL	Laser/radar	√	√	√	√	AC0994	
Saipan	INFINITI QX50	J50	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI QX50	J50	2014.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saipan	INFINITI QX50	J50	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saipan	INFINITI QX50	J50	2014.NULL	Air bag	√	√	√	√		
Saipan	INFINITI QX50	J50	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
Saipan	INFINITI QX50	J50	2014.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saipan	INFINITI QX50	J50	2014.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saipan	INFINITI QX50	J50	2014.NULL	Transmission	√	√	√	√		SP0274
Saipan	INFINITI QX50	I50	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saipan	INFINITI QX50	J50	2014.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI QX50	J50	2014.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI QX50	J50	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI QX50	J50	2014.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI QX50	I50	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saipan	INFINITI QX50	I50	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saipan	INFINITI QX50	I50	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Saipan	INFINITI QX50	I50	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI QX50	J50	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI QX50	J50	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI QX50	J50	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saipan	INFINITI QX50	J50	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Saipan	INFINITI QX50	J50	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI QX50	I50	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592

Saipan	INFINITI QX50	I50	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI QX50	I55	2019.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Saipan	INFINITI QX50	I55	2019.NULL	Laser/radar	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saipan	INFINITI QX50	J55	2019.NULL_	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Saipan	INFINITI QX50	J55	2019.NULL	Air bag	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL	EPS/DAST 3	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL	Meter/M&A	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saipan	INFINITI QX50	J55	2019.NULL	EHS/PKB	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL_	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Saipan	INFINITI QX50	J55	2019.NULL	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Saipan	INFINITI QX50	J55	2019.NULL	ABS	√	√	√	√		SP0313, SP0315
Saipan	INFINITI QX50	J55	2019.NULL	Total illum C/U	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI QX50	J55	2019.NULL	HVAC	√	√	√	√		
Saipan	INFINITI QX50	I55	2019.NULL	Auto drive position	√	√	√	√		
Saipan	INFINITI QX50	I55	2019.NULL	Auto back door	√	√	√	√		SP0611
Saipan	INFINITI QX50	I55	2019.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI QX50	I55	2019.NULL	Shift						
Saipan	INFINITI QX50	J55	2019.NULL	Adaptive light	√	√	√	√		SP0562
Saipan	INFINITI QX50	J55	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saipan	INFINITI QX50	J55	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saipan	INFINITI QX50	J55	2019.NULL	All mode AWD/4WD	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL	DAST 2	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI QX50	J55	2019.NULL	CAN gateway	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL	Lane camera	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL	DAST 1	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL	Chassis control	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL	ANC						
Saipan	INFINITI QX50	J55	2019.NULL	E-HUD	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI QX50	J55	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saipan	INFINITI QX50	J55	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI QX50	J55	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
Saipan	INFINITI QX50	J55	2019.NULL	ICC/ADAS 2	√	√	√	√		
Saipan	INFINITI QX56	IA60	2004.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saipan	INFINITI QX56	IA60	2004.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saipan	INFINITI QX56	IA60	2004.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saipan	INFINITI QX56	JA60	2004.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saipan	INFINITI QX56	JA60	2004.NULL	Air bag	√	√	√	√		
Saipan	INFINITI QX56	JA60	2004.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saipan	INFINITI QX56	JA60	2004.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saipan	INFINITI QX56	JA60	2004.NULL	Motor control						
Saipan	INFINITI QX56	JA60	2004.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saipan	INFINITI QX56	JA60	2004.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saipan	INFINITI QX56	JA60	2004.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saipan	INFINITI QX56	JA60	2004.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saipan	INFINITI QX56	JA60	2004.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI QX56	JA60	2004.NULL	HVAC	√	√	√	√		
Saipan	INFINITI QX56	JA60	2004.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI QX56	JA60	2004.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI QX56	JA60	2004.NULL	Auto slide door	√	√	√	√	AC0941	
Saipan	INFINITI QX56	JA60	2004.NULL	DIU		√	√	√		
Saipan	INFINITI QX56	JA60	2004.NULL	Adaptive light	√	√	√	√		
Saipan	INFINITI QX56	JA60	2004.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saipan	INFINITI QX56	JA60	2004.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saipan	INFINITI QX56	JA60	2004.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI QX56	JA60	2004.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saipan	INFINITI QX56	JA60	2004.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saipan	INFINITI QX56	IA60	2004.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI QX56	IA60	2004.NULL	IVMS	√	√		√		
Saipan	INFINITI QX56	IA60	2004.NULL	Distance control	√	√		√		
Saipan	INFINITI QX56	IA60	2004.NULL	Active suspense system	√	√	√	√		
Saipan	INFINITI QX56	JA60	2004.NULL	Motor assist		√	√	√		SP0574
Saipan	INFINITI QX56	JA60	2004.NULL	ASCD	√	√	√	√		
Saipan	INFINITI QX56	JA60	2004.NULL	Active engine mount	√	√	√	√		
Saipan	INFINITI QX56	JA60	2004.NULL	TCS	√	√	√	√		
Saipan	INFINITI QX56	JA60	2004.NULL	S/blind camera	√			√		SP0572, SP0573
Saipan	INFINITI QX56	JA60	2004.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saipan	INFINITI QX56	JA60	2004.NULL	Nats immu	√	√	√			
Saipan	INFINITI QX56	JA60	2004.NULL	Rearview camera	√			√		SP0570, SP0571
Saipan	INFINITI QX56	JA60	2004.NULL	Smart entrance						SP0568
Saipan	INFINITI QX56	Z62	2011.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saipan	INFINITI QX56	Z62	2011.NULL	Laser/radar	√	√	√	√		
Saipan	INFINITI QX56	Z62	2011.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI QX56	Z62	2011.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saipan	INFINITI QX56	Z62	2011.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saipan	INFINITI QX56	Z62	2011.NULL	Air bag	√	√	√	√		
Saipan	INFINITI QX56	Z62	2011.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Saipan	INFINITI QX56	Z62	2011.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saipan	INFINITI QX56	Z62	2011.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saipan	INFINITI QX56	Z62	2011.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saipan	INFINITI QX56	Z62	2011.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Saipan	INFINITI QX56	Z62	2011.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI QX56	Z62	2011.NULL_	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0476, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488, SP0489, SP0490
Saipan	INFINITI QX56	Z62	2011.NULL	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Saipan	INFINITI QX56	Z62	2011.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI QX56	Z62	2011.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI QX56	Z62	2011.NULL	Auto back door	√	√	√	√		
Saipan	INFINITI QX56	Z62	2011.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI QX56	Z62	2011.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Saipan	INFINITI QX56	Z62	2011.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saipan	INFINITI QX56	Z62	2011.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Saipan	INFINITI QX56	Z62	2011.NULL	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Saipan	INFINITI QX56	Z62	2011.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI QX56	Z62	2011.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567

Saipan	INFINITI QX56	Z62	2011.NULL	CAN gateway	√	√	√			
Saipan	INFINITI QX56	Z62	2011.NULL	Lane camera	√	√	√	√	AC0973.AC0974.AC0976.AC0977	
Saipan	INFINITI QX56	Z62	2011.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI QX56	Z62	2011.NULL	Telematics	√	√	√	√		SP0590.SP0591.SP0592
Saipan	INFINITI QX56	Z62	2011.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI QX56	Z62	2011.NULL	Rearview camera	√			√		SP0570,SP0571
Saipan	INFINITI QX60	L50	2019.2-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Saipan	INFINITI QX60	L50	2019.2-	Laser/radar	√	√	√	√	AC0994	
Saipan	INFINITI QX60	L50	2019.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI QX60	L50	2019.2-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Saipan	INFINITI QX60	L50	2019.2-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI QX60	L50	2019.2-	Air bag	√	√	√	√		
Saipan	INFINITI QX60	L50	2019.2-	EPS/DAST 3	√	√	√	√		
Saipan	INFINITI QX60	L50	2019.2-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Saipan	INFINITI QX60	L50	2019.2-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0009,SP0016,SP0032,SP0033,SP0038,SP0039,SP0053,SP0063,SP0064,SP0074,SP0079,SP0082,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Saipan	INFINITI QX60	L50	2019.2-	Transmission	√	√	√	√	AC0439	SP0246,SP0274,SP0275,SP0276,SP0278,SP0279,SP0281,SP0282,SP0283,SP0287,SP0288,SP0289,SP0290,SP0292
Saipan	INFINITI QX60	L50	2019.2-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Saipan	INFINITI QX60	L50	2019.2-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Saipan	INFINITI QX60	L50	2019.2-	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI QX60	L50	2019.2-	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0487
Saipan	INFINITI QX60	L50	2019.2-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI QX60	L50	2019.2-	Auto back door	√	√	√	√		SP0611
Saipan	INFINITI QX60	L50	2019.2-	Occupant detection			√	√		SP0584
Saipan	INFINITI QX60	L50	2019.2-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Saipan	INFINITI QX60	L50	2019.2-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Saipan	INFINITI QX60	L50	2019.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI QX60	L50	2019.2-	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI QX60	L50	2019.2-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Saipan	INFINITI QX60	L50	2019.2-	CAN gateway	√	√	√			
Saipan	INFINITI QX60	L50	2019.2-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0976,AC0977	
Saipan	INFINITI QX60	L50	2019.2-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Saipan	INFINITI QX60	L50	2019.2-	ANC	√	√	√	√	AC1024	
Saipan	INFINITI QX60	L50	2019.2-	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI QX60	L50	2019.2-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Saipan	INFINITI QX60	L50	2019.2-	HIGH BEAM ASSIST	√	√	√	√		
Saipan	INFINITI QX60	L50	2019.2-	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI QX60	L50	2019.2-	3ch CAN GATEWAY	√	√	√	√		
Saipan	INFINITI QX60	L50	2019.2-	ICC/ADAS 2	√	√	√	√		
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Laser/radar	√	√	√	√		
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Air bag	√	√	√	√		
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	EPS/DAST 3	√	√	√	√		
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Motor control	√	√	√	√		
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0038,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Transmission	√	√	√	√	AC0439	SP0246,SP0276,SP0279,SP0281,SP0282,SP0283,SP0287,SP0289,SP0290,SP0292
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0487
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	HV battery	√	√	√	√	AC1121	
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Auto back door	√	√	√	√		SP0611
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	EV/HEV	√	√	√	√	AC1081,AC1084,AC1085,AC1086,AC1087,AC1088,AC1089	
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	CAN gateway	√	√	√			
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0976,AC0977	
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	ANC	√	√	√	√		
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	HIGH BEAM ASSIST	√	√	√	√		
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	ICC/ADAS 2	√	√	√	√		
Saipan	INFINITI QX60 HYBRID	HL50	2014.NULL	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Saipan	INFINITI QX70	S51	2014.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Saipan	INFINITI QX70	S51	2014.NULL	Laser/radar	√	√	√	√	AC0994	
Saipan	INFINITI QX70	S51	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI QX70	S51	2014.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Saipan	INFINITI QX70	S51	2014.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI QX70	S51	2014.NULL	Air bag	√	√	√	√		
Saipan	INFINITI QX70	S51	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
Saipan	INFINITI QX70	S51	2014.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Saipan	INFINITI QX70	S51	2014.NULL	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Saipan	INFINITI QX70	S51	2014.NULL	Transmission	√	√	√	√		SP0274
Saipan	INFINITI QX70	S51	2014.NULL	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Saipan	INFINITI QX70	S51	2014.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Saipan	INFINITI QX70	S51	2014.NULL	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Saipan	INFINITI QX70	S51	2014.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI QX70	S51	2014.NULL	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Saipan	INFINITI QX70	S51	2014.NULL	4WAS(front)	√	√	√	√	AC1027,AC1028	
Saipan	INFINITI QX70	S51	2014.NULL	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Saipan	INFINITI QX70	S51	2014.NULL	Auto back door	√	√	√	√		SP0611
Saipan	INFINITI QX70	S51	2014.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI QX70	S51	2014.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Saipan	INFINITI QX70	S51	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Saipan	INFINITI QX70	S51	2014.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0555,SP0556,SP0557
Saipan	INFINITI QX70	S51	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
Saipan	INFINITI QX70	S51	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI QX70	S51	2014.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Saipan	INFINITI QX70	S51	2014.NULL	CAN gateway	√	√	√			
Saipan	INFINITI QX70	S51	2014.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Saipan	INFINITI QX70	S51	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saipan	INFINITI QX80	Z62	2019.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Saipan	INFINITI QX80	Z62	2019.NULL	Laser/radar	√	√	√	√	AC0994	
Saipan	INFINITI QX80	Z62	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saipan	INFINITI QX80	Z62	2019.NULL	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Saipan	INFINITI QX80	Z62	2019.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Saipan	INFINITI QX80	Z62	2019.NULL	Air bag	√	√	√	√		
Saipan	INFINITI QX80	Z62	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
Saipan	INFINITI QX80	Z62	2019.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350,SP0351

Saipan	INFINITI QX80	Z62	2019.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saipan	INFINITI QX80	Z62	2019.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saipan	INFINITI QX80	Z62	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saipan	INFINITI QX80	Z62	2019.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saipan	INFINITI QX80	Z62	2019.NULL	Multi AV	√	√	√	√		SP0503
Saipan	INFINITI QX80	Z62	2019.NULL_	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Saipan	INFINITI QX80	Z62	2019.NULL	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Saipan	INFINITI QX80	Z62	2019.NULL	Difference lock	√	√	√	√		
Saipan	INFINITI QX80	Z62	2019.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saipan	INFINITI QX80	Z62	2019.NULL	Auto back door	√	√	√	√		
Saipan	INFINITI QX80	Z62	2019.NULL	Occupant detection			√	√		SP0584
Saipan	INFINITI QX80	Z62	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Saipan	INFINITI QX80	Z62	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saipan	INFINITI QX80	Z62	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saipan	INFINITI QX80	Z62	2019.NULL	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Saipan	INFINITI QX80	Z62	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
Saipan	INFINITI QX80	Z62	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saipan	INFINITI QX80	Z62	2019.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saipan	INFINITI QX80	Z62	2019.NULL	CAN gateway	√	√	√			
Saipan	INFINITI QX80	Z62	2019.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Saipan	INFINITI QX80	Z62	2019.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Saipan	INFINITI QX80	Z62	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
Saipan	INFINITI QX80	Z62	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saipan	INFINITI QX80	Z62	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
Saipan	INFINITI QX80	Z62	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
Saipan	INFINITI QX80	Z62	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
Saipan	INFINITI QX80	Z62	2019.NULL	ICC/ADAS 2	√	√	√	√		
Saipan	INFINITI QX80	Z62	2019.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saudi arabia	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saudi arabia	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Saudi arabia	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saudi arabia	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saudi arabia	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saudi arabia	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saudi arabia	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saudi arabia	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saudi arabia	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saudi arabia	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	

Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Saudi arabia	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

XTOOL

Saudi arabia	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Saudi arabia	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Saudi arabia	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	

Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Saudi arabia	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Saudi arabia	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Saudi arabia	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saudi arabia	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saudi arabia	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Saudi arabia	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saudi arabia	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Saudi arabia	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Saudi arabia	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Saudi arabia	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319

XTOOL

Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saudi arabia	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Saudi arabia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Saudi arabia	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Saudi arabia	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saudi arabia	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Saudi arabia	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Saudi arabia	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saudi arabia	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Saudi arabia	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saudi arabia	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saudi arabia	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Saudi arabia	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Saudi arabia	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Saudi arabia	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Saudi arabia	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Saudi arabia	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567

Saudi arabia	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Saudi arabia	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saudi arabia	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Saudi arabia	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Saudi arabia	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Saudi arabia	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Saudi arabia	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Saudi arabia	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501

Saudi arabia	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Saudi arabia	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Saudi arabia	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Saudi arabia	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Saudi arabia	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Saudi arabia	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Saudi arabia	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Saudi arabia	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Saudi arabia	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Saudi arabia	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622

XTOOL

Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Saudi arabia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Saudi arabia	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saudi arabia	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saudi arabia	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saudi arabia	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saudi arabia	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Saudi arabia	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saudi arabia	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saudi arabia	INFINITI Q45	F50	2001.8-	Motor control						
Saudi arabia	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saudi arabia	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saudi arabia	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Saudi arabia	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Saudi arabia	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Saudi arabia	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Saudi arabia	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Saudi arabia	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saudi arabia	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saudi arabia	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saudi arabia	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Saudi arabia	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Saudi arabia	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Saudi arabia	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Saudi arabia	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Saudi arabia	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Saudi arabia	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Saudi arabia	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Saudi arabia	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saudi arabia	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Saudi arabia	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Saudi arabia	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Saudi arabia	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saudi arabia	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Saudi arabia	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Saudi arabia	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

Saudi arabia	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Saudi arabia	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Saudi arabia	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saudi arabia	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Saudi arabia	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saudi arabia	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saudi arabia	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Saudi arabia	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saudi arabia	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saudi arabia	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saudi arabia	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Saudi arabia	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Saudi arabia	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Saudi arabia	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Saudi arabia	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Saudi arabia	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Saudi arabia	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Saudi arabia	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Saudi arabia	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Saudi arabia	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Saudi arabia	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Saudi arabia	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Saudi arabia	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Saudi arabia	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saudi arabia	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Saudi arabia	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Saudi arabia	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Saudi arabia	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Saudi arabia	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Saudi arabia	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Saudi arabia	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Saudi arabia	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Saudi arabia	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503

Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Saudi arabia	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		

Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Saudi arabia	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Saudi arabia	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Saudi arabia	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Saudi arabia	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Saudi arabia	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Saudi arabia	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Saudi arabia	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saudi arabia	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Saudi arabia	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saudi arabia	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saudi arabia	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Saudi arabia	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saudi arabia	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saudi arabia	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Saudi arabia	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Saudi arabia	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Saudi arabia	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Saudi arabia	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Saudi arabia	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Saudi arabia	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Saudi arabia	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Saudi arabia	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Saudi arabia	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Saudi arabia	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Saudi arabia	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saudi arabia	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Saudi arabia	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Saudi arabia	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Saudi arabia	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Saudi arabia	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		

Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saudi arabia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Saudi arabia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Saudi arabia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Saudi arabia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Saudi arabia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saudi arabia	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Saudi arabia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saudi arabia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Saudi arabia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saudi arabia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Saudi arabia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Saudi arabia	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Saudi arabia	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saudi arabia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saudi arabia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Saudi arabia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Saudi arabia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Saudi arabia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Saudi arabia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612

XTOOL

Saudi arabia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Saudi arabia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saudi arabia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Saudi arabia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Saudi arabia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Saudi arabia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saudi arabia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Saudi arabia	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Saudi arabia	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Saudi arabia	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Saudi arabia	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Saudi arabia	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Saudi arabia	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Saudi arabia	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Saudi arabia	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Saudi arabia	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Saudi arabia	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saudi arabia	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saudi arabia	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Saudi arabia	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saudi arabia	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Saudi arabia	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saudi arabia	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Saudi arabia	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Saudi arabia	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Saudi arabia	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Saudi arabia	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saudi arabia	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Saudi arabia	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saudi arabia	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Saudi arabia	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Saudi arabia	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Saudi arabia	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Saudi arabia	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Saudi arabia	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Saudi arabia	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584

Saudi arabia	INFINITI QX50	J55	2018.5-	Shift						
Saudi arabia	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Saudi arabia	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	ANC						
Saudi arabia	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saudi arabia	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Saudi arabia	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Saudi arabia	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saudi arabia	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Saudi arabia	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Saudi arabia	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Saudi arabia	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Saudi arabia	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Saudi arabia	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Saudi arabia	INFINITI QX56	JA60	2004.10-	Motor control						
Saudi arabia	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Saudi arabia	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Saudi arabia	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Saudi arabia	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Saudi arabia	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Saudi arabia	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Saudi arabia	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Saudi arabia	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Saudi arabia	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Saudi arabia	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Saudi arabia	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Saudi arabia	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Saudi arabia	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Saudi arabia	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Saudi arabia	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Saudi arabia	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Saudi arabia	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Saudi arabia	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Saudi arabia	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Saudi arabia	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Saudi arabia	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Saudi arabia	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Saudi arabia	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Saudi arabia	INFINITI QX56	Z62	2010.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Saudi arabia	INFINITI QX56	Z62	2010.3-	Laser/radar	√	√	√	√		
Saudi arabia	INFINITI QX56	Z62	2010.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI QX56	Z62	2010.3-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Saudi arabia	INFINITI QX56	Z62	2010.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI QX56	Z62	2010.3-	Air bag	√	√	√	√		
Saudi arabia	INFINITI QX56	Z62	2010.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Saudi arabia	INFINITI QX56	Z62	2010.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI QX56	Z62	2010.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saudi arabia	INFINITI QX56	Z62	2010.3-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saudi arabia	INFINITI QX56	Z62	2010.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saudi arabia	INFINITI QX56	Z62	2010.3-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI QX56	Z62	2010.3-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Saudi arabia	INFINITI QX56	Z62	2010.3-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Saudi arabia	INFINITI QX56	Z62	2010.3-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI QX56	Z62	2010.3-	Auto back door	√	√	√	√		
Saudi arabia	INFINITI QX56	Z62	2010.3-	Occupant detection			√	√		SP0584
Saudi arabia	INFINITI QX56	Z62	2010.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saudi arabia	INFINITI QX56	Z62	2010.3-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI QX56	Z62	2010.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI QX56	Z62	2010.3-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Saudi arabia	INFINITI QX56	Z62	2010.3-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI QX56	Z62	2010.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI QX56	Z62	2010.3-	CAN gateway	√	√	√			
Saudi arabia	INFINITI QX56	Z62	2010.3-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Saudi arabia	INFINITI QX56	Z62	2010.3-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI QX56	Z62	2010.3-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saudi arabia	INFINITI QX56	Z62	2010.3-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI QX56	Z62	2010.3-	Rearview camera	√			√		SP0570, SP0571
Saudi arabia	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Saudi arabia	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Saudi arabia	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Saudi arabia	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Saudi arabia	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Saudi arabia	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saudi arabia	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Saudi arabia	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Saudi arabia	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saudi arabia	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saudi arabia	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Saudi arabia	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Saudi arabia	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Saudi arabia	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Saudi arabia	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Saudi arabia	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Saudi arabia	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Saudi arabia	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Saudi arabia	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Saudi arabia	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Saudi arabia	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Saudi arabia	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saudi arabia	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Saudi arabia	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Saudi arabia	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Saudi arabia	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Saudi arabia	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Saudi arabia	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Saudi arabia	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saudi arabia	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Saudi arabia	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Saudi arabia	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Saudi arabia	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Saudi arabia	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Saudi arabia	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Saudi arabia	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Saudi arabia	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Saudi arabia	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Saudi arabia	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Saudi arabia	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Saudi arabia	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saudi arabia	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Saudi arabia	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Saudi arabia	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Saudi arabia	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Saudi arabia	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Saudi arabia	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Saudi arabia	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Saudi arabia	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Saudi arabia	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Saudi arabia	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Saudi arabia	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saudi arabia	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Saudi arabia	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Saudi arabia	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Saudi arabia	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Saudi arabia	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Saudi arabia	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Saudi arabia	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Saudi arabia	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Saudi arabia	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Saudi arabia	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Saudi arabia	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Saudi arabia	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Saudi arabia	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Saudi arabia	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Saudi arabia	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Saudi arabia	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Saudi arabia	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Saudi arabia	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Saudi arabia	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Saudi arabia	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Saudi arabia	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Saudi arabia	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Saudi arabia	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Saudi arabia	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Saudi arabia	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Saudi arabia	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Saudi arabia	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Saudi arabia	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Saudi arabia	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Saudi arabia	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Saudi arabia	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Saudi arabia	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Saudi arabia	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Saudi arabia	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Saudi arabia	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Saudi arabia	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Saudi arabia	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Saudi arabia	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Saudi arabia	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Senegal	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Senegal	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Senegal	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Senegal	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Senegal	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Senegal	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Senegal	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Senegal	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Senegal	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Senegal	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Senegal	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Senegal	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Senegal	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Senegal	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Senegal	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Senegal	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Senegal	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494

Senegal	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Senegal	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Senegal	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Senegal	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Senegal	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Senegal	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Senegal	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Senegal	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Senegal	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Senegal	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Senegal	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Senegal	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Senegal	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Senegal	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Senegal	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Senegal	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Senegal	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Senegal	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Senegal	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Senegal	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Senegal	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Senegal	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Senegal	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Senegal	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Senegal	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Senegal	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Senegal	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Senegal	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Senegal	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503

Senegal	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Senegal	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Senegal	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Senegal	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Senegal	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Senegal	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Senegal	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Senegal	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Senegal	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Senegal	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Senegal	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Senegal	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Senegal	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Senegal	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Senegal	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Senegal	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Senegal	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Senegal	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Senegal	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Senegal	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Senegal	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Senegal	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Senegal	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Senegal	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Senegal	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Senegal	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Senegal	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Senegal	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Senegal	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Senegal	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Senegal	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Senegal	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Senegal	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Senegal	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Senegal	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Senegal	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Senegal	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Senegal	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Senegal	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Senegal	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Senegal	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Senegal	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Senegal	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Senegal	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Senegal	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Senegal	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Senegal	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Senegal	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Senegal	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Senegal	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Senegal	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Senegal	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Senegal	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Senegal	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Senegal	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Senegal	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Senegal	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Senegal	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Senegal	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Senegal	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Senegal	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Senegal	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315

Senegal	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Senegal	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Senegal	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Senegal	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Senegal	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Senegal	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Senegal	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Senegal	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Senegal	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Senegal	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Senegal	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Senegal	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Senegal	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Senegal	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Senegal	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Senegal	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Senegal	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Senegal	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Senegal	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Senegal	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Senegal	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Senegal	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Senegal	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Senegal	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Senegal	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Senegal	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Senegal	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Senegal	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Senegal	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Senegal	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Senegal	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Senegal	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Senegal	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Senegal	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Senegal	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Senegal	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Senegal	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Senegal	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Senegal	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Senegal	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Senegal	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Senegal	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Senegal	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Senegal	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Senegal	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Senegal	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Senegal	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Senegal	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Senegal	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Senegal	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Senegal	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Senegal	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Senegal	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Senegal	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Senegal	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Senegal	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Senegal	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Senegal	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Senegal	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Senegal	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		

Senegal	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Senegal	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Senegal	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Senegal	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Senegal	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Senegal	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Senegal	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Senegal	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Senegal	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Senegal	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Senegal	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Senegal	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Senegal	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Senegal	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Senegal	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Senegal	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Senegal	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Senegal	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Senegal	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Senegal	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Senegal	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Senegal	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Senegal	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Senegal	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Senegal	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Senegal	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Senegal	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Senegal	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Senegal	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Senegal	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Senegal	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Senegal	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Senegal	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Senegal	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Senegal	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Senegal	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Senegal	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Senegal	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Senegal	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Senegal	INFINITI QX50	I50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Senegal	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Senegal	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI QX50	I50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Senegal	INFINITI QX50	I50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Senegal	INFINITI QX50	I50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Senegal	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Senegal	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Senegal	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Senegal	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Senegal	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Senegal	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Senegal	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Senegal	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Senegal	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Senegal	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Senegal	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Senegal	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Senegal	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Senegal	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Senegal	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Senegal	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Senegal	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Senegal	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Senegal	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Senegal	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Senegal	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Senegal	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Senegal	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Senegal	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Senegal	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Senegal	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Senegal	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Senegal	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Senegal	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Senegal	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Senegal	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Senegal	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Senegal	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Senegal	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Senegal	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Senegal	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Senegal	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Senegal	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Senegal	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Senegal	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Senegal	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Senegal	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Senegal	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Senegal	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Senegal	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Senegal	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Senegal	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Senegal	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Senegal	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Senegal	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Senegal	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Senegal	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Senegal	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Senegal	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Senegal	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Senegal	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Senegal	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Senegal	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Senegal	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Senegal	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Senegal	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Senegal	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Senegal	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Senegal	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Senegal	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Senegal	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Senegal	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Senegal	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Senegal	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Senegal	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Senegal	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Senegal	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Senegal	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Serbia	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Serbia	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Serbia	INFINITI EX35/EX30D	I50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI EX35/EX30D	I50	2009.7-	Air bag	√	√	√	√		
Serbia	INFINITI EX35/EX30D	I50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

XTOOL

Serbia	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Serbia	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Serbia	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Serbia	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Serbia	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Serbia	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Serbia	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Serbia	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Serbia	INFINITI EX35/EX30D	I50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Serbia	INFINITI EX35/EX30D	I50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Serbia	INFINITI EX35/EX30D	I50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Serbia	INFINITI EX35/EX30D	I50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Serbia	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Serbia	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Serbia	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Serbia	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Serbia	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Serbia	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Serbia	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Serbia	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Serbia	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Serbia	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Serbia	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Serbia	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Serbia	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Serbia	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Serbia	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Serbia	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Serbia	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Serbia	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Serbia	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Serbia	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Serbia	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Serbia	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Serbia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Serbia	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Serbia	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Serbia	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Serbia	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Serbia	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Serbia	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Serbia	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Serbia	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Serbia	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Serbia	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553. SP0554. SP0555. SP0556
Serbia	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Serbia	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Serbia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Serbia	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Serbia	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Serbia	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Serbia	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Serbia	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Serbia	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Serbia	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Serbia	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Serbia	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Serbia	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Serbia	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553. SP0554. SP0555. SP0556
Serbia	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956. AC0957	
Serbia	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Serbia	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Serbia	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Serbia	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Serbia	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Serbia	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Serbia	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Serbia	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Serbia	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Serbia	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Serbia	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Serbia	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Serbia	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Serbia	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Serbia	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Serbia	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570. SP0571
Serbia	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Serbia	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		

Serbia	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Serbia	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Serbia	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Serbia	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Serbia	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Serbia	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Serbia	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Serbia	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Serbia	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Serbia	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Serbia	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Serbia	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Serbia	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Serbia	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Serbia	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Serbia	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Serbia	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Serbia	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Serbia	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Serbia	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Serbia	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Serbia	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Serbia	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Serbia	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Serbia	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Serbia	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Serbia	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Serbia	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Serbia	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Serbia	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Serbia	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Serbia	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Serbia	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		

Serbia	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Serbia	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Serbia	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Serbia	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Serbia	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Serbia	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Serbia	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Serbia	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Serbia	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Serbia	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Serbia	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Serbia	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Serbia	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Serbia	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Serbia	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Serbia	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Serbia	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Serbia	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Serbia	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Serbia	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Serbia	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Serbia	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Serbia	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Serbia	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Serbia	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Serbia	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Serbia	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Serbia	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Serbia	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Serbia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Serbia	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Serbia	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Serbia	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Serbia	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Serbia	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Serbia	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Serbia	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Serbia	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Serbia	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Serbia	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Serbia	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Serbia	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Serbia	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Serbia	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Serbia	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Serbia	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Serbia	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Serbia	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Serbia	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562

XTOOL

Serbia	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Serbia	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Serbia	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Serbia	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Serbia	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Serbia	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Serbia	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Serbia	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Serbia	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Serbia	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Serbia	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604,SP0605,SP0606
Serbia	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Serbia	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Serbia	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Serbia	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Serbia	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Serbia	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Serbia	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Serbia	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Serbia	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Serbia	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Serbia	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Serbia	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Serbia	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Serbia	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Serbia	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0311,AC0314,AC0315,AC0320,AC0325,AC0327,AC0330,AC0331,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247,SP0265,SP0274,SP0276
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Serbia	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0009,SP0016,SP0032,SP0033,SP0038,SP0039,SP0053,SP0063,SP0064,SP0074,SP0079,SP0082,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		

Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Serbia	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Serbia	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Serbia	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Serbia	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Serbia	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Serbia	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Serbia	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Serbia	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Serbia	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Serbia	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Serbia	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Serbia	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Serbia	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Serbia	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Serbia	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980. AC0981. AC0982	SP0561. SP0562
Serbia	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
Serbia	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962. AC0963. AC0964. AC0966. AC0967. AC0968. AC0969. AC0970	SP0553. SP0554. SP0555. SP0556. SP0557. SP0558. SP0559
Serbia	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Serbia	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Serbia	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Serbia	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Serbia	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Serbia	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Serbia	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Serbia	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Serbia	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Serbia	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Serbia	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Serbia	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Serbia	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Serbia	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Serbia	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Serbia	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Serbia	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Serbia	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Serbia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613. AC0618. AC0663. AC0692. AC0702. AC0719	SP0372. SP0429
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980	SP0561. SP0562
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Serbia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Serbia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Serbia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Serbia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Serbia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Serbia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Serbia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Serbia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Serbia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Serbia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Serbia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Serbia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Serbia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Serbia	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Serbia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Serbia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Serbia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Serbia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Serbia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Serbia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Serbia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Serbia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Serbia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Serbia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Serbia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Serbia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Serbia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Serbia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Serbia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Serbia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Serbia	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Serbia	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Serbia	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Serbia	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Serbia	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Serbia	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Serbia	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Serbia	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Serbia	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Serbia	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Serbia	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Serbia	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Serbia	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Serbia	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Serbia	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319

Serbia	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Serbia	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Serbia	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Serbia	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Serbia	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Serbia	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Serbia	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Serbia	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Serbia	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Serbia	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Serbia	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Serbia	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Serbia	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Serbia	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Serbia	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Serbia	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Serbia	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Serbia	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Serbia	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Serbia	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Serbia	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Serbia	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Serbia	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Serbia	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Serbia	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Serbia	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Serbia	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Serbia	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Serbia	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Serbia	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Serbia	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Serbia	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Serbia	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Serbia	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Serbia	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Serbia	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Serbia	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Serbia	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Serbia	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Serbia	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Serbia	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Serbia	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Serbia	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Serbia	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Serbia	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Serbia	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Serbia	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Serbia	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Serbia	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Serbia	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Serbia	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Serbia	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Serbia	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Serbia	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Serbia	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Serbia	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Serbia	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Serbia	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Serbia	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Serbia	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Seychelle island	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510

Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Seychelle island	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Seychelle island	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Seychelle island	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		

Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Seychelle island	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Seychelle island	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Seychelle island	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Seychelle island	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Seychelle island	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Seychelle island	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Seychelle island	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Seychelle island	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Seychelle island	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Seychelle island	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Seychelle island	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Seychelle island	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Seychelle island	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Seychelle island	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Seychelle island	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Seychelle island	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Seychelle island	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Seychelle island	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		

Seychelle island	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Seychelle island	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Seychelle island	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Seychelle island	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Seychelle island	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Seychelle island	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Seychelle island	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Seychelle island	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Seychelle island	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Seychelle island	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Seychelle island	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Seychelle island	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Seychelle island	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Seychelle island	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Seychelle island	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Seychelle island	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Seychelle island	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Seychelle island	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Seychelle island	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Seychelle island	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Seychelle island	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Seychelle island	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Seychelle island	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Seychelle island	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Seychelle island	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Seychelle island	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Seychelle island	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Seychelle island	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Seychelle island	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Seychelle island	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Seychelle island	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Seychelle island	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Seychelle island	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Seychelle island	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Seychelle island	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Seychelle island	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Seychelle island	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Seychelle island	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Seychelle island	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Seychelle island	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Seychelle island	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Seychelle island	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Seychelle island	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606

XTOOL

Seychelle island	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Seychelle island	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Seychelle island	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Seychelle island	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Seychelle island	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Seychelle island	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Seychelle island	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Seychelle island	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Seychelle island	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection		√	√	√		SP0584
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Seychelle island	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Seychelle island	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Seychelle island	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Seychelle island	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Seychelle island	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Seychelle island	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Seychelle island	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

XTOOL

Seychelle island	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Seychelle island	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Seychelle island	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Seychelle island	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Seychelle island	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Seychelle island	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Seychelle island	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Seychelle island	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Seychelle island	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Seychelle island	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Seychelle island	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Seychelle island	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Seychelle island	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Seychelle island	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Seychelle island	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Seychelle island	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Seychelle island	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Seychelle island	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Seychelle island	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Seychelle island	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Seychelle island	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Seychelle island	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Seychelle island	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Seychelle island	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Seychelle island	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Seychelle island	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Seychelle island	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Seychelle island	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Seychelle island	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Seychelle island	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507

Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Seychelle island	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Seychelle island	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Seychelle island	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Seychelle island	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Seychelle island	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Seychelle island	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Seychelle island	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Seychelle island	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Seychelle island	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Seychelle island	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Seychelle island	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Seychelle island	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Seychelle island	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Seychelle island	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Seychelle island	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Seychelle island	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Seychelle island	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Seychelle island	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Seychelle island	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Seychelle island	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Seychelle island	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Seychelle island	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Seychelle island	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Seychelle island	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Seychelle island	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Seychelle island	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Seychelle island	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Seychelle island	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Seychelle island	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Seychelle island	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Seychelle island	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Seychelle island	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Seychelle island	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Seychelle island	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Seychelle island	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Seychelle island	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Seychelle island	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Seychelle island	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Seychelle island	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Seychelle island	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Seychelle island	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Seychelle island	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Seychelle island	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Seychelle island	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Seychelle island	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Seychelle island	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Seychelle island	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Seychelle island	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Seychelle island	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Seychelle island	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Seychelle island	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Seychelle island	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Seychelle island	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Seychelle island	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Seychelle island	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Seychelle island	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Seychelle island	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Seychelle island	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Seychelle island	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Seychelle island	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Seychelle island	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Seychelle island	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Seychelle island	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Seychelle island	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Seychelle island	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Seychelle island	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Seychelle island	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Seychelle island	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Seychelle island	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Seychelle island	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Seychelle island	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Seychelle island	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Seychelle island	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Seychelle island	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Seychelle island	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Seychelle island	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Seychelle island	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Seychelle island	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Seychelle island	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Seychelle island	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Seychelle island	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Seychelle island	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Seychelle island	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Seychelle island	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Seychelle island	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Seychelle island	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Seychelle island	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Seychelle island	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Seychelle island	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Seychelle island	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Seychelle island	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Seychelle island	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Seychelle island	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Seychelle island	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Seychelle island	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Seychelle island	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Seychelle island	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Seychelle island	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Seychelle island	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Seychelle island	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Seychelle island	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Seychelle island	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Seychelle island	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Seychelle island	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Seychelle island	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Seychelle island	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Seychelle island	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Seychelle island	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Seychelle island	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Seychelle island	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Seychelle island	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Seychelle island	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Seychelle island	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Seychelle island	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Sierra leone	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315

Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sierra leone	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Sierra leone	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Sierra leone	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319

Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Sierra leone	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Sierra leone	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Sierra leone	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Sierra leone	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Sierra leone	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Sierra leone	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Sierra leone	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sierra leone	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Sierra leone	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Sierra leone	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Sierra leone	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Sierra leone	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Sierra leone	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Sierra leone	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Sierra leone	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Sierra leone	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Sierra leone	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Sierra leone	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Sierra leone	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Sierra leone	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Sierra leone	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Sierra leone	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Sierra leone	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Sierra leone	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622

XTOOL

Sierra leone	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Sierra leone	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Sierra leone	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Sierra leone	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Sierra leone	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Sierra leone	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Sierra leone	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Sierra leone	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Sierra leone	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Sierra leone	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Sierra leone	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Sierra leone	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Sierra leone	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Sierra leone	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Sierra leone	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Sierra leone	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Sierra leone	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sierra leone	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Sierra leone	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Sierra leone	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Sierra leone	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Sierra leone	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Sierra leone	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Sierra leone	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Sierra leone	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Sierra leone	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sierra leone	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Sierra leone	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Sierra leone	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Sierra leone	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Sierra leone	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Sierra leone	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Sierra leone	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Sierra leone	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sierra leone	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Sierra leone	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Sierra leone	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Sierra leone	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Sierra leone	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Sierra leone	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Sierra leone	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Sierra leone	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Sierra leone	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Sierra leone	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Sierra leone	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497

Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Sierra leone	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Sierra leone	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Sierra leone	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Sierra leone	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Sierra leone	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Sierra leone	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Sierra leone	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Sierra leone	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sierra leone	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Sierra leone	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Sierra leone	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Sierra leone	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Sierra leone	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Sierra leone	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Sierra leone	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Sierra leone	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Sierra leone	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sierra leone	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Sierra leone	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	

Sierra leone	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Sierra leone	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Sierra leone	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Sierra leone	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Sierra leone	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Sierra leone	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sierra leone	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Sierra leone	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Sierra leone	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Sierra leone	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Sierra leone	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Sierra leone	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Sierra leone	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Sierra leone	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Sierra leone	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Sierra leone	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Sierra leone	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Sierra leone	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Sierra leone	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sierra leone	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Sierra leone	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Sierra leone	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Sierra leone	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Sierra leone	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Sierra leone	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Sierra leone	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Sierra leone	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Sierra leone	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Sierra leone	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Sierra leone	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Sierra leone	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Sierra leone	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Sierra leone	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Sierra leone	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Sierra leone	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sierra leone	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Sierra leone	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Sierra leone	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Sierra leone	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Sierra leone	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Sierra leone	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Sierra leone	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sierra leone	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Sierra leone	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Sierra leone	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Sierra leone	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Sierra leone	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Sierra leone	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Sierra leone	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Sierra leone	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Sierra leone	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Sierra leone	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sierra leone	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Sierra leone	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Sierra leone	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sierra leone	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Sierra leone	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sierra leone	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sierra leone	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Sierra leone	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Sierra leone	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Sierra leone	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Sierra leone	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Sierra leone	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Sierra leone	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Sierra leone	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Sierra leone	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Sierra leone	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Sierra leone	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510

XTOOL

Sierra leone	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Sierra leone	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Sierra leone	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Sierra leone	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Sierra leone	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sierra leone	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Sierra leone	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Sierra leone	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sierra leone	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Sierra leone	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Sierra leone	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Sierra leone	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Sierra leone	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Sierra leone	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Sierra leone	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sierra leone	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sierra leone	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Sierra leone	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Sierra leone	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Sierra leone	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Sierra leone	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Sierra leone	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Sierra leone	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sierra leone	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Sierra leone	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Sierra leone	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Sierra leone	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Sierra leone	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Sierra leone	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Sierra leone	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Sierra leone	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Sierra leone	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sierra leone	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Sierra leone	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sierra leone	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Sierra leone	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Sierra leone	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sierra leone	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Sierra leone	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Sierra leone	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Sierra leone	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Sierra leone	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Sierra leone	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Sierra leone	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Sierra leone	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sierra leone	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Sierra leone	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Sierra leone	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Sierra leone	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sierra leone	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Sierra leone	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Sierra leone	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Sierra leone	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Sierra leone	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Sierra leone	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Sierra leone	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Sierra leone	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582

XTOOL

Sierra leone	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Sierra leone	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Sierra leone	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Sierra leone	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Sierra leone	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Sierra leone	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Singapore	INFINITI FX35/FX50	S51	2011.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Singapore	INFINITI FX35/FX50	S51	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI FX35/FX50	S51	2011.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Singapore	INFINITI FX35/FX50	S51	2011.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Singapore	INFINITI FX35/FX50	S51	2011.7-	Air bag	√	√	√	√		
Singapore	INFINITI FX35/FX50	S51	2011.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Singapore	INFINITI FX35/FX50	S51	2011.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Singapore	INFINITI FX35/FX50	S51	2011.7-	Transmission	√	√	√	√		SP0274
Singapore	INFINITI FX35/FX50	S51	2011.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Singapore	INFINITI FX35/FX50	S51	2011.7-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Singapore	INFINITI FX35/FX50	S51	2011.7-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Singapore	INFINITI FX35/FX50	S51	2011.7-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI FX35/FX50	S51	2011.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Singapore	INFINITI FX35/FX50	S51	2011.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Singapore	INFINITI FX35/FX50	S51	2011.7-	Auto back door	√	√	√	√		SP0611
Singapore	INFINITI FX35/FX50	S51	2011.7-	Occupant detection			√	√		SP0584
Singapore	INFINITI FX35/FX50	S51	2011.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Singapore	INFINITI FX35/FX50	S51	2011.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Singapore	INFINITI FX35/FX50	S51	2011.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0556,SP0557
Singapore	INFINITI FX35/FX50	S51	2011.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Singapore	INFINITI FX35/FX50	S51	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Singapore	INFINITI FX35/FX50	S51	2011.7-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Singapore	INFINITI FX35/FX50	S51	2011.7-	CAN gateway	√	√	√			
Singapore	INFINITI FX35/FX50	S51	2011.7-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Singapore	INFINITI FX35/FX50	S51	2011.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Singapore	INFINITI FX35/FX50	S51	2011.7-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0200,SP0202,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270,SP0274
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Singapore	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Singapore	INFINITI M25/M37	Y51	2011.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Singapore	INFINITI M25/M37	Y51	2011.7-	Laser/radar	√	√	√	√		
Singapore	INFINITI M25/M37	Y51	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI M25/M37	Y51	2011.7-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Singapore	INFINITI M25/M37	Y51	2011.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Singapore	INFINITI M25/M37	Y51	2011.7-	Air bag	√	√	√	√		
Singapore	INFINITI M25/M37	Y51	2011.7-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Singapore	INFINITI M25/M37	Y51	2011.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Singapore	INFINITI M25/M37	Y51	2011.7-	Transmission	√	√	√	√		SP0274
Singapore	INFINITI M25/M37	Y51	2011.7-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Singapore	INFINITI M25/M37	Y51	2011.7-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0313,SP0315
Singapore	INFINITI M25/M37	Y51	2011.7-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI M25/M37	Y51	2011.7-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Singapore	INFINITI M25/M37	Y51	2011.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Singapore	INFINITI M25/M37	Y51	2011.7-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Singapore	INFINITI M25/M37	Y51	2011.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Singapore	INFINITI M25/M37	Y51	2011.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Singapore	INFINITI M25/M37	Y51	2011.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Singapore	INFINITI M25/M37	Y51	2011.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Singapore	INFINITI M25/M37	Y51	2011.7-	CAN gateway	√	√	√			
Singapore	INFINITI M25/M37	Y51	2011.7-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Singapore	INFINITI M25/M37	Y51	2011.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Singapore	INFINITI M25/M37	Y51	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Singapore	INFINITI M25/M37	Y51	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Singapore	INFINITI M35H	HY51	2012.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Singapore	INFINITI M35H	HY51	2012.1-	Laser/radar	√	√	√	√		
Singapore	INFINITI M35H	HY51	2012.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI M35H	HY51	2012.1-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Singapore	INFINITI M35H	HY51	2012.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Singapore	INFINITI M35H	HY51	2012.1-	Air bag	√	√	√	√		
Singapore	INFINITI M35H	HY51	2012.1-	EPS/DAST 3	√	√	√	√		
Singapore	INFINITI M35H	HY51	2012.1-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Singapore	INFINITI M35H	HY51	2012.1-	Motor control	√	√	√	√		

Singapore	INFINITI M35H	HY51	2012.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Singapore	INFINITI M35H	HY51	2012.1-	Transmission	√	√	√	√		SP0274, SP0276
Singapore	INFINITI M35H	HY51	2012.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Singapore	INFINITI M35H	HY51	2012.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Singapore	INFINITI M35H	HY51	2012.1-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI M35H	HY51	2012.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Singapore	INFINITI M35H	HY51	2012.1-	HV battery	√	√	√	√	AC1121	
Singapore	INFINITI M35H	HY51	2012.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Singapore	INFINITI M35H	HY51	2012.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Singapore	INFINITI M35H	HY51	2012.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Singapore	INFINITI M35H	HY51	2012.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Singapore	INFINITI M35H	HY51	2012.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Singapore	INFINITI M35H	HY51	2012.1-	Precrash seatbelt	√	√	√	√		SP0612
Singapore	INFINITI M35H	HY51	2012.1-	CAN gateway	√	√	√			
Singapore	INFINITI M35H	HY51	2012.1-	Brake	√	√	√	√	AC1127	
Singapore	INFINITI M35H	HY51	2012.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Singapore	INFINITI Q30	H15	2016.1-	Air pressure monitor	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	Air bag	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	EPS/DAST 3	√	√	√			
Singapore	INFINITI Q30	H15	2016.1-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Singapore	INFINITI Q30	H15	2016.1-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Singapore	INFINITI Q30	H15	2016.1-	EHS/PKB	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	Transmission	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Singapore	INFINITI Q30	H15	2016.1-	ABS	√	√	√	√		SP0308
Singapore	INFINITI Q30	H15	2016.1-	Multi AV	√	√	√	√		SP0501
Singapore	INFINITI Q30	H15	2016.1-	HVAC	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	Auto drive position	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	Shift	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	All mode AWD/4WD	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	AVM	√	√		√		
Singapore	INFINITI Q30	H15	2016.1-	Intelligent key	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	CAN gateway	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	ANC	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	Telematics	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	FSCM	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	Siren control unit	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Singapore	INFINITI Q30	H15	2016.1-	Overhead Control Panel Unit	√			√		
Singapore	INFINITI Q30	H15	2016.1-	Universal Garage Door Opener	√			√		
Singapore	INFINITI Q30	H15	2016.1-	Upper control panel cont unit	√					
Singapore	INFINITI Q30	H15	2016.1-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Singapore	INFINITI Q30	H15	2016.1-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Singapore	INFINITI Q30	H15	2016.1-	Light/Rain Sensor Module	√			√		
Singapore	INFINITI Q30	H15	2016.1-	EC Mirror Compass	√					
Singapore	INFINITI Q30	H15	2016.1-	Intelligent Battery Sensor	√					
Singapore	INFINITI Q30	H15	2016.1-	Alarm siren	√			√		
Singapore	INFINITI Q30	H15	2016.1-	Radar sensor	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	Steering column cont module	√	√	√			
Singapore	INFINITI Q30	H15	2016.1-	ICC sensor	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	Trailer recognition control unit	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	H/L control module LH	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	Powertrain cont module	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	Side radar LH	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	LED H/L control module LH	√			√		
Singapore	INFINITI Q30	H15	2016.1-	Steering Wheel Switch Pad	√			√		
Singapore	INFINITI Q30	H15	2016.1-	Parking assist	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	Occupant Classification Unit	√			√		
Singapore	INFINITI Q30	H15	2016.1-	Electronic Ignition Switch cont unit	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	H/L control module RH	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	Front camera unit	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	Side radar RH	√	√	√	√		
Singapore	INFINITI Q30	H15	2016.1-	LED H/L control module RH	√			√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Singapore	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Singapore	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Singapore	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Singapore	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Singapore	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Singapore	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Singapore	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Singapore	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Singapore	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Singapore	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					

XTOOL

Singapore	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Singapore	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Singapore	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Singapore	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Singapore	INFINITI Q45	F50	ALL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Singapore	INFINITI Q45	F50	ALL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Singapore	INFINITI Q45	F50	ALL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Singapore	INFINITI Q45	F50	ALL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Singapore	INFINITI Q45	F50	ALL	Air bag	√	√	√	√		
Singapore	INFINITI Q45	F50	ALL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Singapore	INFINITI Q45	F50	ALL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Singapore	INFINITI Q45	F50	ALL	Motor control						
Singapore	INFINITI Q45	F50	ALL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Singapore	INFINITI Q45	F50	ALL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Singapore	INFINITI Q45	F50	ALL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Singapore	INFINITI Q45	F50	ALL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Singapore	INFINITI Q45	F50	ALL	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI Q45	F50	ALL	HVAC	√	√	√	√		
Singapore	INFINITI Q45	F50	ALL	Difference lock	√	√	√	√		
Singapore	INFINITI Q45	F50	ALL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Singapore	INFINITI Q45	F50	ALL	Auto slide door	√	√	√	√	AC0941	
Singapore	INFINITI Q45	F50	ALL	DIU		√	√	√		
Singapore	INFINITI Q45	F50	ALL	Adaptive light	√	√	√	√		
Singapore	INFINITI Q45	F50	ALL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Singapore	INFINITI Q45	F50	ALL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Singapore	INFINITI Q45	F50	ALL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Singapore	INFINITI Q45	F50	ALL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Singapore	INFINITI Q45	F50	ALL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Singapore	INFINITI Q45	F50	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Singapore	INFINITI Q45	F50	ALL	IVMS	√	√		√		
Singapore	INFINITI Q45	F50	ALL	Distance control	√	√		√		
Singapore	INFINITI Q45	F50	ALL	Active suspense system	√	√	√	√		
Singapore	INFINITI Q45	F50	ALL	Motor assist		√	√	√		SP0574
Singapore	INFINITI Q45	F50	ALL	ASCD	√	√	√	√		
Singapore	INFINITI Q45	F50	ALL	Active engine mount	√	√	√	√		
Singapore	INFINITI Q45	F50	ALL	TCS	√	√	√	√		
Singapore	INFINITI Q45	F50	ALL	S/blind camera	√			√		SP0572, SP0573
Singapore	INFINITI Q45	F50	ALL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Singapore	INFINITI Q45	F50	ALL	Nats immu	√	√	√			
Singapore	INFINITI Q45	F50	ALL	Rearview camera	√			√		SP0570, SP0571
Singapore	INFINITI Q45	F50	ALL	Smart entrance						SP0568
Singapore	INFINITI Q50	V37	2014.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Singapore	INFINITI Q50	V37	2014.1-	Laser/radar	√	√	√	√	AC0994	
Singapore	INFINITI Q50	V37	2014.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI Q50	V37	2014.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Singapore	INFINITI Q50	V37	2014.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Singapore	INFINITI Q50	V37	2014.1-	Air bag	√	√	√	√		
Singapore	INFINITI Q50	V37	2014.1-	EPS/DAST 3	√	√	√	√		SP0507
Singapore	INFINITI Q50	V37	2014.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Singapore	INFINITI Q50	V37	2014.1-	Motor control	√	√	√	√		
Singapore	INFINITI Q50	V37	2014.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Singapore	INFINITI Q50	V37	2014.1-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Singapore	INFINITI Q50	V37	2014.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Singapore	INFINITI Q50	V37	2014.1-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Singapore	INFINITI Q50	V37	2014.1-	Pop up hood	√	√	√	√		
Singapore	INFINITI Q50	V37	2014.1-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI Q50	V37	2014.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Singapore	INFINITI Q50	V37	2014.1-	HV battery	√	√	√	√	AC1121	
Singapore	INFINITI Q50	V37	2014.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Singapore	INFINITI Q50	V37	2014.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Singapore	INFINITI Q50	V37	2014.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Singapore	INFINITI Q50	V37	2014.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Singapore	INFINITI Q50	V37	2014.1-	Occupant detection			√	√		SP0584
Singapore	INFINITI Q50	V37	2014.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Singapore	INFINITI Q50	V37	2014.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Singapore	INFINITI Q50	V37	2014.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Singapore	INFINITI Q50	V37	2014.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Singapore	INFINITI Q50	V37	2014.1-	DAST 2	√	√	√	√		
Singapore	INFINITI Q50	V37	2014.1-	Precrash seatbelt	√	√	√	√		SP0612
Singapore	INFINITI Q50	V37	2014.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Singapore	INFINITI Q50	V37	2014.1-	CAN gateway	√	√	√			
Singapore	INFINITI Q50	V37	2014.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Singapore	INFINITI Q50	V37	2014.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Singapore	INFINITI Q50	V37	2014.1-	DAST 1	√	√	√	√		
Singapore	INFINITI Q50	V37	2014.1-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Singapore	INFINITI Q50	V37	2014.1-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Singapore	INFINITI Q50	V37	2014.1-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Singapore	INFINITI Q50	V37	2014.1-	ANC	√	√	√	√	AC1024	
Singapore	INFINITI Q50	V37	2014.1-	Side radar left	√	√	√	√	AC1025	SP0582
Singapore	INFINITI Q50	V37	2014.1-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610

Singapore	INFINITI Q50	V37	2014.1-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Singapore	INFINITI Q50	V37	2014.1-	HIGH BEAM ASSIST	√	√	√	√		
Singapore	INFINITI Q50	V37	2014.1-	Side radar right	√	√	√	√	AC1026	SP0583
Singapore	INFINITI Q50	V37	2014.1-	Brake	√	√	√	√	AC1127	
Singapore	INFINITI Q50	V37	2014.1-	6ch CAN GATEWAY	√	√	√	√		
Singapore	INFINITI Q50	V37	2014.1-	3ch CAN GATEWAY	√	√	√	√		
Singapore	INFINITI Q50	V37	2014.1-	ICC/ADAS 2	√	√	√	√		
Singapore	INFINITI Q50	V37	2014.1-	PMAS	√	√	√	√		
Singapore	INFINITI Q50	V37	2014.1-	FSCM	√	√	√	√	AC1109	
Singapore	INFINITI Q50	V37	2014.1-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Laser/radar	√	√	√	√	AC0994	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Air bag	√	√	√	√		
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Motor control	√	√	√	√		
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Transmission	√	√	√	√		SP0247,SP0265,SP0274,SP0276
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Pop up hood	√	√	√	√		
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	HV battery	√	√	√	√	AC1121	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Occupant detection			√	√		SP0584
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	DAST 2	√	√	√	√		
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	CAN gateway	√	√	√			
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	DAST 1	√	√	√	√		
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	ANC	√	√	√	√	AC1024	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Brake	√	√	√	√	AC1127	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	6ch CAN GATEWAY	√	√	√	√		
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	FSCM	√	√	√	√	AC1109	
Singapore	INFINITI Q50 HYBRID	HV37	2013.7-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Laser/radar	√	√	√	√		
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Air bag	√	√	√	√		
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	EPS/DAST 3	√	√	√	√		
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Motor control	√	√	√	√		
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0009,SP0016,SP0032,SP0033,SP0038,SP0039,SP0053,SP0063,SP0064,SP0074,SP0079,SP0082,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Transmission	√	√	√	√		SP0276
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Pop up hood	√	√	√	√		
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	HV battery	√	√	√	√	AC1121	
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Occupant detection			√	√		SP0584
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	DAST 2	√	√	√	√		
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Precrash seatbelt	√	√	√	√		SP0612
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	DAST 1	√	√	√	√		
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	ANC	√	√	√	√	AC1024	
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	HIGH BEAM ASSIST	√	√	√	√		
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	VSP	√	√	√	√		
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	Brake	√	√	√	√	AC1127	
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Singapore	INFINITI Q50 Hybrid	HV37	2018.5-	ICC/ADAS 2	√	√	√	√		
Singapore	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Singapore	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Singapore	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Singapore	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Singapore	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Singapore	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Singapore	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351

Singapore	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Singapore	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Singapore	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Singapore	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Singapore	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Singapore	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Singapore	INFINITI Q60	CV37	2016.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Singapore	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Singapore	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Singapore	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980. AC0981. AC0982	SP0561, SP0562
Singapore	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Singapore	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962. AC0963. AC0964. AC0966. AC0967. AC0968. AC0969. AC0970	SP0553. SP0554. SP0555. SP0556. SP0557. SP0558. SP0559
Singapore	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Singapore	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Singapore	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Singapore	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Singapore	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Singapore	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√		
Singapore	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Singapore	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Singapore	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Singapore	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Singapore	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Singapore	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Singapore	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Singapore	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Singapore	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Singapore	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Singapore	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Singapore	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Singapore	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Laser/radar	√	√	√	√	AC0994	
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Air bag	√	√	√	√		
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Transmission	√	√	√	√		SP0274
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Pop up hood	√	√	√	√		
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Precrash seatbelt	√	√	√	√		
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Singapore	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Singapore	INFINITI Q70	Y51	2013.11-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Singapore	INFINITI Q70	Y51	2013.11-	Laser/radar	√	√	√	√	AC0994	
Singapore	INFINITI Q70	Y51	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI Q70	Y51	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Singapore	INFINITI Q70	Y51	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Singapore	INFINITI Q70	Y51	2013.11-	Air bag	√	√	√	√		
Singapore	INFINITI Q70	Y51	2013.11-	EPS/DAST 3	√	√	√	√		
Singapore	INFINITI Q70	Y51	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Singapore	INFINITI Q70	Y51	2013.11-	Motor control	√	√	√	√		
Singapore	INFINITI Q70	Y51	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Singapore	INFINITI Q70	Y51	2013.11-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Singapore	INFINITI Q70	Y51	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Singapore	INFINITI Q70	Y51	2013.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Singapore	INFINITI Q70	Y51	2013.11-	Pop up hood	√	√	√	√		
Singapore	INFINITI Q70	Y51	2013.11-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI Q70	Y51	2013.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Singapore	INFINITI Q70	Y51	2013.11-	HV battery	√	√	√	√	AC1121	
Singapore	INFINITI Q70	Y51	2013.11-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Singapore	INFINITI Q70	Y51	2013.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Singapore	INFINITI Q70	Y51	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Singapore	INFINITI Q70	Y51	2013.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Singapore	INFINITI Q70	Y51	2013.11-	Occupant detection			√	√		SP0584

Singapore	INFINITI Q70	Y51	2013.11-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Singapore	INFINITI Q70	Y51	2013.11-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Singapore	INFINITI Q70	Y51	2013.11-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Singapore	INFINITI Q70	Y51	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Singapore	INFINITI Q70	Y51	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Singapore	INFINITI Q70	Y51	2013.11-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Singapore	INFINITI Q70	Y51	2013.11-	CAN gateway	√	√	√	√		
Singapore	INFINITI Q70	Y51	2013.11-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Singapore	INFINITI Q70	Y51	2013.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Singapore	INFINITI Q70	Y51	2013.11-	ADCM	√	√	√	√		SP0604,SP0605,SP0606
Singapore	INFINITI Q70	Y51	2013.11-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Singapore	INFINITI Q70	Y51	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Singapore	INFINITI Q70	Y51	2013.11-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Singapore	INFINITI Q70	Y51	2013.11-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Singapore	INFINITI Q70	Y51	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Singapore	INFINITI Q70	Y51	2013.11-	VSP	√	√	√	√		
Singapore	INFINITI Q70	Y51	2013.11-	Brake	√	√	√	√	AC1127	
Singapore	INFINITI Q70	Y51	2013.11-	6ch CAN GATEWAY	√	√	√	√		
Singapore	INFINITI Q70	Y51	2013.11-	ICC/ADAS 2	√	√	√	√		
Singapore	INFINITI Q70	Y51	2013.11-	FSCM	√	√	√	√	AC1109	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0330,AC0331,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√		SP0274,SP0276
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√	√		
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	ANC	√	√	√	√	AC1024	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	FSCM	√	√	√	√	AC1109	
Singapore	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Laser/radar	√	√	√	√		
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Air bag	√	√	√	√		
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	EPS/DAST 3	√	√	√	√		
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Motor control	√	√	√	√		
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Transmission	√	√	√	√		SP0247,SP0265,SP0274,SP0276
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Pop up hood	√	√	√	√		
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	HV battery	√	√	√	√	AC1121	
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Precrash seatbelt	√	√	√	√		SP0612
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	VSP	√	√	√	√		
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	Brake	√	√	√	√	AC1127	
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	ICC/ADAS 2	√	√	√	√		
Singapore	INFINITI Q70L Hybrid	HY51	2018.5-	FSCM	√	√	√	√	AC1109	
Singapore	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0898,AC0900,AC0901,AC0902	SP0508,SP0510
Singapore	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Singapore	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833,AC0834,AC0835,AC0836,AC0837,AC0838,AC0839,AC0840,AC0841,AC0842,AC0843,AC0844,AC0845,AC0846,AC0847	
Singapore	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		

Singapore	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Singapore	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Singapore	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Singapore	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Singapore	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Singapore	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Singapore	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Singapore	INFINITI QX50	J55	2018.5-	Shift						
Singapore	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Singapore	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Singapore	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Singapore	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Singapore	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	ANC						
Singapore	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Singapore	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Singapore	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Singapore	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Singapore	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Singapore	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Singapore	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Singapore	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Singapore	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Singapore	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Singapore	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Singapore	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Singapore	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Singapore	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Singapore	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Singapore	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Singapore	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Singapore	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Singapore	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Singapore	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Singapore	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Singapore	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Singapore	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Singapore	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Singapore	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Singapore	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Singapore	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Singapore	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Singapore	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Singapore	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Singapore	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Singapore	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Singapore	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Singapore	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Singapore	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Singapore	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Singapore	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Singapore	INFINITI QX80	Z62	2014.11-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Singapore	INFINITI QX80	Z62	2014.11-	Laser/radar	√	√	√	√	AC0994	
Singapore	INFINITI QX80	Z62	2014.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Singapore	INFINITI QX80	Z62	2014.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Singapore	INFINITI QX80	Z62	2014.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Singapore	INFINITI QX80	Z62	2014.11-	Air bag	√	√	√	√		
Singapore	INFINITI QX80	Z62	2014.11-	EPS/DAST 3	√	√	√	√		SP0507
Singapore	INFINITI QX80	Z62	2014.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Singapore	INFINITI QX80	Z62	2014.11-	Motor control	√	√	√	√		
Singapore	INFINITI QX80	Z62	2014.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Singapore	INFINITI QX80	Z62	2014.11-	Transmission	√	√	√	√	AC0439, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0246, SP0270, SP0274, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Singapore	INFINITI QX80	Z62	2014.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Singapore	INFINITI QX80	Z62	2014.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Singapore	INFINITI QX80	Z62	2014.11-	Multi AV	√	√	√	√		SP0503
Singapore	INFINITI QX80	Z62	2014.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Singapore	INFINITI QX80	Z62	2014.11-	HV battery	√	√	√	√	AC1121	
Singapore	INFINITI QX80	Z62	2014.11-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Singapore	INFINITI QX80	Z62	2014.11-	Difference lock	√	√	√	√		
Singapore	INFINITI QX80	Z62	2014.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Singapore	INFINITI QX80	Z62	2014.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Singapore	INFINITI QX80	Z62	2014.11-	Auto back door	√	√	√	√		SP0611
Singapore	INFINITI QX80	Z62	2014.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Singapore	INFINITI QX80	Z62	2014.11-	Occupant detection			√	√		SP0584
Singapore	INFINITI QX80	Z62	2014.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Singapore	INFINITI QX80	Z62	2014.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Singapore	INFINITI QX80	Z62	2014.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Singapore	INFINITI QX80	Z62	2014.11-	All mode AWD/4WD	√	√	√	√	AC0956	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Singapore	INFINITI QX80	Z62	2014.11-	Precrash seatbelt	√	√	√	√		SP0612
Singapore	INFINITI QX80	Z62	2014.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Singapore	INFINITI QX80	Z62	2014.11-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Singapore	INFINITI QX80	Z62	2014.11-	CAN gateway	√	√	√			
Singapore	INFINITI QX80	Z62	2014.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Singapore	INFINITI QX80	Z62	2014.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Singapore	INFINITI QX80	Z62	2014.11-	Side radar left	√	√	√	√	AC1025	SP0582

Singapore	INFINITI QX80	Z62	2014.11-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Singapore	INFINITI QX80	Z62	2014.11-	HIGH BEAM ASSIST	√	√	√	√		
Singapore	INFINITI QX80	Z62	2014.11-	Side radar right	√	√	√	√	AC1026	SP0583
Singapore	INFINITI QX80	Z62	2014.11-	Vehicle data transmitter	√	√	√	√		
Singapore	INFINITI QX80	Z62	2014.11-	6ch CAN GATEWAY	√	√	√	√		
Singapore	INFINITI QX80	Z62	2014.11-	ICC/ADAS 2	√	√	√	√		
Singapore	INFINITI QX80	Z62	2014.11-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Singapore	INFINITI QX80	Z62	2014.11-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Slovakia	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Slovakia	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Slovakia	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Slovakia	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Slovakia	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Slovakia	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Slovakia	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Slovakia	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Slovakia	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Slovakia	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Slovakia	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Slovakia	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Slovakia	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovakia	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Slovakia	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270

Xtool

Slovakia	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovakia	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Slovakia	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Slovakia	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Slovakia	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Slovakia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Slovakia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Slovakia	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Slovakia	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Slovakia	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Slovakia	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Slovakia	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Slovakia	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Slovakia	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Slovakia	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Slovakia	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		

Slovakia	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Slovakia	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Slovakia	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Slovakia	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Slovakia	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Slovakia	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Slovakia	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Slovakia	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Slovakia	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Slovakia	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Slovakia	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Slovakia	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovakia	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Slovakia	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovakia	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Slovakia	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Slovakia	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Slovakia	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Slovakia	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Slovakia	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovakia	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Slovakia	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Slovakia	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovakia	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovakia	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovakia	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Slovakia	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Slovakia	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Slovakia	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Slovakia	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Slovakia	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Slovakia	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Slovakia	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Slovakia	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Slovakia	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Slovakia	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Slovakia	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		

XTOOL

Slovakia	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Slovakia	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Slovakia	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Slovakia	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Slovakia	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Slovakia	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Slovakia	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Slovakia	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Slovakia	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Slovakia	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Slovakia	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Slovakia	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Slovakia	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Slovakia	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Slovakia	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Slovakia	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Slovakia	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Slovakia	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Slovakia	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Slovakia	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Slovakia	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Slovakia	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Slovakia	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Slovakia	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Slovakia	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Slovakia	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Slovakia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Slovakia	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Slovakia	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Slovakia	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Slovakia	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Slovakia	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Slovakia	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovakia	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Slovakia	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

XTOOL

Slovakia	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Slovakia	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Slovakia	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Slovakia	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Slovakia	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovakia	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Slovakia	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Slovakia	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovakia	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Slovakia	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Slovakia	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Slovakia	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovakia	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Slovakia	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Slovakia	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Slovakia	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Slovakia	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovakia	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Slovakia	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Slovakia	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Slovakia	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Slovakia	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Slovakia	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Slovakia	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Slovakia	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Slovakia	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Slovakia	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Slovakia	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovakia	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Slovakia	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Slovakia	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Slovakia	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Slovakia	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Slovakia	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Slovakia	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Slovakia	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Slovakia	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Slovakia	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557

Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Slovakia	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Slovakia	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Slovakia	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Slovakia	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Slovakia	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Slovakia	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Slovakia	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovakia	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovakia	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Slovakia	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Slovakia	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Slovakia	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Slovakia	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovakia	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Slovakia	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Slovakia	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovakia	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Slovakia	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovakia	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Slovakia	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Slovakia	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Slovakia	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Slovakia	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Slovakia	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Slovakia	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Slovakia	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Slovakia	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Slovakia	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Slovakia	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovakia	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Slovakia	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Slovakia	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Slovakia	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Slovakia	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Slovakia	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovakia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√	AC0394	SP0274
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovakia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Slovakia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Slovakia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Slovakia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Slovakia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Slovakia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovakia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovakia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Slovakia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Slovakia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Slovakia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovakia	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Slovakia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovakia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Slovakia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Slovakia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovakia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Slovakia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Slovakia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Slovakia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovakia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Slovakia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Slovakia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Slovakia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Slovakia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Slovakia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Slovakia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovakia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Slovakia	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Slovakia	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Slovakia	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Slovakia	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Slovakia	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Slovakia	INFINITI QX50	I50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Slovakia	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Slovakia	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Slovakia	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Slovakia	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Slovakia	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovakia	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovakia	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Slovakia	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovakia	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovakia	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovakia	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovakia	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovakia	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Slovakia	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovakia	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Slovakia	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Slovakia	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Slovakia	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovakia	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Slovakia	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Slovakia	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Slovakia	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Slovakia	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Slovakia	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Slovakia	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Slovakia	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Slovakia	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovakia	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Slovakia	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Slovakia	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Slovakia	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovakia	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Slovakia	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Slovakia	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Slovakia	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Slovakia	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Slovakia	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Slovakia	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovakia	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Slovakia	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovakia	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Slovakia	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Slovakia	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovakia	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovakia	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Slovakia	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovakia	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Slovakia	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Slovakia	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Slovakia	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Slovakia	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovakia	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovakia	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Slovakia	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Slovakia	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovakia	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovakia	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Slovakia	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovakia	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Slovakia	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Slovakia	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Slovakia	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Slovakia	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovakia	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Slovakia	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Slovakia	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovakia	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Slovakia	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503

Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Slovenia	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Slovenia	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Slovenia	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Slovenia	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Slovenia	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Slovenia	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Slovenia	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Slovenia	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Slovenia	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Slovenia	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Slovenia	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Slovenia	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Slovenia	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovenia	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Slovenia	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Slovenia	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovenia	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Slovenia	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Slovenia	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Slovenia	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Slovenia	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Slovenia	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	Laser/radar	√	√	√	√		
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	Air bag	√	√	√	√		
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	Pop up hood	√	√	√	√		
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Slovenia	INFINITI G37 SEDAN	V36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Slovenia	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Slovenia	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Slovenia	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Slovenia	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Slovenia	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Slovenia	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Slovenia	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Slovenia	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Slovenia	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Slovenia	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Slovenia	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Slovenia	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Slovenia	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Slovenia	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Slovenia	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Slovenia	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Slovenia	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Slovenia	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Slovenia	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Slovenia	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovenia	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		

Slovenia	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovenia	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Slovenia	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Slovenia	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Slovenia	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Slovenia	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Slovenia	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovenia	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Slovenia	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Slovenia	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovenia	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovenia	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovenia	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Slovenia	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Slovenia	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Slovenia	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Slovenia	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Slovenia	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Slovenia	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Slovenia	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Slovenia	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Slovenia	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Slovenia	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Slovenia	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Slovenia	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Slovenia	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Slovenia	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Slovenia	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Slovenia	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Slovenia	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		

XTOOL

Slovenia	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Slovenia	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Slovenia	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Slovenia	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Slovenia	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Slovenia	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Slovenia	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Slovenia	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Slovenia	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Slovenia	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Slovenia	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Slovenia	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Slovenia	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Slovenia	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Slovenia	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Slovenia	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Slovenia	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Slovenia	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Slovenia	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Slovenia	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Slovenia	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Slovenia	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Slovenia	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Slovenia	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Slovenia	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Slovenia	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovenia	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Slovenia	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovenia	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Slovenia	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Slovenia	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Slovenia	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Slovenia	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovenia	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Slovenia	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Slovenia	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovenia	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Slovenia	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Slovenia	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Slovenia	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovenia	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Slovenia	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Slovenia	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Slovenia	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Slovenia	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovenia	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540

Slovenia	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Slovenia	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Slovenia	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Slovenia	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Slovenia	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Slovenia	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Slovenia	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Slovenia	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Slovenia	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Slovenia	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovenia	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Slovenia	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Slovenia	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Slovenia	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Slovenia	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Slovenia	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Slovenia	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Slovenia	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Slovenia	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Slovenia	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Slovenia	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Slovenia	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Slovenia	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Slovenia	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Slovenia	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Slovenia	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Slovenia	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovenia	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovenia	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Slovenia	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Slovenia	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Slovenia	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Slovenia	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovenia	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Slovenia	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Slovenia	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovenia	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Slovenia	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovenia	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Slovenia	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Slovenia	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985. AC0986. AC0987. AC0988. AC0989	SP0563. SP0564. SP0565. SP0566. SP0567
Slovenia	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Slovenia	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971. AC0972. AC0973. AC0974. AC0975. AC0976. AC0977	SP0560
Slovenia	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Slovenia	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Slovenia	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Slovenia	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Slovenia	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Slovenia	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovenia	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Slovenia	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Slovenia	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Slovenia	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Slovenia	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Slovenia	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovenia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983. AC0984. AC0985. AC0986. AC0987. AC0988. AC0989. AC0990	SP0563. SP0564. SP0565. SP0566. SP0567
Slovenia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894. AC0895. AC0896. AC0897. AC0898. AC0899. AC0900. AC0901. AC0902	SP0508. SP0509. SP0510
Slovenia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Slovenia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

Slovenia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Slovenia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Slovenia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovenia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovenia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Slovenia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Slovenia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Slovenia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovenia	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Slovenia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovenia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Slovenia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Slovenia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovenia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Slovenia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Slovenia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Slovenia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovenia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Slovenia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Slovenia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Slovenia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Slovenia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Slovenia	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Slovenia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovenia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Slovenia	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Slovenia	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Slovenia	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Slovenia	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Slovenia	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Slovenia	INFINITI QX50	I50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Slovenia	INFINITI QX50	I50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Slovenia	INFINITI QX50	I50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Slovenia	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Slovenia	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Slovenia	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovenia	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovenia	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Slovenia	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovenia	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovenia	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovenia	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovenia	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	

Slovenia	INFINITI QX50	I50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Slovenia	INFINITI QX50	I50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Slovenia	INFINITI QX50	I50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Slovenia	INFINITI QX50	I50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Slovenia	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Slovenia	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovenia	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Slovenia	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Slovenia	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Slovenia	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Slovenia	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Slovenia	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Slovenia	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Slovenia	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Slovenia	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Slovenia	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Slovenia	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Slovenia	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Slovenia	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Slovenia	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Slovenia	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Slovenia	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Slovenia	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Slovenia	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Slovenia	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Slovenia	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Slovenia	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Slovenia	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Slovenia	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Slovenia	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Slovenia	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Slovenia	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Slovenia	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Slovenia	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Slovenia	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Slovenia	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Slovenia	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Slovenia	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Slovenia	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Slovenia	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Slovenia	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Slovenia	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Slovenia	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Slovenia	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Slovenia	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Slovenia	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Slovenia	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Slovenia	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Slovenia	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Slovenia	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Slovenia	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Slovenia	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Slovenia	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Slovenia	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Slovenia	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Slovenia	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Somalia	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Somalia	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Somalia	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Somalia	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Somalia	INFINITI EX35/EX37	I50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Somalia	INFINITI EX35/EX37	I50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Somalia	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Somalia	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI EX35/EX37	I50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Somalia	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Somalia	INFINITI EX35/EX37	I50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Somalia	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Somalia	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Somalia	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Somalia	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Somalia	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Somalia	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Somalia	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Somalia	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Somalia	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Somalia	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Somalia	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Somalia	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Somalia	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Somalia	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Somalia	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	

Somalia	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Somalia	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Somalia	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Somalia	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Somalia	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Somalia	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Somalia	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Somalia	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Somalia	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Somalia	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Somalia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Somalia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Somalia	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Somalia	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Somalia	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Somalia	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Somalia	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Somalia	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Somalia	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Somalia	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Somalia	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Somalia	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Somalia	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Somalia	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Somalia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Somalia	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Somalia	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Somalia	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Somalia	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Somalia	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Somalia	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Somalia	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Somalia	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Somalia	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Somalia	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Somalia	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Somalia	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Somalia	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Somalia	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Somalia	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Somalia	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Somalia	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Somalia	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Somalia	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Somalia	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Somalia	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Somalia	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Somalia	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Somalia	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Somalia	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Somalia	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Somalia	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Somalia	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Somalia	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Somalia	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Somalia	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Somalia	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Somalia	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Somalia	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Somalia	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Somalia	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Somalia	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Somalia	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Somalia	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Somalia	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Somalia	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Somalia	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Somalia	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Somalia	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Somalia	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Somalia	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Somalia	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Somalia	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Somalia	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Somalia	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Somalia	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Somalia	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Somalia	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Somalia	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Somalia	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Somalia	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Somalia	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Somalia	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Somalia	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Somalia	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Somalia	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Somalia	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Somalia	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Somalia	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Somalia	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Somalia	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Somalia	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Somalia	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Somalia	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Somalia	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	

Somalia	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Somalia	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Somalia	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Somalia	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Somalia	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Somalia	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Somalia	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Somalia	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Somalia	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Somalia	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Somalia	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Somalia	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Somalia	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Somalia	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Somalia	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Somalia	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Somalia	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Somalia	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Somalia	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Somalia	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Somalia	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Somalia	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Somalia	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Somalia	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Somalia	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Somalia	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Somalia	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Somalia	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Somalia	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Somalia	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Somalia	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Somalia	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Somalia	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Somalia	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Somalia	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Somalia	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Somalia	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Somalia	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Somalia	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Somalia	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Somalia	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Somalia	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Somalia	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Somalia	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Somalia	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Somalia	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Somalia	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Somalia	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		

Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Somalia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Somalia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Somalia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Somalia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Somalia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Somalia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Somalia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Somalia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Somalia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Somalia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Somalia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Somalia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Somalia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Somalia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Somalia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Somalia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Somalia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Somalia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Somalia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Somalia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Somalia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Somalia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Somalia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Somalia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Somalia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Somalia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Somalia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Somalia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Somalia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Somalia	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Somalia	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Somalia	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Somalia	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Somalia	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Somalia	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Somalia	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Somalia	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Somalia	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Somalia	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Somalia	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Somalia	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Somalia	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Somalia	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Somalia	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Somalia	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Somalia	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Somalia	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Somalia	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Somalia	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Somalia	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Somalia	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Somalia	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Somalia	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Somalia	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Somalia	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Somalia	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Somalia	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Somalia	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Somalia	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Somalia	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Somalia	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Somalia	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Somalia	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Somalia	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Somalia	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Somalia	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Somalia	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Somalia	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Somalia	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Somalia	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Somalia	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Somalia	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Somalia	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Somalia	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Somalia	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Somalia	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Somalia	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Somalia	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Somalia	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Somalia	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Somalia	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Somalia	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Somalia	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Somalia	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Somalia	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Somalia	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Somalia	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Somalia	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Somalia	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Somalia	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Somalia	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Somalia	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Somalia	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Somalia	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Somalia	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Somalia	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Somalia	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Somalia	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Somalia	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Somalia	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Somalia	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Somalia	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Somalia	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Somalia	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Somalia	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Somalia	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Somalia	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Somalia	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Somalia	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Somalia	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Somalia	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Somalia	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Somalia	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Somalia	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Somalia	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
South africa	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
South africa	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
South africa	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
South africa	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

South africa	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
South africa	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
South africa	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
South africa	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
South africa	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
South africa	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
South africa	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
South africa	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
South africa	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
South africa	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
South africa	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
South africa	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
South africa	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
South africa	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
South africa	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
South africa	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
South africa	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
South africa	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
South africa	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
South africa	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
South africa	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
South africa	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
South africa	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
South africa	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
South africa	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
South africa	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
South africa	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
South africa	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
South africa	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
South africa	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
South africa	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
South africa	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
South africa	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
South africa	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
South africa	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556

South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
South africa	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
South africa	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
South africa	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
South africa	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
South africa	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
South africa	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
South africa	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
South africa	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
South africa	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
South africa	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
South africa	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
South africa	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
South africa	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
South africa	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
South africa	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
South africa	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
South africa	INFINITI G37 SEDAN	V36	2012.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI G37 SEDAN	V36	2012.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
South africa	INFINITI G37 SEDAN	V36	2012.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
South africa	INFINITI G37 SEDAN	V36	2012.3-	Air bag	√	√	√	√		
South africa	INFINITI G37 SEDAN	V36	2012.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
South africa	INFINITI G37 SEDAN	V36	2012.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
South africa	INFINITI G37 SEDAN	V36	2012.3-	Transmission	√	√	√	√		SP0274
South africa	INFINITI G37 SEDAN	V36	2012.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
South africa	INFINITI G37 SEDAN	V36	2012.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
South africa	INFINITI G37 SEDAN	V36	2012.3-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI G37 SEDAN	V36	2012.3-	4WAS(front)	√	√	√	√	AC1027, AC1028	
South africa	INFINITI G37 SEDAN	V36	2012.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI G37 SEDAN	V36	2012.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
South africa	INFINITI G37 SEDAN	V36	2012.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
South africa	INFINITI G37 SEDAN	V36	2012.3-	All mode AWD/4WD	√	√	√	√	AC0956	
South africa	INFINITI G37 SEDAN	V36	2012.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
South africa	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
South africa	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
South africa	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

South africa	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
South africa	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
South africa	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
South africa	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
South africa	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
South africa	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
South africa	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
South africa	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
South africa	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
South africa	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
South africa	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
South africa	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
South africa	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
South africa	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
South africa	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
South africa	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
South africa	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
South africa	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
South africa	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
South africa	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
South africa	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
South africa	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
South africa	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
South africa	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
South africa	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
South africa	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
South africa	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
South africa	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
South africa	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
South africa	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
South africa	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
South africa	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
South africa	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
South africa	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
South africa	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
South africa	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
South africa	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
South africa	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
South africa	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
South africa	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
South africa	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
South africa	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		

South africa	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
South africa	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
South africa	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
South africa	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
South africa	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
South africa	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
South africa	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
South africa	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
South africa	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
South africa	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
South africa	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
South africa	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
South africa	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
South africa	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
South africa	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
South africa	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
South africa	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
South africa	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
South africa	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
South africa	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
South africa	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
South africa	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
South africa	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
South africa	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
South africa	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
South africa	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
South africa	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
South africa	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
South africa	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
South africa	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
South africa	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
South africa	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
South africa	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
South africa	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
South africa	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
South africa	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
South africa	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
South africa	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
South africa	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
South africa	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
South africa	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276

South africa	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
South africa	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
South africa	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
South africa	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
South africa	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
South africa	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
South africa	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
South africa	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
South africa	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
South africa	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
South africa	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
South africa	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
South africa	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
South africa	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
South africa	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
South africa	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
South africa	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
South africa	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
South africa	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
South africa	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
South africa	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
South africa	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
South africa	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
South africa	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
South africa	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
South africa	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
South africa	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
South africa	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
South africa	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
South africa	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
South africa	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
South africa	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610

South africa	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
South africa	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
South africa	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
South africa	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
South africa	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
South africa	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
South africa	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
South africa	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
South africa	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
South africa	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
South africa	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
South africa	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
South africa	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
South africa	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
South africa	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
South africa	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
South africa	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
South africa	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
South africa	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
South africa	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
South africa	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
South africa	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
South africa	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
South africa	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
South africa	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
South africa	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
South africa	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
South africa	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
South africa	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
South africa	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
South africa	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
South africa	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
South africa	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
South africa	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
South africa	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351

South africa	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
South africa	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
South africa	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
South africa	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
South africa	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
South africa	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
South africa	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
South africa	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
South africa	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
South africa	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
South africa	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
South africa	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
South africa	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
South africa	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
South africa	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
South africa	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
South africa	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
South africa	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
South africa	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
South africa	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
South africa	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
South africa	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
South africa	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
South africa	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
South africa	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
South africa	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
South africa	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
South africa	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
South africa	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
South africa	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
South africa	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
South africa	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
South africa	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
South africa	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
South africa	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
South africa	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
South africa	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
South africa	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
South africa	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
South africa	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
South africa	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
South africa	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
South africa	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
South africa	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
South africa	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
South africa	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
South africa	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
South africa	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
South africa	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
South africa	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
South africa	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
South africa	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
South africa	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

South africa	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
South africa	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
South africa	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
South africa	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
South africa	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
South africa	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
South africa	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
South africa	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
South africa	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
South africa	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
South africa	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
South africa	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
South africa	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
South africa	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
South africa	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
South africa	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
South africa	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
South africa	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
South africa	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
South africa	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
South africa	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
South africa	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
South africa	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
South africa	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
South africa	INFINITI QX80	Z62	2014.11-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
South africa	INFINITI QX80	Z62	2014.11-	Laser/radar	√	√	√	√	AC0994	
South africa	INFINITI QX80	Z62	2014.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
South africa	INFINITI QX80	Z62	2014.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
South africa	INFINITI QX80	Z62	2014.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
South africa	INFINITI QX80	Z62	2014.11-	Air bag	√	√	√	√		
South africa	INFINITI QX80	Z62	2014.11-	EPS/DAST 3	√	√	√	√		SP0507
South africa	INFINITI QX80	Z62	2014.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
South africa	INFINITI QX80	Z62	2014.11-	Motor control	√	√	√	√		
South africa	INFINITI QX80	Z62	2014.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
South africa	INFINITI QX80	Z62	2014.11-	Transmission	√	√	√	√	AC0439, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0246, SP0270, SP0274, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
South africa	INFINITI QX80	Z62	2014.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
South africa	INFINITI QX80	Z62	2014.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
South africa	INFINITI QX80	Z62	2014.11-	Multi AV	√	√	√	√		SP0503
South africa	INFINITI QX80	Z62	2014.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
South africa	INFINITI QX80	Z62	2014.11-	HV battery	√	√	√	√	AC1121	
South africa	INFINITI QX80	Z62	2014.11-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
South africa	INFINITI QX80	Z62	2014.11-	Difference lock	√	√	√	√		
South africa	INFINITI QX80	Z62	2014.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
South africa	INFINITI QX80	Z62	2014.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
South africa	INFINITI QX80	Z62	2014.11-	Auto back door	√	√	√	√		SP0611
South africa	INFINITI QX80	Z62	2014.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
South africa	INFINITI QX80	Z62	2014.11-	Occupant detection			√	√		SP0584
South africa	INFINITI QX80	Z62	2014.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
South africa	INFINITI QX80	Z62	2014.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
South africa	INFINITI QX80	Z62	2014.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
South africa	INFINITI QX80	Z62	2014.11-	All mode AWD/4WD	√	√	√	√	AC0956	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
South africa	INFINITI QX80	Z62	2014.11-	Precrash seatbelt	√	√	√	√		SP0612
South africa	INFINITI QX80	Z62	2014.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
South africa	INFINITI QX80	Z62	2014.11-	CAN gateway	√	√	√			
South africa	INFINITI QX80	Z62	2014.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
South africa	INFINITI QX80	Z62	2014.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
South africa	INFINITI QX80	Z62	2014.11-	Side radar left	√	√	√	√	AC1025	SP0582
South africa	INFINITI QX80	Z62	2014.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
South africa	INFINITI QX80	Z62	2014.11-	HIGH BEAM ASSIST	√	√	√	√		

South africa	INFINITI QX80	Z62	2014.11-	Side radar right	√	√	√	√	AC1026	SP0583
South africa	INFINITI QX80	Z62	2014.11-	Vehicle data transmitter	√	√	√	√		
South africa	INFINITI QX80	Z62	2014.11-	ICC/ADAS 2	√	√	√	√		
South africa	INFINITI QX80	Z62	2014.11-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
South africa	INFINITI QX80	Z62	2014.11-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Spain	INFINITI EX35/EX30D	I50	2009.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Spain	INFINITI EX35/EX30D	I50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI EX35/EX30D	I50	2009.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Spain	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Spain	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Spain	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Spain	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0202,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0236,SP0237,SP0238,SP0239
Spain	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Spain	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Spain	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
Spain	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Spain	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Spain	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Spain	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Spain	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Spain	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Spain	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Spain	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022,AC1023	
Spain	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Spain	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Spain	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Spain	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Spain	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Spain	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Spain	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Spain	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Spain	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Spain	INFINITI EX37	J50	2008.6-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Spain	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Spain	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Spain	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Spain	INFINITI EX37	I50	2008.6-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Spain	INFINITI EX37	I50	2008.6-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Spain	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Spain	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
Spain	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Spain	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347,SP0348,SP0349
Spain	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Spain	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270
Spain	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653,AC0695	SP0372,SP0429
Spain	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Spain	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Spain	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
Spain	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Spain	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
Spain	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570,SP0571
Spain	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Spain	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Spain	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Spain	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Spain	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Spain	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Spain	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
Spain	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Spain	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Spain	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Spain	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Spain	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Spain	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Spain	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Spain	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Spain	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Spain	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Spain	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239

Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Spain	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Spain	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Spain	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Spain	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Spain	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Spain	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Spain	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Spain	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Spain	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Spain	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Spain	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Spain	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Spain	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Spain	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Spain	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Spain	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Spain	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Spain	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Spain	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Spain	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Spain	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Spain	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Spain	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Spain	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Spain	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		

Spain	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Spain	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Spain	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Spain	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Spain	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Spain	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Spain	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Spain	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Spain	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Spain	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Spain	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Spain	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Spain	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Spain	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Spain	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Spain	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Spain	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Spain	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Spain	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Spain	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Spain	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Spain	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Spain	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Spain	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Spain	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Spain	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Spain	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Spain	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Spain	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Spain	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Spain	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Spain	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Spain	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Spain	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Spain	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Spain	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Spain	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Spain	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Spain	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Spain	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Spain	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Spain	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Spain	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Spain	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Spain	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Spain	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Spain	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Spain	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Spain	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Spain	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Spain	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Spain	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Spain	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Spain	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319

Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Spain	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Spain	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Spain	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Spain	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Spain	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Spain	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Spain	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Spain	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Spain	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Spain	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Spain	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Spain	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Spain	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Spain	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Spain	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Spain	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Spain	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Spain	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Spain	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Spain	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Spain	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Spain	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Spain	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Spain	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Spain	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Spain	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Spain	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Spain	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Spain	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Spain	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Spain	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Spain	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Spain	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Spain	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Spain	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					

XTOOL

Spain	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Spain	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Spain	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Spain	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Spain	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Spain	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Spain	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Spain	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Spain	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Spain	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Spain	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Spain	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Spain	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Spain	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Spain	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Spain	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Spain	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Spain	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Spain	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Spain	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Spain	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Spain	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Spain	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Spain	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Spain	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Spain	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Spain	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Spain	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Spain	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Spain	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Spain	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Spain	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Spain	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Spain	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Spain	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Spain	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Spain	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Spain	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Spain	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Spain	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Spain	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Spain	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Spain	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Spain	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Spain	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Spain	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Spain	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Spain	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Spain	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		

Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Spain	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Spain	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Spain	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Spain	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Spain	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Spain	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Spain	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Spain	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Spain	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Spain	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Spain	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Spain	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Spain	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Spain	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Spain	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Spain	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Spain	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Spain	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Spain	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Spain	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Spain	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Spain	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Spain	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Spain	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Spain	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Spain	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Spain	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Spain	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Spain	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Spain	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Spain	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Spain	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Spain	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Spain	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Spain	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Spain	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Spain	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Spain	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Spain	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Spain	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Spain	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Spain	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Spain	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Spain	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Spain	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Spain	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Spain	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Spain	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Spain	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Spain	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Spain	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Spain	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Spain	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Spain	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Spain	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Spain	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Spain	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Spain	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Spain	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Spain	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Spain	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Spain	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Spain	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Spain	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Spain	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Spain	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Spain	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Spain	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Spain	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Spain	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Spain	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Spain	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Spain	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Spain	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Spain	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Spain	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Spain	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Spain	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Spain	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Spain	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Spain	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Spain	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Spain	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Spain	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		

Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Spain	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Spain	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Spain	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Spain	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Spain	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Spain	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Spain	INFINITI QX50	I50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Spain	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Spain	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Spain	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Spain	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Spain	INFINITI QX50	I50	2013.9-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Spain	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Spain	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Spain	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Spain	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Spain	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Spain	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Spain	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Spain	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Spain	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Spain	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Spain	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Spain	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Spain	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Spain	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Spain	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Spain	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Spain	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Spain	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Spain	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Spain	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Spain	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Spain	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Spain	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Spain	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Spain	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Spain	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Spain	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Spain	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Spain	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Spain	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Spain	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Spain	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Spain	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Spain	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Spain	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Spain	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Spain	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Spain	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Spain	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621

Spain	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Spain	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Spain	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Spain	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Spain	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Spain	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Spain	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Spain	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Spain	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Spain	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Spain	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Spain	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Spain	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Spain	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Spain	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Spain	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Spain	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Spain	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Spain	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Spain	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sri lanka	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√		
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Sri lanka	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Suriname	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Suriname	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Suriname	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Suriname	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Suriname	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Suriname	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Suriname	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Suriname	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Suriname	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Suriname	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Suriname	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Suriname	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Suriname	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Suriname	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Suriname	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Suriname	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Suriname	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Suriname	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Suriname	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Suriname	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Suriname	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

Suriname	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Suriname	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Suriname	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Suriname	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Suriname	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Suriname	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Suriname	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Suriname	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Suriname	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Suriname	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Suriname	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Suriname	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Suriname	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Suriname	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Suriname	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Suriname	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Suriname	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Suriname	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Suriname	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Suriname	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Suriname	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Suriname	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Suriname	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Suriname	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Suriname	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Suriname	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Suriname	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Suriname	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Suriname	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Xtool

Suriname	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Suriname	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Suriname	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Suriname	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Suriname	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Suriname	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Suriname	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Suriname	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Suriname	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Suriname	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Suriname	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Suriname	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Suriname	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Suriname	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Suriname	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Suriname	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Suriname	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Suriname	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Suriname	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Suriname	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Suriname	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Suriname	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Suriname	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Suriname	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Suriname	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Suriname	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Suriname	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Suriname	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Suriname	INFINITI TX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Suriname	INFINITI TX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Suriname	INFINITI TX35	L50	2012.9-	CAN gateway	√	√	√			
Suriname	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Suriname	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Suriname	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Suriname	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Suriname	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Suriname	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Suriname	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Suriname	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Suriname	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Suriname	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Suriname	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Suriname	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Suriname	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Suriname	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Suriname	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Suriname	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Suriname	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Suriname	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Suriname	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Suriname	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Suriname	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Suriname	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Suriname	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Suriname	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Suriname	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Suriname	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Suriname	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Suriname	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Suriname	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Suriname	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Suriname	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Suriname	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Suriname	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Suriname	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Suriname	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Suriname	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Suriname	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Suriname	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Suriname	INFINITI Q45	F50	2001.8-	Motor control						
Suriname	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Suriname	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Suriname	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Suriname	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Suriname	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Suriname	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Suriname	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Suriname	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Suriname	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Suriname	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Suriname	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Suriname	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Suriname	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Suriname	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Suriname	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Suriname	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Suriname	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Suriname	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Suriname	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Suriname	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Suriname	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Suriname	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Suriname	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Suriname	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Suriname	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Suriname	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Suriname	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Suriname	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Suriname	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Suriname	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Suriname	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Suriname	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Suriname	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Suriname	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Suriname	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Suriname	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Suriname	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Suriname	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Suriname	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Suriname	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Suriname	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Suriname	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Suriname	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Suriname	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Suriname	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Suriname	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Suriname	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Suriname	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Suriname	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Suriname	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Suriname	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Suriname	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Suriname	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Suriname	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Suriname	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Swaziland	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Swaziland	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Swaziland	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Swaziland	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Swaziland	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Swaziland	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Swaziland	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Swaziland	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Swaziland	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Swaziland	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Swaziland	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Swaziland	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Swaziland	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Swaziland	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Swaziland	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Swaziland	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Swaziland	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Swaziland	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Swaziland	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Swaziland	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Swaziland	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Swaziland	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Swaziland	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Swaziland	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Swaziland	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Swaziland	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Swaziland	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Swaziland	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Swaziland	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Swaziland	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Swaziland	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Swaziland	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Swaziland	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Swaziland	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Swaziland	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Swaziland	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Swaziland	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Swaziland	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Swaziland	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Swaziland	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Swaziland	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Swaziland	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Swaziland	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Swaziland	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Swaziland	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Swaziland	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Swaziland	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Swaziland	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Swaziland	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Swaziland	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Swaziland	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Swaziland	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Swaziland	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Swaziland	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Swaziland	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Swaziland	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Swaziland	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Swaziland	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Swaziland	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Swaziland	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Swaziland	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Swaziland	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Swaziland	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Swaziland	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Swaziland	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Swaziland	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Swaziland	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Swaziland	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Swaziland	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Swaziland	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Swaziland	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Swaziland	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Swaziland	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Swaziland	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Swaziland	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Swaziland	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Swaziland	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Swaziland	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Swaziland	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Swaziland	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Swaziland	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Swaziland	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Swaziland	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Swaziland	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Swaziland	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Swaziland	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Swaziland	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Swaziland	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Swaziland	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Swaziland	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Swaziland	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Swaziland	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Swaziland	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Swaziland	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Swaziland	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Swaziland	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Swaziland	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		

Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Swaziland	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Swaziland	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Swaziland	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Swaziland	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Swaziland	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Swaziland	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Swaziland	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Swaziland	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Swaziland	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Swaziland	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Swaziland	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Swaziland	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Swaziland	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Swaziland	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Swaziland	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Swaziland	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Swaziland	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Swaziland	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Swaziland	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Swaziland	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Swaziland	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Swaziland	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Swaziland	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Swaziland	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Swaziland	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Swaziland	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Swaziland	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Swaziland	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Swaziland	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Swaziland	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Swaziland	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Swaziland	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Swaziland	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Swaziland	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Swaziland	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Swaziland	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503

Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Swaziland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Swaziland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Swaziland	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Swaziland	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Swaziland	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Swaziland	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Swaziland	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Swaziland	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Swaziland	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Swaziland	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Swaziland	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Swaziland	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Swaziland	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Swaziland	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Swaziland	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Swaziland	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Swaziland	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Swaziland	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Swaziland	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Swaziland	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Swaziland	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Swaziland	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Swaziland	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Swaziland	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Swaziland	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Swaziland	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Swaziland	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Swaziland	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Swaziland	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Swaziland	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Swaziland	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Swaziland	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Swaziland	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Swaziland	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Swaziland	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Swaziland	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Swaziland	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Swaziland	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Swaziland	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Swaziland	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Swaziland	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Swaziland	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Swaziland	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Swaziland	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Swaziland	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Swaziland	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Swaziland	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Swaziland	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Swaziland	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Swaziland	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Swaziland	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Swaziland	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Swaziland	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Swaziland	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Swaziland	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Swaziland	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Swaziland	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Swaziland	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Swaziland	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Swaziland	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Swaziland	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Swaziland	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Swaziland	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Swaziland	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Swaziland	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Swaziland	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Swaziland	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Swaziland	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Swaziland	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Swaziland	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Swaziland	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Swaziland	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Swaziland	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Swaziland	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Swaziland	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Swaziland	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Swaziland	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Swaziland	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Swaziland	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Swaziland	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Swaziland	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Swaziland	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Swaziland	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Swaziland	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Swaziland	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Swaziland	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Swaziland	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Swaziland	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Swaziland	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Swaziland	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Swaziland	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Swaziland	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Swaziland	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Swaziland	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Swaziland	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Swaziland	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Swaziland	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Swaziland	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Swaziland	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Swaziland	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Swaziland	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Swaziland	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Swaziland	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Swaziland	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Swaziland	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Swaziland	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Swaziland	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Swaziland	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Swaziland	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Swaziland	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Swaziland	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Swaziland	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Swaziland	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Swaziland	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Swaziland	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Swaziland	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Sweden	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Sweden	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sweden	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sweden	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Sweden	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Sweden	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Sweden	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Sweden	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Sweden	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sweden	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Sweden	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sweden	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239

Sweden	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Sweden	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sweden	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Sweden	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Sweden	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sweden	INFINITI EX37	I50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sweden	INFINITI EX37	I50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Sweden	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Sweden	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Sweden	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Sweden	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Sweden	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Sweden	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Sweden	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Sweden	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Sweden	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Sweden	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Sweden	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Sweden	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Sweden	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Sweden	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sweden	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Sweden	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sweden	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Sweden	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Sweden	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sweden	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Sweden	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Sweden	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Sweden	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Sweden	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sweden	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sweden	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Sweden	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Sweden	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Sweden	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sweden	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Sweden	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sweden	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Sweden	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Sweden	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sweden	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Sweden	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Sweden	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Sweden	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	

Sweden	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Sweden	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Sweden	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Sweden	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Sweden	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sweden	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sweden	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Sweden	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sweden	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Sweden	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Sweden	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Sweden	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sweden	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sweden	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Sweden	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Sweden	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Sweden	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Sweden	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sweden	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Sweden	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sweden	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sweden	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Sweden	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sweden	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Sweden	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Sweden	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Sweden	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sweden	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sweden	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Sweden	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Sweden	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Sweden	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Sweden	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Sweden	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Sweden	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Sweden	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Sweden	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Sweden	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Sweden	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Sweden	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Sweden	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Sweden	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Sweden	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Sweden	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537

Sweden	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570,SP0571
Sweden	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Sweden	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Sweden	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Sweden	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sweden	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Sweden	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Sweden	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Sweden	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Sweden	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Sweden	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Sweden	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Sweden	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Sweden	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Sweden	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Sweden	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Sweden	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Sweden	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Sweden	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sweden	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sweden	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sweden	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Sweden	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Sweden	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Sweden	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Sweden	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Sweden	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Sweden	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Sweden	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Sweden	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Sweden	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Sweden	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Sweden	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Sweden	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Sweden	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Sweden	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Sweden	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		

Sweden	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Sweden	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Sweden	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Sweden	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Sweden	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Sweden	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Sweden	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Sweden	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Sweden	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Sweden	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Sweden	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Sweden	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Sweden	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Sweden	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Sweden	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Sweden	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Sweden	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Sweden	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Sweden	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Sweden	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Sweden	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Sweden	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Sweden	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Sweden	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Sweden	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Sweden	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Sweden	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Sweden	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Sweden	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Sweden	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Sweden	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Sweden	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Sweden	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Sweden	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sweden	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Sweden	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Sweden	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Sweden	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Sweden	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sweden	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Sweden	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Sweden	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Sweden	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Sweden	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Sweden	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Sweden	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Sweden	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Sweden	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Sweden	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Sweden	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Sweden	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sweden	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Sweden	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Sweden	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Sweden	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Sweden	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Sweden	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Sweden	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Sweden	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Sweden	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Sweden	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604. SP0605. SP0606
Sweden	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Sweden	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Sweden	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Sweden	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Sweden	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111. AC1112	SP0608. SP0609. SP0610
Sweden	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590. SP0591. SP0592
Sweden	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Sweden	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Sweden	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Sweden	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Sweden	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Sweden	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Sweden	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Sweden	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Sweden	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Sweden	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	

Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Sweden	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Sweden	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Sweden	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Sweden	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Sweden	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Sweden	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Sweden	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Sweden	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Sweden	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Sweden	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Sweden	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Sweden	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Sweden	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Sweden	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Sweden	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Sweden	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Sweden	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Sweden	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Sweden	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Sweden	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Sweden	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Sweden	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Sweden	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Sweden	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Sweden	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Sweden	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Sweden	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Sweden	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Sweden	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Sweden	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Sweden	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Sweden	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Sweden	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Sweden	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Sweden	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Sweden	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Sweden	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Sweden	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543

Sweden	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Sweden	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Sweden	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Sweden	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Sweden	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Sweden	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Sweden	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Sweden	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Sweden	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Sweden	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0247,SP0265,SP0270,SP0274
Sweden	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Sweden	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Sweden	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Sweden	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Sweden	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Sweden	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Sweden	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Sweden	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Sweden	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Sweden	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Sweden	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Sweden	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Sweden	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Sweden	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Sweden	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Sweden	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Sweden	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604,SP0605,SP0606
Sweden	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Sweden	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Sweden	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Sweden	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Sweden	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Sweden	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107,AC1108	
Sweden	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Sweden	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Sweden	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274,SP0276
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084.AC1085.AC1086.AC1087.AC1088.AC1089.AC1106	
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Sweden	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Sweden	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Sweden	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Sweden	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Sweden	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Sweden	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Sweden	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Sweden	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Sweden	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239

Sweden	INFINITI QX50	I50	2013.9-	Transmission	√	√	√	√		SP0274
Sweden	INFINITI QX50	I50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sweden	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Sweden	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI QX50	I50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sweden	INFINITI QX50	I50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sweden	INFINITI QX50	I50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sweden	INFINITI QX50	I50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Sweden	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Sweden	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Sweden	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Sweden	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Sweden	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Sweden	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Sweden	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Sweden	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Sweden	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Sweden	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Sweden	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Sweden	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Sweden	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Sweden	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Sweden	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Sweden	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Sweden	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Sweden	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Sweden	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Sweden	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Sweden	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Sweden	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Sweden	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Sweden	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Sweden	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Sweden	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Sweden	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Sweden	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Sweden	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Sweden	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Sweden	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Sweden	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Sweden	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Sweden	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Sweden	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Sweden	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Sweden	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Sweden	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Sweden	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Sweden	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Sweden	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Sweden	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Sweden	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Sweden	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Sweden	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Sweden	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Sweden	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Sweden	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Sweden	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Sweden	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Sweden	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Sweden	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Sweden	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Sweden	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Sweden	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Sweden	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612

Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Switzerland	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Switzerland	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Switzerland	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Switzerland	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Switzerland	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Switzerland	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Switzerland	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Switzerland	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Switzerland	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Switzerland	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Switzerland	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Switzerland	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Switzerland	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Switzerland	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Switzerland	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Switzerland	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Switzerland	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Switzerland	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Switzerland	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Switzerland	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Switzerland	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Switzerland	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Switzerland	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Switzerland	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Switzerland	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Switzerland	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Switzerland	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Switzerland	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Switzerland	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Switzerland	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Switzerland	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Switzerland	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Switzerland	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Switzerland	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Switzerland	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Switzerland	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Switzerland	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Switzerland	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Switzerland	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274

Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Switzerland	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Switzerland	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Switzerland	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Switzerland	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Switzerland	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Switzerland	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Switzerland	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Switzerland	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Switzerland	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Switzerland	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Switzerland	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Switzerland	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Switzerland	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Switzerland	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Switzerland	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Switzerland	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Switzerland	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Switzerland	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Switzerland	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Switzerland	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Switzerland	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Switzerland	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Switzerland	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Switzerland	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Switzerland	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Switzerland	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Switzerland	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Switzerland	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Switzerland	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Switzerland	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Switzerland	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Switzerland	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Switzerland	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Switzerland	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Switzerland	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Switzerland	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276

Switzerland	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Switzerland	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Switzerland	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Switzerland	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Switzerland	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Switzerland	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Switzerland	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Switzerland	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Switzerland	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Switzerland	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Switzerland	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Switzerland	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Switzerland	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Switzerland	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Switzerland	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Switzerland	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Switzerland	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Switzerland	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Switzerland	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Switzerland	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Switzerland	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Switzerland	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Switzerland	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Switzerland	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Switzerland	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		

Switzerland	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Switzerland	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Switzerland	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Switzerland	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Switzerland	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Switzerland	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Switzerland	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Switzerland	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Switzerland	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Switzerland	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Switzerland	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Switzerland	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Switzerland	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Switzerland	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Switzerland	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Switzerland	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Switzerland	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Switzerland	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Switzerland	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Switzerland	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Switzerland	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Switzerland	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Switzerland	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		

XTOOL

Switzerland	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Switzerland	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Switzerland	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Switzerland	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Switzerland	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Switzerland	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Switzerland	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Switzerland	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Switzerland	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Switzerland	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Switzerland	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Switzerland	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Switzerland	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Switzerland	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Switzerland	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Switzerland	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Switzerland	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Switzerland	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Switzerland	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Switzerland	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Switzerland	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Switzerland	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Switzerland	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Switzerland	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Switzerland	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Switzerland	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Switzerland	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Switzerland	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Switzerland	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Switzerland	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Switzerland	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Switzerland	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Switzerland	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Switzerland	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Switzerland	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Switzerland	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Switzerland	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Switzerland	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Switzerland	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Switzerland	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Switzerland	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Switzerland	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Switzerland	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Switzerland	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Switzerland	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Switzerland	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Switzerland	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	

XTOOL

Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Switzerland	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	

Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Switzerland	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Switzerland	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Switzerland	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Switzerland	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Switzerland	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Switzerland	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Switzerland	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Switzerland	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Switzerland	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Switzerland	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Switzerland	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Switzerland	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Switzerland	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Switzerland	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Switzerland	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Switzerland	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Switzerland	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Switzerland	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Switzerland	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Switzerland	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Switzerland	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Switzerland	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Switzerland	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Switzerland	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Switzerland	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Switzerland	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Switzerland	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Switzerland	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Switzerland	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Switzerland	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Switzerland	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Switzerland	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Switzerland	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Switzerland	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		

Switzerland	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Switzerland	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Switzerland	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Switzerland	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Switzerland	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Switzerland	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Switzerland	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Switzerland	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Switzerland	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Switzerland	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Switzerland	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Switzerland	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		

Switzerland	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Switzerland	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Switzerland	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Switzerland	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Switzerland	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Switzerland	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Switzerland	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Switzerland	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Switzerland	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Switzerland	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Switzerland	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Switzerland	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Switzerland	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Switzerland	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Switzerland	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Switzerland	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Switzerland	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Switzerland	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Switzerland	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Switzerland	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Switzerland	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Switzerland	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Switzerland	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Switzerland	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Switzerland	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	

Switzerland	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Switzerland	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Switzerland	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Switzerland	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Switzerland	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Switzerland	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Switzerland	INFINITI QX50	J50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Switzerland	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI QX50	J50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Switzerland	INFINITI QX50	J50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Switzerland	INFINITI QX50	J50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Switzerland	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Switzerland	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Switzerland	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Switzerland	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Switzerland	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Switzerland	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Switzerland	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Switzerland	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Switzerland	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Switzerland	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Switzerland	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Switzerland	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Switzerland	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Switzerland	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Switzerland	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Switzerland	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Switzerland	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Switzerland	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Switzerland	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Switzerland	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Switzerland	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Switzerland	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Switzerland	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Switzerland	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Switzerland	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Switzerland	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Switzerland	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Switzerland	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Switzerland	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Switzerland	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Switzerland	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Switzerland	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Switzerland	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Switzerland	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Switzerland	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Switzerland	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Switzerland	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Switzerland	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Switzerland	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Switzerland	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Switzerland	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Switzerland	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Switzerland	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Switzerland	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Switzerland	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Switzerland	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Switzerland	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Switzerland	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Switzerland	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Switzerland	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Switzerland	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Switzerland	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Switzerland	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Switzerland	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Switzerland	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Switzerland	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Switzerland	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Syria	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Syria	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Syria	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Syria	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Syria	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Syria	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Syria	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Syria	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Syria	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Syria	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Syria	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Syria	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Syria	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Syria	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Syria	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Syria	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Syria	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Syria	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Syria	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Syria	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Syria	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Syria	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Syria	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Syria	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Syria	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Syria	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Syria	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Syria	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Syria	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Syria	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Syria	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Syria	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Syria	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Syria	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Syria	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Syria	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Syria	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Syria	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Syria	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Syria	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Syria	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Syria	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		

Syria	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Syria	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Syria	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Syria	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Syria	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Syria	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Syria	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Syria	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Syria	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Syria	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Syria	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Syria	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Syria	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Syria	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Syria	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Syria	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Syria	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Syria	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Syria	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Syria	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Syria	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Syria	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Syria	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Syria	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Syria	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Syria	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Syria	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Syria	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Syria	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Syria	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Syria	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Syria	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Syria	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Syria	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Syria	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Syria	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Syria	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Syria	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Syria	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Syria	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Syria	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Syria	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Syria	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Syria	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Syria	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Syria	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Syria	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Syria	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971. AC0972. AC0973	
Syria	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Syria	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Syria	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		

Syria	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Syria	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Syria	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Syria	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Syria	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Syria	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Syria	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Syria	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Syria	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Syria	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Syria	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Syria	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Syria	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Syria	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Syria	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Syria	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Syria	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Syria	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Syria	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Syria	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Syria	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Syria	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Syria	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Syria	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Syria	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Syria	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Syria	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Syria	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Syria	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Syria	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Syria	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Syria	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Syria	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Syria	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Syria	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Syria	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Syria	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Syria	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Syria	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Syria	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Syria	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Syria	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Syria	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Syria	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Syria	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Syria	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Syria	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Syria	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Syria	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Syria	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Syria	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Syria	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Syria	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Syria	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Syria	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Syria	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Syria	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Syria	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Syria	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Syria	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Syria	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Syria	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Syria	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Syria	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Syria	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Syria	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Syria	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Syria	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Syria	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Syria	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Syria	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Syria	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Syria	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Syria	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Syria	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Syria	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Syria	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Syria	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Syria	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Syria	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√	AC0276, AC0278, AC0279	SP0276, SP0278, SP0279
Syria	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Syria	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Syria	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Syria	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Syria	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Syria	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Syria	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Syria	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Syria	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Syria	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Syria	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Syria	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Syria	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Syria	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Syria	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Syria	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Syria	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Syria	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Syria	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Syria	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Syria	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Syria	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Syria	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Syria	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Syria	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Syria	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Syria	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Syria	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Syria	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Syria	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Syria	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Syria	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Syria	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471

Syria	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Syria	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Syria	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Syria	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Syria	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Syria	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Syria	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Syria	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Syria	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Syria	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Syria	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Syria	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Syria	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Syria	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Syria	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Syria	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Syria	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Syria	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Syria	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Syria	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Syria	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Syria	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Syria	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Syria	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Syria	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Syria	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Syria	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Syria	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Syria	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Syria	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Syria	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Syria	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Syria	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Syria	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Syria	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Syria	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Syria	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Syria	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Syria	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Syria	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Syria	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Syria	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Syria	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Syria	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Syria	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Syria	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		

XTOOL

Syria	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Syria	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Syria	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Syria	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Syria	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Syria	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Syria	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Syria	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Syria	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Syria	INFINITI Q45	F50	2001.8-	Motor control						
Syria	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Syria	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Syria	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Syria	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Syria	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Syria	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Syria	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Syria	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Syria	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Syria	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Syria	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Syria	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Syria	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Syria	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Syria	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Syria	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Syria	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Syria	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Syria	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Syria	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Syria	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Syria	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Syria	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Syria	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Syria	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Syria	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Syria	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Syria	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Syria	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Syria	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Syria	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Syria	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Syria	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Syria	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Syria	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Syria	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Syria	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Syria	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Syria	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Syria	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Syria	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Syria	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Syria	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Syria	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Syria	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Syria	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Syria	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Syria	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Syria	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Syria	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Syria	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Syria	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Syria	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Syria	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Syria	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Syria	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Syria	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		

Syria	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Syria	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962. AC0963. AC0964. AC0966. AC0967. AC0968. AC0969. AC0970	SP0553. SP0554. SP0555. SP0556. SP0557. SP0558. SP0559
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Syria	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Syria	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Syria	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Syria	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Syria	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Syria	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Syria	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Syria	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Syria	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Syria	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Syria	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Syria	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Syria	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Syria	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Syria	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Syria	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Syria	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Syria	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Syria	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Syria	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Syria	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Syria	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Syria	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Syria	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Syria	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Syria	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Syria	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Syria	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Syria	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Syria	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Syria	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Syria	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Syria	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Syria	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Syria	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Syria	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Syria	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Syria	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Syria	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Syria	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Syria	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Syria	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Syria	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Syria	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Syria	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Syria	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Syria	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Syria	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Syria	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Syria	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Syria	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Syria	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Syria	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Syria	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Syria	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Syria	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Syria	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Syria	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Syria	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Syria	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Syria	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Syria	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Syria	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Syria	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		

Syria	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Syria	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Syria	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Syria	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Syria	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Syria	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Syria	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Syria	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Syria	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Syria	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Syria	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Syria	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Syria	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Syria	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Syria	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Syria	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Syria	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Syria	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Syria	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Syria	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Syria	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Syria	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Syria	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Syria	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Syria	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Syria	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Syria	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Syria	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Syria	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Syria	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Syria	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Syria	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Syria	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Syria	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Syria	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Syria	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Syria	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Syria	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Syria	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Syria	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Syria	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Syria	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Syria	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Syria	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Syria	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Syria	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Syria	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Syria	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Syria	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Syria	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Syria	INFINITI QX50	J55	2018.5-	Shift						
Syria	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Syria	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	ANC						
Syria	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Syria	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Syria	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		

Syria	INFINITI QX50	I55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Syria	INFINITI QX50	I55	2018.5-	ICC/ADAS 2	√	√	√	√		
Syria	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Syria	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Syria	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Syria	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Syria	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Syria	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Syria	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Syria	INFINITI QX56	JA60	2004.10-	Motor control						
Syria	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Syria	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Syria	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Syria	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Syria	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Syria	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Syria	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Syria	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Syria	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Syria	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Syria	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Syria	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Syria	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Syria	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Syria	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Syria	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Syria	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Syria	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Syria	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Syria	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Syria	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Syria	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Syria	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Syria	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Syria	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Syria	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Syria	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Syria	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Syria	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270, SP0274
Syria	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Syria	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Syria	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Syria	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Syria	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Syria	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Syria	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Syria	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Syria	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Syria	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Syria	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Syria	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Syria	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Syria	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Syria	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Syria	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Syria	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Syria	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Syria	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Syria	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Syria	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Syria	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Syria	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Syria	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Syria	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Syria	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Syria	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Syria	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Syria	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			

Syria	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Syria	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Syria	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Syria	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Syria	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Syria	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Syria	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Syria	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Syria	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0120, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Syria	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Syria	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Syria	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Syria	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Syria	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Syria	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Syria	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Syria	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Syria	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Syria	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Syria	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Syria	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Syria	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Syria	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Syria	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Syria	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Syria	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Syria	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Syria	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Syria	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Syria	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Syria	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Syria	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Syria	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Syria	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Syria	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Syria	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Syria	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Syria	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Syria	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Syria	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Syria	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Syria	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Syria	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Syria	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Syria	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Syria	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Syria	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Syria	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Syria	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Syria	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Syria	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Syria	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Syria	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Syria	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Syria	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Syria	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Syria	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Syria	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Syria	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Syria	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Syria	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Syria	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Syria	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Syria	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Syria	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Syria	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Syria	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Syria	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Syria	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Syria	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Syria	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Syria	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Syria	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tadzhikistan	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tadzhikistan	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tadzhikistan	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tadzhikistan	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tadzhikistan	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tadzhikistan	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tadzhikistan	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tadzhikistan	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Tadzhikistan	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Tadzhikistan	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Tadzhikistan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Tadzhikistan	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Motor control						

Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Tadzhikistan	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Tadzhikistan	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tadzhikistan	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tadzhikistan	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Tadzhikistan	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tadzhikistan	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Tadzhikistan	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Tadzhikistan	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Tadzhikistan	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556

XTOOL

Tadzhikistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Tadzhikistan	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Tadzhikistan	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Tadzhikistan	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tadzhikistan	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Tadzhikistan	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tadzhikistan	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Tadzhikistan	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tadzhikistan	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tadzhikistan	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Tadzhikistan	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Tadzhikistan	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Tadzhikistan	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Tadzhikistan	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Tadzhikistan	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tadzhikistan	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583

Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Tadzhikistan	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Tadzhikistan	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Tadzhikistan	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Tadzhikistan	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Tadzhikistan	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Tadzhikistan	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		

Tadzhikistan	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Tadzhikistan	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Tadzhikistan	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Tadzhikistan	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Tadzhikistan	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Tadzhikistan	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Tadzhikistan	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Tadzhikistan	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Tadzhikistan	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		

Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Tadzhikistan	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Tadzhikistan	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tadzhikistan	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tadzhikistan	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tadzhikistan	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tadzhikistan	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tadzhikistan	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tadzhikistan	INFINITI Q45	F50	2001.8-	Motor control						
Tadzhikistan	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tadzhikistan	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tadzhikistan	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Tadzhikistan	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Tadzhikistan	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Tadzhikistan	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Tadzhikistan	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Tadzhikistan	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tadzhikistan	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tadzhikistan	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tadzhikistan	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Tadzhikistan	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Tadzhikistan	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Tadzhikistan	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Tadzhikistan	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Tadzhikistan	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Tadzhikistan	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Tadzhikistan	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Tadzhikistan	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tadzhikistan	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Tadzhikistan	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Tadzhikistan	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Tadzhikistan	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tadzhikistan	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Tadzhikistan	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tadzhikistan	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Tadzhikistan	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Tadzhikistan	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Tadzhikistan	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tadzhikistan	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tadzhikistan	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Tadzhikistan	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tadzhikistan	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tadzhikistan	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tadzhikistan	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tadzhikistan	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Tadzhikistan	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Tadzhikistan	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Tadzhikistan	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Tadzhikistan	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tadzhikistan	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Tadzhikistan	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Tadzhikistan	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Tadzhikistan	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Tadzhikistan	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Tadzhikistan	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tadzhikistan	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tadzhikistan	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Tadzhikistan	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Tadzhikistan	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Tadzhikistan	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Tadzhikistan	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Tadzhikistan	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Tadzhikistan	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Tadzhikistan	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Tadzhikistan	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Tadzhikistan	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		

Tadzhikistan	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tadzhikistan	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Tadzhikistan	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tadzhikistan	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tadzhikistan	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Tadzhikistan	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Tadzhikistan	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tadzhikistan	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Tadzhikistan	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tadzhikistan	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Tadzhikistan	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Tadzhikistan	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Tadzhikistan	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

XTOOL

Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tadzhikistan	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Tadzhikistan	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Tadzhikistan	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tadzhikistan	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Tadzhikistan	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tadzhikistan	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	

Tadzhikistan	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Tadzhikistan	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Tadzhikistan	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Tadzhikistan	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Tadzhikistan	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Tadzhikistan	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Tadzhikistan	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tadzhikistan	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Tadzhikistan	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tadzhikistan	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Tadzhikistan	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tadzhikistan	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Tadzhikistan	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tadzhikistan	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tadzhikistan	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Tadzhikistan	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Tadzhikistan	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tadzhikistan	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Tadzhikistan	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tadzhikistan	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Tadzhikistan	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tadzhikistan	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Tadzhikistan	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Tadzhikistan	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Tadzhikistan	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Tadzhikistan	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Tadzhikistan	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Tadzhikistan	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI QX50	J55	2018.5-	Shift						
Tadzhikistan	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Tadzhikistan	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	

Tadzhikistan	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	ANC						
Tadzhikistan	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tadzhikistan	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Tadzhikistan	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tadzhikistan	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tadzhikistan	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Motor control						
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tadzhikistan	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tadzhikistan	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Tadzhikistan	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tadzhikistan	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tadzhikistan	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Tadzhikistan	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Tadzhikistan	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Tadzhikistan	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Tadzhikistan	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tadzhikistan	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Tadzhikistan	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270, SP0274
Tadzhikistan	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Tadzhikistan	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Tadzhikistan	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tadzhikistan	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tadzhikistan	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Tadzhikistan	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tadzhikistan	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Tadzhikistan	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tadzhikistan	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Tadzhikistan	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Tadzhikistan	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tadzhikistan	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tadzhikistan	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Tadzhikistan	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Tadzhikistan	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Tadzhikistan	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Tadzhikistan	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Tadzhikistan	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Tadzhikistan	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Tadzhikistan	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tadzhikistan	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tadzhikistan	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Tadzhikistan	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tadzhikistan	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Tadzhikistan	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Tadzhikistan	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Tadzhikistan	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Tadzhikistan	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	

Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Tadzhikistan	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Tadzhikistan	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tadzhikistan	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Tadzhikistan	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tadzhikistan	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Tadzhikistan	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tadzhikistan	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Tadzhikistan	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tadzhikistan	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Tadzhikistan	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Tadzhikistan	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tadzhikistan	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tadzhikistan	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Tadzhikistan	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tadzhikistan	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Tadzhikistan	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			

Tadzhikistan	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tadzhikistan	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tadzhikistan	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tadzhikistan	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Tadzhikistan	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tadzhikistan	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tadzhikistan	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tadzhikistan	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Tadzhikistan	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tadzhikistan	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Tadzhikistan	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Tadzhikistan	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Tadzhikistan	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Tadzhikistan	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tadzhikistan	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Tadzhikistan	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Tadzhikistan	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tadzhikistan	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tadzhikistan	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Tadzhikistan	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Tadzhikistan	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Tadzhikistan	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Taiwan	INFINITI EX35	J50	2007.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI EX35	J50	2007.12-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Taiwan	INFINITI EX35	J50	2007.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI EX35	J50	2007.12-	Air bag	√	√	√	√		
Taiwan	INFINITI EX35	J50	2007.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Taiwan	INFINITI EX35	J50	2007.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Taiwan	INFINITI EX35	J50	2007.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Taiwan	INFINITI EX35	J50	2007.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Taiwan	INFINITI EX35	J50	2007.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI EX35	J50	2007.12-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI EX35	J50	2007.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI EX35	J50	2007.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Taiwan	INFINITI EX35	J50	2007.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI EX35	J50	2007.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Taiwan	INFINITI EX35	J50	2007.12-	All mode AWD/4WD	√	√	√	√	AC0956	
Taiwan	INFINITI EX35	J50	2007.12-	Precrash seatbelt	√	√	√	√		SP0612
Taiwan	INFINITI EX35	J50	2007.12-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Taiwan	INFINITI EX35	J50	2007.12-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI EX35	J50	2007.12-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Taiwan	INFINITI FX35/FX45	S50	2003.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494

Taiwan	INFINITI FX35/FX45	S50	2003.6-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Air bag	√	√	√	√		
Taiwan	INFINITI FX35/FX45	S50	2003.6-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Motor control						
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Taiwan	INFINITI FX35/FX45	S50	2003.6-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Taiwan	INFINITI FX35/FX45	S50	2003.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI FX35/FX45	S50	2003.6-	HVAC	√	√	√	√		
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Difference lock	√	√	√	√		
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Auto slide door	√	√	√	√	AC0941	
Taiwan	INFINITI FX35/FX45	S50	2003.6-	DIU		√	√	√		
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Adaptive light	√	√	√	√		
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Taiwan	INFINITI FX35/FX45	S50	2003.6-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Taiwan	INFINITI FX35/FX45	S50	2003.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Taiwan	INFINITI FX35/FX45	S50	2003.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI FX35/FX45	S50	2003.6-	IVMS	√	√		√		
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Distance control	√	√		√		
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Active suspense system	√	√	√	√		
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Motor assist		√	√	√		SP0574
Taiwan	INFINITI FX35/FX45	S50	2003.6-	ASCD	√	√	√	√		
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Active engine mount	√	√	√	√		
Taiwan	INFINITI FX35/FX45	S50	2003.6-	TCS	√	√	√	√		
Taiwan	INFINITI FX35/FX45	S50	2003.6-	S/blind camera	√			√		SP0572, SP0573
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Nats immu	√	√	√			
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Rearview camera	√			√		SP0570, SP0571
Taiwan	INFINITI FX35/FX45	S50	2003.6-	Smart entrance						SP0568
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Taiwan	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Taiwan	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Taiwan	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Taiwan	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Taiwan	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Taiwan	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Taiwan	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	Air bag	√	√	√	√		
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	Transmission	√	√	√	√		SP0270, SP0274
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	Multi AV	√	√	√	√		
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	Precrash seatbelt	√	√	√	√		
Taiwan	INFINITI G25/G37 SEDAN	V36	2010.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493

Taiwan	INFINITI G35 COUPE	CV35	2005.4-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Air bag	√	√	√	√		
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Motor control						
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	HVAC	√	√	√	√		
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Difference lock	√	√	√	√		
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Auto slide door	√	√	√	√	AC0941	
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	DIU		√	√	√		
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Adaptive light	√	√	√	√		
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	IVMS	√	√		√		
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Distance control	√	√		√		
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Active suspense system	√	√	√	√		
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Motor assist		√	√	√		SP0574
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	ASCD	√	√	√	√		
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Active engine mount	√	√	√	√		
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	TCS	√	√	√	√		
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	S/blind camera	√			√		SP0572, SP0573
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Nats immu	√	√	√			
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Rearview camera	√			√		SP0570, SP0571
Taiwan	INFINITI G35 COUPE	CV35	2005.4-	Smart entrance						SP0568
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Air bag	√	√	√	√		
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Motor control						
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	HVAC	√	√	√	√		
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Difference lock	√	√	√	√		
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Auto slide door	√	√	√	√	AC0941	
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	DIU		√	√	√		
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Adaptive light	√	√	√	√		
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	IVMS	√	√		√		
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Distance control	√	√		√		
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Active suspense system	√	√	√	√		
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Motor assist		√	√	√		SP0574
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	ASCD	√	√	√	√		
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Active engine mount	√	√	√	√		
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	TCS	√	√	√	√		
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	S/blind camera	√			√		SP0572, SP0573
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Nats immu	√	√	√			
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Rearview camera	√			√		SP0570, SP0571
Taiwan	INFINITI G35 SEDAN	V35	2003.1-	Smart entrance						SP0568
Taiwan	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Taiwan	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Taiwan	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Taiwan	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Taiwan	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Taiwan	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Taiwan	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI G35 SEDAN	V36	2006.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Taiwan	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Taiwan	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	Air bag	√	√	√	√		
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	Pop up hood	√	√	√	√		
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	Precrash seatbelt	√	√	√	√		
Taiwan	INFINITI G37 CONVERTIBLE	HV36	2009.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	Air bag	√	√	√	√		
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	Pop up hood	√	√	√	√		
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	Precrash seatbelt	√	√	√	√		
Taiwan	INFINITI G37 COUPE	CV36	2007.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	Air bag	√	√	√	√		
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	Multi AV	√	√	√	√		
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	Precrash seatbelt	√	√	√	√		
Taiwan	INFINITI G37 SEDAN	V36	2008.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI JX35	L50	2012.10-	Laser/radar	√	√	√	√		
Taiwan	INFINITI JX35	L50	2012.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI JX35	L50	2012.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Taiwan	INFINITI JX35	L50	2012.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI JX35	L50	2012.10-	Air bag	√	√	√	√		
Taiwan	INFINITI JX35	L50	2012.10-	EPS/DAST 3	√	√	√	√		
Taiwan	INFINITI JX35	L50	2012.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Taiwan	INFINITI JX35	L50	2012.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI JX35	L50	2012.10-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Taiwan	INFINITI JX35	L50	2012.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Taiwan	INFINITI JX35	L50	2012.10-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Taiwan	INFINITI JX35	L50	2012.10-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI JX35	L50	2012.10-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Taiwan	INFINITI JX35	L50	2012.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI JX35	L50	2012.10-	Auto back door	√	√	√	√		SP0611
Taiwan	INFINITI JX35	L50	2012.10-	Occupant detection			√	√		SP0584
Taiwan	INFINITI JX35	L50	2012.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI JX35	L50	2012.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Taiwan	INFINITI JX35	L50	2012.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Taiwan	INFINITI JX35	L50	2012.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI JX35	L50	2012.10-	CAN gateway	√	√	√			
Taiwan	INFINITI JX35	L50	2012.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Taiwan	INFINITI JX35	L50	2012.10-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI JX35	L50	2012.10-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI M25/M37	Y51	2010.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Taiwan	INFINITI M25/M37	Y51	2010.5-	Laser/radar	√	√	√	√		
Taiwan	INFINITI M25/M37	Y51	2010.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI M25/M37	Y51	2010.5-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Taiwan	INFINITI M25/M37	Y51	2010.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Taiwan	INFINITI M25/M37	Y51	2010.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI M25/M37	Y51	2010.5-	Air bag	√	√	√	√		
Taiwan	INFINITI M25/M37	Y51	2010.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Taiwan	INFINITI M25/M37	Y51	2010.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Taiwan	INFINITI M25/M37	Y51	2010.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Taiwan	INFINITI M25/M37	Y51	2010.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Taiwan	INFINITI M25/M37	Y51	2010.5-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI M25/M37	Y51	2010.5-	Pop up hood	√	√	√	√		
Taiwan	INFINITI M25/M37	Y51	2010.5-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI M25/M37	Y51	2010.5-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Taiwan	INFINITI M25/M37	Y51	2010.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Taiwan	INFINITI M25/M37	Y51	2010.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Taiwan	INFINITI M25/M37	Y51	2010.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI M25/M37	Y51	2010.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Taiwan	INFINITI M25/M37	Y51	2010.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI M25/M37	Y51	2010.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Taiwan	INFINITI M25/M37	Y51	2010.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Taiwan	INFINITI M25/M37	Y51	2010.5-	Precrash seatbelt	√	√	√	√		SP0612
Taiwan	INFINITI M25/M37	Y51	2010.5-	CAN gateway	√	√	√			
Taiwan	INFINITI M25/M37	Y51	2010.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Taiwan	INFINITI M25/M37	Y51	2010.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI M25/M37	Y51	2010.5-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI M25/M37	Y51	2010.5-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI M35/M45	Y50	2005.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Taiwan	INFINITI M35/M45	Y50	2005.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Taiwan	INFINITI M35/M45	Y50	2005.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Taiwan	INFINITI M35/M45	Y50	2005.4-	Air bag	√	√	√	√		
Taiwan	INFINITI M35/M45	Y50	2005.4-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Taiwan	INFINITI M35/M45	Y50	2005.4-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Taiwan	INFINITI M35/M45	Y50	2005.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Taiwan	INFINITI M35/M45	Y50	2005.4-	BCM					AC0653, AC0698	SP0391, SP0393
Taiwan	INFINITI M35/M45	Y50	2005.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI M35/M45	Y50	2005.4-	Multi AV	√	√	√	√		
Taiwan	INFINITI M35/M45	Y50	2005.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI M35/M45	Y50	2005.4-	Adaptive light	√	√	√	√		SP0561, SP0562
Taiwan	INFINITI M35/M45	Y50	2005.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Taiwan	INFINITI M35/M45	Y50	2005.4-	All mode AWD/4WD	√	√	√	√	AC0957	
Taiwan	INFINITI M35/M45	Y50	2005.4-	Precrash seatbelt	√	√	√	√		
Taiwan	INFINITI M35/M45	Y50	2005.4-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Taiwan	INFINITI M35/M45	Y50	2005.4-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Taiwan	INFINITI M35/M45	Y50	2005.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI M35/M45	Y50	2005.4-	Rearview camera	√			√		SP0570, SP0571
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Laser/radar	√	√	√	√		
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Air bag	√	√	√	√		
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Transmission	√	√	√	√		SP0274
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Precrash seatbelt	√	√	√	√		SP0612
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	CAN gateway	√	√	√			
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI M37/M56/M30D	Y51	2012.7-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI Q30	H15	2016.1-	Air pressure monitor	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	Air bag	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	EPS/DAST 3	√	√	√			
Taiwan	INFINITI Q30	H15	2016.1-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Taiwan	INFINITI Q30	H15	2016.1-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Taiwan	INFINITI Q30	H15	2016.1-	EHS/PKB	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	Transmission	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Taiwan	INFINITI Q30	H15	2016.1-	ABS	√	√	√	√		SP0308
Taiwan	INFINITI Q30	H15	2016.1-	Multi AV	√	√	√	√		SP0501
Taiwan	INFINITI Q30	H15	2016.1-	HVAC	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	Auto drive position	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	Shift	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	All mode AWD/4WD	√	√	√	√		

XTOOL

Taiwan	INFINITI Q30	H15	2016.1-	AVM	√	√		√		
Taiwan	INFINITI Q30	H15	2016.1-	Intelligent key	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	CAN gateway	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	ANC	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	Telematics	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	FSCM	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	Siren control unit	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Taiwan	INFINITI Q30	H15	2016.1-	Overhead Control Panel Unit	√			√		
Taiwan	INFINITI Q30	H15	2016.1-	Universal Garage Door Opener	√			√		
Taiwan	INFINITI Q30	H15	2016.1-	Upper control panel cont unit	√					
Taiwan	INFINITI Q30	H15	2016.1-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Taiwan	INFINITI Q30	H15	2016.1-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Taiwan	INFINITI Q30	H15	2016.1-	Light/Rain Sensor Module	√			√		
Taiwan	INFINITI Q30	H15	2016.1-	EC Mirror Compass	√					
Taiwan	INFINITI Q30	H15	2016.1-	Intelligent Battery Sensor	√					
Taiwan	INFINITI Q30	H15	2016.1-	Alarm siren	√			√		
Taiwan	INFINITI Q30	H15	2016.1-	Radar sensor	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	Steering column cont module	√	√	√			
Taiwan	INFINITI Q30	H15	2016.1-	ICC sensor	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	Trailer recognition control unit	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	H/L control module LH	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	Powertrain cont module	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	Side radar LH	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	LED H/L control module LH	√			√		
Taiwan	INFINITI Q30	H15	2016.1-	Steering Wheel Switch Pad	√			√		
Taiwan	INFINITI Q30	H15	2016.1-	Parking assist	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	Occupant Classification Unit	√			√		
Taiwan	INFINITI Q30	H15	2016.1-	Electronic Ignition Switch cont unit	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	H/L control module RH	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	Front camera unit	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	Side radar RH	√	√	√	√		
Taiwan	INFINITI Q30	H15	2016.1-	LED H/L control module RH	√			√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Taiwan	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Taiwan	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Taiwan	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Taiwan	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Taiwan	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Taiwan	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Taiwan	INFINITI Q45	F50	ALL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Taiwan	INFINITI Q45	F50	ALL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Taiwan	INFINITI Q45	F50	ALL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Taiwan	INFINITI Q45	F50	ALL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Taiwan	INFINITI Q45	F50	ALL	Air bag	√	√	√	√		
Taiwan	INFINITI Q45	F50	ALL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Taiwan	INFINITI Q45	F50	ALL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Taiwan	INFINITI Q45	F50	ALL	Motor control						
Taiwan	INFINITI Q45	F50	ALL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Taiwan	INFINITI Q45	F50	ALL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Taiwan	INFINITI Q45	F50	ALL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Taiwan	INFINITI Q45	F50	ALL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI Q45	F50	ALL	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI Q45	F50	ALL	HVAC	√	√	√	√		
Taiwan	INFINITI Q45	F50	ALL	Difference lock	√	√	√	√		
Taiwan	INFINITI Q45	F50	ALL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI Q45	F50	ALL	Auto slide door	√	√	√	√	AC0941	
Taiwan	INFINITI Q45	F50	ALL	DIU		√	√	√		
Taiwan	INFINITI Q45	F50	ALL	Adaptive light	√	√	√	√		
Taiwan	INFINITI Q45	F50	ALL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Taiwan	INFINITI Q45	F50	ALL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Taiwan	INFINITI Q45	F50	ALL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI Q45	F50	ALL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Taiwan	INFINITI Q45	F50	ALL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Taiwan	INFINITI Q45	F50	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI Q45	F50	ALL	IVMS	√	√		√		
Taiwan	INFINITI Q45	F50	ALL	Distance control	√	√		√		
Taiwan	INFINITI Q45	F50	ALL	Active suspense system	√	√	√	√		
Taiwan	INFINITI Q45	F50	ALL	Motor assist		√	√	√		SP0574
Taiwan	INFINITI Q45	F50	ALL	ASCD	√	√	√	√		
Taiwan	INFINITI Q45	F50	ALL	Active engine mount	√	√	√	√		
Taiwan	INFINITI Q45	F50	ALL	TCS	√	√	√	√		
Taiwan	INFINITI Q45	F50	ALL	S/blind camera	√			√		SP0572, SP0573
Taiwan	INFINITI Q45	F50	ALL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Taiwan	INFINITI Q45	F50	ALL	Nats immu	√	√	√			
Taiwan	INFINITI Q45	F50	ALL	Rearview camera	√			√		SP0570, SP0571
Taiwan	INFINITI Q45	F50	ALL	Smart entrance						SP0568
Taiwan	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Taiwan	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Taiwan	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Taiwan	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Taiwan	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Taiwan	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Taiwan	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Taiwan	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Taiwan	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Taiwan	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Taiwan	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Taiwan	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Taiwan	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Taiwan	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Taiwan	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Taiwan	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Taiwan	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Taiwan	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Taiwan	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Taiwan	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Taiwan	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Taiwan	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Taiwan	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Taiwan	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√			
Taiwan	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Taiwan	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Taiwan	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Taiwan	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Taiwan	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Taiwan	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Taiwan	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Taiwan	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Taiwan	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Taiwan	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI Q50	V37	2013.6-	CAN monitor unit	√	√	√	√		
Taiwan	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Taiwan	INFINITI Q50	V37	2013.6-	HDmap	√	√	√	√		
Taiwan	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Taiwan	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Taiwan	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Taiwan	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Taiwan	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	

Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Taiwan	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Laser/radar	√	√	√	√		
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Air bag	√	√	√	√		
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	EPS/DAST 3	√	√	√	√		
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Motor control	√	√	√	√		
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Transmission	√	√	√	√		SP0276
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Pop up hood	√	√	√	√		
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	HV battery	√	√	√	√	AC1121	
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Occupant detection			√	√		SP0584
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	DAST 2	√	√	√	√		
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Precrash seatbelt	√	√	√	√		SP0612
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	DAST 1	√	√	√	√		
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	ANC	√	√	√	√	AC1024	
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	HIGH BEAM ASSIST	√	√	√	√		
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	CAN monitor unit	√	√	√	√		
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	VSP	√	√	√	√		
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	Brake	√	√	√	√	AC1127	
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	HDmap	√	√	√	√		
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	6ch CAN GATEWAY	√	√	√	√		
Taiwan	INFINITI Q50 Hybrid	HV37	2018.9-	ICC/ADAS 2	√	√	√	√		
Taiwan	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Taiwan	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Taiwan	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Taiwan	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Taiwan	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Taiwan	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Taiwan	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Taiwan	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Taiwan	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Taiwan	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Taiwan	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Taiwan	INFINITI Q60	CV37	2016.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Taiwan	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Taiwan	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Taiwan	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Taiwan	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Taiwan	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Taiwan	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Taiwan	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI Q60	CV37	2016.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Taiwan	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Taiwan	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Taiwan	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Taiwan	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Taiwan	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Taiwan	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Taiwan	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Taiwan	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Taiwan	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		

Taiwan	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Taiwan	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Taiwan	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Air bag	√	√	√	√		
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Transmission	√	√	√	√		SP0274
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Pop up hood	√	√	√	√		
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Taiwan	INFINITI Q60 CONVERTIBLE	HV36	2013.9-	Precrash seatbelt	√	√	√	√		
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	Laser/radar	√	√	√	√	AC0994	
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	Air bag	√	√	√	√		
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	Transmission	√	√	√	√		SP0274
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	Pop up hood	√	√	√	√		
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980	SP0561. SP0562
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553. SP0554. SP0555. SP0556
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956. AC0957. AC0958. AC0959. AC0960	SP0544. SP0545. SP0546. SP0547. SP0548. SP0549. SP0550. SP0551
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	Precrash seatbelt	√	√	√	√		
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI Q60 COUPE	CV36	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Taiwan	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Taiwan	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Taiwan	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Taiwan	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Taiwan	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348. SP0349. SP0350. SP0351
Taiwan	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Taiwan	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Taiwan	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0247. SP0265. SP0274. SP0276
Taiwan	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613. AC0618. AC0663. AC0690. AC0692. AC0702	SP0372. SP0429. SP0471
Taiwan	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Taiwan	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Taiwan	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Taiwan	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Taiwan	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Taiwan	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Taiwan	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Taiwan	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Taiwan	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Taiwan	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Taiwan	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Taiwan	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Taiwan	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Taiwan	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Taiwan	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Taiwan	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Taiwan	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590. SP0591. SP0592
Taiwan	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Taiwan	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Taiwan	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Taiwan	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Taiwan	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Taiwan	INFINITI QX50	J50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Taiwan	INFINITI QX50	J50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Taiwan	INFINITI QX50	J50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI QX50	J50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Taiwan	INFINITI QX50	J50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI QX50	J50	2013.7-	Air bag	√	√	√	√		
Taiwan	INFINITI QX50	J50	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Taiwan	INFINITI QX50	J50	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Taiwan	INFINITI QX50	J50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Taiwan	INFINITI QX50	J50	2013.7-	Transmission	√	√	√	√		SP0274
Taiwan	INFINITI QX50	J50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Taiwan	INFINITI QX50	J50	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Taiwan	INFINITI QX50	J50	2013.7-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI QX50	J50	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI QX50	J50	2013.7-	Occupant detection			√	√		SP0584
Taiwan	INFINITI QX50	J50	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Taiwan	INFINITI QX50	J50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI QX50	J50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Taiwan	INFINITI QX50	J50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Taiwan	INFINITI QX50	J50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Taiwan	INFINITI QX50	J50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI QX50	J50	2013.7-	CAN gateway	√	√	√	√		
Taiwan	INFINITI QX50	J50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Taiwan	INFINITI QX50	J50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Taiwan	INFINITI QX50	J50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI QX50	J50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Taiwan	INFINITI QX50	J50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Taiwan	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Taiwan	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Taiwan	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Taiwan	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Taiwan	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Taiwan	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Taiwan	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Taiwan	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Taiwan	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Taiwan	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Taiwan	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Taiwan	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Taiwan	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Taiwan	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Taiwan	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Taiwan	INFINITI QX50	J55	2018.5-	Shift						
Taiwan	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Taiwan	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Taiwan	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Taiwan	INFINITI QX50	I55	2018.5-	DAST 2	√	√	√	√		
Taiwan	INFINITI QX50	I55	2018.5-	AVM	√	√	√	√	AC0983. AC0984. AC0985. AC0986. AC0987. AC0988. AC0989. AC0990	SP0563. SP0564. SP0565. SP0566. SP0567
Taiwan	INFINITI QX50	I55	2018.5-	CAN gateway	√	√	√	√		
Taiwan	INFINITI QX50	I55	2018.5-	Lane camera	√	√	√	√		
Taiwan	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Taiwan	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Taiwan	INFINITI QX50	J55	2018.5-	ANC						
Taiwan	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Taiwan	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Taiwan	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Taiwan	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Taiwan	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Taiwan	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Taiwan	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Taiwan	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Taiwan	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Taiwan	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Taiwan	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Taiwan	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Taiwan	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Taiwan	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Taiwan	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Taiwan	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Taiwan	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Taiwan	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Taiwan	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Taiwan	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Taiwan	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Taiwan	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Taiwan	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Taiwan	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Taiwan	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Taiwan	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Taiwan	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971. AC0972. AC0973. AC0974. AC0975. AC0976. AC0977	SP0560
Taiwan	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014. AC1015. AC1016. AC1017. AC1018. AC1019. AC1020. AC1021	
Taiwan	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Taiwan	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Taiwan	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Taiwan	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Taiwan	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Taiwan	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	

Taiwan	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Taiwan	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Taiwan	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Taiwan	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Taiwan	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Taiwan	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Taiwan	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Taiwan	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Taiwan	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Taiwan	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Taiwan	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Taiwan	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Taiwan	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Taiwan	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Taiwan	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Taiwan	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Taiwan	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Taiwan	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Taiwan	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Taiwan	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Taiwan	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Taiwan	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Taiwan	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Taiwan	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Taiwan	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Taiwan	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Taiwan	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Taiwan	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Taiwan	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Taiwan	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Taiwan	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Taiwan	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Taiwan	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Taiwan	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Taiwan	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Taiwan	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Tanzania	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tanzania	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tanzania	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Tanzania	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tanzania	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tanzania	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Tanzania	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tanzania	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tanzania	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tanzania	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tanzania	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tanzania	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tanzania	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Tanzania	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Tanzania	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Tanzania	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Tanzania	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tanzania	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Tanzania	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Tanzania	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tanzania	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tanzania	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Tanzania	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Tanzania	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tanzania	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Tanzania	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Tanzania	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

XTOOL

Tanzania	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Tanzania	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tanzania	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Tanzania	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Tanzania	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Tanzania	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Tanzania	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Tanzania	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Tanzania	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Tanzania	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Tanzania	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
Tanzania	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Tanzania	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Tanzania	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Tanzania	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Tanzania	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Tanzania	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Tanzania	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Tanzania	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Tanzania	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Tanzania	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Tanzania	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Tanzania	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Tanzania	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Tanzania	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Tanzania	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tanzania	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Tanzania	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Tanzania	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Tanzania	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546,AC0547,AC0548,AC0549	SP0342,SP0343,SP0344
Tanzania	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002,AC0103,AC0214,AC0264,AC0265,AC0266,AC0267,AC0268,AC0269,AC0270,AC0271,AC0272,AC0273,AC0274,AC0275,AC0276,AC0277,AC0308,AC0310,AC0311,AC0312,AC0314,AC0315,AC0317,AC0320,AC0325,AC0327,AC0328,AC0329,AC0330,AC0331,AC0332	SP0034,SP0035,SP0159,SP0193,SP0194
Tanzania	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580,AC0674,AC0739,AC0740,AC0741,AC0742,AC0743,AC0744,AC0745,AC0746,AC0747,AC0748,AC0749,AC0750,AC0751,AC0752,AC0753,AC0754,AC0755,AC0756,AC0757,AC0758,AC0759,AC0760,AC0761,AC0762,AC0763,AC0764,AC0765,AC0766,AC0767,AC0768,AC0769,AC0770	
Tanzania	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Tanzania	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Tanzania	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Tanzania	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143,AC1144,AC1145,AC1146,AC1147,AC1148,AC1149,AC1150,AC1151,AC1152,AC1153,AC1154,AC1155,AC1156	
Tanzania	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Tanzania	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Tanzania	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Tanzania	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171,AC1172,AC1173,AC1174,AC1175	
Tanzania	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157,AC1158,AC1159,AC1160,AC1161,AC1162,AC1163,AC1164,AC1165,AC1166,AC1167,AC1168,AC1169,AC1170	SP0622
Tanzania	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Tanzania	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Tanzania	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Tanzania	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Tanzania	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Tanzania	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Tanzania	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Tanzania	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Tanzania	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Tanzania	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Tanzania	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Tanzania	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Tanzania	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Tanzania	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Tanzania	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Tanzania	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Tanzania	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Tanzania	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Tanzania	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0274
Tanzania	INFINITI Q50	V37	2013.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Tanzania	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
Tanzania	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Tanzania	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503

Tanzania	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tanzania	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tanzania	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tanzania	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Tanzania	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Tanzania	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tanzania	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Tanzania	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Tanzania	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Tanzania	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Tanzania	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tanzania	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Tanzania	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tanzania	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tanzania	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Tanzania	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Tanzania	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Tanzania	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tanzania	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Tanzania	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Tanzania	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tanzania	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tanzania	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Tanzania	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Tanzania	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Tanzania	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Tanzania	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tanzania	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Tanzania	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tanzania	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tanzania	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Tanzania	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Tanzania	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tanzania	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tanzania	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Tanzania	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tanzania	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tanzania	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Tanzania	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tanzania	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tanzania	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tanzania	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Tanzania	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tanzania	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tanzania	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Tanzania	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Tanzania	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Tanzania	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Tanzania	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Tanzania	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Tanzania	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Tanzania	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tanzania	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Tanzania	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Tanzania	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Tanzania	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Tanzania	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tanzania	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tanzania	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Tanzania	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Tanzania	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Tanzania	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Tanzania	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	

Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Tanzania	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Tanzania	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tanzania	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Tanzania	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Tanzania	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Tanzania	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Tanzania	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Tanzania	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Tanzania	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Tanzania	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Tanzania	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Tanzania	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Tanzania	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Tanzania	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Tanzania	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Tanzania	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Tanzania	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946.AC0947.AC0948.AC0950.AC0951.AC0952.AC0953.AC0954.AC0955	SP0541.SP0542.SP0543
Tanzania	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Tanzania	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978.AC0979.AC0980.AC0981.AC0982	SP0561.SP0562
Tanzania	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Tanzania	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0555,SP0556,SP0557
Tanzania	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Tanzania	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Tanzania	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Tanzania	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Tanzania	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Tanzania	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tanzania	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Tanzania	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Tanzania	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Tanzania	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Tanzania	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Tanzania	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Tanzania	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497

Tanzania	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Tanzania	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Tanzania	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Tanzania	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Tanzania	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0223, SP0225, SP0237, SP0238, SP0239
Tanzania	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Tanzania	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tanzania	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tanzania	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tanzania	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tanzania	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tanzania	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tanzania	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Tanzania	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Tanzania	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tanzania	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Tanzania	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tanzania	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021,AC1022,AC1023	
Tanzania	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Tanzania	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tanzania	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Tanzania	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tanzania	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Tanzania	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tanzania	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tanzania	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Tanzania	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Tanzania	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tanzania	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tanzania	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Tanzania	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tanzania	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Tanzania	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Tanzania	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tanzania	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tanzania	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tanzania	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Tanzania	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Tanzania	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tanzania	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tanzania	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tanzania	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Tanzania	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Tanzania	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tanzania	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Tanzania	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tanzania	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tanzania	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tanzania	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Tanzania	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Tanzania	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tanzania	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Tanzania	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Tanzania	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tanzania	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Tanzania	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tanzania	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tanzania	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tanzania	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Tanzania	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Tanzania	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tanzania	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tanzania	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Tanzania	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tanzania	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Tanzania	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Tanzania	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Tanzania	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Tanzania	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tanzania	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Tanzania	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Tanzania	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tanzania	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tanzania	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Tanzania	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Tanzania	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Tanzania	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Tanzania	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Tanzania	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tanzania	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tanzania	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Tanzania	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tanzania	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Tanzania	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Tanzania	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Tanzania	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Tanzania	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Thailand	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Thailand	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Thailand	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Thailand	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Thailand	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Thailand	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Thailand	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Thailand	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Thailand	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Thailand	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Thailand	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Thailand	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Thailand	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Thailand	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Thailand	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Thailand	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Thailand	INFINITI Q45	F50	ALL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Thailand	INFINITI Q45	F50	ALL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Thailand	INFINITI Q45	F50	ALL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Thailand	INFINITI Q45	F50	ALL	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Thailand	INFINITI Q45	F50	ALL	Air bag	√	√	√	√		
Thailand	INFINITI Q45	F50	ALL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Thailand	INFINITI Q45	F50	ALL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Thailand	INFINITI Q45	F50	ALL	Motor control						
Thailand	INFINITI Q45	F50	ALL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Thailand	INFINITI Q45	F50	ALL	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Thailand	INFINITI Q45	F50	ALL	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Thailand	INFINITI Q45	F50	ALL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Thailand	INFINITI Q45	F50	ALL	Multi AV	√	√	√	√		SP0503
Thailand	INFINITI Q45	F50	ALL	HVAC	√	√	√	√		
Thailand	INFINITI Q45	F50	ALL	Difference lock	√	√	√	√		
Thailand	INFINITI Q45	F50	ALL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Thailand	INFINITI Q45	F50	ALL	Auto slide door	√	√	√	√	AC0941	
Thailand	INFINITI Q45	F50	ALL	DIU		√	√	√		
Thailand	INFINITI Q45	F50	ALL	Adaptive light	√	√	√	√		
Thailand	INFINITI Q45	F50	ALL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559

XTOOL

Thailand	INFINITI Q45	F50	ALL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Thailand	INFINITI Q45	F50	ALL	AVM	√	√	√	√	AC0983、AC0984、AC0985、AC0986、AC0987、AC0988、AC0989、AC0990	SP0563、SP0564、SP0565、SP0566、SP0567
Thailand	INFINITI Q45	F50	ALL	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Thailand	INFINITI Q45	F50	ALL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Thailand	INFINITI Q45	F50	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Thailand	INFINITI Q45	F50	ALL	IVMS	√	√		√		
Thailand	INFINITI Q45	F50	ALL	Distance control	√	√		√		
Thailand	INFINITI Q45	F50	ALL	Active suspense system	√	√	√	√		
Thailand	INFINITI Q45	F50	ALL	Motor assist		√	√	√		SP0574
Thailand	INFINITI Q45	F50	ALL	ASCD	√	√	√	√		
Thailand	INFINITI Q45	F50	ALL	Active engine mount	√	√	√	√		
Thailand	INFINITI Q45	F50	ALL	TCS	√	√	√	√		
Thailand	INFINITI Q45	F50	ALL	S/blind camera	√			√		SP0572, SP0573
Thailand	INFINITI Q45	F50	ALL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Thailand	INFINITI Q45	F50	ALL	Nats immu	√	√	√			
Thailand	INFINITI Q45	F50	ALL	Rearview camera	√			√		SP0570, SP0571
Thailand	INFINITI Q45	F50	ALL	Smart entrance						SP0568
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√		
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0983、AC0984、AC0985、AC0986、AC0987、AC0988、AC0989、AC0990	SP0563、SP0564、SP0565、SP0566、SP0567
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Thailand	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Tinian island	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Air bag	√	√	√	√		
Tinian island	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	
Tinian island	INFINITI EX35	J50	2008.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI EX35	J50	2008.NULL-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI EX35	J50	2008.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI EX35	J50	2008.NULL-	Air bag	√	√	√	√		
Tinian island	INFINITI EX35	J50	2008.NULL-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tinian island	INFINITI EX35	J50	2008.NULL-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tinian island	INFINITI EX35	J50	2008.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tinian island	INFINITI EX35	J50	2008.NULL-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tinian island	INFINITI EX35	J50	2008.NULL-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI EX35	J50	2008.NULL-	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI EX35	J50	2008.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI EX35	J50	2008.NULL-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI EX35	J50	2008.NULL-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI EX35	J50	2008.NULL-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tinian island	INFINITI EX35	J50	2008.NULL-	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI EX35	J50	2008.NULL-	CAN gateway	√	√	√			
Tinian island	INFINITI EX35	J50	2008.NULL-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Tinian island	INFINITI EX35	J50	2008.NULL-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Tinian island	INFINITI EX35	J50	2008.NULL-	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI EX35	J50	2008.NULL-	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI EX35	J50	2008.NULL-	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI FX35/FX45	S50	2003.NULL-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI FX35/FX45	S50	2003.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tinian island	INFINITI FX35/FX45	S50	2003.NULL-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI FX35/FX45	S50	2003.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tinian island	INFINITI FX35/FX45	S50	2003.NULL-	Air bag	√	√	√	√		
Tinian island	INFINITI FX35/FX45	S50	2003.NULL-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tinian island	INFINITI FX35/FX45	S50	2003.NULL-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349

Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Motor control						
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	HVAC	√	√	√	√		
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Auto slide door	√	√	√	√	AC0941	
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	DIU		√	√	√		
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Adaptive light	√	√	√	√		
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	IVMS	√	√		√		
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Distance control	√	√		√		
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Active suspense system	√	√	√	√		
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Motor assist		√	√	√		SP0574
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	ASCD	√	√	√	√		
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Active engine mount	√	√	√	√		
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	TCS	√	√	√	√		
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	S/blind camera	√			√		SP0572, SP0573
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Nats immu	√	√	√			
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI FX35/FX45	S50	2003.NULL –	Smart entrance						SP0568
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0045, SP0051, SP0053, SP0063, SP0064, SP0074, SP0079, SP0083, SP0085, SP0086, SP0087, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0225, SP0239
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Auto back door	√	√	√	√		SP0611
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Occupant detection			√	√		SP0584
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	CAN gateway	√	√	√			
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI FX35/FX50	S51	2009.NULL –	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350

XTOOL

Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Transmission	√	√	√	√		SP0274
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Auto back door	√	√	√	√		SP0611
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Occupant detection			√	√		SP0584
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	CAN gateway	√	√	√			
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Tinian island	INFINITI FX37/FX50	S51	2013.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI G20	CA33	2002.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI G20	CA33	2002.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tinian island	INFINITI G20	CA33	2002.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI G20	CA33	2002.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tinian island	INFINITI G20	CA33	2002.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI G20	CA33	2002.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tinian island	INFINITI G20	CA33	2002.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tinian island	INFINITI G20	CA33	2002.NULL –	Motor control						
Tinian island	INFINITI G20	CA33	2002.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI G20	CA33	2002.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tinian island	INFINITI G20	CA33	2002.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tinian island	INFINITI G20	CA33	2002.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI G20	CA33	2002.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI G20	CA33	2002.NULL –	HVAC	√	√	√	√		
Tinian island	INFINITI G20	CA33	2002.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI G20	CA33	2002.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI G20	CA33	2002.NULL –	Auto slide door	√	√	√	√	AC0941	
Tinian island	INFINITI G20	CA33	2002.NULL –	DIU		√	√	√		
Tinian island	INFINITI G20	CA33	2002.NULL –	Adaptive light	√	√	√	√		
Tinian island	INFINITI G20	CA33	2002.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI G20	CA33	2002.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tinian island	INFINITI G20	CA33	2002.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI G20	CA33	2002.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tinian island	INFINITI G20	CA33	2002.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tinian island	INFINITI G20	CA33	2002.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI G20	CA33	2002.NULL –	IVMS	√	√		√		
Tinian island	INFINITI G20	CA33	2002.NULL –	Distance control	√	√		√		
Tinian island	INFINITI G20	CA33	2002.NULL –	Active suspense system	√	√	√	√		
Tinian island	INFINITI G20	CA33	2002.NULL –	Motor assist		√	√	√		SP0574
Tinian island	INFINITI G20	CA33	2002.NULL –	ASCD	√	√	√	√		
Tinian island	INFINITI G20	CA33	2002.NULL –	Active engine mount	√	√	√	√		
Tinian island	INFINITI G20	CA33	2002.NULL –	TCS	√	√	√	√		
Tinian island	INFINITI G20	CA33	2002.NULL –	S/blind camera	√			√		SP0572, SP0573
Tinian island	INFINITI G20	CA33	2002.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tinian island	INFINITI G20	CA33	2002.NULL –	Nats immu	√	√	√			
Tinian island	INFINITI G20	CA33	2002.NULL –	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI G20	CA33	2002.NULL –	Smart entrance						SP0568
Tinian island	INFINITI G20	P11	1999.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI G20	P11	1999.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493

Tinian island	INFINITI G20	P11	1999.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI G20	P11	1999.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tinian island	INFINITI G20	P11	1999.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI G20	P11	1999.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tinian island	INFINITI G20	P11	1999.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tinian island	INFINITI G20	P11	1999.NULL –	Motor control						
Tinian island	INFINITI G20	P11	1999.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI G20	P11	1999.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tinian island	INFINITI G20	P11	1999.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tinian island	INFINITI G20	P11	1999.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI G20	P11	1999.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI G20	P11	1999.NULL –	HVAC	√	√	√	√		
Tinian island	INFINITI G20	P11	1999.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI G20	P11	1999.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI G20	P11	1999.NULL –	Auto slide door	√	√	√	√	AC0941	
Tinian island	INFINITI G20	P11	1999.NULL –	DIU		√	√	√		
Tinian island	INFINITI G20	P11	1999.NULL –	Adaptive light	√	√	√	√		
Tinian island	INFINITI G20	P11	1999.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI G20	P11	1999.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tinian island	INFINITI G20	P11	1999.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI G20	P11	1999.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tinian island	INFINITI G20	P11	1999.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tinian island	INFINITI G20	P11	1999.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI G20	P11	1999.NULL –	IVMS	√	√		√		
Tinian island	INFINITI G20	P11	1999.NULL –	Distance control	√	√		√		
Tinian island	INFINITI G20	P11	1999.NULL –	Active suspense system	√	√	√	√		
Tinian island	INFINITI G20	P11	1999.NULL –	Motor assist		√	√	√		SP0574
Tinian island	INFINITI G20	P11	1999.NULL –	ASCD	√	√	√	√		
Tinian island	INFINITI G20	P11	1999.NULL –	Active engine mount	√	√	√	√		
Tinian island	INFINITI G20	P11	1999.NULL –	TCS	√	√	√	√		
Tinian island	INFINITI G20	P11	1999.NULL –	S/blind camera	√			√		SP0572, SP0573
Tinian island	INFINITI G20	P11	1999.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tinian island	INFINITI G20	P11	1999.NULL –	Nats immu	√	√	√			
Tinian island	INFINITI G20	P11	1999.NULL –	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI G20	P11	1999.NULL –	Smart entrance						SP0568
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Transmission	√	√	√	√		SP0274
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Pop up hood	√	√	√	√		
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	Precrash seatbelt	√	√	√	√		
Tinian island	INFINITI G25/G37 SEDAN	V36	2011.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Air bag	√	√	√	√		

XTOOL

Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Motor control						
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	HVAC	√	√	√	√		
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Auto slide door	√	√	√	√	AC0941	
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	DIU		√	√	√		
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Adaptive light	√	√	√	√		
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	IVMS	√	√		√		
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Distance control	√	√		√		
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Active suspense system	√	√	√	√		
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Motor assist		√	√	√		SP0574
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	ASCD	√	√	√	√		
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Active engine mount	√	√	√	√		
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	TCS	√	√	√	√		
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	S/blind camera	√			√		SP0572, SP0573
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Nats immu	√	√	√			
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI G35 COUPE	CV35	2003.NULL –	Smart entrance						SP0568
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Motor control						
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	HVAC	√	√	√	√		
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Auto slide door	√	√	√	√	AC0941	
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	DIU		√	√	√		
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Adaptive light	√	√	√	√		
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537

Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	IVMS	√	√		√		
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	Distance control	√	√		√		
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	Active suspense system	√	√	√	√		
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	Motor assist		√	√	√		SP0574
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	ASCD	√	√	√	√		
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	Active engine mount	√	√	√	√		
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	TCS	√	√	√	√		
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	S/blind camera	√			√		SP0572, SP0573
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	Nats immu	√	√	√			
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI G35 SEDAN	V35	2003.NULL–	Smart entrance						SP0568
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	Air bag	√	√	√	√		
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	Multi AV	√	√	√	√		
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	All mode AWD/4WD	√	√	√	√	AC0957	
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	Precrash seatbelt	√	√	√	√		
Tinian island	INFINITI G35 SEDAN	V36	2007.NULL–	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	Air bag	√	√	√	√		
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	Pop up hood	√	√	√	√		
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	Precrash seatbelt	√	√	√	√		
Tinian island	INFINITI G37 CONVERTIBLE	HV36	2009.NULL–	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL–	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL–	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL–	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL–	Air bag	√	√	√	√		
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL–	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL–	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL–	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL–	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL–	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL–	Pop up hood	√	√	√	√		
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL–	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL–	4WAS(front)	√	√	√	√	AC1027, AC1028	

Tinian island	INFINITI G37 COUPE	CV36	2008.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL –	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL –	Precrash seatbelt	√	√	√	√		
Tinian island	INFINITI G37 COUPE	CV36	2008.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	Precrash seatbelt	√	√	√	√		
Tinian island	INFINITI G37 SEDAN	V36	2009.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI I30	CA32	1996.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI I30	CA32	1996.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tinian island	INFINITI I30	CA32	1996.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI I30	CA32	1996.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tinian island	INFINITI I30	CA32	1996.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI I30	CA32	1996.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tinian island	INFINITI I30	CA32	1996.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tinian island	INFINITI I30	CA32	1996.NULL –	Motor control						
Tinian island	INFINITI I30	CA32	1996.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI I30	CA32	1996.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tinian island	INFINITI I30	CA32	1996.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tinian island	INFINITI I30	CA32	1996.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI I30	CA32	1996.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI I30	CA32	1996.NULL –	HVAC	√	√	√	√		
Tinian island	INFINITI I30	CA32	1996.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI I30	CA32	1996.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI I30	CA32	1996.NULL –	Auto slide door	√	√	√	√	AC0941	
Tinian island	INFINITI I30	CA32	1996.NULL –	DIU		√	√	√		
Tinian island	INFINITI I30	CA32	1996.NULL –	Adaptive light	√	√	√	√		
Tinian island	INFINITI I30	CA32	1996.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI I30	CA32	1996.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tinian island	INFINITI I30	CA32	1996.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI I30	CA32	1996.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tinian island	INFINITI I30	CA32	1996.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tinian island	INFINITI I30	CA32	1996.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI I30	CA32	1996.NULL –	IVMS	√	√		√		
Tinian island	INFINITI I30	CA32	1996.NULL –	Distance control	√	√		√		
Tinian island	INFINITI I30	CA32	1996.NULL –	Active suspense system	√	√	√	√		
Tinian island	INFINITI I30	CA32	1996.NULL –	Motor assist		√	√	√		SP0574
Tinian island	INFINITI I30	CA32	1996.NULL –	ASCD	√	√	√	√		
Tinian island	INFINITI I30	CA32	1996.NULL –	Active engine mount	√	√	√	√		
Tinian island	INFINITI I30	CA32	1996.NULL –	TCS	√	√	√	√		
Tinian island	INFINITI I30	CA32	1996.NULL –	S/blind camera	√			√		SP0572, SP0573
Tinian island	INFINITI I30	CA32	1996.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tinian island	INFINITI I30	CA32	1996.NULL –	Nats immu	√	√	√			
Tinian island	INFINITI I30	CA32	1996.NULL –	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI I30	CA32	1996.NULL –	Smart entrance						SP0568

Tinian island	INFINITI I35	CA33	2002.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI I35	CA33	2002.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tinian island	INFINITI I35	CA33	2002.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI I35	CA33	2002.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tinian island	INFINITI I35	CA33	2002.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI I35	CA33	2002.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tinian island	INFINITI I35	CA33	2002.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tinian island	INFINITI I35	CA33	2002.NULL –	Motor control						
Tinian island	INFINITI I35	CA33	2002.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI I35	CA33	2002.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tinian island	INFINITI I35	CA33	2002.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tinian island	INFINITI I35	CA33	2002.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI I35	CA33	2002.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI I35	CA33	2002.NULL –	HVAC	√	√	√	√		
Tinian island	INFINITI I35	CA33	2002.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI I35	CA33	2002.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI I35	CA33	2002.NULL –	Auto slide door	√	√	√	√	AC0941	
Tinian island	INFINITI I35	CA33	2002.NULL –	DIU		√	√	√		
Tinian island	INFINITI I35	CA33	2002.NULL –	Adaptive light	√	√	√	√		
Tinian island	INFINITI I35	CA33	2002.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI I35	CA33	2002.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tinian island	INFINITI I35	CA33	2002.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI I35	CA33	2002.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tinian island	INFINITI I35	CA33	2002.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tinian island	INFINITI I35	CA33	2002.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI I35	CA33	2002.NULL –	IVMS	√	√		√		
Tinian island	INFINITI I35	CA33	2002.NULL –	Distance control	√	√		√		
Tinian island	INFINITI I35	CA33	2002.NULL –	Active suspense system	√	√	√	√		
Tinian island	INFINITI I35	CA33	2002.NULL –	Motor assist		√	√	√		SP0574
Tinian island	INFINITI I35	CA33	2002.NULL –	ASCD	√	√	√	√		
Tinian island	INFINITI I35	CA33	2002.NULL –	Active engine mount	√	√	√	√		
Tinian island	INFINITI I35	CA33	2002.NULL –	TCS	√	√	√	√		
Tinian island	INFINITI I35	CA33	2002.NULL –	S/blind camera	√			√		SP0572, SP0573
Tinian island	INFINITI I35	CA33	2002.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tinian island	INFINITI I35	CA33	2002.NULL –	Nats immu	√	√	√			
Tinian island	INFINITI I35	CA33	2002.NULL –	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI I35	CA33	2002.NULL –	Smart entrance						SP0568
Tinian island	INFINITI JX35	L50	2013.NULL –	Laser/radar	√	√	√	√		
Tinian island	INFINITI JX35	L50	2013.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI JX35	L50	2013.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tinian island	INFINITI JX35	L50	2013.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI JX35	L50	2013.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI JX35	L50	2013.NULL –	EPS/DAST 3	√	√	√	√		
Tinian island	INFINITI JX35	L50	2013.NULL –	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tinian island	INFINITI JX35	L50	2013.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI JX35	L50	2013.NULL –	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Tinian island	INFINITI JX35	L50	2013.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tinian island	INFINITI JX35	L50	2013.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tinian island	INFINITI JX35	L50	2013.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI JX35	L50	2013.NULL –	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Tinian island	INFINITI JX35	L50	2013.NULL –	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI JX35	L50	2013.NULL –	Auto back door	√	√	√	√		SP0611
Tinian island	INFINITI JX35	L50	2013.NULL –	Occupant detection			√	√		SP0584
Tinian island	INFINITI JX35	L50	2013.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI JX35	L50	2013.NULL –	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Tinian island	INFINITI JX35	L50	2013.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI JX35	L50	2013.NULL –	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI JX35	L50	2013.NULL –	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567

XTOOL

Tinian island	INFINITI JX35	L50	2013.NULL–	CAN gateway	√	√	√			
Tinian island	INFINITI JX35	L50	2013.NULL–	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tinian island	INFINITI JX35	L50	2013.NULL–	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI JX35	L50	2013.NULL–	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI JX35	L50	2013.NULL–	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	IPDM E/R	√	√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	Air bag	√	√	√	√		
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	BCM					AC0653, AC0698	SP0391, SP0393
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	Multi AV	√	√	√	√		
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	Adaptive light	√	√	√	√		SP0561, SP0562
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	All mode AWD/4WD	√	√	√	√	AC0957	
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	Precrash seatbelt	√	√	√	√		
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	Intelligent key	√	√	√	√	AC0911, AC0913, AC0915, AC0916, AC0917, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976	SP0560
Tinian island	INFINITI M35/M45	Y50	2006.NULL–	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI M35H	HY51	2012.NULL–	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tinian island	INFINITI M35H	HY51	2012.NULL–	Laser/radar	√	√	√	√		
Tinian island	INFINITI M35H	HY51	2012.NULL–	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI M35H	HY51	2012.NULL–	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tinian island	INFINITI M35H	HY51	2012.NULL–	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI M35H	HY51	2012.NULL–	Air bag	√	√	√	√		
Tinian island	INFINITI M35H	HY51	2012.NULL–	EPS/DAST 3	√	√	√	√		
Tinian island	INFINITI M35H	HY51	2012.NULL–	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tinian island	INFINITI M35H	HY51	2012.NULL–	Motor control	√	√	√	√		
Tinian island	INFINITI M35H	HY51	2012.NULL–	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tinian island	INFINITI M35H	HY51	2012.NULL–	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Tinian island	INFINITI M35H	HY51	2012.NULL–	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Tinian island	INFINITI M35H	HY51	2012.NULL–	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tinian island	INFINITI M35H	HY51	2012.NULL–	Diag data recorder	√					
Tinian island	INFINITI M35H	HY51	2012.NULL–	Pop up hood	√	√	√	√		
Tinian island	INFINITI M35H	HY51	2012.NULL–	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI M35H	HY51	2012.NULL–	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tinian island	INFINITI M35H	HY51	2012.NULL–	HV battery	√	√	√	√	AC1121	
Tinian island	INFINITI M35H	HY51	2012.NULL–	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI M35H	HY51	2012.NULL–	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Tinian island	INFINITI M35H	HY51	2012.NULL–	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI M35H	HY51	2012.NULL–	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI M35H	HY51	2012.NULL–	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tinian island	INFINITI M35H	HY51	2012.NULL–	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI M35H	HY51	2012.NULL–	CAN gateway	√	√	√			
Tinian island	INFINITI M35H	HY51	2012.NULL–	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tinian island	INFINITI M35H	HY51	2012.NULL–	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI M35H	HY51	2012.NULL–	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI M35H	HY51	2012.NULL–	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI M35H	HY51	2012.NULL–	Brake	√	√	√	√	AC1127	
Tinian island	INFINITI M35H	HY51	2012.NULL–	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Tinian island	INFINITI M37/M56	Y51	2011.NULL–	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tinian island	INFINITI M37/M56	Y51	2011.NULL–	Laser/radar	√	√	√	√		
Tinian island	INFINITI M37/M56	Y51	2011.NULL–	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI M37/M56	Y51	2011.NULL–	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Tinian island	INFINITI M37/M56	Y51	2011.NULL–	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tinian island	INFINITI M37/M56	Y51	2011.NULL–	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI M37/M56	Y51	2011.NULL–	Air bag	√	√	√	√		
Tinian island	INFINITI M37/M56	Y51	2011.NULL–	EPS/DAST 3	√	√	√	√		
Tinian island	INFINITI M37/M56	Y51	2011.NULL–	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tinian island	INFINITI M37/M56	Y51	2011.NULL–	Motor control	√	√	√	√		

Tinian island	INFINITI M37/M56	Y51	2011.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	Pop up hood	√	√	√	√		
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	HV battery	√	√	√	√	AC1121	
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	CAN gateway	√	√	√			
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI M37/M56	Y51	2011.NULL –	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Tinian island	INFINITI M45	Y34	2003.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI M45	Y34	2003.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tinian island	INFINITI M45	Y34	2003.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI M45	Y34	2003.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tinian island	INFINITI M45	Y34	2003.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI M45	Y34	2003.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tinian island	INFINITI M45	Y34	2003.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tinian island	INFINITI M45	Y34	2003.NULL –	Motor control						
Tinian island	INFINITI M45	Y34	2003.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI M45	Y34	2003.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tinian island	INFINITI M45	Y34	2003.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tinian island	INFINITI M45	Y34	2003.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI M45	Y34	2003.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI M45	Y34	2003.NULL –	HVAC	√	√	√	√		
Tinian island	INFINITI M45	Y34	2003.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI M45	Y34	2003.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI M45	Y34	2003.NULL –	Auto slide door	√	√	√	√	AC0941	
Tinian island	INFINITI M45	Y34	2003.NULL –	DIU		√	√	√		
Tinian island	INFINITI M45	Y34	2003.NULL –	Adaptive light	√	√	√	√		
Tinian island	INFINITI M45	Y34	2003.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI M45	Y34	2003.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tinian island	INFINITI M45	Y34	2003.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI M45	Y34	2003.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tinian island	INFINITI M45	Y34	2003.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tinian island	INFINITI M45	Y34	2003.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI M45	Y34	2003.NULL –	IVMS	√	√		√		
Tinian island	INFINITI M45	Y34	2003.NULL –	Distance control	√	√		√		
Tinian island	INFINITI M45	Y34	2003.NULL –	Active suspense system	√	√	√	√		
Tinian island	INFINITI M45	Y34	2003.NULL –	Motor assist		√	√	√		SP0574
Tinian island	INFINITI M45	Y34	2003.NULL –	ASCD	√	√	√	√		
Tinian island	INFINITI M45	Y34	2003.NULL –	Active engine mount	√	√	√	√		
Tinian island	INFINITI M45	Y34	2003.NULL –	TCS	√	√	√	√		
Tinian island	INFINITI M45	Y34	2003.NULL –	S/blind camera	√			√		SP0572, SP0573

XTOOL

Tinian island	INFINITI M45	Y34	2003.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tinian island	INFINITI M45	Y34	2003.NULL –	Nats immu	√	√	√			
Tinian island	INFINITI M45	Y34	2003.NULL –	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI M45	Y34	2003.NULL –	Smart entrance						SP0568
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0038, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	Transmission	√	√	√	√		SP0274
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	Pop up hood	√	√	√	√		
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI Q40 SEDAN	V36	2015.NULL –	Precrash seatbelt	√	√	√	√		
Tinian island	INFINITI Q45	F50	2002.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI Q45	F50	2002.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tinian island	INFINITI Q45	F50	2002.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI Q45	F50	2002.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tinian island	INFINITI Q45	F50	2002.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI Q45	F50	2002.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tinian island	INFINITI Q45	F50	2002.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tinian island	INFINITI Q45	F50	2002.NULL –	Motor control						
Tinian island	INFINITI Q45	F50	2002.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI Q45	F50	2002.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tinian island	INFINITI Q45	F50	2002.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tinian island	INFINITI Q45	F50	2002.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI Q45	F50	2002.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI Q45	F50	2002.NULL –	HVAC	√	√	√	√		
Tinian island	INFINITI Q45	F50	2002.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI Q45	F50	2002.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI Q45	F50	2002.NULL –	Auto slide door	√	√	√	√	AC0941	
Tinian island	INFINITI Q45	F50	2002.NULL –	DIU		√	√	√		
Tinian island	INFINITI Q45	F50	2002.NULL –	Adaptive light	√	√	√	√		
Tinian island	INFINITI Q45	F50	2002.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI Q45	F50	2002.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tinian island	INFINITI Q45	F50	2002.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI Q45	F50	2002.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tinian island	INFINITI Q45	F50	2002.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tinian island	INFINITI Q45	F50	2002.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI Q45	F50	2002.NULL –	IVMS	√	√		√		
Tinian island	INFINITI Q45	F50	2002.NULL –	Distance control	√	√		√		
Tinian island	INFINITI Q45	F50	2002.NULL –	Active suspense system	√	√	√	√		
Tinian island	INFINITI Q45	F50	2002.NULL –	Motor assist		√	√	√		SP0574
Tinian island	INFINITI Q45	F50	2002.NULL –	ASCD	√	√	√	√		
Tinian island	INFINITI Q45	F50	2002.NULL –	Active engine mount	√	√	√	√		
Tinian island	INFINITI Q45	F50	2002.NULL –	TCS	√	√	√	√		
Tinian island	INFINITI Q45	F50	2002.NULL –	S/blind camera	√			√		SP0572, SP0573
Tinian island	INFINITI Q45	F50	2002.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tinian island	INFINITI Q45	F50	2002.NULL –	Nats immu	√	√	√			
Tinian island	INFINITI Q45	F50	2002.NULL –	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI Q45	F50	2002.NULL –	Smart entrance						SP0568
Tinian island	INFINITI Q45	FY33	1995.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI Q45	FY33	1995.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tinian island	INFINITI Q45	FY33	1995.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI Q45	FY33	1995.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	

Tinian island	INFINITI Q45	FY33	1995.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI Q45	FY33	1995.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tinian island	INFINITI Q45	FY33	1995.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tinian island	INFINITI Q45	FY33	1995.NULL –	Motor control						
Tinian island	INFINITI Q45	FY33	1995.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI Q45	FY33	1995.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tinian island	INFINITI Q45	FY33	1995.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tinian island	INFINITI Q45	FY33	1995.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI Q45	FY33	1995.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI Q45	FY33	1995.NULL –	HVAC	√	√	√	√		
Tinian island	INFINITI Q45	FY33	1995.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI Q45	FY33	1995.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI Q45	FY33	1995.NULL –	Auto slide door	√	√	√	√	AC0941	
Tinian island	INFINITI Q45	FY33	1995.NULL –	DIU		√	√	√		
Tinian island	INFINITI Q45	FY33	1995.NULL –	Adaptive light	√	√	√	√		
Tinian island	INFINITI Q45	FY33	1995.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI Q45	FY33	1995.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tinian island	INFINITI Q45	FY33	1995.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI Q45	FY33	1995.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tinian island	INFINITI Q45	FY33	1995.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tinian island	INFINITI Q45	FY33	1995.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI Q45	FY33	1995.NULL –	IVMS	√	√		√		
Tinian island	INFINITI Q45	FY33	1995.NULL –	Distance control	√	√		√		
Tinian island	INFINITI Q45	FY33	1995.NULL –	Active suspense system	√	√	√	√		
Tinian island	INFINITI Q45	FY33	1995.NULL –	Motor assist		√	√	√		SP0574
Tinian island	INFINITI Q45	FY33	1995.NULL –	ASCD	√	√	√	√		
Tinian island	INFINITI Q45	FY33	1995.NULL –	Active engine mount	√	√	√	√		
Tinian island	INFINITI Q45	FY33	1995.NULL –	TCS	√	√	√	√		
Tinian island	INFINITI Q45	FY33	1995.NULL –	S/blind camera	√			√		SP0572, SP0573
Tinian island	INFINITI Q45	FY33	1995.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tinian island	INFINITI Q45	FY33	1995.NULL –	Nats immu	√	√	√			
Tinian island	INFINITI Q45	FY33	1995.NULL –	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI Q45	FY33	1995.NULL –	Smart entrance						SP0568
Tinian island	INFINITI Q50	V37	2019.NULL –	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tinian island	INFINITI Q50	V37	2019.NULL –	Laser/radar	√	√	√	√	AC0994	
Tinian island	INFINITI Q50	V37	2019.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI Q50	V37	2019.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tinian island	INFINITI Q50	V37	2019.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI Q50	V37	2019.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI Q50	V37	2019.NULL –	EPS/DAST 3	√	√	√	√		SP0507
Tinian island	INFINITI Q50	V37	2019.NULL –	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tinian island	INFINITI Q50	V37	2019.NULL –	Motor control	√	√	√	√		
Tinian island	INFINITI Q50	V37	2019.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI Q50	V37	2019.NULL –	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
Tinian island	INFINITI Q50	V37	2019.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tinian island	INFINITI Q50	V37	2019.NULL –	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tinian island	INFINITI Q50	V37	2019.NULL –	Pop up hood	√	√	√	√		
Tinian island	INFINITI Q50	V37	2019.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI Q50	V37	2019.NULL –	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tinian island	INFINITI Q50	V37	2019.NULL –	HV battery	√	√	√	√	AC1121	
Tinian island	INFINITI Q50	V37	2019.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tinian island	INFINITI Q50	V37	2019.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tinian island	INFINITI Q50	V37	2019.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI Q50	V37	2019.NULL –	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Tinian island	INFINITI Q50	V37	2019.NULL –	Occupant detection			√	√		SP0584
Tinian island	INFINITI Q50	V37	2019.NULL –	Shift	√	√	√	√		SP0613

XTOOL

Tinian island	INFINITI Q50	V37	2019.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tinian island	INFINITI Q50	V37	2019.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI Q50	V37	2019.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI Q50	V37	2019.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI Q50	V37	2019.NULL –	DAST 2	√	√	√	√		
Tinian island	INFINITI Q50	V37	2019.NULL –	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI Q50	V37	2019.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI Q50	V37	2019.NULL –	CAN gateway	√	√	√			
Tinian island	INFINITI Q50	V37	2019.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tinian island	INFINITI Q50	V37	2019.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI Q50	V37	2019.NULL –	DAST 1	√	√	√	√		
Tinian island	INFINITI Q50	V37	2019.NULL –	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Tinian island	INFINITI Q50	V37	2019.NULL –	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tinian island	INFINITI Q50	V37	2019.NULL –	ANC	√	√	√	√	AC1024	
Tinian island	INFINITI Q50	V37	2019.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI Q50	V37	2019.NULL –	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tinian island	INFINITI Q50	V37	2019.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI Q50	V37	2019.NULL –	HIGH BEAM ASSIST	√	√	√	√		
Tinian island	INFINITI Q50	V37	2019.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI Q50	V37	2019.NULL –	Brake	√	√	√	√	AC1127	
Tinian island	INFINITI Q50	V37	2019.NULL –	6ch CAN GATEWAY	√	√	√	√		
Tinian island	INFINITI Q50	V37	2019.NULL –	3ch CAN GATEWAY	√	√	√	√		
Tinian island	INFINITI Q50	V37	2019.NULL –	ICC/ADAS 2	√	√	√	√		
Tinian island	INFINITI Q50	V37	2019.NULL –	FSCM	√	√	√	√	AC1109	
Tinian island	INFINITI Q50	V37	2019.NULL –	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Laser/radar	√	√	√	√		
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	EPS/DAST 3	√	√	√	√		SP0507
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Motor control	√	√	√	√		
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Transmission	√	√	√	√		SP0274, SP0276
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Pop up hood	√	√	√	√		
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	HV battery	√	√	√	√	AC1121	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Occupant detection			√	√		SP0584
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Shift	√	√	√	√		SP0613
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	DAST 2	√	√	√	√		
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	CAN gateway	√	√	√			
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	DAST 1	√	√	√	√		
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	ANC	√	√	√	√	AC1024	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL –	HIGH BEAM ASSIST	√	√	√	√		

Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL–	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL–	Brake	√	√	√	√	AC1127	
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL–	6ch CAN GATEWAY	√	√	√	√		
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL–	3ch CAN GATEWAY	√	√	√	√		
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL–	ICC/ADAS 2	√	√	√	√		
Tinian island	INFINITI Q50 HYBRID	HV37	2014.NULL–	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Laser/radar	√	√	√	√		
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Air bag	√	√	√	√		
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	EPS/DAST 3	√	√	√	√		
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Motor control	√	√	√	√		
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Transmission	√	√	√	√		SP0276
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Pop up hood	√	√	√	√		
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	HV battery	√	√	√	√	AC1121	
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Occupant detection			√	√		SP0584
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 2	√	√	√	√		
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Lane camera	√	√	√	√		
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 1	√	√	√	√		
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	ANC	√	√	√	√	AC1024	
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	HIGH BEAM ASSIST	√	√	√	√		
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√		
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	Brake	√	√	√	√	AC1127	
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	6ch CAN GATEWAY	√	√	√	√		
Tinian island	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Tinian island	INFINITI Q60	CV37	2019.NULL–	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tinian island	INFINITI Q60	CV37	2019.NULL–	Laser/radar	√	√	√	√	AC0994	
Tinian island	INFINITI Q60	CV37	2019.NULL–	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI Q60	CV37	2019.NULL–	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tinian island	INFINITI Q60	CV37	2019.NULL–	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI Q60	CV37	2019.NULL–	Air bag	√	√	√	√		
Tinian island	INFINITI Q60	CV37	2019.NULL–	EPS/DAST 3	√	√	√	√		
Tinian island	INFINITI Q60	CV37	2019.NULL–	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tinian island	INFINITI Q60	CV37	2019.NULL–	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI Q60	CV37	2019.NULL–	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Tinian island	INFINITI Q60	CV37	2019.NULL–	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tinian island	INFINITI Q60	CV37	2019.NULL–	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tinian island	INFINITI Q60	CV37	2019.NULL–	Pop up hood	√	√	√	√		

XTOOL

Tinian island	INFINITI Q60	CV37	2019.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI Q60	CV37	2019.NULL –	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tinian island	INFINITI Q60	CV37	2019.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tinian island	INFINITI Q60	CV37	2019.NULL –	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI Q60	CV37	2019.NULL –	Occupant detection			√	√		SP0584
Tinian island	INFINITI Q60	CV37	2019.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tinian island	INFINITI Q60	CV37	2019.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI Q60	CV37	2019.NULL –	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Tinian island	INFINITI Q60	CV37	2019.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI Q60	CV37	2019.NULL –	DAST 2	√	√	√	√		
Tinian island	INFINITI Q60	CV37	2019.NULL –	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI Q60	CV37	2019.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI Q60	CV37	2019.NULL –	CAN gateway	√	√	√			
Tinian island	INFINITI Q60	CV37	2019.NULL –	Lane camera	√	√	√	√		
Tinian island	INFINITI Q60	CV37	2019.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI Q60	CV37	2019.NULL –	DAST 1	√	√	√	√		
Tinian island	INFINITI Q60	CV37	2019.NULL –	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Tinian island	INFINITI Q60	CV37	2019.NULL –	ANC	√	√	√	√	AC1024	
Tinian island	INFINITI Q60	CV37	2019.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI Q60	CV37	2019.NULL –	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tinian island	INFINITI Q60	CV37	2019.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI Q60	CV37	2019.NULL –	HIGH BEAM ASSIST	√	√	√	√		
Tinian island	INFINITI Q60	CV37	2019.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI Q60	CV37	2019.NULL –	Lane camera 2	√	√	√	√		
Tinian island	INFINITI Q60	CV37	2019.NULL –	6ch CAN GATEWAY	√	√	√	√		
Tinian island	INFINITI Q60	CV37	2019.NULL –	3ch CAN GATEWAY	√	√	√	√		
Tinian island	INFINITI Q60	CV37	2019.NULL –	ICC/ADAS 2	√	√	√	√		
Tinian island	INFINITI Q60	CV37	2019.NULL –	FSCM	√	√	√	√	AC1109	
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Transmission	√	√	√	√		SP0274
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Pop up hood	√	√	√	√		
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tinian island	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL –	Precrash seatbelt	√	√	√	√		
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	Transmission	√	√	√	√		SP0274
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	Pop up hood	√	√	√	√		
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	

Tinian island	INFINITI Q60 COUPE	CV36	2014.NULL –	Precrash seatbelt	√	√	√	√		
Tinian island	INFINITI Q70	Y51	2019.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tinian island	INFINITI Q70	Y51	2019.NULL –	Laser/radar	√	√	√	√	AC0994	
Tinian island	INFINITI Q70	Y51	2019.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI Q70	Y51	2019.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tinian island	INFINITI Q70	Y51	2019.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI Q70	Y51	2019.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI Q70	Y51	2019.NULL –	EPS/DAST 3	√	√	√	√		SP0507
Tinian island	INFINITI Q70	Y51	2019.NULL –	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tinian island	INFINITI Q70	Y51	2019.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tinian island	INFINITI Q70	Y51	2019.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Tinian island	INFINITI Q70	Y51	2019.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Tinian island	INFINITI Q70	Y51	2019.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI Q70	Y51	2019.NULL –	Pop up hood	√	√	√	√		
Tinian island	INFINITI Q70	Y51	2019.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI Q70	Y51	2019.NULL –	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tinian island	INFINITI Q70	Y51	2019.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tinian island	INFINITI Q70	Y51	2019.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tinian island	INFINITI Q70	Y51	2019.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI Q70	Y51	2019.NULL –	Occupant detection			√	√		SP0584
Tinian island	INFINITI Q70	Y51	2019.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tinian island	INFINITI Q70	Y51	2019.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI Q70	Y51	2019.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI Q70	Y51	2019.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI Q70	Y51	2019.NULL –	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI Q70	Y51	2019.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI Q70	Y51	2019.NULL –	CAN gateway	√	√	√			
Tinian island	INFINITI Q70	Y51	2019.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
Tinian island	INFINITI Q70	Y51	2019.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI Q70	Y51	2019.NULL –	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tinian island	INFINITI Q70	Y51	2019.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI Q70	Y51	2019.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI Q70	Y51	2019.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI Q70	Y51	2019.NULL –	6ch CAN GATEWAY	√	√	√	√		
Tinian island	INFINITI Q70	Y51	2019.NULL –	ICC/ADAS 2	√	√	√	√		
Tinian island	INFINITI Q70	Y51	2019.NULL –	FSCM	√	√	√	√	AC1109	
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	Laser/radar	√	√	√	√	AC0994	
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	EPS/DAST 3	√	√	√	√		
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	Motor control	√	√	√	√		
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	BCM				√	AC0613, AC0618, AC0653, AC0663, AC0690, AC0692, AC0698, AC0702	SP0372, SP0429, SP0471
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	Pop up hood	√	√	√	√		
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	HV battery	√	√	√	√	AC1121	
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL –	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	

XTOOL

Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	Occupant detection			√	√		SP0584
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	CAN gateway	√	√	√			
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	Brake	√	√	√	√	AC1127	
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	6ch CAN GATEWAY	√	√	√	√		
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	ICC/ADAS 2	√	√	√	√		
Tinian island	INFINITI Q70 HYBRID	HY51	2014.NULL–	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Tinian island	INFINITI QX30	H15	2019.NULL–	Air pressure monitor	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Air bag	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	EPS/DAST 3	√	√	√			
Tinian island	INFINITI QX30	H15	2019.NULL–	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Tinian island	INFINITI QX30	H15	2019.NULL–	Engine	√	√	√	√	AC0002, AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0103, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tinian island	INFINITI QX30	H15	2019.NULL–	EHS/PKB	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Transmission	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Tinian island	INFINITI QX30	H15	2019.NULL–	ABS	√	√	√	√		SP0308
Tinian island	INFINITI QX30	H15	2019.NULL–	Multi AV	√	√	√	√		SP0501
Tinian island	INFINITI QX30	H15	2019.NULL–	HVAC	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Auto drive position	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Shift	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	All mode AWD/4WD	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	AVM	√	√		√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Intelligent key	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	CAN gateway	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	ANC	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Telematics	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	FSCM	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Siren control unit	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Tinian island	INFINITI QX30	H15	2019.NULL–	Overhead Control Panel Unit	√			√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Universal Garage Door Opener	√			√		
Tinian island	INFINITI QX30	H15	2019.NULL	Upper control panel cont unit	√					
Tinian island	INFINITI QX30	H15	2019.NULL–	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Tinian island	INFINITI QX30	H15	2019.NULL–	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Tinian island	INFINITI QX30	H15	2019.NULL–	Light/Rain Sensor Module	√			√		
Tinian island	INFINITI QX30	H15	2019.NULL–	EC Mirror Compass	√					
Tinian island	INFINITI QX30	H15	2019.NULL–	Intelligent Battery Sensor	√					
Tinian island	INFINITI QX30	H15	2019.NULL–	Alarm siren	√			√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Radar sensor	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Steering column cont module	√	√	√			
Tinian island	INFINITI QX30	H15	2019.NULL–	ICC sensor	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Trailer recognition control unit	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	H/L control module LH	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Powertrain cont module	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Side radar LH	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	LED H/L control module LH	√			√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Steering Wheel Switch Pad	√			√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Parking assist	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Occupant Classification Unit	√			√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Electronic Ignition Switch cont unit	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	H/L control module RH	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Front camera unit	√	√	√	√		
Tinian island	INFINITI QX30	H15	2019.NULL–	Side radar RH	√	√	√	√		

XTOOL

Tinian island	INFINITI QX30	H15	2019.NULL –	LED H/L control module RH	√			√		
Tinian island	INFINITI QX4	JR50	1997.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI QX4	JR50	1997.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tinian island	INFINITI QX4	JR50	1997.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI QX4	JR50	1997.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tinian island	INFINITI QX4	JR50	1997.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI QX4	JR50	1997.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tinian island	INFINITI QX4	JR50	1997.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tinian island	INFINITI QX4	JR50	1997.NULL –	Motor control						
Tinian island	INFINITI QX4	JR50	1997.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI QX4	JR50	1997.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tinian island	INFINITI QX4	JR50	1997.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tinian island	INFINITI QX4	JR50	1997.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI QX4	JR50	1997.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI QX4	JR50	1997.NULL –	HVAC	√	√	√	√		
Tinian island	INFINITI QX4	JR50	1997.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI QX4	JR50	1997.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI QX4	JR50	1997.NULL –	Auto slide door	√	√	√	√	AC0941	
Tinian island	INFINITI QX4	JR50	1997.NULL –	DIU		√	√	√		
Tinian island	INFINITI QX4	JR50	1997.NULL –	Adaptive light	√	√	√	√		
Tinian island	INFINITI QX4	JR50	1997.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI QX4	JR50	1997.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tinian island	INFINITI QX4	JR50	1997.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI QX4	JR50	1997.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tinian island	INFINITI QX4	JR50	1997.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tinian island	INFINITI QX4	JR50	1997.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI QX4	JR50	1997.NULL –	IVMS	√	√		√		
Tinian island	INFINITI QX4	JR50	1997.NULL –	Distance control	√	√		√		
Tinian island	INFINITI QX4	JR50	1997.NULL –	Active suspense system	√	√	√	√		
Tinian island	INFINITI QX4	JR50	1997.NULL –	Motor assist		√	√	√		SP0574
Tinian island	INFINITI QX4	JR50	1997.NULL –	ASCD	√	√	√	√		
Tinian island	INFINITI QX4	JR50	1997.NULL –	Active engine mount	√	√	√	√		
Tinian island	INFINITI QX4	JR50	1997.NULL –	TCS	√	√	√	√		
Tinian island	INFINITI QX4	JR50	1997.NULL –	S/blind camera	√			√		SP0572, SP0573
Tinian island	INFINITI QX4	JR50	1997.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tinian island	INFINITI QX4	JR50	1997.NULL –	Nats immu	√	√	√			
Tinian island	INFINITI QX4	JR50	1997.NULL –	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI QX4	JR50	1997.NULL –	Smart entrance						SP0568
Tinian island	INFINITI QX50	J50	2014.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI QX50	J50	2014.NULL –	Laser/radar	√	√	√	√	AC0994	
Tinian island	INFINITI QX50	J50	2014.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI QX50	J50	2014.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI QX50	J50	2014.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI QX50	J50	2014.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI QX50	J50	2014.NULL –	EPS/DAST 3	√	√	√	√		SP0507
Tinian island	INFINITI QX50	J50	2014.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tinian island	INFINITI QX50	J50	2014.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tinian island	INFINITI QX50	J50	2014.NULL –	Transmission	√	√	√	√		SP0274
Tinian island	INFINITI QX50	J50	2014.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tinian island	INFINITI QX50	J50	2014.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI QX50	J50	2014.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI QX50	J50	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI QX50	J50	2014.NULL –	Occupant detection			√	√		SP0584
Tinian island	INFINITI QX50	J50	2014.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI QX50	J50	2014.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI QX50	J50	2014.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Tinian island	INFINITI QX50	J50	2014.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	

Tinian island	INFINITI QX50	J50	2014.NULL –	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI QX50	J50	2014.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI QX50	J50	2014.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tinian island	INFINITI QX50	J50	2014.NULL –	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Tinian island	INFINITI QX50	J50	2014.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI QX50	J50	2014.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI QX50	J50	2014.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI QX50	J55	2019.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Tinian island	INFINITI QX50	J55	2019.NULL –	Laser/radar	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tinian island	INFINITI QX50	J55	2019.NULL –	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Tinian island	INFINITI QX50	J55	2019.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	EPS/DAST 3	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	Meter/M&A	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tinian island	INFINITI QX50	J55	2019.NULL –	EHS/PKB	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Tinian island	INFINITI QX50	J55	2019.NULL –	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Tinian island	INFINITI QX50	J55	2019.NULL –	ABS	√	√	√	√		SP0313, SP0315
Tinian island	INFINITI QX50	J55	2019.NULL –	Total illum C/U	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI QX50	J55	2019.NULL –	HVAC	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	Auto drive position	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	Auto back door	√	√	√	√		SP0611
Tinian island	INFINITI QX50	J55	2019.NULL –	Occupant detection			√	√		SP0584
Tinian island	INFINITI QX50	J55	2019.NULL –	Shift						
Tinian island	INFINITI QX50	J55	2019.NULL –	Adaptive light	√	√	√	√		SP0562
Tinian island	INFINITI QX50	J55	2019.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI QX50	J55	2019.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI QX50	J55	2019.NULL –	All mode AWD/4WD	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	DAST 2	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI QX50	J55	2019.NULL –	CAN gateway	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	Lane camera	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	DAST 1	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	Chassis control	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	ANC						
Tinian island	INFINITI QX50	J55	2019.NULL –	E-HUD	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI QX50	J55	2019.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI QX50	J55	2019.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI QX50	J55	2019.NULL –	6ch CAN GATEWAY	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	3ch CAN GATEWAY	√	√	√	√		
Tinian island	INFINITI QX50	J55	2019.NULL –	ICC/ADAS 2	√	√	√	√		
Tinian island	INFINITI QX56	JA60	2004.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI QX56	JA60	2004.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Tinian island	INFINITI QX56	JA60	2004.NULL –	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI QX56	JA60	2004.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Tinian island	INFINITI QX56	JA60	2004.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI QX56	JA60	2004.NULL –	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Tinian island	INFINITI QX56	JA60	2004.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Tinian island	INFINITI QX56	JA60	2004.NULL –	Motor control						
Tinian island	INFINITI QX56	JA60	2004.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI QX56	JA60	2004.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Tinian island	INFINITI QX56	JA60	2004.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Tinian island	INFINITI QX56	JA60	2004.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tinian island	INFINITI QX56	JA60	2004.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI QX56	JA60	2004.NULL –	HVAC	√	√	√	√		
Tinian island	INFINITI QX56	JA60	2004.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI QX56	JA60	2004.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI QX56	JA60	2004.NULL –	Auto slide door	√	√	√	√	AC0941	

XTOOL

Tinian island	INFINITI QX56	JA60	2004.NULL –	DIU		√	√	√		
Tinian island	INFINITI QX56	JA60	2004.NULL –	Adaptive light	√	√	√	√		
Tinian island	INFINITI QX56	JA60	2004.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI QX56	JA60	2004.NULL –	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Tinian island	INFINITI QX56	JA60	2004.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI QX56	JA60	2004.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tinian island	INFINITI QX56	JA60	2004.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Tinian island	INFINITI QX56	JA60	2004.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI QX56	JA60	2004.NULL –	IVMS	√	√		√		
Tinian island	INFINITI QX56	JA60	2004.NULL –	Distance control	√	√		√		
Tinian island	INFINITI QX56	JA60	2004.NULL –	Active suspense system	√	√	√	√		
Tinian island	INFINITI QX56	JA60	2004.NULL –	Motor assist		√	√	√		SP0574
Tinian island	INFINITI QX56	JA60	2004.NULL –	ASCD	√	√	√	√		
Tinian island	INFINITI QX56	JA60	2004.NULL –	Active engine mount	√	√	√	√		
Tinian island	INFINITI QX56	JA60	2004.NULL –	TCS	√	√	√	√		
Tinian island	INFINITI QX56	JA60	2004.NULL –	S/blind camera	√			√		SP0572, SP0573
Tinian island	INFINITI QX56	JA60	2004.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Tinian island	INFINITI QX56	JA60	2004.NULL –	Nats immu	√	√	√			
Tinian island	INFINITI QX56	JA60	2004.NULL –	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI QX56	JA60	2004.NULL –	Smart entrance						SP0568
Tinian island	INFINITI QX56	Z62	2011.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tinian island	INFINITI QX56	Z62	2011.NULL –	Laser/radar	√	√	√	√		
Tinian island	INFINITI QX56	Z62	2011.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI QX56	Z62	2011.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tinian island	INFINITI QX56	Z62	2011.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI QX56	Z62	2011.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI QX56	Z62	2011.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Tinian island	INFINITI QX56	Z62	2011.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tinian island	INFINITI QX56	Z62	2011.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tinian island	INFINITI QX56	Z62	2011.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Tinian island	INFINITI QX56	Z62	2011.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Tinian island	INFINITI QX56	Z62	2011.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI QX56	Z62	2011.NULL –	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0476, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488, SP0489, SP0490
Tinian island	INFINITI QX56	Z62	2011.NULL –	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Tinian island	INFINITI QX56	Z62	2011.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI QX56	Z62	2011.NULL –	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI QX56	Z62	2011.NULL –	Auto back door	√	√	√	√		
Tinian island	INFINITI QX56	Z62	2011.NULL –	Occupant detection			√	√		SP0584
Tinian island	INFINITI QX56	Z62	2011.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tinian island	INFINITI QX56	Z62	2011.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI QX56	Z62	2011.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Tinian island	INFINITI QX56	Z62	2011.NULL –	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Tinian island	INFINITI QX56	Z62	2011.NULL –	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI QX56	Z62	2011.NULL –	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI QX56	Z62	2011.NULL –	CAN gateway	√	√	√			
Tinian island	INFINITI QX56	Z62	2011.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tinian island	INFINITI QX56	Z62	2011.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI QX56	Z62	2011.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI QX56	Z62	2011.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI QX56	Z62	2011.NULL –	Rearview camera	√			√		SP0570, SP0571
Tinian island	INFINITI QX60	L50	2019.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tinian island	INFINITI QX60	L50	2019.2-	Laser/radar	√	√	√	√	AC0994	
Tinian island	INFINITI QX60	L50	2019.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI QX60	L50	2019.2-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tinian island	INFINITI QX60	L50	2019.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI QX60	L50	2019.2-	Air bag	√	√	√	√		
Tinian island	INFINITI QX60	L50	2019.2-	EPS/DAST 3	√	√	√	√		
Tinian island	INFINITI QX60	L50	2019.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tinian island	INFINITI QX60	L50	2019.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tinian island	INFINITI QX60	L50	2019.2-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Tinian island	INFINITI QX60	L50	2019.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tinian island	INFINITI QX60	L50	2019.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tinian island	INFINITI QX60	L50	2019.2-	Multi AV	√	√	√	√		SP0503

Tinian island	INFINITI QX60	L50	2019.2-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Tinian island	INFINITI QX60	L50	2019.2-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI QX60	L50	2019.2-	Auto back door	√	√	√	√		SP0611
Tinian island	INFINITI QX60	L50	2019.2-	Occupant detection			√	√		SP0584
Tinian island	INFINITI QX60	L50	2019.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI QX60	L50	2019.2-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI QX60	L50	2019.2-	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI QX60	L50	2019.2-	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI QX60	L50	2019.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI QX60	L50	2019.2-	CAN gateway	√	√	√			
Tinian island	INFINITI QX60	L50	2019.2-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
Tinian island	INFINITI QX60	L50	2019.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tinian island	INFINITI QX60	L50	2019.2-	ANC	√	√	√	√	AC1024	
Tinian island	INFINITI QX60	L50	2019.2-	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI QX60	L50	2019.2-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI QX60	L50	2019.2-	HIGH BEAM ASSIST	√	√	√	√		
Tinian island	INFINITI QX60	L50	2019.2-	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI QX60	L50	2019.2-	3ch CAN GATEWAY	√	√	√	√		
Tinian island	INFINITI QX60	L50	2019.2-	ICC/ADAS 2	√	√	√	√		
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Laser/radar	√	√	√	√		
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Air bag	√	√	√	√		
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	EPS/DAST 3	√	√	√	√		
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Motor control	√	√	√	√		
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0038, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	HV battery	√	√	√	√	AC1121	
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Auto back door	√	√	√	√		SP0611
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Occupant detection			√	√		SP0584
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	CAN gateway	√	√	√			
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	ANC	√	√	√	√		
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	HIGH BEAM ASSIST	√	√	√	√		
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	ICC/ADAS 2	√	√	√	√		
Tinian island	INFINITI QX60 HYBRID	HL50	2014.NULL-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Tinian island	INFINITI QX70	S51	2014.NULL-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tinian island	INFINITI QX70	S51	2014.NULL-	Laser/radar	√	√	√	√	AC0994	
Tinian island	INFINITI QX70	S51	2014.NULL-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI QX70	S51	2014.NULL-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tinian island	INFINITI QX70	S51	2014.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI QX70	S51	2014.NULL-	Air bag	√	√	√	√		
Tinian island	INFINITI QX70	S51	2014.NULL-	EPS/DAST 3	√	√	√	√		SP0507
Tinian island	INFINITI QX70	S51	2014.NULL-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tinian island	INFINITI QX70	S51	2014.NULL-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239

Tinian island	INFINITI QX70	S51	2014.NULL –	Transmission	√	√	√	√		SP0274
Tinian island	INFINITI QX70	S51	2014.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tinian island	INFINITI QX70	S51	2014.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Tinian island	INFINITI QX70	S51	2014.NULL –	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Tinian island	INFINITI QX70	S51	2014.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI QX70	S51	2014.NULL –	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tinian island	INFINITI QX70	S51	2014.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tinian island	INFINITI QX70	S51	2014.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI QX70	S51	2014.NULL –	Auto back door	√	√	√	√		SP0611
Tinian island	INFINITI QX70	S51	2014.NULL –	Occupant detection			√	√		SP0584
Tinian island	INFINITI QX70	S51	2014.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tinian island	INFINITI QX70	S51	2014.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI QX70	S51	2014.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Tinian island	INFINITI QX70	S51	2014.NULL –	All mode AWD/4WD	√	√	√	√	AC0956	
Tinian island	INFINITI QX70	S51	2014.NULL –	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI QX70	S51	2014.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI QX70	S51	2014.NULL –	CAN gateway	√	√	√			
Tinian island	INFINITI QX70	S51	2014.NULL –	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tinian island	INFINITI QX70	S51	2014.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tinian island	INFINITI QX80	Z62	2019.NULL –	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tinian island	INFINITI QX80	Z62	2019.NULL –	Laser/radar	√	√	√	√	AC0994	
Tinian island	INFINITI QX80	Z62	2019.NULL –	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tinian island	INFINITI QX80	Z62	2019.NULL –	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tinian island	INFINITI QX80	Z62	2019.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tinian island	INFINITI QX80	Z62	2019.NULL –	Air bag	√	√	√	√		
Tinian island	INFINITI QX80	Z62	2019.NULL –	EPS/DAST 3	√	√	√	√		SP0507
Tinian island	INFINITI QX80	Z62	2019.NULL –	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Tinian island	INFINITI QX80	Z62	2019.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tinian island	INFINITI QX80	Z62	2019.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tinian island	INFINITI QX80	Z62	2019.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Tinian island	INFINITI QX80	Z62	2019.NULL –	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tinian island	INFINITI QX80	Z62	2019.NULL –	Multi AV	√	√	√	√		SP0503
Tinian island	INFINITI QX80	Z62	2019.NULL –	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Tinian island	INFINITI QX80	Z62	2019.NULL –	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Tinian island	INFINITI QX80	Z62	2019.NULL –	Difference lock	√	√	√	√		
Tinian island	INFINITI QX80	Z62	2019.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tinian island	INFINITI QX80	Z62	2019.NULL –	Auto back door	√	√	√	√		
Tinian island	INFINITI QX80	Z62	2019.NULL –	Occupant detection			√	√		SP0584
Tinian island	INFINITI QX80	Z62	2019.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tinian island	INFINITI QX80	Z62	2019.NULL –	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tinian island	INFINITI QX80	Z62	2019.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tinian island	INFINITI QX80	Z62	2019.NULL –	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Tinian island	INFINITI QX80	Z62	2019.NULL –	Precrash seatbelt	√	√	√	√		SP0612
Tinian island	INFINITI QX80	Z62	2019.NULL –	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tinian island	INFINITI QX80	Z62	2019.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Tinian island	INFINITI QX80	Z62	2019.NULL –	CAN gateway	√	√	√			
Tinian island	INFINITI QX80	Z62	2019.NULL –	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tinian island	INFINITI QX80	Z62	2019.NULL –	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tinian island	INFINITI QX80	Z62	2019.NULL –	Side radar left	√	√	√	√	AC1025	SP0582
Tinian island	INFINITI QX80	Z62	2019.NULL –	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tinian island	INFINITI QX80	Z62	2019.NULL –	HIGH BEAM ASSIST	√	√	√	√		
Tinian island	INFINITI QX80	Z62	2019.NULL –	Side radar right	√	√	√	√	AC1026	SP0583
Tinian island	INFINITI QX80	Z62	2019.NULL –	6ch CAN GATEWAY	√	√	√	√		
Tinian island	INFINITI QX80	Z62	2019.NULL –	ICC/ADAS 2	√	√	√	√		
Tinian island	INFINITI QX80	Z62	2019.NULL –	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Togo	INFINITI EX35/EX37	J50	2011.1–	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI EX35/EX37	J50	2011.1–	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Togo	INFINITI EX35/EX37	J50	2011.1–	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Togo	INFINITI EX35/EX37	J50	2011.1–	Air bag	√	√	√	√		
Togo	INFINITI EX35/EX37	J50	2011.1–	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Togo	INFINITI EX35/EX37	J50	2011.1–	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Togo	INFINITI EX35/EX37	J50	2011.1–	Transmission	√	√	√	√		SP0270, SP0274
Togo	INFINITI EX35/EX37	J50	2011.1–	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Togo	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Togo	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Togo	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Togo	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Togo	INFINITI EX35/EX37	I50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Togo	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Togo	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Togo	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Togo	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Togo	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Togo	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Togo	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Togo	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Togo	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Togo	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Togo	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Togo	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Togo	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Togo	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Togo	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Togo	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Togo	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Togo	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Togo	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Togo	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Togo	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Togo	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Togo	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Togo	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Togo	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Togo	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Togo	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Togo	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Togo	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Togo	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Togo	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Togo	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Togo	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Togo	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Togo	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Togo	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Togo	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Togo	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Togo	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Togo	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Togo	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Togo	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Togo	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Togo	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Togo	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Togo	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Togo	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Togo	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Togo	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Togo	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Togo	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Togo	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Togo	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Togo	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Togo	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Togo	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Togo	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Togo	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Togo	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Togo	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Togo	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Togo	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Togo	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Togo	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Togo	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Togo	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Togo	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Togo	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Togo	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Togo	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Togo	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Togo	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Togo	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Togo	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Togo	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Togo	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Togo	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Togo	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Togo	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Togo	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Togo	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Togo	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Togo	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Togo	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Togo	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Togo	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Togo	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Togo	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Togo	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Togo	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Togo	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Togo	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Togo	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Togo	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Togo	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Togo	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Togo	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Togo	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Togo	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		

Xtool

Togo	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Togo	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Togo	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Togo	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Togo	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Togo	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Togo	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Togo	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Togo	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Togo	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Togo	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Togo	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Togo	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Togo	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Togo	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Togo	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Togo	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Togo	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Togo	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Togo	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Togo	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Togo	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Togo	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Togo	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Togo	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Togo	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Togo	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Togo	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Togo	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Togo	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Togo	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Togo	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Togo	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Togo	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Togo	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Togo	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Togo	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Togo	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Togo	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Togo	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Togo	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Togo	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Togo	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Togo	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Togo	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Togo	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Togo	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Togo	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Togo	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Togo	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	

Togo	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Togo	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Togo	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Togo	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Togo	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Togo	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Togo	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Togo	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Togo	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Togo	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Togo	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Togo	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Togo	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Togo	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Togo	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Togo	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Togo	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Togo	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Togo	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Togo	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Togo	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Togo	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Togo	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Togo	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Togo	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Togo	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Togo	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Togo	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Togo	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Togo	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Togo	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Togo	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Togo	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Togo	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Togo	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Togo	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Togo	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Togo	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
Togo	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Togo	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Togo	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Togo	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
Togo	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Togo	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Togo	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Togo	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Togo	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Togo	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Togo	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Togo	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Togo	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
Togo	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0313,SP0315,SP0316,SP0317,SP0319
Togo	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Togo	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Togo	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Togo	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Togo	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584

XTOOL

Togo	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Togo	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Togo	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Togo	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Togo	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Togo	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Togo	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Togo	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Togo	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Togo	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Togo	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Togo	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Togo	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Togo	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Togo	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Togo	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Togo	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Togo	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Togo	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Togo	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Togo	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Togo	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Togo	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Togo	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Togo	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Togo	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Togo	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Togo	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Togo	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Togo	INFINITI QX50	I50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Togo	INFINITI QX50	I50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Togo	INFINITI QX50	I50	2013.8-	CAN gateway	√	√	√	√		
Togo	INFINITI QX50	I50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Togo	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Togo	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Togo	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Togo	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Togo	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Togo	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Togo	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Togo	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Togo	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Togo	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Togo	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Togo	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Togo	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Togo	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Togo	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Togo	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Togo	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Togo	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Togo	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Togo	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Togo	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Togo	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Togo	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Togo	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Togo	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Togo	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Togo	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Togo	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Togo	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Togo	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Togo	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Togo	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Togo	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Togo	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Togo	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Togo	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Togo	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Togo	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Togo	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Togo	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Togo	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Togo	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Togo	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Togo	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Togo	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Togo	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Togo	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Togo	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Togo	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Togo	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Togo	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Togo	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Togo	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Togo	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Togo	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Togo	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Togo	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Togo	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Togo	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Togo	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Togo	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			

Togo	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Togo	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Togo	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Togo	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Togo	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Togo	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Togo	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Togo	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Togo	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
Trinidad	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Trinidad	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Trinidad	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Trinidad	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Trinidad	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0051,AC0052,AC0053,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0147,AC0148,AC0149,AC0150,AC0154,AC0155,AC0156,AC0157,AC0160,AC0162,AC0164,AC0166,AC0168,AC0171,AC0172,AC0173,AC0174,AC0178,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0053,SP0063,SP0064,SP0074,SP0079,SP0085,SP0086,SP0087,SP0104,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Trinidad	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270,SP0274
Trinidad	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Trinidad	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Trinidad	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Trinidad	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Trinidad	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Trinidad	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Trinidad	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Trinidad	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Trinidad	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Trinidad	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Trinidad	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Trinidad	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
Trinidad	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Trinidad	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Trinidad	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Trinidad	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0556,SP0557
Trinidad	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Trinidad	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Trinidad	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
Trinidad	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Trinidad	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570,SP0571
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Trinidad	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0884	SP0494
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0200,SP0202,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239

XTOOL

Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Trinidad	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Trinidad	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Trinidad	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Trinidad	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Trinidad	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Trinidad	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Trinidad	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Trinidad	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Trinidad	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Trinidad	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Trinidad	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Trinidad	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Trinidad	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Trinidad	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Trinidad	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Trinidad	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Trinidad	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Trinidad	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Trinidad	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Trinidad	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Trinidad	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Trinidad	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Trinidad	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Trinidad	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Trinidad	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Trinidad	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Trinidad	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Trinidad	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Trinidad	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Trinidad	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Trinidad	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Trinidad	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Trinidad	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Trinidad	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Trinidad	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Trinidad	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Trinidad	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Trinidad	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Trinidad	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Trinidad	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Trinidad	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Trinidad	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Trinidad	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Trinidad	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Trinidad	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Trinidad	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Trinidad	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Trinidad	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Trinidad	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Trinidad	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Trinidad	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Trinidad	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Trinidad	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Trinidad	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Trinidad	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Trinidad	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Trinidad	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Trinidad	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Trinidad	INFINITI Q45	F50	2001.8-	Motor control						

Trinidad	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Trinidad	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Trinidad	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Trinidad	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Trinidad	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Trinidad	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Trinidad	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Trinidad	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Trinidad	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Trinidad	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Trinidad	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Trinidad	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Trinidad	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Trinidad	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Trinidad	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Trinidad	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Trinidad	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Trinidad	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Trinidad	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Trinidad	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Trinidad	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Trinidad	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Trinidad	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Trinidad	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Trinidad	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Trinidad	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Trinidad	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Trinidad	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Trinidad	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Trinidad	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Trinidad	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Trinidad	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Trinidad	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Trinidad	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Trinidad	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Trinidad	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Trinidad	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Trinidad	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Trinidad	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Trinidad	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Trinidad	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Trinidad	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Trinidad	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Trinidad	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Trinidad	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Trinidad	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Trinidad	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Trinidad	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Trinidad	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Trinidad	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Trinidad	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Trinidad	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Trinidad	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Trinidad	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Trinidad	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Tunisia	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tunisia	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Tunisia	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tunisia	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tunisia	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Tunisia	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tunisia	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tunisia	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tunisia	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tunisia	INFINITI EX35/EX37	I50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tunisia	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Tunisia	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Tunisia	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Tunisia	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Tunisia	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tunisia	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Tunisia	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Tunisia	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tunisia	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Tunisia	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Tunisia	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tunisia	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Tunisia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Tunisia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Tunisia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tunisia	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Tunisia	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Tunisia	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Tunisia	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tunisia	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Tunisia	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Tunisia	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tunisia	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tunisia	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Tunisia	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Tunisia	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Tunisia	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tunisia	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tunisia	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tunisia	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tunisia	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tunisia	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tunisia	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Tunisia	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Tunisia	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Tunisia	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tunisia	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tunisia	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Tunisia	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Tunisia	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Tunisia	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Tunisia	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Tunisia	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Tunisia	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Tunisia	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Tunisia	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Tunisia	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Tunisia	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Tunisia	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Tunisia	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Tunisia	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Tunisia	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Tunisia	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Tunisia	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Tunisia	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Tunisia	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Tunisia	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Tunisia	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Tunisia	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Tunisia	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Tunisia	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Tunisia	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Tunisia	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tunisia	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Tunisia	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tunisia	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Tunisia	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Tunisia	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tunisia	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tunisia	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Tunisia	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tunisia	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Tunisia	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Tunisia	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tunisia	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tunisia	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Tunisia	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Tunisia	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tunisia	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Tunisia	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Tunisia	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Tunisia	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Tunisia	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tunisia	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Tunisia	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	

Tunisia	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tunisia	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Tunisia	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Tunisia	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Tunisia	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tunisia	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Tunisia	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Tunisia	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tunisia	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tunisia	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Tunisia	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Tunisia	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Tunisia	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Tunisia	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tunisia	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Tunisia	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tunisia	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Tunisia	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Tunisia	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tunisia	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tunisia	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Tunisia	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Tunisia	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tunisia	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Tunisia	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tunisia	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tunisia	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Tunisia	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tunisia	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tunisia	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Tunisia	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Tunisia	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Tunisia	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Tunisia	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Tunisia	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Tunisia	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Tunisia	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tunisia	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Tunisia	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Tunisia	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Tunisia	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Tunisia	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Tunisia	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tunisia	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Tunisia	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Tunisia	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Tunisia	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Tunisia	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		

Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tunisia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tunisia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tunisia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tunisia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Tunisia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tunisia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Tunisia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Tunisia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Tunisia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tunisia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Tunisia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Tunisia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Tunisia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Tunisia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Tunisia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tunisia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Tunisia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tunisia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tunisia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Tunisia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Tunisia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Tunisia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tunisia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Tunisia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tunisia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tunisia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tunisia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Tunisia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tunisia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Tunisia	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tunisia	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Tunisia	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tunisia	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Tunisia	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Tunisia	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Tunisia	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tunisia	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Tunisia	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tunisia	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Tunisia	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tunisia	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tunisia	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tunisia	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Tunisia	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Tunisia	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tunisia	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Tunisia	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tunisia	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Tunisia	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Tunisia	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tunisia	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Tunisia	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Tunisia	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Tunisia	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Tunisia	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Tunisia	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Tunisia	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Tunisia	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Tunisia	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Tunisia	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Tunisia	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Tunisia	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Tunisia	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Tunisia	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Tunisia	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Tunisia	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Tunisia	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Tunisia	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tunisia	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Tunisia	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Tunisia	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Tunisia	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Tunisia	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Tunisia	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tunisia	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Tunisia	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tunisia	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Tunisia	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Tunisia	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tunisia	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Tunisia	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Tunisia	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Tunisia	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Tunisia	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Tunisia	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Tunisia	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Tunisia	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Tunisia	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Tunisia	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Tunisia	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Tunisia	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Tunisia	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Tunisia	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Tunisia	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Tunisia	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Tunisia	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Tunisia	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Tunisia	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Tunisia	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Tunisia	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Tunisia	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Tunisia	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Tunisia	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Tunisia	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Tunisia	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Tunisia	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Tunisia	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Tunisia	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Tunisia	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Tunisia	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Tunisia	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Tunisia	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Tunisia	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Tunisia	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Tunisia	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkey	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Turkey	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Turkey	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkey	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkey	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Turkey	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Turkey	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Turkey	INFINITI EX37	J50	2008.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Turkey	INFINITI EX37	J50	2008.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI EX37	J50	2008.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkey	INFINITI EX37	J50	2008.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI EX37	J50	2008.6-	Air bag	√	√	√	√		
Turkey	INFINITI EX37	J50	2008.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkey	INFINITI EX37	J50	2008.6-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Turkey	INFINITI EX37	J50	2008.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Turkey	INFINITI EX37	J50	2008.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkey	INFINITI EX37	J50	2008.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Turkey	INFINITI EX37	J50	2008.6-	Multi AV	√	√	√	√		
Turkey	INFINITI EX37	J50	2008.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI EX37	J50	2008.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkey	INFINITI EX37	J50	2008.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkey	INFINITI EX37	J50	2008.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkey	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Turkey	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Turkey	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Turkey	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Turkey	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Turkey	INFINITI FX35/FX45	S50	2006.7-	BCM					AC0653, AC0695	SP0372, SP0429
Turkey	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Turkey	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Turkey	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Turkey	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Turkey	INFINITI FX37/FX50	S51	2009.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Turkey	INFINITI FX37/FX50	S51	2009.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Turkey	INFINITI FX37/FX50	S51	2009.3-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI FX37/FX50	S51	2009.3-	Air bag	√	√	√	√		
Turkey	INFINITI FX37/FX50	S51	2009.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkey	INFINITI FX37/FX50	S51	2009.3-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Turkey	INFINITI FX37/FX50	S51	2009.3-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Turkey	INFINITI FX37/FX50	S51	2009.3-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkey	INFINITI FX37/FX50	S51	2009.3-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Turkey	INFINITI FX37/FX50	S51	2009.3-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Turkey	INFINITI FX37/FX50	S51	2009.3-	Multi AV	√	√	√	√		
Turkey	INFINITI FX37/FX50	S51	2009.3-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkey	INFINITI FX37/FX50	S51	2009.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI FX37/FX50	S51	2009.3-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkey	INFINITI FX37/FX50	S51	2009.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkey	INFINITI FX37/FX50	S51	2009.3-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkey	INFINITI FX37/FX50	S51	2009.3-	CAN gateway	√	√	√			
Turkey	INFINITI FX37/FX50	S51	2009.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611

Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Turkey	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Turkey	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkey	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Turkey	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Turkey	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkey	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Turkey	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Turkey	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Turkey	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Turkey	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkey	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Turkey	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Turkey	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkey	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkey	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Turkey	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkey	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Turkey	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkey	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkey	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkey	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkey	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Turkey	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI G37 SEDAN	V36	2008.7-	Laser/radar	√	√	√	√		
Turkey	INFINITI G37 SEDAN	V36	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI G37 SEDAN	V36	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkey	INFINITI G37 SEDAN	V36	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI G37 SEDAN	V36	2008.7-	Air bag	√	√	√	√		
Turkey	INFINITI G37 SEDAN	V36	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkey	INFINITI G37 SEDAN	V36	2008.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Turkey	INFINITI G37 SEDAN	V36	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Turkey	INFINITI G37 SEDAN	V36	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkey	INFINITI G37 SEDAN	V36	2008.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI G37 SEDAN	V36	2008.7-	Pop up hood	√	√	√	√		
Turkey	INFINITI G37 SEDAN	V36	2008.7-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI G37 SEDAN	V36	2008.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkey	INFINITI G37 SEDAN	V36	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI G37 SEDAN	V36	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkey	INFINITI G37 SEDAN	V36	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkey	INFINITI G37 SEDAN	V36	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Turkey	INFINITI G37 SEDAN	V36	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Turkey	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Turkey	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Turkey	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Turkey	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Turkey	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Turkey	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Turkey	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Turkey	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Turkey	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Turkey	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Turkey	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Turkey	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Turkey	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Turkey	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Turkey	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Turkey	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Turkey	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Turkey	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Turkey	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Turkey	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkey	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		
Turkey	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Turkey	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Turkey	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Turkey	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Turkey	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Turkey	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Turkey	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Turkey	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Turkey	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Turkey	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkey	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkey	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkey	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Turkey	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Turkey	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Turkey	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Turkey	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Turkey	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Turkey	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Motor control	√	√	√	√		
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	HV battery	√	√	√	√	AC1121	
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	

Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Turkey	INFINITI M37/M56/M30D	Y51	2010.4-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Turkey	INFINITI Q30	H15	2015.11-	Air pressure monitor	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	Air bag	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	EPS/DAST 3	√	√	√			
Turkey	INFINITI Q30	H15	2015.11-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Turkey	INFINITI Q30	H15	2015.11-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Turkey	INFINITI Q30	H15	2015.11-	EHS/PKB	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	Transmission	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Turkey	INFINITI Q30	H15	2015.11-	ABS	√	√	√	√		SP0308
Turkey	INFINITI Q30	H15	2015.11-	Multi AV	√	√	√	√		SP0501
Turkey	INFINITI Q30	H15	2015.11-	HVAC	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	Auto drive position	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	Shift	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	All mode AWD/4WD	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	AVM	√	√		√		
Turkey	INFINITI Q30	H15	2015.11-	Intelligent key	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	CAN gateway	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	ANC	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	Telematics	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	FSCM	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	Siren control unit	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Turkey	INFINITI Q30	H15	2015.11-	Overhead Control Panel Unit	√			√		
Turkey	INFINITI Q30	H15	2015.11-	Universal Garage Door Opener	√			√		
Turkey	INFINITI Q30	H15	2015.11-	Upper control panel cont unit	√					
Turkey	INFINITI Q30	H15	2015.11-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Turkey	INFINITI Q30	H15	2015.11-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Turkey	INFINITI Q30	H15	2015.11-	Light/Rain Sensor Module	√			√		
Turkey	INFINITI Q30	H15	2015.11-	EC Mirror Compass	√					
Turkey	INFINITI Q30	H15	2015.11-	Intelligent Battery Sensor	√					
Turkey	INFINITI Q30	H15	2015.11-	Alarm siren	√			√		
Turkey	INFINITI Q30	H15	2015.11-	Radar sensor	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	Steering column cont module	√	√	√			
Turkey	INFINITI Q30	H15	2015.11-	ICC sensor	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	Trailer recognition control unit	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	H/L control module LH	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	Powertrain cont module	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	Side radar LH	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	LED H/L control module LH	√			√		
Turkey	INFINITI Q30	H15	2015.11-	Steering Wheel Switch Pad	√			√		
Turkey	INFINITI Q30	H15	2015.11-	Parking assist	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	Occupant Classification Unit	√			√		
Turkey	INFINITI Q30	H15	2015.11-	Electronic Ignition Switch cont unit	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	H/L control module RH	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	Front camera unit	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	Side radar RH	√	√	√	√		
Turkey	INFINITI Q30	H15	2015.11-	LED H/L control module RH	√			√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Turkey	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Turkey	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Turkey	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Turkey	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Turkey	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Turkey	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Turkey	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Turkey	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Turkey	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Turkey	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Turkey	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Turkey	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Turkey	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		

XTOOL

Turkey	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Turkey	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Turkey	INFINITI Q50	V37	2013.6-	Air pressure monitor	√	√	√	√	AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509
Turkey	INFINITI Q50	V37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Turkey	INFINITI Q50	V37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI Q50	V37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkey	INFINITI Q50	V37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI Q50	V37	2013.6-	Air bag	√	√	√	√		
Turkey	INFINITI Q50	V37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Turkey	INFINITI Q50	V37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkey	INFINITI Q50	V37	2013.6-	Motor control	√	√	√	√		
Turkey	INFINITI Q50	V37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkey	INFINITI Q50	V37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Turkey	INFINITI Q50	V37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Turkey	INFINITI Q50	V37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Turkey	INFINITI Q50	V37	2013.6-	Pop up hood	√	√	√	√		
Turkey	INFINITI Q50	V37	2013.6-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI Q50	V37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Turkey	INFINITI Q50	V37	2013.6-	HV battery	√	√	√	√	AC1121	
Turkey	INFINITI Q50	V37	2013.6-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkey	INFINITI Q50	V37	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkey	INFINITI Q50	V37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI Q50	V37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Turkey	INFINITI Q50	V37	2013.6-	Occupant detection			√	√		SP0584
Turkey	INFINITI Q50	V37	2013.6-	Adaptive light	√	√	√	√	AC0978、AC0979、AC0980、AC0981、AC0982	SP0561、SP0562
Turkey	INFINITI Q50	V37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029、AC1030	
Turkey	INFINITI Q50	V37	2013.6-	Sonar	√	√	√	√	AC0962、AC0963、AC0964、AC0966、AC0967、AC0968、AC0969、AC0970	SP0553、SP0554、SP0555、SP0556、SP0557、SP0558、SP0559
Turkey	INFINITI Q50	V37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956、AC0958、AC0959、AC0960	SP0544、SP0545、SP0546、SP0547、SP0548、SP0549、SP0550、SP0551
Turkey	INFINITI Q50	V37	2013.6-	DAST 2	√	√	√	√		
Turkey	INFINITI Q50	V37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Turkey	INFINITI Q50	V37	2013.6-	AVM	√	√	√	√	AC0983、AC0984、AC0985、AC0986、AC0987、AC0988、AC0989、AC0990	SP0563、SP0564、SP0565、SP0566、SP0567
Turkey	INFINITI Q50	V37	2013.6-	Intelligent key	√	√	√	√		SP0511、SP0515、SP0516、SP0538、SP0539、SP0540
Turkey	INFINITI Q50	V37	2013.6-	CAN gateway	√	√	√	√		
Turkey	INFINITI Q50	V37	2013.6-	Lane camera	√	√	√	√	AC0973、AC0974、AC0976、AC0977	
Turkey	INFINITI Q50	V37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI Q50	V37	2013.6-	DAST 1	√	√	√	√		
Turkey	INFINITI Q50	V37	2013.6-	ADCM	√	√	√	√		SP0604、SP0605、SP0606
Turkey	INFINITI Q50	V37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Turkey	INFINITI Q50	V37	2013.6-	BSW/buzzer	√	√	√	√	AC1014、AC1015、AC1016、AC1017、AC1018、AC1019、AC1020、AC1021、AC1022、AC1023	
Turkey	INFINITI Q50	V37	2013.6-	ANC	√	√	√	√	AC1024	
Turkey	INFINITI Q50	V37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Turkey	INFINITI Q50	V37	2013.6-	EMCM	√	√	√	√	AC1111、AC1112	SP0608、SP0609、SP0610
Turkey	INFINITI Q50	V37	2013.6-	Telematics	√	√	√	√		SP0590、SP0591、SP0592
Turkey	INFINITI Q50	V37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Turkey	INFINITI Q50	V37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Turkey	INFINITI Q50	V37	2013.6-	Brake	√	√	√	√	AC1127	
Turkey	INFINITI Q50	V37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Turkey	INFINITI Q50	V37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Turkey	INFINITI Q50	V37	2013.6-	ICC/ADAS 2	√	√	√	√		
Turkey	INFINITI Q50	V37	2013.6-	PMAS	√	√	√	√		
Turkey	INFINITI Q50	V37	2013.6-	FSCM	√	√	√	√	AC1109	
Turkey	INFINITI Q50	V37	2013.6-	VSP	√	√	√	√	AC1122、AC1123、AC1124、AC1125、AC1126	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897、AC0898、AC0899、AC0900、AC0901、AC0902	SP0508、SP0509
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√	AC0994	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	3ch CAN GATEWAY	√	√	√	√		
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS 2	√	√	√	√		
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	FSCM	√	√	√	√	AC1109	
Turkey	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Laser/radar	√	√	√	√		
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Air bag	√	√	√	√		
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	EPS/DAST 3	√	√	√	√		
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Motor control	√	√	√	√		
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Transmission	√	√	√	√		SP0276
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Pop up hood	√	√	√	√		
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	HV battery	√	√	√	√	AC1121	
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Occupant detection			√	√		SP0584
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 2	√	√	√	√		
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Precrash seatbelt	√	√	√	√		SP0612
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	DAST 1	√	√	√	√		
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	ANC	√	√	√	√	AC1024	
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar left	√	√	√	√	AC1025	SP0582
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	HIGH BEAM ASSIST	√	√	√	√		
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Side radar right	√	√	√	√	AC1026	SP0583
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	VSP	√	√	√	√		
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	Brake	√	√	√	√	AC1127	
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	6ch CAN GATEWAY	√	√	√	√		
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	ICC/ADAS 2	√	√	√	√		
Turkey	INFINITI Q50 Hybrid	HV37	2018.10-	A-IVC(Renault common)	√	√	√	√		
Turkey	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Turkey	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Turkey	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkey	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Turkey	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Turkey	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkey	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkey	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Turkey	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Turkey	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Turkey	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Turkey	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Turkey	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Turkey	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Turkey	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkey	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkey	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkey	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Turkey	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Turkey	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Turkey	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Turkey	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Turkey	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Turkey	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Turkey	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Turkey	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Turkey	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Turkey	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkey	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Turkey	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Turkey	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Turkey	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Turkey	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Turkey	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkey	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkey	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Turkey	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Turkey	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkey	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Turkey	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Turkey	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkey	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Turkey	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
Turkey	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Turkey	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Turkey	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Turkey	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkey	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkey	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Turkey	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Turkey	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkey	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkey	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Turkey	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Turkey	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkey	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Turkey	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Turkey	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Turkey	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Turkey	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Turkey	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Turkey	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkey	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Turkey	INFINITI Q70	Y51	2013.9-	PTC heater	√	√	√	√	AC1107, AC1108	
Turkey	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Turkey	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Turkey	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Laser/radar	√	√	√	√		
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Air bag	√	√	√	√		
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	EPS/DAST 3	√	√	√	√		
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Motor control	√	√	√	√		
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Pop up hood	√	√	√	√		
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Multi AV	√	√	√	√		SP0503

Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	HV battery	√	√	√	√	AC1121	
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Occupant detection			√	√		SP0584
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	CAN gateway	√	√	√			
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	Brake	√	√	√	√	AC1127	
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	ICC/ADAS 2	√	√	√	√		
Turkey	INFINITI Q70 HYBRID	HY51	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Turkey	INFINITI QX50	J50	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Turkey	INFINITI QX50	J50	2013.9-	Laser/radar	√	√	√	√	AC0994	
Turkey	INFINITI QX50	J50	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI QX50	J50	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkey	INFINITI QX50	J50	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI QX50	J50	2013.9-	Air bag	√	√	√	√		
Turkey	INFINITI QX50	J50	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Turkey	INFINITI QX50	J50	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkey	INFINITI QX50	J50	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Turkey	INFINITI QX50	J50	2013.9-	Transmission	√	√	√	√		SP0274
Turkey	INFINITI QX50	I50	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkey	INFINITI QX50	J50	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI QX50	J50	2013.9-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI QX50	J50	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI QX50	I50	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkey	INFINITI QX50	I50	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkey	INFINITI QX50	I50	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkey	INFINITI QX50	J50	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkey	INFINITI QX50	J50	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Turkey	INFINITI QX50	J50	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkey	INFINITI QX50	J50	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Turkey	INFINITI QX50	J50	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Turkey	INFINITI QX50	J50	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Turkey	INFINITI QX50	J50	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkey	INFINITI QX50	J50	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Turkey	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Turkey	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Turkey	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Turkey	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Turkey	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Turkey	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Turkey	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429
Turkey	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkey	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Turkey	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Turkey	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Turkey	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkey	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Turkey	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Turkey	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Turkey	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Turkey	INFINITI QX70	S51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Turkey	INFINITI QX70	S51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Turkey	INFINITI QX70	S51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkey	INFINITI QX70	S51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkey	INFINITI QX70	S51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkey	INFINITI QX70	S51	2013.9-	Air bag	√	√	√	√		
Turkey	INFINITI QX70	S51	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Turkey	INFINITI QX70	S51	2013.9-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkey	INFINITI QX70	S51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Turkey	INFINITI QX70	S51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Turkey	INFINITI QX70	S51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkey	INFINITI QX70	S51	2013.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Turkey	INFINITI QX70	S51	2013.9-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Turkey	INFINITI QX70	S51	2013.9-	Multi AV	√	√	√	√		SP0503
Turkey	INFINITI QX70	S51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkey	INFINITI QX70	S51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkey	INFINITI QX70	S51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkey	INFINITI QX70	S51	2013.9-	Auto back door	√	√	√	√		SP0611
Turkey	INFINITI QX70	S51	2013.9-	Occupant detection			√	√		SP0584
Turkey	INFINITI QX70	S51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkey	INFINITI QX70	S51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkey	INFINITI QX70	S51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Turkey	INFINITI QX70	S51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkey	INFINITI QX70	S51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Turkey	INFINITI QX70	S51	2013.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Turkey	INFINITI QX70	S51	2013.9-	CAN gateway	√	√	√			
Turkey	INFINITI QX70	S51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Turkey	INFINITI QX70	S51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkey	INFINITI QX70	S51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Turkey	INFINITI QX70	S51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Turkey	INFINITI QX70	S51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkey	INFINITI QX70	S51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583

Turkey	INFINITI QX70	S51	2013.9-	ICC/ADAS 2	√	√	√	√		
Turkmenistan	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkmenistan	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Turkmenistan	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkmenistan	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Turkmenistan	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Turkmenistan	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkmenistan	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkmenistan	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkmenistan	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkmenistan	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		

Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Turkmenistan	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		

Turkmenistan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Turkmenistan	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	

Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Turkmenistan	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Turkmenistan	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Turkmenistan	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkmenistan	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Turkmenistan	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Turkmenistan	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkmenistan	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Turkmenistan	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Turkmenistan	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Turkmenistan	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkmenistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503

Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Turkmenistan	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Turkmenistan	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Turkmenistan	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Turkmenistan	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Turkmenistan	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Turkmenistan	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkmenistan	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Turkmenistan	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Turkmenistan	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Turkmenistan	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Turkmenistan	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Turkmenistan	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Turkmenistan	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkmenistan	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Turkmenistan	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Turkmenistan	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	

Turkmenistan	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Turkmenistan	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Turkmenistan	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Turkmenistan	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Turkmenistan	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Turkmenistan	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Turkmenistan	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Turkmenistan	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Turkmenistan	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Turkmenistan	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Turkmenistan	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Turkmenistan	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Turkmenistan	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Turkmenistan	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		

Turkmenistan	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Turkmenistan	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Turkmenistan	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Turkmenistan	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Turkmenistan	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510

XTOOL

Turkmenistan	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Turkmenistan	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkmenistan	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Turkmenistan	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Turkmenistan	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Turkmenistan	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Turkmenistan	INFINITI Q45	F50	2001.8-	Motor control						
Turkmenistan	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Turkmenistan	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Turkmenistan	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Turkmenistan	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Turkmenistan	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Turkmenistan	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Turkmenistan	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Turkmenistan	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Turkmenistan	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Turkmenistan	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Turkmenistan	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Turkmenistan	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Turkmenistan	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Turkmenistan	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Turkmenistan	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Turkmenistan	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Turkmenistan	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Turkmenistan	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Turkmenistan	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Turkmenistan	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Turkmenistan	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Turkmenistan	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Turkmenistan	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Turkmenistan	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Turkmenistan	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkmenistan	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Turkmenistan	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Turkmenistan	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkmenistan	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Turkmenistan	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Turkmenistan	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Turkmenistan	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Turkmenistan	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Turkmenistan	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkmenistan	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkmenistan	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562

Turkmenistan	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Turkmenistan	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Turkmenistan	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Turkmenistan	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Turkmenistan	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Turkmenistan	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Turkmenistan	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Turkmenistan	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Turkmenistan	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Turkmenistan	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Turkmenistan	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Turkmenistan	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkmenistan	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Turkmenistan	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Turkmenistan	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Turkmenistan	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Turkmenistan	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Turkmenistan	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Turkmenistan	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Turkmenistan	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Turkmenistan	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582

Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Turkmenistan	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0009,SP0016,SP0032,SP0033,SP0038,SP0039,SP0053,SP0063,SP0064,SP0074,SP0079,SP0082,SP0085,SP0086,SP0087,SP0103,SP0104,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0239
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Turkmenistan	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Turkmenistan	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Turkmenistan	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Turkmenistan	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Turkmenistan	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Turkmenistan	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Turkmenistan	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Turkmenistan	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Turkmenistan	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Turkmenistan	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274

Turkmenistan	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Turkmenistan	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Turkmenistan	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Turkmenistan	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Turkmenistan	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkmenistan	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Turkmenistan	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkmenistan	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Turkmenistan	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Turkmenistan	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Turkmenistan	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Turkmenistan	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Turkmenistan	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Turkmenistan	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Turkmenistan	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Turkmenistan	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkmenistan	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Turkmenistan	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Turkmenistan	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Turkmenistan	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Turkmenistan	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Turkmenistan	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Turkmenistan	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkmenistan	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Turkmenistan	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Turkmenistan	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkmenistan	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Turkmenistan	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Turkmenistan	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Turkmenistan	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Turkmenistan	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Turkmenistan	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Turkmenistan	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Turkmenistan	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkmenistan	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkmenistan	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Turkmenistan	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Turkmenistan	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Turkmenistan	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Turkmenistan	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Turkmenistan	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Turkmenistan	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Turkmenistan	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Turkmenistan	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkmenistan	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Turkmenistan	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Turkmenistan	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Turkmenistan	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Turkmenistan	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Turkmenistan	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Turkmenistan	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Turkmenistan	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkmenistan	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Turkmenistan	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Turkmenistan	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkmenistan	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Turkmenistan	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Turkmenistan	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkmenistan	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkmenistan	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkmenistan	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Turkmenistan	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Turkmenistan	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Turkmenistan	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkmenistan	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Turkmenistan	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Turkmenistan	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Turkmenistan	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Turkmenistan	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Turkmenistan	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Turkmenistan	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Turkmenistan	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Turkmenistan	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI QX50	J55	2018.5-	Shift						
Turkmenistan	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Turkmenistan	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	ANC						
Turkmenistan	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkmenistan	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583

Turkmenistan	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Turkmenistan	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Turkmenistan	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Turkmenistan	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Turkmenistan	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Turkmenistan	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Turkmenistan	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Turkmenistan	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Turkmenistan	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Turkmenistan	INFINITI QX56	JA60	2004.10-	Motor control						
Turkmenistan	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Turkmenistan	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Turkmenistan	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Turkmenistan	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Turkmenistan	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Turkmenistan	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Turkmenistan	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Turkmenistan	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Turkmenistan	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Turkmenistan	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Turkmenistan	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Turkmenistan	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Turkmenistan	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Turkmenistan	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Turkmenistan	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Turkmenistan	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Turkmenistan	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Turkmenistan	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Turkmenistan	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Turkmenistan	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Turkmenistan	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Turkmenistan	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Turkmenistan	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Turkmenistan	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Turkmenistan	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Turkmenistan	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Turkmenistan	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Turkmenistan	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Turkmenistan	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270, SP0274
Turkmenistan	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Turkmenistan	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Turkmenistan	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Turkmenistan	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Turkmenistan	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Turkmenistan	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Turkmenistan	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Turkmenistan	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Turkmenistan	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Turkmenistan	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkmenistan	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Turkmenistan	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Turkmenistan	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkmenistan	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Turkmenistan	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Turkmenistan	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkmenistan	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Turkmenistan	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Turkmenistan	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Turkmenistan	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Turkmenistan	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Turkmenistan	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Turkmenistan	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Turkmenistan	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Turkmenistan	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkmenistan	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Turkmenistan	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Turkmenistan	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Turkmenistan	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Turkmenistan	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Turkmenistan	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkmenistan	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Turkmenistan	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Turkmenistan	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Turkmenistan	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Turkmenistan	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315

Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Turkmenistan	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Turkmenistan	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Turkmenistan	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Turkmenistan	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkmenistan	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Turkmenistan	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Turkmenistan	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Turkmenistan	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Turkmenistan	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Turkmenistan	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Turkmenistan	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Turkmenistan	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Turkmenistan	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Turkmenistan	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkmenistan	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Turkmenistan	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Turkmenistan	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Turkmenistan	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Turkmenistan	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Turkmenistan	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Turkmenistan	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Turkmenistan	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Turkmenistan	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkmenistan	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Turkmenistan	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Turkmenistan	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Turkmenistan	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Turkmenistan	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Turkmenistan	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Turkmenistan	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Turkmenistan	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Turkmenistan	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Turkmenistan	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Turkmenistan	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Turkmenistan	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Turkmenistan	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Turkmenistan	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Turkmenistan	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Turkmenistan	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Turkmenistan	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Turkmenistan	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Turkmenistan	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Turkmenistan	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Turkmenistan	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Turkmenistan	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Turkmenistan	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Turkmenistan	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Turkmenistan	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Turkmenistan	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Turkmenistan	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Turkmenistan	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Turkmenistan	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Turkmenistan	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Turkmenistan	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Turkmenistan	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Turkmenistan	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Turkmenistan	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Turkmenistan	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Turkmenistan	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Turkmenistan	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Turkmenistan	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Turkmenistan	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
U.S.A.	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Air bag	√	√	√	√		
U.S.A.	*INFINITI EX35 CAMP:P8202	J50	2008.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	
U.S.A.	INFINITI EX35	J50	2008.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI EX35	J50	2008.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
U.S.A.	INFINITI EX35	J50	2008.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI EX35	J50	2008.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI EX35	J50	2008.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
U.S.A.	INFINITI EX35	J50	2008.NULL-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
U.S.A.	INFINITI EX35	J50	2008.NULL-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
U.S.A.	INFINITI EX35	J50	2008.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
U.S.A.	INFINITI EX35	J50	2008.NULL-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI EX35	J50	2008.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI EX35	J50	2008.NULL-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI EX35	J50	2008.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
U.S.A.	INFINITI EX35	J50	2008.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI EX35	J50	2008.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
U.S.A.	INFINITI EX35	J50	2008.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI EX35	J50	2008.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI EX35	J50	2008.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
U.S.A.	INFINITI EX35	J50	2008.NULL	BSW/buzzer	√	√	√	√	AC1022, AC1023	
U.S.A.	INFINITI EX35	J50	2008.NULL	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI EX35	J50	2008.NULL	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI EX35	J50	2008.NULL	Rearview camera	√			√		SP0570, SP0571
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Motor control						
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	HVAC	√	√	√	√		

U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Auto slide door	√	√	√	√	AC0941	
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	DIU		√	√	√		
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Adaptive light	√	√	√	√		
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	IVMS	√	√		√		
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Distance control	√	√		√		
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Active suspense system	√	√	√	√		
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Motor assist		√	√	√		SP0574
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	ASCD	√	√	√	√		
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Active engine mount	√	√	√	√		
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	TCS	√	√	√	√		
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	S/blind camera	√			√		SP0572,SP0573
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Nats immu	√	√	√			
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Rearview camera	√			√		SP0570,SP0571
U.S.A.	INFINITI FX35/FX45	S50	2003.NULL	Smart entrance						SP0568
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Engine	√	√	√	√	AC0004,AC0035,AC0036,AC0037,AC0052,AC0053,AC0062,AC0066,AC0067,AC0068,AC0148,AC0149,AC0150,AC0156,AC0164,AC0166,AC0168,AC0173,AC0174,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0016,SP0032,SP0033,SP0045,SP0051,SP0053,SP0063,SP0064,SP0074,SP0079,SP0083,SP0085,SP0086,SP0087,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0225,SP0239
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0274
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Auto back door	√	√	√	√		SP0611
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Occupant detection			√	√		SP0584
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0556
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI FX35/FX50	S51	2009.NULL	Rearview camera	√			√		SP0570,SP0571
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877	SP0494
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0350
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Transmission	√	√	√	√		SP0274
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Auto back door	√	√	√	√		SP0611
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Occupant detection			√	√		SP0584
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0556,SP0557
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
U.S.A.	INFINITI FX37/FX50	S51	2013.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI G20	CA33	2002.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
U.S.A.	INFINITI G20	CA33	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
U.S.A.	INFINITI G20	CA33	2002.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
U.S.A.	INFINITI G20	CA33	2002.NULL	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
U.S.A.	INFINITI G20	CA33	2002.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI G20	CA33	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
U.S.A.	INFINITI G20	CA33	2002.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
U.S.A.	INFINITI G20	CA33	2002.NULL	Motor control						
U.S.A.	INFINITI G20	CA33	2002.NULL	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
U.S.A.	INFINITI G20	CA33	2002.NULL	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
U.S.A.	INFINITI G20	CA33	2002.NULL	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
U.S.A.	INFINITI G20	CA33	2002.NULL	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
U.S.A.	INFINITI G20	CA33	2002.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI G20	CA33	2002.NULL	HVAC	√	√	√	√		
U.S.A.	INFINITI G20	CA33	2002.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI G20	CA33	2002.NULL	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
U.S.A.	INFINITI G20	CA33	2002.NULL	Auto slide door	√	√	√	√	AC0941	
U.S.A.	INFINITI G20	CA33	2002.NULL	DIU		√	√	√		
U.S.A.	INFINITI G20	CA33	2002.NULL	Adaptive light	√	√	√	√		
U.S.A.	INFINITI G20	CA33	2002.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
U.S.A.	INFINITI G20	CA33	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
U.S.A.	INFINITI G20	CA33	2002.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
U.S.A.	INFINITI G20	CA33	2002.NULL	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
U.S.A.	INFINITI G20	CA33	2002.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
U.S.A.	INFINITI G20	CA33	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

U.S.A.	INFINITI G20	CA33	2002.NULL	IVMS	√	√		√		
U.S.A.	INFINITI G20	CA33	2002.NULL	Distance control	√	√		√		
U.S.A.	INFINITI G20	CA33	2002.NULL	Active suspense system	√	√	√	√		
U.S.A.	INFINITI G20	CA33	2002.NULL	Motor assist		√	√	√		SP0574
U.S.A.	INFINITI G20	CA33	2002.NULL	ASCD	√	√	√	√		
U.S.A.	INFINITI G20	CA33	2002.NULL	Active engine mount	√	√	√	√		
U.S.A.	INFINITI G20	CA33	2002.NULL	TCS	√	√	√	√		
U.S.A.	INFINITI G20	CA33	2002.NULL	S/blind camera	√			√		SP0572, SP0573
U.S.A.	INFINITI G20	CA33	2002.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
U.S.A.	INFINITI G20	CA33	2002.NULL	Nats immu	√	√	√			
U.S.A.	INFINITI G20	CA33	2002.NULL	Rearview camera	√			√		SP0570, SP0571
U.S.A.	INFINITI G20	CA33	2002.NULL	Smart entrance						SP0568
U.S.A.	INFINITI G20	P11	1999.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
U.S.A.	INFINITI G20	P11	1999.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
U.S.A.	INFINITI G20	P11	1999.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
U.S.A.	INFINITI G20	P11	1999.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
U.S.A.	INFINITI G20	P11	1999.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI G20	P11	1999.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
U.S.A.	INFINITI G20	P11	1999.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
U.S.A.	INFINITI G20	P11	1999.NULL	Motor control						
U.S.A.	INFINITI G20	P11	1999.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI G20	P11	1999.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
U.S.A.	INFINITI G20	P11	1999.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
U.S.A.	INFINITI G20	P11	1999.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI G20	P11	1999.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI G20	P11	1999.NULL	HVAC	√	√	√	√		
U.S.A.	INFINITI G20	P11	1999.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI G20	P11	1999.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI G20	P11	1999.NULL	Auto slide door	√	√	√	√	AC0941	
U.S.A.	INFINITI G20	P11	1999.NULL	DIU		√	√	√		
U.S.A.	INFINITI G20	P11	1999.NULL	Adaptive light	√	√	√	√		
U.S.A.	INFINITI G20	P11	1999.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
U.S.A.	INFINITI G20	P11	1999.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
U.S.A.	INFINITI G20	P11	1999.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI G20	P11	1999.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
U.S.A.	INFINITI G20	P11	1999.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
U.S.A.	INFINITI G20	P11	1999.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI G20	P11	1999.NULL	IVMS	√	√		√		
U.S.A.	INFINITI G20	P11	1999.NULL	Distance control	√	√		√		
U.S.A.	INFINITI G20	P11	1999.NULL	Active suspense system	√	√	√	√		
U.S.A.	INFINITI G20	P11	1999.NULL	Motor assist		√	√	√		SP0574
U.S.A.	INFINITI G20	P11	1999.NULL	ASCD	√	√	√	√		
U.S.A.	INFINITI G20	P11	1999.NULL	Active engine mount	√	√	√	√		
U.S.A.	INFINITI G20	P11	1999.NULL	TCS	√	√	√	√		
U.S.A.	INFINITI G20	P11	1999.NULL	S/blind camera	√			√		SP0572, SP0573
U.S.A.	INFINITI G20	P11	1999.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
U.S.A.	INFINITI G20	P11	1999.NULL	Nats immu	√	√	√			
U.S.A.	INFINITI G20	P11	1999.NULL	Rearview camera	√			√		SP0570, SP0571
U.S.A.	INFINITI G20	P11	1999.NULL	Smart entrance						SP0568
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Air bag	√	√	√	√		
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Transmission	√	√	√	√		SP0274
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Pop up hood	√	√	√	√		
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	4WAS(front)	√	√	√	√	AC1027, AC1028	
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	Precrash seatbelt	√	√	√	√		
U.S.A.	INFINITI G25/G37 SEDAN	V36	2011.NULL_	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Motor control						
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288

U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	HVAC	√	√	√	√		
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Auto slide door	√	√	√	√	AC0941	
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	DIU		√	√	√		
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Adaptive light	√	√	√	√		
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	IVMS	√	√		√		
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Distance control	√	√		√		
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Active suspense system	√	√	√	√		
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Motor assist		√	√	√		SP0574
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	ASCD	√	√	√	√		
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Active engine mount	√	√	√	√		
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	TCS	√	√	√	√		
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	S/blind camera	√			√		SP0572, SP0573
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Nats immu	√	√	√			
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Rearview camera	√			√		SP0570, SP0571
U.S.A.	INFINITI G35 COUPE	CV35	2003.NULL	Smart entrance						SP0568
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Motor control						
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	HVAC	√	√	√	√		
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Auto slide door	√	√	√	√	AC0941	
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	DIU		√	√	√		
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Adaptive light	√	√	√	√		
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	IVMS	√	√		√		
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Distance control	√	√		√		
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Active suspense system	√	√	√	√		
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Motor assist		√	√	√		SP0574
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	ASCD	√	√	√	√		
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Active engine mount	√	√	√	√		
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	TCS	√	√	√	√		
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	S/blind camera	√			√		SP0572, SP0573
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Nats immu	√	√	√			
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Rearview camera	√			√		SP0570, SP0571
U.S.A.	INFINITI G35 SEDAN	V35	2003.NULL	Smart entrance						SP0568
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL	Multi AV	√	√	√	√		
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL	All mode AWD/4WD	√	√	√	√	AC0957	
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL	Precrash seatbelt	√	√	√	√		
U.S.A.	INFINITI G35 SEDAN	V36	2007.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Air bag	√	√	√	√		
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274

U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Pop up hood	√	√	√	√		
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	4WAS(front)	√	√	√	√	AC1027, AC1028	
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	Precrash seatbelt	√	√	√	√		
U.S.A.	INFINITI G37 CONVERTIBLE	HV36	2009.NULL –	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0052, AC0053, AC0054, AC0062, AC0066, AC0067, AC0068, AC0069, AC0070, AC0148, AC0149, AC0150, AC0156, AC0161, AC0164, AC0166, AC0168, AC0173, AC0174, AC0176, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	Pop up hood	√	√	√	√		
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	Precrash seatbelt	√	√	√	√		
U.S.A.	INFINITI G37 COUPE	CV36	2008.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL	Convertible roof	√	√	√	√	AC1006. AC1007. AC1008. AC1009. AC1010	SP0575. SP0576. SP0577. SP0578. SP0579. SP0580
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL –	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL –	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL	Precrash seatbelt	√	√	√	√		
U.S.A.	INFINITI G37 SEDAN	V36	2009.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI I30	CA32	1996.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
U.S.A.	INFINITI I30	CA32	1996.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
U.S.A.	INFINITI I30	CA32	1996.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
U.S.A.	INFINITI I30	CA32	1996.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
U.S.A.	INFINITI I30	CA32	1996.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI I30	CA32	1996.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
U.S.A.	INFINITI I30	CA32	1996.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
U.S.A.	INFINITI I30	CA32	1996.NULL	Motor control						
U.S.A.	INFINITI I30	CA32	1996.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI I30	CA32	1996.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
U.S.A.	INFINITI I30	CA32	1996.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
U.S.A.	INFINITI I30	CA32	1996.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI I30	CA32	1996.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI I30	CA32	1996.NULL	HVAC	√	√	√	√		
U.S.A.	INFINITI I30	CA32	1996.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI I30	CA32	1996.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI I30	CA32	1996.NULL	Auto slide door	√	√	√	√	AC0941	
U.S.A.	INFINITI I30	CA32	1996.NULL	DIU		√	√	√		
U.S.A.	INFINITI I30	CA32	1996.NULL	Adaptive light	√	√	√	√		
U.S.A.	INFINITI I30	CA32	1996.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
U.S.A.	INFINITI I30	CA32	1996.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
U.S.A.	INFINITI I30	CA32	1996.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI I30	CA32	1996.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
U.S.A.	INFINITI I30	CA32	1996.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
U.S.A.	INFINITI I30	CA32	1996.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI I30	CA32	1996.NULL	IVMS	√	√		√		
U.S.A.	INFINITI I30	CA32	1996.NULL	Distance control	√	√		√		
U.S.A.	INFINITI I30	CA32	1996.NULL	Active suspense system	√	√	√	√		
U.S.A.	INFINITI I30	CA32	1996.NULL	Motor assist		√	√	√		SP0574
U.S.A.	INFINITI I30	CA32	1996.NULL	ASCD	√	√	√	√		
U.S.A.	INFINITI I30	CA32	1996.NULL	Active engine mount	√	√	√	√		
U.S.A.	INFINITI I30	CA32	1996.NULL	TCS	√	√	√	√		
U.S.A.	INFINITI I30	CA32	1996.NULL	S/blind camera	√			√		SP0572, SP0573
U.S.A.	INFINITI I30	CA32	1996.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
U.S.A.	INFINITI I30	CA32	1996.NULL	Nats immu	√	√	√			
U.S.A.	INFINITI I30	CA32	1996.NULL	Rearview camera	√			√		SP0570, SP0571
U.S.A.	INFINITI I30	CA32	1996.NULL	Smart entrance						SP0568
U.S.A.	INFINITI I35	CA33	2002.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
U.S.A.	INFINITI I35	CA33	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
U.S.A.	INFINITI I35	CA33	2002.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
U.S.A.	INFINITI I35	CA33	2002.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	

U.S.A.	INFINITI I35	CA33	2002.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI I35	CA33	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
U.S.A.	INFINITI I35	CA33	2002.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
U.S.A.	INFINITI I35	CA33	2002.NULL	Motor control						
U.S.A.	INFINITI I35	CA33	2002.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI I35	CA33	2002.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
U.S.A.	INFINITI I35	CA33	2002.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
U.S.A.	INFINITI I35	CA33	2002.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI I35	CA33	2002.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI I35	CA33	2002.NULL	HVAC	√	√	√	√		
U.S.A.	INFINITI I35	CA33	2002.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI I35	CA33	2002.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI I35	CA33	2002.NULL	Auto slide door	√	√	√	√	AC0941	
U.S.A.	INFINITI I35	CA33	2002.NULL	DIU		√	√	√		
U.S.A.	INFINITI I35	CA33	2002.NULL	Adaptive light	√	√	√	√		
U.S.A.	INFINITI I35	CA33	2002.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
U.S.A.	INFINITI I35	CA33	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
U.S.A.	INFINITI I35	CA33	2002.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI I35	CA33	2002.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
U.S.A.	INFINITI I35	CA33	2002.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
U.S.A.	INFINITI I35	CA33	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI I35	CA33	2002.NULL	IVMS	√	√		√		
U.S.A.	INFINITI I35	CA33	2002.NULL	Distance control	√	√		√		
U.S.A.	INFINITI I35	CA33	2002.NULL	Active suspense system	√	√	√	√		
U.S.A.	INFINITI I35	CA33	2002.NULL	Motor assist		√	√	√		SP0574
U.S.A.	INFINITI I35	CA33	2002.NULL	ASCD	√	√	√	√		
U.S.A.	INFINITI I35	CA33	2002.NULL	Active engine mount	√	√	√	√		
U.S.A.	INFINITI I35	CA33	2002.NULL	TCS	√	√	√	√		
U.S.A.	INFINITI I35	CA33	2002.NULL	S/blind camera	√			√		SP0572, SP0573
U.S.A.	INFINITI I35	CA33	2002.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
U.S.A.	INFINITI I35	CA33	2002.NULL	Nats immu	√	√	√			
U.S.A.	INFINITI I35	CA33	2002.NULL	Rearview camera	√			√		SP0570, SP0571
U.S.A.	INFINITI I35	CA33	2002.NULL	Smart entrance						SP0568
U.S.A.	INFINITI JX35	L50	2013.NULL	Laser/radar	√	√	√	√		
U.S.A.	INFINITI JX35	L50	2013.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI JX35	L50	2013.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
U.S.A.	INFINITI JX35	L50	2013.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI JX35	L50	2013.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI JX35	L50	2013.NULL	EPS/DAST 3	√	√	√	√		
U.S.A.	INFINITI JX35	L50	2013.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
U.S.A.	INFINITI JX35	L50	2013.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI JX35	L50	2013.NULL_	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
U.S.A.	INFINITI JX35	L50	2013.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
U.S.A.	INFINITI JX35	L50	2013.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
U.S.A.	INFINITI JX35	L50	2013.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI JX35	L50	2013.NULL	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
U.S.A.	INFINITI JX35	L50	2013.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI JX35	L50	2013.NULL	Auto back door	√	√	√	√		SP0611
U.S.A.	INFINITI JX35	L50	2013.NULL	Occupant detection			√	√		SP0584
U.S.A.	INFINITI JX35	L50	2013.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI JX35	L50	2013.NULL	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
U.S.A.	INFINITI JX35	L50	2013.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI JX35	L50	2013.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI JX35	L50	2013.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI JX35	L50	2013.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI JX35	L50	2013.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
U.S.A.	INFINITI JX35	L50	2013.NULL	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI JX35	L50	2013.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI JX35	L50	2013.NULL	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI M35/M45	Y50	2006.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
U.S.A.	INFINITI M35/M45	Y50	2006.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
U.S.A.	INFINITI M35/M45	Y50	2006.NULL_	IPDM E/R	√	√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
U.S.A.	INFINITI M35/M45	Y50	2006.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI M35/M45	Y50	2006.NULL	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
U.S.A.	INFINITI M35/M45	Y50	2006.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
U.S.A.	INFINITI M35/M45	Y50	2006.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
U.S.A.	INFINITI M35/M45	Y50	2006.NULL	BCM					AC0653, AC0698	SP0391, SP0393
U.S.A.	INFINITI M35/M45	Y50	2006.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI M35/M45	Y50	2006.NULL	Multi AV	√	√	√	√		
U.S.A.	INFINITI M35/M45	Y50	2006.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI M35/M45	Y50	2006.NULL	Adaptive light	√	√	√	√		SP0561, SP0562
U.S.A.	INFINITI M35/M45	Y50	2006.NULL	All mode AWD/4WD	√	√	√	√	AC0957	
U.S.A.	INFINITI M35/M45	Y50	2006.NULL	Precrash seatbelt	√	√	√	√		
U.S.A.	INFINITI M35/M45	Y50	2006.NULL_	Intelligent key	√	√	√	√	AC0911, AC0913, AC0915, AC0916, AC0917, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
U.S.A.	INFINITI M35/M45	Y50	2006.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976	SP0560
U.S.A.	INFINITI M35/M45	Y50	2006.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI M35H	HY51	2012.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
U.S.A.	INFINITI M35H	HY51	2012.NULL	Laser/radar	√	√	√	√		
U.S.A.	INFINITI M35H	HY51	2012.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI M35H	HY51	2012.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
U.S.A.	INFINITI M35H	HY51	2012.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI M35H	HY51	2012.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI M35H	HY51	2012.NULL	EPS/DAST 3	√	√	√	√		
U.S.A.	INFINITI M35H	HY51	2012.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
U.S.A.	INFINITI M35H	HY51	2012.NULL	Motor control	√	√	√	√		
U.S.A.	INFINITI M35H	HY51	2012.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
U.S.A.	INFINITI M35H	HY51	2012.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
U.S.A.	INFINITI M35H	HY51	2012.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
U.S.A.	INFINITI M35H	HY51	2012.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315

U.S.A.	INFINITI M35H	HY51	2012.NULL	Diag data recorder	√			√		
U.S.A.	INFINITI M35H	HY51	2012.NULL	Pop up hood	√	√	√	√		
U.S.A.	INFINITI M35H	HY51	2012.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI M35H	HY51	2012.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
U.S.A.	INFINITI M35H	HY51	2012.NULL	HV battery	√	√	√	√	AC1121	
U.S.A.	INFINITI M35H	HY51	2012.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI M35H	HY51	2012.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
U.S.A.	INFINITI M35H	HY51	2012.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
U.S.A.	INFINITI M35H	HY51	2012.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI M35H	HY51	2012.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
U.S.A.	INFINITI M35H	HY51	2012.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI M35H	HY51	2012.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI M35H	HY51	2012.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
U.S.A.	INFINITI M35H	HY51	2012.NULL	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI M35H	HY51	2012.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI M35H	HY51	2012.NULL	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI M35H	HY51	2012.NULL	Brake	√	√	√	√	AC1127	
U.S.A.	INFINITI M35H	HY51	2012.NULL	VSP	√	√	√	√	AC1124, AC1125, AC1126	
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Laser/radar	√	√	√	√		
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
U.S.A.	INFINITI M37/M56	Y51	2011.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	EPS/DAST 3	√	√	√	√		
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Motor control	√	√	√	√		
U.S.A.	INFINITI M37/M56	Y51	2011.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
U.S.A.	INFINITI M37/M56	Y51	2011.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
U.S.A.	INFINITI M37/M56	Y51	2011.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Pop up hood	√	√	√	√		
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI M37/M56	Y51	2011.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	HV battery	√	√	√	√	AC1121	
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
U.S.A.	INFINITI M37/M56	Y51	2011.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI M37/M56	Y51	2011.NULL	VSP	√	√	√	√	AC1124, AC1125, AC1126	
U.S.A.	INFINITI M45	Y34	2003.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
U.S.A.	INFINITI M45	Y34	2003.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
U.S.A.	INFINITI M45	Y34	2003.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
U.S.A.	INFINITI M45	Y34	2003.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
U.S.A.	INFINITI M45	Y34	2003.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI M45	Y34	2003.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
U.S.A.	INFINITI M45	Y34	2003.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
U.S.A.	INFINITI M45	Y34	2003.NULL	Motor control						
U.S.A.	INFINITI M45	Y34	2003.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI M45	Y34	2003.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
U.S.A.	INFINITI M45	Y34	2003.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
U.S.A.	INFINITI M45	Y34	2003.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI M45	Y34	2003.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI M45	Y34	2003.NULL	HVAC	√	√	√	√		
U.S.A.	INFINITI M45	Y34	2003.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI M45	Y34	2003.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI M45	Y34	2003.NULL	Auto slide door	√	√	√	√	AC0941	
U.S.A.	INFINITI M45	Y34	2003.NULL	DIU		√	√	√		
U.S.A.	INFINITI M45	Y34	2003.NULL	Adaptive light	√	√	√	√		
U.S.A.	INFINITI M45	Y34	2003.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
U.S.A.	INFINITI M45	Y34	2003.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
U.S.A.	INFINITI M45	Y34	2003.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI M45	Y34	2003.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
U.S.A.	INFINITI M45	Y34	2003.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
U.S.A.	INFINITI M45	Y34	2003.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI M45	Y34	2003.NULL	IVMS	√	√		√		
U.S.A.	INFINITI M45	Y34	2003.NULL	Distance control	√	√		√		
U.S.A.	INFINITI M45	Y34	2003.NULL	Active suspense system	√	√	√	√		
U.S.A.	INFINITI M45	Y34	2003.NULL	Motor assist		√	√	√		SP0574
U.S.A.	INFINITI M45	Y34	2003.NULL	ASCD	√	√	√	√		
U.S.A.	INFINITI M45	Y34	2003.NULL	Active engine mount	√	√	√	√		
U.S.A.	INFINITI M45	Y34	2003.NULL	TCS	√	√	√	√		
U.S.A.	INFINITI M45	Y34	2003.NULL	S/blind camera	√			√		SP0572, SP0573
U.S.A.	INFINITI M45	Y34	2003.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
U.S.A.	INFINITI M45	Y34	2003.NULL	Nats immu	√	√	√			
U.S.A.	INFINITI M45	Y34	2003.NULL	Rearview camera	√			√		SP0570, SP0571
U.S.A.	INFINITI M45	Y34	2003.NULL	Smart entrance						SP0568
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0038, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL	Transmission	√	√	√	√		SP0274
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL_	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL	Pop up hood	√	√	√	√		
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI Q40 SEDAN	V36	2015.NULL	Precrash seatbelt	√	√	√	√		
U.S.A.	INFINITI Q45	F50	2002.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
U.S.A.	INFINITI Q45	F50	2002.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
U.S.A.	INFINITI Q45	F50	2002.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
U.S.A.	INFINITI Q45	F50	2002.NULL_	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
U.S.A.	INFINITI Q45	F50	2002.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI Q45	F50	2002.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
U.S.A.	INFINITI Q45	F50	2002.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
U.S.A.	INFINITI Q45	F50	2002.NULL	Motor control						
U.S.A.	INFINITI Q45	F50	2002.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
U.S.A.	INFINITI Q45	F50	2002.NULL_	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
U.S.A.	INFINITI Q45	F50	2002.NULL_	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
U.S.A.	INFINITI Q45	F50	2002.NULL_	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
U.S.A.	INFINITI Q45	F50	2002.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI Q45	F50	2002.NULL	HVAC	√	√	√	√		
U.S.A.	INFINITI Q45	F50	2002.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI Q45	F50	2002.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
U.S.A.	INFINITI Q45	F50	2002.NULL	Auto slide door	√	√	√	√	AC0941	
U.S.A.	INFINITI Q45	F50	2002.NULL	DIU		√	√	√		
U.S.A.	INFINITI Q45	F50	2002.NULL	Adaptive light	√	√	√	√		
U.S.A.	INFINITI Q45	F50	2002.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
U.S.A.	INFINITI Q45	F50	2002.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
U.S.A.	INFINITI Q45	F50	2002.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
U.S.A.	INFINITI Q45	F50	2002.NULL_	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
U.S.A.	INFINITI Q45	F50	2002.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
U.S.A.	INFINITI Q45	F50	2002.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI Q45	F50	2002.NULL	IVMS	√	√		√		
U.S.A.	INFINITI Q45	F50	2002.NULL	Distance control	√	√		√		
U.S.A.	INFINITI Q45	F50	2002.NULL	Active suspense system	√	√	√	√		
U.S.A.	INFINITI Q45	F50	2002.NULL	Motor assist		√	√	√		SP0574
U.S.A.	INFINITI Q45	F50	2002.NULL	ASCD	√	√	√	√		
U.S.A.	INFINITI Q45	F50	2002.NULL	Active engine mount	√	√	√	√		
U.S.A.	INFINITI Q45	F50	2002.NULL	TCS	√	√	√	√		
U.S.A.	INFINITI Q45	F50	2002.NULL	S/blind camera	√			√		SP0572,SP0573
U.S.A.	INFINITI Q45	F50	2002.NULL	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
U.S.A.	INFINITI Q45	F50	2002.NULL	Nats immu	√	√	√			
U.S.A.	INFINITI Q45	F50	2002.NULL	Rearview camera	√			√		SP0570,SP0571
U.S.A.	INFINITI Q45	F50	2002.NULL	Smart entrance						SP0568
U.S.A.	INFINITI Q45	FY33	1995.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
U.S.A.	INFINITI Q45	FY33	1995.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492,SP0493
U.S.A.	INFINITI Q45	FY33	1995.NULL	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
U.S.A.	INFINITI Q45	FY33	1995.NULL_	IPDM E/R	√	√	√	√	AC0811,AC0812,AC0814,AC0815,AC0816,AC0817,AC0818,AC0819,AC0820,AC0821,AC0822,AC0823,AC0825,AC0831	
U.S.A.	INFINITI Q45	FY33	1995.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI Q45	FY33	1995.NULL	EPS/DAST 3	√	√	√	√		SP0506,SP0507
U.S.A.	INFINITI Q45	FY33	1995.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349
U.S.A.	INFINITI Q45	FY33	1995.NULL	Motor control						
U.S.A.	INFINITI Q45	FY33	1995.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0104,AC0105,AC0106,AC0107,AC0108,AC0109,AC0110,AC0111,AC0112,AC0113,AC0114,AC0115,AC0116,AC0117,AC0118,AC0119,AC0120,AC0121,AC0122,AC0123,AC0124,AC0125,AC0126,AC0127,AC0128,AC0129,AC0131,AC0145,AC0146,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0068,SP0074,SP0075,SP0076,SP0077,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0093,SP0094,SP0098,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
U.S.A.	INFINITI Q45	FY33	1995.NULL_	Transmission	√	√	√	√	AC0398,AC0399,AC0417,AC0418,AC0419,AC0420,AC0421,AC0422,AC0423,AC0424,AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0271,SP0272,SP0273,SP0274,SP0275,SP0276,SP0278,SP0279,SP0280,SP0287,SP0288
U.S.A.	INFINITI Q45	FY33	1995.NULL_	BCM	√	√	√	√	AC0586,AC0587,AC0588,AC0602,AC0603,AC0604,AC0605,AC0606,AC0607,AC0608,AC0609,AC0610,AC0613,AC0618,AC0626,AC0630,AC0653,AC0660,AC0663,AC0672,AC0678,AC0689,AC0690,AC0692,AC0695,AC0698,AC0702,AC0712,AC0719	SP0372,SP0381,SP0382,SP0385,SP0387,SP0388,SP0390,SP0391,SP0392,SP0393,SP0394,SP0397,SP0399,SP0402,SP0403,SP0419,SP0428,SP0429,SP0438,SP0450,SP0458,SP0469,SP0471
U.S.A.	INFINITI Q45	FY33	1995.NULL_	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535,AC0536	SP0300,SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
U.S.A.	INFINITI Q45	FY33	1995.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI Q45	FY33	1995.NULL	HVAC	√	√	√	√		
U.S.A.	INFINITI Q45	FY33	1995.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI Q45	FY33	1995.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
U.S.A.	INFINITI Q45	FY33	1995.NULL	Auto slide door	√	√	√	√	AC0941	
U.S.A.	INFINITI Q45	FY33	1995.NULL	DIU		√	√	√		
U.S.A.	INFINITI Q45	FY33	1995.NULL	Adaptive light	√	√	√	√		
U.S.A.	INFINITI Q45	FY33	1995.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
U.S.A.	INFINITI Q45	FY33	1995.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
U.S.A.	INFINITI Q45	FY33	1995.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
U.S.A.	INFINITI Q45	FY33	1995.NULL_	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
U.S.A.	INFINITI Q45	FY33	1995.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973	
U.S.A.	INFINITI Q45	FY33	1995.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI Q45	FY33	1995.NULL	IVMS	√	√		√		
U.S.A.	INFINITI Q45	FY33	1995.NULL	Distance control	√	√		√		
U.S.A.	INFINITI Q45	FY33	1995.NULL	Active suspense system	√	√	√	√		
U.S.A.	INFINITI Q45	FY33	1995.NULL	Motor assist		√	√	√		SP0574
U.S.A.	INFINITI Q45	FY33	1995.NULL	ASCD	√	√	√	√		
U.S.A.	INFINITI Q45	FY33	1995.NULL	Active engine mount	√	√	√	√		
U.S.A.	INFINITI Q45	FY33	1995.NULL	TCS	√	√	√	√		
U.S.A.	INFINITI Q45	FY33	1995.NULL	S/blind camera	√			√		SP0572,SP0573
U.S.A.	INFINITI Q45	FY33	1995.NULL	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
U.S.A.	INFINITI Q45	FY33	1995.NULL	Nats immu	√	√	√			
U.S.A.	INFINITI Q45	FY33	1995.NULL	Rearview camera	√			√		SP0570,SP0571
U.S.A.	INFINITI Q45	FY33	1995.NULL	Smart entrance						SP0568
U.S.A.	INFINITI Q50	V37	2019.NULL	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
U.S.A.	INFINITI Q50	V37	2019.NULL	Laser/radar	√	√	√	√	AC0994	
U.S.A.	INFINITI Q50	V37	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI Q50	V37	2019.NULL_	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
U.S.A.	INFINITI Q50	V37	2019.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
U.S.A.	INFINITI Q50	V37	2019.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI Q50	V37	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
U.S.A.	INFINITI Q50	V37	2019.NULL	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
U.S.A.	INFINITI Q50	V37	2019.NULL	Motor control	√	√	√	√		

U.S.A.	INFINITI Q50	V37	2019.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI Q50	V37	2019.NULL	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274, SP0276
U.S.A.	INFINITI Q50	V37	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
U.S.A.	INFINITI Q50	V37	2019.NULL_	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
U.S.A.	INFINITI Q50	V37	2019.NULL	Pop up hood	√	√	√	√		
U.S.A.	INFINITI Q50	V37	2019.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI Q50	V37	2019.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
U.S.A.	INFINITI Q50	V37	2019.NULL	HV battery	√	√	√	√	AC1121	
U.S.A.	INFINITI Q50	V37	2019.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
U.S.A.	INFINITI Q50	V37	2019.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
U.S.A.	INFINITI Q50	V37	2019.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI Q50	V37	2019.NULL	EV/HEV	√	√	√	√	AC1084. AC1085. AC1086. AC1087. AC1088. AC1089. AC1106	
U.S.A.	INFINITI Q50	V37	2019.NULL	Occupant detection			√	√		SP0584
U.S.A.	INFINITI Q50	V37	2019.NULL	Shift	√	√	√	√		SP0613
U.S.A.	INFINITI Q50	V37	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
U.S.A.	INFINITI Q50	V37	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI Q50	V37	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
U.S.A.	INFINITI Q50	V37	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI Q50	V37	2019.NULL	DAST 2	√	√	√	√		
U.S.A.	INFINITI Q50	V37	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI Q50	V37	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI Q50	V37	2019.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI Q50	V37	2019.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
U.S.A.	INFINITI Q50	V37	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI Q50	V37	2019.NULL	DAST 1	√	√	√	√		
U.S.A.	INFINITI Q50	V37	2019.NULL_	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
U.S.A.	INFINITI Q50	V37	2019.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
U.S.A.	INFINITI Q50	V37	2019.NULL	ANC	√	√	√	√	AC1024	
U.S.A.	INFINITI Q50	V37	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI Q50	V37	2019.NULL	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
U.S.A.	INFINITI Q50	V37	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI Q50	V37	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
U.S.A.	INFINITI Q50	V37	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI Q50	V37	2019.NULL	Brake	√	√	√	√	AC1127	
U.S.A.	INFINITI Q50	V37	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
U.S.A.	INFINITI Q50	V37	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
U.S.A.	INFINITI Q50	V37	2019.NULL	ICC/ADAS 2	√	√	√	√		
U.S.A.	INFINITI Q50	V37	2019.NULL	FSCM	√	√	√	√	AC1109	
U.S.A.	INFINITI Q50	V37	2019.NULL	VSP	√	√	√	√	AC1122. AC1123. AC1124. AC1125. AC1126	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Laser/radar	√	√	√	√		
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Motor control	√	√	√	√		
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Transmission	√	√	√	√		SP0274, SP0276
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL_	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Pop up hood	√	√	√	√		
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	HV battery	√	√	√	√	AC1121	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Occupant detection			√	√		SP0584
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Shift	√	√	√	√		SP0613
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	DAST 2	√	√	√	√		
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	DAST 1	√	√	√	√		
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL_	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	ANC	√	√	√	√	AC1024	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	HIGH BEAM ASSIST	√	√	√	√		
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	Brake	√	√	√	√	AC1127	
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	6ch CAN GATEWAY	√	√	√	√		
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	3ch CAN GATEWAY	√	√	√	√		
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	ICC/ADAS 2	√	√	√	√		
U.S.A.	INFINITI Q50 HYBRID	HV37	2014.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Laser/radar	√	√	√	√		
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Air bag	√	√	√	√		
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	EPS/DAST 3	√	√	√	√		
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Motor control	√	√	√	√		
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Transmission	√	√	√	√		SP0276
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Pop up hood	√	√	√	√		
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Multi AV	√	√	√	√		SP0503

U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	HV battery	√	√	√	√	AC1121	
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Occupant detection			√	√		SP0584
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 2	√	√	√	√		
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Lane camera	√	√	√	√		
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	DAST 1	√	√	√	√		
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	ANC	√	√	√	√	AC1024	
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	HIGH BEAM ASSIST	√	√	√	√		
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√		
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	Brake	√	√	√	√	AC1127	
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	6ch CAN GATEWAY	√	√	√	√		
U.S.A.	INFINITI Q50 Hybrid	HV37	2018.2-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
U.S.A.	INFINITI Q60	CV37	2019.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
U.S.A.	INFINITI Q60	CV37	2019.NULL	Laser/radar	√	√	√	√	AC0994	
U.S.A.	INFINITI Q60	CV37	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI Q60	CV37	2019.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
U.S.A.	INFINITI Q60	CV37	2019.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI Q60	CV37	2019.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI Q60	CV37	2019.NULL	EPS/DAST 3	√	√	√	√		
U.S.A.	INFINITI Q60	CV37	2019.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
U.S.A.	INFINITI Q60	CV37	2019.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI Q60	CV37	2019.NULL	Transmission	√	√	√	√		SP0247, SP0265, SP0274
U.S.A.	INFINITI Q60	CV37	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
U.S.A.	INFINITI Q60	CV37	2019.NULL	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
U.S.A.	INFINITI Q60	CV37	2019.NULL	Pop up hood	√	√	√	√		
U.S.A.	INFINITI Q60	CV37	2019.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI Q60	CV37	2019.NULL	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
U.S.A.	INFINITI Q60	CV37	2019.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
U.S.A.	INFINITI Q60	CV37	2019.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI Q60	CV37	2019.NULL	Occupant detection			√	√		SP0584
U.S.A.	INFINITI Q60	CV37	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
U.S.A.	INFINITI Q60	CV37	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI Q60	CV37	2019.NULL	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
U.S.A.	INFINITI Q60	CV37	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI Q60	CV37	2019.NULL	DAST 2	√	√	√	√		
U.S.A.	INFINITI Q60	CV37	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI Q60	CV37	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI Q60	CV37	2019.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI Q60	CV37	2019.NULL	Lane camera	√	√	√	√		
U.S.A.	INFINITI Q60	CV37	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI Q60	CV37	2019.NULL	DAST 1	√	√	√	√		
U.S.A.	INFINITI Q60	CV37	2019.NULL	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
U.S.A.	INFINITI Q60	CV37	2019.NULL	ANC	√	√	√	√	AC1024	
U.S.A.	INFINITI Q60	CV37	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI Q60	CV37	2019.NULL	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
U.S.A.	INFINITI Q60	CV37	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI Q60	CV37	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
U.S.A.	INFINITI Q60	CV37	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI Q60	CV37	2019.NULL	Lane camera 2	√	√	√	√		
U.S.A.	INFINITI Q60	CV37	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
U.S.A.	INFINITI Q60	CV37	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
U.S.A.	INFINITI Q60	CV37	2019.NULL	ICC/ADAS 2	√	√	√	√		
U.S.A.	INFINITI Q60	CV37	2019.NULL	FSCM	√	√	√	√	AC1109	
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	Transmission	√	√	√	√		SP0274
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	Pop up hood	√	√	√	√		
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
U.S.A.	INFINITI Q60 CONVERTIBLE	HV36	2014.NULL	Precrash seatbelt	√	√	√	√		
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL_	Transmission	√	√	√	√		SP0274
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL	Pop up hood	√	√	√	√		
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI Q60 COUPE	CV36	2014.NULL	Precrash seatbelt	√	√	√	√		
U.S.A.	INFINITI Q70	Y51	2019.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
U.S.A.	INFINITI Q70	Y51	2019.NULL	Laser/radar	√	√	√	√	AC0994	
U.S.A.	INFINITI Q70	Y51	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI Q70	Y51	2019.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
U.S.A.	INFINITI Q70	Y51	2019.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI Q70	Y51	2019.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI Q70	Y51	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
U.S.A.	INFINITI Q70	Y51	2019.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
U.S.A.	INFINITI Q70	Y51	2019.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
U.S.A.	INFINITI Q70	Y51	2019.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274
U.S.A.	INFINITI Q70	Y51	2019.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
U.S.A.	INFINITI Q70	Y51	2019.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI Q70	Y51	2019.NULL	Pop up hood	√	√	√	√		
U.S.A.	INFINITI Q70	Y51	2019.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI Q70	Y51	2019.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
U.S.A.	INFINITI Q70	Y51	2019.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
U.S.A.	INFINITI Q70	Y51	2019.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
U.S.A.	INFINITI Q70	Y51	2019.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI Q70	Y51	2019.NULL	Occupant detection			√	√		SP0584
U.S.A.	INFINITI Q70	Y51	2019.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
U.S.A.	INFINITI Q70	Y51	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI Q70	Y51	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
U.S.A.	INFINITI Q70	Y51	2019.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI Q70	Y51	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI Q70	Y51	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI Q70	Y51	2019.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI Q70	Y51	2019.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
U.S.A.	INFINITI Q70	Y51	2019.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI Q70	Y51	2019.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
U.S.A.	INFINITI Q70	Y51	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI Q70	Y51	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI Q70	Y51	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI Q70	Y51	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
U.S.A.	INFINITI Q70	Y51	2019.NULL	ICC/ADAS 2	√	√	√	√		
U.S.A.	INFINITI Q70	Y51	2019.NULL	FSCM	√	√	√	√	AC1109	
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Laser/radar	√	√	√	√	AC0994	
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL_	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	EPS/DAST 3	√	√	√	√		
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Motor control	√	√	√	√		
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL_	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274, SP0276
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	BCM				√	AC0613, AC0618, AC0653, AC0663, AC0690, AC0692, AC0698, AC0702	SP0372, SP0429, SP0471
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Pop up hood	√	√	√	√		
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL_	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	HV battery	√	√	√	√	AC1121	
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	4WAS(front)	√	√	√	√	AC1027, AC1028	
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Occupant detection			√	√		SP0584
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL_	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	Brake	√	√	√	√	AC1127	
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	6ch CAN GATEWAY	√	√	√	√		
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	ICC/ADAS 2	√	√	√	√		
U.S.A.	INFINITI Q70 HYBRID	HY51	2014.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
U.S.A.	INFINITI QX30	H15	2019.NULL	Air pressure monitor	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Air bag	√	√	√	√		

U.S.A.	INFINITI QX30	H15	2019.NULL	EPS/DAST 3	√	√	√			
U.S.A.	INFINITI QX30	H15	2019.NULL	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
U.S.A.	INFINITI QX30	H15	2019.NULL –	Engine	√	√	√	√	AC0002, AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0103, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
U.S.A.	INFINITI QX30	H15	2019.NULL	EHS/PKB	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Transmission	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL –	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
U.S.A.	INFINITI QX30	H15	2019.NULL	ABS	√	√	√	√		SP0308
U.S.A.	INFINITI QX30	H15	2019.NULL	Multi AV	√	√	√	√		SP0501
U.S.A.	INFINITI QX30	H15	2019.NULL	HVAC	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Auto drive position	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Shift	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	All mode AWD/4WD	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	AVM	√	√		√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Intelligent key	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	CAN gateway	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	ANC	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Telematics	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	FSCM	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Siren control unit	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL –	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
U.S.A.	INFINITI QX30	H15	2019.NULL –	Overhead Control Panel Unit	√			√		
U.S.A.	INFINITI QX30	H15	2019.NULL –	Universal Garage Door Opener	√			√		
U.S.A.	INFINITI QX30	H15	2019.NULL –	Upper control panel cont unit	√					
U.S.A.	INFINITI QX30	H15	2019.NULL –	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
U.S.A.	INFINITI QX30	H15	2019.NULL –	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
U.S.A.	INFINITI QX30	H15	2019.NULL	Light/Rain Sensor Module	√			√		
U.S.A.	INFINITI QX30	H15	2019.NULL	EC Mirror Compass	√					
U.S.A.	INFINITI QX30	H15	2019.NULL –	Intelligent Battery Sensor	√					
U.S.A.	INFINITI QX30	H15	2019.NULL	Alarm siren	√			√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Radar sensor	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL –	Steering column cont module	√	√	√			
U.S.A.	INFINITI QX30	H15	2019.NULL	ICC sensor	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL –	Trailer recognition control unit	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	H/L control module LH	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Powertrain cont module	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Side radar LH	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	LED H/L control module LH	√			√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Steering Wheel Switch Pad	√			√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Parking assist	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL –	Occupant Classification Unit	√			√		
U.S.A.	INFINITI QX30	H15	2019.NULL –	Electronic Ignition Switch cont unit	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	H/L control module RH	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Front camera unit	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	Side radar RH	√	√	√	√		
U.S.A.	INFINITI QX30	H15	2019.NULL	LED H/L control module RH	√			√		
U.S.A.	INFINITI QX4	JR50	1997.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
U.S.A.	INFINITI QX4	JR50	1997.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
U.S.A.	INFINITI QX4	JR50	1997.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
U.S.A.	INFINITI QX4	JR50	1997.NULL –	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
U.S.A.	INFINITI QX4	JR50	1997.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI QX4	JR50	1997.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
U.S.A.	INFINITI QX4	JR50	1997.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
U.S.A.	INFINITI QX4	JR50	1997.NULL	Motor control						
U.S.A.	INFINITI QX4	JR50	1997.NULL –	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI QX4	JR50	1997.NULL –	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
U.S.A.	INFINITI QX4	JR50	1997.NULL –	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
U.S.A.	INFINITI QX4	JR50	1997.NULL –	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI QX4	JR50	1997.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI QX4	JR50	1997.NULL	HVAC	√	√	√	√		
U.S.A.	INFINITI QX4	JR50	1997.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI QX4	JR50	1997.NULL –	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI QX4	JR50	1997.NULL	Auto slide door	√	√	√	√	AC0941	
U.S.A.	INFINITI QX4	JR50	1997.NULL	DIU		√	√	√		
U.S.A.	INFINITI QX4	JR50	1997.NULL	Adaptive light	√	√	√	√		
U.S.A.	INFINITI QX4	JR50	1997.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
U.S.A.	INFINITI QX4	JR50	1997.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
U.S.A.	INFINITI QX4	JR50	1997.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI QX4	JR50	1997.NULL –	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
U.S.A.	INFINITI QX4	JR50	1997.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
U.S.A.	INFINITI QX4	JR50	1997.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI QX4	JR50	1997.NULL	IVMS	√	√		√		
U.S.A.	INFINITI QX4	JR50	1997.NULL	Distance control	√	√		√		
U.S.A.	INFINITI QX4	JR50	1997.NULL	Active suspense system	√	√	√	√		
U.S.A.	INFINITI QX4	JR50	1997.NULL	Motor assist		√	√	√		SP0574
U.S.A.	INFINITI QX4	JR50	1997.NULL	ASCD	√	√	√	√		
U.S.A.	INFINITI QX4	JR50	1997.NULL	Active engine mount	√	√	√	√		
U.S.A.	INFINITI QX4	JR50	1997.NULL	TCS	√	√	√	√		
U.S.A.	INFINITI QX4	JR50	1997.NULL	S/blind camera	√			√		SP0572, SP0573
U.S.A.	INFINITI QX4	JR50	1997.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
U.S.A.	INFINITI QX4	JR50	1997.NULL	Nats immu	√	√	√			
U.S.A.	INFINITI QX4	JR50	1997.NULL	Rearview camera	√			√		SP0570, SP0571
U.S.A.	INFINITI QX4	JR50	1997.NULL	Smart entrance						SP0568
U.S.A.	INFINITI QX50	J50	2014.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
U.S.A.	INFINITI QX50	J50	2014.NULL	Laser/radar	√	√	√	√	AC0994	
U.S.A.	INFINITI QX50	J50	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI QX50	J50	2014.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
U.S.A.	INFINITI QX50	J50	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI QX50	J50	2014.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI QX50	J50	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
U.S.A.	INFINITI QX50	J50	2014.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

U.S.A.	INFINITI QX50	J50	2014.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
U.S.A.	INFINITI QX50	J50	2014.NULL_	Transmission	√	√	√	√		SP0274
U.S.A.	INFINITI QX50	J50	2014.NULL_	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
U.S.A.	INFINITI QX50	J50	2014.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI QX50	J50	2014.NULL_	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI QX50	J50	2014.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI QX50	J50	2014.NULL_	Occupant detection			√	√		SP0584
U.S.A.	INFINITI QX50	J50	2014.NULL_	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
U.S.A.	INFINITI QX50	J50	2014.NULL_	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI QX50	J50	2014.NULL_	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
U.S.A.	INFINITI QX50	J50	2014.NULL_	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI QX50	J50	2014.NULL_	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI QX50	J50	2014.NULL_	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI QX50	J50	2014.NULL_	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
U.S.A.	INFINITI QX50	J50	2014.NULL_	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
U.S.A.	INFINITI QX50	J50	2014.NULL_	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI QX50	J50	2014.NULL_	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI QX50	J50	2014.NULL_	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI QX50	I55	2019.NULL_	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
U.S.A.	INFINITI QX50	I55	2019.NULL_	Laser/radar	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
U.S.A.	INFINITI QX50	J55	2019.NULL_	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
U.S.A.	INFINITI QX50	J55	2019.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL	EPS/DAST 3	√	√	√	√		
U.S.A.	INFINITI QX50	I55	2019.NULL	Meter/M&A	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL_	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
U.S.A.	INFINITI QX50	J55	2019.NULL	EHS/PKB	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL_	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
U.S.A.	INFINITI QX50	J55	2019.NULL	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
U.S.A.	INFINITI QX50	J55	2019.NULL	ABS	√	√	√	√		SP0313, SP0315
U.S.A.	INFINITI QX50	J55	2019.NULL	Total illum C/U	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI QX50	J55	2019.NULL	HVAC	√	√	√	√		
U.S.A.	INFINITI QX50	I55	2019.NULL	Auto drive position	√	√	√	√		
U.S.A.	INFINITI QX50	I55	2019.NULL	Auto back door	√	√	√	√		SP0611
U.S.A.	INFINITI QX50	I55	2019.NULL	Occupant detection			√	√		SP0584
U.S.A.	INFINITI QX50	I55	2019.NULL	Shift						
U.S.A.	INFINITI QX50	J55	2019.NULL	Adaptive light	√	√	√	√		SP0562
U.S.A.	INFINITI QX50	J55	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI QX50	J55	2019.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
U.S.A.	INFINITI QX50	J55	2019.NULL	All mode AWD/4WD	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL	DAST 2	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI QX50	J55	2019.NULL	CAN gateway	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL	Lane camera	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL	DAST 1	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL	Chassis control	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL	ANC		√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL	E-HUD	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI QX50	J55	2019.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI QX50	J55	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI QX50	J55	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL	3ch CAN GATEWAY	√	√	√	√		
U.S.A.	INFINITI QX50	J55	2019.NULL	ICC/ADAS 2	√	√	√	√		
U.S.A.	INFINITI QX56	JA60	2004.NULL_	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
U.S.A.	INFINITI QX56	JA60	2004.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
U.S.A.	INFINITI QX56	JA60	2004.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
U.S.A.	INFINITI QX56	JA60	2004.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
U.S.A.	INFINITI QX56	JA60	2004.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI QX56	JA60	2004.NULL	EPS/DAST 3	√	√	√	√		SP0506, SP0507
U.S.A.	INFINITI QX56	JA60	2004.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
U.S.A.	INFINITI QX56	JA60	2004.NULL	Motor control						
U.S.A.	INFINITI QX56	JA60	2004.NULL_	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI QX56	JA60	2004.NULL_	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
U.S.A.	INFINITI QX56	JA60	2004.NULL_	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
U.S.A.	INFINITI QX56	JA60	2004.NULL_	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
U.S.A.	INFINITI QX56	JA60	2004.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI QX56	JA60	2004.NULL	HVAC	√	√	√	√		
U.S.A.	INFINITI QX56	JA60	2004.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI QX56	JA60	2004.NULL_	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI QX56	JA60	2004.NULL	Auto slide door	√	√	√	√	AC0941	
U.S.A.	INFINITI QX56	JA60	2004.NULL	DIU		√	√	√		
U.S.A.	INFINITI QX56	JA60	2004.NULL	Adaptive light	√	√	√	√		
U.S.A.	INFINITI QX56	JA60	2004.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
U.S.A.	INFINITI QX56	JA60	2004.NULL	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
U.S.A.	INFINITI QX56	JA60	2004.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI QX56	JA60	2004.NULL_	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
U.S.A.	INFINITI QX56	JA60	2004.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
U.S.A.	INFINITI QX56	JA60	2004.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI QX56	JA60	2004.NULL	IVMS	√	√		√		
U.S.A.	INFINITI QX56	JA60	2004.NULL	Distance control	√	√		√		
U.S.A.	INFINITI QX56	JA60	2004.NULL	Active suspense system	√	√	√	√		
U.S.A.	INFINITI QX56	JA60	2004.NULL	Motor assist		√	√	√		SP0574
U.S.A.	INFINITI QX56	JA60	2004.NULL	ASCD	√	√	√	√		
U.S.A.	INFINITI QX56	JA60	2004.NULL	Active engine mount	√	√	√	√		
U.S.A.	INFINITI QX56	JA60	2004.NULL	TCS	√	√	√	√		
U.S.A.	INFINITI QX56	JA60	2004.NULL	S/blind camera	√			√		SP0572, SP0573
U.S.A.	INFINITI QX56	JA60	2004.NULL	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
U.S.A.	INFINITI QX56	JA60	2004.NULL	Nats immu	√	√	√			
U.S.A.	INFINITI QX56	JA60	2004.NULL	Rearview camera	√			√		SP0570, SP0571
U.S.A.	INFINITI QX56	JA60	2004.NULL	Smart entrance						SP0568
U.S.A.	INFINITI QX56	Z62	2011.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
U.S.A.	INFINITI QX56	Z62	2011.NULL	Laser/radar	√	√	√	√		
U.S.A.	INFINITI QX56	Z62	2011.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI QX56	Z62	2011.NULL_	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
U.S.A.	INFINITI QX56	Z62	2011.NULL_	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

XTOOL

U.S.A.	INFINITI QX56	Z62	2011.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI QX56	Z62	2011.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
U.S.A.	INFINITI QX56	Z62	2011.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
U.S.A.	INFINITI QX56	Z62	2011.NULL	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
U.S.A.	INFINITI QX56	Z62	2011.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
U.S.A.	INFINITI QX56	Z62	2011.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
U.S.A.	INFINITI QX56	Z62	2011.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI QX56	Z62	2011.NULL	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0476, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488, SP0489, SP0490
U.S.A.	INFINITI QX56	Z62	2011.NULL	E-SUS	√	√	√	√	AC1031. AC1032. AC1033	SP0585. SP0586. SP0587
U.S.A.	INFINITI QX56	Z62	2011.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI QX56	Z62	2011.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI QX56	Z62	2011.NULL	Auto back door	√	√	√	√		
U.S.A.	INFINITI QX56	Z62	2011.NULL	Occupant detection			√	√		SP0584
U.S.A.	INFINITI QX56	Z62	2011.NULL	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
U.S.A.	INFINITI QX56	Z62	2011.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI QX56	Z62	2011.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
U.S.A.	INFINITI QX56	Z62	2011.NULL	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
U.S.A.	INFINITI QX56	Z62	2011.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI QX56	Z62	2011.NULL	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI QX56	Z62	2011.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI QX56	Z62	2011.NULL	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
U.S.A.	INFINITI QX56	Z62	2011.NULL	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI QX56	Z62	2011.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI QX56	Z62	2011.NULL	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI QX56	Z62	2011.NULL	Rearview camera	√			√		SP0570, SP0571
U.S.A.	INFINITI QX60	L50	2019.2-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
U.S.A.	INFINITI QX60	L50	2019.2-	Laser/radar	√	√	√	√	AC0994	
U.S.A.	INFINITI QX60	L50	2019.2-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI QX60	L50	2019.2-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
U.S.A.	INFINITI QX60	L50	2019.2-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI QX60	L50	2019.2-	Air bag	√	√	√	√		
U.S.A.	INFINITI QX60	L50	2019.2-	EPS/DAST 3	√	√	√	√		
U.S.A.	INFINITI QX60	L50	2019.2-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
U.S.A.	INFINITI QX60	L50	2019.2-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
U.S.A.	INFINITI QX60	L50	2019.2-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
U.S.A.	INFINITI QX60	L50	2019.2-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
U.S.A.	INFINITI QX60	L50	2019.2-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
U.S.A.	INFINITI QX60	L50	2019.2-	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI QX60	L50	2019.2-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
U.S.A.	INFINITI QX60	L50	2019.2-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI QX60	L50	2019.2-	Auto back door	√	√	√	√		SP0611
U.S.A.	INFINITI QX60	L50	2019.2-	Occupant detection			√	√		SP0584
U.S.A.	INFINITI QX60	L50	2019.2-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
U.S.A.	INFINITI QX60	L50	2019.2-	Sonar	√	√	√	√	AC0962. AC0963. AC0964. AC0966. AC0967. AC0968. AC0969. AC0970	SP0553. SP0554. SP0555. SP0556. SP0557. SP0558. SP0559
U.S.A.	INFINITI QX60	L50	2019.2-	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI QX60	L50	2019.2-	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI QX60	L50	2019.2-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI QX60	L50	2019.2-	CAN gateway	√	√	√			
U.S.A.	INFINITI QX60	L50	2019.2-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
U.S.A.	INFINITI QX60	L50	2019.2-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
U.S.A.	INFINITI QX60	L50	2019.2-	ANC	√	√	√	√	AC1024	
U.S.A.	INFINITI QX60	L50	2019.2-	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI QX60	L50	2019.2-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI QX60	L50	2019.2-	HIGH BEAM ASSIST	√	√	√	√		
U.S.A.	INFINITI QX60	L50	2019.2-	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI QX60	L50	2019.2-	3ch CAN GATEWAY	√	√	√	√		
U.S.A.	INFINITI QX60	L50	2019.2-	ICC/ADAS 2	√	√	√	√		
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Laser/radar	√	√	√	√		
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	EPS/DAST 3	√	√	√	√		
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Motor control	√	√	√	√		
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0038, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	HV battery	√	√	√	√	AC1121	
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Auto back door	√	√	√	√		SP0611
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Occupant detection			√	√		SP0584
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0976, AC0977	
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	ANC	√	√	√	√		
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Telematics	√	√	√	√		SP0590, SP0591, SP0592
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	HIGH BEAM ASSIST	√	√	√	√		
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	ICC/ADAS 2	√	√	√	√		
U.S.A.	INFINITI QX60 HYBRID	HL50	2014.NULL	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
U.S.A.	INFINITI QX70	S51	2014.NULL	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
U.S.A.	INFINITI QX70	S51	2014.NULL	Laser/radar	√	√	√	√	AC0994	
U.S.A.	INFINITI QX70	S51	2014.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI QX70	S51	2014.NULL	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
U.S.A.	INFINITI QX70	S51	2014.NULL	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
U.S.A.	INFINITI QX70	S51	2014.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI QX70	S51	2014.NULL	EPS/DAST 3	√	√	√	√		SP0507
U.S.A.	INFINITI QX70	S51	2014.NULL	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
U.S.A.	INFINITI QX70	S51	2014.NULL	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
U.S.A.	INFINITI QX70	S51	2014.NULL	Transmission	√	√	√	√		SP0274
U.S.A.	INFINITI QX70	S51	2014.NULL	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

U.S.A.	INFINITI QX70	S51	2014.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0301,SP0313,SP0315
U.S.A.	INFINITI QX70	S51	2014.NULL	Total illum C/U	√			√	AC1133,AC1134,AC1135,AC1136,AC1137,AC1138,AC1139,AC1140,AC1141,AC1142	SP0614,SP0615,SP0616,SP0617,SP0618,SP0619,SP0620,SP0621
U.S.A.	INFINITI QX70	S51	2014.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI QX70	S51	2014.NULL	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
U.S.A.	INFINITI QX70	S51	2014.NULL	4WAS(front)	√	√	√	√	AC1027,AC1028	
U.S.A.	INFINITI QX70	S51	2014.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
U.S.A.	INFINITI QX70	S51	2014.NULL	Auto back door	√	√	√	√		SP0611
U.S.A.	INFINITI QX70	S51	2014.NULL	Occupant detection			√	√		SP0584
U.S.A.	INFINITI QX70	S51	2014.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
U.S.A.	INFINITI QX70	S51	2014.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
U.S.A.	INFINITI QX70	S51	2014.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968	SP0553,SP0554,SP0555,SP0556,SP0557
U.S.A.	INFINITI QX70	S51	2014.NULL	All mode AWD/4WD	√	√	√	√	AC0956	
U.S.A.	INFINITI QX70	S51	2014.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI QX70	S51	2014.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
U.S.A.	INFINITI QX70	S51	2014.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI QX70	S51	2014.NULL	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
U.S.A.	INFINITI QX70	S51	2014.NULL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
U.S.A.	INFINITI QX80	Z62	2019.NULL	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
U.S.A.	INFINITI QX80	Z62	2019.NULL	Laser/radar	√	√	√	√	AC0994	
U.S.A.	INFINITI QX80	Z62	2019.NULL	Head lamp levelizer	√	√	√	√	AC0864	SP0492
U.S.A.	INFINITI QX80	Z62	2019.NULL_	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
U.S.A.	INFINITI QX80	Z62	2019.NULL	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
U.S.A.	INFINITI QX80	Z62	2019.NULL	Air bag	√	√	√	√		
U.S.A.	INFINITI QX80	Z62	2019.NULL	EPS/DAST 3	√	√	√	√		SP0507
U.S.A.	INFINITI QX80	Z62	2019.NULL	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350,SP0351
U.S.A.	INFINITI QX80	Z62	2019.NULL_	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0282,AC0283,AC0284,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0039,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
U.S.A.	INFINITI QX80	Z62	2019.NULL_	Transmission	√	√	√	√	AC0460,AC0461,AC0462,AC0463,AC0464,AC0465,AC0466,AC0467,AC0468,AC0469,AC0470,AC0471,AC0472,AC0473,AC0474	SP0270,SP0274
U.S.A.	INFINITI QX80	Z62	2019.NULL	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429,SP0471
U.S.A.	INFINITI QX80	Z62	2019.NULL	ABS	√	√	√	√	AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
U.S.A.	INFINITI QX80	Z62	2019.NULL	Multi AV	√	√	√	√		SP0503
U.S.A.	INFINITI QX80	Z62	2019.NULL_	HVAC	√	√	√	√	AC0808,AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0478,SP0483,SP0484,SP0485,SP0486,SP0487,SP0488
U.S.A.	INFINITI QX80	Z62	2019.NULL	E-SUS	√	√	√	√	AC1031,AC1032,AC1033	SP0585,SP0586,SP0587
U.S.A.	INFINITI QX80	Z62	2019.NULL	Difference lock	√	√	√	√		
U.S.A.	INFINITI QX80	Z62	2019.NULL_	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
U.S.A.	INFINITI QX80	Z62	2019.NULL	Auto back door	√	√	√	√		
U.S.A.	INFINITI QX80	Z62	2019.NULL	Occupant detection			√	√		SP0584
U.S.A.	INFINITI QX80	Z62	2019.NULL	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
U.S.A.	INFINITI QX80	Z62	2019.NULL	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
U.S.A.	INFINITI QX80	Z62	2019.NULL	Sonar	√	√	√	√	AC0962,AC0963,AC0964,AC0966,AC0967,AC0968,AC0969,AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
U.S.A.	INFINITI QX80	Z62	2019.NULL	All mode AWD/4WD	√	√	√	√		SP0544,SP0545,SP0546,SP0547,SP0548,SP0549
U.S.A.	INFINITI QX80	Z62	2019.NULL	Precrash seatbelt	√	√	√	√		SP0612
U.S.A.	INFINITI QX80	Z62	2019.NULL	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
U.S.A.	INFINITI QX80	Z62	2019.NULL_	Intelligent key	√	√	√	√	AC0903,AC0904,AC0905,AC0906,AC0907,AC0908,AC0909,AC0910,AC0911,AC0912,AC0913,AC0914,AC0915,AC0916,AC0917,AC0918,AC0919,AC0920,AC0921,AC0922,AC0923,AC0924,AC0925,AC0926,AC0927,AC0928,AC0929,AC0930,AC0931,AC0932,AC0933,AC0934,AC0935	SP0511,SP0512,SP0517,SP0518,SP0519,SP0520,SP0521,SP0522,SP0523,SP0524,SP0525,SP0526,SP0527,SP0528,SP0529,SP0530,SP0531,SP0532,SP0533,SP0534,SP0535,SP0536,SP0537
U.S.A.	INFINITI QX80	Z62	2019.NULL	CAN gateway	√	√	√			
U.S.A.	INFINITI QX80	Z62	2019.NULL	Lane camera	√	√	√	√	AC0971,AC0972,AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
U.S.A.	INFINITI QX80	Z62	2019.NULL	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
U.S.A.	INFINITI QX80	Z62	2019.NULL	Side radar left	√	√	√	√	AC1025	SP0582
U.S.A.	INFINITI QX80	Z62	2019.NULL	Telematics	√	√	√	√		SP0590,SP0591,SP0592
U.S.A.	INFINITI QX80	Z62	2019.NULL	HIGH BEAM ASSIST	√	√	√	√		
U.S.A.	INFINITI QX80	Z62	2019.NULL	Side radar right	√	√	√	√	AC1026	SP0583
U.S.A.	INFINITI QX80	Z62	2019.NULL	6ch CAN GATEWAY	√	√	√	√		
U.S.A.	INFINITI QX80	Z62	2019.NULL	ICC/ADAS 2	√	√	√	√		
U.S.A.	INFINITI QX80	Z62	2019.NULL	Air levelizer	√	√	√	√	AC0991,AC0992,AC0993	
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0282,AC0283,AC0307,AC0333,AC0334,AC0335,AC0336,AC0337,AC0338,AC0339,AC0351,AC0352,AC0365,AC0366,AC0367,AC0369,AC0371,AC0372,AC0373,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0043,SP0045,SP0051,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0083,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0196,SP0197,SP0198,SP0199,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0225,SP0237,SP0238,SP0239
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270,SP0274
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0301,SP0313,SP0315,SP0316,SP0317,SP0319
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976	SP0560
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
UN bulgaria	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896	SP0510
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350

UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN bulgaria	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
UN bulgaria	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN bulgaria	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
UN bulgaria	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
UN bulgaria	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
UN bulgaria	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
UN bulgaria	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
UN bulgaria	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
UN bulgaria	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
UN bulgaria	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
UN bulgaria	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
UN bulgaria	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		

XTOOL

UN bulgaria	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
UN bulgaria	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
UN bulgaria	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
UN bulgaria	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
UN bulgaria	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
UN bulgaria	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
UN bulgaria	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
UN bulgaria	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
UN bulgaria	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
UN bulgaria	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
UN bulgaria	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN bulgaria	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
UN bulgaria	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN bulgaria	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN bulgaria	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
UN bulgaria	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
UN bulgaria	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN bulgaria	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN bulgaria	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
UN bulgaria	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
UN bulgaria	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
UN bulgaria	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
UN bulgaria	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN bulgaria	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN bulgaria	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN bulgaria	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
UN bulgaria	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
UN bulgaria	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN bulgaria	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
UN bulgaria	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
UN bulgaria	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
UN bulgaria	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
UN bulgaria	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN bulgaria	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
UN bulgaria	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
UN bulgaria	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN bulgaria	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
UN bulgaria	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
UN bulgaria	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
UN bulgaria	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN bulgaria	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
UN bulgaria	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582

UN bulgaria	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
UN bulgaria	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
UN bulgaria	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
UN bulgaria	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
UN bulgaria	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0330,AC0331,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247,SP0274,SP0276
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979,AC0981,AC0982	SP0562
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
UN bulgaria	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
UN bulgaria	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
UN bulgaria	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
UN bulgaria	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
UN bulgaria	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
UN bulgaria	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
UN bulgaria	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
UN bulgaria	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
UN bulgaria	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
UN bulgaria	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
UN bulgaria	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
UN bulgaria	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
UN bulgaria	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		

UN bulgaria	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN bulgaria	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN bulgaria	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN bulgaria	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
UN bulgaria	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
UN bulgaria	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN bulgaria	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
UN bulgaria	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
UN bulgaria	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
UN bulgaria	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
UN bulgaria	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
UN bulgaria	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
UN bulgaria	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
UN bulgaria	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN bulgaria	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
UN bulgaria	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
UN bulgaria	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
UN bulgaria	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
UN bulgaria	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
UN bulgaria	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN bulgaria	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
UN bulgaria	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
UN bulgaria	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
UN bulgaria	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
UN bulgaria	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN bulgaria	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		

UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN bulgaria	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN bulgaria	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
UN bulgaria	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
UN bulgaria	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN bulgaria	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN bulgaria	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
UN bulgaria	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
UN bulgaria	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN bulgaria	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN bulgaria	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
UN bulgaria	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
UN bulgaria	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
UN bulgaria	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
UN bulgaria	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN bulgaria	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN bulgaria	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN bulgaria	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
UN bulgaria	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
UN bulgaria	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN bulgaria	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
UN bulgaria	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
UN bulgaria	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
UN bulgaria	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN bulgaria	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
UN bulgaria	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN bulgaria	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN bulgaria	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN bulgaria	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
UN bulgaria	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN bulgaria	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
UN bulgaria	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN bulgaria	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
UN bulgaria	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN bulgaria	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN bulgaria	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
UN bulgaria	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
UN bulgaria	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN bulgaria	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN bulgaria	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
UN bulgaria	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN bulgaria	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
UN bulgaria	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN bulgaria	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN bulgaria	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN bulgaria	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
UN bulgaria	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	

UN bulgaria	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
UN bulgaria	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN bulgaria	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
UN bulgaria	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN bulgaria	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
UN bulgaria	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
UN bulgaria	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN bulgaria	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
UN bulgaria	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
UN bulgaria	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
UN bulgaria	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN bulgaria	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN bulgaria	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
UN bulgaria	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
UN bulgaria	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN bulgaria	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN bulgaria	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
UN bulgaria	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN bulgaria	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
UN bulgaria	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
UN bulgaria	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN bulgaria	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN bulgaria	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN bulgaria	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
UN bulgaria	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
UN bulgaria	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN bulgaria	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN bulgaria	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
UN bulgaria	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
UN bulgaria	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
UN bulgaria	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN bulgaria	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
UN bulgaria	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN bulgaria	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN bulgaria	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN bulgaria	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
UN bulgaria	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
UN bulgaria	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN bulgaria	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
UN bulgaria	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
UN bulgaria	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN bulgaria	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
UN bulgaria	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN bulgaria	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
UN bulgaria	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN bulgaria	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
UN bulgaria	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
UN bulgaria	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN bulgaria	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
UN bulgaria	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
UN bulgaria	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
UN bulgaria	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
UN bulgaria	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
UN bulgaria	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
UN bulgaria	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
UN bulgaria	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN bulgaria	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
UN bulgaria	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
UN bulgaria	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562

UN bulgaria	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN bulgaria	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
UN bulgaria	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
UN bulgaria	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
UN bulgaria	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
UN bulgaria	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
UN bulgaria	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN bulgaria	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN bulgaria	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
UN bulgaria	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN bulgaria	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
UN bulgaria	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
UN bulgaria	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
UN bulgaria	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
UN bulgaria	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
UN	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
UN	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN denmark	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
UN	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN denmark	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
UN	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
UN denmark	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
UN	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
UN	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
UN	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
UN	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
UN	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
UN	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN denmark	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
UN	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
UN	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
UN	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
UN	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN denmark	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
UN	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
UN	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
UN	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
UN	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
UN	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
UN denmark	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN denmark	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
UN	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
UN	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN denmark	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
UN	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN denmark	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
UN	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
UN	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN denmark	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
UN	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
UN	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
UN	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006. AC1007. AC1008. AC1009. AC1010	SP0575. SP0576. SP0577. SP0578. SP0579. SP0580
UN denmark	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
UN	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
UN	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN denmark	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN denmark	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
UN	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
UN denmark	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
UN	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
UN	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
UN denmark	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN denmark	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980	SP0561. SP0562
UN	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029. AC1030	
UN	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553. SP0554. SP0555. SP0556
UN	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
UN	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
UN	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
UN	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
UN	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
UN	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
UN	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
UN denmark	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
UN	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
UN denmark	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
UN	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
UN	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
UN	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
UN	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		

UN	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
UN denmark	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
UN denmark	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
UN denmark	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
UN denmark	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
UN denmark	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
UN denmark	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
UN	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
UN	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
UN denmark	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
UN	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
UN	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
UN denmark	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
UN	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
UN denmark	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
UN	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
UN	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
UN denmark	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
UN denmark	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
UN	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
UN	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
UN	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN denmark	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
UN	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
UN	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN denmark	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
UN	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
UN	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
UN	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
UN	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
UN denmark	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
UN	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
UN	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
UN	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
UN	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
UN	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
UN	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
UN	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
UN	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
UN	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
UN denmark	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
UN	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
UN	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
UN	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
UN	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
UN	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
UN	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN denmark	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
UN	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
UN	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
UN denmark	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
UN	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
UN	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
UN denmark	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
UN	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
UN	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
UN	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
UN	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
UN denmark	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
UN	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	

UN	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
UN	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
UN	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
UN	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
UN	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
UN	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
UN	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN denmark	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
UN	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
UN	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN denmark	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
UN	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
UN denmark	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
UN	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
UN	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
UN denmark	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN denmark	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
UN	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
UN	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
UN	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
UN	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
UN	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
UN	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
UN	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
UN	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
UN	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
UN	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
UN	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
UN	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
UN	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
UN	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
UN	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
UN	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
UN	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
UN	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
UN	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN denmark	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
UN	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
UN	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
UN	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN denmark	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
UN	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

XTOOL

UN denmark	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
UN	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
UN	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN denmark	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
UN	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
UN	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
UN	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
UN	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN denmark	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
UN	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
UN	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN denmark	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
UN	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
UN denmark	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
UN	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
UN	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
UN denmark	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
UN	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
UN	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
UN	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
UN	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
UN	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
UN	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
UN	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
UN	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
UN	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN denmark	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
UN	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
UN	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN denmark	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
UN	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN denmark	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
UN	INFINITI QX50	I50	2013.8-	Multi AV	√	√	√	√		SP0503
UN denmark	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
UN	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
UN	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
UN	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
UN	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
UN	INFINITI QX50	I50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
UN	INFINITI QX50	I50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN	INFINITI QX50	I50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
UN	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
UN	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
UN	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN denmark	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
UN	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
UN	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN denmark	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN denmark	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
UN	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
UN	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
UN	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
UN	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN denmark	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
UN	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
UN	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
UN	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
UN	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612

UN	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
UN	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
UN	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
UN	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
UN	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
UN	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
UN	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN denmark	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
UN	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
UN	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
UN denmark	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN denmark	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
UN	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
UN	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
UN	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
UN denmark	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
UN	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
UN	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
UN denmark	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
UN	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
UN	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
UN	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
UN	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
UN	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
UN	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
UN	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
UN	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
UN	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
UN	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
UN	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
UN	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
UN	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
UN gibralter	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	

UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN gibralter	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
UN gibralter	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN gibralter	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	

UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
UN gibralter	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
UN gibralter	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
UN gibralter	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
UN gibralter	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
UN gibralter	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN gibralter	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN gibralter	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN gibralter	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
UN gibralter	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
UN gibralter	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
UN gibralter	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
UN gibralter	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
UN gibralter	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
UN gibralter	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
UN gibralter	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
UN gibralter	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
UN gibralter	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
UN gibralter	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
UN gibralter	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
UN gibralter	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
UN gibralter	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
UN gibralter	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
UN gibralter	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
UN gibralter	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
UN gibralter	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
UN gibralter	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
UN gibralter	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					

XTOOL

UN gibralter	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
UN gibralter	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
UN gibralter	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
UN gibralter	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
UN gibralter	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
UN gibralter	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
UN gibralter	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
UN gibralter	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN gibralter	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
UN gibralter	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN gibralter	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN gibralter	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
UN gibralter	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
UN gibralter	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN gibralter	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN gibralter	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
UN gibralter	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
UN gibralter	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
UN gibralter	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
UN gibralter	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN gibralter	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN gibralter	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN gibralter	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
UN gibralter	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
UN gibralter	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN gibralter	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
UN gibralter	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
UN gibralter	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
UN gibralter	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
UN gibralter	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN gibralter	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
UN gibralter	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
UN gibralter	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN gibralter	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
UN gibralter	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
UN gibralter	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
UN gibralter	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN gibralter	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
UN gibralter	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
UN gibralter	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
UN gibralter	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN gibralter	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
UN gibralter	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
UN gibralter	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		

XTOOL

UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
UN gibralter	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
UN gibralter	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN gibralter	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
UN gibralter	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN gibralter	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN gibralter	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
UN gibralter	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
UN gibralter	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN gibralter	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN gibralter	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
UN gibralter	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
UN gibralter	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
UN gibralter	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
UN gibralter	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN gibralter	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN gibralter	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN gibralter	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
UN gibralter	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
UN gibralter	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN gibralter	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
UN gibralter	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
UN gibralter	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
UN gibralter	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
UN gibralter	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567

XTOOL

UN gibralter	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
UN gibralter	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
UN gibralter	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN gibralter	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
UN gibralter	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
UN gibralter	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
UN gibralter	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
UN gibralter	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
UN gibralter	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
UN gibralter	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
UN gibralter	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
UN gibralter	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
UN gibralter	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
UN gibralter	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
UN gibralter	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027,AC1028	
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956,AC0957,AC0958,AC0959,AC0960	SP0544,SP0545,SP0546,SP0547,SP0548,SP0549,SP0550,SP0551
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
UN gibralter	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN gibralter	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894,AC0895,AC0896,AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509,SP0510
UN gibralter	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		

Xtool

UN gibralter	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN gibralter	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN gibralter	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
UN gibralter	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
UN gibralter	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN gibralter	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN gibralter	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
UN gibralter	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
UN gibralter	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
UN gibralter	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
UN gibralter	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN gibralter	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN gibralter	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN gibralter	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
UN gibralter	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
UN gibralter	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN gibralter	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
UN gibralter	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
UN gibralter	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
UN gibralter	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN gibralter	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
UN gibralter	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN gibralter	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN gibralter	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN gibralter	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
UN gibralter	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN gibralter	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
UN gibralter	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN gibralter	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
UN gibralter	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN gibralter	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN gibralter	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
UN gibralter	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
UN gibralter	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN gibralter	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN gibralter	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
UN gibralter	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN gibralter	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
UN gibralter	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN gibralter	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN gibralter	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN gibralter	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
UN gibralter	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
UN gibralter	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
UN gibralter	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN gibralter	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
UN gibralter	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN gibralter	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
UN gibralter	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
UN gibralter	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN gibralter	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
UN gibralter	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
UN gibralter	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
UN gibralter	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

UN gibralter	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN gibralter	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN gibralter	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
UN gibralter	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
UN gibralter	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN gibralter	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN gibralter	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
UN gibralter	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN gibralter	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
UN gibralter	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
UN gibralter	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN gibralter	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN gibralter	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN gibralter	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
UN gibralter	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
UN gibralter	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN gibralter	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN gibralter	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
UN gibralter	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
UN gibralter	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
UN gibralter	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN gibralter	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
UN gibralter	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN gibralter	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN gibralter	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN gibralter	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
UN gibralter	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
UN gibralter	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN gibralter	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
UN gibralter	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
UN gibralter	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN gibralter	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
UN gibralter	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN gibralter	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
UN gibralter	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN gibralter	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
UN gibralter	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
UN gibralter	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN gibralter	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
UN gibralter	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
UN gibralter	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
UN gibralter	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
UN gibralter	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
UN gibralter	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
UN gibralter	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
UN gibralter	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN gibralter	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
UN gibralter	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
UN gibralter	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
UN gibralter	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN gibralter	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
UN gibralter	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
UN gibralter	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
UN gibralter	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
UN gibralter	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
UN gibralter	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN gibralter	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN gibralter	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
UN gibralter	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN gibralter	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		

XTOOL

UN gibralter	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
UN gibralter	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
UN gibralter	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
UN gibralter	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
UN rwanda	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN rwanda	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
UN rwanda	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN rwanda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
UN rwanda	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
UN rwanda	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
UN rwanda	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
UN rwanda	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
UN rwanda	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN rwanda	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN rwanda	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553. SP0554. SP0555. SP0556
UN rwanda	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
UN rwanda	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
UN rwanda	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
UN rwanda	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
UN rwanda	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
UN rwanda	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
UN rwanda	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
UN rwanda	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
UN rwanda	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
UN rwanda	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
UN rwanda	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
UN rwanda	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
UN rwanda	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
UN rwanda	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
UN rwanda	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
UN rwanda	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
UN rwanda	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
UN rwanda	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
UN rwanda	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
UN rwanda	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
UN rwanda	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
UN rwanda	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			

UN rwanda	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
UN rwanda	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
UN rwanda	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
UN rwanda	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
UN rwanda	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
UN rwanda	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
UN rwanda	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
UN rwanda	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
UN rwanda	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
UN rwanda	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
UN rwanda	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
UN rwanda	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
UN rwanda	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
UN rwanda	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0274
UN rwanda	INFINITI Q50	V37	2013.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
UN rwanda	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
UN rwanda	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
UN rwanda	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
UN rwanda	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
UN rwanda	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
UN rwanda	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
UN rwanda	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979,AC0981,AC0982	SP0562
UN rwanda	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
UN rwanda	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
UN rwanda	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
UN rwanda	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
UN rwanda	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
UN rwanda	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
UN rwanda	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
UN rwanda	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
UN rwanda	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN rwanda	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
UN rwanda	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604,SP0605,SP0606
UN rwanda	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
UN rwanda	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
UN rwanda	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
UN rwanda	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
UN rwanda	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
UN rwanda	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
UN rwanda	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
UN rwanda	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
UN rwanda	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0495,SP0496,SP0497
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0330,AC0331,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247,SP0274,SP0276
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533	SP0300,SP0313,SP0315
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946,AC0947,AC0948,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084,AC1085,AC1086,AC1087,AC1088,AC1089,AC1106	
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979,AC0981,AC0982	SP0562
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
UN rwanda	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
UN rwanda	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
UN rwanda	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
UN rwanda	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
UN rwanda	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
UN rwanda	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
UN rwanda	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
UN rwanda	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351

UN rwanda	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN rwanda	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
UN rwanda	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
UN rwanda	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
UN rwanda	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
UN rwanda	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN rwanda	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN rwanda	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN rwanda	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
UN rwanda	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
UN rwanda	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN rwanda	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
UN rwanda	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
UN rwanda	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
UN rwanda	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
UN rwanda	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
UN rwanda	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
UN rwanda	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
UN rwanda	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN rwanda	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
UN rwanda	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
UN rwanda	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
UN rwanda	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
UN rwanda	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
UN rwanda	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN rwanda	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
UN rwanda	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
UN rwanda	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
UN rwanda	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
UN rwanda	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN rwanda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN rwanda	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN rwanda	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
UN rwanda	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
UN rwanda	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497

UN rwanda	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
UN rwanda	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
UN rwanda	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
UN rwanda	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
UN rwanda	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN rwanda	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
UN rwanda	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
UN rwanda	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
UN rwanda	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
UN rwanda	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
UN rwanda	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN rwanda	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN rwanda	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
UN rwanda	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
UN rwanda	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN rwanda	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
UN rwanda	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
UN rwanda	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
UN rwanda	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN rwanda	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
UN rwanda	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN rwanda	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN rwanda	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN rwanda	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
UN rwanda	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN rwanda	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
UN rwanda	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN rwanda	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
UN rwanda	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN rwanda	INFINITI QX50	I50	2013.8-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
UN rwanda	INFINITI QX50	I50	2013.8-	Air bag	√	√	√	√		
UN rwanda	INFINITI QX50	I50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
UN rwanda	INFINITI QX50	I50	2013.8-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
UN rwanda	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN rwanda	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
UN rwanda	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN rwanda	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
UN rwanda	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN rwanda	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN rwanda	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN rwanda	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
UN rwanda	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
UN rwanda	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
UN rwanda	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN rwanda	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
UN rwanda	INFINITI QX50	I50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN rwanda	INFINITI QX50	I50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
UN rwanda	INFINITI QX50	I50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
UN rwanda	INFINITI QX50	I50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN rwanda	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
UN rwanda	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
UN rwanda	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
UN rwanda	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
UN rwanda	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
UN rwanda	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
UN rwanda	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
UN rwanda	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
UN rwanda	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
UN rwanda	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
UN rwanda	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
UN rwanda	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
UN rwanda	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
UN rwanda	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
UN rwanda	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
UN rwanda	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN rwanda	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
UN rwanda	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
UN rwanda	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
UN rwanda	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN rwanda	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
UN rwanda	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
UN rwanda	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
UN rwanda	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
UN rwanda	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
UN rwanda	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN rwanda	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
UN rwanda	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN rwanda	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
UN rwanda	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
UN rwanda	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN rwanda	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
UN rwanda	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
UN rwanda	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
UN rwanda	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
UN rwanda	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
UN rwanda	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
UN rwanda	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
UN rwanda	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
UN rwanda	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

UN rwanda	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
UN rwanda	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
UN rwanda	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
UN rwanda	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
UN rwanda	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
UN rwanda	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
UN rwanda	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
UN rwanda	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
UN rwanda	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
UN rwanda	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
UN rwanda	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
UN rwanda	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
UN rwanda	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
UN rwanda	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
UN rwanda	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
UN rwanda	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
UN rwanda	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
UN rwanda	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
UN rwanda	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
UN rwanda	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
UN rwanda	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
UN rwanda	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
UN rwanda	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
UN rwanda	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
UN rwanda	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
UN rwanda	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
UN rwanda	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Uganda	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uganda	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uganda	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Uganda	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uganda	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Uganda	INFINITI EX35/EX37	I50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Uganda	INFINITI EX35/EX37	I50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uganda	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Uganda	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uganda	INFINITI EX35/EX37	I50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uganda	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uganda	INFINITI EX35/EX37	I50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uganda	INFINITI EX35/EX37	I50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Uganda	INFINITI EX35/EX37	I50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Uganda	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Uganda	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Uganda	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Uganda	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Uganda	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uganda	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uganda	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Uganda	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uganda	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Uganda	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Uganda	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uganda	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Uganda	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Uganda	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Uganda	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uganda	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Uganda	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Uganda	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uganda	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uganda	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Uganda	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Uganda	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Uganda	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Uganda	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uganda	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	

Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Uganda	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Uganda	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Uganda	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uganda	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uganda	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Uganda	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uganda	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uganda	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Uganda	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uganda	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uganda	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Uganda	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uganda	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uganda	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uganda	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uganda	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Uganda	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uganda	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Uganda	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Uganda	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Uganda	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Uganda	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uganda	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Uganda	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Uganda	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Uganda	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Uganda	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Uganda	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Uganda	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Uganda	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Uganda	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Uganda	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uganda	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uganda	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uganda	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uganda	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uganda	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Uganda	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Uganda	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Uganda	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Uganda	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uganda	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Uganda	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Uganda	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Uganda	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Uganda	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Uganda	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Uganda	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Uganda	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501

Uganda	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Uganda	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Uganda	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Uganda	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Uganda	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Uganda	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Uganda	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Uganda	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Uganda	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Uganda	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Uganda	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Uganda	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Uganda	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Uganda	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Uganda	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Uganda	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Uganda	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Uganda	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Uganda	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Uganda	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Uganda	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uganda	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Uganda	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Uganda	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Uganda	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uganda	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Uganda	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Uganda	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Uganda	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Uganda	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Uganda	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uganda	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uganda	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Uganda	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Uganda	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uganda	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Uganda	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Uganda	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Uganda	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Uganda	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uganda	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Uganda	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Uganda	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uganda	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Uganda	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Uganda	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Uganda	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Uganda	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Uganda	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Uganda	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Uganda	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uganda	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Uganda	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Uganda	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		

Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973,AC0974,AC0976,AC0977	
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043,AC1044,AC1045,AC1046,AC1047,AC1048,AC1049,AC1050,AC1051,AC1052,AC1053,AC1054,AC1055,AC1056,AC1057,AC1058,AC1059,AC1060,AC1061,AC1062,AC1063,AC1064,AC1065,AC1066,AC1067,AC1068,AC1069,AC1070,AC1071,AC1072,AC1073,AC1074,AC1075,AC1076,AC1077	
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014,AC1015,AC1016,AC1017,AC1018,AC1019,AC1020,AC1021	
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129,AC1130,AC1131	
Uganda	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122,AC1123,AC1124,AC1125,AC1126	
Uganda	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Uganda	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Uganda	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0869,AC0870,AC0871,AC0872,AC0873,AC0874,AC0875,AC0876,AC0877,AC0878,AC0879,AC0880,AC0881,AC0882,AC0883,AC0884,AC0885	SP0494,SP0495,SP0496,SP0497
Uganda	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Uganda	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Uganda	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Uganda	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Uganda	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0229,AC0256,AC0266,AC0270,AC0272,AC0277,AC0282,AC0283,AC0284,AC0307,AC0308,AC0309,AC0311,AC0312,AC0313,AC0314,AC0315,AC0316,AC0317,AC0318,AC0319,AC0320,AC0321,AC0322,AC0323,AC0324,AC0325,AC0326,AC0327,AC0330,AC0331,AC0332,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0009,SP0016,SP0017,SP0018,SP0032,SP0033,SP0034,SP0038,SP0039,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0082,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0128,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0193,SP0194,SP0195,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Uganda	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Uganda	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613,AC0618,AC0663,AC0690,AC0692,AC0702	SP0372,SP0429
Uganda	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498,AC0509,AC0510,AC0514,AC0515,AC0528,AC0529,AC0531,AC0532,AC0533,AC0536	SP0300,SP0313,SP0315
Uganda	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Uganda	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472,SP0473,SP0474,SP0475,SP0477,SP0479,SP0480,SP0481,SP0482,SP0486,SP0487
Uganda	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027,AC1028	
Uganda	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Uganda	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Uganda	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980,AC0981,AC0982	SP0561,SP0562
Uganda	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029,AC1030	
Uganda	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966,AC0967,AC0968	SP0557
Uganda	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Uganda	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Uganda	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Uganda	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985,AC0986,AC0987,AC0988,AC0989	SP0563,SP0564,SP0565,SP0566,SP0567
Uganda	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Uganda	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Uganda	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uganda	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Uganda	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Uganda	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Uganda	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Uganda	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111,AC1112	SP0608,SP0609,SP0610
Uganda	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590,SP0591,SP0592
Uganda	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Uganda	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Uganda	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Uganda	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Uganda	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006,AC1007,AC1008,AC1009,AC1010	SP0575,SP0576,SP0577,SP0578,SP0579,SP0580
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004,AC0005,AC0006,AC0007,AC0008,AC0009,AC0034,AC0035,AC0036,AC0037,AC0038,AC0039,AC0040,AC0041,AC0042,AC0049,AC0051,AC0052,AC0053,AC0054,AC0060,AC0061,AC0062,AC0063,AC0065,AC0066,AC0067,AC0068,AC0069,AC0070,AC0131,AC0147,AC0148,AC0149,AC0150,AC0151,AC0152,AC0153,AC0154,AC0155,AC0156,AC0157,AC0158,AC0159,AC0160,AC0161,AC0162,AC0163,AC0164,AC0165,AC0166,AC0167,AC0168,AC0169,AC0170,AC0171,AC0172,AC0173,AC0174,AC0175,AC0176,AC0177,AC0178,AC0179,AC0180,AC0181,AC0182,AC0183,AC0184,AC0185,AC0186,AC0187,AC0188,AC0189,AC0190,AC0191,AC0192,AC0193,AC0194,AC0195,AC0196,AC0197,AC0198,AC0199,AC0200,AC0225,AC0226,AC0282,AC0283,AC0307,AC0351,AC0352,AC0365,AC0366,AC0369,AC0371,AC0372,AC0375,AC0388,AC0389,AC0390,AC0391,AC0392,AC0393,AC0394	SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0016,SP0017,SP0018,SP0032,SP0033,SP0038,SP0043,SP0053,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0067,SP0074,SP0078,SP0079,SP0080,SP0081,SP0085,SP0086,SP0087,SP0100,SP0103,SP0104,SP0105,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,SP0116,SP0140,SP0143,SP0150,SP0152,SP0153,SP0158,SP0159,SP0160,SP0172,SP0173,SP0191,SP0192,SP0200,SP0212,SP0213,SP0216,SP0217,SP0218,SP0219,SP0221,SP0223,SP0237,SP0238,SP0239
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613,AC0618,AC0663,AC0692,AC0702,AC0719	SP0372,SP0429
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498,AC0507,AC0508,AC0509,AC0510,AC0511,AC0512,AC0513,AC0514,AC0515,AC0516,AC0517,AC0527,AC0528,AC0529,AC0530,AC0531,AC0532,AC0533,AC0534,AC0535	SP0315,SP0316,SP0317,SP0319
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034,AC1035,AC1036,AC1037,AC1038,AC1039	
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945,AC0946,AC0947,AC0948,AC0949,AC0950,AC0951,AC0952,AC0953,AC0954,AC0955	SP0541,SP0542,SP0543
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978,AC0979,AC0980	SP0561,SP0562
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962,AC0963,AC0964	SP0553,SP0554,SP0555,SP0556
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983,AC0984,AC0985,AC0986,AC0987,AC0988,AC0989,AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Uganda	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897,AC0898,AC0899,AC0900,AC0901,AC0902	SP0508,SP0509
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865,AC0866,AC0867,AC0868,AC0876,AC0877,AC0884	SP0494
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811,AC0815,AC0816,AC0817,AC0818,AC0819,AC0821,AC0822,AC0825,AC0831	
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347,SP0348,SP0349,SP0350

Uganda	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uganda	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uganda	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Uganda	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Uganda	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Uganda	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uganda	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Uganda	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Uganda	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Uganda	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Uganda	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Uganda	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Uganda	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Uganda	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Uganda	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Uganda	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uganda	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uganda	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Uganda	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Uganda	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uganda	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Uganda	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Uganda	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Uganda	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uganda	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Uganda	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Uganda	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uganda	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Uganda	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Uganda	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uganda	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Uganda	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Uganda	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Uganda	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Uganda	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uganda	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Uganda	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Uganda	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uganda	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Uganda	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Uganda	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uganda	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Uganda	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uganda	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uganda	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uganda	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uganda	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Uganda	INFINITI QX50	I50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Uganda	INFINITI QX50	I50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uganda	INFINITI QX50	I50	2013.8-	CAN gateway	√	√	√	√		
Uganda	INFINITI QX50	I50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Uganda	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Uganda	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Uganda	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uganda	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Uganda	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Uganda	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Uganda	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Uganda	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uganda	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Uganda	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Uganda	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uganda	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Uganda	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Uganda	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uganda	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315

Uganda	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Uganda	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Uganda	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uganda	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uganda	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Uganda	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Uganda	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uganda	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uganda	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uganda	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Uganda	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Uganda	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uganda	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Uganda	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Uganda	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uganda	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Uganda	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Uganda	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Uganda	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uganda	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Uganda	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Uganda	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Uganda	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Uganda	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uganda	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Uganda	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uganda	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Uganda	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Uganda	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uganda	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Uganda	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Uganda	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Uganda	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Uganda	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Uganda	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Uganda	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Uganda	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uganda	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Uganda	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Uganda	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Uganda	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uganda	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Uganda	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Uganda	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Uganda	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Uganda	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Uganda	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Uganda	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Uganda	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Uganda	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uganda	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Uganda	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Uganda	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Uganda	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Uganda	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Ukraine	INFINITI EX35	J50	2008.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI EX35	J50	2008.4-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ukraine	INFINITI EX35	J50	2008.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI EX35	J50	2008.4-	Air bag	√	√	√	√		
Ukraine	INFINITI EX35	J50	2008.4-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ukraine	INFINITI EX35	J50	2008.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Ukraine	INFINITI EX35	J50	2008.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ukraine	INFINITI EX35	J50	2008.4-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ukraine	INFINITI EX35	J50	2008.4-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Ukraine	INFINITI EX35	J50	2008.4-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI EX35	J50	2008.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI EX35	J50	2008.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ukraine	INFINITI EX35	J50	2008.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ukraine	INFINITI EX35	J50	2008.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ukraine	INFINITI EX35	J50	2008.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Ukraine	INFINITI EX35	J50	2008.4-	Precrash seatbelt	√	√	√	√		SP0612
Ukraine	INFINITI EX35	J50	2008.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Air bag	√	√	√	√		
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	BSW/buzzer	√	√	√	√	AC1022, AC1023	
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Side radar left	√	√	√	√	AC1025	SP0582
Ukraine	INFINITI EX35/EX30D	J50	2009.7-	Side radar right	√	√	√	√	AC1026	SP0583
Ukraine	INFINITI FX35/FX45	S50	2006.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI FX35/FX45	S50	2006.7-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Ukraine	INFINITI FX35/FX45	S50	2006.7-	Air bag	√	√	√	√		
Ukraine	INFINITI FX35/FX45	S50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349

Ukraine	INFINITI FX35/FX45	S50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ukraine	INFINITI FX35/FX45	S50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Ukraine	INFINITI FX35/FX45	S50	2006.7-	BCM				√	AC0653, AC0695	SP0372, SP0429
Ukraine	INFINITI FX35/FX45	S50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ukraine	INFINITI FX35/FX45	S50	2006.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI FX35/FX45	S50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Ukraine	INFINITI FX35/FX45	S50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Ukraine	INFINITI FX35/FX45	S50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Ukraine	INFINITI FX35/FX45	S50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Ukraine	INFINITI FX37/FX50	S51	2008.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ukraine	INFINITI FX37/FX50	S51	2008.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI FX37/FX50	S51	2008.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ukraine	INFINITI FX37/FX50	S51	2008.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI FX37/FX50	S51	2008.7-	Air bag	√	√	√	√		
Ukraine	INFINITI FX37/FX50	S51	2008.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ukraine	INFINITI FX37/FX50	S51	2008.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ukraine	INFINITI FX37/FX50	S51	2008.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Ukraine	INFINITI FX37/FX50	S51	2008.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ukraine	INFINITI FX37/FX50	S51	2008.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Ukraine	INFINITI FX37/FX50	S51	2008.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Ukraine	INFINITI FX37/FX50	S51	2008.7-	Multi AV	√	√	√	√		
Ukraine	INFINITI FX37/FX50	S51	2008.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ukraine	INFINITI FX37/FX50	S51	2008.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI FX37/FX50	S51	2008.7-	Occupant detection			√	√		SP0584
Ukraine	INFINITI FX37/FX50	S51	2008.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ukraine	INFINITI FX37/FX50	S51	2008.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ukraine	INFINITI FX37/FX50	S51	2008.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Ukraine	INFINITI FX37/FX50	S51	2008.7-	CAN gateway	√	√	√			
Ukraine	INFINITI FX37/FX50	S51	2008.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Air bag	√	√	√	√		
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0236, SP0237, SP0238, SP0239
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Auto back door	√	√	√	√		SP0611
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Occupant detection			√	√		SP0584
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Precrash seatbelt	√	√	√	√		SP0612
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	CAN gateway	√	√	√			
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ukraine	INFINITI FX37/FX50/FX30D	S51	2009.7-	Rearview camera	√			√		SP0570, SP0571
Ukraine	INFINITI G35 SEDAN	V36	2006.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI G35 SEDAN	V36	2006.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI G35 SEDAN	V36	2006.12-	Air bag	√	√	√	√		
Ukraine	INFINITI G35 SEDAN	V36	2006.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ukraine	INFINITI G35 SEDAN	V36	2006.12-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ukraine	INFINITI G35 SEDAN	V36	2006.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Ukraine	INFINITI G35 SEDAN	V36	2006.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ukraine	INFINITI G35 SEDAN	V36	2006.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ukraine	INFINITI G35 SEDAN	V36	2006.12-	Multi AV	√	√	√	√		
Ukraine	INFINITI G35 SEDAN	V36	2006.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI G35 SEDAN	V36	2006.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Ukraine	INFINITI G35 SEDAN	V36	2006.12-	All mode AWD/4WD	√	√	√	√	AC0957	
Ukraine	INFINITI G35 SEDAN	V36	2006.12-	Rearview camera	√			√		SP0570, SP0571
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Air bag	√	√	√	√		

Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Pop up hood	√	√	√	√		
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	Precrash seatbelt	√	√	√	√		
Ukraine	INFINITI G37 CONVERTIBLE	HV36	2009.6-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Ukraine	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	Air bag	√	√	√	√		
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	Pop up hood	√	√	√	√		
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Ukraine	INFINITI G37 SEDAN	V36	2008.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ukraine	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ukraine	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Ukraine	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Ukraine	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Ukraine	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Ukraine	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ukraine	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ukraine	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Ukraine	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ukraine	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Ukraine	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Ukraine	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Ukraine	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Ukraine	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Ukraine	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Ukraine	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ukraine	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Ukraine	INFINITI M35H	HY51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ukraine	INFINITI M35H	HY51	2011.1-	Laser/radar	√	√	√	√		
Ukraine	INFINITI M35H	HY51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI M35H	HY51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ukraine	INFINITI M35H	HY51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI M35H	HY51	2011.1-	Air bag	√	√	√	√		
Ukraine	INFINITI M35H	HY51	2011.1-	EPS/DAST 3	√	√	√	√		
Ukraine	INFINITI M35H	HY51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ukraine	INFINITI M35H	HY51	2011.1-	Motor control	√	√	√	√		

Ukraine	INFINITI M35H	HY51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ukraine	INFINITI M35H	HY51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274, SP0276
Ukraine	INFINITI M35H	HY51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ukraine	INFINITI M35H	HY51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ukraine	INFINITI M35H	HY51	2011.1-	Diag data recorder	√					
Ukraine	INFINITI M35H	HY51	2011.1-	Pop up hood	√	√	√	√		
Ukraine	INFINITI M35H	HY51	2011.1-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI M35H	HY51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ukraine	INFINITI M35H	HY51	2011.1-	HV battery	√	√	√	√	AC1121	
Ukraine	INFINITI M35H	HY51	2011.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI M35H	HY51	2011.1-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Ukraine	INFINITI M35H	HY51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ukraine	INFINITI M35H	HY51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ukraine	INFINITI M35H	HY51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ukraine	INFINITI M35H	HY51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Ukraine	INFINITI M35H	HY51	2011.1-	CAN gateway	√	√	√			
Ukraine	INFINITI M35H	HY51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ukraine	INFINITI M35H	HY51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Ukraine	INFINITI M35H	HY51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Ukraine	INFINITI M35H	HY51	2011.1-	Brake	√	√	√	√	AC1127	
Ukraine	INFINITI M35H	HY51	2011.1-	VSP	√	√	√	√	AC1124, AC1125, AC1126	
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Laser/radar	√	√	√	√		
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Air bag	√	√	√	√		
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Pop up hood	√	√	√	√		
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Precrash seatbelt	√	√	√	√		SP0612
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	CAN gateway	√	√	√			
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar left	√	√	√	√	AC1025	SP0582
Ukraine	INFINITI M37/M56/M30D	Y51	2010.4-	Side radar right	√	√	√	√	AC1026	SP0583
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Air pressure monitor	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Air bag	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	EPS/DAST 3	√	√	√			
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Ukraine	INFINITI Q30/QX30	H15	2018.1-	EHS/PKB	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Transmission	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Ukraine	INFINITI Q30/QX30	H15	2018.1-	ABS	√	√	√	√		SP0308
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Multi AV	√	√	√	√		SP0501
Ukraine	INFINITI Q30/QX30	H15	2018.1-	HVAC	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Auto drive position	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Shift	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	All mode AWD/4WD	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	AVM	√	√		√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Intelligent key	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	CAN gateway	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	ANC	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Telematics	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	FSCM	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Siren control unit	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Overhead Control Panel Unit	√			√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Universal Garage Door Opener	√			√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Upper control panel cont unit	√					
Ukraine	INFINITI Q30/QX30	H15	2018.1-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Ukraine	INFINITI Q30/QX30	H15	2018.1-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Light/Rain Sensor Module	√			√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	EC Mirror Compass	√					

XTOOL

Ukraine	INFINITI Q30/QX30	H15	2018.1-	Intelligent Battery Sensor	√					
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Alarm siren	√			√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Radar sensor	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Steering column cont module	√	√	√			
Ukraine	INFINITI Q30/QX30	H15	2018.1-	ICC sensor	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Trailer recognition control unit	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	H/L control module LH	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Powertrain cont module	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Side radar LH	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	LED H/L control module LH	√			√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Steering Wheel Switch Pad	√			√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Parking assist	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Occupant Classification Unit	√			√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Electronic Ignition Switch cont unit	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	H/L control module RH	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Front camera unit	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	Side radar RH	√	√	√	√		
Ukraine	INFINITI Q30/QX30	H15	2018.1-	LED H/L control module RH	√			√		
Ukraine	INFINITI Q50	V37	2014.5-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ukraine	INFINITI Q50	V37	2014.5-	Laser/radar	√	√	√	√	AC0994	
Ukraine	INFINITI Q50	V37	2014.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI Q50	V37	2014.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ukraine	INFINITI Q50	V37	2014.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI Q50	V37	2014.5-	Air bag	√	√	√	√		
Ukraine	INFINITI Q50	V37	2014.5-	EPS/DAST 3	√	√	√	√		SP0507
Ukraine	INFINITI Q50	V37	2014.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ukraine	INFINITI Q50	V37	2014.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ukraine	INFINITI Q50	V37	2014.5-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Ukraine	INFINITI Q50	V37	2014.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ukraine	INFINITI Q50	V37	2014.5-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ukraine	INFINITI Q50	V37	2014.5-	Pop up hood	√	√	√	√		
Ukraine	INFINITI Q50	V37	2014.5-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI Q50	V37	2014.5-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ukraine	INFINITI Q50	V37	2014.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ukraine	INFINITI Q50	V37	2014.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI Q50	V37	2014.5-	Occupant detection			√	√		SP0584
Ukraine	INFINITI Q50	V37	2014.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ukraine	INFINITI Q50	V37	2014.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ukraine	INFINITI Q50	V37	2014.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ukraine	INFINITI Q50	V37	2014.5-	All mode AWD/4WD	√	√	√	√	AC0956, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Ukraine	INFINITI Q50	V37	2014.5-	DAST 2	√	√	√	√		
Ukraine	INFINITI Q50	V37	2014.5-	Precrash seatbelt	√	√	√	√		SP0612
Ukraine	INFINITI Q50	V37	2014.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ukraine	INFINITI Q50	V37	2014.5-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Ukraine	INFINITI Q50	V37	2014.5-	CAN gateway	√	√	√			
Ukraine	INFINITI Q50	V37	2014.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ukraine	INFINITI Q50	V37	2014.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ukraine	INFINITI Q50	V37	2014.5-	DAST 1	√	√	√	√		
Ukraine	INFINITI Q50	V37	2014.5-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Ukraine	INFINITI Q50	V37	2014.5-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Ukraine	INFINITI Q50	V37	2014.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Ukraine	INFINITI Q50	V37	2014.5-	ANC	√	√	√	√	AC1024	
Ukraine	INFINITI Q50	V37	2014.5-	Side radar left	√	√	√	√	AC1025	SP0582
Ukraine	INFINITI Q50	V37	2014.5-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ukraine	INFINITI Q50	V37	2014.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ukraine	INFINITI Q50	V37	2014.5-	HIGH BEAM ASSIST	√	√	√	√		
Ukraine	INFINITI Q50	V37	2014.5-	Side radar right	√	√	√	√	AC1026	SP0583
Ukraine	INFINITI Q50	V37	2014.5-	6ch CAN GATEWAY	√	√	√	√		
Ukraine	INFINITI Q50	V37	2014.5-	3ch CAN GATEWAY	√	√	√	√		
Ukraine	INFINITI Q50	V37	2014.5-	ICC/ADAS 2	√	√	√	√		
Ukraine	INFINITI Q50	V37	2014.5-	PMAS	√	√	√	√		
Ukraine	INFINITI Q50	V37	2014.5-	FSCM	√	√	√	√	AC1109	
Ukraine	INFINITI Q50	V37	2014.5-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√		
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0274, SP0276
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Ukraine	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509

Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Laser/radar	√	√	√	√		
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Air bag	√	√	√	√		
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	EPS/DAST 3	√	√	√	√		
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Motor control	√	√	√	√		
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Transmission	√	√	√	√		SP0276
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Pop up hood	√	√	√	√		
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	HV battery	√	√	√	√	AC1121	
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Occupant detection			√	√		SP0584
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	DAST 2	√	√	√	√		
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Precrash seatbelt	√	√	√	√		SP0612
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Lane camera	√	√	√	√		
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	DAST 1	√	√	√	√		
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Side radar left	√	√	√	√	AC1025	SP0582
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	HIGH BEAM ASSIST	√	√	√	√		
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Side radar right	√	√	√	√	AC1026	SP0583
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	VSP	√	√	√	√		
Ukraine	INFINITI Q50 Hybrid	HV37	2018.4-	Brake	√	√	√	√	AC1127	
Ukraine	INFINITI Q60	CV37	2016.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ukraine	INFINITI Q60	CV37	2016.7-	Laser/radar	√	√	√	√	AC0994	
Ukraine	INFINITI Q60	CV37	2016.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI Q60	CV37	2016.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ukraine	INFINITI Q60	CV37	2016.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI Q60	CV37	2016.7-	Air bag	√	√	√	√		
Ukraine	INFINITI Q60	CV37	2016.7-	EPS/DAST 3	√	√	√	√		
Ukraine	INFINITI Q60	CV37	2016.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ukraine	INFINITI Q60	CV37	2016.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ukraine	INFINITI Q60	CV37	2016.7-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Ukraine	INFINITI Q60	CV37	2016.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Ukraine	INFINITI Q60	CV37	2016.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Ukraine	INFINITI Q60	CV37	2016.7-	Pop up hood	√	√	√	√		
Ukraine	INFINITI Q60	CV37	2016.7-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI Q60	CV37	2016.7-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ukraine	INFINITI Q60	CV37	2016.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI Q60	CV37	2016.7-	Occupant detection			√	√		SP0584
Ukraine	INFINITI Q60	CV37	2016.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ukraine	INFINITI Q60	CV37	2016.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ukraine	INFINITI Q60	CV37	2016.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ukraine	INFINITI Q60	CV37	2016.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Ukraine	INFINITI Q60	CV37	2016.7-	DAST 2	√	√	√	√		
Ukraine	INFINITI Q60	CV37	2016.7-	Precrash seatbelt	√	√	√	√		SP0612
Ukraine	INFINITI Q60	CV37	2016.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ukraine	INFINITI Q60	CV37	2016.7-	CAN gateway	√	√	√			
Ukraine	INFINITI Q60	CV37	2016.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ukraine	INFINITI Q60	CV37	2016.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ukraine	INFINITI Q60	CV37	2016.7-	DAST 1	√	√	√	√		
Ukraine	INFINITI Q60	CV37	2016.7-	Chassis control	√	√	√	√		
Ukraine	INFINITI Q60	CV37	2016.7-	ANC	√	√	√	√		
Ukraine	INFINITI Q60	CV37	2016.7-	Side radar left	√	√	√	√	AC1025	SP0582
Ukraine	INFINITI Q60	CV37	2016.7-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ukraine	INFINITI Q60	CV37	2016.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ukraine	INFINITI Q60	CV37	2016.7-	HIGH BEAM ASSIST	√	√	√	√		
Ukraine	INFINITI Q60	CV37	2016.7-	Side radar right	√	√	√	√	AC1026	SP0583
Ukraine	INFINITI Q60	CV37	2016.7-	Lane camera 2	√	√	√	√		
Ukraine	INFINITI Q60	CV37	2016.7-	6ch CAN GATEWAY	√	√	√	√		
Ukraine	INFINITI Q60	CV37	2016.7-	ICC/ADAS 2	√	√	√	√		
Ukraine	INFINITI Q60	CV37	2016.7-	FSCM	√	√	√	√	AC1109	
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503

Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ukraine	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ukraine	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ukraine	INFINITI Q70	Y51	2015.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Ukraine	INFINITI Q70	Y51	2015.4-	Laser/radar	√	√	√	√	AC0994	
Ukraine	INFINITI Q70	Y51	2015.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI Q70	Y51	2015.4-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Ukraine	INFINITI Q70	Y51	2015.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI Q70	Y51	2015.4-	Air bag	√	√	√	√		
Ukraine	INFINITI Q70	Y51	2015.4-	EPS/DAST 3	√	√	√	√		
Ukraine	INFINITI Q70	Y51	2015.4-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Ukraine	INFINITI Q70	Y51	2015.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ukraine	INFINITI Q70	Y51	2015.4-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Ukraine	INFINITI Q70	Y51	2015.4-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ukraine	INFINITI Q70	Y51	2015.4-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Ukraine	INFINITI Q70	Y51	2015.4-	Pop up hood	√	√	√	√		
Ukraine	INFINITI Q70	Y51	2015.4-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI Q70	Y51	2015.4-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Ukraine	INFINITI Q70	Y51	2015.4-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ukraine	INFINITI Q70	Y51	2015.4-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI Q70	Y51	2015.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ukraine	INFINITI Q70	Y51	2015.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ukraine	INFINITI Q70	Y51	2015.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Ukraine	INFINITI Q70	Y51	2015.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Ukraine	INFINITI Q70	Y51	2015.4-	Precrash seatbelt	√	√	√	√		SP0612
Ukraine	INFINITI Q70	Y51	2015.4-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ukraine	INFINITI Q70	Y51	2015.4-	CAN gateway	√	√	√			
Ukraine	INFINITI Q70	Y51	2015.4-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ukraine	INFINITI Q70	Y51	2015.4-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ukraine	INFINITI Q70	Y51	2015.4-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Ukraine	INFINITI Q70	Y51	2015.4-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ukraine	INFINITI Q70	Y51	2015.4-	Side radar left	√	√	√	√	AC1025	SP0582
Ukraine	INFINITI Q70	Y51	2015.4-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Ukraine	INFINITI Q70	Y51	2015.4-	Side radar right	√	√	√	√	AC1026	SP0583
Ukraine	INFINITI Q70	Y51	2015.4-	PTC heater	√	√	√	√	AC1107, AC1108	
Ukraine	INFINITI Q70	Y51	2015.4-	6ch CAN GATEWAY	√	√	√	√		
Ukraine	INFINITI Q70	Y51	2015.4-	FSCM	√	√	√	√	AC1109	
Ukraine	INFINITI QX50	J50	2015.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Ukraine	INFINITI QX50	J50	2015.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI QX50	J50	2015.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Ukraine	INFINITI QX50	J50	2015.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI QX50	J50	2015.11-	Air bag	√	√	√	√		
Ukraine	INFINITI QX50	I50	2015.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ukraine	INFINITI QX50	J50	2015.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ukraine	INFINITI QX50	J50	2015.11-	Transmission	√	√	√	√		SP0274
Ukraine	INFINITI QX50	J50	2015.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ukraine	INFINITI QX50	J50	2015.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Ukraine	INFINITI QX50	J50	2015.11-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI QX50	J50	2015.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI QX50	J50	2015.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ukraine	INFINITI QX50	J50	2015.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Ukraine	INFINITI QX50	J50	2015.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Ukraine	INFINITI QX50	J50	2015.11-	Precrash seatbelt	√	√	√	√		SP0612
Ukraine	INFINITI QX50	J50	2015.11-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Ukraine	INFINITI QX56	JA60	2007.8-	ICC/ADAS						
Ukraine	INFINITI QX56	JA60	2007.8-	IPDM E/R		√	√	√	AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Ukraine	INFINITI QX56	JA60	2007.8-	Air bag	√	√	√	√		
Ukraine	INFINITI QX56	JA60	2007.8-	Meter/M&A	√	√	√	√		SP0347, SP0348
Ukraine	INFINITI QX56	JA60	2007.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Ukraine	INFINITI QX56	JA60	2007.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Ukraine	INFINITI QX56	JA60	2007.8-	BCM				√	AC0613, AC0653, AC0663, AC0689, AC0692, AC0695, AC0702, AC0719	SP0372, SP0429

Ukraine	INFINITI QX56	JA60	2007.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Ukraine	INFINITI QX56	JA60	2007.8-	Multi AV	√	√	√	√		
Ukraine	INFINITI QX56	JA60	2007.8-	HVAC	√	√	√	√		
Ukraine	INFINITI QX56	JA60	2007.8-	Difference lock	√	√	√	√		
Ukraine	INFINITI QX56	JA60	2007.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI QX56	JA60	2007.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Ukraine	INFINITI QX56	JA60	2007.8-	All mode AWD/4WD	√	√	√	√		SP0544
Ukraine	INFINITI QX56	JA60	2007.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Ukraine	INFINITI QX56	JA60	2007.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Ukraine	INFINITI QX56	JA60	2007.8-	Rearview camera	√			√		SP0570, SP0571
Ukraine	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Ukraine	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Ukraine	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Ukraine	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Ukraine	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Ukraine	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Ukraine	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Ukraine	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√		SP0274
Ukraine	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Ukraine	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Ukraine	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Ukraine	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Ukraine	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ukraine	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Ukraine	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Ukraine	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Ukraine	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ukraine	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Ukraine	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Ukraine	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Ukraine	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ukraine	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Ukraine	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Ukraine	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Ukraine	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ukraine	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Ukraine	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ukraine	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Ukraine	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Ukraine	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√		
Ukraine	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Ukraine	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Ukraine	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Ukraine	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Ukraine	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Ukraine	INFINITI QX80	Z62	2013.6-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Ukraine	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Ukraine	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Ukraine	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Ukraine	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Ukraine	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Ukraine	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Ukraine	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Ukraine	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Ukraine	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Ukraine	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Ukraine	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Ukraine	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Ukraine	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Ukraine	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Ukraine	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Ukraine	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Ukraine	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Ukraine	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Ukraine	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Ukraine	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Ukraine	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Ukraine	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Ukraine	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Ukraine	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Ukraine	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Ukraine	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Ukraine	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Uruguay	INFINITI EX35/EX37	I50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uruguay	INFINITI EX35/EX37	I50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Uruguay	INFINITI EX35/EX37	I50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uruguay	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Uruguay	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Uruguay	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Uruguay	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uruguay	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Uruguay	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Uruguay	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uruguay	INFINITI EX35/EX37	I50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uruguay	INFINITI EX35/EX37	I50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uruguay	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uruguay	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Uruguay	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Uruguay	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Uruguay	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uruguay	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Uruguay	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Uruguay	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Uruguay	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uruguay	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Uruguay	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Uruguay	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Uruguay	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Uruguay	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Uruguay	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uruguay	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Uruguay	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Uruguay	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Uruguay	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Uruguay	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uruguay	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Uruguay	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Uruguay	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uruguay	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Uruguay	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Uruguay	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Uruguay	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Uruguay	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Uruguay	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Uruguay	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Uruguay	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Uruguay	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uruguay	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Uruguay	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uruguay	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Uruguay	INFINITI IX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Uruguay	INFINITI IX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Uruguay	INFINITI IX35	L50	2012.9-	CAN gateway	√	√	√			
Uruguay	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Uruguay	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Uruguay	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Uruguay	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Uruguay	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Uruguay	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uruguay	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Uruguay	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Uruguay	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uruguay	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Uruguay	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Uruguay	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Uruguay	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Uruguay	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Uruguay	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Uruguay	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Uruguay	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Uruguay	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Uruguay	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Uruguay	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uruguay	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uruguay	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uruguay	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uruguay	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uruguay	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Uruguay	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Uruguay	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Uruguay	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Uruguay	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uruguay	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Uruguay	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Uruguay	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Uruguay	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Uruguay	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uruguay	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Uruguay	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Uruguay	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Uruguay	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Uruguay	INFINITI Q45	F50	2001.8-	Motor control						
Uruguay	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uruguay	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Uruguay	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Uruguay	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Uruguay	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Uruguay	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Uruguay	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Uruguay	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uruguay	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Uruguay	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Uruguay	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Uruguay	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uruguay	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Uruguay	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Uruguay	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Uruguay	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Uruguay	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uruguay	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Uruguay	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Uruguay	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Uruguay	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Uruguay	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Uruguay	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Uruguay	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Uruguay	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Uruguay	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Uruguay	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Uruguay	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Uruguay	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Uruguay	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Uruguay	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Uruguay	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Uruguay	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Uruguay	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Uruguay	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Uruguay	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uruguay	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Uruguay	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Uruguay	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Uruguay	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Uruguay	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Uruguay	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Uruguay	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uruguay	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Uruguay	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Uruguay	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uruguay	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uruguay	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Uruguay	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Uruguay	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Uruguay	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Uruguay	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Uruguay	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Uruguay	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uruguay	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekista	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekista	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uzbekista	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekista	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Uzbekista	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uzbekistan	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Uzbekistan	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Uzbekista	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uzbekistan	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Uzbekista	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Uzbekistan	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekista	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uzbekista	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekista	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uzbekista	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Uzbekista	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekista	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uzbekistan	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uzbekistan	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Uzbekistan	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekista	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uzbekistan	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Motor control						
Uzbekistan	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekistan	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288

Uzbekistan	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Uzbekistan	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Uzbekistan	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekistan	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Uzbekista	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uzbekistan	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Uzbekistan	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Uzbekistan	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekista	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Uzbekistan	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekista	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Uzbekista	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Uzbekista	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Uzbekista	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Uzbekista	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Uzbekista	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Uzbekista	INFINITI G35 COUPE	CV35	2005.1-	Motor control						
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288

Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Uzbekistan	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Uzbekistan	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Uzbekistan	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekistan	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Uzbekistan	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uzbekistan	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Uzbekistan	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Uzbekistan	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uzbekistan	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uzbekistan	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Uzbekistan	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekistan	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Uzbekistan	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Uzbekistan	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uzbekistan	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Uzbekistan	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Uzbekistan	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekistan	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Uzbekistan	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Uzbekistan	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekistan	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Uzbekistan	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Uzbekistan	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Uzbekistan	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekistan	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√		SP0276, SP0278, SP0279
Uzbekistan	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Uzbekistan	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Uzbekistan	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Uzbekistan	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Uzbekistan	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekistan	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Uzbekistan	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Uzbekistan	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekistan	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Uzbekistan	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Uzbekistan	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekistan	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Uzbekistan	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Uzbekistan	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekistan	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekistan	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978.AC0979.AC0980	SP0561.SP0562
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029.AC1030	
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekistan	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekistan	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Uzbekistan	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Uzbekistan	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Uzbekistan	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Uzbekistan	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Uzbekistan	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Uzbekistan	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Uzbekistan	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Uzbekistan	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Uzbekistan	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Uzbekistan	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Uzbekistan	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Uzbekistan	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Uzbekistan	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Uzbekistan	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Uzbekistan	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		

XTOOL

Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√			
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√						
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175		
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170		SP0622
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√			
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√						
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√						
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√			
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√			
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√				
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√			
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√			
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√			
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√			
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√			
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√			
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√			
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√			
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√			
Uzbekistan	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√			
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√			
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√			
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√			
Uzbekista	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√			
Uzbekista	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902		SP0508, SP0509, SP0510
Uzbekista	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864		SP0492, SP0493
Uzbekista	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884		SP0494
Uzbekistan	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831		
Uzbekista	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√			
Uzbekista	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√			SP0506, SP0507
Uzbekista	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√			SP0347, SP0348, SP0349
Uzbekista	INFINITI Q45	F50	2001.8-	Motor control							
Uzbekistan	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394		SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekistan	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474		SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Uzbekistan	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719		SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Uzbekistan	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536		SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Uzbekista	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√			SP0503
Uzbekista	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√			
Uzbekista	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√			
Uzbekistan	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955		SP0541, SP0542, SP0543
Uzbekista	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941		
Uzbekista	INFINITI Q45	F50	2001.8-	DIU		√	√	√			
Uzbekista	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√			
Uzbekista	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970		SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekista	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957		SP0544
Uzbekista	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990		SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekistan	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932		SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Uzbekista	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973		
Uzbekista	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961		
Uzbekista	INFINITI Q45	F50	2001.8-	IVMS	√	√		√			
Uzbekista	INFINITI Q45	F50	2001.8-	Distance control	√	√		√			
Uzbekista	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√			
Uzbekista	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√			SP0574
Uzbekista	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√			
Uzbekista	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√			
Uzbekista	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√			
Uzbekista	INFINITI Q45	F50	2001.8-	S/blind camera	√			√			SP0572, SP0573
Uzbekista	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993		
Uzbekista	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√				
Uzbekista	INFINITI Q45	F50	2001.8-	Rearview camera	√			√			SP0570, SP0571
Uzbekista	INFINITI Q45	F50	2001.8-	Smart entrance							SP0568
Uzbekista	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902		SP0508, SP0509, SP0510
Uzbekista	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994		
Uzbekista	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864		SP0492
Uzbekistan	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885		SP0494, SP0495, SP0496, SP0497
Uzbekista	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831		
Uzbekista	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√			
Uzbekista	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√			
Uzbekista	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√			SP0348, SP0349, SP0350, SP0351
Uzbekistan	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394		SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekista	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√			SP0247, SP0265, SP0274
Uzbekista	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702		SP0372, SP0429
Uzbekistan	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536		SP0300, SP0313, SP0315
Uzbekista	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√			
Uzbekista	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√			SP0503
Uzbekistan	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809		SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Uzbekista	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039		
Uzbekista	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028		
Uzbekistan	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955		SP0541, SP0542, SP0543
Uzbekista	INFINITI Q50	V37	2013.9-	Occupant detection			√	√			SP0584
Uzbekista	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982		SP0561, SP0562
Uzbekista	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030		
Uzbekista	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970		SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekista	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Uzbekista	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√			
Uzbekista	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√			SP0612
Uzbekista	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990		SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekista	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√			SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Uzbekista	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√				
Uzbekista	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977		SP0560
Uzbekista	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961		
Uzbekista	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√			
Uzbekista	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√			SP0604, SP0605, SP0606

Uzbekistan	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Uzbekistan	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Uzbekistan	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Uzbekistan	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekistan	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Uzbekistan	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uzbekistan	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Uzbekistan	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekistan	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Uzbekistan	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Uzbekistan	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Uzbekistan	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Uzbekistan	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Uzbekistan	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Uzbekistan	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Uzbekistan	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Uzbekistan	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Uzbekistan	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Uzbekistan	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Uzbekistan	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Uzbekistan	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Uzbekistan	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	

Uzbekista	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Uzbekista	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Uzbekista	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348,SP0349,SP0350,SP0351
Uzbekista n	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekista	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247,SP0265,SP0270,SP0274
Uzbekista	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372,SP0429
Uzbekista n	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300,SP0313,SP0315
Uzbekista	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Uzbekista	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Uzbekista n	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Uzbekista	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uzbekista n	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541,SP0542,SP0543
Uzbekista	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Uzbekista	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561,SP0562
Uzbekista	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekista	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553,SP0554,SP0555,SP0556,SP0557,SP0558,SP0559
Uzbekista	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Uzbekista	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Uzbekista	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekista	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563,SP0564,SP0565,SP0566,SP0567
Uzbekista	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511,SP0515,SP0516,SP0538,SP0539,SP0540
Uzbekista	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Uzbekista	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Uzbekista	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekista	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Uzbekista	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Uzbekista	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Uzbekista	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekista	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Uzbekista	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uzbekista	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Uzbekista	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekista	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Uzbekista	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Uzbekista	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Uzbekista	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekista n	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uzbekista n	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uzbekista n	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uzbekista n	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekista	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekista	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510

Uzbekista	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Uzbekista	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Uzbekista	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekista	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Uzbekista	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Uzbekista	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Uzbekista	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Uzbekistan	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Uzbekistan	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Uzbekista	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Uzbekistan	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Uzbekista	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Uzbekista	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Uzbekistan	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Uzbekista	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Uzbekista	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Uzbekista	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uzbekistan	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekista	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Uzbekista	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Uzbekista	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Uzbekista	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekista	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekista	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Uzbekista	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekista	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekista	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Uzbekista	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Uzbekista	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekista	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Uzbekista	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Uzbekista	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekista	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Uzbekista	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uzbekista	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekista	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Uzbekista	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Uzbekista	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Uzbekista	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Uzbekista	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Uzbekista	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Uzbekista	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Uzbekista	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Uzbekista	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekista	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Uzbekista	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Uzbekista	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uzbekistan	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Uzbekista	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Uzbekista	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uzbekistan	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Uzbekista	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Uzbekistan	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekista	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Uzbekista	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uzbekista	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekista	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekista	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Uzbekista	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekista	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekista	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Uzbekista	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Uzbekista	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Uzbekista	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekista	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uzbekista	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekista	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Uzbekista	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Uzbekistan	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Uzbekistan	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Uzbekista	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Uzbekistan	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekista	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Uzbekistan	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Uzbekista	INFINITI QX50	I55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Uzbekista	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Uzbekista	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Uzbekista	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Uzbekista	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Uzbekista	INFINITI QX50	J55	2018.5-	Shift						
Uzbekista	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Uzbekista	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekista	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekista	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567

Uzbekista	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	ANC						
Uzbekista	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekista	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uzbekista	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekista	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Uzbekista	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Uzbekista	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Uzbekista	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Uzbekista	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Uzbekista n	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Uzbekista	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Uzbekista	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Uzbekista	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Uzbekista	INFINITI QX56	JA60	2004.10-	Motor control						
Uzbekista n	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekista n	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Uzbekista n	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Uzbekista n	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Uzbekista	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Uzbekista	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Uzbekista	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Uzbekista n	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekista	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Uzbekista	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Uzbekista	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Uzbekista	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekista	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Uzbekista	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekista n	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Uzbekista	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Uzbekista	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekista	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Uzbekista	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Uzbekista	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Uzbekista	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Uzbekista	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Uzbekista	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Uzbekista	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Uzbekista	INFINITI QX56	JA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Uzbekista	INFINITI QX56	JA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Uzbekista	INFINITI QX56	JA60	2004.10-	Nats immu	√	√	√			
Uzbekista	INFINITI QX56	JA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Uzbekista	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Uzbekista	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Uzbekista	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Uzbekista	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekista n	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Uzbekista	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekista	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Uzbekista	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Uzbekista n	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekista	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270, SP0274
Uzbekista	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Uzbekista	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Uzbekista	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Uzbekista n	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Uzbekista	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Uzbekista	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekista	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Uzbekista	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Uzbekista	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uzbekista	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekista	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekista	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Uzbekista	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekista	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekista	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Uzbekista	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Uzbekista	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekista	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uzbekista	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekista	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Uzbekista	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Uzbekista	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekista n	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Uzbekista	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekista	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Uzbekista	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Uzbekista	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Uzbekista	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		
Uzbekista n	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekista n	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Uzbekista	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Uzbekista n	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Uzbekista	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Uzbekista	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Uzbekista	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Uzbekista	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Uzbekista	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Uzbekista	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Uzbekista	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Uzbekista	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekista	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekista	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Uzbekista	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekista	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekista	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Uzbekista	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Uzbekista	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Uzbekista	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Uzbekista	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Uzbekista	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekista	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uzbekista	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Uzbekista	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekista	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Uzbekista	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Uzbekista	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Uzbekista	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Uzbekistan	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekistan	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Uzbekistan	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Uzbekista	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Uzbekista	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Uzbekista	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Uzbekista	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Uzbekista	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekista	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Uzbekista	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Uzbekista	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Uzbekistan	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Uzbekistan	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Uzbekista	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Uzbekista	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Uzbekista	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Uzbekista	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Uzbekista	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Uzbekista	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uzbekistan	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekista	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Uzbekista	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Uzbekista	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Uzbekista	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekista	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekista	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Uzbekista	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekista	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekista	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Uzbekista	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Uzbekista	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Uzbekista	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Uzbekista	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Uzbekista	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekista	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uzbekista	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekista	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Uzbekista	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Uzbekista	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Uzbekista	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Uzbekistan	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Uzbekista	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Uzbekista	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Uzbekista	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Uzbekista	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Uzbekistan	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Uzbekistan	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274

Uzbekista	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Uzbekista	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Uzbekista	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Uzbekista n	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Uzbekista	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Uzbekista	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Uzbekista	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Uzbekista n	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Uzbekista	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Uzbekista	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Uzbekista	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Uzbekista	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Uzbekista	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Uzbekista	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Uzbekista	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Uzbekista	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Uzbekista n	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Uzbekista	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Uzbekista	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Uzbekista	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Uzbekista	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Uzbekista	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Uzbekista	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Uzbekista	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Uzbekista	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Uzbekista	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Uzbekista	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Uzbekista	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Venezuela	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Venezuela	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Venezuela	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Venezuela	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Venezuela	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Venezuela	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Venezuela	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Venezuela	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Venezuela	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Venezuela	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Venezuela	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Venezuela	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Venezuela	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Venezuela	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Venezuela	INFINITI EX35/EX37	I50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Venezuela	INFINITI EX35/EX37	I50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Venezuela	INFINITI EX35/EX37	I50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Venezuela	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Venezuela	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Venezuela	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Venezuela	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Venezuela	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Venezuela	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Venezuela	INFINITI FX35/FX50	S51	2011.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Venezuela	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Venezuela	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Venezuela	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	Precrash seatbelt	√	√	√	√		
Venezuela	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Venezuela	INFINITI G37 CONVERTIBLE	HV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978. AC0979. AC0980	SP0561. SP0562
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962. AC0963. AC0964	SP0553. SP0554. SP0555. SP0556
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Venezuela	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Venezuela	INFINITI JX35	L50	2012.9-	Laser/radar	√	√	√	√		
Venezuela	INFINITI JX35	L50	2012.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Venezuela	INFINITI JX35	L50	2012.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Venezuela	INFINITI JX35	L50	2012.9-	EPS/DAST 3	√	√	√	√		
Venezuela	INFINITI JX35	L50	2012.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Venezuela	INFINITI JX35	L50	2012.9-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Venezuela	INFINITI JX35	L50	2012.9-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0286, SP0287, SP0288, SP0289, SP0290, SP0291, SP0292
Venezuela	INFINITI JX35	L50	2012.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Venezuela	INFINITI JX35	L50	2012.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Venezuela	INFINITI JX35	L50	2012.9-	Multi AV	√	√	√	√		SP0503
Venezuela	INFINITI JX35	L50	2012.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Venezuela	INFINITI JX35	L50	2012.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Venezuela	INFINITI JX35	L50	2012.9-	Auto back door	√	√	√	√		SP0611
Venezuela	INFINITI JX35	L50	2012.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Venezuela	INFINITI JX35	L50	2012.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Venezuela	INFINITI JX35	L50	2012.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Venezuela	INFINITI JX35	L50	2012.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Venezuela	INFINITI JX35	L50	2012.9-	CAN gateway	√	√	√			
Venezuela	INFINITI JX35	L50	2012.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Venezuela	INFINITI JX35	L50	2012.9-	Side radar left	√	√	√	√	AC1025	SP0582
Venezuela	INFINITI JX35	L50	2012.9-	Side radar right	√	√	√	√	AC1026	SP0583
Venezuela	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894. AC0895. AC0896	SP0510
Venezuela	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Venezuela	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Venezuela	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Venezuela	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Venezuela	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Venezuela	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Venezuela	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Venezuela	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Venezuela	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Venezuela	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Venezuela	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Venezuela	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Venezuela	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Venezuela	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Venezuela	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Venezuela	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Venezuela	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Venezuela	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562

Venezuela	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Venezuela	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Venezuela	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Venezuela	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Venezuela	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Venezuela	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Venezuela	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Venezuela	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Venezuela	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Venezuela	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Venezuela	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Venezuela	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Venezuela	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Venezuela	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Venezuela	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Venezuela	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Venezuela	INFINITI Q45	F50	2001.8-	Motor control						
Venezuela	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Venezuela	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Venezuela	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Venezuela	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Venezuela	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Venezuela	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Venezuela	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Venezuela	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Venezuela	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Venezuela	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Venezuela	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Venezuela	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Venezuela	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Venezuela	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Venezuela	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Venezuela	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Venezuela	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Venezuela	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Venezuela	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Venezuela	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Venezuela	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Venezuela	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Venezuela	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Venezuela	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Venezuela	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Venezuela	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Venezuela	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Venezuela	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Venezuela	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Venezuela	INFINITI QX56	Z62	2011.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Venezuela	INFINITI QX56	Z62	2011.8-	Laser/radar	√	√	√	√		
Venezuela	INFINITI QX56	Z62	2011.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Venezuela	INFINITI QX56	Z62	2011.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Venezuela	INFINITI QX56	Z62	2011.8-	Air bag	√	√	√	√		
Venezuela	INFINITI QX56	Z62	2011.8-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Venezuela	INFINITI QX56	Z62	2011.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Venezuela	INFINITI QX56	Z62	2011.8-	Transmission	√	√	√	√		SP0270, SP0274
Venezuela	INFINITI QX56	Z62	2011.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Venezuela	INFINITI QX56	Z62	2011.8-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Venezuela	INFINITI QX56	Z62	2011.8-	Multi AV	√	√	√	√		SP0503
Venezuela	INFINITI QX56	Z62	2011.8-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Venezuela	INFINITI QX56	Z62	2011.8-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Venezuela	INFINITI QX56	Z62	2011.8-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Venezuela	INFINITI QX56	Z62	2011.8-	Auto back door	√	√	√	√		
Venezuela	INFINITI QX56	Z62	2011.8-	Occupant detection			√	√		SP0584
Venezuela	INFINITI QX56	Z62	2011.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Venezuela	INFINITI QX56	Z62	2011.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Venezuela	INFINITI QX56	Z62	2011.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Venezuela	INFINITI QX56	Z62	2011.8-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Venezuela	INFINITI QX56	Z62	2011.8-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Venezuela	INFINITI QX56	Z62	2011.8-	CAN gateway	√	√	√			
Venezuela	INFINITI QX56	Z62	2011.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Venezuela	INFINITI QX56	Z62	2011.8-	Side radar left	√	√	√	√	AC1025	SP0582
Venezuela	INFINITI QX56	Z62	2011.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Venezuela	INFINITI QX56	Z62	2011.8-	Side radar right	√	√	√	√	AC1026	SP0583
Vietnam	INFINITI FX37	S51	2013.4-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Vietnam	INFINITI FX37	S51	2013.4-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Vietnam	INFINITI FX37	S51	2013.4-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877	SP0494
Vietnam	INFINITI FX37	S51	2013.4-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Vietnam	INFINITI FX37	S51	2013.4-	Air bag	√	√	√	√		
Vietnam	INFINITI FX37	S51	2013.4-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0350
Vietnam	INFINITI FX37	S51	2013.4-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Vietnam	INFINITI FX37	S51	2013.4-	Transmission	√	√	√	√		SP0274
Vietnam	INFINITI FX37	S51	2013.4-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Vietnam	INFINITI FX37	S51	2013.4-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Vietnam	INFINITI FX37	S51	2013.4-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Vietnam	INFINITI FX37	S51	2013.4-	Multi AV	√	√	√	√		SP0503
Vietnam	INFINITI FX37	S51	2013.4-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Vietnam	INFINITI FX37	S51	2013.4-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Vietnam	INFINITI FX37	S51	2013.4-	Auto back door	√	√	√	√		SP0611
Vietnam	INFINITI FX37	S51	2013.4-	Occupant detection			√	√		SP0584
Vietnam	INFINITI FX37	S51	2013.4-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Vietnam	INFINITI FX37	S51	2013.4-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Vietnam	INFINITI FX37	S51	2013.4-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0556, SP0557
Vietnam	INFINITI FX37	S51	2013.4-	All mode AWD/4WD	√	√	√	√	AC0956	
Vietnam	INFINITI FX37	S51	2013.4-	Precrash seatbelt	√	√	√	√		SP0612
Vietnam	INFINITI FX37	S51	2013.4-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Vietnam	INFINITI FX37	S51	2013.4-	CAN gateway	√	√	√			

Vietnam	INFINITI FX37	S51	2013.4-	Lane camera	√	√	√	√	AC0973,AC0974,AC0975,AC0976,AC0977	SP0560
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Air bag	√	√	√	√		
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Transmission	√	√	√	√		SP0270, SP0274
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Multi AV	√	√	√	√		SP0503
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Vietnam	INFINITI G37 CONVERTIBLE	HV36	2011.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Vietnam	INFINITI JX35	L50	2013.1-	Laser/radar	√	√	√	√		
Vietnam	INFINITI JX35	L50	2013.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Vietnam	INFINITI JX35	L50	2013.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Vietnam	INFINITI JX35	L50	2013.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Vietnam	INFINITI JX35	L50	2013.1-	Air bag	√	√	√	√		
Vietnam	INFINITI JX35	L50	2013.1-	EPS/DAST 3	√	√	√	√		
Vietnam	INFINITI JX35	L50	2013.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Vietnam	INFINITI JX35	L50	2013.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Vietnam	INFINITI JX35	L50	2013.1-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Vietnam	INFINITI JX35	L50	2013.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Vietnam	INFINITI JX35	L50	2013.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Vietnam	INFINITI JX35	L50	2013.1-	Multi AV	√	√	√	√		SP0503
Vietnam	INFINITI JX35	L50	2013.1-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Vietnam	INFINITI JX35	L50	2013.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Vietnam	INFINITI JX35	L50	2013.1-	Auto back door	√	√	√	√		SP0611
Vietnam	INFINITI JX35	L50	2013.1-	Occupant detection			√	√		SP0584
Vietnam	INFINITI JX35	L50	2013.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Vietnam	INFINITI JX35	L50	2013.1-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Vietnam	INFINITI JX35	L50	2013.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Vietnam	INFINITI JX35	L50	2013.1-	Precrash seatbelt	√	√	√	√		SP0612
Vietnam	INFINITI JX35	L50	2013.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Vietnam	INFINITI JX35	L50	2013.1-	CAN gateway	√	√	√			
Vietnam	INFINITI JX35	L50	2013.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Vietnam	INFINITI JX35	L50	2013.1-	Side radar left	√	√	√	√	AC1025	SP0582
Vietnam	INFINITI JX35	L50	2013.1-	Side radar right	√	√	√	√	AC1026	SP0583
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Laser/radar	√	√	√	√		
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Air bag	√	√	√	√		
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	EPS/DAST 3	√	√	√	√		
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Motor control	√	√	√	√		
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Pop up hood	√	√	√	√		
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Multi AV	√	√	√	√		SP0503
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	HV battery	√	√	√	√	AC1121	
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Occupant detection			√	√		SP0584
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 2	√	√	√	√		
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	CAN gateway	√	√	√			
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	DAST 1	√	√	√	√		
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	ANC	√	√	√	√	AC1024	
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Brake	√	√	√	√	AC1127	
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Vietnam	INFINITI Q50 HYBRID	HV37	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Vietnam	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Vietnam	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Vietnam	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Vietnam	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		

Vietnam	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Vietnam	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588
Vietnam	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Vietnam	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Vietnam	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Vietnam	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Vietnam	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Vietnam	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Vietnam	INFINITI QX50	J55	2018.5-	Shift						
Vietnam	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Vietnam	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Vietnam	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Vietnam	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	DAST 2	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Vietnam	INFINITI QX50	J55	2018.5-	CAN gateway	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	Lane camera	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	ANC						
Vietnam	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Vietnam	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Vietnam	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Vietnam	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Vietnam	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Vietnam	INFINITI QX56	Z62	2013.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Vietnam	INFINITI QX56	Z62	2013.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Vietnam	INFINITI QX56	Z62	2013.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Vietnam	INFINITI QX56	Z62	2013.1-	Air bag	√	√	√	√		
Vietnam	INFINITI QX56	Z62	2013.1-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Vietnam	INFINITI QX56	Z62	2013.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Vietnam	INFINITI QX56	Z62	2013.1-	Transmission	√	√	√	√		SP0270, SP0274
Vietnam	INFINITI QX56	Z62	2013.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Vietnam	INFINITI QX56	Z62	2013.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Vietnam	INFINITI QX56	Z62	2013.1-	Multi AV	√	√	√	√		SP0503
Vietnam	INFINITI QX56	Z62	2013.1-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Vietnam	INFINITI QX56	Z62	2013.1-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Vietnam	INFINITI QX56	Z62	2013.1-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Vietnam	INFINITI QX56	Z62	2013.1-	Auto back door	√	√	√	√		
Vietnam	INFINITI QX56	Z62	2013.1-	Occupant detection			√	√		SP0584
Vietnam	INFINITI QX56	Z62	2013.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Vietnam	INFINITI QX56	Z62	2013.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Vietnam	INFINITI QX56	Z62	2013.1-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Vietnam	INFINITI QX56	Z62	2013.1-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Vietnam	INFINITI QX56	Z62	2013.1-	Precrash seatbelt	√	√	√	√		SP0612
Vietnam	INFINITI QX56	Z62	2013.1-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Vietnam	INFINITI QX56	Z62	2013.1-	CAN gateway	√	√	√			
Vietnam	INFINITI QX60	L50	2014.12-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Vietnam	INFINITI QX60	L50	2014.12-	Laser/radar	√	√	√	√	AC0994	
Vietnam	INFINITI QX60	L50	2014.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Vietnam	INFINITI QX60	L50	2014.12-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Vietnam	INFINITI QX60	L50	2014.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Vietnam	INFINITI QX60	L50	2014.12-	Air bag	√	√	√	√		
Vietnam	INFINITI QX60	L50	2014.12-	EPS/DAST 3	√	√	√	√		
Vietnam	INFINITI QX60	L50	2014.12-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Vietnam	INFINITI QX60	L50	2014.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Vietnam	INFINITI QX60	L50	2014.12-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Vietnam	INFINITI QX60	L50	2014.12-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Vietnam	INFINITI QX60	L50	2014.12-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Vietnam	INFINITI QX60	L50	2014.12-	Multi AV	√	√	√	√		SP0503
Vietnam	INFINITI QX60	L50	2014.12-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Vietnam	INFINITI QX60	L50	2014.12-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Vietnam	INFINITI QX60	L50	2014.12-	Auto back door	√	√	√	√		SP0611
Vietnam	INFINITI QX60	L50	2014.12-	Occupant detection			√	√		SP0584
Vietnam	INFINITI QX60	L50	2014.12-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Vietnam	INFINITI QX60	L50	2014.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Vietnam	INFINITI QX60	L50	2014.12-	All mode AWD/4WD	√	√	√	√	AC0956	
Vietnam	INFINITI QX60	L50	2014.12-	Precrash seatbelt	√	√	√	√		SP0612
Vietnam	INFINITI QX60	L50	2014.12-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Vietnam	INFINITI QX60	L50	2014.12-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Vietnam	INFINITI QX60	L50	2014.12-	CAN gateway	√	√	√			
Vietnam	INFINITI QX60	L50	2014.12-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Vietnam	INFINITI QX60	L50	2014.12-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Vietnam	INFINITI QX60	L50	2014.12-	ANC	√	√	√	√	AC1024	
Vietnam	INFINITI QX60	L50	2014.12-	Side radar left	√	√	√	√	AC1025	SP0582
Vietnam	INFINITI QX60	L50	2014.12-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Vietnam	INFINITI QX60	L50	2014.12-	Side radar right	√	√	√	√	AC1026	SP0583
Vietnam	INFINITI QX60	L50	2014.12-	3ch CAN GATEWAY	√	√	√	√		
Vietnam	INFINITI QX60	L50	2014.12-	ICC/ADAS 2	√	√	√	√		
Vietnam	INFINITI QX60	L50	2014.12-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Vietnam	INFINITI QX60	L50	2014.12-	A-IVC(Renault common)	√	√	√	√		
Vietnam	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Vietnam	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Vietnam	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Vietnam	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Vietnam	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Vietnam	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Vietnam	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Vietnam	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Vietnam	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Vietnam	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Vietnam	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Vietnam	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Vietnam	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Vietnam	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Vietnam	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Vietnam	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Vietnam	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Vietnam	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Vietnam	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Vietnam	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Vietnam	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Vietnam	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Vietnam	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Vietnam	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Vietnam	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Vietnam	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Vietnam	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Vietnam	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Vietnam	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Vietnam	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Vietnam	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Vietnam	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Vietnam	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Vietnam	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Vietnam	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Vietnam	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Vietnam	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Vietnam	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Vietnam	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Vietnam	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Vietnam	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Vietnam	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Vietnam	INFINITI QX80	Z62	2013.6-	Motor control	√	√	√	√		
Vietnam	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Vietnam	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0439, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0246, SP0270, SP0274, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Vietnam	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Vietnam	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Vietnam	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Vietnam	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Vietnam	INFINITI QX80	Z62	2013.6-	HV battery	√	√	√	√	AC1121	
Vietnam	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Vietnam	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Vietnam	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Vietnam	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Vietnam	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		SP0611
Vietnam	INFINITI QX80	Z62	2013.6-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Vietnam	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Vietnam	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Vietnam	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Vietnam	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Vietnam	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Vietnam	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Vietnam	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Vietnam	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Vietnam	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Vietnam	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Vietnam	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Vietnam	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Vietnam	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Vietnam	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Vietnam	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Vietnam	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Vietnam	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Vietnam	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Vietnam	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Vietnam	INFINITI QX80	Z62	2013.6-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
West sahara	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
West sahara	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
West sahara	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
West sahara	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
West sahara	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
West sahara	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
West sahara	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
West sahara	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
West sahara	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
West sahara	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
West sahara	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
West sahara	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612

West sahara	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
West sahara	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
West sahara	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
West sahara	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
West sahara	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
West sahara	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
West sahara	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
West sahara	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
West sahara	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
West sahara	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
West sahara	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
West sahara	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
West sahara	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
West sahara	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
West sahara	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
West sahara	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
West sahara	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
West sahara	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
West sahara	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
West sahara	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
West sahara	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
West sahara	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
West sahara	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
West sahara	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

XTOOL

West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
West sahara	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
West sahara	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
West sahara	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
West sahara	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
West sahara	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
West sahara	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
West sahara	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
West sahara	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
West sahara	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
West sahara	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
West sahara	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
West sahara	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
West sahara	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
West sahara	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
West sahara	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
West sahara	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
West sahara	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
West sahara	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
West sahara	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
West sahara	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
West sahara	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
West sahara	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
West sahara	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
West sahara	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
West sahara	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
West sahara	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
West sahara	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
West sahara	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
West sahara	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
West sahara	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
West sahara	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
West sahara	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
West sahara	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
West sahara	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
West sahara	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
West sahara	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
West sahara	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
West sahara	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
West sahara	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
West sahara	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
West sahara	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
West sahara	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
West sahara	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308

West sahara	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
West sahara	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
West sahara	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
West sahara	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
West sahara	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
West sahara	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
West sahara	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
West sahara	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
West sahara	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
West sahara	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
West sahara	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
West sahara	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
West sahara	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
West sahara	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
West sahara	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
West sahara	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
West sahara	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
West sahara	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
West sahara	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
West sahara	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
West sahara	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
West sahara	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
West sahara	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
West sahara	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
West sahara	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
West sahara	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
West sahara	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
West sahara	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
West sahara	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
West sahara	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
West sahara	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
West sahara	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
West sahara	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
West sahara	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
West sahara	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
West sahara	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
West sahara	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
West sahara	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
West sahara	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
West sahara	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			

XTOOL

West sahara	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
West sahara	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
West sahara	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
West sahara	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
West sahara	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
West sahara	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
West sahara	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
West sahara	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
West sahara	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
West sahara	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
West sahara	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
West sahara	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
West sahara	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
West sahara	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
West sahara	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
West sahara	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
West sahara	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
West sahara	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
West sahara	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
West sahara	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

West sahara	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
West sahara	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
West sahara	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
West sahara	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
West sahara	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
West sahara	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
West sahara	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
West sahara	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
West sahara	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
West sahara	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
West sahara	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
West sahara	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
West sahara	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
West sahara	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
West sahara	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
West sahara	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
West sahara	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
West sahara	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
West sahara	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
West sahara	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
West sahara	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
West sahara	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
West sahara	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
West sahara	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
West sahara	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
West sahara	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
West sahara	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
West sahara	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
West sahara	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
West sahara	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507

XTOOL

West sahara	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
West sahara	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
West sahara	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
West sahara	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
West sahara	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
West sahara	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
West sahara	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
West sahara	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
West sahara	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
West sahara	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
West sahara	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
West sahara	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
West sahara	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
West sahara	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
West sahara	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
West sahara	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
West sahara	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
West sahara	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
West sahara	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
West sahara	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
West sahara	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
West sahara	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
West sahara	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
West sahara	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
West sahara	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
West sahara	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
West sahara	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
West sahara	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
West sahara	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
West sahara	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
West sahara	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
West sahara	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
West sahara	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
West sahara	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
West sahara	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

West sahara	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
West sahara	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
West sahara	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
West sahara	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
West sahara	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
West sahara	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
West sahara	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
West sahara	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
West sahara	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
West sahara	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
West sahara	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
West sahara	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
West sahara	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
West sahara	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
West sahara	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
West sahara	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
West sahara	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
West sahara	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
West sahara	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
West sahara	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
West sahara	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
West sahara	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
West sahara	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
West sahara	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
West sahara	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
West sahara	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
West sahara	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
West sahara	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
West sahara	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
West sahara	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
West sahara	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
West sahara	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
West sahara	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
West sahara	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
West sahara	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
West sahara	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
West sahara	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
West sahara	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
West sahara	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
West sahara	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
West sahara	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
West sahara	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
West sahara	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
West sahara	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
West sahara	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
West sahara	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
West sahara	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
West sahara	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
West sahara	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
West sahara	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
West sahara	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
West sahara	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
West sahara	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

West sahara	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
West sahara	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
West sahara	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
West sahara	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
West sahara	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
West sahara	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
West sahara	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
West sahara	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
West sahara	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
West sahara	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
West sahara	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
West sahara	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
West sahara	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
West sahara	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
West sahara	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
West sahara	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
West sahara	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
West sahara	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
West sahara	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
West sahara	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
West sahara	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
West sahara	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
West sahara	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
West sahara	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
West sahara	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
West sahara	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
West sahara	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Yemen	INFINITI EX35	J50	2008.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI EX35	J50	2008.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Yemen	INFINITI EX35	J50	2008.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI EX35	J50	2008.1-	Air bag	√	√	√	√		
Yemen	INFINITI EX35	J50	2008.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Yemen	INFINITI EX35	J50	2008.1-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Yemen	INFINITI EX35	J50	2008.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Yemen	INFINITI EX35	J50	2008.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Yemen	INFINITI EX35	J50	2008.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI EX35	J50	2008.1-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI EX35	J50	2008.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI EX35	J50	2008.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Yemen	INFINITI EX35	J50	2008.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI EX35	J50	2008.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Yemen	INFINITI EX35	J50	2008.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Yemen	INFINITI EX35	J50	2008.1-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI EX35	J50	2008.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Yemen	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Yemen	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Yemen	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Yemen	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Yemen	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Yemen	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Yemen	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Yemen	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Yemen	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Yemen	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Yemen	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI FX35/FX45	S50	2005.3-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Yemen	INFINITI FX35/FX45	S50	2005.3-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Yemen	INFINITI FX35/FX45	S50	2005.3-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Yemen	INFINITI FX35/FX45	S50	2005.3-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Yemen	INFINITI FX35/FX45	S50	2005.3-	Air bag	√	√	√	√		
Yemen	INFINITI FX35/FX45	S50	2005.3-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Yemen	INFINITI FX35/FX45	S50	2005.3-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Yemen	INFINITI FX35/FX45	S50	2005.3-	Motor control						

Yemen	INFINITI FX35/FX45	S50	2005.3-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI FX35/FX45	S50	2005.3-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Yemen	INFINITI FX35/FX45	S50	2005.3-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Yemen	INFINITI FX35/FX45	S50	2005.3-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI FX35/FX45	S50	2005.3-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI FX35/FX45	S50	2005.3-	HVAC	√	√	√	√		
Yemen	INFINITI FX35/FX45	S50	2005.3-	Difference lock	√	√	√	√		
Yemen	INFINITI FX35/FX45	S50	2005.3-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI FX35/FX45	S50	2005.3-	Auto slide door	√	√	√	√	AC0941	
Yemen	INFINITI FX35/FX45	S50	2005.3-	DIU		√	√	√		
Yemen	INFINITI FX35/FX45	S50	2005.3-	Adaptive light	√	√	√	√		
Yemen	INFINITI FX35/FX45	S50	2005.3-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI FX35/FX45	S50	2005.3-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Yemen	INFINITI FX35/FX45	S50	2005.3-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI FX35/FX45	S50	2005.3-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Yemen	INFINITI FX35/FX45	S50	2005.3-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Yemen	INFINITI FX35/FX45	S50	2005.3-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI FX35/FX45	S50	2005.3-	IVMS	√	√		√		
Yemen	INFINITI FX35/FX45	S50	2005.3-	Distance control	√	√		√		
Yemen	INFINITI FX35/FX45	S50	2005.3-	Active suspense system	√	√	√	√		
Yemen	INFINITI FX35/FX45	S50	2005.3-	Motor assist		√	√	√		SP0574
Yemen	INFINITI FX35/FX45	S50	2005.3-	ASCD	√	√	√	√		
Yemen	INFINITI FX35/FX45	S50	2005.3-	Active engine mount	√	√	√	√		
Yemen	INFINITI FX35/FX45	S50	2005.3-	TCS	√	√	√	√		
Yemen	INFINITI FX35/FX45	S50	2005.3-	S/blind camera	√			√		SP0572, SP0573
Yemen	INFINITI FX35/FX45	S50	2005.3-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Yemen	INFINITI FX35/FX45	S50	2005.3-	Nats immu	√	√	√			
Yemen	INFINITI FX35/FX45	S50	2005.3-	Rearview camera	√			√		SP0570, SP0571
Yemen	INFINITI FX35/FX45	S50	2005.3-	Smart entrance						SP0568
Yemen	INFINITI FX35/FX50	S51	2008.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Yemen	INFINITI FX35/FX50	S51	2008.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI FX35/FX50	S51	2008.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Yemen	INFINITI FX35/FX50	S51	2008.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI FX35/FX50	S51	2008.5-	Air bag	√	√	√	√		
Yemen	INFINITI FX35/FX50	S51	2008.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Yemen	INFINITI FX35/FX50	S51	2008.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Yemen	INFINITI FX35/FX50	S51	2008.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Yemen	INFINITI FX35/FX50	S51	2008.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Yemen	INFINITI FX35/FX50	S51	2008.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Yemen	INFINITI FX35/FX50	S51	2008.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Yemen	INFINITI FX35/FX50	S51	2008.5-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI FX35/FX50	S51	2008.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Yemen	INFINITI FX35/FX50	S51	2008.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI FX35/FX50	S51	2008.5-	Auto back door	√	√	√	√		SP0611
Yemen	INFINITI FX35/FX50	S51	2008.5-	Occupant detection			√	√		SP0584
Yemen	INFINITI FX35/FX50	S51	2008.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Yemen	INFINITI FX35/FX50	S51	2008.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI FX35/FX50	S51	2008.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Yemen	INFINITI FX35/FX50	S51	2008.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Yemen	INFINITI FX35/FX50	S51	2008.5-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI FX35/FX50	S51	2008.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI FX35/FX50	S51	2008.5-	CAN gateway	√	√	√			
Yemen	INFINITI FX35/FX50	S51	2008.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Yemen	INFINITI FX35/FX50	S51	2008.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI FX35/FX50	S51	2008.5-	Rearview camera	√			√		SP0570, SP0571
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	Air bag	√	√	√	√		
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	Transmission	√	√	√	√		SP0270, SP0274
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	Precrash seatbelt	√	√	√	√		
Yemen	INFINITI G25/G37 SEDAN	V36	2010.12-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Yemen	INFINITI G35 COUPE	CV35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Yemen	INFINITI G35 COUPE	CV35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Air bag	√	√	√	√		
Yemen	INFINITI G35 COUPE	CV35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Motor control						

Yemen	INFINITI G35 COUPE	CV35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Yemen	INFINITI G35 COUPE	CV35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Yemen	INFINITI G35 COUPE	CV35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI G35 COUPE	CV35	2005.1-	HVAC	√	√	√	√		
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Difference lock	√	√	√	√		
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Yemen	INFINITI G35 COUPE	CV35	2005.1-	DIU		√	√	√		
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Adaptive light	√	√	√	√		
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI G35 COUPE	CV35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Yemen	INFINITI G35 COUPE	CV35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Yemen	INFINITI G35 COUPE	CV35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI G35 COUPE	CV35	2005.1-	IVMS	√	√		√		
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Distance control	√	√		√		
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Active suspense system	√	√	√	√		
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Motor assist		√	√	√		SP0574
Yemen	INFINITI G35 COUPE	CV35	2005.1-	ASCD	√	√	√	√		
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Active engine mount	√	√	√	√		
Yemen	INFINITI G35 COUPE	CV35	2005.1-	TCS	√	√	√	√		
Yemen	INFINITI G35 COUPE	CV35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Nats immu	√	√	√			
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Yemen	INFINITI G35 COUPE	CV35	2005.1-	Smart entrance						SP0568
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Yemen	INFINITI G35 SEDAN	V35	2005.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Yemen	INFINITI G35 SEDAN	V35	2005.1-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Air bag	√	√	√	√		
Yemen	INFINITI G35 SEDAN	V35	2005.1-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Motor control						
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Yemen	INFINITI G35 SEDAN	V35	2005.1-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Yemen	INFINITI G35 SEDAN	V35	2005.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI G35 SEDAN	V35	2005.1-	HVAC	√	√	√	√		
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Difference lock	√	√	√	√		
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Auto slide door	√	√	√	√	AC0941	
Yemen	INFINITI G35 SEDAN	V35	2005.1-	DIU		√	√	√		
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Adaptive light	√	√	√	√		
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI G35 SEDAN	V35	2005.1-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Yemen	INFINITI G35 SEDAN	V35	2005.1-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Yemen	INFINITI G35 SEDAN	V35	2005.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI G35 SEDAN	V35	2005.1-	IVMS	√	√		√		
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Distance control	√	√		√		
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Active suspense system	√	√	√	√		
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Motor assist		√	√	√		SP0574
Yemen	INFINITI G35 SEDAN	V35	2005.1-	ASCD	√	√	√	√		
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Active engine mount	√	√	√	√		
Yemen	INFINITI G35 SEDAN	V35	2005.1-	TCS	√	√	√	√		
Yemen	INFINITI G35 SEDAN	V35	2005.1-	S/blind camera	√			√		SP0572, SP0573
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Nats immu	√	√	√			
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Rearview camera	√			√		SP0570, SP0571
Yemen	INFINITI G35 SEDAN	V35	2005.1-	Smart entrance						SP0568
Yemen	INFINITI G35 SEDAN	V36	2006.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI G35 SEDAN	V36	2006.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI G35 SEDAN	V36	2006.8-	Air bag	√	√	√	√		
Yemen	INFINITI G35 SEDAN	V36	2006.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Yemen	INFINITI G35 SEDAN	V36	2006.8-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Yemen	INFINITI G35 SEDAN	V36	2006.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270
Yemen	INFINITI G35 SEDAN	V36	2006.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Yemen	INFINITI G35 SEDAN	V36	2006.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI G35 SEDAN	V36	2006.8-	Multi AV	√	√	√	√		
Yemen	INFINITI G35 SEDAN	V36	2006.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI G35 SEDAN	V36	2006.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Yemen	INFINITI G35 SEDAN	V36	2006.8-	All mode AWD/4WD	√	√	√	√	AC0957	
Yemen	INFINITI G35 SEDAN	V36	2006.8-	Rearview camera	√			√		SP0570, SP0571
Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Air bag	√	√	√	√		
Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0200, SP0202, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Yemen	INFINITI G37 CONVERTIBLE	HV36	2010.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI G37 COUPE	CV36	2007.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI G37 COUPE	CV36	2007.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Yemen	INFINITI G37 COUPE	CV36	2007.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI G37 COUPE	CV36	2007.11-	Air bag	√	√	√	√		
Yemen	INFINITI G37 COUPE	CV36	2007.11-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Yemen	INFINITI G37 COUPE	CV36	2007.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI G37 COUPE	CV36	2007.11-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Yemen	INFINITI G37 COUPE	CV36	2007.11-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Yemen	INFINITI G37 COUPE	CV36	2007.11-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI G37 COUPE	CV36	2007.11-	Pop up hood	√	√	√	√		
Yemen	INFINITI G37 COUPE	CV36	2007.11-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI G37 COUPE	CV36	2007.11-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Yemen	INFINITI G37 COUPE	CV36	2007.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI G37 COUPE	CV36	2007.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Yemen	INFINITI G37 COUPE	CV36	2007.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Yemen	INFINITI G37 COUPE	CV36	2007.11-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Yemen	INFINITI G37 COUPE	CV36	2007.11-	Precrash seatbelt	√	√	√	√		
Yemen	INFINITI G37 COUPE	CV36	2007.11-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI G37 SEDAN	V36	2008.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI G37 SEDAN	V36	2008.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI G37 SEDAN	V36	2008.10-	Air bag	√	√	√	√		
Yemen	INFINITI G37 SEDAN	V36	2008.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Yemen	INFINITI G37 SEDAN	V36	2008.10-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Yemen	INFINITI G37 SEDAN	V36	2008.10-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Yemen	INFINITI G37 SEDAN	V36	2008.10-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Yemen	INFINITI G37 SEDAN	V36	2008.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI G37 SEDAN	V36	2008.10-	Multi AV	√	√	√	√		
Yemen	INFINITI G37 SEDAN	V36	2008.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Yemen	INFINITI G37 SEDAN	V36	2008.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI G37 SEDAN	V36	2008.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Yemen	INFINITI G37 SEDAN	V36	2008.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Yemen	INFINITI G37 SEDAN	V36	2008.10-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Yemen	INFINITI G37 SEDAN	V36	2008.10-	Precrash seatbelt	√	√	√	√		
Yemen	INFINITI G37 SEDAN	V36	2008.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI JX35	L50	2012.5-	Laser/radar	√	√	√	√		
Yemen	INFINITI JX35	L50	2012.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI JX35	L50	2012.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Yemen	INFINITI JX35	L50	2012.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI JX35	L50	2012.5-	Air bag	√	√	√	√		
Yemen	INFINITI JX35	L50	2012.5-	EPS/DAST 3	√	√	√	√		
Yemen	INFINITI JX35	L50	2012.5-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Yemen	INFINITI JX35	L50	2012.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI JX35	L50	2012.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0276, SP0278, SP0279
Yemen	INFINITI JX35	L50	2012.5-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Yemen	INFINITI JX35	L50	2012.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Yemen	INFINITI JX35	L50	2012.5-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI JX35	L50	2012.5-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Yemen	INFINITI JX35	L50	2012.5-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI JX35	L50	2012.5-	Auto back door	√	√	√	√		SP0611
Yemen	INFINITI JX35	L50	2012.5-	Occupant detection			√	√		SP0584
Yemen	INFINITI JX35	L50	2012.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI JX35	L50	2012.5-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Yemen	INFINITI JX35	L50	2012.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Yemen	INFINITI JX35	L50	2012.5-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI JX35	L50	2012.5-	CAN gateway	√	√	√			
Yemen	INFINITI JX35	L50	2012.5-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Yemen	INFINITI JX35	L50	2012.5-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI JX35	L50	2012.5-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI M35/M45	Y50	2006.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Yemen	INFINITI M35/M45	Y50	2006.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0884	SP0494
Yemen	INFINITI M35/M45	Y50	2006.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831, AC0856	
Yemen	INFINITI M35/M45	Y50	2006.7-	Air bag	√	√	√	√		
Yemen	INFINITI M35/M45	Y50	2006.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349
Yemen	INFINITI M35/M45	Y50	2006.7-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0051, AC0052, AC0053, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0016, SP0032, SP0033, SP0053, SP0063, SP0064, SP0074, SP0079, SP0085, SP0086, SP0087, SP0104, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Yemen	INFINITI M35/M45	Y50	2006.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Yemen	INFINITI M35/M45	Y50	2006.7-	BCM					AC0653, AC0698	SP0391, SP0393
Yemen	INFINITI M35/M45	Y50	2006.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI M35/M45	Y50	2006.7-	Multi AV	√	√	√	√		
Yemen	INFINITI M35/M45	Y50	2006.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI M35/M45	Y50	2006.7-	Adaptive light	√	√	√	√		SP0561, SP0562

Yemen	INFINITI M35/M45	Y50	2006.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0556
Yemen	INFINITI M35/M45	Y50	2006.7-	All mode AWD/4WD	√	√	√	√	AC0957	
Yemen	INFINITI M35/M45	Y50	2006.7-	Precrash seatbelt	√	√	√	√		
Yemen	INFINITI M35/M45	Y50	2006.7-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0922, AC0923, AC0924, AC0925, AC0926, AC0928	SP0511, SP0512, SP0518, SP0520, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0529, SP0530, SP0531, SP0532, SP0534, SP0535, SP0536, SP0537
Yemen	INFINITI M35/M45	Y50	2006.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI M35/M45	Y50	2006.7-	Rearview camera	√			√		SP0570, SP0571
Yemen	INFINITI M37/M56	Y51	2010.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Yemen	INFINITI M37/M56	Y51	2010.8-	Laser/radar	√	√	√	√		
Yemen	INFINITI M37/M56	Y51	2010.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI M37/M56	Y51	2010.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Yemen	INFINITI M37/M56	Y51	2010.8-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Yemen	INFINITI M37/M56	Y51	2010.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI M37/M56	Y51	2010.8-	Air bag	√	√	√	√		
Yemen	INFINITI M37/M56	Y51	2010.8-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Yemen	INFINITI M37/M56	Y51	2010.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI M37/M56	Y51	2010.8-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Yemen	INFINITI M37/M56	Y51	2010.8-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Yemen	INFINITI M37/M56	Y51	2010.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI M37/M56	Y51	2010.8-	Pop up hood	√	√	√	√		
Yemen	INFINITI M37/M56	Y51	2010.8-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI M37/M56	Y51	2010.8-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Yemen	INFINITI M37/M56	Y51	2010.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Yemen	INFINITI M37/M56	Y51	2010.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Yemen	INFINITI M37/M56	Y51	2010.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI M37/M56	Y51	2010.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Yemen	INFINITI M37/M56	Y51	2010.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI M37/M56	Y51	2010.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Yemen	INFINITI M37/M56	Y51	2010.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Yemen	INFINITI M37/M56	Y51	2010.8-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI M37/M56	Y51	2010.8-	CAN gateway	√	√	√			
Yemen	INFINITI M37/M56	Y51	2010.8-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Yemen	INFINITI M37/M56	Y51	2010.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI M37/M56	Y51	2010.8-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI M37/M56	Y51	2010.8-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Yemen	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Yemen	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Yemen	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Yemen	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Yemen	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Yemen	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Yemen	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Yemen	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Yemen	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Yemen	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Yemen	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Yemen	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Yemen	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Yemen	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Yemen	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Yemen	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Yemen	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Yemen	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Yemen	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Yemen	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Yemen	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Yemen	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Air pressure monitor	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Air bag	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	EPS/DAST 3	√	√	√			
Yemen	INFINITI Q30/QX30	H15	2016.10-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Yemen	INFINITI Q30/QX30	H15	2016.10-	Engine	√	√	√	√	AC0002, AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0103, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0214, AC0225, AC0226, AC0229, AC0256, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0035, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI Q30/QX30	H15	2016.10-	EHS/PKB	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Transmission	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Yemen	INFINITI Q30/QX30	H15	2016.10-	ABS	√	√	√	√		SP0308
Yemen	INFINITI Q30/QX30	H15	2016.10-	Multi AV	√	√	√	√		SP0501
Yemen	INFINITI Q30/QX30	H15	2016.10-	HVAC	√	√	√	√		

Yemen	INFINITI Q30/QX30	H15	2016.10-	Auto drive position	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Shift	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	All mode AWD/4WD	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	AVM	√	√		√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Intelligent key	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	CAN gateway	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	ANC	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Telematics	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	FSCM	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Siren control unit	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Yemen	INFINITI Q30/QX30	H15	2016.10-	Overhead Control Panel Unit	√			√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Universal Garage Door Opener	√			√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Upper control panel cont unit	√					
Yemen	INFINITI Q30/QX30	H15	2016.10-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Yemen	INFINITI Q30/QX30	H15	2016.10-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Yemen	INFINITI Q30/QX30	H15	2016.10-	Light/Rain Sensor Module	√			√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	EC Mirror Compass	√					
Yemen	INFINITI Q30/QX30	H15	2016.10-	Intelligent Battery Sensor	√					
Yemen	INFINITI Q30/QX30	H15	2016.10-	Alarm siren	√			√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Radar sensor	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Steering column cont module	√	√	√			
Yemen	INFINITI Q30/QX30	H15	2016.10-	ICC sensor	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Trailer recognition control unit	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	H/L control module LH	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Powertrain cont module	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Side radar LH	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module LH	√			√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Steering Wheel Switch Pad	√			√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Parking assist	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Occupant Classification Unit	√			√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Electronic Ignition Switch cont unit	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	H/L control module RH	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Front camera unit	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	Side radar RH	√	√	√	√		
Yemen	INFINITI Q30/QX30	H15	2016.10-	LED H/L control module RH	√			√		
Yemen	INFINITI Q45	F50	2001.8-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Yemen	INFINITI Q45	F50	2001.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Yemen	INFINITI Q45	F50	2001.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Yemen	INFINITI Q45	F50	2001.8-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Yemen	INFINITI Q45	F50	2001.8-	Air bag	√	√	√	√		
Yemen	INFINITI Q45	F50	2001.8-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Yemen	INFINITI Q45	F50	2001.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Yemen	INFINITI Q45	F50	2001.8-	Motor control						
Yemen	INFINITI Q45	F50	2001.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI Q45	F50	2001.8-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Yemen	INFINITI Q45	F50	2001.8-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Yemen	INFINITI Q45	F50	2001.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI Q45	F50	2001.8-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI Q45	F50	2001.8-	HVAC	√	√	√	√		
Yemen	INFINITI Q45	F50	2001.8-	Difference lock	√	√	√	√		
Yemen	INFINITI Q45	F50	2001.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI Q45	F50	2001.8-	Auto slide door	√	√	√	√	AC0941	
Yemen	INFINITI Q45	F50	2001.8-	DIU		√	√	√		
Yemen	INFINITI Q45	F50	2001.8-	Adaptive light	√	√	√	√		
Yemen	INFINITI Q45	F50	2001.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI Q45	F50	2001.8-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Yemen	INFINITI Q45	F50	2001.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI Q45	F50	2001.8-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Yemen	INFINITI Q45	F50	2001.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Yemen	INFINITI Q45	F50	2001.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI Q45	F50	2001.8-	IVMS	√	√		√		
Yemen	INFINITI Q45	F50	2001.8-	Distance control	√	√		√		
Yemen	INFINITI Q45	F50	2001.8-	Active suspense system	√	√	√	√		
Yemen	INFINITI Q45	F50	2001.8-	Motor assist		√	√	√		SP0574
Yemen	INFINITI Q45	F50	2001.8-	ASCD	√	√	√	√		
Yemen	INFINITI Q45	F50	2001.8-	Active engine mount	√	√	√	√		
Yemen	INFINITI Q45	F50	2001.8-	TCS	√	√	√	√		
Yemen	INFINITI Q45	F50	2001.8-	S/blind camera	√			√		SP0572, SP0573
Yemen	INFINITI Q45	F50	2001.8-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Yemen	INFINITI Q45	F50	2001.8-	Nats immu	√	√	√			
Yemen	INFINITI Q45	F50	2001.8-	Rearview camera	√			√		SP0570, SP0571
Yemen	INFINITI Q45	F50	2001.8-	Smart entrance						SP0568
Yemen	INFINITI Q50	V37	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Yemen	INFINITI Q50	V37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Yemen	INFINITI Q50	V37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI Q50	V37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Yemen	INFINITI Q50	V37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI Q50	V37	2013.9-	Air bag	√	√	√	√		
Yemen	INFINITI Q50	V37	2013.9-	EPS/DAST 3	√	√	√	√		
Yemen	INFINITI Q50	V37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Yemen	INFINITI Q50	V37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI Q50	V37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Yemen	INFINITI Q50	V37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Yemen	INFINITI Q50	V37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Yemen	INFINITI Q50	V37	2013.9-	Pop up hood	√	√	√	√		
Yemen	INFINITI Q50	V37	2013.9-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI Q50	V37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Yemen	INFINITI Q50	V37	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Yemen	INFINITI Q50	V37	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Yemen	INFINITI Q50	V37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

Yemen	INFINITI Q50	V37	2013.9-	Occupant detection			√	√		SP0584
Yemen	INFINITI Q50	V37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Yemen	INFINITI Q50	V37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI Q50	V37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI Q50	V37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Yemen	INFINITI Q50	V37	2013.9-	DAST 2	√	√	√	√		
Yemen	INFINITI Q50	V37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI Q50	V37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI Q50	V37	2013.9-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Yemen	INFINITI Q50	V37	2013.9-	CAN gateway	√	√	√			
Yemen	INFINITI Q50	V37	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Yemen	INFINITI Q50	V37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI Q50	V37	2013.9-	DAST 1	√	√	√	√		
Yemen	INFINITI Q50	V37	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Yemen	INFINITI Q50	V37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Yemen	INFINITI Q50	V37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Yemen	INFINITI Q50	V37	2013.9-	ANC	√	√	√	√	AC1024	
Yemen	INFINITI Q50	V37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI Q50	V37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Yemen	INFINITI Q50	V37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Yemen	INFINITI Q50	V37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Yemen	INFINITI Q50	V37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI Q50	V37	2013.9-	CAN monitor unit	√	√	√	√		
Yemen	INFINITI Q50	V37	2013.9-	HDmap	√	√	√	√		
Yemen	INFINITI Q50	V37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Yemen	INFINITI Q50	V37	2013.9-	3ch CAN GATEWAY	√	√	√	√		
Yemen	INFINITI Q50	V37	2013.9-	ICC/ADAS 2	√	√	√	√		
Yemen	INFINITI Q50	V37	2013.9-	PMAS	√	√	√	√		
Yemen	INFINITI Q50	V37	2013.9-	FSCM	√	√	√	√	AC1109	
Yemen	INFINITI Q50	V37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Laser/radar	√	√	√	√	AC0994	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Air bag	√	√	√	√		
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	EPS/DAST 3	√	√	√	√		SP0507
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Motor control	√	√	√	√		
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0311, AC0314, AC0315, AC0320, AC0325, AC0327, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Transmission	√	√	√	√		SP0247, SP0265, SP0274, SP0276
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Pop up hood	√	√	√	√		
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	HV battery	√	√	√	√	AC1121	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Occupant detection			√	√		SP0584
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 2	√	√	√	√		
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	CAN gateway	√	√	√			
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	DAST 1	√	√	√	√		
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	ANC	√	√	√	√	AC1024	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	HIGH BEAM ASSIST	√	√	√	√		
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Brake	√	√	√	√	AC1127	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	FSCM	√	√	√	√	AC1109	
Yemen	INFINITI Q50 HYBRID	HV37	2013.9-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Laser/radar	√	√	√	√		
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Air bag	√	√	√	√		
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	EPS/DAST 3	√	√	√	√		
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Motor control	√	√	√	√		
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Engine	√	√	√	√	AC0004, AC0035, AC0036, AC0037, AC0052, AC0053, AC0062, AC0066, AC0067, AC0068, AC0148, AC0149, AC0150, AC0156, AC0164, AC0166, AC0168, AC0173, AC0174, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0009, SP0016, SP0032, SP0033, SP0038, SP0039, SP0053, SP0063, SP0064, SP0074, SP0079, SP0082, SP0085, SP0086, SP0087, SP0103, SP0104, SP0109, SP0110, SP0111, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0239
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Transmission	√	√	√	√		SP0276
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Pop up hood	√	√	√	√		
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	HV battery	√	√	√	√	AC1121	
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Occupant detection			√	√		SP0584
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 2	√	√	√	√		
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	DAST 1	√	√	√	√		
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	ANC	√	√	√	√	AC1024	
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	HIGH BEAM ASSIST	√	√	√	√		

Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	CAN monitor unit	√	√	√	√		
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	VSP	√	√	√	√		
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	Brake	√	√	√	√	AC1127	
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	HDmap	√	√	√	√		
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	6ch CAN GATEWAY	√	√	√	√		
Yemen	INFINITI Q50 Hybrid	HV37	2018.11-	ICC/ADAS 2	√	√	√	√		
Yemen	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Yemen	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Yemen	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Yemen	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Yemen	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Yemen	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Yemen	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Yemen	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Yemen	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Yemen	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Yemen	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Yemen	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Yemen	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Yemen	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Yemen	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Yemen	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Yemen	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI Q60	CV37	2016.10-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Yemen	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Yemen	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Yemen	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Yemen	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Yemen	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Yemen	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Yemen	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Yemen	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Yemen	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Yemen	INFINITI Q60	CV37	2016.10-	6ch CAN GATEWAY	√	√	√	√		
Yemen	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Yemen	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Air bag	√	√	√	√		
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Transmission	√	√	√	√		SP0274
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Pop up hood	√	√	√	√		
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	Precrash seatbelt	√	√	√	√		
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI Q60 CONVERTIBLE	HV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	Laser/radar	√	√	√	√	AC0994	
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	Air bag	√	√	√	√		
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	Transmission	√	√	√	√		SP0274
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429

Yemen	INFINITI Q60 COUPE	CV36	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	Pop up hood	√	√	√	√		
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	Precrash seatbelt	√	√	√	√		
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI Q60 COUPE	CV36	2013.8-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Yemen	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√	AC0994	
Yemen	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Yemen	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Yemen	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Yemen	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Yemen	INFINITI Q70	Y51	2013.9-	Motor control	√	√	√	√		
Yemen	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Yemen	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0247, SP0265, SP0270, SP0274, SP0276
Yemen	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Yemen	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Yemen	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Yemen	INFINITI Q70	Y51	2013.9-	HV battery	√	√	√	√	AC1121	
Yemen	INFINITI Q70	Y51	2013.9-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Yemen	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Yemen	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI Q70	Y51	2013.9-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Yemen	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Yemen	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Yemen	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Yemen	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Yemen	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Yemen	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI Q70	Y51	2013.9-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Yemen	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Yemen	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI Q70	Y51	2013.9-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Yemen	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Yemen	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI Q70	Y51	2013.9-	VSP	√	√	√	√		
Yemen	INFINITI Q70	Y51	2013.9-	Brake	√	√	√	√	AC1127	
Yemen	INFINITI Q70	Y51	2013.9-	6ch CAN GATEWAY	√	√	√	√		
Yemen	INFINITI Q70	Y51	2013.9-	ICC/ADAS 2	√	√	√	√		
Yemen	INFINITI Q70	Y51	2013.9-	FSCM	√	√	√	√	AC1109	
Yemen	INFINITI QX50	J50	2013.6-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Yemen	INFINITI QX50	J50	2013.6-	Laser/radar	√	√	√	√	AC0994	
Yemen	INFINITI QX50	J50	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI QX50	J50	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Yemen	INFINITI QX50	J50	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI QX50	J50	2013.6-	Air bag	√	√	√	√		
Yemen	INFINITI QX50	J50	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Yemen	INFINITI QX50	J50	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Yemen	INFINITI QX50	J50	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Yemen	INFINITI QX50	J50	2013.6-	Transmission	√	√	√	√		SP0274
Yemen	INFINITI QX50	J50	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Yemen	INFINITI QX50	J50	2013.6-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI QX50	J50	2013.6-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI QX50	J50	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI QX50	J50	2013.6-	Occupant detection			√	√		SP0584
Yemen	INFINITI QX50	J50	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Yemen	INFINITI QX50	J50	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI QX50	J50	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI QX50	J50	2013.6-	All mode AWD/4WD	√	√	√	√	AC0956	
Yemen	INFINITI QX50	J50	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI QX50	J50	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI QX50	J50	2013.6-	CAN gateway	√	√	√	√		
Yemen	INFINITI QX50	J50	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Yemen	INFINITI QX50	J50	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Yemen	INFINITI QX50	J50	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI QX50	J50	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Yemen	INFINITI QX50	J50	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI QX50	J55	2018.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0898, AC0900, AC0901, AC0902	SP0508, SP0510
Yemen	INFINITI QX50	J55	2018.5-	Laser/radar	√	√	√	√		
Yemen	INFINITI QX50	J55	2018.5-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Yemen	INFINITI QX50	J55	2018.5-	IPDM E/R	√	√	√	√	AC0833, AC0834, AC0835, AC0836, AC0837, AC0838, AC0839, AC0840, AC0841, AC0842, AC0843, AC0844, AC0845, AC0846, AC0847	
Yemen	INFINITI QX50	J55	2018.5-	Air bag	√	√	√	√		
Yemen	INFINITI QX50	J55	2018.5-	EPS/DAST 3	√	√	√	√		
Yemen	INFINITI QX50	J55	2018.5-	Meter/M&A	√	√	√	√		
Yemen	INFINITI QX50	J55	2018.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI QX50	J55	2018.5-	EHS/PKB	√	√	√	√		SP0588

Yemen	INFINITI QX50	J55	2018.5-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Yemen	INFINITI QX50	J55	2018.5-	BCM					AC0618, AC0690, AC0692	SP0390, SP0438, SP0450, SP0458
Yemen	INFINITI QX50	J55	2018.5-	ABS	√	√	√	√		SP0313, SP0315
Yemen	INFINITI QX50	J55	2018.5-	Total illum C/U	√	√	√	√		
Yemen	INFINITI QX50	J55	2018.5-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI QX50	J55	2018.5-	HVAC	√	√	√	√		
Yemen	INFINITI QX50	J55	2018.5-	Auto drive position	√	√	√	√		
Yemen	INFINITI QX50	J55	2018.5-	Auto back door	√	√	√	√		SP0611
Yemen	INFINITI QX50	J55	2018.5-	Occupant detection			√	√		SP0584
Yemen	INFINITI QX50	J55	2018.5-	Shift						
Yemen	INFINITI QX50	J55	2018.5-	Adaptive light	√	√	√	√		SP0562
Yemen	INFINITI QX50	J55	2018.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI QX50	J55	2018.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI QX50	J55	2018.5-	All mode AWD/4WD	√	√	√	√		
Yemen	INFINITI QX50	I55	2018.5-	DAST 2	√	√	√	√		
Yemen	INFINITI QX50	I55	2018.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI QX50	I55	2018.5-	CAN gateway	√	√	√	√		
Yemen	INFINITI QX50	I55	2018.5-	Lane camera	√	√	√	√		
Yemen	INFINITI QX50	J55	2018.5-	DAST 1	√	√	√	√		
Yemen	INFINITI QX50	J55	2018.5-	Chassis control	√	√	√	√		
Yemen	INFINITI QX50	J55	2018.5-	ANC						
Yemen	INFINITI QX50	J55	2018.5-	E-HUD	√	√	√	√		
Yemen	INFINITI QX50	J55	2018.5-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI QX50	J55	2018.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Yemen	INFINITI QX50	J55	2018.5-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI QX50	J55	2018.5-	6ch CAN GATEWAY	√	√	√	√		
Yemen	INFINITI QX50	J55	2018.5-	3ch CAN GATEWAY	√	√	√	√		
Yemen	INFINITI QX50	J55	2018.5-	ICC/ADAS 2	√	√	√	√		
Yemen	INFINITI QX56	JA60	2004.10-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Yemen	INFINITI QX56	JA60	2004.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492, SP0493
Yemen	INFINITI QX56	JA60	2004.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Yemen	INFINITI QX56	JA60	2004.10-	IPDM E/R	√	√	√	√	AC0811, AC0812, AC0814, AC0815, AC0816, AC0817, AC0818, AC0819, AC0820, AC0821, AC0822, AC0823, AC0825, AC0831	
Yemen	INFINITI QX56	JA60	2004.10-	Air bag	√	√	√	√		
Yemen	INFINITI QX56	JA60	2004.10-	EPS/DAST 3	√	√	√	√		SP0506, SP0507
Yemen	INFINITI QX56	JA60	2004.10-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349
Yemen	INFINITI QX56	JA60	2004.10-	Motor control						
Yemen	INFINITI QX56	JA60	2004.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0104, AC0105, AC0106, AC0107, AC0108, AC0109, AC0110, AC0111, AC0112, AC0113, AC0114, AC0115, AC0116, AC0117, AC0118, AC0119, AC0120, AC0121, AC0122, AC0123, AC0124, AC0125, AC0126, AC0127, AC0128, AC0129, AC0131, AC0145, AC0146, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0068, SP0074, SP0075, SP0076, SP0077, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0093, SP0094, SP0098, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI QX56	JA60	2004.10-	Transmission	√	√	√	√	AC0398, AC0399, AC0417, AC0418, AC0419, AC0420, AC0421, AC0422, AC0423, AC0424, AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0271, SP0272, SP0273, SP0274, SP0275, SP0276, SP0278, SP0279, SP0280, SP0287, SP0288
Yemen	INFINITI QX56	JA60	2004.10-	BCM	√	√	√	√	AC0586, AC0587, AC0588, AC0602, AC0603, AC0604, AC0605, AC0606, AC0607, AC0608, AC0609, AC0610, AC0613, AC0618, AC0626, AC0630, AC0653, AC0660, AC0663, AC0672, AC0678, AC0689, AC0690, AC0692, AC0695, AC0698, AC0702, AC0712, AC0719	SP0372, SP0381, SP0382, SP0385, SP0387, SP0388, SP0390, SP0391, SP0392, SP0393, SP0394, SP0397, SP0399, SP0402, SP0403, SP0419, SP0428, SP0429, SP0438, SP0450, SP0458, SP0469, SP0471
Yemen	INFINITI QX56	JA60	2004.10-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Yemen	INFINITI QX56	JA60	2004.10-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI QX56	JA60	2004.10-	HVAC	√	√	√	√		
Yemen	INFINITI QX56	JA60	2004.10-	Difference lock	√	√	√	√		
Yemen	INFINITI QX56	JA60	2004.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI QX56	JA60	2004.10-	Auto slide door	√	√	√	√	AC0941	
Yemen	INFINITI QX56	JA60	2004.10-	DIU		√	√	√		
Yemen	INFINITI QX56	JA60	2004.10-	Adaptive light	√	√	√	√		
Yemen	INFINITI QX56	JA60	2004.10-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI QX56	JA60	2004.10-	All mode AWD/4WD	√	√	√	√	AC0957	SP0544
Yemen	INFINITI QX56	JA60	2004.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI QX56	JA60	2004.10-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932	SP0511, SP0512, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537
Yemen	INFINITI QX56	JA60	2004.10-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973	
Yemen	INFINITI QX56	JA60	2004.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI QX56	JA60	2004.10-	IVMS	√	√		√		
Yemen	INFINITI QX56	JA60	2004.10-	Distance control	√	√		√		
Yemen	INFINITI QX56	JA60	2004.10-	Active suspense system	√	√	√	√		
Yemen	INFINITI QX56	JA60	2004.10-	Motor assist		√	√	√		SP0574
Yemen	INFINITI QX56	JA60	2004.10-	ASCD	√	√	√	√		
Yemen	INFINITI QX56	JA60	2004.10-	Active engine mount	√	√	√	√		
Yemen	INFINITI QX56	JA60	2004.10-	TCS	√	√	√	√		
Yemen	INFINITI QX56	IA60	2004.10-	S/blind camera	√			√		SP0572, SP0573
Yemen	INFINITI QX56	IA60	2004.10-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Yemen	INFINITI QX56	IA60	2004.10-	Nats immu	√	√	√			
Yemen	INFINITI QX56	IA60	2004.10-	Rearview camera	√			√		SP0570, SP0571
Yemen	INFINITI QX56	JA60	2004.10-	Smart entrance						SP0568
Yemen	INFINITI QX56	Z62	2011.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Yemen	INFINITI QX56	Z62	2011.7-	Laser/radar	√	√	√	√		
Yemen	INFINITI QX56	Z62	2011.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI QX56	Z62	2011.7-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Yemen	INFINITI QX56	Z62	2011.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI QX56	Z62	2011.7-	Air bag	√	√	√	√		
Yemen	INFINITI QX56	Z62	2011.7-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Yemen	INFINITI QX56	Z62	2011.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI QX56	Z62	2011.7-	Transmission	√	√	√	√		SP0270, SP0274
Yemen	INFINITI QX56	Z62	2011.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Yemen	INFINITI QX56	Z62	2011.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0313, SP0315
Yemen	INFINITI QX56	Z62	2011.7-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI QX56	Z62	2011.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Yemen	INFINITI QX56	Z62	2011.7-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Yemen	INFINITI QX56	Z62	2011.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI QX56	Z62	2011.7-	Auto back door	√	√	√	√		
Yemen	INFINITI QX56	Z62	2011.7-	Occupant detection			√	√		SP0584
Yemen	INFINITI QX56	Z62	2011.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Yemen	INFINITI QX56	Z62	2011.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI QX56	Z62	2011.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI QX56	Z62	2011.7-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Yemen	INFINITI QX56	Z62	2011.7-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI QX56	Z62	2011.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI QX56	Z62	2011.7-	CAN gateway	√	√	√			
Yemen	INFINITI QX56	Z62	2011.7-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Yemen	INFINITI QX56	Z62	2011.7-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI QX56	Z62	2011.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Yemen	INFINITI QX56	Z62	2011.7-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI QX60	L50	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Yemen	INFINITI QX60	L50	2013.7-	Laser/radar	√	√	√	√	AC0994	
Yemen	INFINITI QX60	L50	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI QX60	L50	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Yemen	INFINITI QX60	L50	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI QX60	L50	2013.7-	Air bag	√	√	√	√		
Yemen	INFINITI QX60	L50	2013.7-	EPS/DAST 3	√	√	√	√		
Yemen	INFINITI QX60	L50	2013.7-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Yemen	INFINITI QX60	L50	2013.7-	Motor control	√	√	√	√		

Yemen	INFINITI QX60	L50	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI QX60	L50	2013.7-	Transmission	√	√	√	√	AC0439	SP0246, SP0274, SP0275, SP0276, SP0278, SP0279, SP0281, SP0282, SP0283, SP0287, SP0288, SP0289, SP0290, SP0292
Yemen	INFINITI QX60	L50	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Yemen	INFINITI QX60	L50	2013.7-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Yemen	INFINITI QX60	L50	2013.7-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI QX60	L50	2013.7-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Yemen	INFINITI QX60	L50	2013.7-	HV battery	√	√	√	√	AC1121	
Yemen	INFINITI QX60	L50	2013.7-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI QX60	L50	2013.7-	Auto back door	√	√	√	√		SP0611
Yemen	INFINITI QX60	L50	2013.7-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Yemen	INFINITI QX60	L50	2013.7-	Occupant detection			√	√		SP0584
Yemen	INFINITI QX60	L50	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI QX60	L50	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI QX60	L50	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Yemen	INFINITI QX60	L50	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI QX60	L50	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI QX60	L50	2013.7-	Intelligent key	√	√	√	√		SP0511, SP0515, SP0516, SP0538, SP0539, SP0540
Yemen	INFINITI QX60	L50	2013.7-	CAN gateway	√	√	√			
Yemen	INFINITI QX60	L50	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Yemen	INFINITI QX60	L50	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Yemen	INFINITI QX60	L50	2013.7-	ANC	√	√	√	√	AC1024	
Yemen	INFINITI QX60	L50	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI QX60	L50	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Yemen	INFINITI QX60	L50	2013.7-	HIGH BEAM ASSIST	√	√	√	√		
Yemen	INFINITI QX60	L50	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI QX60	L50	2013.7-	3ch CAN GATEWAY	√	√	√	√		
Yemen	INFINITI QX60	L50	2013.7-	ICC/ADAS 2	√	√	√	√		
Yemen	INFINITI QX60	L50	2013.7-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Yemen	INFINITI QX60	L50	2013.7-	A-IVC(Renault common)	√	√	√	√		
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Laser/radar	√	√	√	√	AC0994	
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Air bag	√	√	√	√		
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	EPS/DAST 3	√	√	√	√		
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Motor control	√	√	√	√		
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Transmission	√	√	√	√	AC0439	SP0246, SP0276, SP0279, SP0281, SP0282, SP0283, SP0287, SP0289, SP0290, SP0292
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0487
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	HV battery	√	√	√	√	AC1121	
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Auto back door	√	√	√	√		SP0611
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	EV/HEV	√	√	√	√	AC1081, AC1084, AC1085, AC1086, AC1087, AC1088, AC1089	
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Occupant detection			√	√		SP0584
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	All mode AWD/4WD	√	√	√	√	AC0956	
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	CAN gateway	√	√	√			
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	ANC	√	√	√	√		
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	HIGH BEAM ASSIST	√	√	√	√		
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	ICC/ADAS 2	√	√	√	√		
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	PMAS	√	√	√	√		
Yemen	INFINITI QX60 HYBRID	HL50	2013.11-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Yemen	INFINITI QX70	S51	2013.5-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Yemen	INFINITI QX70	S51	2013.5-	Laser/radar	√	√	√	√	AC0994	
Yemen	INFINITI QX70	S51	2013.5-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Yemen	INFINITI QX70	S51	2013.5-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Yemen	INFINITI QX70	S51	2013.5-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI QX70	S51	2013.5-	Air bag	√	√	√	√		
Yemen	INFINITI QX70	S51	2013.5-	EPS/DAST 3	√	√	√	√		SP0507
Yemen	INFINITI QX70	S51	2013.5-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Yemen	INFINITI QX70	S51	2013.5-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Yemen	INFINITI QX70	S51	2013.5-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Yemen	INFINITI QX70	S51	2013.5-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Yemen	INFINITI QX70	S51	2013.5-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Yemen	INFINITI QX70	S51	2013.5-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Yemen	INFINITI QX70	S51	2013.5-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI QX70	S51	2013.5-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Yemen	INFINITI QX70	S51	2013.5-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Yemen	INFINITI QX70	S51	2013.5-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI QX70	S51	2013.5-	Auto back door	√	√	√	√		SP0611
Yemen	INFINITI QX70	S51	2013.5-	Occupant detection			√	√		SP0584
Yemen	INFINITI QX70	S51	2013.5-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Yemen	INFINITI QX70	S51	2013.5-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI QX70	S51	2013.5-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI QX70	S51	2013.5-	All mode AWD/4WD	√	√	√	√	AC0956	
Yemen	INFINITI QX70	S51	2013.5-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI QX70	S51	2013.5-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI QX70	S51	2013.5-	CAN gateway	√	√	√			
Yemen	INFINITI QX70	S51	2013.5-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Yemen	INFINITI QX70	S51	2013.5-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Yemen	INFINITI QX70	S51	2013.5-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Yemen	INFINITI QX70	S51	2013.5-	ANC	√	√	√	√		
Yemen	INFINITI QX70	S51	2013.5-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI QX70	S51	2013.5-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Yemen	INFINITI QX70	S51	2013.5-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI QX70	S51	2013.5-	ICC/ADAS 2	√	√	√	√		
Yemen	INFINITI QX80	Z62	2013.6-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Yemen	INFINITI QX80	Z62	2013.6-	Laser/radar	√	√	√	√	AC0994	
Yemen	INFINITI QX80	Z62	2013.6-	Head lamp levelizer	√	√	√	√	AC0864	SP0492

Yemen	INFINITI QX80	Z62	2013.6-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Yemen	INFINITI QX80	Z62	2013.6-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Yemen	INFINITI QX80	Z62	2013.6-	Air bag	√	√	√	√		
Yemen	INFINITI QX80	Z62	2013.6-	EPS/DAST 3	√	√	√	√		SP0507
Yemen	INFINITI QX80	Z62	2013.6-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Yemen	INFINITI QX80	Z62	2013.6-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Yemen	INFINITI QX80	Z62	2013.6-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Yemen	INFINITI QX80	Z62	2013.6-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Yemen	INFINITI QX80	Z62	2013.6-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Yemen	INFINITI QX80	Z62	2013.6-	Multi AV	√	√	√	√		SP0503
Yemen	INFINITI QX80	Z62	2013.6-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Yemen	INFINITI QX80	Z62	2013.6-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Yemen	INFINITI QX80	Z62	2013.6-	Difference lock	√	√	√	√		
Yemen	INFINITI QX80	Z62	2013.6-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Yemen	INFINITI QX80	Z62	2013.6-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Yemen	INFINITI QX80	Z62	2013.6-	Auto back door	√	√	√	√		
Yemen	INFINITI QX80	Z62	2013.6-	Occupant detection			√	√		SP0584
Yemen	INFINITI QX80	Z62	2013.6-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Yemen	INFINITI QX80	Z62	2013.6-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Yemen	INFINITI QX80	Z62	2013.6-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Yemen	INFINITI QX80	Z62	2013.6-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Yemen	INFINITI QX80	Z62	2013.6-	Precrash seatbelt	√	√	√	√		SP0612
Yemen	INFINITI QX80	Z62	2013.6-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Yemen	INFINITI QX80	Z62	2013.6-	Intelligent key	√	√	√	√	AC0903, AC0904, AC0905, AC0906, AC0907, AC0908, AC0909, AC0910, AC0911, AC0912, AC0913, AC0914, AC0915, AC0916, AC0917, AC0918, AC0919, AC0920, AC0921, AC0922, AC0923, AC0924, AC0925, AC0926, AC0927, AC0928, AC0929, AC0930, AC0931, AC0932, AC0933, AC0934, AC0935	SP0511, SP0512, SP0515, SP0516, SP0517, SP0518, SP0519, SP0520, SP0521, SP0522, SP0523, SP0524, SP0525, SP0526, SP0527, SP0528, SP0529, SP0530, SP0531, SP0532, SP0533, SP0534, SP0535, SP0536, SP0537, SP0538, SP0539, SP0540
Yemen	INFINITI QX80	Z62	2013.6-	CAN gateway	√	√	√			
Yemen	INFINITI QX80	Z62	2013.6-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Yemen	INFINITI QX80	Z62	2013.6-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Yemen	INFINITI QX80	Z62	2013.6-	Side radar left	√	√	√	√	AC1025	SP0582
Yemen	INFINITI QX80	Z62	2013.6-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Yemen	INFINITI QX80	Z62	2013.6-	HIGH BEAM ASSIST	√	√	√	√		
Yemen	INFINITI QX80	Z62	2013.6-	Side radar right	√	√	√	√	AC1026	SP0583
Yemen	INFINITI QX80	Z62	2013.6-	Vehicle data transmitter	√	√	√	√		
Yemen	INFINITI QX80	Z62	2013.6-	6ch CAN GATEWAY	√	√	√	√		
Yemen	INFINITI QX80	Z62	2013.6-	ICC/ADAS 2	√	√	√	√		
Yemen	INFINITI QX80	Z62	2013.6-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Zaire	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI EX35/EX37	I50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zaire	INFINITI EX35/EX37	I50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI EX35/EX37	I50	2011.1-	Air bag	√	√	√	√		
Zaire	INFINITI EX35/EX37	I50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zaire	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zaire	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Zaire	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zaire	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Zaire	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zaire	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zaire	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zaire	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Zaire	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Zaire	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Zaire	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Zaire	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Zaire	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Zaire	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zaire	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Zaire	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zaire	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zaire	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Zaire	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zaire	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Zaire	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Zaire	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zaire	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Zaire	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Zaire	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zaire	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zaire	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Zaire	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Zaire	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Zaire	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Zaire	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zaire	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239

Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Zaire	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Zaire	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Zaire	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zaire	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Zaire	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zaire	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zaire	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Zaire	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zaire	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Zaire	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Zaire	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zaire	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zaire	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zaire	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Zaire	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zaire	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Zaire	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Zaire	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Zaire	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Zaire	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Zaire	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Zaire	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zaire	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Zaire	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Zaire	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Zaire	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Zaire	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zaire	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zaire	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zaire	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zaire	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zaire	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zaire	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Zaire	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Zaire	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Zaire	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Zaire	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zaire	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Zaire	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Zaire	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			

Zaire	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Zaire	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Zaire	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Zaire	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Zaire	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Zaire	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Zaire	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Zaire	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Zaire	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Zaire	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Zaire	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Zaire	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Zaire	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Zaire	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Zaire	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Zaire	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Zaire	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Zaire	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Zaire	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Zaire	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Zaire	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Zaire	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Zaire	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zaire	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Zaire	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zaire	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Zaire	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Zaire	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Zaire	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zaire	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Zaire	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Zaire	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Zaire	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Zaire	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zaire	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zaire	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Zaire	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Zaire	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zaire	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Zaire	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Zaire	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Zaire	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Zaire	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zaire	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Zaire	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Zaire	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zaire	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Zaire	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Zaire	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Zaire	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zaire	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Zaire	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Zaire	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Zaire	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zaire	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Zaire	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Zaire	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315

Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Zaire	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Zaire	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zaire	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Zaire	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zaire	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Zaire	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Zaire	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Zaire	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zaire	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Zaire	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Zaire	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Zaire	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Zaire	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zaire	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zaire	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Zaire	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Zaire	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zaire	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Zaire	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Zaire	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Zaire	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Zaire	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Zaire	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Zaire	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Zaire	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zaire	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Zaire	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Zaire	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Zaire	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Zaire	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Zaire	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zaire	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Zaire	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Zaire	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Zaire	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Zaire	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zaire	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	

Zaire	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zaire	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zaire	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Zaire	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Zaire	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zaire	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Zaire	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Zaire	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Zaire	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zaire	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Zaire	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Zaire	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Zaire	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Zaire	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zaire	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zaire	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Zaire	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Zaire	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zaire	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Zaire	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Zaire	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Zaire	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zaire	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Zaire	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Zaire	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zaire	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zaire	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Zaire	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zaire	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Zaire	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zaire	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Zaire	INFINITI QX50	I50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zaire	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Zaire	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Zaire	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zaire	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zaire	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Zaire	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zaire	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Zaire	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zaire	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zaire	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Zaire	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Zaire	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Zaire	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zaire	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Zaire	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Zaire	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Zaire	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Zaire	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zaire	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Zaire	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Zaire	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Zaire	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zaire	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Zaire	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Zaire	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Zaire	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zaire	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Zaire	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zaire	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Zaire	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Zaire	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zaire	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zaire	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Zaire	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Zaire	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zaire	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zaire	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Zaire	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Zaire	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Zaire	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zaire	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Zaire	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Zaire	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zaire	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zaire	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Zaire	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Zaire	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zaire	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Zaire	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Zaire	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zaire	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Zaire	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zaire	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Zaire	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zaire	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Zaire	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Zaire	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zaire	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Zaire	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Zaire	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Zaire	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Zaire	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Zaire	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Zaire	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Zaire	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zaire	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Zaire	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Zaire	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Zaire	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zaire	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Zaire	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Zaire	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Zaire	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Zaire	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Zaire	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Zaire	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zaire	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Zaire	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zaire	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Zaire	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Zaire	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Zaire	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Zaire	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Zambia	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zambia	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Zambia	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zambia	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zambia	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√	AC0270, AC0274	
Zambia	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zambia	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Zambia	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zambia	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zambia	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zambia	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Zambia	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Zambia	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Zambia	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Zambia	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Zambia	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Zambia	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zambia	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Zambia	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zambia	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zambia	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√	AC0274	SP0274
Zambia	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zambia	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Zambia	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Zambia	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503

Zambia	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zambia	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Zambia	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Zambia	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zambia	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zambia	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Zambia	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Zambia	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Zambia	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Zambia	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zambia	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Zambia	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Zambia	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Zambia	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zambia	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Zambia	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zambia	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zambia	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Zambia	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zambia	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Zambia	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Zambia	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zambia	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zambia	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zambia	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Zambia	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zambia	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Zambia	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Zambia	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Zambia	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Zambia	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Zambia	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Zambia	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zambia	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Zambia	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Zambia	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Zambia	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Zambia	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zambia	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zambia	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zambia	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zambia	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zambia	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zambia	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Zambia	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Zambia	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Zambia	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Zambia	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zambia	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Zambia	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Zambia	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Zambia	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Zambia	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Zambia	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Zambia	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Zambia	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Zambia	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Zambia	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Zambia	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Zambia	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Zambia	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Zambia	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Zambia	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Zambia	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Zambia	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Zambia	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Zambia	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Zambia	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Zambia	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Zambia	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Zambia	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Zambia	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Zambia	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Zambia	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zambia	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Zambia	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zambia	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Zambia	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Zambia	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Zambia	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zambia	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Zambia	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Zambia	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Zambia	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Zambia	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zambia	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zambia	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Zambia	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Zambia	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zambia	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Zambia	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Zambia	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Zambia	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Zambia	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zambia	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Zambia	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	

Zambia	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zambia	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Zambia	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Zambia	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Zambia	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zambia	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Zambia	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Zambia	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Zambia	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zambia	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Zambia	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Zambia	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Zambia	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Zambia	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zambia	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Zambia	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zambia	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Zambia	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Zambia	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Zambia	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zambia	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274
Zambia	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Zambia	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Zambia	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Zambia	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zambia	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zambia	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Zambia	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Zambia	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zambia	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Zambia	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Zambia	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Zambia	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Zambia	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Zambia	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Zambia	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Zambia	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zambia	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Zambia	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Zambia	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Zambia	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Zambia	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Zambia	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zambia	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Zambia	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Zambia	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Zambia	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Zambia	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		

Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zambia	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zambia	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zambia	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Zambia	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Zambia	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zambia	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Zambia	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Zambia	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Zambia	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zambia	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Zambia	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Zambia	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Zambia	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Zambia	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zambia	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zambia	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Zambia	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Zambia	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zambia	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Zambia	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Zambia	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Zambia	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zambia	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Zambia	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Zambia	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zambia	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zambia	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Zambia	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zambia	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Zambia	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zambia	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Zambia	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zambia	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Zambia	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Zambia	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Zambia	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zambia	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Zambia	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zambia	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Zambia	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zambia	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zambia	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Zambia	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Zambia	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Zambia	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zambia	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Zambia	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Zambia	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Zambia	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Zambia	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zambia	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Zambia	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Zambia	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Zambia	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zambia	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Zambia	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Zambia	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zambia	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zambia	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Zambia	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zambia	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Zambia	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Zambia	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zambia	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zambia	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Zambia	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Zambia	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zambia	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zambia	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Zambia	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Zambia	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Zambia	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zambia	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Zambia	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Zambia	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zambia	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zambia	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Zambia	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Zambia	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zambia	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Zambia	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Zambia	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zambia	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Zambia	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zambia	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Zambia	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zambia	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Zambia	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351
Zambia	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zambia	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Zambia	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Zambia	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Zambia	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Zambia	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Zambia	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Zambia	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Zambia	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zambia	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Zambia	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Zambia	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Zambia	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zambia	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Zambia	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Zambia	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Zambia	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Zambia	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Zambia	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Zambia	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zambia	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Zambia	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zambia	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Zambia	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Zambia	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Zambia	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Zambia	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Air bag	√	√	√	√		
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350

Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Transmission	√	√	√	√		SP0270, SP0274
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Zimbabwe	INFINITI EX35/EX37	J50	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Air bag	√	√	√	√		
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Transmission	√	√	√	√		SP0274
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Auto back door	√	√	√	√		SP0611
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Occupant detection			√	√		SP0584
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	CAN gateway	√	√	√			
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0975, AC0976	SP0560
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zimbabwe	INFINITI FX35/FX50	S51	2011.1-	Rearview camera	√			√		SP0570, SP0571
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	Air bag	√	√	√	√		
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	Transmission	√	√	√	√		SP0274
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	Pop up hood	√	√	√	√		
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957	
Zimbabwe	INFINITI G25/G37 SEDAN	V36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Air bag	√	√	√	√		
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0147, AC0148, AC0149, AC0150, AC0154, AC0155, AC0156, AC0157, AC0160, AC0161, AC0162, AC0164, AC0166, AC0168, AC0171, AC0172, AC0173, AC0174, AC0176, AC0178, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0238, SP0239
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Transmission	√	√	√	√		SP0274
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Pop up hood	√	√	√	√		
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543

XTOOL

Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Zimbabwe	INFINITI G37 CONVERTIBLE	HV36	2011.1-	Precrash seatbelt	√	√	√	√		
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	Air bag	√	√	√	√		
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	Transmission	√	√	√	√		SP0274
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	Pop up hood	√	√	√	√		
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	Precrash seatbelt	√	√	√	√		
Zimbabwe	INFINITI G37 COUPE	CV36	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896	SP0510
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Laser/radar	√	√	√	√		
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Air bag	√	√	√	√		
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Pop up hood	√	√	√	√		
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	All mode AWD/4WD	√	√	√	√	AC0956	
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Precrash seatbelt	√	√	√	√		SP0612
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	CAN gateway	√	√	√			
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Side radar left	√	√	√	√	AC1025	SP0582
Zimbabwe	INFINITI M37/M56	Y51	2011.1-	Side radar right	√	√	√	√	AC1026	SP0583
Zimbabwe	INFINITI Q30	H15	2016.4-	Air pressure monitor	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Air bag	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	EPS/DAST 3	√	√	√			
Zimbabwe	INFINITI Q30	H15	2016.4-	Meter/M&A	√	√	√	√	AC0546, AC0547, AC0548, AC0549	SP0342, SP0343, SP0344
Zimbabwe	INFINITI Q30	H15	2016.4-	Engine	√	√	√	√	AC0002, AC0103, AC0214, AC0264, AC0265, AC0266, AC0267, AC0268, AC0269, AC0270, AC0271, AC0272, AC0273, AC0274, AC0275, AC0276, AC0277, AC0308, AC0310, AC0311, AC0312, AC0314, AC0315, AC0317, AC0320, AC0325, AC0327, AC0328, AC0329, AC0330, AC0331, AC0332	SP0034, SP0035, SP0159, SP0193, SP0194
Zimbabwe	INFINITI Q30	H15	2016.4-	EHS/PKB	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Transmission	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	BCM	√	√	√	√	AC0580, AC0674, AC0739, AC0740, AC0741, AC0742, AC0743, AC0744, AC0745, AC0746, AC0747, AC0748, AC0749, AC0750, AC0751, AC0752, AC0753, AC0754, AC0755, AC0756, AC0757, AC0758, AC0759, AC0760, AC0761, AC0762, AC0763, AC0764, AC0765, AC0766, AC0767, AC0768, AC0769, AC0770	
Zimbabwe	INFINITI Q30	H15	2016.4-	ABS	√	√	√	√		SP0308
Zimbabwe	INFINITI Q30	H15	2016.4-	Multi AV	√	√	√	√		SP0501
Zimbabwe	INFINITI Q30	H15	2016.4-	HVAC	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Auto drive position	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Shift	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	All mode AWD/4WD	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	AVM	√	√		√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Intelligent key	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	CAN gateway	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	ANC	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Telematics	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	FSCM	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Siren control unit	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	LEFT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1143, AC1144, AC1145, AC1146, AC1147, AC1148, AC1149, AC1150, AC1151, AC1152, AC1153, AC1154, AC1155, AC1156	
Zimbabwe	INFINITI Q30	H15	2016.4-	Overhead Control Panel Unit	√			√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Universal Garage Door Opener	√			√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Upper control panel cont unit	√					
Zimbabwe	INFINITI Q30	H15	2016.4-	PASSENGER SEAT CONTROL UNIT	√	√	√	√	AC1171, AC1172, AC1173, AC1174, AC1175	
Zimbabwe	INFINITI Q30	H15	2016.4-	RIGHT FRONT DOOR CONTROL UNIT	√	√	√	√	AC1157, AC1158, AC1159, AC1160, AC1161, AC1162, AC1163, AC1164, AC1165, AC1166, AC1167, AC1168, AC1169, AC1170	SP0622
Zimbabwe	INFINITI Q30	H15	2016.4-	Light/Rain Sensor Module	√			√		
Zimbabwe	INFINITI Q30	H15	2016.4-	EC Mirror Compass	√					
Zimbabwe	INFINITI Q30	H15	2016.4-	Intelligent Battery Sensor	√					
Zimbabwe	INFINITI Q30	H15	2016.4-	Alarm siren	√			√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Radar sensor	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Steering column cont module	√	√	√			
Zimbabwe	INFINITI Q30	H15	2016.4-	ICC sensor	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Trailer recognition control unit	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	H/L control module LH	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Powertrain cont module	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Side radar LH	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	LED H/L control module LH	√			√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Steering Wheel Switch Pad	√			√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Parking assist	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Occupant Classification Unit	√			√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Electronic Ignition Switch cont unit	√	√	√	√		

Zimbabwe	INFINITI Q30	H15	2016.4-	H/L control module RH	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Front camera unit	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	Side radar RH	√	√	√	√		
Zimbabwe	INFINITI Q30	H15	2016.4-	LED H/L control module RH	√			√		
Zimbabwe	INFINITI Q50	V37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zimbabwe	INFINITI Q50	V37	2013.10-	Laser/radar	√	√	√	√	AC0994	
Zimbabwe	INFINITI Q50	V37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI Q50	V37	2013.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zimbabwe	INFINITI Q50	V37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI Q50	V37	2013.10-	Air bag	√	√	√	√		
Zimbabwe	INFINITI Q50	V37	2013.10-	EPS/DAST 3	√	√	√	√		
Zimbabwe	INFINITI Q50	V37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Zimbabwe	INFINITI Q50	V37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zimbabwe	INFINITI Q50	V37	2013.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0274
Zimbabwe	INFINITI Q50	V37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Zimbabwe	INFINITI Q50	V37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Zimbabwe	INFINITI Q50	V37	2013.10-	Pop up hood	√	√	√	√		
Zimbabwe	INFINITI Q50	V37	2013.10-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI Q50	V37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zimbabwe	INFINITI Q50	V37	2013.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zimbabwe	INFINITI Q50	V37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI Q50	V37	2013.10-	Occupant detection			√	√		SP0584
Zimbabwe	INFINITI Q50	V37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Zimbabwe	INFINITI Q50	V37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zimbabwe	INFINITI Q50	V37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Zimbabwe	INFINITI Q50	V37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Zimbabwe	INFINITI Q50	V37	2013.10-	DAST 2	√	√	√	√		
Zimbabwe	INFINITI Q50	V37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Zimbabwe	INFINITI Q50	V37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zimbabwe	INFINITI Q50	V37	2013.10-	CAN gateway	√	√	√			
Zimbabwe	INFINITI Q50	V37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Zimbabwe	INFINITI Q50	V37	2013.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zimbabwe	INFINITI Q50	V37	2013.10-	DAST 1	√	√	√	√		
Zimbabwe	INFINITI Q50	V37	2013.10-	ADCM	√	√	√	√		SP0604, SP0605, SP0606
Zimbabwe	INFINITI Q50	V37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Zimbabwe	INFINITI Q50	V37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zimbabwe	INFINITI Q50	V37	2013.10-	ANC	√	√	√	√	AC1024	
Zimbabwe	INFINITI Q50	V37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Zimbabwe	INFINITI Q50	V37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Zimbabwe	INFINITI Q50	V37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zimbabwe	INFINITI Q50	V37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Zimbabwe	INFINITI Q50	V37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Zimbabwe	INFINITI Q50	V37	2013.10-	FSCM	√	√	√	√	AC1109	
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Laser/radar	√	√	√	√		
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Air bag	√	√	√	√		
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	EPS/DAST 3	√	√	√	√		
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Motor control	√	√	√	√		
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0330, AC0331, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Transmission	√	√	√	√		SP0247, SP0274, SP0276
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0300, SP0313, SP0315
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Pop up hood	√	√	√	√		
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	HV battery	√	√	√	√	AC1121	
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	EV/HEV	√	√	√	√	AC1084, AC1085, AC1086, AC1087, AC1088, AC1089, AC1106	
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Occupant detection			√	√		SP0584
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Adaptive light	√	√	√	√	AC0979, AC0981, AC0982	SP0562
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 2	√	√	√	√		
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Precrash seatbelt	√	√	√	√		SP0612
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	CAN gateway	√	√	√			
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Lane camera	√	√	√	√	AC0973, AC0974, AC0976, AC0977	
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	DAST 1	√	√	√	√		
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Chassis control	√	√	√	√	AC1043, AC1044, AC1045, AC1046, AC1047, AC1048, AC1049, AC1050, AC1051, AC1052, AC1053, AC1054, AC1055, AC1056, AC1057, AC1058, AC1059, AC1060, AC1061, AC1062, AC1063, AC1064, AC1065, AC1066, AC1067, AC1068, AC1069, AC1070, AC1071, AC1072, AC1073, AC1074, AC1075, AC1076, AC1077	
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	ANC	√	√	√	√	AC1024	
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar left	√	√	√	√	AC1025	SP0582
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	HIGH BEAM ASSIST	√	√	√	√		
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Side radar right	√	√	√	√	AC1026	SP0583
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Brake	√	√	√	√	AC1127	
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	Charger/PD module	√	√	√	√	AC1129, AC1130, AC1131	
Zimbabwe	INFINITI Q50 HYBRID	HV37	2013.10-	VSP	√	√	√	√	AC1122, AC1123, AC1124, AC1125, AC1126	
Zimbabwe	INFINITI Q60	CV37	2016.10-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zimbabwe	INFINITI Q60	CV37	2016.10-	Laser/radar	√	√	√	√	AC0994	
Zimbabwe	INFINITI Q60	CV37	2016.10-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI Q60	CV37	2016.10-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zimbabwe	INFINITI Q60	CV37	2016.10-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI Q60	CV37	2016.10-	Air bag	√	√	√	√		
Zimbabwe	INFINITI Q60	CV37	2016.10-	EPS/DAST 3	√	√	√	√		
Zimbabwe	INFINITI Q60	CV37	2016.10-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351
Zimbabwe	INFINITI Q60	CV37	2016.10-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0266, AC0270, AC0272, AC0277, AC0282, AC0283, AC0284, AC0307, AC0308, AC0309, AC0311, AC0312, AC0313, AC0314, AC0315, AC0316, AC0317, AC0318, AC0319, AC0320, AC0321, AC0322, AC0323, AC0324, AC0325, AC0326, AC0327, AC0330, AC0331, AC0332, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0034, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0128, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0193, SP0194, SP0195, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zimbabwe	INFINITI Q60	CV37	2016.10-	Transmission	√	√	√	√		SP0247, SP0265, SP0270, SP0274

Zimbabwe	INFINITI Q60	CV37	2016.10-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429
Zimbabwe	INFINITI Q60	CV37	2016.10-	ABS	√	√	√	√	AC0498, AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Zimbabwe	INFINITI Q60	CV37	2016.10-	Pop up hood	√	√	√	√		
Zimbabwe	INFINITI Q60	CV37	2016.10-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI Q60	CV37	2016.10-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zimbabwe	INFINITI Q60	CV37	2016.10-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zimbabwe	INFINITI Q60	CV37	2016.10-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI Q60	CV37	2016.10-	Occupant detection			√	√		SP0584
Zimbabwe	INFINITI Q60	CV37	2016.10-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Zimbabwe	INFINITI Q60	CV37	2016.10-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zimbabwe	INFINITI Q60	CV37	2016.10-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Zimbabwe	INFINITI Q60	CV37	2016.10-	All mode AWD/4WD	√	√	√	√	AC0956	
Zimbabwe	INFINITI Q60	CV37	2016.10-	DAST 2	√	√	√	√		
Zimbabwe	INFINITI Q60	CV37	2016.10-	Precrash seatbelt	√	√	√	√		SP0612
Zimbabwe	INFINITI Q60	CV37	2016.10-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Zimbabwe	INFINITI Q60	CV37	2016.10-	CAN gateway	√	√	√			
Zimbabwe	INFINITI Q60	CV37	2016.10-	Lane camera	√	√	√	√		
Zimbabwe	INFINITI Q60	CV37	2016.10-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zimbabwe	INFINITI Q60	CV37	2016.10-	DAST 1	√	√	√	√		
Zimbabwe	INFINITI Q60	CV37	2016.10-	Chassis control	√	√	√	√		
Zimbabwe	INFINITI Q60	CV37	2016.10-	ANC	√	√	√	√		
Zimbabwe	INFINITI Q60	CV37	2016.10-	Side radar left	√	√	√	√	AC1025	SP0582
Zimbabwe	INFINITI Q60	CV37	2016.10-	EMCM	√	√	√	√	AC1111, AC1112	SP0608, SP0609, SP0610
Zimbabwe	INFINITI Q60	CV37	2016.10-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zimbabwe	INFINITI Q60	CV37	2016.10-	HIGH BEAM ASSIST	√	√	√	√		
Zimbabwe	INFINITI Q60	CV37	2016.10-	Side radar right	√	√	√	√	AC1026	SP0583
Zimbabwe	INFINITI Q60	CV37	2016.10-	Lane camera 2	√	√	√	√		
Zimbabwe	INFINITI Q60	CV37	2016.10-	ICC/ADAS 2	√	√	√	√		
Zimbabwe	INFINITI Q60	CV37	2016.10-	FSCM	√	√	√	√	AC1109	
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Convertible roof	√	√	√	√	AC1006, AC1007, AC1008, AC1009, AC1010	SP0575, SP0576, SP0577, SP0578, SP0579, SP0580
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Air bag	√	√	√	√		
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Transmission	√	√	√	√		SP0274
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Pop up hood	√	√	√	√		
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	Precrash seatbelt	√	√	√	√		
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zimbabwe	INFINITI Q60 CONVERTIBLE	HV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	Laser/radar	√	√	√	√	AC0994	
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0876, AC0877, AC0884	SP0494
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	Air bag	√	√	√	√		
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	Transmission	√	√	√	√		SP0274
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0315, SP0316, SP0317, SP0319
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	Pop up hood	√	√	√	√		
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964	SP0553, SP0554, SP0555, SP0556
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956, AC0957, AC0958, AC0959, AC0960	SP0544, SP0545, SP0546, SP0547, SP0548, SP0549, SP0550, SP0551
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	Precrash seatbelt	√	√	√	√		
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zimbabwe	INFINITI Q60 COUPE	CV36	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zimbabwe	INFINITI Q70	Y51	2013.9-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Zimbabwe	INFINITI Q70	Y51	2013.9-	Laser/radar	√	√	√	√		
Zimbabwe	INFINITI Q70	Y51	2013.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI Q70	Y51	2013.9-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zimbabwe	INFINITI Q70	Y51	2013.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI Q70	Y51	2013.9-	Air bag	√	√	√	√		
Zimbabwe	INFINITI Q70	Y51	2013.9-	EPS/DAST 3	√	√	√	√		
Zimbabwe	INFINITI Q70	Y51	2013.9-	Meter/M&A	√	√	√	√		SP0348, SP0349, SP0350, SP0351

Zimbabwe	INFINITI Q70	Y51	2013.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zimbabwe	INFINITI Q70	Y51	2013.9-	Transmission	√	√	√	√		SP0274
Zimbabwe	INFINITI Q70	Y51	2013.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Zimbabwe	INFINITI Q70	Y51	2013.9-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535, AC0536	SP0300, SP0313, SP0315, SP0316, SP0317, SP0319
Zimbabwe	INFINITI Q70	Y51	2013.9-	Pop up hood	√	√	√	√		
Zimbabwe	INFINITI Q70	Y51	2013.9-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI Q70	Y51	2013.9-	HVAC	√	√	√	√	AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0479, SP0480, SP0481, SP0482, SP0486, SP0487
Zimbabwe	INFINITI Q70	Y51	2013.9-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zimbabwe	INFINITI Q70	Y51	2013.9-	Auto drive position	√	√	√	√	AC0946, AC0947, AC0948, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI Q70	Y51	2013.9-	Occupant detection			√	√		SP0584
Zimbabwe	INFINITI Q70	Y51	2013.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Zimbabwe	INFINITI Q70	Y51	2013.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zimbabwe	INFINITI Q70	Y51	2013.9-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968	SP0553, SP0554, SP0555, SP0556, SP0557
Zimbabwe	INFINITI Q70	Y51	2013.9-	All mode AWD/4WD	√	√	√	√	AC0956	
Zimbabwe	INFINITI Q70	Y51	2013.9-	Precrash seatbelt	√	√	√	√		SP0612
Zimbabwe	INFINITI Q70	Y51	2013.9-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zimbabwe	INFINITI Q70	Y51	2013.9-	CAN gateway	√	√	√	√		
Zimbabwe	INFINITI Q70	Y51	2013.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Zimbabwe	INFINITI Q70	Y51	2013.9-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zimbabwe	INFINITI Q70	Y51	2013.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zimbabwe	INFINITI Q70	Y51	2013.9-	Side radar left	√	√	√	√	AC1025	SP0582
Zimbabwe	INFINITI Q70	Y51	2013.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zimbabwe	INFINITI Q70	Y51	2013.9-	Side radar right	√	√	√	√	AC1026	SP0583
Zimbabwe	INFINITI QX50	J50	2013.8-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zimbabwe	INFINITI QX50	J50	2013.8-	Laser/radar	√	√	√	√	AC0994	
Zimbabwe	INFINITI QX50	J50	2013.8-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI QX50	J50	2013.8-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zimbabwe	INFINITI QX50	J50	2013.8-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI QX50	J50	2013.8-	Air bag	√	√	√	√		
Zimbabwe	INFINITI QX50	J50	2013.8-	EPS/DAST 3	√	√	√	√		SP0507
Zimbabwe	INFINITI QX50	J50	2013.8-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zimbabwe	INFINITI QX50	J50	2013.8-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0282, AC0283, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zimbabwe	INFINITI QX50	J50	2013.8-	Transmission	√	√	√	√		SP0274
Zimbabwe	INFINITI QX50	J50	2013.8-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zimbabwe	INFINITI QX50	J50	2013.8-	ABS	√	√	√	√	AC0498, AC0507, AC0508, AC0509, AC0510, AC0511, AC0512, AC0513, AC0514, AC0515, AC0516, AC0517, AC0527, AC0528, AC0529, AC0530, AC0531, AC0532, AC0533, AC0534, AC0535	SP0301, SP0313, SP0315, SP0316, SP0317, SP0319
Zimbabwe	INFINITI QX50	J50	2013.8-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI QX50	J50	2013.8-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI QX50	J50	2013.8-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zimbabwe	INFINITI QX50	J50	2013.8-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zimbabwe	INFINITI QX50	J50	2013.8-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Zimbabwe	INFINITI QX50	J50	2013.8-	All mode AWD/4WD	√	√	√	√	AC0956	
Zimbabwe	INFINITI QX50	J50	2013.8-	Precrash seatbelt	√	√	√	√		SP0612
Zimbabwe	INFINITI QX50	J50	2013.8-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zimbabwe	INFINITI QX50	J50	2013.8-	CAN gateway	√	√	√	√		
Zimbabwe	INFINITI QX50	J50	2013.8-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Zimbabwe	INFINITI QX50	J50	2013.8-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021, AC1022, AC1023	
Zimbabwe	INFINITI QX50	J50	2013.8-	Side radar left	√	√	√	√	AC1025	SP0582
Zimbabwe	INFINITI QX50	J50	2013.8-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zimbabwe	INFINITI QX50	J50	2013.8-	Side radar right	√	√	√	√	AC1026	SP0583
Zimbabwe	INFINITI QX70	S51	2013.7-	Air pressure monitor	√	√	√	√	AC0894, AC0895, AC0896, AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509, SP0510
Zimbabwe	INFINITI QX70	S51	2013.7-	Laser/radar	√	√	√	√	AC0994	
Zimbabwe	INFINITI QX70	S51	2013.7-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI QX70	S51	2013.7-	ICC/ADAS	√	√	√	√	AC0865, AC0866, AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0876, AC0877, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0494, SP0495, SP0496, SP0497
Zimbabwe	INFINITI QX70	S51	2013.7-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI QX70	S51	2013.7-	Air bag	√	√	√	√		
Zimbabwe	INFINITI QX70	S51	2013.7-	EPS/DAST 3	√	√	√	√		SP0507
Zimbabwe	INFINITI QX70	S51	2013.7-	Meter/M&A	√	√	√	√		SP0347, SP0348, SP0349, SP0350
Zimbabwe	INFINITI QX70	S51	2013.7-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0333, AC0334, AC0335, AC0336, AC0337, AC0338, AC0339, AC0351, AC0352, AC0365, AC0366, AC0367, AC0369, AC0371, AC0372, AC0373, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0045, SP0051, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0083, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0196, SP0197, SP0198, SP0199, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0225, SP0237, SP0238, SP0239
Zimbabwe	INFINITI QX70	S51	2013.7-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0274
Zimbabwe	INFINITI QX70	S51	2013.7-	BCM				√	AC0613, AC0618, AC0663, AC0692, AC0702, AC0719	SP0372, SP0429
Zimbabwe	INFINITI QX70	S51	2013.7-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533	SP0301, SP0313, SP0315
Zimbabwe	INFINITI QX70	S51	2013.7-	Total illum C/U	√			√	AC1133, AC1134, AC1135, AC1136, AC1137, AC1138, AC1139, AC1140, AC1141, AC1142	SP0614, SP0615, SP0616, SP0617, SP0618, SP0619, SP0620, SP0621
Zimbabwe	INFINITI QX70	S51	2013.7-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI QX70	S51	2013.7-	E-SUS	√	√	√	√	AC1034, AC1035, AC1036, AC1037, AC1038, AC1039	
Zimbabwe	INFINITI QX70	S51	2013.7-	4WAS(front)	√	√	√	√	AC1027, AC1028	
Zimbabwe	INFINITI QX70	S51	2013.7-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI QX70	S51	2013.7-	Auto back door	√	√	√	√		SP0611
Zimbabwe	INFINITI QX70	S51	2013.7-	Occupant detection			√	√		SP0584
Zimbabwe	INFINITI QX70	S51	2013.7-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980	SP0561, SP0562
Zimbabwe	INFINITI QX70	S51	2013.7-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zimbabwe	INFINITI QX70	S51	2013.7-	Sonar	√	√	√	√	AC0962, AC0963, AC0964, AC0966, AC0967, AC0968, AC0969, AC0970	SP0553, SP0554, SP0555, SP0556, SP0557, SP0558, SP0559
Zimbabwe	INFINITI QX70	S51	2013.7-	All mode AWD/4WD	√	√	√	√	AC0956	
Zimbabwe	INFINITI QX70	S51	2013.7-	Precrash seatbelt	√	√	√	√		SP0612
Zimbabwe	INFINITI QX70	S51	2013.7-	AVM	√	√	√	√	AC0983, AC0984, AC0985, AC0986, AC0987, AC0988, AC0989, AC0990	SP0563, SP0564, SP0565, SP0566, SP0567
Zimbabwe	INFINITI QX70	S51	2013.7-	CAN gateway	√	√	√			
Zimbabwe	INFINITI QX70	S51	2013.7-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Zimbabwe	INFINITI QX70	S51	2013.7-	4WAS(MAIN)/RAS/HICAS	√	√	√	√	AC0961	
Zimbabwe	INFINITI QX70	S51	2013.7-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zimbabwe	INFINITI QX70	S51	2013.7-	ANC	√	√	√	√		
Zimbabwe	INFINITI QX70	S51	2013.7-	Side radar left	√	√	√	√	AC1025	SP0582
Zimbabwe	INFINITI QX70	S51	2013.7-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zimbabwe	INFINITI QX70	S51	2013.7-	Side radar right	√	√	√	√	AC1026	SP0583
Zimbabwe	INFINITI QX70	S51	2013.7-	ICC/ADAS 2	√	√	√	√		
Zimbabwe	INFINITI QX80	Z62	2016.9-	Air pressure monitor	√	√	√	√	AC0897, AC0898, AC0899, AC0900, AC0901, AC0902	SP0508, SP0509
Zimbabwe	INFINITI QX80	Z62	2016.9-	Laser/radar	√	√	√	√		
Zimbabwe	INFINITI QX80	Z62	2016.9-	Head lamp levelizer	√	√	√	√	AC0864	SP0492
Zimbabwe	INFINITI QX80	Z62	2016.9-	ICC/ADAS	√	√	√	√	AC0867, AC0868, AC0869, AC0870, AC0871, AC0872, AC0873, AC0874, AC0875, AC0878, AC0879, AC0880, AC0881, AC0882, AC0883, AC0884, AC0885	SP0495, SP0496, SP0497
Zimbabwe	INFINITI QX80	Z62	2016.9-	IPDM E/R	√	√	√	√	AC0811, AC0815, AC0816, AC0817, AC0818, AC0819, AC0821, AC0822, AC0825, AC0831	
Zimbabwe	INFINITI QX80	Z62	2016.9-	Air bag	√	√	√	√		
Zimbabwe	INFINITI QX80	Z62	2016.9-	Meter/M&A		√	√	√		SP0347, SP0348, SP0349, SP0350, SP0351

Zimbabwe	INFINITI QX80	Z62	2016.9-	Engine	√	√	√	√	AC0004, AC0005, AC0006, AC0007, AC0008, AC0009, AC0034, AC0035, AC0036, AC0037, AC0038, AC0039, AC0040, AC0041, AC0042, AC0049, AC0051, AC0052, AC0053, AC0054, AC0060, AC0061, AC0062, AC0063, AC0065, AC0066, AC0067, AC0068, AC0069, AC0070, AC0131, AC0147, AC0148, AC0149, AC0150, AC0151, AC0152, AC0153, AC0154, AC0155, AC0156, AC0157, AC0158, AC0159, AC0160, AC0161, AC0162, AC0163, AC0164, AC0165, AC0166, AC0167, AC0168, AC0169, AC0170, AC0171, AC0172, AC0173, AC0174, AC0175, AC0176, AC0177, AC0178, AC0179, AC0180, AC0181, AC0182, AC0183, AC0184, AC0185, AC0186, AC0187, AC0188, AC0189, AC0190, AC0191, AC0192, AC0193, AC0194, AC0195, AC0196, AC0197, AC0198, AC0199, AC0200, AC0225, AC0226, AC0229, AC0256, AC0282, AC0283, AC0284, AC0307, AC0351, AC0352, AC0365, AC0366, AC0369, AC0371, AC0372, AC0375, AC0388, AC0389, AC0390, AC0391, AC0392, AC0393, AC0394	SP0001, SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0009, SP0016, SP0017, SP0018, SP0032, SP0033, SP0038, SP0039, SP0043, SP0053, SP0056, SP0057, SP0058, SP0059, SP0060, SP0061, SP0062, SP0063, SP0064, SP0067, SP0074, SP0078, SP0079, SP0080, SP0081, SP0082, SP0085, SP0086, SP0087, SP0100, SP0103, SP0104, SP0105, SP0109, SP0110, SP0111, SP0112, SP0113, SP0114, SP0115, SP0116, SP0140, SP0143, SP0150, SP0152, SP0153, SP0158, SP0159, SP0160, SP0172, SP0173, SP0191, SP0192, SP0200, SP0212, SP0213, SP0216, SP0217, SP0218, SP0219, SP0221, SP0223, SP0237, SP0238, SP0239
Zimbabwe	INFINITI QX80	Z62	2016.9-	Transmission	√	√	√	√	AC0460, AC0461, AC0462, AC0463, AC0464, AC0465, AC0466, AC0467, AC0468, AC0469, AC0470, AC0471, AC0472, AC0473, AC0474	SP0270, SP0274
Zimbabwe	INFINITI QX80	Z62	2016.9-	BCM				√	AC0613, AC0618, AC0663, AC0690, AC0692, AC0702	SP0372, SP0429, SP0471
Zimbabwe	INFINITI QX80	Z62	2016.9-	ABS	√	√	√	√	AC0509, AC0510, AC0514, AC0515, AC0528, AC0529, AC0531, AC0532, AC0533, AC0536	SP0300, SP0313, SP0315
Zimbabwe	INFINITI QX80	Z62	2016.9-	Multi AV	√	√	√	√		SP0503
Zimbabwe	INFINITI QX80	Z62	2016.9-	HVAC	√	√	√	√	AC0808, AC0809	SP0472, SP0473, SP0474, SP0475, SP0477, SP0478, SP0483, SP0484, SP0485, SP0486, SP0487, SP0488
Zimbabwe	INFINITI QX80	Z62	2016.9-	E-SUS	√	√	√	√	AC1031, AC1032, AC1033	SP0585, SP0586, SP0587
Zimbabwe	INFINITI QX80	Z62	2016.9-	Difference lock	√	√	√	√		
Zimbabwe	INFINITI QX80	Z62	2016.9-	Auto drive position	√	√	√	√	AC0945, AC0946, AC0947, AC0948, AC0949, AC0950, AC0951, AC0952, AC0953, AC0954, AC0955	SP0541, SP0542, SP0543
Zimbabwe	INFINITI QX80	Z62	2016.9-	Auto back door	√	√	√	√		
Zimbabwe	INFINITI QX80	Z62	2016.9-	Occupant detection			√	√		SP0584
Zimbabwe	INFINITI QX80	Z62	2016.9-	Adaptive light	√	√	√	√	AC0978, AC0979, AC0980, AC0981, AC0982	SP0561, SP0562
Zimbabwe	INFINITI QX80	Z62	2016.9-	Accele pedal ACT	√	√	√	√	AC1029, AC1030	
Zimbabwe	INFINITI QX80	Z62	2016.9-	Sonar	√	√	√	√	AC0966, AC0967, AC0968	SP0557
Zimbabwe	INFINITI QX80	Z62	2016.9-	All mode AWD/4WD	√	√	√	√		SP0544, SP0545, SP0546, SP0547, SP0548, SP0549
Zimbabwe	INFINITI QX80	Z62	2016.9-	Precrash seatbelt	√	√	√	√		SP0612
Zimbabwe	INFINITI QX80	Z62	2016.9-	AVM	√	√	√	√	AC0985, AC0986, AC0987, AC0988, AC0989	SP0563, SP0564, SP0565, SP0566, SP0567
Zimbabwe	INFINITI QX80	Z62	2016.9-	CAN gateway	√	√	√			
Zimbabwe	INFINITI QX80	Z62	2016.9-	Lane camera	√	√	√	√	AC0971, AC0972, AC0973, AC0974, AC0975, AC0976, AC0977	SP0560
Zimbabwe	INFINITI QX80	Z62	2016.9-	BSW/buzzer	√	√	√	√	AC1014, AC1015, AC1016, AC1017, AC1018, AC1019, AC1020, AC1021	
Zimbabwe	INFINITI QX80	Z62	2016.9-	Side radar left	√	√	√	√	AC1025	SP0582
Zimbabwe	INFINITI QX80	Z62	2016.9-	Telematics	√	√	√	√		SP0590, SP0591, SP0592
Zimbabwe	INFINITI QX80	Z62	2016.9-	HIGH BEAM ASSIST	√	√	√	√		
Zimbabwe	INFINITI QX80	Z62	2016.9-	Side radar right	√	√	√	√	AC1026	SP0583
Zimbabwe	INFINITI QX80	Z62	2016.9-	Vehicle data transmitter	√	√	√	√		
Zimbabwe	INFINITI QX80	Z62	2016.9-	ICC/ADAS 2	√	√	√	√		
Zimbabwe	INFINITI QX80	Z62	2016.9-	Air levelizer	√	√	√	√	AC0991, AC0992, AC0993	

XTOOL

Actuation Test

Index NO.	Functions Name	System Name
AC0001	AIR CONDITIONING COMPRESSOR RELAY CONTROL	Engine
AC0002	FUEL PUMP	Engine
AC0003	EGR VALVE	Engine
AC0004	SCB/V CONT SOL/V	Engine
AC0005	GLOW RLY	Engine
AC0006	SWIRL CONT S/V1	Engine
AC0007	COOLING FAN	Engine
AC0008	EGR/V ANGLE	Engine
AC0009	TC BOOST CONT/V	Engine
AC0010	TURBOCHARGER CNTRL SOL/V	Engine
AC0011	IDLE SPEED SET INCREMENT	Engine
AC0012	FUEL PRESSURE SOLENOID/V	Engine
AC0013	High pres circuit leak test	Engine
AC0014	FUEL FLOW SOLENOID/V	Engine
AC0015	CANISTER BLEED SOLENOID VALVE	Engine
AC0016	THERMOPLUNGER RELAY NO.1	Engine
AC0017	COOLANT TEMPERATURE WARNING LIGHT	Engine
AC0018	FUEL PUMP RELAY CIRC	Engine
AC0019	FUEL FLOW REGULATOR	Engine
AC0020	TURBOCHARGING SOLENOID VALVE	Engine
AC0021	High pressure circuit leak test	Engine
AC0022	FUEL PRESSURE SOLENOID VALVE	Engine
AC0023	PRESSURE REGULATION ADAPTIVES	Engine
AC0024	INJECTOR CYLINDER 4	Engine
AC0025	INJECTOR CYLINDER 3	Engine
AC0026	INJECTOR CYLINDER 2	Engine
AC0027	INJECTOR CYLINDER 1	Engine
AC0028	EXHAUST FUEL INJECTOR	Engine
AC0029	HEATER PLUG4	Engine
AC0030	DIAG CAP TEMP DPF	Engine
AC0031	AC COMPRESSOR RELAY	Engine
AC0032	HEATER PLUG1 AND 2	Engine
AC0033	HEATER PLUG3	Engine
AC0034	THRTL POSITION	Engine
AC0035	IGNITION TIMING	Engine
AC0036	FAN DUTY CONTROL	Engine
AC0037	ALTERNATOR DUTY	Engine
AC0038	SATUCLR	Engine
AC0039	EGRPOSCLR	Engine
AC0040	TP POS LEARN CLR	Engine
AC0041	EGR/V ANGLE	Engine
AC0042	THRTL POSITION	Engine
AC0043	AIR INLET FLAP	Engine
AC0044	FUEL SPLY PREV	Engine
AC0045	PREHEATER RELAY	Engine
AC0046	STP E/CCONSUM PREV	Engine
AC0047	STP FUEL SPLY PREV	Engine
AC0048	REFILLING NEW PUMP BODY	Engine
AC0049	TARGET ETC ANGLE	Engine
AC0050	AIR INLET FLAP	Engine
AC0051	TCVACTK	Engine
AC0052	TUMBLE CONTROL VALVE	Engine
AC0053	VIAS S/V-2	Engine
AC0054	TRG EGR/V ANGLE	Engine
AC0055	Commande privee 2	Engine
AC0056	Commande privee 3	Engine
AC0057	ADDITIONAL HEATING	Engine
AC0058	EGR BYPASS	Engine
AC0059	PUMP PRESSURE REGULATOR	Engine
AC0060	VVL S/V	Engine
AC0061	FUEL CUT VALVE	Engine
AC0062	TARGET FAN RPM	Engine
AC0063	AIR COND RLY	Engine
AC0064	STARTER RELAY	Engine
AC0065	SCB/V CONT SOL/V	Engine
AC0066	INT V/T ASSIGN ANGLE	Engine
AC0067	EXH V/T ASSIGN ANGLE	Engine
AC0068	INTAKE DUCT S/V	Engine
AC0069	PRES REGULATOR	Engine
AC0070	POWER BALANCE	Engine
AC0071	STATIC TEST OF ACTUATOR	Engine
AC0072	INJECTION FAULT LIGHT	Engine
AC0073	OVERHEAT WARN LIGHT	Engine
AC0074	MAJOR INJE FAULT W/L	Engine
AC0075	PREHEATER RLY	Engine
AC0076	THERMOPLUNGER RLY N-1	Engine
AC0077	Fan unit high speed rly	Engine

XTOOL

AC0078	FUEL PUMP RLY	Engine
AC0079	CANISTER BLEED SOL/V	Engine
AC0080	SWIRL FLAP	Engine
AC0081	THERMOPLUNGER RLY N-2	Engine
AC0082	PREHEATER LIGHT	Engine
AC0083	Fan unit low speed rly	Engine
AC0084	OBD LIGHT	Engine
AC0085	THERMOPLNGR RLY N2	Engine
AC0086	INLET FLAP	Engine
AC0087	EGR VALVE	Engine
AC0088	LOW PRESS PUMP RLY	Engine
AC0089	A/C PREVENTION	Engine
AC0090	THERMOPLNGER 3 RLY	Engine
AC0091	EGR VALVE	Engine
AC0092	THERMOPLNGR RLY N1	Engine
AC0093	FUEL PRESS SOL/V	Engine
AC0094	BOOST PRESS WASTEGATE	Engine
AC0095	THERMOPLUNGER NO3 RLY	Engine
AC0096	OBD LIGHT	Engine
AC0097	OV/HT WARNING	Engine
AC0098	FAN UT HI SPD	Engine
AC0099	FAN UNIT LOW	Engine
AC0100	A/C CNT COMP	Engine
AC0101	DOWN/ST O2 HT	Engine
AC0102	UP/ST O2 HTR	Engine
AC0103	RAIL PRESSURE	Engine
AC0104	Unlock INJECTOR CTRL	Engine
AC0105	THERMOPLUNGER RLY2	Engine
AC0106	A/C COMPRESSOR	Engine
AC0107	OVERHEATING W/L	Engine
AC0108	INJECTION FAULT LIGHT	Engine
AC0109	lock INJECTOR CTRL	Engine
AC0110	HIGH PRESSURE PUMP	Engine
AC0111	THERMOPLUNGER RLY1	Engine
AC0112	THERMO NO. 3 RELAY	Engine
AC0113	PREHEATER LIGHT	Engine
AC0114	INJECTOR CYLINDER4	Engine
AC0115	INJECTOR CYLINDER2	Engine
AC0116	Fan unit h SPD rly	Engine
AC0117	EGR SOLENOID VALVE	Engine
AC0118	P/S STRG UNIT RLY	Engine
AC0119	M INJECTION FAULT W/L	Engine
AC0120	OBD LIGHT	Engine
AC0121	PRHT RLY GROUP N-1	Engine
AC0122	INJECTOR CYLINDER3	Engine
AC0123	INJECTOR CYLINDER1	Engine
AC0124	Fan unit s SPD rly	Engine
AC0125	PRE ELEC CONSUM	Engine
AC0126	RAIL PRESS REG	Engine
AC0127	PREHEATER UNIT	Engine
AC0128	DAMPER FLAP	Engine
AC0129	TURBO SOL VALVE	Engine
AC0130	STARTER RELAY	Engine
AC0131	PUMP LEANT CLEAR	Engine
AC0132	MOTORISED THROTTLE	Engine
AC0133	lock INJECTOR CTRL	Engine
AC0134	MOTORISED THROTTLE	Engine
AC0135	Unlock INJECTOR CTRL	Engine
AC0136	FAULT WARNING LIGHT	Engine
AC0137	FUEL PUMP	Engine
AC0138	EGR SOLENOID VALVE	Engine
AC0139	THERMO NO. 3 RELAY	Engine
AC0140	FAN UNIT HIGH SPEED	Engine
AC0141	FAN UNIT LOW SPEED	Engine
AC0142	BOILER RELAY	Engine
AC0143	EGR VALVE PROGRAMMING	Engine
AC0144	A/C COMPRESSOR	Engine
AC0145	STATIC TEST	Engine
AC0146	High press circ leak t	Engine
AC0147	FFD CLEAR	Engine
AC0148	EGR CONT(MODE 1)	Engine
AC0149	EGR CONT(MODE 3)	Engine
AC0150	EGR VOL CONT/V	Engine
AC0151	SWIRL CONT S/V 2	Engine
AC0152	GLOW RLY 2	Engine
AC0153	FUEL CUT SOL/V	Engine
AC0154	VVL S/V(INTAKE)	Engine
AC0155	TURBOCHARGE PRES	Engine
AC0156	FUEL/T TEMP SEN	Engine
AC0157	ETC-ISC CRCT VLU	Engine

XJOL

AC0158	off acceleration position signal	Engine
AC0159	SWIRL CONT S/V 1	Engine
AC0160	ETC'LEARN	Engine
AC0161	GLOW RLY	Engine
AC0162	POWER BALANCE(MODE 1)	Engine
AC0163	EGR SOL/V B	Engine
AC0164	IGN TIMING(MODE3)	Engine
AC0165	EGR SOL/V A	Engine
AC0166	MAP/BARO SW/V	Engine
AC0167	THL CONT/SOL-V A	Engine
AC0168	FPCM	Engine
AC0169	INTER COOLER PUMP	Engine
AC0170	CUCOND	Engine
AC0171	TGT IDL ar LARN CLR	Engine
AC0172	POWER BALANCE(MODE 3)	Engine
AC0173	INJECTION TIMING	Engine
AC0174	IGN TIMING(MODE1)	Engine
AC0175	THL CONT/SOL-V B	Engine
AC0176	INJ TIMING	Engine
AC0177	INTER COOLER FAN	Engine
AC0178	TARGET A/F RATIO	Engine
AC0179	TARGET IDLE RPM	Engine
AC0180	Engine MOUNTING	Engine
AC0181	COOLING FAN	Engine
AC0182	PURG VOL CONT/V	Engine
AC0183	VIAS S/V-1	Engine
AC0184	IGNITION TIMING	Engine
AC0185	EGRC SOLENOID VALVE	Engine
AC0186	POWER BALANCE	Engine
AC0187	ENG COOLANT TEMP	Engine
AC0188	SWIRL CONT SOL VALVE	Engine
AC0189	VALVE TIMING SOL	Engine
AC0190	P/REG CONT SOL/V	Engine
AC0191	IACV-AAC/V OPENING	Engine
AC0192	FUEL PUMP RELAY	Engine
AC0193	FUEL INJECTION	Engine
AC0194	VENT CONTROL/V	Engine
AC0195	AIR COND RLY	Engine
AC0196	V/T ASSIGN ANGLE	Engine
AC0197	VC/V BYPASS/V	Engine
AC0198	PRES REGULATOR	Engine
AC0199	EGR VOL CONT/V	Engine
AC0200	SWIRL CONTROL VALVE	Engine
AC0201	DEF Line Heater Test	Engine
AC0202	DEF Dosing Unit Override Test	Engine
AC0203	DEF Tank Heater Test	Engine
AC0204	Fuel System Leakage Test	Engine
AC0205	DEF System Leak Test	Engine
AC0206	RTCV Hysteresis Test	Engine
AC0207	Electric Fan Override Test	Engine
AC0208	Fuel Supply Pump Override Test	Engine
AC0209	FUEL HEATER	Engine
AC0210	AIR INLET CONTROL FLAP ON FRONT END PANEL	Engine
AC0211	CBV Position Override	Engine
AC0212	LOW PRESSURE FUEL PUMP	Engine
AC0213	ACTIVE GRILLE AIR SHUTTER	Engine
AC0214	Check exhaust gas recirculation actuator.	Engine
AC0215	ENGINE OIL PRESSURE CONTROL SOLENOID VALVE	Engine
AC0216	HEATED OXYGEN SENSOR 1 HEATER	Engine
AC0217	INTAKE VALVE TIMING CONTROL SOLENOID VALVE	Engine
AC0218	EVAP CANISTER PURGE CONTROL SOLENOID VALVE	Engine
AC0219	THERMOSTAT HEATER CONTROL SOLENOID VALVE	Engine
AC0220	HEATED OXYGEN SENSOR 2 HEATER	Engine
AC0221	TC WASTEGATE CONTROL SOLENOID VALVE	Engine
AC0222	FUEL PUMP RELAY	Engine
AC0223	ELECTRIC THROTTLE CONTROL ACTUATOR	Engine
AC0224	EXHAUST VALVE TIMING CONTROL SOLENOID VALVE	Engine
AC0225	EGR CONTROL VALVE	Engine
AC0226	WASTEGATE ACTUATOR	Engine
AC0227	FUEL HEATER RELAY	Engine
AC0228	ELECTRIC WATER PUMP	Engine
AC0229	TC BYPASS VALVE	Engine
AC0230	EGR COOLER BYPASS VALVE	Engine
AC0231	FUEL INJECTOR	Engine
AC0232	FUEL PUMP	Engine
AC0233	FUEL PUMP RELAY	Engine
AC0234	PTC 1	Engine
AC0235	PTC 3	Engine
AC0236	TURBOCHARGER BOOST PRESSURE	Engine
AC0237	EGR VOLUME CONTROL VALVE	Engine

AC0238	THERMO PLUNGER	Engine
AC0239	IDLE SPEED	Engine
AC0240	PTC 2	Engine
AC0241	FUEL FLOW ACTUATOR	Engine
AC0242	COOLANT FLOW VALVE	Engine
AC0243	THROTTLE VALVE	Engine
AC0244	EGR COOLER BYPASS PWM	Engine
AC0245	TC COOLING WATER PUMP	Engine
AC0246	EGR COOLER BYPASS VALVE	Engine
AC0247	A/C COMPRESSOR	Engine
AC0248	FUEL RAIL PRESSURE	Engine
AC0249	GLOW PLUG	Engine
AC0250	COOLING FAN 1	Engine
AC0251	A/F SENSOR HEATER	Engine
AC0252	EXHAUST THROTTLE	Engine
AC0253	INTAKE MANIFOLD RUNNER VALVE	Engine
AC0254	EXHAUST FUEL INJECTOR	Engine
AC0255	COOLING FAN 2	Engine
AC0256	ENGINE COOLANT ELECTIC WATER PUMP	Engine
AC0257	CAMSHAFT DEPHASER: SOLENOID VALVE SLIDE MOVEMENT	Engine
AC0258	IGNITION CYLINDER 4	Engine
AC0259	IGNITION CYLINDER 3	Engine
AC0260	IGNITION CYLINDER 1	Engine
AC0261	EXHAUST CAMSHAFT DEPHASER SOLENOID VALVE	Engine
AC0262	IGNITION CYLINDER 2	Engine
AC0263	DRAIN CUT VALVE	Engine
AC0264	Check DPF regeneration heater booster control unit	Engine
AC0265	Check cylinder fuel injectors for leaks	Engine
AC0266	Check radiator shutters actuator	Engine
AC0267	Check intake camshaft valve lift switching actuator	Engine
AC0268	VENT LINE HEATING ELEMENT	Engine
AC0269	HEAT EXCHANGER SHUTOFF VALVE	Engine
AC0270	Check EGR valve hall sensor	Engine
AC0271	Check purging pressure control	Engine
AC0272	Check EGR actuator	Engine
AC0273	Check boost pressure regulator	Engine
AC0274	Boost pressure control pressure transducer	Engine
AC0275	Rail pressure reduction	Engine
AC0276	Wide open throttle operation vent line heating element	Engine
AC0277	Partial load operation crankcase ventilation valve	Engine
AC0278	CAMSHAFT SENSOR PROGRAMMING	Engine
AC0279	SECOND EGR COOLING PUMP	Engine
AC0280	FIRST EGR COOLING PUMP	Engine
AC0281	STARTER RELAY COMMAND	Engine
AC0282	SUPERCHARGER CLUTCH RELAY	Engine
AC0283	TC/SC BYPASS VALVE	Engine
AC0284	TC/SC BYPASS VALVE	Engine
AC0285	LOW PRESSURE EGR VALVE	Engine
AC0286	EXHAUST E/THROTTLE CONTROL ACTUATOR	Engine
AC0287	LOW PRESSURE EGR VALVE	Engine
AC0288	FUEL PUMP	Engine
AC0289	SWIRL FLAP	Engine
AC0290	PROGRAMMING THROTTLE LIMITS	Engine
AC0291	RICHNESS REGULATION PROGRAMMING	Engine
AC0292	Speed limiter / cruise control activation	Engine
AC0293	STABILISED VOLTAGE REGULATOR	Engine
AC0294	PROPORTIONAL RICHNESS SENSOR HEATING	Engine
AC0295	THERMOPLUNGER RELAY NO.2	Engine
AC0296	Air conditioning compressor relay control	Engine
AC0297	DOWNSTREAM OXYGEN SENSOR HEATING	Engine
AC0298	DOWNSTREAM OXYGEN SENSOR HEATING	Engine
AC0299	LOW PRESSURE EGR VALVE	Engine
AC0300	EXHAUST AIR FLAP	Engine
AC0301	COOLANT CIRC SWITCHING S/V	Engine
AC0302	STOP ELECTRICAL CONSUMER PREVENTION	Engine
AC0303	Additional petrol circuit solenoid valve	Engine
AC0304	ADDITIONAL FUEL PUMP RELAY	Engine
AC0305	Major injection malfunction warning lamp	Engine
AC0306	STARTER RELAY	Engine
AC0307	FUEL PUMP CONTROL MODULE	Engine
AC0308	Check engine oil pump valve	Engine
AC0309	Check engine diagnosis indicator lamp	Engine
AC0310	CHECK RADIATOR SHUTTERS ACTUATOR	Engine
AC0311	CHECK GLOW PLUGS	Engine
AC0312	CHECK RAIL PRESSURE SENSOR	Engine
AC0313	Check o2 upstream of catalytic converter	Engine
AC0314	Check oil spray nozzles shutoff valve	Engine
AC0315	Check egr cooler bypss SW over valve	Engine
AC0316	Dynamic test quantity control valve	Engine
AC0317	Ck eng and ac with intgrted cont fan motor	Engine

AC0318	Dynamic test pressure regulating valve	Engine
AC0319	CHECK FUEL FILTER HEATER	Engine
AC0320	Check intake port shutoff actuator motor	Engine
AC0321	CHECK PREGLOW SYSTEM	Engine
AC0322	Check tm oil clng clnt circulation pump	Engine
AC0323	Rail pressure sensor offset test	Engine
AC0324	Check cylinder 1 glow plug	Engine
AC0325	CHECK BOOST PRESSURE POSITIONER	Engine
AC0326	Check fuel hi press circ for leaktightness	Engine
AC0327	CHECK THROTTLE VALVE ACTUATOR	Engine
AC0328	CHECK COOLANT PUMP SWITCHOVER VALVE	Engine
AC0329	Check deceleration air switchover valve	Engine
AC0330	CHECK PURGING SWITCHOVER VALVE	Engine
AC0331	CHECK INTAKE CAMSHAFT SOLENOID	Engine
AC0332	CHECK EXHAUST CAMSHAFT SOLENOID	Engine
AC0333	TC BST CONT S/V	Engine
AC0334	FUEL PUMP	Engine
AC0335	Egr cooler bypass cont s/v	Engine
AC0336	FRP CONTROL VALVE	Engine
AC0337	TROTTLE VALVE	Engine
AC0338	GLOW CONTROL UNIT	Engine
AC0339	TURBOCHARGER COOLING PUMP	Engine
AC0340	RAIL PRESSURE REGULATOR	Engine
AC0341	FLYWHL TGT PG	Engine
AC0342	UPSTREAM O2 SENSOR HEATING	Engine
AC0343	DOWNSTREAM O2 SENSOR HEATING	Engine
AC0344	A/C compressor relay control	Engine
AC0345	PRPRT RCH SEN HT	Engine
AC0346	EGR BYPASS	Engine
AC0347	ADDITIONAL HEATING	Engine
AC0348	ENGINE ADAPTIVES	Engine
AC0349	PUMP PRESSURE REGULATOR	Engine
AC0350	MIL LIGHT	Engine
AC0351	SUB FUEL PUMP RELAY	Engine
AC0352	SUB FUEL CONT SOL/V	Engine
AC0353	Additional petrol circuit S/V	Engine
AC0354	CAM/S DEPHASER: NORM CTRL	Engine
AC0355	WATER PUMP RELAY	Engine
AC0356	32696	Engine
AC0357	CONTROLLED CL THERMOS	Engine
AC0358	Water in fuel warning light	Engine
AC0359	HEATING RESISTOR RELAY 1	Engine
AC0360	HEATING RESISTOR RELAY 3	Engine
AC0361	HEATING RESISTOR RELAY 2	Engine
AC0362	PREVENTION ELECTRICAL CNSMERS	Engine
AC0363	Flex-fuel additional pump	Engine
AC0364	Flex-fuel additional solenoid valve	Engine
AC0365	ALTERNATOR VOLTAGE	Engine
AC0366	AUTO STOP START	Engine
AC0367	COOLING FAN SPEED SENSOR	Engine
AC0368	RAIL PRS SEN ADAPTIVES	Engine
AC0369	ALTERNATOR DUTY	Engine
AC0370	PRPR RICH SEN PROG	Engine
AC0371	TC BOOST CONTROL ACTUATOR	Engine
AC0372	EGR COOLER BYPASS VALVE	Engine
AC0373	ALTERNATOR DUTY	Engine
AC0374	DPF INJECTOR	Engine
AC0375	FUEL RETURN VALVE	Engine
AC0376	AFTER DPF REGENERATION	Engine
AC0377	AFTER DPF REPLACEMENT	Engine
AC0378	INJECTION SOL/V OPENING PF	Engine
AC0379	E/O CC/SL PRGRM	Engine
AC0380	CC/SL PRGRM	Engine
AC0381	EXHAUST FUEL INJECTOR CIRCUIT	Engine
AC0382	INJECTOR ADAPTIVES	Engine
AC0383	DPF INJECTOR SOLENOID VALVE	Engine
AC0384	AIR DAMPER VALVE PROGRAMMING	Engine
AC0385	AIR PATH PROGRAMMING	Engine
AC0386	DPF RELATIVE PRESSURE SENSOR	Engine
AC0387	AVERAGE AIR TEMPERATURE	Engine
AC0388	FP RELAY 3	Engine
AC0389	FP RELAY 2	Engine
AC0390	FUEL SHUTOFF VALVE	Engine
AC0391	FUEL SHUTOFF VALVE 2	Engine
AC0392	FUEL SHUTOFF VALVE 3	Engine
AC0393	FUEL SHUTOFF VALVE 1	Engine
AC0394	COOLING FAN	Engine
AC0395	DIFFERENTIAL SOLENOID VALVE	Transmission
AC0396	VALVE ACTIVATION TEST	Transmission
AC0397	Display	Transmission

AC0398	CLUTCH OPRATION TEST	Transmission
AC0399	GEAR ENGAGE TEST	Transmission
AC0400	Display	Transmission
AC0401	Bleed clth slv cyl hyd	Transmission
AC0402	HYD ASSY PUMP RESTORED	Transmission
AC0403	Bld cltch circ phase 1	Transmission
AC0404	G/B RETURN TO NEUTRAL	Transmission
AC0405	STARTING RELAY	Transmission
AC0406	HYD ASSY PUMP PROHIBIT	Transmission
AC0407	BLD HYD PRESS ASSY	Transmission
AC0408	CLUTCH SOLENOID VALVE	Transmission
AC0409	HYDRAULIC PUMP RELAY	Transmission
AC0410	PRESS ACCUM DISCHARGE	Transmission
AC0411	SELECTION SOL/V	Transmission
AC0412	ENGAGING SOL/V	Transmission
AC0413	Bld cltch circ phase 2	Transmission
AC0414	REVERSING LIGHTS	Transmission
AC0415	ENGAGE REVERSE GEAR	Transmission
AC0416	ACT SEQUENTIAL CTRL	Transmission
AC0417	PRESSURE CONTROL SOL C	Transmission
AC0418	PRESSURE CONTROL SOL B	Transmission
AC0419	Shift SOLENOID E	Transmission
AC0420	Shift SOLENOID C	Transmission
AC0421	Shift SOLENOID A	Transmission
AC0422	PRESSURE CONTROL SOL A	Transmission
AC0423	Shift SOLENOID D	Transmission
AC0424	Shift SOLENOID B	Transmission
AC0425	Display	Transmission
AC0426	clutch solenoid valve	Transmission
AC0427	HYDRAULIC PUMP RELAY	Transmission
AC0428	CLUTCH EXHAUST SERVICE	Transmission
AC0429	ENGAGEMENT 1ST	Transmission
AC0430	PROG CLUTCH TOUCHP	Transmission
AC0431	ENGAGEMENT 5TH	Transmission
AC0432	ENGAGEMENT 3RD	Transmission
AC0433	CLUTCH MOVING TEST	Transmission
AC0434	ENGAGEMENT 6TH	Transmission
AC0435	ENGAGEMENT 4TH	Transmission
AC0436	ENGAGEMENT 2ND	Transmission
AC0437	FAN UNIT	Transmission
AC0438	PRESSURE ACCUMULATOR DISCHARGE	Transmission
AC0439	Cvt oil cooler fan circuit	Transmission
AC0440	SOLENOID VALVE SELECTION	Transmission
AC0441	BLEED HYDRAULIC PRESSURE ASSEMBLY	Transmission
AC0442	Bleed clutch circuit phase 1	Transmission
AC0443	HYDRAULIC ASSEMBLY PUMP PROHIBITION	Transmission
AC0444	ENGAGING SOLENOID VALVES	Transmission
AC0445	Bleed clutch circuit phase 2	Transmission
AC0446	HYDRAULIC ASSEMBLY PUMP RESTORED	Transmission
AC0447	Shift TRANSMISSION TO NEUTRAL	Transmission
AC0448	Bleeding clutch slave cyl hydraulic circ	Transmission
AC0449	ACTUATORS SEQUENTIAL CONTROL	Transmission
AC0450	SEQUENCE SOLENOID VALVE 4	Transmission
AC0451	SEQUENCE 2 SOLENOID VALVE	Transmission
AC0452	CONVERTER lock-UP SOLENOID VALVE	Transmission
AC0453	Heat exchanger flow solenoid valve	Transmission
AC0454	SEQUENCE SOLENOID VALVE 6	Transmission
AC0455	SEQUENCE SOLENOID VALVE 3	Transmission
AC0456	SEQUENCE 1 SOLENOID VALVE	Transmission
AC0457	SELECTOR LEVER lockING ELECTROMAGNET	Transmission
AC0458	MODULATION SOLENOID VALVE	Transmission
AC0459	SEQUENCE SOLENOID VALVE 5	Transmission
AC0460	TCM RELAY	Transmission
AC0461	STARTER RELAY	Transmission
AC0462	Shift S/V 2	Transmission
AC0463	Shift lock SOL	Transmission
AC0464	REVERSE LAMP RELAY	Transmission
AC0465	B-AXIS SUPPLY PRESSURE S/V	Transmission
AC0466	A-AXIS SUPPLY PRESSURE S/V	Transmission
AC0467	C/L A PRESS S/V	Transmission
AC0468	LINE PRESS S/V	Transmission
AC0469	Shift S/V 4	Transmission
AC0470	Shift S/V 1	Transmission
AC0471	LUBRICATION FLOW-RATE S/V	Transmission
AC0472	C/L B PRESS S/V	Transmission
AC0473	SEQUENCE S/V	Transmission
AC0474	Shift S/V 3	Transmission
AC0475	Wheel speed sensors supply test	ABS
AC0476	FR l/h wheel solenoid valves	ABS
AC0477	RR l/h wheel solenoid valves	ABS

AC0478	FR r/h wheel solenoid valves	ABS
AC0479	RR r/h wheel solenoid valves	ABS
AC0480	MAIN RELAY 2	ABS
AC0481	SLA FR SOL	ABS
AC0482	SLA FL SOL	ABS
AC0483	MOTOR RELAY 2	ABS
AC0484	AIR REL INHIBIT	ABS
AC0485	SLR FR SOL	ABS
AC0486	SLR FL SOL	ABS
AC0487	MOTOR RELAY 1	ABS
AC0488	SLA RR SOL	ABS
AC0489	SLA RL SOL	ABS
AC0490	ELE BRK WARN LAMP	ABS
AC0491	ABS WARN LAMP	ABS
AC0492	MAIN RELAY 1	ABS
AC0493	SLIP INDI LAMP	ABS
AC0494	SLR RR SOL	ABS
AC0495	SLR RL SOL	ABS
AC0496	VDC WARN LAMP	ABS
AC0497	Brake WARN LAMP	ABS
AC0498	STOP LAMP ON RELAY	ABS
AC0499	Air rel pwr sply 2	ABS
AC0500	AIR REL DRAIN	ABS
AC0501	Brake BUZZER	ABS
AC0502	ACC 0 DOWN	ABS
AC0503	AIR REL STROKE SIM	ABS
AC0504	SCSS	ABS
AC0505	SMC1	ABS
AC0506	SMC2	ABS
AC0507	SLIP LAMP	ABS
AC0508	FRONT ABS SOLENOID(ACT)	ABS
AC0509	RR RH ABS SOLENOID(ACT)	ABS
AC0510	FR RH ABS SOLENOID(ACT)	ABS
AC0511	ASCD SIGNAL	ABS
AC0512	ABS WARNING LAMP	ABS
AC0513	REAR ABS SOLENOID(ACT)	ABS
AC0514	RR LH ABS SOLENOID(ACT)	ABS
AC0515	FR LH ABS SOLENOID(ACT)	ABS
AC0516	TCS FAIL SIGNAL	ABS
AC0517	VDC WARNING LAMP	ABS
AC0518	BLEED FRONT L/H WHEEL	ABS
AC0519	BLEED FRONT R/H WHEEL	ABS
AC0520	VHCL SPD INFOMTION	ABS
AC0521	BLEED FRONT L/H WHEEL	ABS
AC0522	BLEED FRONT R/H WHEEL	ABS
AC0523	BLEED REAR R/H WHEEL	ABS
AC0524	PUMP MOTOR TEST	ABS
AC0525	BLEED REAR L/H WHEEL	ABS
AC0526	VEHICLE SPEED INFORMATION	ABS
AC0527	BOOSTER DRIVE	ABS
AC0528	ABS MOTOR	ABS
AC0529	RR RH SOL	ABS
AC0530	REAR SOL	ABS
AC0531	RR LH SOL	ABS
AC0532	FR LH SOL	ABS
AC0533	FR RH SOL	ABS
AC0534	FRONT SOLENOID	ABS
AC0535	REAR SOLENOID	ABS
AC0536	STOP LAMP ON RELAY	ABS
AC0537	REQUEST TO SWITCH ON HAZARD WARNING LAMPS	ABS
AC0538	REFERENCE ENGINE TORQ	ABS
AC0539	Flh wheel solenoid valve test	ABS
AC0540	Rrh wheel solenoid valve test	ABS
AC0541	Rlh wheel solenoid valve test	ABS
AC0542	Frh wheel solenoid valve test	ABS
AC0543	STOP PUMP MOTOR	ABS
AC0544	STOP LIGHTS ACTIVATION RELAY	ABS
AC0545	PASS AIR BAG FAULT AND STATUS WARNING LIGHTS	Air bag
AC0546	Control unit reset	Meter/M&A
AC0547	Instrument illumination	Meter/M&A
AC0548	Mechanical instrument pointers	Meter/M&A
AC0549	Warning buzzer	Meter/M&A
AC0550	BUZZER	Meter/M&A
AC0551	LEFT INDICATOR	Meter/M&A
AC0552	THEFT-WARNING RELAY	Meter/M&A
AC0553	BATTERY SAVER RELAY	Meter/M&A
AC0554	FOLDING MIRROR	Meter/M&A
AC0555	Commande privee 6	Meter/M&A
AC0556	Commande privee 4	Meter/M&A
AC0557	Commande privee 2	Meter/M&A

AC0558	INTERIOR LIGHTING	Meter/M&A
AC0559	HORN	Meter/M&A
AC0560	DOOR lock	Meter/M&A
AC0561	POWER WINDOWS	Meter/M&A
AC0562	REV COUNTER	Meter/M&A
AC0563	Commande privee 5	Meter/M&A
AC0564	SPEEDOMETER	Meter/M&A
AC0565	Commande privee 3	Meter/M&A
AC0566	WATER TEMPERATURE GAUGE	Meter/M&A
AC0567	Commande privee 1	Meter/M&A
AC0568	OTHER DOOR Unlock	Meter/M&A
AC0569	RIGHT-HAND INDICATOR	Meter/M&A
AC0570	LCD INSTRUMENT SEGMENTS	Meter/M&A
AC0571	FUEL GAUGE	Meter/M&A
AC0572	SELECTLEV lock ELECMAG	Meter/M&A
AC0573	DRIVER DOOR Unlock	Meter/M&A
AC0574	INPANE WARNING LIGHT	Meter/M&A
AC0575	TAIL LAMP	Meter/M&A
AC0576	DOOR lockING LAMP	Meter/M&A
AC0577	REAR SCREEN DEMISTER	Meter/M&A
AC0578	TRUNK OPEN	Meter/M&A
AC0579	UNLOCKING TAILGATE/LUGGAGE COMPARTMENT	BCM
AC0580	Headlamp clean system pump	BCM
AC0581	Unlocking the doors and boot	BCM
AC0582	DRIVER'S DOOR UnlockING	BCM
AC0583	ENG IMMOBILISER LIGHT	BCM
AC0584	ENG IMMOBILISER WARNING LIGHT	BCM
AC0585	MIRROR+5	BCM
AC0586	LOW BEAM TEST LEFT	BCM
AC0587	LEVELIZER TEST	BCM
AC0588	LOW BEAM TEST RIGHT	BCM
AC0589	ST CONT LOW	BCM
AC0590	IGN CONT1	BCM
AC0591	IGN CONT2	BCM
AC0592	SL 12V CPU	BCM
AC0593	KEY SLOT ILLUMI	BCM
AC0594	IGNITION ON IND	BCM
AC0595	lock INDICATOR	BCM
AC0596	ACC INDICATOR	BCM
AC0597	ENGINE SW ILLUMI	BCM
AC0598	P RANGE	BCM
AC0599	Brake SW	BCM
AC0600	BUZZER	BCM
AC0601	STARTER CUT RELAY	BCM
AC0602	DR FR WINDOW	BCM
AC0603	ROOF	BCM
AC0604	VALVE	BCM
AC0605	TRUNK	BCM
AC0606	DR RR WINDOW	BCM
AC0607	HYDRAULIC MOTOR	BCM
AC0608	PARCEL SHELF	BCM
AC0609	AS RR WINDOW	BCM
AC0610	AS FR WINDOW	BCM
AC0611	CENTRAL DOOR lockING	BCM
AC0612	IGNITION RELAY	BCM
AC0613	RUN FLAT TIRE W/L	BCM
AC0614	LCD	BCM
AC0615	LEFT INDICATOR	BCM
AC0616	INTERIOR LIGHTING	BCM
AC0617	RIGHT-HAND INDICATOR	BCM
AC0618	RUN FLAT/T WARN BUZZER	BCM
AC0619	HORN	BCM
AC0620	PW REMOTO DOWN SET	BCM
AC0621	DR D/LK MTR	BCM
AC0622	NON DR D/UN	BCM
AC0623	ALL D/LK MTR	BCM
AC0624	HORN	BCM
AC0625	BATTERY SAVER	BCM
AC0626	INT LAMP	BCM
AC0627	REAR DEFOGGER	BCM
AC0628	NON DR D/LK	BCM
AC0629	DR D/UN MTR	BCM
AC0630	THEFT IND	BCM
AC0631	IGN ILLUM	BCM
AC0632	CHIME	BCM
AC0633	ALL D/UN MTR	BCM
AC0634	REVERSE WARNING	BCM
AC0635	FLASHER	BCM
AC0636	SECURTY INDICATOR	BCM
AC0637	RR WIPER	BCM

XTOOL

AC0638	FR WIPER(LOW)	BCM
AC0639	IMMU ANTENNA	BCM
AC0640	FLASHER LEFT(CAN)	BCM
AC0641	IMMU POWER	BCM
AC0642	FLASHER LEFT	BCM
AC0643	FR WIPER(INT)	BCM
AC0644	POWER WINDOW DOWN	BCM
AC0645	FR WIPER(HI)	BCM
AC0646	TRUNK/BACK DOOR	BCM
AC0647	ILL DIM SIGNAL(CAN)	BCM
AC0648	RR FOG LAMP	BCM
AC0649	HEAD LAMP(LOW)	BCM
AC0650	RETAINED PWR(IGN)	BCM
AC0651	FLASHER RIGHT(CAN)	BCM
AC0652	FLASHER RIGHT	BCM
AC0653	HEAD LAMP(HI)	BCM
AC0654	HEAD LAMP	BCM
AC0655	ILL DIM SIGNAL	BCM
AC0656	FR FOG LAMP	BCM
AC0657	TAIL LAMP	BCM
AC0658	RETAINED PWR	BCM
AC0659	IGN KEY WARN ALM	BCM
AC0660	DOOR lock	BCM
AC0661	FR WIPER	BCM
AC0662	A/C INDICATOR	BCM
AC0663	FLASHER	BCM
AC0664	LIGHT WARN ALM	BCM
AC0665	REAR SCREEN WIPER	BCM
AC0666	RAISE DRIVER WINDOW	BCM
AC0667	LOWER DRIVER WINDOW	BCM
AC0668	HEAD LAMP	BCM
AC0669	CORNERING LAMP	BCM
AC0670	HEAD LAMP WASHER	BCM
AC0671	FUEL LID OPEN	BCM
AC0672	OIL PRESSURE SW	BCM
AC0673	ALARM SIREN	BCM
AC0674	REAR DOORS	BCM
AC0675	REAR FOG LIGHTS	BCM
AC0676	DOOR lockING LAMP	BCM
AC0677	FRONT INTERIOR LAMPS	BCM
AC0678	PTC heater	BCM
AC0679	ACC CONT	BCM
AC0680	INDICATOR	BCM
AC0681	OUTSIDE BUZZER	BCM
AC0682	DEADlockING	BCM
AC0683	INSIDE BUZZER	BCM
AC0684	HAZARD LIGHTS LED	BCM
AC0685	REAR INTERIOR LAMPS	BCM
AC0686	PBD	BCM
AC0687	PSD PBD OPEN TEST	BCM
AC0688	STEP LAMP TEST	BCM
AC0689	FLAT TIRE WARNING	BCM
AC0690	WARNING LAMP	BCM
AC0691	LUGGAGE LAMP TEST	BCM
AC0692	Id regist warning	BCM
AC0693	RISE UP WIPER TEST	BCM
AC0694	Power slide door	BCM
AC0695	PANIC ALARM	BCM
AC0696	CORNERING LAMP	BCM
AC0697	GLASS HATCH	BCM
AC0698	Vehicle security horn	BCM
AC0699	DAYTIME RUNNING LIGHT	BCM
AC0700	TRUNK/BACK DOOR	BCM
AC0701	SEAT BELT WARN TEST	BCM
AC0702	HORN	BCM
AC0703	PTC heater	BCM
AC0704	DOOR WARNING IND	BCM
AC0705	REAR DEFOGGER IND	BCM
AC0706	BOOT OPENER	BCM
AC0707	HEAD LAMP WASHER	BCM
AC0708	BACK DR OPEN WARN	BCM
AC0709	DOOR lock IND	BCM
AC0710	SUPER lock	BCM
AC0711	D/UN OUTPUT SIG	BCM
AC0712	KEY REMINDER WARN	BCM
AC0713	KEY REMINDER WARN	BCM
AC0714	D/LK OUTPUT SIG	BCM
AC0715	DTRL	BCM
AC0716	HEAD LAMP WASHER	BCM
AC0717	CARGO LAMP	BCM

XJDJL

AC0718	TRUNK/GLASS HATCH	BCM
AC0719	WARNING LAMP	BCM
AC0720	INDICATOR	BCM
AC0721	IGN KEY WARN ALM	BCM
AC0722	STARTER CUT RELAY	BCM
AC0723	PUSH SWITCH INDICATOR	BCM
AC0724	STOP LAMP 2	BCM
AC0725	PTC RELAY-3	BCM
AC0726	AUTO ACC 2	BCM
AC0727	ENGINE START REQUEST	BCM
AC0728	STOP LAMP 3	BCM
AC0729	STOP LAMP 1	BCM
AC0730	PTC RELAY-2	BCM
AC0731	PTC RELAY-1	BCM
AC0732	AUTOMATIC BACK DOOR	BCM
AC0733	ENGINE START	BCM
AC0734	AUTO ACC 1	BCM
AC0735	UCH --> TRANSPONDER RING CONNECTION TEST	BCM
AC0736	PCHR RELAY 3	BCM
AC0737	REAR WINDOW LOCKING	BCM
AC0738	HEATED RR SCREEN RELAY	BCM
AC0739	Windshield washer system pump	BCM
AC0740	Left rear fog lamp	BCM
AC0741	Running board courtesy light	BCM
AC0742	Liftgate central locking motor	BCM
AC0743	Illuminated door sill moldings	BCM
AC0744	Symbol illumination	BCM
AC0745	Trunk lid emergency opening switch	BCM
AC0746	Right front lamp unit	BCM
AC0747	Right rear power window	BCM
AC0748	Daytime running light	BCM
AC0749	Left rear power window	BCM
AC0750	Ambiance illumination of rear door	BCM
AC0751	Front turn signal lamp	BCM
AC0752	Front fog lamp	BCM
AC0753	Engine compartment fuse and relay module	BCM
AC0754	Trunk lamp	BCM
AC0755	Circuit 30G relay	BCM
AC0756	Spray nozzle hose heater	BCM
AC0757	Inner right rear lamp unit	BCM
AC0758	Back-up lamp	BCM
AC0759	Activate demo mode of exterior lamp	BCM
AC0760	Footwell lamp	BCM
AC0761	Rear fuse box	BCM
AC0762	Right rear lamp unit	BCM
AC0763	Inner left rear lamp unit	BCM
AC0764	Centre brake lamp	BCM
AC0765	Resetting reading of frequency counter	BCM
AC0766	Tank cap central locking actuator	BCM
AC0767	License plate lamp	BCM
AC0768	Left front lamp unit	BCM
AC0769	Erase alarm sources	BCM
AC0770	Left rear lamp unit	BCM
AC0771	STORED ENERGY MANAGEMENT DATA	BCM
AC0772	LOWER DRIVER WINDOW	BCM
AC0773	PCHR RELAY 1	BCM
AC0774	ACCESSORIES RELAY NO. 2	BCM
AC0775	TEMPERATURE DISPLAY	BCM
AC0776	DEADUnlockING	BCM
AC0777	PCHR RELAY 2	BCM
AC0778	INTERIOR LIGHTING	BCM
AC0779	+ access. feed 3 relay	BCM
AC0780	RAISE DRIVER WINDOW	BCM
AC0781	+ access. feed 3 relay	BCM
AC0782	ACCESSORIES RELAY NO. 2	BCM
AC0783	WINDSCREEN WIPER: LOW SPEED	BCM
AC0784	HAZARD WARNING LIGHTS	BCM
AC0785	HEAD LAMP	BCM
AC0786	REAR WIPER	BCM
AC0787	KEYFOB P/W TEST	BCM
AC0788	TRUNK/LUGGAGE LAMP TEST	BCM
AC0789	AS SEAT LAMP TEST	BCM
AC0790	REVERSE LAMP TEST	BCM
AC0791	LUGGAGE COMPARTMENT LIGHTING	BCM
AC0792	REAR DE-ICING INDIC LAMP	BCM
AC0793	KEY REMINDER WARN	BCM
AC0794	REAR SCREEN DE-ICING	BCM
AC0795	WINDSCRN WIPE SLOW SPD	BCM
AC0796	SIREN	BCM
AC0797	CENTRAL lockING KEY LIGHT	BCM

AC0798	RIGHT-HAND INDICATOR	BCM
AC0799	KEYLESS PW UP/DOWN	BCM
AC0800	PUSH SWITCH INDICATOR	BCM
AC0801	RETRACTABLE MIRROR	BCM
AC0802	BCK/TRNK Unlock	BCM
AC0803	BACK/TRNK LCK RLY	BCM
AC0804	INTELLIGENT KEY LINK	BCM
AC0805	INTELLIGENT KEY LINK (CAN)	BCM
AC0806	REMOTE lockING BUZZER	BCM
AC0807	LEFT INDICATER	BCM
AC0808	ALL SEG	HVAC
AC0809	HVAC TEST	HVAC
AC0810	Cooling fan relay	IPDM E/R
AC0811	HORN	IPDM E/R
AC0812	HEAD LAMP WASHER	IPDM E/R
AC0813	DIPPED HEADLIGHTS	IPDM E/R
AC0814	HEAD LAMP	IPDM E/R
AC0815	CORNERING LAMP	IPDM E/R
AC0816	AC COMPRESSOR	IPDM E/R
AC0817	MOTOR FAN	IPDM E/R
AC0818	FRONT WIPER	IPDM E/R
AC0819	HEAD LAMP WASHER	IPDM E/R
AC0820	HORN	IPDM E/R
AC0821	REAR DEFOGGER	IPDM E/R
AC0822	TAIL LAMP	IPDM E/R
AC0823	FRONT FOG LAMP	IPDM E/R
AC0824	REAR FOG LIGHTS	IPDM E/R
AC0825	LAMPS	IPDM E/R
AC0826	FAN UT HI SPD	IPDM E/R
AC0827	FAN UNIT LOW	IPDM E/R
AC0828	A/C CNT COMP	IPDM E/R
AC0829	FAN UNIT HIGH SPEED	IPDM E/R
AC0830	FAN UNIT LOW SPEED	IPDM E/R
AC0831	EXTERNAL LAMPS	IPDM E/R
AC0832	A/C COMPRESSOR	IPDM E/R
AC0833	OPTIC AXIS ACTIVE TEST	IPDM E/R
AC0834	TAIL LAMP	IPDM E/R
AC0835	DAYTIME RUNNING LIGHT	IPDM E/R
AC0836	HORN	IPDM E/R
AC0837	ECV	IPDM E/R
AC0838	PARKING LAMP	IPDM E/R
AC0839	FRONT FOG LAMP	IPDM E/R
AC0840	HEADLAMP (LO)	IPDM E/R
AC0841	COOLING FAN (PWM)	IPDM E/R
AC0842	COOLING FAN (MONO)	IPDM E/R
AC0843	FRONT WIPER	IPDM E/R
AC0844	HEADLAMP (HI)	IPDM E/R
AC0845	COOLING FAN (DUAL)	IPDM E/R
AC0846	COMPRESSOR	IPDM E/R
AC0847	HEADLAMP WASHER	IPDM E/R
AC0848	FRONT FOG LIGHTS	IPDM E/R
AC0849	WINDSCREEN WIPER: LOW SPEED	IPDM E/R
AC0850	ALTERNATOR REGULATION	IPDM E/R
AC0851	WINDSCREEN WIPER: HIGH SPEED	IPDM E/R
AC0852	FRONT FOG LIGHTS	IPDM E/R
AC0853	SIDE LIGHTS	IPDM E/R
AC0854	FAN UNIT	IPDM E/R
AC0855	Electric power supply circuit testing	IPDM E/R
AC0856	HEAD LAMP	IPDM E/R
AC0857	REAR WIPER	IPDM E/R
AC0858	REAR BLOWER RELAY	IPDM E/R
AC0859	HEATER WATER PUMP COMMAND	IPDM E/R
AC0860	VOLTAGE REGULATOR	IPDM E/R
AC0861	REAR SCREEN DE-ICING	IPDM E/R
AC0862	MAIN H/L INF	IPDM E/R
AC0863	STOP LIGHTS ACTIVATION RELAY	IPDM E/R
AC0864	LAMP TEST	Head lamp levelizer
AC0865	ICC BUZZER	ICC/ADAS
AC0866	BOOSTER SOL/V	ICC/ADAS
AC0867	STOP LAMP	ICC/ADAS
AC0868	METER LAMP	ICC/ADAS
AC0869	BSI WARNING INDICATOR	ICC/ADAS
AC0870	LDW WARNING INDICATOR	ICC/ADAS
AC0871	LDW ON INDICATOR	ICC/ADAS
AC0872	BSW ON INDICATOR	ICC/ADAS
AC0873	LDP WARNING INDICATOR	ICC/ADAS
AC0874	LANE DEPARTURE W/L	ICC/ADAS
AC0875	LDP ON IND	ICC/ADAS
AC0876	ACCELERATOR PEDAL ACTUATOR	ICC/ADAS
AC0877	DCA INDICATOR	ICC/ADAS

XJOL

AC0878	LDP BUZZER	ICC/ADAS
AC0879	DCA INDICATOR	ICC/ADAS
AC0880	ACTIVE PEDAL	ICC/ADAS
AC0881	Brake ACTUATOR	ICC/ADAS
AC0882	BSW/BSI WARNING LAMP	ICC/ADAS
AC0883	BSI ON INDICATOR	ICC/ADAS
AC0884	ICC BUZZER	ICC/ADAS
AC0885	WARNING SYSTEM IND	ICC/ADAS
AC0886	SPEAKER TEST	Multi AV
AC0887	DISPLAY TEST	Multi AV
AC0888	CD EJECT	Multi AV
AC0889	AUDIO OUTPUT TONE CONTROL	Multi AV
AC0890	BLUETOOTH DETECTED ON ESPACE	Multi AV
AC0891	NAVIGATION VOICE TEST	Multi AV
AC0892	GPS INFORMATION	Multi AV
AC0893	MICROPHONE TEST	Multi AV
AC0894	HAZARD LAMP	Air pressure monitor
AC0895	BUZZER	Air pressure monitor
AC0896	WARN LAMP	Air pressure monitor
AC0897	RUN FLAT/T WARN BUZZER	Air pressure monitor
AC0898	FLASHER	Air pressure monitor
AC0899	OUTSIDE BUZZER	Air pressure monitor
AC0900	WARNING LAMP	Air pressure monitor
AC0901	Id regist warning	Air pressure monitor
AC0902	HORN	Air pressure monitor
AC0903	MIRROR+5	Intelligent key
AC0904	SL COM K-LINE	Intelligent key
AC0905	ST CONT LOW	Intelligent key
AC0906	IGN CONT1	Intelligent key
AC0907	PDU AWAKE UP	Intelligent key
AC0908	USM RELAY CMD	Intelligent key
AC0909	IGN CONT2	Intelligent key
AC0910	SL 12V CPU	Intelligent key
AC0911	INSIDE BUZZER	Intelligent key
AC0912	SL 12V CONT1	Intelligent key
AC0913	DOOR lock/Unlock	Intelligent key
AC0914	ACC CONT	Intelligent key
AC0915	KEY SLOT ILLUMI	Intelligent key
AC0916	IGNITION ON IND	Intelligent key
AC0917	lock INDICATOR	Intelligent key
AC0918	ESCL CMD	Intelligent key
AC0919	SL 12V CONT2	Intelligent key
AC0920	LCD	Intelligent key
AC0921	ANTENNA	Intelligent key
AC0922	ACC INDICATOR	Intelligent key
AC0923	ENGINE SW ILLUMI	Intelligent key
AC0924	P RANGE	Intelligent key
AC0925	INDICATOR	Intelligent key
AC0926	ANTENNA	Intelligent key
AC0927	INDICATOR	Intelligent key
AC0928	OUTSIDE BUZZER	Intelligent key
AC0929	DOOR lock/Unlock	Intelligent key
AC0930	INSIDE BUZZER	Intelligent key
AC0931	ANTENNA	Intelligent key
AC0932	Key lock solenoid	Intelligent key
AC0933	ANTENNA	Intelligent key
AC0934	INDICATOR	Intelligent key
AC0935	DOOR lock	Intelligent key
AC0936	FR RH external aerial test	Intelligent key
AC0937	EXTERNAL BOOT AERIAL TEST	Intelligent key
AC0938	INTERIOR AERIAL 1 TEST	Intelligent key
AC0939	FR LH external aerial test	Intelligent key
AC0940	INTERIOR AERIAL 2 TEST	Intelligent key
AC0941	CLUTCH	Auto slide door
AC0942	BUZZER	Auto slide door
AC0943	lock RELEASE	Auto slide door
AC0944	SLIDE DOOR	Auto slide door
AC0945	SEAT LIFT	Auto drive position
AC0946	MIRROR MOTOR LH	Auto drive position
AC0947	Memory SW INDCTR	Auto drive position
AC0948	MIRROR MOTOR RH	Auto drive position
AC0949	PEDAL MOTOR	Auto drive position
AC0950	TILT MOTOR	Auto drive position
AC0951	SEAT LIFTER FR	Auto drive position
AC0952	SEAT SLIDE	Auto drive position
AC0953	TELESCO MOTOR	Auto drive position
AC0954	SEAT LIFTER RR	Auto drive position
AC0955	SEAT RECLINING	Auto drive position
AC0956	ETS S/V	All mode AWD/4WD
AC0957	ETS S/V	All mode AWD/4WD

AC0958	DRIVE PWR DSTRBT TORQUE	All mode AWD/4WD
AC0959	SOLENOID RIGHT	All mode AWD/4WD
AC0960	SOLENOID LEFT	All mode AWD/4WD
AC0961	SELF DIAGNOSTIC MODE	4WAS(MAIN)/RAS/HICAS
AC0962	CANCEL SW IND	Sonar
AC0963	SONAR SENSOR	Sonar
AC0964	BUZZER	Sonar
AC0965	REAR PROXIMITY SENSOR TEST	Sonar
AC0966	FRONT BUZZER	Sonar
AC0967	LED	Sonar
AC0968	REAR BUZZER	Sonar
AC0969	DISPLAY CONTROL	Sonar
AC0970	PSM SONAR SENSOR	Sonar
AC0971	INDICATOR LAMP DRIVE	Lane camera
AC0972	SYSTEM ON LAMP DRIVE	Lane camera
AC0973	BUZZER DRIVE	Lane camera
AC0974	LANE DEPARTURE W/L	Lane camera
AC0975	LDP ON IND	Lane camera
AC0976	LDW ON IND	Lane camera
AC0977	LDP ON IND	Lane camera
AC0978	LOW BEAM TEST LEFT	Adaptive light
AC0979	LEVELIZER TEST	Adaptive light
AC0980	LOW BEAM TEST RIGHT	Adaptive light
AC0981	LOW BEAM TEST RIGHT	Adaptive light
AC0982	LOW BEAM TEST LEFT	Adaptive light
AC0983	EPS ACTIVE	AVM
AC0984	EXTERNAL BUZZER	AVM
AC0985	LED LH INDICATOR	AVM
AC0986	LED RH INDICATOR	AVM
AC0987	AVM BUZZER	AVM
AC0988	AIR ACTIVE	AVM
AC0989	WASH ACTIVE	AVM
AC0990	AIR & WASH ACTIVE	AVM
AC0991	COMPRESSOR	Air levelizer
AC0992	WARNNIG LAMP	Air levelizer
AC0993	EXHAUST SOLENOID	Air levelizer
AC0994	METER LAMP	Laser/radar
AC0995	POWER WINDOW (LH/RH)	Convertible roof
AC0996	TRUNK OPENER	Convertible roof
AC0997	ROOF SYSTEM	Convertible roof
AC0998	REAR WINDOW DEFOGGER	Convertible roof
AC0999	ROOF STATE OUTPUT(AUDIO)	Convertible roof
AC1000	HYDRAULIC PRESSURE RELEASE	Convertible roof
AC1001	5TH BOW SYSTEM	Convertible roof
AC1002	SOFT TOP SYSTEM	Convertible roof
AC1003	ROOF LATCHED LH/RH	Convertible roof
AC1004	STORAGE LID	Convertible roof
AC1005	TRUNK OPENER	Convertible roof
AC1006	REAR POWER WINDOW (RH)	Convertible roof
AC1007	FRONT POWER WINDOW (LH/RH)	Convertible roof
AC1008	ROOF SYSTEM	Convertible roof
AC1009	REAR POWER WINDOW (LH)	Convertible roof
AC1010	ROOF STATE OUTPUT(AUDIO)	Convertible roof
AC1011	STORAGE LID CLOSURE MOTOR	Convertible roof
AC1012	INSIDE FLAP MOTOR	Convertible roof
AC1013	OUTSIDE FLAP MOTOR	Convertible roof
AC1014	BUZZER 4 (CCM)	BSW/buzzer
AC1015	BUZZER 2 (CCM)	BSW/buzzer
AC1016	BUZZER 4 (ADAS)	BSW/buzzer
AC1017	BUZZER 3 (CCM)	BSW/buzzer
AC1018	BUZZER 1 (CCM)	BSW/buzzer
AC1019	BUZZER 3 (ADAS)	BSW/buzzer
AC1020	BUZZER 2 (ADAS)	BSW/buzzer
AC1021	BUZZER 1 (ADAS)	BSW/buzzer
AC1022	BSW/BSI WARNING LAMP	BSW/buzzer
AC1023	ICC BUZZER	BSW/buzzer
AC1024	ANC TEST TONE	ANC
AC1025	BSW/BSI INDICATOR DRIVE	Side radar left
AC1026	BSW/BSI INDICATOR DRIVE	Side radar right
AC1027	SLOW MODE	4WAS(front)
AC1028	lock operation	4WAS(front)
AC1029	ACCELERATOR PEDAL ACTUATOR TEST1	Accele pedal ACT
AC1030	ACCELERATOR PEDAL ACTUATOR TEST2	Accele pedal ACT
AC1031	WARNNIG LAMP	E-SUS
AC1032	EXHAUST SOLENOID	E-SUS
AC1033	COMPRESSOR	E-SUS
AC1034	FRONT RIGHT ACTUATOR	E-SUS
AC1035	REAR RIGHT ACTUATOR	E-SUS
AC1036	MODE LAMP	E-SUS
AC1037	REAR LEFT ACTUATOR	E-SUS

AC1038	FRONT LEFT ACTUATOR	E-SUS
AC1039	FOUR WHEEL ACTUATOR	E-SUS
AC1040	EHS VALVE	EHS/PKB
AC1041	EHS INDICATOR LAMP	EHS/PKB
AC1042	EHS WARNING BUZZER	EHS/PKB
AC1043	COMMAND STEERING ANGLE	Chassis control
AC1044	RR TIRE DISP	Chassis control
AC1045	ALC DISP	Chassis control
AC1046	RL TIRE DISP	Chassis control
AC1047	AEB DISP	Chassis control
AC1048	HDC DISP	Chassis control
AC1049	Stop lamp off relay 2 active	Chassis control
AC1050	COMMAND ST WHL FORC	Chassis control
AC1051	Brake actuator 1 mode 1	Chassis control
AC1052	ESS ACTIVE	Chassis control
AC1053	FR TIRE DISP	Chassis control
AC1054	ESS RELAY ACTIVE	Chassis control
AC1055	FL TIRE DISP	Chassis control
AC1056	Brake actuator 3 mode 3	Chassis control
AC1057	Brake HOLD DISP	Chassis control
AC1058	Brake actuator 3 mode 1	Chassis control
AC1059	MASTER WARNING ACTIVE	Chassis control
AC1060	Brake actuator 2 mode 2	Chassis control
AC1061	Stop lamp off relay 1 active	Chassis control
AC1062	Brake actuator 1 mode 3	Chassis control
AC1063	Brake actuator 3 mode 2	Chassis control
AC1064	Brake actuator 2 mode 3	Chassis control
AC1065	Brake actuator 2 mode 1	Chassis control
AC1066	Brake actuator 1 mode 2	Chassis control
AC1067	ATC 3 DISP	Chassis control
AC1068	ATC 1 DISP	Chassis control
AC1069	ALC LEVEL	Chassis control
AC1070	INTERRUPT DISP	Chassis control
AC1071	ATC 5 DISP	Chassis control
AC1072	ATC 2 DISP	Chassis control
AC1073	ALC SETTING	Chassis control
AC1074	TURN DISP	Chassis control
AC1075	VEHICLE DISP	Chassis control
AC1076	ARC DISP	Chassis control
AC1077	ATC 4 DISP	Chassis control
AC1078	DC/DC CONVERTER	EV/HEV
AC1079	INV WATER PUMP	EV/HEV
AC1080	POWER LIMITATION INDICATOR	EV/HEV
AC1081	INSPECTION MODE 1	EV/HEV
AC1082	COMPRESSION TEST	EV/HEV
AC1083	COOLING FAN SPD	EV/HEV
AC1084	VOLTAGE CONTROL	EV/HEV
AC1085	WATER PUMP	EV/HEV
AC1086	INSPECTION MODE 2	EV/HEV
AC1087	INSPECTION MODE 3	EV/HEV
AC1088	ENGINE CRANKING	EV/HEV
AC1089	INSPECTION MODE 5	EV/HEV
AC1090	WATER PUMP 2	EV/HEV
AC1091	WATER PUMP 1	EV/HEV
AC1092	ECO TREE	EV/HEV
AC1093	COOLING FAN	EV/HEV
AC1094	CHARGE STAT INDICATOR 3	EV/HEV
AC1095	CHARGE STAT INDICATOR 1	EV/HEV
AC1096	CHARGE STAT INDICATOR 2	EV/HEV
AC1097	PLUG IN INDICATOR	EV/HEV
AC1098	ECO INDICATOR	EV/HEV
AC1099	VOLTAGE CONTROL	EV/HEV
AC1100	12V BATTERY CHARGE W/L	EV/HEV
AC1101	DC/DC CONV DUTY	EV/HEV
AC1102	REVERSE LAMP RLY	EV/HEV
AC1103	F/S CHG RLY	EV/HEV
AC1104	EV SYSTEM W/L	EV/HEV
AC1105	READY INDICATOR	EV/HEV
AC1106	INSPECTION MODE 1	EV/HEV
AC1107	ALL SEG	PTC heater
AC1108	HVAC TEST	PTC heater
AC1109	Ck fuel prss & intrnl lktghtnss of fl sys	FSCM
AC1110	INDICATOR	Multi display
AC1111	ALTERNATOR DUTY	EMCM
AC1112	AUTO STOP START	EMCM
AC1113	MOTOR 2 CHECK	E-4wd
AC1114	E-4wd RELAY CHECK	E-4wd
AC1115	MOTOR 1 CHECK	E-4wd
AC1116	GENERETOR CHECK	E-4wd
AC1117	MAIN RELAY CHECK	E-4wd

AC1118	CLUTCH CHECK	E-4wd
AC1119	BATTERY HEATER	HV battery
AC1120	HEATER RELAY UNIT	HV battery
AC1121	HV BATTERY COOLING FAN	HV battery
AC1122	VSP speaker LH	VSP
AC1123	VSP speaker RH	VSP
AC1124	VSP OFF INDICATOR	VSP
AC1125	VSP SPEAKER	VSP
AC1126	START UP SOUND SPEAKER	VSP
AC1127	STOP LAMP OFF RELAY	Brake
AC1128	NORMAL CHARGE RELAY	Charger/PD module
AC1129	QUICK CHARGE RELAY	Charger/PD module
AC1130	QUICK CHARGE RELAY	Charger/PD module
AC1131	Quick charge permit sig circuit	Charger/PD module
AC1132	NORMAL CHARGE RELAY	Charger/PD module
AC1133	HSPL ILLUMINATION	Total illum C/U
AC1134	MOOD LAMP	Total illum C/U
AC1135	AMBIENCE LAMP	Total illum C/U
AC1136	PUDDLE LAMP	Total illum C/U
AC1137	PERSONAL LAMP-RR	Total illum C/U
AC1138	MAP LAMP-DR	Total illum C/U
AC1139	ENGINE SWITCH ILLUMINATION	Total illum C/U
AC1140	PERSONAL LAMP-RL	Total illum C/U
AC1141	MAP LAMP-AS	Total illum C/U
AC1142	FOOT LAMP	Total illum C/U
AC1143	LED	LEFT FRONT DOOR CONTROL UNIT
AC1144	Control unit reset	LEFT FRONT DOOR CONTROL UNIT
AC1145	Adjustment actuator motor via actuation	LEFT FRONT DOOR CONTROL UNIT
AC1146	Auto anti-dazzling mirror	LEFT FRONT DOOR CONTROL UNIT
AC1147	Door mirror defogger	LEFT FRONT DOOR CONTROL UNIT
AC1148	Front door exit and warning lamp left	LEFT FRONT DOOR CONTROL UNIT
AC1149	Front door handle illumination left	LEFT FRONT DOOR CONTROL UNIT
AC1150	Front door lock actuator left	LEFT FRONT DOOR CONTROL UNIT
AC1151	Front door switch illumination left	LEFT FRONT DOOR CONTROL UNIT
AC1152	Front power window motor left	LEFT FRONT DOOR CONTROL UNIT
AC1153	Front super lock actuator left	LEFT FRONT DOOR CONTROL UNIT
AC1154	Left blind spot assist warning	LEFT FRONT DOOR CONTROL UNIT
AC1155	Left outside mirror adjust	LEFT FRONT DOOR CONTROL UNIT
AC1156	Side turn signal lamp left	LEFT FRONT DOOR CONTROL UNIT
AC1157	LED	RIGHT FRONT DOOR CONTROL UNIT
AC1158	Control unit reset	RIGHT FRONT DOOR CONTROL UNIT
AC1159	Adjustment actuator motor via actuation	RIGHT FRONT DOOR CONTROL UNIT
AC1160	Door mirror defogger	RIGHT FRONT DOOR CONTROL UNIT
AC1161	Front door handle illumination right	RIGHT FRONT DOOR CONTROL UNIT
AC1162	Front door lock actuator right	RIGHT FRONT DOOR CONTROL UNIT
AC1164	Front super lock actuator right	RIGHT FRONT DOOR CONTROL UNIT
AC1165	Front door exit and warning lamp right	RIGHT FRONT DOOR CONTROL UNIT
AC1166	Outside mirror ambient lamp right	RIGHT FRONT DOOR CONTROL UNIT
AC1168	Right blind spot assist warning	RIGHT FRONT DOOR CONTROL UNIT
AC1169	Right outside mirror adjust	RIGHT FRONT DOOR CONTROL UNIT
AC1170	Side turn signal lamp right	RIGHT FRONT DOOR CONTROL UNIT
AC1171	Front passenger seat headrest motor	PASSENGER SEAT CONTROL UNIT
AC1172	Front passenger seat lifting motor (front)	PASSENGER SEAT CONTROL UNIT
AC1173	Front passenger seat lifting motor (rear)	PASSENGER SEAT CONTROL UNIT
AC1174	Front passenger seat reclining motor	PASSENGER SEAT CONTROL UNIT
AC1175	Front passenger seat sliding motor	PASSENGER SEAT CONTROL UNIT
AC1176	CD EJECT	Radio
AC1177	SUBWOOFER TEST	Radio
AC1178	MICROPHONE TEST	Radio
AC1179	Rear right-hand speaker line test	Radio
AC1180	Front right-hand speaker line test	Radio
AC1181	Front left-hand speaker line test	Radio
AC1182	Rear left-hand speaker line test	Radio
AC1183	BIVC 2	HAS
AC1184	Initial check	HAS
AC1185	SSV 2	HAS
AC1186	BSV	HAS
AC1187	BOVS	HAS
AC1188	BOVC 1	HAS
AC1189	BIVC 1	HAS
AC1190	SSV 1	HAS
AC1191	BOVC 2	HAS
AC1192	BIVS	HAS
AC1193	DISPLAY TEST	CIU
AC1194	On/off switch	CIU
AC1195	ECU PROGRAMMING ROUTINE	Cluster
AC1196	ECU --> TRANSPONDER RING CONNECTION TEST	Cluster
AC1197	COMPUTER INITIALISATION	Cluster
AC1198	Display	Cluster
AC1199	BUZZER	Cluster

AC1200	BUZZER	Cluster
AC1201	BUZZER	Cluster
AC1202	HAZARD LIGHTS LED	Cluster
AC1203	BUZZER	Cluster
AC1204	MATRIX DISPLAY	Cluster
AC1205	Oil change interval in months	Cluster
AC1206	INSTRUMENT PANEL WARNING LIGHTS	Cluster
AC1207	LIGHTING	Cluster
AC1208	INSTRUMENT PANEL W/L	Cluster
AC1209	INSTRUMENT PANEL NEEDLES	Cluster
AC1210	IGNITE HEATER	CHA
AC1211	SWITCH OFF THE HEATER	CHA
AC1212	REAR FAN : HOT	CHA
AC1213	MIXING MOTOR: ALL COLD	CHA
AC1214	DISTRIBUTION MOTOR: DEMISTING	CHA
AC1215	RECYCLING MOTOR: EXTERNAL AIR	CHA
AC1216	MIXING MOTOR: ALL HOT	CHA
AC1217	DISTRIBUTION MOTOR: VENT	CHA
AC1218	RECYCLING MOTOR: RECYCLING	CHA
AC1219	PASS. COMPARTMENT FAN ASSY	CHA
AC1220	REAR FAN:COLD	CHA
AC1221	CLUTCH	Auto slide door right

XTOOL

Special Functions List

Index NO.	Functions Name	System Name
SP0001	ENTER INJCTR CALIB DATA 2	Engine
SP0002	A/F SEN 1 LEARN CLR	Engine
SP0003	A/F SEN 2 LEARN CLR	Engine
SP0004	CONFIG CLR	Engine
SP0005	DPF DATA CLEAR	Engine
SP0006	INJ ADJ VAL CLR	Engine
SP0007	TC BOOST CONTROL ACTUATOR POSITION LEARNING	Engine
SP0008	Adaptives on etc actuator malfunction	Engine
SP0009	Writing data for replc ecu	Engine
SP0010	Ignition coil component	Engine
SP0011	Saving data for replc ecu	Engine
SP0012	EXHAUST THROTTLE VALVE PROGRAMMING	Engine
SP0013	LOW PRESSURE EGR VALVE PROGRAMMING	Engine
SP0014	H/P FUEL PUMP INITIAL STARTS COUNTER RESET	Engine
SP0015	H/P FUEL PUMP TOTAL STARTS COUNTER RESET	Engine
SP0016	TARGET IGN TIM HLD	Engine
SP0017	ENTER INJCTR CALIB DATA 2	Engine
SP0018	FUEL INJ QUANTITY LEARNING	Engine
SP0019	Start OBD test: Catalytic converter	Engine
SP0020	Start OBD test: O2 sensors	Engine
SP0021	ADAPTIVES AFTER REGENERATING PF	Engine
SP0022	ADAPTIVES ON AIR INTAKE FLAP MALFUNCTION 2	Engine
SP0023	AIR DAMPER VALVE PROGRAMMING(R044)	Engine
SP0024	AIR DAMPER VALVE PROGRAMMING(R044-2)	Engine
SP0025	VARIABLE VALVE TIMING	Engine
SP0026	AIR DAMPER VALVE PROGRAMMING(R088-2)	Engine
SP0027	EGR VALVE PROGRAMMING 2	Engine
SP0028	LOW PRESSURE EGR VALVE PROGRAMMING	Engine
SP0029	INTERVAL OF OIL CHANGE (OCS) OXIDATION	Engine
SP0030	OIL CHANGE INTERVAL (OCS): DILUTION	Engine
SP0031	Battery discharge current totalizing clear	Engine
SP0032	Misfire count (past)	Engine
SP0033	Misfire count (real-time)	Engine
SP0034	TEACH IN OF CAMSHAFT POSITION	Engine
SP0035	Teach in throttle valve actuator	Engine
SP0036	WASTE GATE REGULATION	Engine
SP0037	Common rail switching clear	Engine
SP0038	EGR control valve closed position learning	Engine
SP0039	VCR engine basis parts value 1 and 2 clear	Engine
SP0040	HIGH PRESSURE PUMP COUNTER (V344)	Engine
SP0041	INJECTION PUMP ADAPTATIVES (R077)	Engine
SP0042	EGR VALVE	Engine
SP0043	EGR/V LEARN CLR	Engine
SP0044	PRGRM REINITIALIZE	Engine
SP0045	PRES REG ADAPTIVE	Engine
SP0046	FUEL FLOW REGULATOR	Engine
SP0047	PRESSURE REGULATION ADAPTIVES	Engine
SP0048	SAVE COMPUTER DATA	Engine
SP0049	WRITE V.I.N.	Engine
SP0050	WRITE SAVED DATA	Engine
SP0051	INJ ADJ VAL REGIST	Engine
SP0052	INJECTOR	Engine
SP0053	CLSD THL POS LEARN	Engine
SP0054	DPF DATA CLEAR	Engine
SP0055	SERVC REGENERATION	Engine
SP0056	A/F SEN LEAN CLR	Engine
SP0057	Dif ex pre lrn CLR	Engine
SP0058	SERVICE REGENERATION	Engine
SP0059	PTO REGISTRATION	Engine
SP0060	DPF DATA CLEAR	Engine
SP0061	TP POS LEARN CLR	Engine
SP0062	EGR/V LEARN CLR	Engine
SP0063	TARGET IGN TIM ADJ	Engine
SP0064	AP POS LEARN CLR	Engine
SP0065	READ VIN	Engine
SP0066	IDL SPD REFFR	Engine
SP0067	ENTER INJCTR CALIB DATA	Engine
SP0068	ENTER INJCTR CALIB DATA	Engine
SP0069	DIFF EXH PRES. SEN	Engine
SP0070	FUEL SPLY PREV	Engine
SP0071	INCREMENT IDLE SPEED	Engine
SP0072	STP FUEL SPLY PREV	Engine
SP0073	DECREMENT IDLE SPEED	Engine
SP0074	VIN REGISTRATION	Engine
SP0075	RESET INJCTR ADAPTATIVE	Engine
SP0076	EGR ADAPTIVES	Engine
SP0077	RESET PUMP FORCEFEEDING	Engine

SP0078	SERVICE REGENE	Engine
SP0079	EXH V/T CONTROL LEARN	Engine
SP0080	INJ ADJ VAL CLR	Engine
SP0081	CONFIG CLR	Engine
SP0082	G SENSOR CALIBRATION	Engine
SP0083	EGR ADAPTIVES	Engine
SP0084	P/FLT DIFF PRS SEN	Engine
SP0085	TARGET IDLE RPM ADJ	Engine
SP0086	CO ADJUSTMENT	Engine
SP0087	V/T CONTROL LEARN	Engine
SP0088	SWIRL FLAP	Engine
SP0089	PROGRAM REINITIALIZE	Engine
SP0090	THERMOPLUNGER	Engine
SP0091	INLET FLAP	Engine
SP0092	EGR VALVE	Engine
SP0093	DECREMENT IDLE SPEED	Engine
SP0094	INCREMENT IDLE SPEED	Engine
SP0095	INCREMENT OF IDLE SPD	Engine
SP0096	Unlock INJECTOR CTRL	Engine
SP0097	SPEED LIMITER	Engine
SP0098	PROGRAMMED VALUES	Engine
SP0099	PREHEATER UNIT	Engine
SP0100	PUMP LEANT CLEAR	Engine
SP0101	lock INJECTOR CTRL	Engine
SP0102	INJECTOR	Engine
SP0103	Saving data for replc cpu	Engine
SP0104	ETHANOL M/R ADJ	Engine
SP0105	Writing data for replc cpu	Engine
SP0106	ECU MEMORY	Engine
SP0107	EGR VALVE PROGRAMMING	Engine
SP0108	STATIC TEST	Engine
SP0109	CHECK FUEL LINES	Engine
SP0110	FUEL PRESSURE RELEASE	Engine
SP0111	IGNITION TIMING ADJ	Engine
SP0112	TP SW/TP SEN idle posi ADJ	Engine
SP0113	IDLE AIR VOL LEARN	Engine
SP0114	SELF-LEARNING CONT	Engine
SP0115	TARGET IGN TIM ADJ	Engine
SP0116	TARGET IDLE RPM ADJ	Engine
SP0117	HIGH PRESSURE PUMP COUNTER	Engine
SP0118	STOP AND START FUNCTION	Engine
SP0119	AFT maintenance	Engine
SP0120	Reset fuel and timing learn tables	Engine
SP0121	Reset fuel consumption short term log	Engine
SP0122	RTCV actuator calibrate	Engine
SP0123	Engine serial number	Engine
SP0124	THERMOPLUNGER PROGRAMMING	Engine
SP0125	AIR FUEL RATIO SENSOR	Engine
SP0126	NOX TRAP	Engine
SP0127	CLUTCH PEDAL END STROKE	Engine
SP0128	H/P FUEL PUMP TOTAL STARTS COUNTER CLEAR	Engine
SP0129	FUEL RAIL PRESS LIMITING INJCTN COUNTR CLEAR	Engine
SP0130	AFTER CLUCH PEDAL SWITCH REPLACEMENT	Engine
SP0131	AFTER TURBOCHARGER REPLACEMENT	Engine
SP0132	AFTER TC SOLENOID VALVE REPLACEMENT	Engine
SP0133	AFTR ELECTRIC THRTTL CNTRL ACTUATOR RPLCMNT	Engine
SP0134	AFTER FUEL RAIL PRESSURE SENSOR REPLACEMENT	Engine
SP0135	AFTER CRANKSHAFT POS SENSOR REPLACEMENT	Engine
SP0136	AFTER FUEL INJECTOR REPLACEMENT	Engine
SP0137	AFTER HIGH PRESSURE FUEL PUMP REPLACEMENT	Engine
SP0138	AFTER CAMSHAFT POS SENSOR REPLACEMENT	Engine
SP0139	STARTER OPERATION COUNTER CLEAR	Engine
SP0140	WRITE STARTER OPERATION COUNT	Engine
SP0141	WRITE H/P FUEL PUMP TOTAL STARTS COUNT	Engine
SP0142	H/P FUEL PUMP TOTAL STARTS COUNTER CLEAR	Engine
SP0143	WASTEGATE ACTUATOR POSI LEARN VALUE CLEAR	Engine
SP0144	HIGH PRESSURE TURBINE BYPASS SOLENOID VALVE	Engine
SP0145	FUEL PUMP	Engine
SP0146	FUEL RAIL PRESSURE TEST	Engine
SP0147	ACTIVATE EVAP SYSTEM	Engine
SP0148	INHIBIT EVAP SYSTEM	Engine
SP0149	VACUUM PUMP	Engine
SP0150	ENGINE COOLANT BYPASS VALVE	Engine
SP0151	CAMSHAFT SENSOR PROGRAMMING	Engine
SP0152	Valve timing offset data writing	Engine
SP0153	Valve timing offset data clear	Engine
SP0154	CYLINDER 3 INJECTOR CODE	Engine
SP0155	CYLINDER 1 INJECTOR CODE	Engine
SP0156	CYLINDER 4 INJECTOR CODE	Engine
SP0157	CYLINDER 2 INJECTOR CODE	Engine

SP0158	Mixture ratio learning value clear	Engine
SP0159	INJECTOR LEARNING VALUE CLEAR	Engine
SP0160	Sc magnetic clutch engage count clear	Engine
SP0161	TURBOCHARGER PROGRAMMING	Engine
SP0162	SWIRL FLAP PROGRAMMING	Engine
SP0163	Low pressure egr valve programming	Engine
SP0164	AIR FLOW METER PROGRAMMING	Engine
SP0165	SWIRL FLAP	Engine
SP0166	INJECTION PUMP ADAPTATIVES	Engine
SP0167	MANIFOLD PRESSURE SENSOR PROGRAMMING	Engine
SP0168	PROGRAMMING THROTTLE LIMITS	Engine
SP0169	RICHNESS REGULATION PROGRAMMING	Engine
SP0170	ALTERNATOR SETPOINT VOLTAGE	Engine
SP0171	lock INJECTOR CONTROL	Engine
SP0172	Cumulative sub-battry dischg current clear	Engine
SP0173	Sub-starter & generator oper count clear	Engine
SP0174	EGR PROGRAMMING	Engine
SP0175	AIR DAMPER VALVE PROGRAMMING(R044)	Engine
SP0176	EXHAUST FLAP LOW SETTING	Engine
SP0177	AIR DAMPER VALVE PROGRAMMING(R088)	Engine
SP0178	Low pressure egr valve programming	Engine
SP0179	After particle filter regeneration with the diag tool.	Engine
SP0180	After replacement of the particle filter	Engine
SP0181	EGR BYPASS PROGRAMMING	Engine
SP0182	AIR FLOWMETER PROGRAMMING	Engine
SP0183	FUEL PUMP PROGRAMMING	Engine
SP0184	NUMBER OF STARTING 4	Engine
SP0185	NUMBER OF STARTING 2	Engine
SP0186	NUMBER OF STARTING 3	Engine
SP0187	NUMBER OF STARTING 1	Engine
SP0188	EXHAUST AIR FLAP PROGRAMMING	Engine
SP0189	RAIL PRESSURE SENSOR ADAPTIVES	Engine
SP0190	ADAPTIVES ON AIR INTAKE FLAP MALFUNCTION	Engine
SP0191	Active control engine mounting a	Engine
SP0192	Active control engine mounting b	Engine
SP0193	Reset of learned values of cmsft hall SEN	Engine
SP0194	Reset of contamination level of air filter	Engine
SP0195	REPLACE DIESEL PARTICULATE FILTER	Engine
SP0196	ZFC VALUE RESET	Engine
SP0197	EGR/V LEARN CLR	Engine
SP0198	DPF DATA CLEAR	Engine
SP0199	TP POS LEARN CLR	Engine
SP0200	Vvel pos SEN adj prep	Engine
SP0201	SERVC REGENERATION	Engine
SP0202	LEARNING	Engine
SP0203	HEATER PLUGS	Engine
SP0204	FLYWHL TGT PG	Engine
SP0205	After replacement of the p/filter	Engine
SP0206	After p/filter regen with diag tool	Engine
SP0207	ENTER INJECTOR CODES	Engine
SP0208	ENGINE ADAPTIVES	Engine
SP0209	ENGINE ADAPTIVES	Engine
SP0210	PUMP PRESSURE REGULATOR TYPE	Engine
SP0211	Alcohol level prog.	Engine
SP0212	ENGINE COOLANT BYPASS VALVE	Engine
SP0213	M/T NEUTRAL POS LEARN	Engine
SP0214	Commercial VHCL idle SPD mod	Engine
SP0215	NUMBER OF STARTING CYCLES	Engine
SP0216	WRT FUEL LEARN VALUE	Engine
SP0217	A/F INITIAL LEARNING	Engine
SP0218	CML B/DCHRG CRNT CLEAR	Engine
SP0219	STRT OPRTN CNTR CLEAR	Engine
SP0220	FAST IDLE SPEED MODIFICATION	Engine
SP0221	E/r air temp SEN learn CLR	Engine
SP0222	RAIL PRS SEN ADAPTIVES	Engine
SP0223	Df exh pres SEN learn CLR	Engine
SP0224	PRPR RICH SEN PROG	Engine
SP0225	Exh fuel inj data clear	Engine
SP0226	AFTER DPF REGENERATION	Engine
SP0227	AFTER DPF REPLACEMENT	Engine
SP0228	E/O CC/SL PRGRM	Engine
SP0229	CC/SL PRGRM	Engine
SP0230	EXHAUST FUEL INJECTOR CIRCUIT	Engine
SP0231	INJECTOR ADAPTIVES	Engine
SP0232	AIR DAMPER VALVE PROGRAMMING	Engine
SP0233	AIR PATH PROGRAMMING	Engine
SP0234	DPF RELATIVE PRESSURE SENSOR	Engine
SP0235	AVERAGE AIR TEMPERATURE	Engine
SP0236	OC DATA CLEAR	Engine
SP0237	OC DATA CLEAR	Engine

SP0238	Exh prsr SEN learn clear	Engine
SP0239	G SENSOR CALIBRATION	Engine
SP0240	Reset clutch data	Transmission
SP0241	Reset clutch data protection	Transmission
SP0242	Reset gearbox data	Transmission
SP0243	MEMORISATION OF SPEEDS	Transmission
SP0244	PROGRAM CLUTCH OPEN POSITION	Transmission
SP0245	WRITE DATE NEW CLTH FIT	Transmission
SP0246	Clutch Point	Transmission
SP0247	RESETTING OF ADAPTION VALUES	Transmission
SP0248	EMPTY PRESSURE RESERVOIR	Transmission
SP0249	EXHAUST CLUTCH FAST MODE	Transmission
SP0250	EXHAUST HYDRAULIC PUMP	Transmission
SP0251	EXHAUST TRANSMISSION	Transmission
SP0252	FILL PRESSURE RESERVOIR	Transmission
SP0253	FORCE INITIAL ABSOLUTE CLUTCH POSITION	Transmission
SP0254	GEAR SHIFTING	Transmission
SP0255	NEW CLUTCH INSTALLED	Transmission
SP0256	POSITION CLUTCH ACTUATOR	Transmission
SP0257	RECALCULATE FACTOR RDYN	Transmission
SP0258	RESET CLUTCH LOAD CONFIGURATION	Transmission
SP0259	SET DEFAULT CHARACTERISTIC LINE	Transmission
SP0260	START TRANSMISSION SELF ADAPTION	Transmission
SP0261	TEACH IN CLUTCH TOUCH POINT	Transmission
SP0262	NOTE OIL WEAR COUNTER	Transmission
SP0263	WRITE TRANSMISSION OIL CHANGE DATE	Transmission
SP0264	Write date of last after sales ope	Transmission
SP0265	VIN REGISTRATION	Transmission
SP0266	AUTO-ADAPTIVES	Transmission
SP0267	Wrte clth ini close pos	Transmission
SP0268	PROGRAM SLIP POINT	Transmission
SP0269	CLTH INI CLOSE POS	Transmission
SP0270	EEPROM CLEAR CONFIRM	Transmission
SP0271	CLTCH TOUCHPOINT ADJST	Transmission
SP0272	MAX. CLTCH STRK MSRMNT	Transmission
SP0273	TM ACTR SELF ADJST	Transmission
SP0274	G SENSOR CALIBRATION	Transmission
SP0275	Calib data	Transmission
SP0276	CONFORM CVTF DETERIORTN	Transmission
SP0277	PROGRAMMED VALUES	Transmission
SP0278	CALIB DATA	Transmission
SP0279	ENGINE Brake ADJ.	Transmission
SP0280	INITIALIZATION	Transmission
SP0281	Read ip chara - replacement tcm	Transmission
SP0282	Write ip chara - replacement tcm	Transmission
SP0283	FWD CLUTCH POINT LEARNING	Transmission
SP0284	Programming selection/engaging zones	Transmission
SP0285	Reinit. extreme cold rev gear engage	Transmission
SP0286	CLUTCH POINT LEARNING	Transmission
SP0287	ELECTRIC Q.P. AIR BLEEDING	Transmission
SP0288	ECO MODE RESET FUNCTION	Transmission
SP0289	ERASE MEMORY DATA	Transmission
SP0290	ERASE LEARNING VALUE	Transmission
SP0291	ERASE CALIBRATION DATA	Transmission
SP0292	G SENSOR CALIBRATION	Transmission
SP0293	Reset	ABS
SP0294	Steering Angle Sensor	ABS
SP0295	GEARBOX TYPE	ABS
SP0296	Improved grip function	ABS
SP0297	STEERING WHEEL ANGLE OFFSET SENSOR	ABS
SP0298	HILL START	ABS
SP0299	TRANSVERSE ACCELERATION SENSOR	ABS
SP0300	STROKE SENSOR CALIBRATION	ABS
SP0301	ACT OR DEACT ROLLER BENCH TEST MODE	ABS
SP0302	TEST MODE EXTEN	ABS
SP0303	Bld hyd unit brk circ	ABS
SP0304	CHECK TARGET TEETH	ABS
SP0305	Write date of last after sales ope	ABS
SP0306	WRITE VIN	ABS
SP0307	STEERING WHL ANGLE SEN	ABS
SP0308	VIN REGISTRATION	ABS
SP0309	VEHICLE PARAMETERS	ABS
SP0310	TEST MODE END	ABS
SP0311	TEST MODE	ABS
SP0312	Memory ERASING	ABS
SP0313	ST ANGLE SENSOR ADJUSTMENT	ABS
SP0314	SPEEDO INDEX	ABS
SP0315	DECEL G SEN CALIBRATION	ABS
SP0316	PRESS SEN CALIBRATION	ABS
SP0317	SIDE G SEN CALIBRATION	ABS

SP0318	SPEEDO INDEX	ABS
SP0319	St ang sen adjustment	ABS
SP0320	Reset	ABS
SP0321	HILL START	ABS
SP0322	ACCELERATION SENSOR	ABS
SP0323	TRANSVERSE ACCELERATION OFFSET SENSOR	ABS
SP0324	Steering wheel angle offset sensor	ABS
SP0325	LONGITUDINAL ACCELERATION SENSOR OFFSET	ABS
SP0326	Brake PRESSURE OFFSET SENSOR	ABS
SP0327	STEERING WHEEL ANGLE SENSOR	ABS
SP0328	LONGITUDINAL ACCELERATION SENSOR	ABS
SP0329	Bleed hydraulic unit and braking circuits	ABS
SP0330	VEH. SPEED AT INITIALISATION	ABS
SP0331	LONGITUDINAL ACCEL SEN	ABS
SP0332	ESP AUTO RECONNECTION THRSH	ABS
SP0333	ESP SENSOR PROGRAMMING	ABS
SP0334	Write date of last after sales ope	Air bag
SP0335	WRITE VIN	Air bag
SP0336	VIN REGISTRATION	Air bag
SP0337	lock ECU	Air bag
SP0338	Unlock ECU	Air bag
SP0339	Unlock COMPUTER	Air bag
SP0340	lock COMPUTER	Air bag
SP0341	Custom reset query	Meter/M&A
SP0342	TABLE INITIALIZATION ASSYST	Meter/M&A
SP0343	TEACH IN COMBINATION METER	Meter/M&A
SP0344	TRANSFER OF MANUFACTURER DEFAULT SETTINGS	Meter/M&A
SP0345	CUSTOMIZE RESET DIAGNOISE EQUIPMENT	Meter/M&A
SP0346	RESET GUIDELINE POSITION	Meter/M&A
SP0347	WARNING LAMP DIAGNOSIS	Meter/M&A
SP0348	FUEL METER DIAGNOSIS(ANALOG POINTER)	Meter/M&A
SP0349	TURN SIGNAL BUZZER DIAGNOSIS	Meter/M&A
SP0350	OUTSIDE AIR TEMPERATURE DIAGNOSIS	Meter/M&A
SP0351	W/L ON HISTORY	Meter/M&A
SP0352	WELCOME LIGHT SELECT	BCM
SP0353	R lamp timer logic set	BCM
SP0354	SWITCH MONITOR	BCM
SP0355	HEAD LIGHT TIMER	BCM
SP0356	VIN REGISTRATION	BCM
SP0357	SHORT CRANKING OUTPUT	BCM
SP0358	Room lamp on at lock	BCM
SP0359	ENGINE START BY I-KEY	BCM
SP0360	TRUNK/GLASS HATCH OPEN	BCM
SP0361	ANS BACK I-KEY lock	BCM
SP0362	Anti key lock in functi	BCM
SP0363	Lo-batt of key fob warn	BCM
SP0364	Room lamp timer set	BCM
SP0365	lock/Unlock BY I-KEY	BCM
SP0366	ANS BACK I-KEY Unlock	BCM
SP0367	D/lock VHCL SPD AJT	BCM
SP0368	HAZARD ANSWER BACK	BCM
SP0369	INSIDE ANT DIAGNOSIS	BCM
SP0370	HORN WITH KEYLESS lock	BCM
SP0371	ANSWER BACK FUNCTION	BCM
SP0372	Id regist	BCM
SP0373	AUTO lock SET	BCM
SP0374	Room lamp bat sav set	BCM
SP0375	PW DOWN SET	BCM
SP0376	PANIC ALARM SET	BCM
SP0377	MULTI ANSWER BACK SET	BCM
SP0378	ANTI-lock OUT SET	BCM
SP0379	DOOR lock-Unlock SET	BCM
SP0380	AUDIBLE TRAILER WARNING	BCM
SP0381	OLDEST ALARM TRIGGER	BCM
SP0382	PREVIOUS ALARM TRIGGER	BCM
SP0383	PANIC ALARM SET	BCM
SP0384	MULTI ANSWER BACK SET	BCM
SP0385	Room lamp bat sav set	BCM
SP0386	ANTI-lock OUT SET	BCM
SP0387	Ill delay set	BCM
SP0388	Custom a/light setting	BCM
SP0389	PW DOWN SET	BCM
SP0390	AUTO lock SET	BCM
SP0391	SECURITY ALARM SET	BCM
SP0392	Room lamp timer set	BCM
SP0393	Theft alm trg	BCM
SP0394	Battery saver set	BCM
SP0395	RETAINED PWR SET	BCM
SP0396	TRUNK OPEN SET	BCM
SP0397	LASTEST ALARM TRIGGER	BCM

SP0398	KEYLESS CHECK	BCM
SP0399	THEFT WARNING	BCM
SP0400	KEYLESS DI FLASH	BCM
SP0401	KEYLESS REGISTRATION	BCM
SP0402	PRE-ARM FAST FLASH	BCM
SP0403	SIREN FITTED	BCM
SP0404	TRUNK OPEN DELAY	BCM
SP0405	SELECTIVE Unlock	BCM
SP0406	AUTO RE-lock	BCM
SP0407	RR WIP RVRS SET	BCM
SP0408	SET R-DEF TIMER	BCM
SP0409	ANSWER BACK FUNCTION	BCM
SP0410	CONFIRM KEY FOB ID	BCM
SP0411	REMO CONT ID ERASUR	BCM
SP0412	Set i/l d-Unlock intcon	BCM
SP0413	SET R/DEF -ENG INTCON	BCM
SP0414	Wiper speed setting	BCM
SP0415	lock/Unlock BY I-KEY	BCM
SP0416	HAZARD ANSWER BACK	BCM
SP0417	Anti key lock in function	BCM
SP0418	HORN WITH KEYLESS lock	BCM
SP0419	Reset setting value	BCM
SP0420	Back to initial value	BCM
SP0421	Security door lock set	BCM
SP0422	HORN CHIRP SET	BCM
SP0423	Custom a/light setting	BCM
SP0424	Room lamp off time set	BCM
SP0425	Room lamp on time set	BCM
SP0426	Hazard lamp set	BCM
SP0427	REMO CONT ID REGIST	BCM
SP0428	St ang sen adjustment	BCM
SP0429	ID READ	BCM
SP0430	REMO CONT ID ERASUR	BCM
SP0431	REMO CONT ID REGIST	BCM
SP0432	REMO CONT ID CONFIR	BCM
SP0433	CARGO DOOR SET	BCM
SP0434	Box i-key operation mode set	BCM
SP0435	AUTO ACC FNCTN (AUDIO/NAVI SET AFTER IGN OFF)	BCM
SP0436	AUTO Unlock FUNCTION	BCM
SP0437	AUTO Unlock TYPE	BCM
SP0438	ANSWER BACK	BCM
SP0439	IGN/ACC BATTERY SAVER	BCM
SP0440	RAIN SENSOR	BCM
SP0441	TWILIGHT On	BCM
SP0442	AUTO lock FUNCTION	BCM
SP0443	REMOTE ENGINE STARTER	BCM
SP0444	FR RR DRIP	BCM
SP0445	WIPER LINK	BCM
SP0446	FOG LAMP OVERRIDE	BCM
SP0447	RESET SETTING VALUE	BCM
SP0448	ANSWERBACK I-KEY lock Unlock	BCM
SP0449	SECURITY ALARM SET	BCM
SP0450	ANSWERBACK KEYLESS lock Unlock	BCM
SP0451	Answer back i-key lock Unlock	BCM
SP0452	AUTOMATIC DOOR Unlock SELECT	BCM
SP0453	DAYTIME RUNNING LIGHT SETTING	BCM
SP0454	Rear wiper link with reverse setting	BCM
SP0455	3-TIME FLASHER SETTING	BCM
SP0456	SIGNATURE LIGHT SETTING	BCM
SP0457	SIREN SET	BCM
SP0458	WELCOME LIGHT OP SET	BCM
SP0459	RESET SETTING VALUE	BCM
SP0460	CONFIRM DONGLE ID	BCM
SP0461	AUTOMATIC DOOR Unlock SELECT	BCM
SP0462	AUTOMATIC lock/Unlock SELECT	BCM
SP0463	AUTOMATIC DOOR lock SELECT	BCM
SP0464	Retractable mirror set	BCM
SP0465	AUTO LIGHT LOGIC SET	BCM
SP0466	DROP WIPE FUNC SET	BCM
SP0467	Rain SEN wip func set	BCM
SP0468	INTELLIGENT KEY LINK SET	BCM
SP0469	SECURITY ALARM SET (SIREN)	BCM
SP0470	HEADLAMP WASHER AUTO SET	BCM
SP0471	SWITCH TPMS BETWEEN On/Off	BCM
SP0472	BLOW SET	HVAC
SP0473	REC MEMORY SET	HVAC
SP0474	FRE MEMORY SET	HVAC
SP0475	TEMP SET CORRECT	HVAC
SP0476	Comp oprt set at def mode (tim/rmt climt cont)	HVAC
SP0477	CLEAN SW SET	HVAC

SP0478	GAS SENSOR ADJUSTMENT	HVAC
SP0479	AROMA DIFFUSER SETTING	HVAC
SP0480	BLOWER MOTOR SETTING	HVAC
SP0481	FRAGRANCE SETTING	HVAC
SP0482	AROMA SETTING	HVAC
SP0483	REAR TEMP SET CORRECT	HVAC
SP0484	AIR FLOW REDUCTION SETTING	HVAC
SP0485	Stop/start system operation cond setting	HVAC
SP0486	AIR INLET CHANGE SETTING	HVAC
SP0487	Target evaporator temp upper limit setting	HVAC
SP0488	Door motor starting position reset	HVAC
SP0489	Target max rpm adj at pre-climate	HVAC
SP0490	Target max rpm adj at idl	HVAC
SP0491	RESETTING INTERNAL PROTECTION	IPDM E/R
SP0492	SENSOR INITIALISE	Head lamp levelizer
SP0493	SENSOR CUSTOMIZE	Head lamp levelizer
SP0494	CAUSE OF AUTO-CANCEL	ICC/ADAS
SP0495	CAUSE OF AUTO-CANCEL 3	ICC/ADAS
SP0496	CAUSE OF AUTO-CANCEL 2	ICC/ADAS
SP0497	CAUSE OF AUTO-CANCEL 1	ICC/ADAS
SP0498	Write date of last after sales ope	Multi AV
SP0499	WRITE VIN	Multi AV
SP0500	VIN REGISTRATION	Multi AV
SP0501	St ang sen adjustment	Multi AV
SP0502	ECU MEMORY	Multi AV
SP0503	St ang sen adjustment	Multi AV
SP0504	REVERSING CAMERA CALIBRATION	Multi AV
SP0505	SENSOR CALIBRATION	EPS/DAST 3
SP0506	ST/ANGLE ADJUSTMENT	EPS/DAST 3
SP0507	St ang sen adjustment	EPS/DAST 3
SP0508	Switching the status of TPMS between On and Off	Air pressure monitor
SP0509	Id regist	Air pressure monitor
SP0510	Id regist	Air pressure monitor
SP0511	TRUNK/GLASS HATCH OPEN	Intelligent key
SP0512	SHORT CRANKING OUTPUT	Intelligent key
SP0513	ENGINE START BY I-KEY	Intelligent key
SP0514	lock/Unlock BY I-KEY	Intelligent key
SP0515	AUTO lock SET	Intelligent key
SP0516	DOOR lock-Unlock SET	Intelligent key
SP0517	TRUNK OPEN DELAY	Intelligent key
SP0518	ANSWER BACK FUNCTION	Intelligent key
SP0519	KEYLESS FUNCTION	Intelligent key
SP0520	Take out from window warn	Intelligent key
SP0521	I-KEY FUNCTION	Intelligent key
SP0522	Low batt of key fob warn	Intelligent key
SP0523	CONFIRM KEY FOB ID	Intelligent key
SP0524	ENGINE START BY I-KEY	Intelligent key
SP0525	P/W DOWN DELAY	Intelligent key
SP0526	PANIC ALARM DELAY	Intelligent key
SP0527	lock/Unlock BY I-KEY	Intelligent key
SP0528	POWER SLIDE DOOR DELAY	Intelligent key
SP0529	TRUNK OPEN DELAY	Intelligent key
SP0530	AUTO RElock TIMER	Intelligent key
SP0531	Answer back with i-key Unlock	Intelligent key
SP0532	HAZARD ANSWER BACK	Intelligent key
SP0533	Anti key lock in function	Intelligent key
SP0534	LUG ROOM ENGINE START	Intelligent key
SP0535	Answer back with i-key lock	Intelligent key
SP0536	HORN WITH KEYLESS lock	Intelligent key
SP0537	SELECTIVE Unlock FUNCTION	Intelligent key
SP0538	ANSWERBACK I-KEY lock Unlock	Intelligent key
SP0539	ANSWERBACK KEYLESS lock Unlock	Intelligent key
SP0540	Answer back i-key lock Unlock	Intelligent key
SP0541	SEAT SLIDE VOLUME SET	Auto drive position
SP0542	EXIT SEAT SLIDE SETTING	Auto drive position
SP0543	EXIT TILT SETTING	Auto drive position
SP0544	CLUTCH/F RLS LIM ADJ	All mode AWD/4WD
SP0545	UNIT CHARACTERISTICS WRITE	All mode AWD/4WD
SP0546	OIL DETERIORATION INFO RESET	All mode AWD/4WD
SP0547	lock SLEEVE SENSOR INITIALIZE	All mode AWD/4WD
SP0548	lock SLEEVE SENSOR LEARNING	All mode AWD/4WD
SP0549	START CALIBRATION	All mode AWD/4WD
SP0550	UNIT CHARACTERISTICS DATA	All mode AWD/4WD
SP0551	UNIT CHARACTERISTICS WRITE	All mode AWD/4WD
SP0552	WRITE VIN	Sonar
SP0553	TRAILER HITCH MODE	Sonar
SP0554	CENTER SEN DISTANCE SET	Sonar
SP0555	VOLUME SETTING	Sonar
SP0556	CORNER SEN DISTANCE SET	Sonar
SP0557	VOLUME SETTING	Sonar

SP0558	TIRE DIAMETER ADJUSTMENT	Sonar
SP0559	PARKING WIDTH LEVEL SETTING	Sonar
SP0560	CAUSE OF AUTO-CANCEL	Lane camera
SP0561	LEVELIZER ADJUSTMENT	Adaptive light
SP0562	St ang sen adjustment	Adaptive light
SP0563	STEERING ANGLE SENSOR ADJUSTMENT	AVM
SP0564	PREDICTIVE COURSE LINE DISPLAY	AVM
SP0565	INITIALIZE CAMERA IMAGE CALIBRATION	AVM
SP0566	Select language of warning message	AVM
SP0567	NON-VIEWABLE AREA REMINDER	AVM
SP0568	PRE-ARM FAST FLASH	Smart entrance
SP0569	SELECTIVE Unlock	Smart entrance
SP0570	ADJ GUIDELINE POSITION	Rearview camera
SP0571	SELCT GUIDELINE PATTERN	Rearview camera
SP0572	SELCT GUIDELINE PATTERN	S/blind camera
SP0573	ADJ GUIDELINE POSITION	S/blind camera
SP0574	CALIBRATE ALL	Motor assist
SP0575	ROOF STATE RESET	Convertible roof
SP0576	ROOF LATCH	Convertible roof
SP0577	TRUNK OPENER	Convertible roof
SP0578	ROOF STATE LEARNING	Convertible roof
SP0579	FLIPPER DOOR	Convertible roof
SP0580	ROOF/TRUNK/PARCEL SHELF	Convertible roof
SP0581	ANC SETTING	ANC
SP0582	ACTIVATE OPERATION	Side radar left
SP0583	ACTIVATE OPERATION	Side radar right
SP0584	Zero point reset function	Occupant detection
SP0585	STANDARD HEIGHT LEVEL	E-SUS
SP0586	CLEAR HEIGHT INI	E-SUS
SP0587	ADJUST HEIGHT INI	E-SUS
SP0588	Parking brake brake in (drag on)	EHS/PKB
SP0589		Telematics
SP0590	WRITE VIN DATA	Telematics
SP0591	SAVE VIN DATA	Telematics
SP0592	TCU ACTIVATE SETTING	Telematics
SP0593	WRITE VIN (MANUAL INPUT)	Telematics
SP0594		Telematics
SP0595	SVT SETTING	SVT
SP0596	Battery gradual cap loss data clear	EV/HEV
SP0597	programming of adblue injector	ADCM
SP0598	radiator fan active request (air conditioner	ADCM
SP0599	radiator fan active request (engine control module	ADCM
SP0600	SCR CAT AMOUNT OF UREA ADSORPT DATA CLEAR	ADCM
SP0601	SAVE COMPUTER DATA	ADCM
SP0602	WRITE SAVED DATA	ADCM
SP0603	VIN REGISTRATION	ADCM
SP0604	UREA INJECTOR LEARNING VALUE CLEAR	ADCM
SP0605	UREA PUMP LEARNINNG VALUE CLEAR	ADCM
SP0606	UREA TANK UNIT ASSEMBLY LEARNING VALUE CLEAR	ADCM
SP0607	ADBLUE DOS MOD CATALYST	ADCM
SP0608	Cumulative sub-battry dischg current clear	EMCM
SP0609	CML B/DCHRG CRNT CLEAR	EMCM
SP0610	STRT OPRTN CNTR CLEAR	EMCM
SP0611	Reset auto back door status	Auto back door
SP0612	DOOR OPENING RETRACT RETRY	Precrash seatbelt
SP0613	P POSITION LEARNING VALUE CLEAR	Shift
SP0614	AMBIENCE LAMP FADE-IN/OUT	Total illum C/U
SP0615	PUDDLE LAMP FADE-IN/OUT	Total illum C/U
SP0616	FOOT LAMP FADE-IN/OUT	Total illum C/U
SP0617	E/G SW ILLUMI FADE-IN/OUT	Total illum C/U
SP0618	MOOD LAMP FADE-IN/OUT	Total illum C/U
SP0619	MAP&PERSNL LAMP FADE-IN/OUT	Total illum C/U
SP0620	E/g SW ill heart beat function	Total illum C/U
SP0621	HSPL ILLUMINATION FADE-IN/OUT	Total illum C/U
SP0622	Power window initialization	RIGHT FRONT DOOR CONTROL UNIT
SP0623	WRITE VIN	Radio
SP0624	Write date of after sales operation	Radio
SP0625	VIN REGISTRATION	BAC
SP0626	HOUR SETTING	CIU
SP0627	WRITE VIN	CIU
SP0628	VIN REGISTRATION	CIU
SP0629	ECU MEMORY	CIU
SP0630	WRITE VIN	Cluster
SP0631	VIN REGISTRATION	Cluster
SP0632	Oil change range:current value in months	Cluster
SP0633	Oil change interval in months	Cluster
SP0634	Oil change range: in km	Cluster
SP0635	OIL CHG INT(km)	Cluster
SP0636	UPDATE ODOMETER	Cluster
SP0637	Write date of last after sales ope	MM conn

SP0638	WRITE VIN	MM conn